### TECHNICAL MANUAL

## AVIATION UNIT AND INTERMEDIATE MAINTENANCE MANUAL

# ARMY MODEL OH-58A AND OH-58C HELICOPTERS

"Approved for public release; distribution is unlimited."

This manual supersedes TM 55-1520-228-23-1 dated 4 August 1978, including changes 1 through 51.

HEADQUARTERS, DEPARTMENT OF THE ARMY

**CHANGE** 

NO. 27

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 18 July 1997

#### Aviation Unit and Intermediate Maintenance Manual

#### ARMY MODEL OH-58A AND OH-58C HELICOPTERS

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

### TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-66.3/(1-66.4 blank)	1-66.3/(1-66.4 blank)
6-125 through 6-128	6-125 through 6-128
	6-128.1 and 6-128.2
8-31 and 8-32	8-31 and 8-32
	8-36.1/(8-36.2 blank)

2. Retain this sheet in front of manual for reference purposes.

#### By Order of the Secretary of the Army:

Official:

DENNIS J. REIMER General, United States Army Chief of Staff

JOEL B. HUDSON Administrative Assistant to the Secretary of the Army 03871

#### DISTRIBUTION:

TM 55-1520-228-23-1 C 26

**CHANGE** 

NO. 26

HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D.C., 3 December 1996

Aviation Unit and Intermediate Maintenance Manual

## ARMY MODEL OH-58A AND OH-58C HELICOPTERS

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages 1-57 and 1-58 1-66.1 and 1-66.2 ----1-67 and 1-68 Insert pages 1-57 and 1-58 1-66.1 and 1-66.2 1-66.3/(1-66.4 blank) 1-67 and 1-68

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

DENNIS J. REIMER General, United States Army Chief of Staff

Official:

JOEL B.HUDSON Administrative Assistant to the Secretary of the Army 02807

#### DISTRIBUTION:

TM 55-1520-228-23-1 C 25

**CHANGE** 

NO. 25

HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D.C., 4 October 1996

#### Aviation Unit and Intermediate Maintenance Manual

## ARMY MODEL OH-58A AND OH-58C HELICOPTERS

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
2-29 and 2-30	2-29 and 2-30
6-63 and 6-64	6-63 and 6-64
9-57 and 9-58	9-57 and 9-58

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

DENNIS J. REIMER General, United States Army Chief of Staff

Official:

JOEL B. HUDSON Administrative Assistant to the Secretary of the Army 02678

### **DISTRIBUTION:**

**CHANGE** 

NO. 24

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 31 August 1996

### Aviation Unit and Intermediate Maintenance Manual

#### ARMY MODEL OH-58A AND OH-58C HELICOPTERS

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

3. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-9 and 1-10	1-9 and 1-10
1-13 through 1-20	1-13 through 1-20
1-24.1/(1-24.2 blank)	1-24.1/(1-24.2 blank)
1-31 and 1-32	1-31 and 1-32
1-59 and 1-60	1-59 and 1-60
1-67 and 1-68	1-67 and 1-68
2-5 and 2-6	2-5 and 2-6
2-27 and 2-28	2-27 and 2-28
2-28.1/(2-28.2 blank)	2-28.1/(2-28.2 blank)
2-37 and 2-38	2-37 and 2-38
2-105 and 2-106	2-105 and 2-106
	2-106.1/(2-106.2 blank)
2-107 through 2-110	2-107 through 2-110
2-137 through 2-140	2-137 through 2-140
3-1 through 3-4	3-1 through 3-4
3-4.1 and 3-4.2	3-4.1 and 3-4.2
3-13 through 3-16	3-13 through 3-16
	4-6.1/(4-6.2 blank)
4-9 and 4-10	4-9 and 4-10
4-17 and 4-18	4-17 and 4-18
4-22.3 and 4-22.4	4-22.3 and 4-22.4
4-23 and 4-24	4-23 and 4-24
4-27 and 4-28	4-27 and 4-28
5-13 and 5-14	5-13 and 5-14

#### TM 55-1520-228-23-1 C 24

Remove pages 5-127 and 5-128 5-157 and 5-158 5-169 and 5-170 6-3 through 6-6 6-13 and 6-14 6-27 and 6-28 6-37 and 6-38 6-91 through 6-94 7-21 through 7-24 8-5 through 8-8 9-19 and 9-20 9-20.3 and 9-20.4 9-25 and 9-26 2-27 and 9-28 -----9-61 and 9-62 9-71 and 9-72 9-108.1 through 9-108.4 9-108.13 and 9-108.14

**Insert pages** 5-127 and 5-128 5-157 and 5-158 5-169 and 5-170 6-3 through 6-6 6-13 and 6-14 6-27 and 6-28 6-37 and 6-38 6-91 through 6-94 7-21 through 7-24 8-5 through 8-8 9-19 and 9-20 9-20.3 and 9-20.4 9-25 and 9-26 9-27 and 9-28 9-28.1/(9-28.2 blank) 9-61 and 9-62 9-71 and 9-72 9-108.1 through 9-108.4 9-108.13 and 9-108.14

2. Retain this sheet in front of manual for reference purposes.

#### By Order of the Secretaries of the Army:

Official:

DENNIS J. REIMER General, United States Army Chief of Staff

JOEL B. HUDSON Administrative Assistant to the Secretary of the Army 02349

### DISTRIBUTION:

TM 55-1520-22823-1 C 23

**CHANGE** 

NO. 23

HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D.C., 11 June 1996

#### Aviation Unit and Intermediate Maintenance Manual

### Army Model OH-58A and OH-58C Helicopters

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-1 and 1-2	1-1 and 1-2
	1-56.1/(1-56.2 blank)
2-1 and 2-2	2-1 and 2-2
8-9 and 8-10	8-9 and 8-10
8-37 and 8-38	8-37 and 8-38
9-13 through 9-16	9-13 through 9-16

2. Retain this sheet in front of manual for reference purposes.

#### By Order of the Secretary of the Army:

DENNIS J. REIMER General, United States Army Chief of Staff

Official:

JOEL B. HUDSON Administrative Assistant to the Secretary of the Army 01874

### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no. 0226, requirements for TM 55-1520-228-23-1.

TM 55-1520-228-23-1 C22

**CHANGE** 

NO. 22

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 15 JULY 1995

### Aviation Unit and Intermediate Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 55-1520-228-23-1,28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages Insert pages 1-1 and 1-2 1-1 and 1-2 1-51 and 1-52 1-51 and 1-52 1-55 through 1-58 1-55 through 1-58 1-63 and 1-64 1-63 and 1-64 1-66.1 and 1-66.2 1-66.1 and 1-66.2 4-31 and 4-32 4-31 and 4-32 4-32.1/(4-32.2 blank 4-38.1 and 4-38.2 4-39 and 4-40 4-39 and 4-40 4-40.1 and 4-40.2 4-50.1/(4-50.2blank) 4-50.1/(4-50.2blank) 5-9 through 5-12 5-9 through 5-12 5-139 and 5-140 5-139 and 5-140 8-37 through 8-42 8-37 through 8-42

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

DENNIS J. REIMER General, United States Army Chief of Staff

Official:

Acting Administrative Assistant to the Secretary of the Army

#### **DISTRIBUTION:**

TM55-1520-228-23-1 C 21

**CHANGE** 

NO. 21

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 15 September 1994

### Aviation Unit and Intermediate Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
5-17 and 5-18	5-17 and 5-18
5-40.1 and 5-40.2	5-40.1 and 5-40.2
5-43 and 5-44	5-43 and 5-44
5-90 and 5-94	5-93 and 5-94
5-137 and 5-138	5-137 and 5-138
5-147 and 5-148	5-147 and 5-148
5-155 and 5-156	5-155 and 5-156

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretafy of the Army:

GORDON R. SULLIVAN General, United States Army Chief of Staff

Official:

MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no. 0226, requirements for TM55-1520-228-23-1.

TM 55-1520-228-23-1 C 20

CHANGE

NO. 20

HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D.C., 26 JULY 1994

### Aviation Unit and Intermediate Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

 Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-66.1 and 1-66.2	1-66.1 and 1-66.2
3-3 and 3-4	3-3 and 3-4
	3-4.1 and 3-4.2
3-11 through 3-14	3-11 through 3-14
	3-14.1 and 3-14.2
5-67 and 5-68	5-67 and 5-68
40 kg 40 m (d) 40 m (d) 40 m (m (m)	5-68.1/(5-68.2 blank)
5-69 and 5-70	5-69 and 5-70

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official:

MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army

GORDON R. SULLIVAN General, United States Army Chief of Staff

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no. 0226, requirements for TM 55-1520-228-23-1.

TM 55-1520-228-23-1 C 19

CHANGE

NO. 19

**HEADQUARTERS** DEPARTMENT OF THE ARMY WASHINGTON, D.C., 1 MARCH 1994

Aviation Unit and Intermediate Maintenance Manual

> ARMY MODEL OH-58A AND OH-58C **HELICOPTERS**

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-23 and 1-24	1-23 and 1-24
1-61 and 1-62	1-61 and 1-62
1-66.1/(1-66.2 blank)	1-66.1 and 1-66.2
5-11 and 5-12	5-11 and 5-12
5-17 and 5-18	5-17 and 5-18
5-18.1/(5-18.2 blank)	5-18.1 and 5-18.2
8-43 and 8-44	8-43 and 8-44
9-63 and 9-64	9-63 and 9-64

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official:

GORDON R. SULLIVAN General, United States Army Chief of Staff

Mitta of Samta MILTON H. HAMILTON Administrative Assistant to the Secretary of the Army 05817

#### DISTRIBUTION:

CHANGE

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 28 February 1994

NO. 18

### Aviation Unit and Intermediate Maintenance Manual

## ARMY MODEL OH-58A AND OH-58C HELICOPTERS

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimit

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material i indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
a and b	a through c/(d blank)
i and ii	i and ii
1-1 and 1-2	1-1 and 1-2
1-7 through 1-10	1-7 through 1-10
	1-13 through 1-20
1-21 and 1-22	1-21 and 1-22
1-24.1/(1-24.2 blank)	1-24.1/(1-24.2 blank)
1-29 through 1-32	1-29 through 1-32
1-34.1 and 1-34.2	1-34.1 and 1-34.2
1-39 and 1-40	1-39 and 1-40
1-43 and 1-44	1-43 and 1-44
1-47 and 1-48	1-47 and 1-48
1-51 and 1-52	1-51 and 1-52
1-57 through 1-60	1-57 through 1-60
1-63 through 1-66	1-63 through 1-66
2-1 and 2-2	2-1 and 2-2
	2-2.1/(2-2.2 blank)
2-5 and 2-6	2-5 and 2-6
	2-11 through 2-16
2-25 and 2-26	2-25 and 2-26
2-29 and 2-30	2-29 and 2-30
	2-39 through 2-44
2-50.1 through 2-50.7/	2-50.1 through 2-50.7/
(2-50.8 blank)	(2-50.8 blank)
2-51 and 2-52	2-51 and 2-52
2-71 and 2-72	2-71 and 2-72
2-77 and 2-78	2-77 and 2-78
2-101 and 2-102	2-101 and 2-102
2-111 and 2-112	2-111 and 2-112
2-115 and 2-116	2-115 and 2-116
2-121 and 2-122	2-121 and 2-122
	2-131 through 2-140
2-143 and 2-144	2-143 and 2-144

### Remove pages

### Insert pages

3-1 through 3-6	3-1 through 3-6
3-9 through 3-14	3-9 through 3-14
3-17 through 3-24	3-17 through 3-24
4-5 and 4-6	4-5 and 4-6
4-11 through 4-14	4-11 through 4-14
4-17 through 4-22	4-17 through 4-22
4-23 and 4-24	4-23 and 4-24
4-31 through 4-34	4-31 through 4-34
4-37 through 4-42	4-37 through 4-42
4 57 CHIOUGH 4 42	4-42.1 and 4-42.2
4-43 and 4-44	4-43 and 4-44
4-49 and 4-50	4-49 and 4-50
4-50.1/(4-50.2 blank)	4-50.1/(4-50.2 blank)
4-50.1/(4-50.2 blank) 4-52.1/(4-52.2 blank)	4-52.1/(4-52.2 blank)
4-53 and 4-54	4-53 and 4-54
5-1 and 5-2	5-1 and 5-2
5-7 through 5-16	5-7 through 5-16
5-25 through 5-30	5-25 through 5-30
5-35 and 5-36	5-35 and 5-36
5-39 and 5-40	5-39 and 5-40
5-40.1/(5-40.2 blank)	5-40.1 and 5-40.2
5-40:17 (5-40:2 blank) 5-41 through 5-44	5-41 through 5-44
5-55 through 5-58	5-55 through 5-58
5-65 and 5-66	5-65 and 5-66
5-69 and 5-70	5-69 and 5-70
5-75 and 5-76	5-75 and 5-76
5-79 and 5-80	5-79 and 5-80
5-87 and 5-88	5-87 and 5-88
5-93 and 5-94	5-93 and 5-94
5-99 through 5-102	5-99 through 5-102
5-105 through 5-108	5-105 through 5-108
5-123 and 5-124	5-123 and 5-124
5-129 through 5-134	5-129 through 5-134
5-137 through 5-142	5-137 through 5-142
5-144.1/(5-144.2 blank)	5-144.1/(5-144.2 blank)
5-145 and 5-146	5-145 and 5-146
5-153 and 5-154	5-153 and 5-154
5-157 through 5-160	5-157 through 5-160
5-167 and 5-168	5-167 and 5-168
	5-168.1/(5-168.2 blank)
5-169 and 5-170	5-169 and 5-170
5-183 and 5-184	5-183 and 5-184
5-191 through 5-194	5-191 through 5-194
6-17 through 6-26	6-17 through 6-26
6-27 and 6-28	6-27 and 6-28
6-35 through 6-42	6-35 through 6-42

### Remove pages Insert pages

6-45 and 6-46 6-45 and 6-46 6-49 through 6-54 6-49 through 6-54 6-54.1/(6-54.2 blank)6-55 through 6-58 6-55 through 6-58 6-61 through 6-64 6-61 through 6-64 6-67 through 6-72 6-67 through 6-72 6-79 through 6-86 6-79 through 6-86 6-89 through 6-102 6-89 through 6-102 6-105 and 6-106 6-105 and 6-106 6-109 through 6-112 6-109 through 6-112 6-115 and 6-116 6-115 and 6-116 6-117 and 6-118 6-117 and 6-118 6-125 through 6-128 6-125 through 6-128 6-131 and 6-132 6-131 and 6-132 7-9 through 7-12 7-9 through 7-12 7-21 through 7-24 7-21 through 7-24 7-27 through 7-30 7-27 through 7-30 8-1 through 8-12 8-1 through 8-12 8-15 and 8-16 8-15 and 8-16 8-16.1/(8-16.2 blank) 8-16.1/(8-16.2 blank)8-19 through 8-24 8-19 through 8-24 8-31 and 8-32 8-31 and 8-32 8-35 through 8-38 8-35 through 8-38 8-45 and 8-46 8-45 and 8-46 9-1 and 9-2 9-1 and 9-2 9-21 and 9-22 9-21 and 9-22 9-35 and 9-36 9-35 and 9-36 9-87 and 9-88 9-87 and 9-88 9-108.7 and 9-108.8 9-108.7 and 9-108.8 Index 13 through Index 16 Index 13 through Index 16 Index 19 and Index 20 Index 19 and Index 20 Index 29 and Index 30 Index 29 and Index 30 Index 41 through Index 44 Index 41 through Index 44 Index 51 and Index 52 Index 51 and Index 52

2. Retain these sheets in front of manual for reference purposes.

TM 55-1520-228-23-1 C 18

By Order of the Secretary of the Army:

GORDON R. SULLIVAN General, United States Army Chief of Staff

Official:

Milto H. Samello MILTON H. HAMILTON Administrative Assistant to the Secretary of the Army

#### DISTRIBUTION:

x 43

### **URGENT**

TM 55-1520-228-23-1 C 17

CHANGE

NO. 17

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 23 MARCH 1993

Aviation Unit and Intermediate
Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

√4-3 and 4-4 √5-19 and 5-20 √5-37 and 5-38 √5-40.1/(5-40.2 blank) Insert pages

4-3 and 4-4 5-19 and 5-20 5-37 and 5-38 5-40.1/(5-40.2 blank)

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

GORDON R. SULLIVAN
General, United States Army
Chief of Staff

Official:

MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no. 0226, requirements for TM 55-1520-228-23-1.

TM 55-1520-228-23-1

C 16

**CHANGE** 

NO. 16

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 16 February 1993

Aviation Unit and Intermediate Maintenance Manual

## ARMY MODEL OH-58A and OH-58C HELICOPTERS

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 55–1520–228–23–1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

Insert pages

5-95 through 5-98 6-65 and 6-66

5–95 through 5–98 6–65 and 6–66

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

GORDON R. SULLIVAN
General, United States Army
Chief of Staff

Official:

MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army

Mitte of Seulto

#### DISTRIBUTION:

TM 55-1520-228-23-1

C 15

**CHANGE** 

NO. 15

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 22 January 1993

Aviation Unit and Intermediate Maintenance Manual

## ARMY MODEL OH-58A and OH-58C HELICOPTERS

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-15 and 1-16	1-15 and 1-16
9-17 through 9-20	9-17 through 9-20
	9-20.1/(9-20.2 blank)
	9-20.3 and 9-20.4

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

GORDON R. SULLIVAN General, United States Army Chief of Staff

Official:

MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army

Mitte of Shoulton

#### **DISTRIBUTION:**

TM 55-1520-228-23-1 C 14

**CHANGE** 

NO. 14

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 30 OCTOBER 1992

Aviation Unit and Intermediate Maintenance Manual

## ARMY MODEL OH-58A AND OH-58C HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

Insert pages

1-66.1/(1-66.2 blank)

1-66.1/(1-66.2 blank)

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

GORDON R. SULLIVAN General, United States Army Chief of Staff

Official: Milton St. Samellow

MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army

**DISTRIBUTION:** 

To be distributed in accordance with DA Form 12-31-E, block no. 0226, requirements for TM 55-1520-228-23-1.

**DISTRIBUTION STATEMENT A:** Approved for public release; distribution is unlimited.

TM 55-1520-228-23-1 C 13

CHANGE )

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHIGNTON, D.C., 31 July 1992

Aviation Unit and Intermediate
Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-51 and 1-52	1-51 and 1-52
1-59 through 1-62	1-59 through 1-62
1-65 and 1-66	1-65 and 1-66
	1-66.1/1-66.2
6-113 through 6-116	6-113 through 6-116
9-63 and 9-64	9-63 and 9-64
	9-64.1/9-64.2

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

GORDON R. SULLIVAN General, United States Army Chief of Staff

Official: Mitta H. Hamelton

MILTON H. HAMILTON Administrative Assistant to the Secretary of the Army

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no. 0226, AVUM and AVIM maintenance requirements for TM 55-1520-228-23-1.

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

TM 55-1520-228-23-1 C 12

CHANGE NO. 12

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 27 May 1992

### Aviation Unit and Intermediate Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hands.

Remove pages

Insert pages

4-11 and 4-12 4-22.1 and 4-22.2 4-11 and 4-12 4-22.1 and 4-22.2

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

GORDON R. SULLIVAN General, United States Army Chief of Staff

Official: Mitto St. Samello

MILTON H. HAMILTON Administrative Assistant to the Secretary of the Army

1485

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no. 0226, AVUM and AVIM maintenance requirements for TM 55-1520-228-23-1.

TM 55-1520-228-23-1 C 11

CHANGE NO. 11

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 30 April 1992

### Aviation Unit and Intermediate Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove apges

Insert pages

1-55 and 1-56 1-59 through 1-62 1-67 through 1-69/1-70 6-113 through 6-116 1-55 and 1-56 1-59 through 1-62 1-67 through 1-69/1-70 6-113 through 6-116

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

GORDON R. SULLIVAN General, United States Army Chief of Staff

Official: Mitta St. Samella

MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no. 0226, AVUM and AVIM maintenance requirements for TM 55-1520-228-23-1.

TM 55-1520-228-23-1

C 10

CHANGE NO. 10

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 31 October 1991

### Aviation Unit and Intermediate Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

Insert pages

4-22.1 through 4-22.4 4-23 and 4-24

4-22.1 through 4-22.4 4-23 and 4-24

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

GORDON R. SULLIVAN General, United States Army Chief of Staff

Official: Milton St. Samelin

MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no. 0226, AVUM and AVIM maintenance requirements for TM 55-1520-228-23-1.

CHANGE )

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 20 September 1991

### Aviation Unit and Intermediate Maintenance Manual

ARMY MODEL
OH-58A and OH-58C
HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

Insert pages

9-108.19 and 9-108.20 9-108.20.1 through 9-108.20.4 Index 1 through Index 4 Index 9 and Index 10 9-108.19 and 9-108.20 9-108.20.1 through 9-108.20.4 Index 1 through Index 4 Index 9 and Index 10

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

GORDON R. SULLIVAN General, United States Army Chief of Staff

Official:

PATRICIA P. HICKERSON Colonel, United States Army The Adjutant General

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no. 0226, AVUM and AVIM maintenance requirements for TM 55-1520-228-23-1.

TM 55-1520-228-23-1 C 8

CHANGE NO. 8

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 3 July 1991

Aviation Unit and Intermediate
Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-65 and 1-66	1-65 and 1-66
4-21 and 4-22	4-21 and 4-22
4-22.1/4-22.2	4-22.1 through 4-22.4
4-23 and 4-24	4-23 and 4-24

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official:

CARL E. VUONO General, United States Army Chief of Staff

PATRICIA P. HICKERSON Colonel, United States Army The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no., 0226, AVUM and AVIM maintenance requirements for TM 55-1520-228-23-1.

TM 55-1520-228-23-1 C 7

CHANGE NO. 7

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 24 May 1991

### Aviation Unit and Intermediate Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-21 and 1-22	1-21 and 1-22
1-35 and 1-36	1-35 and 1-36
1-39 and 1-40	1-39 and 1-40
1-45 and 1-46	1-45 and 1-46
	1-46.1/1-46.2
1-47 through 1-52	1-47 through 1-52
	1-52.1/1-52.2
1-53 through 1-56	1-53 through 1-56
1-56.1/1-56.2	1-56.1/1-56.2
1-57 through 1-62	1-57 through 1-62
<b></b>	1-62.1/1-62.2
1-63 and 1-64	1-63 and 1-64
1-67 and 1-68	1-67 and 1-68
	1-69/1-70
2-31 and 2-32	2-31 and 2-32
	2-32.1/2-32.2
2-133 through 2-136	2-133 through 2-136
4-21 and 4-22	4-21 and 4-22
	4-22.1/4-22.2
4-23 and 4-24	4-23 and 4-24
4-49 and 4-50	4-49 and 4-50
	4-50.1/4-50.2
5-21 and 5-22	5-21 and 5-22
5-39 and 5-40	5-39 and 5-40
_ ~	5-48.1/5-48.2
5-49 and 5-50	5-49 and 5-50
6-45 and 6-46	6-45 and 6-46
6-103 through 6-106	6-103 through 6-106
0-105 culough 0-100	O 103 CHIOGEN O 100

Remove pages

Insert pages

6-113 through 6-116 - - - -8-21 and 8-22 9-25 and 9-26 6-113 through 6-116 6-116.1/6-116.2 8-21 and 8-22 9-25 and 9-26 9-26.1/9-26.2

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

CARL E. VUONO General, United States Army Chief of Staff

Official:

PATRICIA P. HICKERSON Colonel, United States Army The Adjutant General

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no., 0226, AVUM and AVIM maintenance requirements for TM 55-1520-228-23-1.

C 6

CHANGE NO. 6

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 15 September 1990

Aviation Unit and Intermediate
Maintenance Manual

ARMY MODEL OH-58A AND OH-58C HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

Insert pages

5-22.1 and 5-22.2

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official:

CARL E. VUONO General, United States Army Chief of Staff

THOMAS F. SIKORA
Brigadier General, United States Army
The Adjutant General

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31, AVUM and AVIM Maintenance requirements for the OH-58A/C Helicopters, Observation.

TM 55-1520-228-23-1 C 5

CHANGE NO. 5

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 24 August 1990

Aviation Unit and Intermediate
Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-34.1 and 1-34.2	1-34.1 and 1-34.2
4-51 and 4-52	4-51 and 4-52
	4-52.1/4-52.2
4-53 and 4-54	4-53 and 4-54
5-17 and 5-18	5-17 and 5-18
	5-18.1/5-18.2
5-19 through 5-22	5-19 through 5-22
5-37 through 5-40	5-37 through 5-40
۔ حن بن ھے	5-40.1/5-40.2
8-15 and 8-16	8-15 and 8-16
	8-16.1/8-16.2
8-19 and 8-20	8-19 and 8-20
9-25 and 9-26	9-25 and 9-26
9-29 and 9-30	9-29 and 9-30

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

CARL E. VUONO General, United States Army Chief of Staff

Official:

THOMAS F. SIKORA Brigadier General, United States Army The Adjutant General

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31, AVUM and AVIM Maintenance requirements for the OH-58A/C Helicopters, Observation.

CHANGE NO. 3

DEPARTMENT
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 15 March 1990

### Aviation Unit and Intermediate Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

Insert pages

1-67 and 1-68

1-67 and 1-68

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

CARL E. VUONO General, United States Army Chief of Staff

Official:

WILLIAM J. MEEHAN II Brigadier General, United States Army The Adjutant General

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31, AVUM and AVIM Maintenance requirements for the OH-58A/C Helicopters, Observation.

NOTICE: THIS CHANGE HAS BEEN PRINTED AND DISTRIBUTED OUT OF SEQUENCE. IT SHOULD BE INSERTED IN THE MANUAL AND USED. UPON RECEIPT OF THE EARLIER SEQUENCED CHANGE INSURE A MORE CURRENT CHANGE PAGE IS NOT REPLACED WITH A LESS CURRENT PAGE

TM 55-1520-228-23-1 C 3

CHANGE NO. 3

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 27 November 1989

Aviation Unit and Intermediate
Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-31 through 1-34	1-31 through 1-34
***	1-34.1 and $1-34.2$
2-50.1 and 2-50.2	2-50.1 and $2-50.2$
5-143 and 5-144	5-143 and 5-144
	5-144.1/5-144.2
5-147 and 5-148	5-147 and 5-148
5-151 through 5-154	5-151 through 5-154

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

CARL E. VUONO
General, United States Army
Chief of Staff

Official:

WILLIAM J. MEEHAN II Brigadier General, United States Army The Adjutant General

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31, AVUM and AVIM Maintenance requirements for the OH-58A/C Helicopters, Observation.

NOTICE: THIS CHANGE HAS BEEN PRINTED AND DISTRIBUTED OUT OF SEQUENCE. IT SHOULD BE INSERTED IN THE MANUAL AND USED. UPON RECEIPT OF THE EARLIER SEQUENCED CHANGE INSURE A MORE CURRENT CHANGE PAGE IS NOT REPLACED WITH A LESS CURRENT PAGE.

TM 55-1520-228-23-1 C 2

CHANGE )

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 23 OCTOBER 1989

### Aviation Unit and Intermediate Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-53 through 1-56	1-53 through 1-56
	1-56.1/1-56.2
1-67 and 1-68	1-67 and 1-68
6-11 and 6-12	6-11 and 6-12
	6-12.1/6-12.2
6-15 through 6-18	6-15 through 6-18
6-21 through 6-26	6-21 through 6-26
	6-26.1/6-26.2
6-27 and 6-28	6-27 and 6-28

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

CARL E. VUONO General, United States Army Chief of Staff

Official:

WILLIAM J. MEEHAN II Brigadier General, United States Army The Adjutant General

#### DISTRIBUTION:

To be distributed in accordance with DA Form 12-31, AVUM and AVIM Maintenance requirements for the OH-58A/C Helicopters, Observation.

CHANGE NO. 1

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 1 February 1990

### Aviation Unit and Intermediate Maintenance Manual

ARMY MODEL
OH-58A AND OH-58C
HELICOPTERS

TM 55-1520-228-23-1, 28 February 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
P-1 and P-2	P-1 and P-2
a and b	a and b
i and ii	i and ii
1-1 and 1-2	1-1 and 1-2
1-9 and 1-10	1-9 and 1-10
	1-10.1/1-10.2
1-15 through 1-20	1-15 through 1-20
	1-20.1/1-20.2
1-23 and 1-24	1-23 and 1-24
	1-24.1/1-24.2
1-63 and 1-64	1-63 and 1-64
1-67 and 1-68	1-67 and 1-68
2-1 and 2-2	2-1 and 2-2
2-5 and 2-6	2-5 and 2-6
	2-6.1 and 2-6.2
2-27 and 2-28	2-27 and 2-28
	2-28.1/2-28.2
2-107 through 2-110	2-107 through 2-110
3-25 and 3-26	3-25 and $3-26$
gan deb bin	3-26.1/3-26.2
9-53 through 9-56	9-53 through 9-56
	9-56.1/9-56.2
9-57 and 9-58	9-57 and 9-58
9-101 through 9-108	9-101 through 9-108
	9-108.1 through 9-108.25/108.26
Index 1 through Index 10	Index 1 through Index 10
	Index 10.1/Index 10.2

### **PREFACE**

#### P-1. GENERAL.

**a.** This manual is the official document for Aviation Unit and Intermediate Maintenance of Army Model OH-58A and OH-58C Helicopters.

b. The purpose of this manual is to familiarize you with the maintenance functions to be performed at the Aviation Unit and Intermediate Maintenance levels. The Table of Contents for this manual is provided to assist in determining the chapter in the manual in which individual functions are covered. This manual provides all essential information for personnel to accomplish Aviation Unit and Intermediate Maintenance on the complete airframe, its components, and systems, excluding the armament and avionics subsystem as indicated for Aviation Unit and Intermediate Maintenance activities in the Maintenance Allocation Chart (MAC). (Refer to Appendix B.)

### P-2. QUALITY ASSURANCE/QUALITY CONTROL [QA/QC).

Personnel will assure proper maintenance has been performed by verification of dimensions and tolerances as set forth within this manual.

#### P-3. DESCRIPTION.

The helicopter described in this manual is a single engine, light observation helicopter which features a low silhouette and low vulnerability to meet combat requirements. The fuselage consists of two main sections; the forward section and the aft, or boom section. This helicopter is capable of operating from prepared or unprepared landing areas by day or night. Minimum instrumentation has been provided in event of inadvertent IFR flight. (Refer to AR 95-1.) Maximum visibility is afforded the crew by extensive use of transparent plastic panels at the top, front, bottom, and sides of the cabin. For principal dimensions, refer to TM55-1520-228-10.

### F-4. DESTRUCTION OF ARMY MATERIAL TO PREVENT ENEMY USE.

For destruction of Army material to prevent enemy use, refer to TM 750-244-1-5.

### P-5. MAINTENANCE OF FORMS AND RECORDS.

Maintenance of forms, records, and reports which are to be used by maintenance personnel at all maintenance levels are listed in and prescribed by DA PAM 738-751.

### P-6 WARNINGS, CAUTIONS, AND NOTES.

Warnings, cautions, and notes are used to emphasize important and critical instructions and are used for the following conditions:



An operating procedure, practice, etc., which if not correctly followed, could result in personal injury or loss of life.

### CAUTION

An operating procedure, practice, etc., which, if not strictly observed, could result in damage to or destruction of equipment.

#### NOTE

An operating procedure, condition, etc., which is essential to highlight.

### P-7. AUTHORITY FOR SUBSTITUTION.

Substitution or interchange of items of material for maintenance of Department of the Army aircraft/ helicopter shall not be authorized, nor shall orders be issued for shipment. Substitution or interchangeability shall only be authorized by AVSCOM, ATTN: DRSAV-MEM, 4300 Goodfellow 81vd., St. Louis, MO 63120.

#### P-8. SPECIAL TOOLS AND EQUIPMENT

Aviation Unit (AVUM) and Intermediate maintenance (AVIM) special tools and equipment will be found in TM 55-1520-228-23P Repair Parts and Special Tools List (RPSTL). Special tools and test equipment for complex tasks are included in this manual.

#### P-9. CALIBRATION

Equipment requiring calibration shall be indicated and reference made to a publication(s) containing the applicable procedures.

- a. Helicopter components, accessories, and instruments requiring calibration shall be specified in Chapter 1.
- b. Special tools and test equipment shall be calibrated as specified in TB 750-25, Army Metrology and Calibration System and TB 43-180, Calibration Procedure.

#### P-10. STORAGE

Refer to Appendix E for Storage of Aircraft.

#### P-11. DESIGNATOR SYMBOLS

Designator symbols used in conjunction with text contents, text headings, and illustration titles are used to indicate limited effectivity of the material. Symbol Andicates material is applicable only to OH-58A helicopter. Symbol C indicates material is applicable only to OH-58C helicopter. Symbol CS indicates material is applicable only to OH-58C helicopters equipped with Air-To-Air Stinger (ATAS) missile system. If material applies to all series and configurations, no designator symbol will be used.

### P-12. EXPLANATION OF CHANGE SYMBOLS

Changes, except as noted below to the text and tables, including new material on added pages, are indicated by a vertical line in the outer margin

extending close to the entire area of the material affected; exception: pages with emergency markings, which consist of black diagonal lines around three edges, may have the vertical line or change symbol placed along the inner margins. Symbols show current changes only. A miniature pointing hand symbol is used to denote a change to an illustration. However, a vertical bar in the outer margin, rather than miniature pointing hand is utilized where there have been extensive changes made to an illustration. Change symbols are not utilized to indicate changes in the following:

- a. Introductory material
- b. Indexes and tabular data where changes cannot be identified
- c. Blank space resulting from the deletion of text, an illustration, or a table
- d. Correction of minor inaccuracies, such as spelling, punctuation, relocation of material, etc., unless such correction changes the meaning of instructive information and procedures.

### P-13. ENGINEERING AUTHORIZATION

All requests for engineering authorization, when required by this manual will be forwarded to USAAVSCOM, ATTN: AMSAV-MEA, 4300 Goodfellow Blvd., St. Louis, MO 63120. Urgent requests shall be clearly identified to ensure priority handling and response. The requests shall include detailed information of the problem, e.g., sketches, photographs, dimensional data, etc., to assist in the evaluation and prompt reply.

### P-14. USE OF WORDS SHALL, SHOULD, AND MAY

Within this technical manual the word "shall" is used to indicate a mandatory requirement. The word "should" is used to indicate a non-mandatory but preferred method of accomplishment. The word "may" is used to indicate an acceptable method of accomplishment.

WARNING PAGE TM 55-1520-228-23-1

#### WARNING

Personnel performing operations, procedures, and practices which are included or implied in this technical manual shall observe the following instructions. Disregard of these warnings and precautionary information can cause serious injury, death, or an aborted mission.

#### **TOXIC POISONS**

#### DANGEROUS CHEMICALS ARE USED IN NICKEL-CADMIUM BATTERIES

The electrolyte used in nickel-cadmium batteries contains potassium hydroxide (KOH), which is a caustic chemical agent. Serious and deep burns of body tissue will result if the electrolyte comes in contact with the eyes or any part of the body. Use rubber gloves, rubber apron, and protective eye covering when handling the battery. If accidental contact with the electrolyte is made, use ONLY clean water and immediately (seconds count) flush contaminated areas. Continue flushing with large quantities of clean water. Seek medical attention immediately. Before removing or installing the battery, ensure that the battery switch is off and the battery has cooled down if overheated. Removal or installation of the battery connector while the battery is under load may result in explosion, electrical arcing, and possible severe burns to personnel. Take every possible step to keep the nickel-cadmium battery as far away as possible from the lead-acid type of battery. Do not use the same tools and materials (screwdrivers, wrenches, gloves, apron, etc.) for both types of batteries. Anything associated with the lead-acid battery, even the air, must never come in contact with the nickel-cadmium battery or its electrolyte. Even a trace of sulfuric acid fumes from a lead-acid battery may result in damage to the nickel-cadmium battery. If sulfuric acid has been inadvertently mixed with the electrolyte in the battery, the upper areas of the cells will appear greenish in color. In such cases, the battery must be replaced.

Turbine fuels and lubricating oils contain additives which are poisonous and readily absorbed through the skin. Do not allow them to remain on skin longer than necessary.

#### HANDLING HYDRAULIC FLUID

Prolonged contact with liquid or mist can irritate eyes and skin. After any prolonged contact with skin, immediately wash contact area with soap and water. If liquid contacts eyes, flush immediately with clear water. If liquid is swallowed, do not induce vomiting; get immediate medical attention. Wear rubber gloves when handling liquid. If prolonged contact with mist is likely, wear an appropriate respirator. When fluid is decomposed by heating, toxic gains are released.

#### NOISE

Sound pressure levels in this helicopter during some operation conditions exceed the Surgeon General hearing conservation criteria, as defined in TB MED 501. Hearing protection devices, such as aviator helmets or ear plugs are required to be worn by all personnel in and around the helicopter during operation.

#### GROUND OPERATION

Engine will be started and operated only by authorized personnel. Reference AR 95-1.

#### FIRE EXTINGUISHER

Exposure to high concentrations of monobromotrifluoromethane (CF3BR) extinguishing agent or decomposition products should be avoided. The liquid should not be allowed to come into contact with the skin, as it may cause frost bite or low temperature burns.

When helicopter is to be parked where ambient temperature equals or exceeds 90°F (32°C), the fire extinguisher shall be removed until the next mission.

TM55-1520-228-23 WARNING PAGE

#### **ARMAMENT**

Loaded weapons, or weapons being loaded or unloaded, shall be pointed in a direction which offers the least exposure to personnel or property in the event of accidental firing. Personnel should remain clear of hazardous area of all loaded weapons.

ANY ROTATION OF THE GUN ARMAMENT SUBSYSTEM BARRELS WILL CAUSE THE GUN TO FIRE. Upon landing, immediately alert personnel to probable presence of live rounds in the gun. Summon armament repairman to clear weapon.

#### **FUELING AND DEFUELING**

When refueling helicopter, the refueling vehicle or forward air refueling unit must be parked a minimum of 20 feet from the helicopter. Before starting the fueling operation, always insert fueling nozzle grounding chain of fuel truck ground wire into GROUND HERE receptacle located on the right side of the helicopter aft of the cabin area.

When defueling, turn off all electrical switches and disconnect external power from the helicopter. The helicopter must be electrically grounded prior to defueling.

#### RADIOACTIVE MATERIALS

Self-luminous dials and ignition units may contain radioactive materials. If such an instrument or unit is broken or becomes unsealed, avoid personal contact. Use forceps or gloves made of rubber or polyethylene to pick up contaminated material. Place materials and gloves in a plastic bag. Seat bag and dispose of it as radioactive waste in accordance with AR 755-15 and TM 3-261 (Refer to TB 55-1500-314-25). Repair procedures shall conform to requirements in AR 700-52.

#### CORROSION

During any inspection of the aircraft or components, the person making the inspection should pay particular attention to areas prone to corrosion. When corrosion is found, a prime consideration is to evaluate what corrective action will be required to correct the discrepancy. Corrosion repair and treatment can be time consuming, and for this reason, early evaluation is essential for good aircraft maintenance planning. This evaluation will assist in determining if sheet metal or aircraft mechanics will be necessary to make the needed repair. In cases where corrosion has exceeded the accept or reject criteria, material replacement will be necessary. For material replacement, refertoTM1-1500-204-23 General Aircraft Maintenance Manual. For corrosion treatment, refer to TM 43-0105, Corrosion Control for Army Aircraft; and for painting, refer to TM 55-1500-345-23, Painting and Marking of Army Aircraft. If corrosion is found and not covered by applicable TM's submit a DA form 2028, Recommended Changes to Equipment Technical Publications, or an Equipment Improvement Recommendation (EIR) where a design change is necessary.

#### **EXPLOSIVES**

The missile round contains explosives. All applicable safety regulations shall be strictly enforced. Explosive components containing electrical wiring must be protected at all times from stray voltages or induced electrical currents.

Handling operations should not be performed during electrical storms.

#### **TOXIC MATERIALS**

The basic stinger missile round and captive flight trainer (CFT) contain mercury thallium. If the IR dome should break, do not touch the basic stinger missile round or CFT in the vicinity of the IR dome. This material is toxic to unprotected skin. Avoid all contact with the released material unless protective equipment is being worn, such as a respirator, gloves, and chemical goggles. If the skin or eyes are exposed to the spilled material, immediately flush with large quantities of water. Any person exposed to the released material should be promptly referred to a physician.

#### **ASBESTOS FIBERS**

Breathing airborne asbestos fibers can cause serious bodily harm, use caution not to create airborne fibers, use respirator when working with asbestos.

TECHNICAL MANUAL

No. TM55-1520-228-23-1

# HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D.C., 28 FEBRUARY 1989

# Aviation Unit and Intermediate Maintenance Manual

#### ARMY MODELS OH-58A AND OH-58C

#### NOTE:

This manual is printed in two volumes, as follows:

TM 55-1520-228-23-1, consisting of Table of Contents, Preface, Chapters 1 through 9.

TM 55-1520-228-23-2, consisting of Table of Contents, Chapters 10 through 17, Appendices A through F, and index.

The Preface, Appendices, and Index are applicable to the -1 and -2.

#### REPORTING ERRORS AND RECOMMENDING IMPROVEMENT

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedure, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-P, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. A reply will be furnished \_vou.

#### TABLE OF CONTENTS

Chapter/Section		Subject	Page
CHAPTER Section	1 II III IV V	AIRCRAFT GENERAL  Servicing  Lubrication  Handling, Jacking, Mooring, Hoisting, and Sling Loading  Inspection Requirements  Overhaul and Retirement Schedule.	1-1 1-25 1-25 1-37 1-67
CHAPTER Section	2   I   III   IV   V   VI	AIRFRAME Fuselage Tailboom Pylon W!ng (Not Applicable) Extrusion Chart (Not Applicable) Wire Strike Protection System	2-1 2-112 2-132 2-154 2-164 2-154
CHAPTER Section	3 	ALIGHTING GEAR Landing Gear Skids and Struts (Not Applicable) Float Landing Gear System Brakes (Not Applicable) Skis (Data Not Available)	3-1 3-25 3-25 3-31 3-31

Change 18

### TABLE OF CONTENTS (CONT)

Chapter/Section	Subject	Page
CHAPTER Section	4 POWER PLANT   Power Plant   Cooling System (Nonapplicable)   Air Induction System   Exhaust System   Oil System   Ugnition System   Power Controls	4-1 4-20 4-20 4-27 4-31 4-40 4-40
CHAPTER Section	5 ROTORS I Main Rotor Hub II Main Rotor Blades III Main Rotor Controls IV Tail Rotor V Tail Rotor Hub and Controls. VI Tail Rotor Blades VII Tracking Procedures	5-11 5-57 5-68 5-107 5-119 5-158 5-170
CHAPTER Section	6 DRIVE TRAIN SYSTEM I Main Driveshaft II Clutches III Main Transmission IV Tail Rotor Driveshaft V Intermediate Gearbox (Not applicable) VI Tail Rotor Gearbox VII Oil System	6-12 6-28 6-41 6-66 6-102 6-103 6-122
CHAPTER Section	7 HYDRAULIC SYSTEM 1 Flight Control 1 Hydraulic Pump 1 Solenoid Valve 1 V Servo Actuators (Cyclic and Collective) 2 V Servo Actuator Support 3 VI Pressure Switch 4 VII Hydraulic Reservoir 5 VIII Hydraulic Filters 6 IX Hydraulic Hoses, Lines, and Quick-Disconnects 7 X Hydraulic Relief Valve 8 XI Hydraulic Relief Valve	7-1 7-16 7-19 7-24 7-28 7-28 7-29 7-31 7-31
CHAPTER Section	8 INSTRUMENT SYSTEMS I Engine, Rotor and Transmission instruments II Flight Instruments III Navigation Instruments IV Miscellaneous Instruments	8-3 8-21 8-36 8-37
CHAPTER Section	9 ELECTRICAL SYSTEM 1 Direct Current Power Distribution System 1 Alternating Current System. 1 Starting System 1 Ignition System 2 Lighting Provision 3 VI Miscellaneous Equipment	9-1 9-66 9-67 9-70 9-72 9-93

# CHAPTER 1 AIRCRAFT GENERAL

#### SECTION I. SERVICING

#### 1-1. SERVICING.

- **1-2. Description Servicing.** Instructions and information for complete servicing of the helicopter with fuel, oil, and hydraulic fluid are provided in the following paragraphs. Location of fillers, sight gages, and drains are shown on servicing diagrams as required, with indication of how frequently each reservoir should be checkd and serviced. Refer to figure 1-1 for the servicing diagram. Instructions for use of greases and other lubricants refer to Lubrication Requirement Section II, this chapter.
- 1-3. Fuel System. The fuel supply system consists of a single bladder type cell, fuel pump, and lines. The filler cap (10, figure 1-1) is located on the right side of helicopter aft of passenger door. Helicopters are equipped with crashworthy fuel system, the self-sealing TANK CAPACITY is 71.5 U.S. GALLONS.
- 1-4. Precautions in Fuel Servicing and Defueling.



Observe the following precautions in all fuel servicing and defueling operations as applicable. Refer to FM 10-68 and FM 10-69 for additional precautions prior to servicing the helicopter.


- **a.** Position auxiliary ground power unit on the windward side of the helicopter.
  - **b.** Do not fuel or defuel during electrical storms.
- **c.** Do not fuel or defuel while ground radar sets are operating within 300 feet of the helicopter.
- **d.** Servicing personnel must not wear metal taps on shoes.


- **e.** Ensure battery switch is in OFF position and external power is disconnected before fueling or defueling the helicopter.
- **f.** Ground the helicopter at receptacle, located adjacent to filler capon right side of helicopter, to the filler-nozzle before removing filler cap.
- **g.** Fuel truck shall be grounded (truck to ground and truck to helicopter). The helicopter shall be grounded to the same ground point as is the fuel truck.
- **h.** Do not use splash-filling. Fill tanks slowly and evenly.
- i. After completion of servicing, wash-down, and remove any spillover of jet fuel. This fuel does not evaporate as rapidly as gasoline, and constitutes a fire hazard for a much longer time. Cleaning materials which have become saturated with fuel shall be disposed of in a designated area well away from buildings.
- j In the event of fuel spillage on personnel, clothing shall be washed down thoroughly with clear water before removing clothing.
- **k.** Refueling will be accomplished as soon as possible after landing to keep moisture condensation to a minimum.
- 1-5. Servicing Fuel System.



Insert nozzle carefully in a generally downward direction, avoiding contact with internal fuel hoses. Fuel nozzles must be hand held during servicing.

**a.** Fill tank cells with specified jet fuel (C75). Crashworthy fuel tank capacity is 71.5 gallons. The





Lubrication oil made to MIL-L-7808 by Shell Oil Company under their part number 307, qualifications number 7D-1 shall not be used in engine or aircraft systems. It contains additives which are harmful to seals in the systems.

#### NOTES

\*On OH-58A/C without MWO 1-1520-228-50-44 completed, drain and refill lubrication system of the T63-A-720 engine after each 100 hours of operation.

- \*\* On OH-58A, drain and refill lubrication system of the T63-A-700 engine after each 150 hours of operation.
- \*\*\*After completion of MWO 1-1520-228-50-44, service engine oil every 200 hours. Additional servicing may be needed for filter replacement.

#### NOTE

After completion of MWO 55-1520-228-50-25, service gear-box to oil level indicator line only.

#### NOTE

Items 8 and 10 are located on right side of aircraft. On helicopters with standard landing gear, gearbox oil level must be 1/8 inch above oil level indicator oil line. On helicopters with high landing gear or floats, maintain oil level at indicator line.

#### CAUTION

Lubrication of DOD-L-85734 will not be used in the engine.

Figure 1-1. Servicing Diagram (Typical)

following fuel servicing instructions apply to helicopters incorporating the closed circuit refueling provision.

b. Closed Circuit Refueling.

### CAUTION

The closed circuit refueling receptacle is subject to damage at the gravity refueling port. Refer to figure 1-2. This damage can cause external fuel leakage during subsequent closed circuit refueling operations. To preclude damage to the receptacle, the closed circuit nozzle will be used if possible when refueling. If, however, the receptacle has been previously damaged and leakage occurs, the following must be observed:

Closed circuit refueling operations with a leaking receptacle shall be discontinued. Gravity refueling method shall be used until the receptacle can be replaced or repaired.

- (1) Ground the helicopter at the receptacle, located adjacent to the filler cap on the helicopter, to the filler-nozzle and remove filler cap.
- (2) Ensure that gravity refueling port is closed. If not, rotate inner sleeve counterclockwise until gravity refueling port is closed and flange of sleeve is in contact with rivet at base of receiver cylinder. Refer to figure 1-3.

# CAUTION

Ensure that servicing unit pressure is not above 125 psi while refueling.

- (3) Insert fueling nozzle into receiver and actuate automatic nozzle lever to ON or FLOW position. Pin at base of nozzle will momentarily indicate when fuel flow stops.
- (4) Fuel flow will automatically shut off when normal fuel level is reached. Just prior to normal shut off, fuel flow may cycle several times as fuel level is

reached. Gage on servicing unit will indicate when flow is stopped.

- **(5)** When fuel flow has stopped, actuate lever on nozzle to OFF, disconnect nozzle from receiver and replace filler cap.
- **(6)** Disconnect fuel nozzle ground and rewind hose assembly.
- (7) Disconnect servicing unit ground at helicopter.
- (8) Disconnect servicing unit ground at grounding stake.

### CAUTION

If helicopter is equipped with closed circuit refueling system and fuel servicing unit is not equipped with related nozzle for closed circuit refueling, a gravity system may be used providing the servicing nozzle does not exceed 1.75 inches outside diameter. To refuel, utilizing the gravity nozzle, it is necessary to position the inner sleeve of receiver until slot is lined up with fuel port in bottom of receiver. Position nozzle into port in order to bypass closed circuit valve. Damage could result to the closed circuit refueling system if caution is not used in positioning nozzle into inner sleeve of fuel receiver at fuel port.

- **c.** Gravity Refueling.
- (1) Ground the helicopter at the receptacle, located adjacent to the filler cap on the helicopter, to the filler-nozzle and remove filler cap.
- (2) Rotate inner sleeve clockwise until sleeve clears the port in bottom of fuel receiver. Refer to figure 1-3.
  - (3) Position nozzle into port of fuel receiver.
  - (4) Fill to specified level.
- (5) Remove nozzle and rotate inner sleeve counterclockwise until gravity refueling port is closed and flange of inner sleeve is in contact with rivet at base of receiver cylinder.





Figure 1-2. Gravity Refueling with Closed Circuit Receiver



206062-105

Figure 1-3. Refueling Receptacle

- (6) Reinstall filler cap.
- (7) Disconnect fuel nozzle ground and rewind hose.
- (8) Disconnect servicing unit ground at helicopter.
- **(9)** Disconnect servicing unit ground at grounding stake.

## 1-6. Fuel System Servicing (Rapid (Hot) Refueling).

### WARNING

Aircraft may be rapid (hot) refueled with engine/engines running, electrical power on, radios on, weapons systems on with safety covers/guards/switches in SAFE position, and any computer systems operating that would require reprogramming.

a. Precautions.

#### NOTE

Servicing personnel shall comply with all safety precautions and procedures in FM 10-68.

- (1) Ground the helicopter at the receptacle, located adjacent to the filler cap on the helicopter, to the filler-nozzle before removing filler cap.
- (2) Servicing unit shall be grounded (servicing unit to ground and servicing unit to helicopter). The helicopter should be grounded to the same ground point as is the servicing unit,
- (3) After completion of servicing, remove nozzle, install cap and disconnect all grounds from helicopter.
- **b.** Servicing Fuel System, Fill tank cells with specified jet fuel (C75). Crashworthy fuel tank capacity is 71.5 gallons. The following fuel servicing instructions apply to helicopters incorporating the closed circuit refueling provision.

c. Before Rapid (Hot) Refueling



Only emergency radio transmission should be made during rapid refueling.

In case of aircraft fire, observe fire emergency procedures in Chapter 9, TM 55-1520-228-10. Do not attempt to fly the helicopter.

- (1) Minimum crew will remain at the controls.
- (2) Throttle Idle.
- (3) Force Trim ON or controls frictioned
- (4) Passengers shall depart the aircraft and go to the terminal or passenger marshaling area.
- (5) No smoking allowed during refueling operations.
- (6) A crewmember, if available, should observe the refueling operation (performed by authorized refueling personnel) and stand fire guard as required,
  - d. During Rapid (Hot) Refueling
    - (1) Closed circuit refueling
- (a) Ground the helicopter at the receptacle, located adjacent to the filler cap on the helicopter, to the filler-nozzle and remove filler cap.
- **(b)** Ensure that gravity refueling port is closed, If not, rotate inner sleeve counterclockwise until gravity refueling port is closed and flange of sleeve is in contact with rivet at base of receiver cylinder. Refer to figure 1-3.

### CAUTION

## Ensure that servicing unit pressure is not above 125 psi while refueling.

(c) Insert fueling nozzle into receiver and actuate automatic nozzle lever to ON or FLOW position. Pin at base of nozzle will momentarily indicate when fuel flow stops.

- (d) Fuel flow will automatically shut off when normal fuel level is reached. Just prior to normal shut off, fuel flow may cycle several times as fuel level is reached. Gage on servicing unit will indicate when flow is stopped.
- **(e)** When fuel flow has stepped, actuate lever on nozzle to OFF, disconnect nozzle from receiver and replace filter cap.
- **(f)** Disconnect fuel nozzle ground and rewind hose assembly.
- **(g)** Disconnect servicing unit ground at helicopter.
  - (h) Disconnect servicing unit ground at

If helicopter is equipped with closed circuit refueling system and fuel servicing unit is not equipped with related nozzle for closed circuit providing a gravity system maybe used providing the servicing nozzle does not exceed 1.76 inches outside diameter. To refuel utilizing the gravity nozzle, it is necessary to position the inner sleeve of receiver until slot is lined up with fuel port in bottom of receiver. Position nozzle into port in order to bypass closed circuit valve. Damage could result to the closed circuit refueling system if caution is not used in positioning nozzle in its inner sleeve of fuel receiver at fuel port.

- (2) Gravity refueling.
- (a) Ground the helicopter at the receptacle, located adjacent to the filler cap on the helicopter, to the filer-nozzle and remove filler cap.
- **(b)** Rotate inner sleeve clockwise until sleeve clears port in bottom of fuel receiver. Refer to figure 1-3.
  - (c) Position nozzle into port of fuel receiver.
  - (d) Fill to specified level.

- **(e)** Remove nozzle and rotate inner sleeve counterclockwise until gravity refueling port is closed and flange of inner sleeve is in contact with rivet at base of receiver cylinder.
  - (f) Reinstall filler cap.
- (g) Disconnect fuel nozzle ground and rewind hose.
- **(h)** Disconnect servicing unit ground at helicopter.
- (i) Disconnect servicing unit ground at grounding stake.
  - e. After Rapid Refueling.
- (1) The pilot shall be advised by the refueling crew that fuel cap(s) are secure and ground cables have been removed.
- (2) Crewmembers and passengers can enter aircraft.

#### 1-7. Defueling and Drain Valves.

- **a.** Remove fuel cap; rotate inner sleeve clockwise until end of sleeve clears port in bottom of fuel receiver.
- **b.** Insert a suction pickup from a defuel unit into the fuel filler opening and remove all possible fuel.
- **c.** To complete defueling, drain remaining fuel into a suitable container by opening fuel cell sump drain valve (9, figure 1-1).
- **d.** Purge fuel cell. Refer to TM 55-1500-204. 25/1.
- 1-8. Servicing Engine Oil System. The engine oil tank (6, figure 1-1) is located aft of the engine and oil cooler blower fan. Oil level is checked by a "trapped ball" sight gage on the tank. Normal capacity is 11.2 pints. Service with lubricating oil (C103). Tank drain valve is accessible through small door on the left side of aft cowl and has an overboard drain line. Clean oil filter at each oil change. Refer to TM 55-2840-231-23 A, TM 55-2840-241-2

An engine high oil level coupled with a transmission low oil level condition indicates a possible failure of the engine gear-box seal(s) which allows oil to be transmitted from the transmission through the freewheeling unit into the engine.

#### NOTE

The oil systems in the helicopter are the engine oil system, the transmission oil system, the tail rotor gearbox oil system, and the main rotor hub oil system. The engine oil systems are serviced with either MIL-L-7808 or MIL-L-23699, depending on the anticipated temperature range in which the helicopter will be operated. (Refer to TB 55-9150-200-24.) Do not mix MIL-L-7808 and MIL-L-23699 except in an emergency. If oils are mixed, drain oil and service with correct oil within six hours of operation.

a. To prime the pumps, perform the following steps:

#### NOTE

For additional information on pump priming refer to TM 55-2840-231-23 A. TM 55-2840-241-23 C.

- (1) Disconnect the engine oil pump inlet hose assembly (figure 1-4) from the elbow fitting.
- (2) Loosen the elbow locknut and rotate the elbow to an upright position.
  - (3) Fill the elbow to spillover with engine oil (C103).
  - (4) Fill engine inlet hose with engine oil (C103).
- (5) Reposition elbow and connect the engine oil pump inlet hose assembly and tighten appropriate components.
- 1-9. Servicing Oil Lubricated Main Rotor Hub. Service two pillow block reservoirs (4, figure 1-1) and

two grip reservoirs (3) with lubricating oil (C102). Fill to one-half full level. Lockwire (C96) filler plugs after servicing.

#### CAUTION

Do not overservice transmission system. To do so will cause damage to the main rotor mast seal and other transmission seals.

#### NOTE

For lubrication requirements for the grease lubricated main rotor hub refer to figure 1-5, detail C.

1-10. Servicing - Transmission Oil System.

#### NOTE

If MIL-L-7808 and MIL-L-23699 or DOD-L-85734 were mixed in the transmission, drain the transmission and freewheeling unit. Replace the oil filter and service with correct oil. DOD-L-85734 is the preferred oil to use.

Service the transmission (1, figure 1-1) with lubricating oil (C103 or C103.1). The normal capacity is 4.0 US quarts. A sight glass located on the transmission housing is used to check the oil level in the transmission. The oil level must be visible in sight glass. If oil is visible, additional oil is not required. If oil is not visible in sight glass, add oil to the center dot only. Transmission is drained by removing the forward chip detector and plug assembly, allowing oil to drain into a trough and into a container; by opening freewheeling unit oil lines at firewall and catching oil in a container, or by using ground drain unit (S4) to avoid spilling oil onto the airframe. To utilize drain fitting, remove chip detector and insert ground drain unit into transmission. After oil has been drained, remove magnetic chip detector from freewheeling unit and drain oil.

1-11. Servicing - Tail Rotor Gearbox. Service the gearbox (5, figure 1-1) with lubricating oil (C103 or C103.1) at the filler-breather cap. The normal capacity is 0.375 US pint (6 oz) A sight glass is provided for ease in checking oil level.




Figure 1-4. Engine Oil Inlet Hose and Elbow.

After completion of MWO 55-1520-228-50-25, service gearbox to the oil level indicator line only.

#### NOTE

When property serviced, the oil level will be 1/8-nch above the oil level line with standard gear, and 1/8-inch below line when high gear or floats are Installed. Drain oil by removing chip detector. Catch oil In a suitable container or by using ground drain unit (S5) to avoid spilling oil onto the airframe. To utilize drain fitting, remove chip detector and Insert drain fitting into the gearbox

#### **NOTE**

Care should be taken to not overfill gearbox as excessive oil leakage may occur. When servicing, allow oil level to stabilize for correct Indication on sight glass.

**1-12. Servicing - Hydraulic System**. Service the hydraulic reservoir (7, figure 1 -1) with hydraulic fluid

(C73). The reservoir is located on the forward side of the transmission. A sight glass with ball float or line level is provided to determine low quantity of fluid in the reservoir. Fill to overflow lip in reservoir. Whenever the fluid in the reservoir is changed, inspect inside of bottom of reservoir for corrosion. Refer to paragraph 7-56.

### WARNING

Contact with liquid or mist can Irritate eyes and skin. After any contact with skin, Immediately wash contacted area with soap and water. If liquid contacts eyes, flush Immediately with clear water. If liquid Is swallowed, do not Induce vomiting; get Immediate medical attention. Wear rubber gloves when handling liquid. If prolonged contact with mist Is likely, wear appropriate respirator. When fluid Is decomposed by heating, toxic gases are released.

**1-13. Servicing - Battery**. Remove the battery from the helicopter for servicing in accordance with procedures in

in TM 11-6140-203-14-2, Chapter 4. Refer to paragraph 9-29 for battery removal procedures.

- **1-14. Servicing Tires**. The ground handling truck assembly tires are inflated to 90 psi.
- **1-14.1. Servicing ATAS Launcher Coolant Bottle.** Service launcher assembly coolant bottle in accordance with TM 9-1440-431-23 1. **CS**

#### 1-15. CLEANING HELICOPTER.

**1-16. DESCRIPTION - Cleaning**. Cleaning the helicopter is important because residues from exhaust gases, dirt, and contamination of any kind will accelerate corrosion, whether coated with preservative compound or not. Helicopter must be electrically grounded prior to any cleaning, maintenance, disassembly, or preservation. Refer to TM 55-1500-344-23.

### WARNING

Solvent should be used with adequate ventilation. Avoid prolonged breathing of the vapors. Do not use solvent near open flames or heat as the products of decomposition are toxic and very Irritating. Wear rubber gloves to avoid solvent contact with skin.

#### **NOTE**

Additional cleaning procedures are covered In this manual under Individual components.

**1-17. Interior - Cleaning**. Clean the interior of the helicopter to prevent debris from falling into the operating mechanism. To dean the upholstery, use dishwashing compound (C61) and water. To remove oil or grease spots, use solvent (C44), then wipe dry with a dean cloth. Clean the interior of the helicopter thoroughly with a vacuum cleaner.

#### CAUTION

Do not use steam or high pressure water hose to dean helicopter. Do not spray water or solvents directly on Isolation mount.

**1-18.** Exterior - Cleaning. Clean the exterior structure in accordance with TM 55-1500-344-23.

#### **CAUTION**

To prevent discoloration, streaking and other damage by Inadvertently splashing cleaning solution on plexiglass, rinse off the area thoroughly with clear water before the surface dries.

- a. Steam cleaning of the helicopter is prohibited.
- b. Low-pressure water, no warmer than 150°F (65°C) may be used providing the following conditions and precautions are observed:
  - (1) A spray head must be used.
- (2) Spray head must be held at a sufficient distance to ensure that the low water pressure does not damage the following;
  - (a) Edge of bonded panels.
  - (b) Electrical components.
  - (c) Bearings.
  - (d) Seals.
  - (e) Oil cooler core and air ducts.
  - c. Preparation of aircraft for washing:
    - (1) Cover open pitot static ports with tape.
    - (2) Install pitot tube cover.
- **1-19. Snow and Ice Removal**. Snow and ice accumulation may be removed from the airframe and rotor blades using de-icing fluid (C58) in accordance with procedures in TM 55-1500-344-23. Refer to TM 1-1500-204-23.

- **1-20.** Plexiglass Cleaning. Observe the following cleaning practices:
- **a.** Clean all transparent plastics with large quantities of dishwashing compound (C61) and water
- **b.** Gently free all mud or dirt with fingers. Do not use sponges or coarse cloths. Rinse the area with low-pressure water while removing the mud.

Do not use aliphatic naphtha TT-N-95, Type I.

Do not use compounds containing any abrasive material or solutions containing chlorinated hydrocarbons. Avoid excessive scrubbing of plastic panels during washing operation.

Remove grease or oil with aliphatic naphtha, Type II (C22).

- d. Allow surfaces to drip dry.
- **e.** To remove or reduce minor scratches apply polishing compound (C113) to affected surfaces.
- **1-21. Acrylic Cleaning.** Acrylic panels on the helicopter are cleaned with large quantities of cleaning compound (C43) and water. Refer to TM 55-1500-204-25/1

### CAUTION

Do not use compounds other than those specified. Avoid excessive scrubbing of acrylics during washing operation.

- **1-22.** Rotor Blades Cleaning. wash rotor blades with dishwashing compound (C61) and water.
- **1-23. Treatment of Aluminum and Magnesium Alloy Corrosion.** Aluminum and magnesium alloy corrosion will be treated in accordance with TM 55-1500-204-25/1. Apply the protective paint finish to the affected area immediately after drying of chemical treatment in accordance with TM 55-1500-345-23.

#### 1-24. PAINTING - TOUCHUP.

Refer to TM 55-1500-345-23 for touchup painting procedures.

# 1-25. TORQUE PROCEDURES AND REQUIREMENTS.

#### **NOTE**

Standard torque to be used if special torque is not specified.

**a.** Requirements Governing Application of Torque Loads.



Standard torque values for final tightening are shown in parts I and II of table 1-1.

(1) The values in table 1-1 apply to cadmiumplated bolts. cadmium-plated nuts, and nuts coated with rnolybdenum disulfide.

#### NOTE

The final torque value for self-locking nuts must be determined by adding the free running torque (torque wrench reading) to the specified torque value. (The free running torque is the torque required to overcome the friction of the nut running down the bolt thread prior to reaching the clamp-up point.)

- (2) Lubricant applied by the manufacturer must not be removed nor additional lubricant added unless otherwise specified.
- (3) The bolts, nuts, and the surfaces they bear on must be clean, dry, and free of lubricant (except as stated in preceding substep (2)).
- (4) The turning (drag) torque required to install a self-locking nut up to the point of final tightening must always be added to the final torque value specified in parts 1 and II of the table 1-1, or the maintenance instruction, as applicable.
- (5) Torques specified in maintenance instructions are special torques that take precedence over those in parts I and II of table 1-1.
- (6) Unless otherwise specified, bolts and screws with strength of less than 125,000 psi do not require a mandatory torque value. The nut and bolt combination will be tightened sufficiently to make a satisfactory joint.
- (7) Bolts and screws with strength of 125,000 psi or higher must have torque applied to table 1-1, part I and II values (except as stated in substep (5) above).

Table 1-1. Recommended Standard Nut Torques

Thread Size	Recommended Torque (in./lb)	Maximum Allowable (in./lb)	Thread Size	Recommended Torque (in. /lb)	Maximum Allowable (in./lb)
8-36	12-15	20	8-32	12-15	20
10-32	20-25	40	10-24	20-25	35
1/4-28	50-70	100	1/4-20	40-50	75
5/16-24	100-140	225	5/16-18	80-90	160
3/8-24	160-190	390	3/8-16	160-185	275
7/16-20	450-500	840	7/16-14	235-255	475
1/2-20	480-690	1100	1/2-13	400-480	880
9/16-18	800-1000	1600	9/16-12	500-700	1100
5/8-18	1100-1300	2400	5/8-11	700-900	1500
3/4-16	2300-2500	5000	3/4-10	1150-1600	2500
7/8-14	2500-3000	7000	7/8-9	2200-3000	4600
1-14	3700-5500	10000	1-8	3700-5000	7600
1-1/8-12	5000-7000	15000	1-1/8-8	5500-6500	12000
1-1/4-12	9000-11000	25000	1-1/4-8	6500-8000	16000

<sup>\*</sup>AN 310, AN365, MS 20365, MS 21042, NAS 1021, NAS 1291, NAS 679

8-36	7-9	12	8-32	7-9	12
10-32	12-15	25	10-24	12-15	21
1/4-28	30-40	60	1/4-20	25-30	45
5/16-24	60-85	140	5/16-18	48-55	180
3/8-24	95-110	240	3/8-16	95-110	170
7/16-20	270-300	500	7/16-14	150-166	280
1/2-20	290-410	600	1/2-13	240-290	520
9/16-18	480-600	960	9/16-12	300-420	650
5/8-18	660-780	1400	5/8-11	420-540	900
3/4-16	1300-1500	3000	3/4-10	700-950	1500
7/8-14	1500-1800	4200	7/8-9	1300-1800	2700
1-14	2200-3300	6000	1-8	2200-3000	4500
1-1/8-12	3000-4200	9000	1-1/8-8	3300-4000	7200
1-1/4-12	5400-6600	15000	1-1/4-8	4000-5000	10000

- (8) If adapters are used such that the adapter and the torque wrench are not at right (90 degree) angles to each other, the wrench or indicator reading must be corrected. Refer to TM55-1500-204-25/1
- **(9)** The bolt must not be rotated during installation or application or torque to nut.
- (10) Checking fasteners accurately to determine if they have been tightened to the specified torque value is not possible. A fastener that has been tightened to a specified torque value requires approximately 10% more torque than was originally applied to overcome friction and start the fastener turning. To ensure proper torque value has been applied, the fastener should be backed off from one-half to one full turn and retightened to the correct torque value. A torque wrench should not be used for the backoff operation.
- **b.** Installation of Castellated Nuts on Nonrotating (Static) Parts. Maximum applied torque must not exceed the applicable values in part I and II of table 1-1.
- **c.** Installation of Castellated Nuts on Rotating (Dynamic) Parts. When tightening castellated nuts on bolts, it is possible that the cotter pin holes will not line up with the slots in the nuts for the range of recommend installation torques. In such a case, the nut may be tightened to minimum torque and rotated one castellation to line up the nearest slot with the cotter pin hole.
- **d.** Installation of Self-locking Tension and Steel-Type Nuts.
- (1) Use torques in part I of table 1-1 for tensiontype cadmium-plated steel nuts.
- (2) Use torques in part II of table 1-1 for shear-type cadmium-plated steel nuts.
  - e. Installation of Bolts General.
- (1) If the bolt can be inserted through the material and started into the nut by the fingers, use the applicable torque in parts I and II of table 1-1.
- (2) If installing the bolt into a close tolerance hole, or under other conditions that increase the tightening resistance, torque to the high limit of the applicable recommended torque in parts I and II of table 1-1

- f. Installation of Bolts into Threaded Parts.
- (1) Use the applicable torque in part I of table 1-1 when installing the bolt into a threaded part if the mating thread length is equal to or greater than one diameter of the bolt.
- **(2)** Use part II of table 1-1 if the mating thread length is less than one diameter of the bolt.

#### **NOTE**

The requirements in preceding steps c. and f. also apply to thread inserts.

# 1-26. RE-USE OF SELF-LOCKING NUTS.

For re-use of self-locking nuts refer to TM 55-1500-204-25/1 .

# 1-27. LIST OF CONSUMABLE MATERIALS.

### WARNING

Special attention to label precautionary instructions regarding: product usage, safety, ventilation requirements. and emergency information should be followed before using any consumable supplies.

1-28. Description. Consumable maintenance supplies and materials are listed in table 1-2 in alphabetical order. Each consumable also has an item number assigned for ease of location and reference. When an item number is unknown You may locate any consumables used within this manual through its alphabetical arrangement. When an item number is referenced in the manual, you may locate the item through its C designator and item number. C designators are used only with consumable maintenance supplies and materials. Consumable maintenance supplies and materials tables are found only in this chapter; therefore, the table number will not be referenced in the text. In the event of deletion of any consumable maintenance supplies and material from the list, the item number shall remain in proper numerical sequence and the word "deleted" will be placed in the empty space. For those materials that have been replaced or for which an alternate material has been listed, a statement such as the following shall be entered: "Replaced, use fibrous cord (C48)".

**Table 1-2. Consumable Maintenance Supplies and Materials** 

The supplies and materials listed in this table are required for maintenance support of this equipment and are authorized to be requisitioned by CTA 50-970.

em No.	Description	Ref No. and FSCM	NSN
1	Accelerator	81C29 (73842)	Local Purchase
2	Acetone, Technical	O-A-51 (81348)	6810-00-184-4796
3	Acid, Acetic	O-A-76 (81348)	6810-00-275-1215
4	Acid, Boric	O-C-265-(81348)	6810-00-264-6535
5	Adhesive	Eccobond (04552)	8040-00-148-7183
6	Adhesive	EC2216 (94960)	8040-00-145-0019
7	Adhesive	MIL-A-46050 (81349)	8040-00-142-9193
8	Adhesive	MMM-A-121 (81348)	8040-00-165-8614
9	Adhesive	MMM-A-122 (81348)	8040-00-664-0439
10	Adhesive, BHT SPEC 299-947-152 Type I, Class 1	DAPCOTAC 3300 (58093)	8040-01-136-5464 8040-00-097-6524
11	Adhesive	EA9309.3NA (04347)	8040-01-163-3481
12	Adhesive— Epoxy Metalset A4 RP1258 EA9340 EPI Seal 1010	MIL-A-14042 (90414) (02684) (22893) (19012)	8040-00-944-7292
12.1	Adhesive Repair Kit	S1607-7021(78286)	1560-00-856-9222
13	Adhesive Film and Primer, Variable Cure System (225° to 280° F)	299-947-121, Type II (97499) (92627)	
14	Adhesive, General Purpose EC1300L	BHT SPEC 299-947 07	8040-00-514-1880
15	Adhesive — Insulation	No. 34 (04963)	Local Purchase
16	Adhesive — Rubber Base	MMM1617, Type II (81 348)	8040-00-664-4318
17	Adhesive (Sealant) EC1675-B2 or Proseal 890-B2	299-947-107, Type III, Class 7 (97499)	8030-00-723-4599
17.1	Adhesive, Urlane (Part A and B) 5738-A/BX	EC3549AB(04963)	8040-01-016-4726

Table 1-2. Consumable Maintenance Supplies and Materials (Cont)

Item No.	Description	Ref No. and FSCM	NSN
18	Adhesive, Silicone Rubber, Color Red	RTV-106 (01139)	8040-00-941-9984
19	Adhesive, Two-Part A and B EA934NA	299-947-100, Type II, Class 2 (97499) (04347)	8040-01-102-2098
20	Adhesive (Urethane) (8089)	(01139)	8030-01-145-1768
21	Alcoholic Phosphoric Acid Solution Turco No. 1	MIL-C-10578 (81349)	6850-00-270-5551
22	Aliphatic Naphtha	TT-N-95, Type II (81348)	6810-00238-8119
23	Aluminum Wool	MIL-A-4864 (81349)	5350-00-597-5367
24	Antiseize Compound Hi-Temp	MIL-A-907 (81349)	8030-00-597-5367
24.1	Aromatic Naphtha	TT-N-97, Type I, Class A	6810-00-223-9067
25	Asbestos Style 89, Type II	TM 89-3-64 (92798)	5330-00-938-1719
26	Barrier Material Grease and Water proof	MIL-B-131, Class 1I (81349)	8135-00-282-0565
27	Barrier Material Water- proofed Grade A, Class I	MIL-B-121, Type 1 (81349)	8135-00-224-8885
28	Bottle, Screw Cap. 16 oz	8275G (64484)	6640-00-404-0660
29	Bottle, Screw Cap. 32 oz	8275H (64484)	6640-00-404-0661
30	Brasso		Local Purchase
31	Brush, Stiff Fiber Bristle	HB6 43 TY2 (81349)	7920-00-514-2417
32	Calcium Sulfate	Commercial	
33	Cement, Silicone Adhesive	RTV 732 (71984)	8040-00-877-9872
34	Cement, Silicone Adhesive A4000	MIL-A-25447 (71984)	8040-00-057-2324
35	Cement - Type 81057	(73842)	Local Purchase
36	Cement - Type III	MIL-A-5092 (81348)	8040-00-152-0067
37	Cheesecloth	(81348)	8305-00-267-3015
38	Chemical Conversion Coating (Alodine)	MIL-C-81706 (81 349)	8030-00-057-2354

Table 1-2. Consumable Maintenance Supplies and Materials (Cont)

Item No.	Description	Ref No. and FSCM	NSN
39	Chromic Acid - 5% Solution	O-C-303 (81 343)	6810420-174-1818
40	Chromic Pickle-Brush Solution Type VI	DOW No. 19 (96717)	8030-00-764-6176
41	Cleaning Compound	MIL-C-0043616CL2 (81349)	6850-00-144-9816
42	Cleaning Compound, Aircraft Surface, Alkaline Base	MIL-C-25769H	6850-30-935-0995
43	Cleaning Compound, Aircraft Surface, Alkaline, Waterbase	MIL-C-25769 (81349)	6850-00-935-0995
44	Cleaning Compound, Solvent, Trichlorotrifluorethane	MIL-C-81302, Type II (81349)	6850-00-105-3084
45	Cloth, Abrasive, Aluminum Oxide	PC 451, Type 1 (81348)	5350-00-246-0330
45.1	Cloth, Cleaning, Low-Lint	MIL-C-85043, Type II (81349)	7920-00-044-9281
46	Cloth, Fiberglass, 120 or 127 Weave Volan, a finish	MIL-C-9084 (81349)	8305-00-082-6135
47	Compound, Lacquer	Torque Seal Green (01195)	8305-00-408-1137
48	Cord, Fibrous	MIL-C-5040 (81349)	4020-00-246-0688
49	Cord, Fibrous	MIL-C-5040 (81349)	4020-00-240-2154
50	Corrosion Preventive Compound	MIL-C-16173, Grade 1 (81349)	8030-00-231-2345
51	Corrosion Preventive Compound	MIL-C-16173, Grade 2 (81349)	8030-00-244-1297
52	Corrosion Preventive Compound	MIL-C-15074 (81349)	8030-00-664-4017
53	Corrosion Preventive Compound	MIL-C-11796, Class 3 (81349)	8030-00-231-2353
53.1	Corrosion Preventive Compound	MIL-C-23411 (81349)	8030-00-838-7789
54	Deleted		
56	Cushioning Cloth	PC-458 (81348)	5350-00-221-0872
56	Cushioning Material, Cellulosic	PPP-C-843, Type II (81348)	8135-00-664-6958
57	Dampening Fluid	W-D-1078 (81348)	9150-00-024-9623

Table 1-2. Consumable Maintenance Supplies and Materials (Cont)

58 59	De-Icing Fluid Denatured Alcohol	MIL-A-8243 (81349)	6850-00-901-0591
59	20.16.16.16.1	<b>a - - - - - - - - - -</b>	
		O-E-760 (81349)	6810-00-201-0907
60	Desiccant, Activated	MIL-D-3464 (81349)	6850-00-264-6573
61	Dishwashing Compound	P-D-410 (81348)	7980-00-880-4454
62	Drycleaning Solvent	P-D-680, Type 11 (81348)	6850-00-274-5421
63	Ethylene Glycol, Mono Butyl Ether	TT-E-776 (81348)	6810-00-281-2001
64	Enamel, Staking, Glyptol	MIL-E-22118A (81349)	8010-00-823-8046
65	End Dip Compound	AE10187-001 (00624)	8030-00-907-0879
66	Epoxy, Epon 828	(36131)	8040-00-952-5713
67	Fabric, Nylon Type 3629N	(73842)	Local Purchase
68	Fabric, Type 3603N	(73842)	Local Purchase
69	Fairing Compound	RP1257-3A (02684)	8030-00-891-3113
70	Fastener Tape (Pile)	MIL-F-21840 (81349)	8315-00-926-4930
71	Fiberglass Cloth	MIL-C-9084	8305-00-530-0109
72	Fingerprint Remover, Corrosion Preventive	MIL-C-15074 (81349)	8030-00664-4017
73	Fluid, Hydraulic,	MIL-H-5606 (81349)	9150-00-252-6383
	(Refer to TB 55-1500-334-24)	MIL-H-83282 (81349)	9150-00-149-7431
74	Fuel Barrier, Type 1282C	1282C (73842)	Local Purchase
75	Fuel, Jet, JP-4	MIL-T-5624 (81349)	9130-00-256-8617
76	Gloves, White, Cotton	MIL-G-3866 (81349)	8415-00-268-8353
77	Grease, Aircraft	MIL-G-81322 (81349)	9150-00-944-8953
78 79	Grease, Aircraft Grease, Aircraft	MIL-G-23827 (81349)	9150-00-985-7246
	Driveshaft Coupling	204-040-755-5 (97499)	9150-00-506-8497

Table 1-2. Consumable Maintenance Supplies and Maintenance (Cont)

Item No.	Description	Ref No. and FSCM	NSN
80	Grease, Helicopter, Oscillating Bearing	MIL-G-25537 (81349)	9150-00478-0055
81 81.1	Grease, Silicone Grease, Silicone, Dow Coming II, or equivalent	MIL-L-15719 (81349) (71984)	9150-00-257-5358 9150-00-294-0860
82 83	Hydraulic Fluid, Preservative Ignition Sealing Compound, DC-4	MIL-H-6083 (81349) MIL-S-8660 (81349)	9150-00-935-9807 6850-00-880-7616
84 85	India Stone, Fine Ink, Marking Stencil (White)	SS-S-736A (81348) TT-1-1795 (81348)	5345-00-260-0759 7510-00-224-6732
86 87	Insulation Sheet, Electrical Jet Engine Lubrication Oil (Grade 1010)	MIL-P-15037 (81347) MIL-L-6081 (81349)	5970-00-118-8838 9150-00-273-2388
88 89	Lacquer, Acrylic, Olive Drab Lacquer, Acrylic, Low- Reflective, Type I, Black	MIL-L-19538 (81349) MIL-L-46159A (81349)	8010-00-082-2479 8010-01-042-4196
90 91	Lacquer, Acrylic, Clear Lacquer, Acrylic, Gloss Gull Gray No. 36440, P-95	TT-L-50 MIL-L-81352 (81349)	8010-00-515-2487 8010-00-935-7060
92	Lacquer, Acrylic, Gloss Red No. 11136	MIL-L-19537 (81349)	8010-00-551-7934
93	Lacquer, Acrylic, Glossy White No. 17875	MIL-L-81352 (81348)	8010-00-935-6608
93.1 94	Lens Cleaning Tissue LHE Cadmium Solution (Brush On) Macro Bronze No. 1 Enthox 982	M42215AJ (97942) MIL-STD-865 (13429)	6640-00-559-1384
95	Lockwire, Steel, 0.020 Dia, Corrosion Resistant	539798 (73471)	9505-00-596-5101

### 1-18 Change 24

Table 1-2. Consumable Maintenance Supplies and Materials (Cont)

Item	Description	Ref No. and FSCM	NSN
No			
96	Lockwire, Steel, 0.032	MS20995C32 (96906)	9505-00-293-4208
	Dia, Corrosion Resistant	,	
97	Lockwire, Steel, 0.041	MS20995C41 (96906)	9505-00-331-3275
	Dia, Corrosion Resistant	,	
98	Lockwire, Copper, 0.020	MS20995CY20 (96906)	9525-01-047-6455
99	Lubricant, Dry, Molybdenum	MIL-M-7866 (81349)	6810-00-264-6715
	Disulphide	,	
100	Lubricant, Solid Film Air	MIL-L-46147A	9150-00-142-9361
	Drying, Corrosion Inhibiting		
101	Lubricating Oil	W-L-825 (83148)	9150-00-598-2911
102	Lubricating Oil (Grade 30)	MIL-L-2104 (83149)	9150-00-186-6681
103	Lubricating Oil, Synthetic	MIL-L-23699 or MIL-L-7808	9150-00-180-6266
	Base, Turbine Engine	(81349)	9150-00-782-2627
103.1	Lubricating Oil (Primary)	DOD-L-85734	9150-01-209-2684
104	Lubricant, Silicone	MIL-S-8660 (81349)	6850-00-880-7616
105	Lubricant, Solid Film	MIL-L-46010 (81349)	9150-00-948-6912
106	Lubricant, Surgical (KY Jelly)	,	6505-00-153-8809
107	Methyl-Ethyl-Ketone (MED)	TT-M-261 (81348)	6810-00-281-2785
107.1	Molding Plastic	Nopcofoam G506 (87570)	9330-01-006-5310
108	Needle, 18 Gage	MIL-N-36124 (81349)	6515-00-754-2834
108.1	Nonslip Walking Compound	MIL-W-5044 Type II	5610-00-641-0426
108.2	Optical Cleaning Compound	Lens Cleaner (06650)	6850-00-392-9751
109	Pad, Scouring	LP50, Type II	7920-00-753-5242
110	Paint Remove, Alkaline	MIL-R-81294A	8010-00-926-1488
	Type, General	(Equivalent MIL-R-8633A)	
111	Petrolatum	W-P-236 (81348)	9150-00-250-0926
	(Technical Vaseline)	,	
112	Plastic, Strip, Pressure	SJ8561 (76381)	9330-00-169-6407
	Sensitive	,	-
113	Polishing Compound	RS-69 (32834)	1560-00-450-3622
	(Transparent Plastic)	,	

Table 1-2. Consumable Maintenance Supplies and Materials (Cont)

Item No.	Description	Ref No. and FSCM	NSN
114	Primer, Adhesive	MIL-S-22473, Grade N (81 349)	8030-00-935-5816
115	Primer, Adhesive (use with item 120)	MIL-S-22473, Grade T (81 349)	8030-00-181-8372
116	Primer, Epoxy Polyamide (Yellow)	MIL-P-23377 Type I (81 349)	8010-00-082-2450
116.1	Primer, Epoxy Polamide (Green)	MIL-P-23377, Type II (81 349)	8010-01-266-5677
117	Primer, Lacquer Type	MIL-P-7962 (81 349)	8010-00-584-2426
118	Primer, Zinc Chromate (Low Moisture Sensitivity)	TT-P-1757 (81348)	8030-00-297-0593
119	Putty, Chromate	MIL-P-8116 (81349)	8030-00-664-4968
119.1	Rag Wiping, Cotton and Cotton Synthetic	A-A-531, Grade B (58536)	7920-01-084-3860
120	Retaining Compound, Sealing, Anaerobic CV 4-10 (use with item 115)	MIL-S-22473, Grade E	8030-00-081-2328
121	Rod, Welding. Aluminum Type 1, Class FS-RA 143	QQ-R-566 (81348)	3439-00-268-9654
122	Rod, Welding, Steel, Type 347,	MIL-R-5031 (81 349)	3439-00-528-1490
123	Class 5 Sandpaper, 80 Grit	P-P-101 (81348)	5350-00-619-9167
124	Sandpaper, 180 Grit	P-P-101 (81348)	5350-00-721-8117
125	Sandpaper, 320 Grit	P-P-101 (81348)	5350-00-224-7203
126	Sandpaper, 400 Grit	P-P-101 (81348)	5350-00-224-7201
127	Sandpaper, 600 Grit	P-P-101 (81348)	5350-01-060-8212
128	Sealant, Epoxy Resin	EPKIC (04347)	8040-00-777-0631
129	Sealant, Proseal 706	MIL-S-8784 (81349)	8030-00-616-9191
130	Sealing Compound	MIL-S-8802 (81349)	8030-00-723-2746
131	Sealing Compound	MIL-S-8802, Type B (81349)	8030-00-753-5006
131.1	Sealant, Proseal 606C-2	MIL-S-8784CLB-2 (81349)	8030-00-680-2041

Table 1-2. Consumable Maintenance Supplies and Materials (Cont)

ltem No.	Description	Ref No. and FSCM	NSN
132	Sealing Compound, F900 Torque Seal	(01195)	8030-01-066-8156
132.1	Soap, Toilet, Cake	P-S-620 (81348)	8520-00-531-6484
133	Solder, Tin Alloy	QQS-571 (81348)	3439-00-224-3567
134	Syringe, Hypodermic	MIL-S-36157 (81349)	6515-00-754-0412
35	Talcum Powder	U-T-30A (81348)	8510-00-817-0295
36	Tape, Adhesive Pressure (Type II)	PPP-T-60 (81348)	7510-00-663-3732
37	Tape, Electrical	MIL-I-15126 (81349)	5970-00-959-0012
138	Tape, Dissimilar Metal Separation	MIL-T-23142 (81349)	7510-00-472-4021

Table 1-2. Consumable Maintenance Supplies and Materials (Cont)

Item No.	Description	Ref No. and FSCM	NSN
139	Tape, Doubleface (Scotch No. 666 3M Corp)	UUT91 (81348)	7510-00-634-1549
140	Tape Fastener, Hook	MIL-F-21840 (81349)	8315-00-926-4931
141	Tape Fastener, Pile	MIL-F-21840 (81349)	8315-00-926-4930
142	Tape, Instrument Marking	L-T-90, Type I, Class B Yellow Red Green	7510-00-550-7125 7510-00-550-7126 7510-00-550-7129
143	Tape, Masking	A-A-883	7510-00-283-0612
144	Tape, Teflon, Self-Adhesive	5490 (76381)	8135-00-923-0591
145	Tedlar	FED SPEC L-P-104B (81348)	
146	Thermomelt (188)	(94858)	6685-00-938-0435
147	Thinner (for Acrylic Nitrocellulose Lacquer)	MIL-T-19544 (81349)	8010-00-527-2897
148	Thread, Cotton, Binding	V-T-276F (81348)	8310-00-187-3920
149	Thread, Nylon, 1616 Test	VT-295 (81348)	8310-00-227-1244
150	Toluene, Technical	TT-548C, Type 2 (81348)	6810-00-281-2002
151	Trichloroethane	O-T-620	6810-00-930-6311
152	Urethane	MIL-P-26514 (81349)	8135-00-181-7456
153	Varnish, Alkali-Resistant	TT-V-119 (81348)	8010-00-597-7856
154	Webb, Nylon Abrasive Pad, Type A (Scotchbrite)	MIL-A-9962A, Type I, Class 1 (76381)	5350-00-967-5092
155	Wool, Steel	FF-S-740, Type I, Class 0 (81348)	5350-00-242-4405
156	Paint, Top Coating, Silver, Sermetel	(78710)	8010-00-111-6384
157	Polyamide Epoxy Primer	MIL-P-23377 (81349)	8010-00-082-2450
158	Grease	130A (73219)	9150-00-754-0063
159	Adhesive	RTV732	8040-00-833-9563
160	Plastic Sheet	L-C-110	8135-00-582-5170
161	Sealant	RTV128	8040-01-252-8567
162	Tape, Adhesive Pressure	7455 (88301)	7510-00-180-6288
163	Shellac	TT-S-300 (81348)	8010-01-070-4549

# 1-29. SPECIAL TOOLS AND TEST EQUIPMENT.

1-30. Description. Special tools and test equipment are listed in table 1-3 in alphanumeric order. Each tool or piece of test equipment has an item number assigned for ease of location and reference. When an item number is unknown, you may locate special tools and test equipment through alphanumeric arrangement within the table. When an item is referenced in the manual, you may locate the item through a T-designator and item number. T-designators are used only with special tools and test equipment. The special tools and test equipment table is found only within this chapter; therefore, the table number will not be referenced within the text. A

complete listing of all special tools and test equipment authorized for use to perform maintenance on the helicopter accessories are contained in the helicopter parts manual. The following usability codes apply to table 1-3.

#### **USABILITY CODES**

R — Removal
D — Disassembly
I — Inspection
RP — Repair/Replace

T — Testing
A — Assembly
I N — Installation
AD — Adjustment

S/P — Storage/Preservation

Table 1-3. Special Tools and Test Equipment

Item No.	Part Number	Nomenclature	Usability Code	Figure Reference
1	B-4951	Kit, Balancing — VIBREX	Т	
2	BH112JA-36	Tester, Exhaust Gas Temp		
3	BH112JB-53	Tester Exhaust Gas Temp T.		
4	FRES 10	Adapter, Torque	IN	
5	MIL-1-18997/1	Gauge, Pressure (0-1000 PSI)	I	
6	MPI	Gage, Pressure (0-100 PSI)	Т	
7	PD1201	Power Wrench	R/IN	
8	PD2733	Adapter, Mast Nut	R/IN	
9	PD2734	Socket, Mast Nut	R/IN	
10	T100061	Tool, Float Inflation	A/IN	
11	T100089	Adapter, Aircraft Hoisting	R/IN	
12	T100220	Sling, Main Rotor	R/IN	
13	T101401	Scope Assembly	AD	
14	T101444	Tool, Tab Bending	AD	
15	T101445	Gage, Tab	AD	

Table 1-3. Special Tools and Test Equipment (Cont)

Item No.	Part Number	Nomenclature	Usability Code	Figure Reference
16	T101491	Puller, Bearing	R	
17	T101499	Fixture, Holding	D/A	
18	T101503	Tool, Bearing	R/IN	
19	T101511	Wrench, Spline	R/IN/D	
20	T101529-3	Tool, Staking	RF	
21	T101529-5	Assembly, Base	D/A	
22	T101529-7	Assembly, Housing	D/A	
23	T101529-23	Punch and Set	D	
24	T101529-25	Pilot	D	
25	T101529-27	Support	RF	
26	T101529-29	Shims	IN/AD	
27	T101530	Tool, Roll Staking	RP	
28	T101532	Support Assembly	AD	
29	T101536	Asssembly, Target	AD/T	
30	T101547	Tool, Staking	RF	
31	T101554	Wrench, Socket	D/A	
32}	T101555 5120-EG-009	Tool, Holding Tool, Holding	R/IN R/IN (Alternative)	
33	T101584	Tool, Roll Staking	A/RP	
34	T101740	Tool, Rigging	AD	11-15
35	T101741	Tool, Flapping Axis	AD	11-15
36	T102040	Wrench	R/IN/D	
37	T102103	Dehydrator	S/P	
38	1560-0H58-105-1	Tool	RF	D-157
39	2539	Post Assembly	AD	

#### TM 55-1520-228-23

Table 1-3. Special Tools and Test Equipment (Cont)

Item No.	Part Number	Nomenclature	Usability Code	Figure Reference
40	6796963	Tool, Engine Lifting	R/IN	
41	7A050	Kit, Propeller Balancing	AD	
42	7HEL069	Balancing Kit, Main and Tail Rotor	AD	
43	810550	Level, Bull's Eye	AD	
44	847A	Puller, Battery Terminal	D	
45	946-29760	Test Fixture	Т	
46	951	Bearing Puller Attachment	R	
47	96369	0.006 Wire Gage	1	
48	209-071-239-1 CS	Wrench, Ejector Rack Release	R/IN	
49	T101844-105 CS	Boresight Device Set	AD/T	
50	76008-159 <b>CS</b>	Pin Set, Ground Safe	AD/T	
51	NSN 6230-00-401-0712 <b>CS</b>	Flashlight, IR	AD/T	
52	AAA-S-133 <b>CS</b>	Spring Scale	AD	
53	TTU-27/E	Tester Tachometer	AD/T	
54	BH22167	Temp Indicator Check Adapter		
55	BH22196	RPM Check Adapter		
56	BH22168	Temp Trim Adapter		
57	1ABB03320AGA	Gauge, Pressure (0-30 PSI)	I	

#### 1-31. SUPPORT EQUIPMENT.

**1-32. Description.** Support equipment required for maintenance performance on the helicopter is listed in alphanumeric sequence in table 1-4. Each item is assigned a number for ease of location and

reference. The S designator and item number is referenced in the text where the equipment is used. The table number will not be referenced since the support equipment table is found only within this chapter. Items not listed within this table may be found in TM 55-1520-228-23P.

Table 1-4. Support Equipment

ITEM	PARTIE	NOMENO, ATURE
NO.	PART NO.	NOMENCLATURE
1	AA173-1251	Tow Bar
2	AA1730-1301-8	Rod Anchor
3	D-5A	Test Stand - Hydraulic
4	DB3188L	Drain Unit - Transmission
5	DB3225L	Drain Unit - Tall Rotor Gearbox
6	Delete	
7	Delete	
8	Delete	
9	Delete	
10	Delete	
11	206-070-472-11	Cover and Shield
12	214-782-001	Maintenance Hoise
13	369A9905	Truck, Ground Handling
14	53D22020	Jack, Helicopter - 5-ton
15	585819	Tiedown Strap
16	* Make Item	Hoisting Adapter
* (F	Reference TM 55-1500-338-S, Pages 3-2 a	

Change 24 1-24.1/(1-24.2 blank)

### SECTION II. LUBRICATION

#### 1-33. LUBRICATION REQUIREMENTS.

**1-34. Description** — Lubrication Requirements. The lubrication chart (figure 1-5) consists of a perspective diagram of the helicopter, indicating parts requiring periodic lubrication.

The lubrication chart uses symbols and abbreviations to indicate the required lubricant, method of application, end time interval for lubrication of each part listed. A key on the chart defines the meanings of symbols and abbreviations. Refer to figure 1-1 for servicing of engine, transmission, and tail rotor gearboxes which are lubricated by oil.

# SECTION III. HANDLING, JACKING, MOORING, HOISTING, AND SLING LOADING

#### 1-35. GROUND HANDLING.

- **1-36. Description.** The ground handling requirements in extreme environmental conditions (heat, cold, dust, high humidity, etc.) consists essentially of procedures followed during normal conditions with added emphasis on the following:
- **a.** Wet weather and high humidity conditions create corrosion, rot, mildew, and mold. Keep helicopter as clean and dry as possible to prevent deterioration.
- **b.** Check frequently to ensure drain valves are open and free of blockage.
- **c.** Ensure fuel tanks are full to prevent internal condensation during cold weather.
- **d.** Ensure protective covers are installed and secured.
- **e.** If space is available, park helicopter in hangar or shed.
- **f.** The following paragraphs contain information necessary for hoisting, jacking, leveling, mooring, parking, towing, and other ground handling operations for the helicopter.

### CAUTION

Ensure that main rotor tiedown (6, figure 1-6) is installed prior to any ground handling,

Do not move helicopter with pilot or copilot windshield removed.

1-37. Towing.

### CAUTION

Do not move helicopter for 25 minutes after power has been removed from the AN/ASN-43 compass to preclude damage to the compass. However, if the helicopter must be moved before 25 minutes has elapsed, apply power to the compass and allow a 5-minute warmup time. The helicopter may then be moved without damage to the gyro with power applied.

### CAUTION

Install ground handling trucks (\$13) in accordance with detail instructions given in Chapter 3. Use ground handling extension lever only for raising helicopter after installation of truck assemblies. Never ground handle helicopter by the vertical stabilizer, nor step on tail skid to raise front of helicopter.

#### **NOTE**

Inspect tow fittings for security prior to attachment of tow bar.

**a.** Tow fittings (11, figure 1-6) are provided on forward inboard portion of each landing gear skid for





Figure 1-5. Lubrication Chart (Sheet 1 of 6)



Lubricate swashplate as follows:


- a. Inspect swashplate (5) and determine whether there are four holes (8) in the cap, or if there is one lubrication fitting (16) and no holes. If there are four holes (8) make certain they are open and unobstructed.
- b. If there are four holes (8), apply lubricant at lubrication fitting (11) until lubricant is purged from one or more holes (8). Rotate outer ring (12) 360 degrees in 90 degree increments. Repeat lubrication at each increment to ensure thorough lubrication of bearings.
- c. If there is one lubrication fitting (16), apply lubricant at lubrication fitting (16) until lubricant is purged from lower seal (20). Rotate outer ring (17) 360 degrees in 90 degree increments. Repeat lubrication at each increment to ensure thorough lubrication of bearings. When lubrication fitting (16) is installed, lubrication fitting (19) should be plugged. If lubrication fitting (19) is open, do not use it because lubricant will purge past seal (20) and bearings (18) will not be lubricated.

CAUTION

If both lubrication fittings (16) and (19) are installed or if the assembly does not purge as described, the swashplate may be improperly assembled and the bearings may not be lubricated. Request assistance from AVIM. Reference TB 55-1520-228-20-24.

206900-540-2

Figure 1-5. Lubrication Chart (Sheet 2)



#### DETAIL **B**

#### OIL LUBRICATED ROTOR HUB




Do not allow main rotor blades to rotate on pitch axis while main rotor pitch links are disconnected in following step. If blade is inadvertently allowed to rotate on pitch change axis beyond 90 degrees, the main rotor grip retention strap must be replaced prior to operation of the helicopter.

- a. Lubricate trunnion lubrication fittings (26) and the opposite trunnion lubrication fittings (22) as shown. During lubrication procedure disconnect main rotor pitch links and support pitch horn to prevent rotor blades from rotating on pitch change axis. Apply lurbicant at fitting, rotate trunnion bearing 360 degrees clockwise and 360 degrees counterclockwise. Apply lubricant until clean lubricant is purged out of bearing seal. Lubricate through 2 fittings at each trunnion. Connect main rotor pitch links and ensure that cotter pins are installed in bolts.
- Lubricate grip reservoirs and pillow block reservoirs as shown on figure 1-1, Servicing Diagram.

206900-540-3

Figure 1-5. Lubrication Chart (Sheet 3)



#### **GREASE LUBRICATED ROTOR HUB**


If grease lubricated rotor hub has been installed, lubricate as follows:

## WARNING

Do not allow main rotor blades to rotate on pitch axis while main rotor pitch links are disconnected in following step. If blade is inadvertently allowed to rotate on pitch change axis beyond 90 degrees, the main rotor grip retention strap must be replaced prior to operation of the helicopter.

- a. Lubricate trunnion lubrication fittings (33) and the opposite trunnion lubrication fittings (28) as shown. During lubrication procedures disconnect main rotor pitch links and support pitch horn to prevent rotor blades from rotating on pitch change axis. Apply lubricant at fitting, rotate trunnion bearing 360 degrees clockwise and 360 degrees counterclockwise. Apply lubricant until clean lubricant is purged out of bearing seal. Lubricate through 2 fittings at each trunnion. Connect main rotor pitch links and ensure that cotter pins are installed in bolts.
- Purge grip cavities with grease at grease fittings (32 and 34) until clean grease is purged past relief valves (27 and 30).
- c. Purge pillow block cavities with grease at grease fittings (29 and 31).
- d. When grease lubricated hub is placed in service, lubricate after first runup, after first flight, and each 25 hours thereafter.

Figure 1-5. Lubrication Chart (Sheet 4)




DETAIL D

## TAIL ROTOR PITCH CONTROL LUBRICATION FITTINGS

Lubricate two pitch control lubrication fittings (36) as follows:

- a. Loosen boot (35) on large end to prevent pumping grease into tail rotor gearbox.
- b. Lubricate two fittings (36) as shown on detail D until grease just purges past sad.
   Do not over lubricate. Clean boot of all grease after purging.
- Check to ensure that vent holes in control tubs and bushing are aligned and free of obstruction. (Reference para 5-212 and included note.)
- d. Secure boot (35).




The improved tail rotor hub trunnion (MWO 55-1520-228-50-25] shall be purge lubricated with grease MIL-G-81322 as follows:

- a. Every 25 hours.
- b. After each day's operation when exposed to rain, snow, washing, or other moisture.
- c. At each runup when in flyable storage.

206900-540-5

Figure 1-5. Lubrication Chart (Sheet 5)





Do not use glass syringe. Breakage of a glass syringe can result in severe injury.

### DETAIL F

#### TAIL ROTOR DRIVESHAFT HANGER BEARINGS

Lubricate all eight bearings with hypodermic syringes (C134) and 18 gage needle (C108) as follows: (use of a hand grease gun with locally procured or made needle adapter is acceptable.)

- a. For bearings having no grease ports,insert tapered portion of needle under lip of bearing seal using care to avoid damage to seal.
- b. For bearings, P/N 20S-040-339-9 having grease ports lubricate through these ports.
- c. Inject 0.5 cc to 1.0 cc of grease (C77)into each bearing
- d. After lubrication is complete, wipe off all excess grease.


## CAUTION

Do not exceed lubricant quantity stated. Excessive lubrication or lubrication by pressure method will damage bearing seals.

- 1. Starter-Generator Gear Shaft and Engine Adapter Splines
- 2 Tail Rotor Spline Couplings
- 3. Engine to Transmission Driveshaft Couplings
- 4. Ground Handling Truck (Wheels)
- 5. Swashplate
- 6. Cap Assembly
- 7. Seal
- 8. Hole (Cap has four symmetrically spaced holes)
- 9. Seal
- 10. Bearing
- 11. Lubrication Fitting
- 12. Outer Ring
- 13. **Seal**
- 14. Cap Assembly
- 15. Seal
- 16. Lubrication Fitting
- 17. Outer Ring
- 18. Bearing
- 19. Lubrication Fitting

- 20. Seal
- 21. Grip Oil Reservoir
- 22. Trunnion Lubrication Fitting
- 23. Pillow Block Reservoir Filler Plug
- 24. Grip Oil Reservoir
- 25. Pillow Block Reservoir Filler Plug
- 26. Trunnion Lubrication Fitting
- 27. Relief Valve
- 28. Trunnion Lubrication Fitting
- 29. Pillow Block Grease Fitting
- 30. Relief Valve
- 31. Pillow Block Grease Fitting
- 32. Grease Fitting
- 33. Trunnion Lubrication Fitting
- 34. Grease Fitting
- 36. Boot
- 36. Lubrication Fittings
- 37. Driveshaft Hanger Bearing
- 38. Lubrication Fitting 206900-540-6

Figure 1-6. Lubrication Chart (Sheet 6)



- 1. Forward Jogging and Tierdoen Fitting
- 2. Washer
- 3. Bolt
- Hosting Adapter
   Main Rotor Mast Nut
- 6. Main Rotor Tiedown
- 7. Engine Exhaust Cover
- 8. Engine Inlet Shield

- 9. Aft Jacking and Tiedown Fitting
- 10. Jack
- 11. Tow Fitting
- 12. Washer
- 13. Washer
- 14. Screw
- 15. Pitot Tube Cover

Figure 1-6. Ground Handling (Sheet 1 of 2)

## **JACK PAD LOCATION DATA**




Figure 1-6. Ground Handling (Sheet 2)

attachment of a standard aircraft tow bar (S1) Helicopter is towed on ground handling truck assemblies mounted on the landing skids.

## CAUTION

Tow the helicopter slowly, observing obstructions to prevent damage to main rotor blades

**b.** Station one person in area of horizontal stabilizer to apply a light force, as needed, to the tailboom to guide and balance the helicopter and to advise towing vehicie driver of conditions at tailboom during towing.

## 1-38. Jacking.

## CAUTION

It is required that area around helicopter be roped off and signs displayed to warn that: THIS HELICOPTER IS ON JACKS.

#### NOTE

The two forward jacking and tiedown fittings (1, figure 1-6) are loose equipment and must be installed prior to jacking.

- a. Place two jacks (S 14) (10) under two forward jacking and tiedown fittings (1) located forward of the landing gear crosstube at each side, and one jack(10) under the aft jacking and tiedown fitting (9) aft of the anticollision light.
- **b.** Raise helicopter evenly. Observe the following precautions while helicopter is supported on jacks
  - (1) Do not climb, on or enter helicopter.
- (2) Personnel will use caution to avoid bumping or otherwise disturbing helicopter while helicopter is on jacks.

## CAUTION

Do not leave helicopter unattended when using jacks without positive locks.

**c.** After necessary work, lower helicopter slow and evenly. Remove jacks.




Figure 1-6.1. OH-58 A & C Paved Surface Mooring Configuration

Table 1-5. Tie-Down and Mooring Hardware

Item No.	Description	Part Number	NSN	QTY
1	Chain Adjuster	MB-1	1670-00-212-1149	8
2	Chain with Hook	For MB-1	4010-00-516-8405	16
3	Shackle	204-031-393-1	4030-00-977-6940	3
4	Bolt	AN5-22A	5306-00-151-2621	3
5	Washer	AN960PD516	5310-00-187-2399	6
6	Nut	MS21042L5	5310-00-807-1476	3
7	Bushing	NAS72-5E100	3120-01-245-2631	3
8	Polyester Rope 1/2 inch diameter		4020-00-630-4873	AR

### 1-39. Parking.

- **a.** Retract the ground handling trucks (S13) and allow the helicopter to rest on the skid-type landing gear. Refer to Chapter 3.
- **b.** Install shield assemblies (8) in engine induction fairing, cover (7) on engine exhaust, and cover (15) on p i t o t t u b e.
  - c. Install static grounds.
- **1-40.Tie-Down and Mooring.** For tie-down and mooring hardware(see Table 1-5)

#### **CAUTION**

Structural damage can occur from flying objects during high wind conditions. Helicopter should be hangared or evacuated to a safe area when wind conditions above 50 knots are expected.

#### NOTE

All active mooring points shall be equipped with this hadwear. For additional information refer to TM 1-1500-250-23.

#### 1-40.1. Mooring, Paved Surface

**a.** Position the aircraft on the mooring pad with the longitudinal centerline of the aircraft directly above and parallel to the longitudinal axis on the pad as shown in figure 1-6.1. The forward mooring rings are to be located 5 feet 4 inches aft of the first mooring point as shown.

#### NOTE

it will be necessary to attach a mooring clevis to each of the three jack/mooring points. The clevis provided with the aircraft will not be large enough to accept the hooks on the mooring chains provided with the mooring pad. Mooring rings are to be installed on the aircraft as shown in figure 1-6.1.

b. Place the hook-ends of the mooring chains into the appropriate clevis rings. Adjust the chains using the adjusting devices provided on the mooring pad. Chains should be adjusted to the point where the slack has been removed.

## **CAUTION**

The mooring hardware is to be carried in the flyaway kit. Flying the OH-58 with the mooring hardware installed may result in damage to the aircrafts' honeycomb surface. Retain all hardware together for each specific installation, due to wear, the bushings may not be interchangeable.

#### 1-40.2. Mooring, Unpaved Surface.

If suitable spaced ramp tiedowns are not available, park the helicopter on an unpaved parking area headed in the direction from which the highest velocity forecast winds are expected and retract ground handling trucks (S13). Use anchor rods (S2), to make "dead man" anchors. Moor helicopter as described in para 1-40.1.

#### 1-40.3. Rotor Blade Tie-Down.

## **CAUTION**

Secure the tiedown ropes carefully. Do not damage the skin by flipping the strap weights around the tailboom.

- **a.** To tie-down the aft blade, securely tie the straps of the boot to the 1/2 inch polyester rope near the boot. Ensure the ropes are long enough to cross and tie in position illustrated in figure 1-6.
- **b.** The forward blade shall also be tied-down using the same boot strap/rope arrangement device. The ropes shall be tied to the forward eyebolts of the landing skids as shown in figure 1-6.

## **CAUTION**

Maximum load at tips is 50 pounds. Maximum allowable deflection is 24 inches measured between flapping axis and connecting line between blade tips as shown in figure 1-6. Excessive deflection of the blade can result in delamination of the doubler.

- **c.** Install covers on pitot tube (15), engine exhaust cover (7) and engine inlet shields (8).
- **d.** An alternative method of installing pitot and engine inlet covers shown in figure 1-6 will aid in preventing marring and scratching of windshields and is accomplished as follows:
- (1) Route strap from pitot tube through the lower front edge of pilot door near lower hinge, and then out the top edge of door to engine air inlets.
- (2) Cut the strap connecting the pitot cover to the engine shields strap at both ends. The pitot tube cover may be held in place with the nylon cord and/or a scrapped packing of the proper diameter. If a packing is used, it may be permanently attached to pitot tube cover to prevent its loss when the cover is removed. The strap connecting the engine shields should also be shortened.

- **e.** Position collective control full down, and tighten friction.
  - f. Center cyclic control and tighten friction.
  - g. Close all windows, doors, and access panels.
  - **h.** Fill fuel tank to capacity with prescribed fuel.
  - i. Secure all ground handling equipment.
- **1-41. Helicopter Covers.** Protective covers must be installed at locations shown in figure 1-6 when helicopter is parked/moored.

## 1-42. Hoisting.

### **CAUTION**

Ensure that main rotor tiedown (6, figure 1-6) is installed prior to any ground handling.

Do not move helicopter with pilot or copilot windshield removed.

Station individual at the hoist emergency shut-off in case of run-away condition.

- **a.** Attach a hoisting shackle (S16) (4, figure 1-6) or cable to eye provided on retaining nut at top of main rotor mast (5). Connect a suitable hoist shackle or cable and take up slack.
- **b.** Station a person at tail skid to steady helicopter when hoisted. If lifting beyond reach from ground, use of a steadying rope will be necessary.
  - **c.** Hoist slowly with a steady lifting force.

## **WARNING**

Install aircraft jacks (S14) prior to removal or installation of landing gear.

#### CAUTION

The following hoisting procedures apply to recovery of downed aircraft only.

All hoisting of serviceable aircraft shall be by using the hoisting shackle and adapter only.

Use of the "belly band" and/or rotor head sling as cited in FM 55-413 is not authorized for serviceable aircraft and/or maintenance.

- **d.** When hoisting is required as a part of recovery the following additional precautions will apply.
- (1) If main rotor mast and transmission attaching points are intact recover as follows:
- (a) Remove all loose equipment from cabin and passenger compartment.
- **(b)** Tie down or remove main rotor and tail rotor blades from hubs.
- (c) Attach main rotor sling (T12) or suitable substitute to hoisting shackle and secure loosely to main rotor hub grips to provide a secondary lifting device in case of failure of the main rotor hub nut.
- (2) If main rotor mast is not in place or structural damage is suspected proceed as follows:
- (a) Remove all loose equipment from cabin and passenger compartment.
- **(b)** Remove all loose or broken hardware (i.e., cowling, tailboom, etc.).
- (c) If landing gear cross tubes are intact, provide a four point sling to the cross tubes on each side of the fuselage to a common hoisting shackle. Use standard sling to provide lifting capability of a minimum of 3,000 pounds 

  C . Protect fuselage where sling may contact with padding.
- (3) If (1) or (2) above cannot be accomplished use larger cargo net under the fuselage with the four corners of the net attached to the lifting clevis.

#### 1-43. SLING LOADING.

## **CAUTION**

The sling loading procedures of FM 55-413 are for recovery of downed aircraft only. As stated in that manual, sling loading will often cause damage to the aircraft.

All normal hoisting of serviceable aircraft shall only be by the procedures of this manual, paragraph 1-42 hoisting procedures.

Use of the "belly band" procedures and/or rotor head sling as covered in FM 55-413 is not authorized for normal maintenance procedures on serviceable aircraft.

Refer to FM 55-413 for sling loading information.

#### 1-44. WEIGHT AND BALANCE.


Refer to TM 55-1520-228-10, TM 55-1500-342-23 and AR 95-3, Chapter 6, Aircraft Weight and Balance.


## **WARNING**

Weight and Balance Records must reflect true and accurate information relative to helicopter configuration at all times.

#### 1-45. LEVELING.

- **a.** Drop plumb bob from smaller hole in upper plate at water line 71.5 and fuselage station 90.0. When pointer is at center of + target on lower plate secured to compartment floor, helicopter is level. Jack to correct helicopter position. Refer to figure 1-7.
- **b.** The fuselage and buttline station shown in figure 1-7 for the lower leveling plate is only approximate. If the lower plate must be installed and the previous location is not indicated by prior rivet holes, contact AVSCOM Engineering for instructions. Do not install a lower plate unless the former location is obviously indicated.





Drop plumb bob from smaller hole in upper plate. When pointer is at center of "+" target on lower plate, the helicopter is level.

206900-542

Figure 1-7. Helicopter Leveling Plates

# 1-46. APPLICATION OF EXTERNAL POWER.

An external power unit with a 28-volt DC output, and minimum capacity of 300 amperes is required for starting the engine; however, limits of 300 to 750 amperes and 28 volts are allowable for starting the engine.

- a. Turn helicopter battery switch OFF.
- **b.** Turn external power OFF.
- **c.** Plug the external power source cable securely into the external power receptacle (8, figure 1-1). Turn external power source switch ON. The electrical system for helicopter should be energized.

## **NOTE**

An external power unit should be used for the first start of the day; however, engine starts can be made on helicopter battery power, but are not recommended.

## SECTION IV. INSPECTION REQUIREMENTS

## 1-47. INSPECTION REQUIREMENTS.

1-48. General Information. This section contains complete requirements for special inspection, overhaul and retirement schedule, and standards of serviceability applicable to the helicopter. The inspections prescribed in this chapter shall be accomplished at specific periods by aviation unit maintenance activities with the assistance of intermediate maintenance activities when required. Complete Daily and Periodic inspections are contained in Preventive Maintenance Checklists (TM 55-1520-228-PM, -PMDA / C).

#### NOTE

During inspection, ensure that component identification plates are available and, if applicable, are current in accordance with TB 55-1500-307-24.

#### NOTE

During inspection of teflon lined bearings, for additional data on bearings, refer to TM 55-1500-322-24 (Maintenance of Aeronautical Antifriction Bearings).

#### 1-49. STANDARDS OF SERVICEABILITY.

Standards of Serviceability to be utilized in the day-today inspection and maintenance of the helicopter can be found as fits, tolerances, wear limits, and specifications in the applicable chapter. Standards of serviceability for transfer to helicopter are contained in TM 55-1500-326-24.


## 1-50. SPECIAL INSPECTION,

#### NOTE

Special inspection criteria may be expanded as deemed necessary by the aviation unit commander.

This section supplements the scheduled inspection as outlined in the Preventive Maintenance Checklists (TM 55-1520-228-PM, -PMDA / This section also includes inspection of items which are required to be inspected at intervals not compatible with airframe, operating time, or airframe inspection intervals. Refer to DA PAM 738-751 for applicable forms, records, and worksheets required for these inspection intervals. Typical of this type inspection items are:

- **a.** An inspection which is contingent upon specific conditions or incidents that arise, and only because of these conditions or incidents, immediate inspection is required to ensure safety of flight. Typical of these conditions are hard landings, overspeed, and sudden stoppage.
- **b.** Inspection of components or airframe on a calendar basis: first aid kits, weight and balance checks, aircraft inventory, etc.
- **c.** Refer to DA PAM 738-751 for applicable forms, records, and worksheets.
  - d. Refer to figure 1-8 for inspection areas.



Area No. 1 Nose Area

All surfaces and components in nose compartment and on exterior ahead of crew doors.

Area No. 2 Cabin and Landing Gear Area

All surfaces, components, equipment inside cabin, and on cabin exterior between forward side of crew doors and aft side of passenger door and cabin overhead. Includes complete landing gear, fuel cell sumps and filler.

Area No. 3 Transmission and Pylon Area

All surfaces, components, and equipment of the main rotor pylon group, from top of mast to cabin roof. Includes main rotor, mast and rotating controls, transmission with accessorial and mounts, and main drive shaft.

Area No. 4 Engine Area

All surfaces, components, and equipment associated with engine installation, located above engine work deck and within engine cowling and tailpipe fairing.

Area No. 5 Avionics and Aft Fuselage Area

All surfaces, components, and equipment in fuselage below engine deck level, between cabin area and tailboom attachment bulkhead.

Area No. 6 Tailboom

All surfaces, components, and equipment located in the tailboom and vertical fin structure. Includes tail rotor, elevetor, and control linkages. Also all supports, bearing, and shafting mounted on tailboom.

206900-S43

Figure 1-8. Inspection Area Diagram

AIRCR	AFT INSPE	ECTION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO.	NO. OF PAGES 28	
Α	IRCRAFT A	AND SERIAL NO.	INSPECTION NO.	DATE O	F IN	SPECTION
AREA NO.	REQUIRE MENT EVERY	-	ITEM		TA- US	RECORDED ON WORKSHEET
All Areas	AFTER /	A HARD LANDING				
	ground allowing cracking tion is co main rote	impact of the helicopter cather hard contact of hub with material of fuselage pylon support support support support support support of the confined only to those accides or or tail rotor.	as any accident or incident in uses severe pitching of main ast, or results in noticeable yiel structure or landing gear. This ents not involving sudden stoppers and landing incident has occording to the control of t	n rotor, Iding or defini- page of		
	a. Check all cowling and doors for proper fit and alignment. Misaligned cowling may indicate a distorted fuselage, resulting in major stresses and damage. Remove centermost cover assembly and inspect cap					
	<b>b.</b> Rem tion.		y to perform a complete visual es and crosstubes for damage	·		
	defle tion.	ction. Inspect crosstube atta	achment points for damage or	distor-		
	miss isola supp	ion mounting points. Particution mount and pylon support where the spike on the	er magnifying glass around the ular attention should be given ort mounts. Inspect the trans drag pin assembly fits into the nsmission on top of the cabin.	to the mission		
		ect upper longerons and adj ion 167) for loose rivets, crac	acent skin near the aft engine cks, or distortion.	firewall		
	nally tailbo struc	and externally for cracks, doom attachment points for	ng for damage. Inspect tailbook istortion, and loose rivets. Inspectories and date of elongated bolt holes and date of f tailboom for cracks in area of	ect the amaged		
	g. Dele	ted.				
	h. Dele	ted.				
ı						

AIRCRA	AIRCRAFT INSPECTION CHECKSHEET  TYPE OF INSP (Daily intermediate, etc.) SPECIAL		PAGE NO. 2				
AIF	RCRAFT AND SEF	RIAL NO.	INSPECTION NO.	DA	TE OF INS	PECTION	
AREA NO.	REQUIREMENT EVERY		ITEM		STATUS	RECORDED ON WORKSHEET	
	j. Completely ins head for ben damaged bea links and colle	nd for					
		aks in the hydrau actory operation.	ulic system and interference or bi	nding,			
	1. Inspect the tra	ansmission and ı	mast assembly for the following:				
	(1) Mast for in	ndentation cause	d by hard contact with static stop	s.			
	(2) Mast outs	ide diameter (0.	D.) for out-of-round condition as fo	ollows:			
	minir ing swas the c mea	ing a suitable micrometer, measure the mast O. D., at a nimum of six places for out-of-round condition; two opposmeasurements under the collar set and above the ashplate, two opposing measurements midway between collar set and the static stop contact area, two opposing asurements approximately 2.000 inches below the static p contact area on the mast.					
	inch,		g measurements vary in excess of spected of bending and a runout				
			NOTE				
		ium plating on t .0004 inch.	he outside diameter of mast is	0.0003			
	(3) Structure deformati		ransmission — mount points for cra	acks or			
	(4) Transmis paragrap		n for security of attachment. Re	efer to			
	roof for d	eformation and/o	<ul> <li>transmission mount support or or loss of attachment bolt torque. S and loose or sheared rivets.</li> </ul>				

AIR	CRAFT INSP	ECTION CHECKSHEET	TYPE OF INSP (Dally, Intermedlate, etc.) SPECIAL	PAGE NO.	NO	OF PAGES
	AIRCRAFT	AND SERIAL NO.	INSPECTION NO.	DATE O	F INSF	PECTION
AREA NO.	REQUIRE- MENT EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET
	(6) Inc. m. Inspect refer for the supplemental system (1) S (2) S (3) S (4) For (5) R (6) R	If inspection, substeps or deformation in the contacted by the massembly should be nonreparable, Mast as of locally. If any inspection, reveals an unsatistation as follows:  (a) The transmission-to-endetailed inspection processed the two forward and for cracks. Refer to paraget main rotor blades for contact AFTER SUDDEN STOP at tail rotor blades for dama DEN STOPPAGE – TAIL Refuel and oil systems for ms for leaks. Inspect the communication.  The transmission assembled to the formation of leaks and surrous distortion.  The transmission assembled to paraget the contact of	embly will be removed and returned the two aft transmission support raph 2-299.  Intact with tailboom. If damage is PAGE — MAIN ROTOR.  age. If damage is found, refer to OTOR.  damage. Before flight, check fuel crashworthy fuel system for the forcunding airframe for cracks.	rned to straps found, AFTER and oil llowing: and/or		

AIRC	RAFT INSP	PECTION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc. ) SPECIAL	PAGE NO.	NO, OF PAGES	
	AIRCRAFT	AND SERIAL NO.	INSPECTION NO.	DATE O	F INSI	PECTION
AREA NO.	REQUIRE- MENT EVERYt		ITEM		STA-	RECORDED ON WORKSHEET
	(8)	Cover assembly to ens attaching cover assembly	ure no pullout has occurred at to seat back panel,	screws		
	(9)	lo aka ga				
		occurs.	railable to engine and that no	eakage		
	, ,	Manual shutoff valve for	binding. for proper operation and probe	) loads		
	(12)	for broken wires.	for proper operation and probe	e leaus		
	(13)	All hoses for chafing and	broken or distorted clamps,			
	<b>p.</b> Inspec dama	_	selage attachment points for crac	cks and		
	<b>q.</b> Check	power and accessory ge	arbox for cracked flanges.			
	r. Inspe	ct magnetic chip detector	rs for metal accumulation.			
	s. Check	engine mounting pads for	or cracks.			
	t. Chec	k air, oil, and fuel hose o	connections for tightness.			
		all engine accessories for ections, and general cond	or cracked flanges, loose bolts ar dition.	nd nuts,		
		n engine hard landing ins 55-2840-241-23 <b>C</b>	spection. Refer to TM 55-2840-23	1-23 <b>A</b> ,		
	<b>w.</b> After skid alignr					
	<b>(1)</b> R					
		(b) Mast assembly (AVIM	). Refer to paragraphs 6-93 and	6-96.		

AIRCRA	AFT INSPECTION	CHECKSHEET	TYPE OF INSP (Daily intermediate, etc.) SPECIAL	PAGE NO. 5	NO. OF PAGES 28	
Al	RCRAFT AND SEF	RIAL NO.	INSPECTION NO.	DA	TE OF INS	SPECTION
AREA NO.	REQUIREMENT EVERY		ITEM		STATUS	RECORDED ON WORKSHEET
	<b>(c)</b> Tra	para-				
	<b>(d)</b> Tai	I rotor driveshafts	s. Refer to paragraphs 6-114 and	6-116.		
	(2) If a thorough visual inspection does not reveal any discrepancies or obvious damage to components listed below, they may be retained in service for continued usage.					
	<b>(a)</b> Ma	in rotor hub and	blades			
	<b>(b)</b> Ma	in rotor controls				
	(c) Sw	ashplate and sup	oport assembly			
	(d) All	control rods and	bolts			
	<b>(e)</b> 90	degree gearbox				
	<b>(f)</b> Tail	rotor hub and b	olades			
	<b>(g)</b> Tai	il rotor controls				
	<b>(h)</b> Iso	lation mount.				
		landing: If dama bllowing steps:	ge is found in rotating controls, a	ccom-		
	` ' '	e all control rods otor hub.	and bolts from hydraulic servos	to the		
		e and inspect the n as indicated:	e following components and mak	ke dis-		
	<b>(a)</b> Ma	in rotor hub asse	embly. (Depot) Refer to paragraph	5-8.		
	` '	ashplate and sup aph 5-114.	oport assembly. (AVIM). Refer to	para-		
	<b>y.</b> After a hard as follows:	• •	t wire strike protection system (V	VSPS)		
	(1) Lower	assembly:				
	(a) Insp	pect for obvious	damage to WSPS.			

AIRCRA	AFT INSPECTION	CHECKSHEET	TYPE OF INSP (Daily intermediate, etc.) SPECIAL	PAGE NO. 6	NO.	OF PAGES 28	
AI	RCRAFT AND SE	RIAL NO.	INSPECTION NO.	DA	TE OF INS	SPECTION	
AREA NO.	REQUIREMENT EVERY		ITEM		STATUS RECORDED ON WORKSHEET		
	(b) Inspect	(b) Inspect attachment area for damage.					
	(2) Windshiel	d deflector and ι	upper WSPS assembly:			l l	
	(a) Inspect	for obvious dam	nage to WSPS.				
	(b) Inspect	attachment area	a for damage.				
A Areas	AFTER PYLON						
Aleas	Definition: A combination of very low rotor speeds, below 330 RPM A. 93% C, and high collective blade angles which results in excessive flapping of the main rotor hub, which in turn causes bumping and rotation of the pylon in an elliptical pattern. Pylon whirl will usually include spike knocking and swashplate to cowling contact.						
	to the horizo		n the area aft of the tailboom attact Look for bending, buckling, or cre ilboom.				
		ect the fiberglass n assembly for c	fairing under the tailboom assem	bly on			
	the tailboom helicopter. Lo ized by perm	attach point for a ook for skin wrink anent creasing a	on assembly of the helicopter forw pproximately 36 inches both sides ding above WL 61.76 which is cha and abrupt changes in profile. Wrin a and frequently result in loose riv	of the racter- kles of			
			NOTE				
			kling occurring aft of the avior 61.76 is normal on the helicopte				
	skin is wrink	led above WL 6	en cracked, or if the aft section as: 1.76, the longerons and stiffener , cracking, or tearing.	-			
	contact. Che	e. Visually inspect the transmission cowling for swashplate to cowling contact. Check for loose jamnuts on swashplate control tubes. Perform fluorescent penetrant inspection of swashplate support assembly for cracks at base of cylinder.					

AIR	CRAFT INSP	ECTION CHECKSHEET	TYPE OF INSP (Dally, Intermediate, etc.) SPECIAL	PAGE NO. 7	NO.	OF PAGES
	AIRCRAFT	TAND SERIAL NO.	INSPECTION NO.	DATE O	OF INSPECTION	
AREA NO.	REQUIRE- MENT EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET
NO.	f. Visually in permand g. If there is forward paragra h. If the proof or sus Otherw  AFTER SPI a. If spike slope helicop b. If spike below the train be inspected (shudder whirl in the lateral speed (drag literator speed) c. If spike lateral speed (drag literator speed)	is damage to the drag pir and the two aft transmission pected pylon whirl, the lise, a complete hard land the two aft transmission, a complete hard land the two aft transmission, and a landing, unusual attitude ter in sand or mud, the high manifestory and the land	rag pin assembly and its static stourity of attachment.  In and/or its static stop, inspect the sion support straps for cracks. Reference in a company of the sion support straps for cracks. Reference in a company of the sion support straps for cracks. Reference in a company of the sion support straps for cracks. Reference in a company of the sion support straps for cracks. Reference in a company of the sion support straps for cracks. Reference in a company of the sion support straps of the sion support	e two fer to  whirl, flight.  flight.  tor rpms s, only must ations  below ission Pylon  ed by rotor unt  e and	IUS	

AIRCR	RAFT INSPE	CTION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. 8	NO	D. OF PAGES 28
Α	AIRCRAFT A	ND SERIAL NO.	INSPECTION NO.	DATE (	OF IN	SPECTION
AREA NO.	REQUIRE- MENT EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET
	n c s c a l'	n e n- n n o-				
	AFTER S					
			NOTE			
	t	ion of the drive system he transmission or by the	ned as an abnormal decelera caused by internal seizure of main rotor or tail rotor blade causes rapid deceleration.	of		
	t	aneous shock load appli	e further defined as an instar ed to the drive train and roto ult from blades striking an ol	or		
	Visible damage to the blades is evidence that a shoc load could have been applied to the system. Damage to only the blade tip-cap fairing should not be cause to do a sudden stoppage inspection. In each case the pilot and maintenance personnel will need to evaluate what occurred and determine if the sudden stoppage inspection is required.					
	ing d	•	or both blades (other than tip-ce the following components for			

AIRCR	AFT INSPEC	TION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. 8.1		O. OF PAGES 28
Α	IRCRAFT AN	D SERIAL NO.	INSPECTION NO.	DATE OF INSPECTION		SPECTION
AREA NO.	REQUIRE- MENT EVERY		ITEM	S. T	RECORDED ON WORKSHEET	
		N	ОТЕ			
	co sh ter int se hu rec yo wh tai us Wh air en rec tic	mponent to avoid reperiould indicate when the mould indicate when the mould indicate when the mould indicate when the formation is not lost parated from the aircrafes, compliance and next corded on DA Form 2408 from 2408-15) in terms of the mould record with the indicate of the component is frame hours that the next record of the inspection is	ould be maintained with the at inspections. The record enext inspection is due in the component so that the when the component in the continuation of the inspection will be a component of the component when remove a paircraft DA Form 2408-16, mainter component when remove a gaircraft DA Form 2408-18. Installed on an aircraft, the ext inspection is due will be aircraft DA Form 2408-18. In available, the special inspection another aircraft is not a ments (depot)	s n e s or ee A n- ft n- d B. e e e If		

AIR	C <b>RAFT</b> INSF	PECTION CHECKSHEET	TYPE OF INSP (Daily, Intermedlate, etc.) SPECIAL	PAGE NO. 9	NO	OF PAGES
	AIRCRAFT	TAND SERIAL NO.	INSPECTION NO.	DATE O	F INSF	PECTION
AREA NO.	REQUIRE- MENT EVERY		ITEM		STA_ TUS	RECORDED ON WORKSHEET
6	(2) Ma (3) Ma (4) Swa (5) Rot (6) No (7) Tra (8) Fre b. After su blades c. Inspect d. Inspect e. Refer to sudder f. Inspect e unusua g. Repeat operati AFTER SU a. Visually distortion result conside b. Inspect integrit movern	control tubes).  Insmission (depot)  ewheeling assembly (A)  dden stoppage with no way for security of all bonds as engine mounts for security each transmission magnet  TM 55-2840-231-23 and stoppage inspection.  Engine inlet for foreign oblaid noise.  Inspection of transmission  DDEN STOPPAGE — TAIL  inspect the tail rotor drippen. If there is obvious dan of torsional overload, allegered unserviceable and not the bonds between the y. Check for obvious local	pitch change links)  (all six swashplate to servo activities)  (all six swashplate to servo activities)  (all six swashplate to servo activities)  (b)  (b)  (c)  (d)  (d)  (e)  (d)  (e)  (e)  (f)  (e)  (f)  (e)  (f)  (e)  (f)  (f	engine ck for urs of las a vill be rs for		WORKSHEET

AIRCRA	FT INSPECTION (	CHECKSHEET	TYPE OF INSP (Daily intermediate, etc.) SPECIAL	PAGE NO. 10		OF PAGES	
AIR	CRAFT AND SEF	RIAL NO.	INSPECTION NO.	DA	TE OF INS	PECTION	
AREA NO.	REQUIREMENT EVERY		ITEM		STATUS RECORDED ON WORKSHEE		
			NOTE				
	loose ear removal a less insp g., revea assembly disposition.  c. Inspect the ta studs, using a d. Inspect the for damage, and e. Inspect the ta missing rivets the attachment.  f. Deleted.  g. Inspect tail routh. Inspect the homounting.  i. Inspect the homounting.  i. Inspect the vertail skid for contain skid f	eth, snow, water, and replacement bection as required an obvious of can be dynamically ca	entact of tail rotor blades with or vegetation does not require to of the 90 degree gearbox unred by this section, a. through defect, and provided the hubically balanced. (see step j. for tail rotor hub.)  ea of the tail rotor gearbox mountailitying glass.  chment points for cracks, distortion or cracks, distortion of attachment bolts of tailboom for cracks in are sal stabilizer.  ger for skin cracks and looseness urity and overall condition. Check	ting ion, s. e or a of s in the ge. tail orthy e tip rtion ided cally nt of hub sual			

	~~ . ~~		TYPE OF INSP (Dally,	PAGE NO.	NO.	OF PAGES
AIRO	CRAFT INSF	PECTION CHECKSHEET	Intermediate, etc.) SPECIAL	11		28
	AIRCRAFT	Γ AND SERIAL NO.	INSPECTION NO.	DATE O	F INSP	ECTION
		г				DECORDED
AREA NO.	E V E R Y		STA- TUS	RECORDED ON WORKSHEET		
3 4	(3) If sign are exercised (4) Regarder (4) Regarder (5) Remove (6) If a constant (7)	earbox, the 90 degree gean degree and sent to depot maintent valuated and repaired and fer to TM 55-2840-231 angine stoppage inspection are and inspect freewheeling and inspections:  MAIN ROTOR OVERSPORT of the serving inspections:  Otor blades — Return to determine the blade has been dama for or any bond lines have crapped.  Any movement of the tipic curred, scrap the blade.  The block is cracked, so the tipic block is cracked, so the tipic block is cracked, so the tipic block is cracked and the tipic block is cracked an	g assembly (AVIM).  EED  Ses of 390 RPMA, 110% per	noved vill be  C for  been ust be shas rity of prazed		WORKSHEET
	Inspec bolts.	t Tension/Torsion (T/T) s	trap assemblies, fitting, pins and	strap		

AIRCR	AFT INSPEC	TION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. NO. OF PA		D. OF PAGES 28		
Α	IRCRAFT AN	D SERIAL NO.	INSPECTION NO.	DATE	OF IN	SPECTION		
AREA NO.	REQUIRE- MENT EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET		
1,2, and 3	AFTER WI	RE STRIKE						
	a. Lower V							
	<b>(1)</b> Insp	pect for obvious damage t	to WSPS.					
	<b>(2)</b> Insp	pect attachment area for o	damage.					
	<b>b.</b> Windshi	eld deflector and upper W	SPS assembly.					
	<b>(1)</b> Insp	pect for obvious damage t	to WSPS.					
	<b>(2)</b> Insp	pect attachment area for o	damage.					
1	AFTER LOWER WSPS GROUND CONTACT							
	a. Inspect	for obvious damage.						
	<b>b.</b> Inspect	attachment area for dama	age.					
		panel and inspect structunks for damage.	ure and directional control tub	es and				
		N	ОТЕ					
	tur ing	ral integrity of installatio	damage not affecting struction are not causes for ground eplacement of tip and damaged as soon as practical.	d-				
4	ANYTIME TAMINATIO		REPLACED DUE TO METAL	. CON-				
	Refer to TM 55-2840-231-23  A TM 55-2840-241-23  G for guidance regarding recognitions of relevant metal contamination. Refer to Chapter 4 for instructions concerning inspection and replacement of applicable engine accessories.							
4	ENGINE P	PERFORMANCE CHECK I	REQUIRED					
	Refer to TI	M 55-1520-228-MTF.						
	a. After ins	stallation of engine.						

Al	RCRAFT INSPECT CHECKSHEET	TION	TYPE OF INSP (Daily, Intermedate, etc.) SPECIAL	PAGE NO 13.	NO.	OF PAGES 28			
AIRC	CRAFT AND SERIA	AL NO.	INSPECTION NO.	DAT	E OF INSP	ECTION			
AREA NO	REQUIREMENT EVERY		ITEM		STATUS	RECORDED ON WORKSHEET			
	b. Anytime poor performance is noted.								
	trol (refer to as	opropriate	pairs certain adjustment o engine manual), governor, or rigging adjustment.	f fuel con- double					
	d. Delete	•							
	e. Anytime a fuel routine 50 hou		ntrol air line is loosened, e ash.	xcept for					
	f. Calibration/Rep	lacement (	of torque or TOT indicating	j system.					
	g. Replacement of	of FAT gag	e for error.						
3 and 4	AFTER INSTALLING AN ENGINE OR ENGINE COMPONENT								
	a. Check turbine outlet temperature system, refer to Chapter 8 TM 55-1520-228-23								
	<u> </u>		ypass valve. Refer to TM : 840-241-23		:				
	c. Operate engir check for leaks 55-2840-241	s. Refer to	rdance with TM 55-1520 TM 55-2840-231-23	-228-10 and , and TM					
	1. Shutdown and	check for	leaks.						
			external engine oil fitter el 1-1520-228-50-44.	ement. After					
<u> </u>	f. Perform engine	post insta	llation as follows:						
		ľ	NOTE						
	engine Is	s removed	igh (3) are not required v to facilitate other maint Is reinstalled						
	(1) Remove, dea	an, inspect	and reinstall both engine	chip					
	(2) Remove, dea to TM55-2840	ter. Refer							
	(3) Check turbit 55-2840-231-2	ne outlet te 23 A, TN	emperature system. Refer 1 1 55-2840-241-23 C.	to TM	,				
	(4) Torque bolts paragraph 2-30		engine mounts to airframe	e. Refer to		]			

AIRCR	AFT INSPEC	TION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. 14	. NC	). OF PAGES 28
Α	IRCRAFT AN	D SERIAL NO.	INSPECTION NO.	DATE	OF INS	SPECTION
AREA NO.	REQUIRE- MENT EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET
4	HEALTH II	NDICATOR TEST (HIT) NE	EW BASELINE REQUIRED			
	Refer to T	M 55-2840-231-23 A ,	TM 55-2840-241-23 C.			
	a. After ins	stallation of engine.				
	<b>b.</b> When the perform		s been affected by any mainte	enance		
3		MAIN ROTOR MAST A AIRCRAFT/TRANSMISS	SSEMBLY IS TRANSFERRE ION	ED TO		
		disassembly inspection fo	r corrosion and condition of p	parts is		
3	ANYTIME PARTICLE		MOVED AS A RESULT OF	METAL		
	<b>a.</b> Remove	e and flush all external trar	nsmission oil lines.			
		te disassembly inspection (AVIM) (paragraph 6-96).	of main rotor mast assembly	y is re-		
		te disassembly inspection (AVIM) (paragraph 6-29).	n of freewheeling assembly	is re-		
3 and 4	ANYTIME	TRANSMISSION IS OPER	RATED WITHOUT OIL			
		te disassembly inspection (AVIM) (paragraph 6-96).	of main rotor mast assembly	y is re-		
		ete disassembly inspectio (AVIM) (paragraph 6-29).	n of freewheeling assembly	is re-		
		r mast bearing and/or fre oil starvation, replace trans	ewheeling assembly fails ins smission.	pection		
	<b>d.</b> If there mission		transmission damage, replace	e trans-		
	e. Accomp	olish transmission servicea	bility check (paragraph 6-6).			

AIRCR	AFT INSPEC	TION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. 14.1	NO. OF PAGES 28	
Α	IRCRAFT AN	D SERIAL NO.	INSPECTION NO.	DATE (	OF IN	SPECTION
AREA NO.	REQUIRE- MENT EVERY		ITEM		TA- TUS	RECORDED ON WORKSHEET
	f. Take oil	sample.				
	g. Take sp	ecial oil sample after five	hours of operation.			
3 and 4	ANYTIME Helicop	THER				
	Complete inspection	I). This				
		N	IOTE			
	sh ter in se hu re Fo wh tai us W air er re tio re AFTER IN a. Ground possib b. Fly heli perforr c. Remove tainer.	rould indicate when the ms of operating hours of operating hours of formation is not lost operated from the aircraful, compliance and next corded on DA Form 2408 orm 2408-15) in terms of the main roth hich do not normally have in local records with the sing data from the losing hen the component is frame hours that the natered in block 8 of the cord of the inspection is on at time of transfer quired.  STALLING A REPAIRED run helicopter for 15 min le without lift-off and deceived the cord of the vicinity of a magnetic power recovery autorotal magnetic power recovery autorotal cord of the vicinity of a magnetic power recovery autorotal contents and the cord of the vicinity of a magnetic power recovery autorotal contents and the cord of the vicinity of a magnetic power recovery autorotal contents and the cord of the vicinity of a magnetic power recovery autorotal contents and the cord of the vicinity of a magnetic power recovery autorotal contents and the cord of the vicinity of a magnetic power recovery autorotal contents and the cord of the vicinity of a magnetic power recovery autorotal contents and the cord of the vicinity of a magnetic power recovery autorotal contents and the cord of the vicinity of a magnetic power recovery autorotal contents and the cord of the vicinity of a magnetic power recovery autorotal contents and the cord of the vicinity o	utes. Obtain as high a power lerate rapidly at least 2 times. safe landing area for 15 minution. rain piug and drain oil into cle	in ne is or oe A n- oft n- ed 8. ne oe If c- ot		

AIRCR	AFT INSPEC	TION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. 15				
Δ	IRCRAFT AN	ID SERIAL NO.	INSPECTION NO.	DATE (	OF IN	SPECTION		
AREA NO.	REQUIRE- MENT EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET		
4	SUSPECT	ED FOREIGN OBJECT DA	AMAGE					
	Refer to TM 55-2840-231-23 A , TM 55-2840-241-23 C for foreign object damage inspection.							
5		THE TAIL ROTOR HUB A TO ANOTHER AIRCRAFT	AND BLADE ASSEMBLY IS T	RANS-				
		nt penetrant inspection of t Refer to paragraph 5-198 o	he yoke, bearing liner and trun or 5-233.)	nnion is				
		N	ОТЕ					
	sh ter in se hu rec po wh tai us Wi air en rec	rould indicate when the rms of operating hours of formation is not lost parated from the aircrafub, compliance and next corded on DA Form 2408 orm 2408-15) in terms of the control of the main rote in local records with the sing data from the losing hen the component is aframe hours that the next tered in block 8 of the cord of the inspection is on at time of transfer quired.	eat inspections. The record enext inspection is due in the component so that the when the component in the component in the continuation of the inspection will be a component in the continuation of the inspection will be a component when remove a paircraft DA Form 2408-16, main the component when remove a component is a component when remove a component when remove a component when remove a component is a component when remove a compo	in ne is or oe A n- oft n- ed 8. ne oe If c- oot				
6	REMOVE		FT AND/OR BEARINGS HAVE ERED. Not applicable on a -25					

AIRCR	AIRCRAFT INSPECTION CHECKSHEET		TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. 16	NO. OF PAGES			
Α	IRCRAFT A	AND SERIAL NO.	INSPECTION NO.	DATE O	F INS	SPECTION		
AREA NO.	REQUIRE MENT EVERY	-	ITEM		TA- US	RECORDED ON WORKSHEET		
		FIRST FLIGHT following marks on tail rotor drivesha	aintenance operational check. ft bearings.	Inspect				
4	AFTER FAILURE		T DUE TO GROUND POWER	R UNIT				
	a. Hot e	nd inspection. Refer to T	M 55-2840-241-23 C .					
	<b>b.</b> Batter	ry inspection. Refer to TM	/I 11-6140-203-14-2.					
	c. Aircraft electrical inspection.							
6		E TAIL ROTOR GEARBOX ARE IS ADJUSTED	X IS INSTALLED OR ATTACH	HMENT				
		ail rotor gearbox retaining roperation.	nuts for proper torque after 10	0 (±10)				
6	AFTER LATION	INITIAL RUNUP FOLLOWII	NG TAIL ROTOR GEARBOX II	NSTAL-				
	Torque t	ail rotor gearbox holddown	nuts.					
4	AFTER	POWER LOSS, N2 DROOF	P, OR FLAMEOUT					
	ance with t	oower loss, N2 droop, or flar the troubleshooting charts in TM 55- 840-241-23 C.	meout occurs, check/inspect in -2840-231-23					
4	AFTER	OVERTEMPERATURE OPI	ERATION					
		M 55-2840-231-23 Anperature operation inspecti	,TM 55-2840-241-23 on.	for after				
4	AFTER	OVERSPEED OR OVERTO	RQUE OPERATION					
	a. Engir	ne:						
	(1)	Remove engine and tag Refer to TM 55-2840-231-2 for overspeed limits.	to indicate overtorque or ove 23 A TM 55-2840-241-2					
	(2)	Engine does not have to torque C.	be removed after transmission	on over-				

AIRCR	AFT INSPEC	TION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. 17					
Α	IRCRAFT AN	ID SERIAL NO.	INSPECTION NO.	DATE OF INSPECTION		SPECTION			
AREA NO.	REQUIRE- MENT EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET			
	b. Main tra	ansmission:							
	(1) Afte	er overspeed, inspect for	obvious damage.						
	(2) Afte sp	(2) After overtorque in excess of 92 psi A ,100% ; inspect for obvious damage.							
	(3) re ov	peed or							
	<b>c.</b> Freewhe	c. Freewheeling assembly:							
	(1) Af								
	(2) Afte								
		er overtorque in excess move and inspect freewhe	of 106 psi A , 115% eeling assembly (AVIM).	С					
	d. Main Dr	riveshaft (206-040-371-11	1)						
		torque of 110% (OH-58 206-040-371-111.	C)/101 psi (OH-58A) replac	e main					
3,4 and 6	ANYTIME	FUEL FILTER LIGHT COI	MES ON						
	a. Remove TM 55-	and replace fuel filterRefer -2840-241-23	to TM 55-2840-231-23	A , or					
	<b>b.</b> Inspect	<b>b.</b> Inspect the fuel system for possible contamination.							
			er fuel control filter assembly or TM 55-2840-241-23	/. Refer					
			bypass valve for proper oper of or TM 55-2840-241-23	eration.					
		ve and replace airframe ance with MWO 1-1520-22	mounted fuel filter elemen 28-50-48.	t. After					

AIRCR	AFT INSPECTION	ON CHECKSHEET	TYPE OF INSP (Daily Intermdate, etc.) SPECIAL	PAGE NO 18	NO. OF PAGES 28		
A	IRCRAFT AND	DATE	OF INSP	ECTION			
AREA NO.	REQUIREMENT EVERY	STATUS	RECORDED ON WORKSHEET				
3, 4 and 6	ANYTIME MA OR FREEWHI		IT COMES ON, TRANSI	MISSION			
	8. Submit oil sa	mple for special ana	llysis. Refer to TB 43-010	<b>)</b> 8.	 		
	b. Remove chip plug caused t		rn, to determine which m	agnetic			
		NOTE u can Identify the n detector as fuzz, s					
	c. Remove and	inspect applicable m	nagnetic plug for metal a	ccumulation			
	d. Clean or repla 6-2 Metal Co		onent is acceptable. Refe	r to table			
	ANYTIME MA	GNETIC CHIP LIGH	IT COMES ON, ENGINE	i.			
	Refer to TM 5	5-2840-231-23 <b>A</b> ,	or TM 55-2840-241-23	C.			
4		L TEMPERATURE NORMAL OIL PRES	EXCEEDS 107°C WITHOSURE.	OUT A			
	Refer to TM 5	5-2840-231-23 A	or TM 55-2840-241-23	C.	] [		
		L TEMPERATURE I	EXCEEDS 107°C WITH A	A			
	Refer to TM 55	5-2840-231-23 <b>A</b> ,,	or TM 55-2840-241-23 (	<b>3</b> .			
						·	

AIRCRA	FT INSPECTION	CHECKSHEET	TYPE OF INSP (Da Intermediate, etc.) SPECIAL	ily, PAGE NO. 18.1		NO. OF PAGES
	AIRCRAFT AND	SERIAL NO.	INSPECTION NO.		DATE	OF INSPECTION
AREA NO.	REQUIRE MENT EV- ERY		ITEM	S	TATUS	RECORDED ON WORK SHEET
All Areas	AFTER THE WATER OR S  Wash entire he compartment of salt water and Apply corrosion anodized, or care 25/1.  WHEN OPERAWITHIN 200 MI  Clean engine of TM 55-2840-23  AFTER WASH  a. Check pit b. Check accumulation of exceed 10% of	licopter with fresh water loors. Wash all components of the last loop water. Water and total amount drained.	st flight of each day. Refer to 40-241-23			

AIRCR	AFT INSPECTION ( SHEET	CHECK-	TYPE OF INSP (Daly, Intermediate, etc.) SPECIAL	PAGE NO 19.	NO. (	OF PAGES 28	
AIRC	ICRAFT AND SERIAL NO. INSPECTION NO. DATE OF INS			TE OF INSPI	ECTION		
AREA NO.	REQUIREMENT EVERY		ITEM		STATUS	RECORDED ON WORKSHEET	
	ANYTIME A CON TURE INDICATIN	-	TEPERA-				
	A system calbration 8-134).	on check i	s required (refer to para	graph			
3			SURE TO RADIOACTIV	ITY			
Ali Areas	Accomplish the following: a. Survey helicopter for level of radioactivity.						
	b. Decontaminate I DA PAM 738-75		as required. Refer to FM	3-5 and			
All	TAILBOOM REPI	LACED					
	When tailboom is and balance reco		weigh aircraft and perfor	m weight			
6	AT EACH TRANS	MISSION	I OIL CHANGE				
	a. Take oil sample	. Refer to	TB 43-0106.				
All Areas	b. Drain freewheeli	ing unit. F	Refer to paragraph 6-25.				
	c. Replace oil fitter to paragraph 6-2		ect oil filter head assemb	ly. Refer			
	d. Remove, inspec	t, and dea	n electrical chip detector	r plugs.			
	e. Check freewheel	•	• •				
			discoloration and cleanlin				
All Areas	pass in and out o	of assemb					
	h. Inspect oil pump	inlet scr	een. Refer to paragraph	6-292.			

AIRCRAF	T INSPECTION	CHECKSHEET	TYPE OF INSP (Dai Intermediate, etc.) SPECIAL	ily,	PAGE NO.	NO. OF PAGES
			, , , , , , , , , , , , , , , , , , ,		18.1	28
A	AIRCRAFT AND	SERIAL NO.	INSPECTION NO.	DATE OF INSPEC		OF INSPECTION
AREA NO.	REQUIRE MENT EV- ERY		ITEM	STA	TUS	RECORDED ON WORK SHEET
All	AT EACH TAI	L ROTOR GEARBOX	OIL CHANGE			
Areas	<b>a</b> . Take oil s	sample. Refer to TB 4	3-0106.			
	<b>b</b> . Remove,	inspect, and clean ele	ectric chip detector plug.			
	<b>c</b> . Inspect o	il sight glass for disco				
All Areas		GINE OIL CHANGE sample. Refer to TB 4				
	<b>b</b> . Inspect a	nd dean oil filter.				
		inspect, replace extenpliance with MWO 1-				
	<b>d</b> . Remove,	inspect, and dean ele				
	e. Inspect o	spect oil sight glass for discoloration and cleanliness.				
	f. Perform f	functional check of oil	bypass valve.			
	Motor en		in line to #6 and #7 bearing. nount of oil to escape. Refer to 552840-2410-23			
	, or TN	scavenge oil flow che M 55-2840-241-23	ck Refer to TM 55-2840-231-23			
4	hours. When overhaul. Any	limit is exceeded, re mixture of emergency	o an accumulative total of 6.00 emove engine and return it for y fuel to regular fuel greater than idered emergency fuel usage.			
		ble container. No ho	tank sump and drain remaining t end inspection or opera tonal			
			NGE TO THE EXISTING R STRUCTURAL CHANGE			
AII Areas		. Compensate when r	emote compass indicators for necessary. Refer to TM 1-1500-			

AIRCRAFT INSPECTION CHECKSHEET			TYPE OF INSP (Daily intermediate, etc.) SPECIAL	PAGE NO. 21		OF PAGES
AIRCRAFT AND SERIAL NO.		INSPECTION NO.	DA	DATE OF INSPECTION		
AREA NO.	REQUIREMENT EVERY		ITEM		STATUS	RECORDED ON WORKSHEET
1	EVERY 25 (± 2.50) HOURS OR 30 DAYS, WHICHEVER OCCURS FIRST, ACCOMPLISH THE FOLLOWING:					
	a. Remove battery and perform preventative maintenance checks and services on the nickel-cadmium battery. Refer to TM 55-1500-345-23, TM 11-6140-203-14-2 and TM 55-1500-344-23.					
	<b>b.</b> Perform battery deck inspection (Not applicable if battery tray is ininstalled).					
	AFTER AIRCRAFT HAS REMAINED INACTIVE FOR SEVEN CONSECUTIVE DAYS.					
	Process the aircraft into the appropriate storage category (refer to Appendix E).					
4	EVERY 90 DAYS					
	Inspect power turbine coupling nut on all T63-700 engines in accordance with TM 55-2840-231-23. This inspection is not required if nut, P/N 6890531 or 23001801 is installed. Engines having this nut installed will be identified with a suffix C after the serial number. (Example: AE400/00ABC, AE 402603BC).					
4 and 6	EVERY 25 HOURS					
	a. Visually inspect tail rotor driveshaft and bearings. (This inspection applicable with or without MWO 55-1520-228-50-25 incorporated.)					
	<b>b.</b> Inspect tailboom P/N 206-032-004-105 for loose or missing rivets, and skin cracks at the rivets securing the gearbox support casting to the tailboom skin immediately forward of the tail rotor gearbox.					
	c. Inspect tailboom P/N 206-032-004-105 for cracks in the tail rotor gearbox support casting by removing the tail cone and visually inspect interior of casting, particularly the web areas for cracks. Removal of the tail rotor gearbox is not required.					
3	d. At each transmission oil sampling - drain, flush and replace transmission oil if water contamination is present or suspected.					
6	e. Purge lubricate improved tail rotor hub trunnion. After compliance with MWO 55-1520-228-50-25.					
3, 4 and 6	EVERY 50 (±5) HOURS					
	<b>a.</b> Clean engine compressor. Refer to TM 55-2840-231-23 A or TM 55-2840-241-23 C.					
		mission oil coole restriction of air	r hose and inspect hose and radia flow.	tor for		

AIRCR.	AIRCRAFT INSPECTION CHECKSHEET			TYPE OF INSP Intermediate, etc.) SPE	(Dail CIAL	ly,	PAGE NO. 18.1	NO. OF PAGES	
	AIR	CRAFT AND	SERIAL NO.	INSPECTION N	Ο.			OF INSPECTION	
AREA NO.	M	EQUIRE MENT EV- ERY		ITEM		S	TATUS	RECORDED ON WORK SHEET	
	C.		ttery tray felt pad in if battery tray and fel	id and					
3		(±5) HOUR TALLATION	S AFTER MAIN F	NIGRIP					
3	50 (	(±5) HOURS A	AFTER ENGINE INSTA	ALLATION					
		orque nuts a agraph 2-308		ounts to airframe. Re	efer to				
3	EVE	ERY 100 ( <u>+</u> 10)	) HOURS.						
	a.	including se		numbers 8383 throug cracks on aft end of pis lve housing.					
			NOTE						
			cial Inspection Is no have an A suffix after	et required on those the serial number					
	b.	Inspect serv Refer to para		valve for excessive le	akage.				
	C.	magnifying		P/N 206-010-360-3 usin corrosion on outer surfa ed.					
5			OURS OR 120 CAL ACCOMPLISH THE F	ENDAR DAYS WHICH FOLLOWING:	HEVER				
	a.		eventive maintenance ium battery. Refer to T	checks and services M 11-6140-203-14-2.	on the				
	b.	Check and a	adjust voltage regulator	. Refer to TM 1-1500-20	)4-23.				
	C.	Perform batt 9-27.	tery quick-disconnect i	nspection. Refer to par	agraph				

AIRCRA	AFT INSPECT	TION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. 23	. NO	D. OF PAGES 28	
Α	IRCRAFT AN	D SERIAL NO.	INSPECTION NO.	DATE	OF IN	SPECTION	
AREA	REQUIRE- MENT		ITEM		STA-	RECORDED	
No.	EVERY		11 6111				
3	100 (±10) TION BOL HAULED N						
	occured, re	eplace hardware. If slippag	and nuts for security. If slippa ge has not occurred, retorque 5-84, depending on type of ha	nuts to			
4 and 5	HOSES A	ND/OR HOSE CLAMPS PPLICABLE IF MWO	EALING AND NONSELF-SE ARE REPLACED OR INSTA 55-1520-228-30-32 HAS	ALLED			
	Retorque h	nose clamps. Refer to table	e 7-3, TM 55-1500-204-25/1.				
5	INSTALLAT	TION.	GHT AS A RESULT OF TAIL 375 TO 415 INCH-POUNDS).	ВООМ			
5	100 (±10)	HOURS AFTER INSTALLA	ATION OF TAILBOOM				
	Retorque t	aiboom attachment bolts (	375 TO 415 INCH-POUNDS).				
3	20 (±5) HC	OURS AFTER SERVOACT	UATOR INSTALLATION				
	a. Retorqu	e trunnion plate nuts.					
	<b>b.</b> Retorqu	e bearing plate nuts.					
4	150 (±15) OCCURS		CALENDAR MONTHS, WHICH	HEVER			
	•	disassemble, inspect, and (Not applicable to P/N 206	lubricate the engine-to-transr 6-040-371-111).	mission			
4	EVERY 30 OCCURS		CALENDAR MONTHS, WHICH	HEVER			
		fuel pump filter element. F 5-2W-241-23 C .	Refer to TM 55-2840-231-23	Α,			
		uel control filter assembly. 55-2M-241-23	Refer to TM 55-2840-231-23	Α ,			
3	c. Main rote	or mast (inside diameter)	for corrosion.				
			y. Refer to TM 55-2840-231-23				
		re and replace airframe ance with MWO 1-1520-22	mounted fuel filter element 28-50-48.	t. After			

1						
AIRC	RAFT INSPECT	ION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. 28.1	NO. OF PAGES	
AIRC	RAFT AND SER	IAL NO.	INSPECTION NO.	DATE OF INS	PECTION	
AREA NO.	REQUIRE- MENT EVERY		ITEM	STA- TUS	RECORDED ON WORKSHEET	
11 F a b 22 c c ( ( ( ( ( ( ( ( ( ( ( ( ( ( ( (	Inspect er or TM 55- Test the et al. Inspect er or TM 55- Test the et al. Inspect er or TM 55- Test the et al. Inspect er or TM 55- At engine TM 55-28- Test the et al. Inspect er or TM 55-28- Test er or TM 55-28- Test er or TM 55-28- Test fuel er or proper or	AND UNTIL ALL CONTAINED FUEL SYSTELM.  Ingine fuel pump filter. Referomendation as follows:  In cell pump filter (after contained fuel filter)  In cell pump filter. Refer to TM 55-2840-241-23 1.  In cell pump filter. Refer to TM 55-2840-241-23 1.  In cell pump filter. Refer to TM 55-2840-241-23 1.  In cell pump filter. Refer to TM 55-2840-241-23 1.  In cell pump filter. Refer to TM 55-2840-241-23 1.  In cell pump filter. Refer to TM 55-2840-241-23 1.  In cell pump filter. Refer to TM 55-2840-241-23 1.  In cell shutoff valve for foreign manager for cell shutoff valve for foreign manager for the shutoff valve for proper right for paragraphs 9-149.b. and the receiver and lanyard for cell filter switch for proper operation in the fuel cell).  In cell shutoff for proper operation for the filter switch for proper operation.	ve. Refer to TM 55-2840- em in the following ompliance with MWO M 55-2840-231-23 A (1 or 40-231-23 A or TM  ULED INSPECTION.  oved) for contamination and deterioration or activation.  naterial in fuel path. Refer gging. Refer to paragraph aragraph 10-26. re switch for proper operand 9-162. damage (plastic coating on tion. lean and inspect fuel system 23, Chapter 10.			

AIRCRAFT INSPECTION CHECKSHEET		TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. 28.2	NO. OF PAGES	
AIF	RCRAFT AND SE	RIAL NO	INSPECTION NO.	DATE OF INS	PECTION
AREA NO.	REQUIRE- MENT EVERY		ITEM	STA- TUS	RECORDED ON WORKSHEET
	d. Test and e. Test Low 10 HOURS AFTI a. Inspect or TM 55 b. Inspect or TM 55 b. Inspect compliance with presence of water BLEEDING OF E a. Fuel line fuel nozz main fue b. Engine h d. Engine h d. Engine h e. When ar loosened	ATER OR CONTAMINATION  In fuel system and airframe material materi	cating System.  FEM.  In to TM 55-2840-231-231 A  In the result of the r	TUS	_
	ground run showing aft operations. change eng SWASHPLATE S HOURS THERE		ndicator is not y be released for er ground run, ge filter element. HOURS AND EVERY 50 ( ±5)		

Alf	RCRAFT INSPECTION CHECKSHEET  TYPE OF INSP (Daily, Intermediate, etc.)  SPECIAL		PAGE NO 28.3		NO. OF PAGES		
Alf	RCRAFT AND SERIA	L NO	INSPECTION NO.	DATE OF	DATE OF INSPECTION		
AREA NO.	REQUIRE- MEN EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET	
	MEN						

Change 26 1-66.3/(1-66.4 blank)

AIRCRAFT	AIRCRAFT INSPECTION CHECKSHEET		TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. 24	NO	O. OF PAGES
AIRC	RAFT AND SERIAL	NO.	INSPECTION NO.	DA	DATE OF INSPECTION	
AREA NO.	REQUIREMENT EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET
	or TM 55-284  g. Test fuel filter  h. Bleed (purge sequence:  (1) At the MWO  (2) At the or TM  (3) At the 55-284	switch for p ) air from airframe mo 1-1520-228 engine fuel p 55-2840-24 engine nozz	entire fuel system in the follounted fuel filter. After compliance -50-48.	owing e with 31-23 or TM		
3	Inspection of the 55-2840-231-23.	compressor	S, WHICHEVER OCCURS FIRST halfs on T63-A-700 engine. Refer  L) INSTALLATION OF MAIN RO ASSEMBLIES	to TM		
			NOTE			
	This inspect main rotor h		uired on 206-011-100-131 or -14 lies.	13		
	a. Remove main		and blade assembly for disass	embly		
	<b>b.</b> Perform comp text for require		on of straps, fittings, and pins. Re	efer to		
	<b>c.</b> Deleted.					
	d. Verify records	S.		•		
	e. Reassemble uf for requirement		on protection procedures. Refer	to text		
			NOTE			
	upon accun new, since tension/tors Main rotor	nulation of last overl ion strap a hub assem	nspection shall be accomplished 600 hours operating time sind naul, or since replacement of ssemblies, whichever is greated ablies may be inspected at the phased inspection nearest the	ce of er. ne		

AIRCR	AFT INSPEC	TION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. 24.1	O. NO. OF PAGES				
A	IRCRAFT AN	ID SERIAL NO.	INSPECTION NO.	DATE	OF INS	SPECTION			
AREA NO.	REQUIRE- MENT EVERY		ITEM	STA- ON TUS WORKSHEE					
3		EVERY 600 HOURS SINCE LAST INSPECTION, SINCE NEW, OR SINCE MAIN ROTOR HUB ASSEMBLY OVERHAUL							
	Remove r inspect trui rotor trunni								
		N	ЮТЕ						
	Th hr: tru ph	or							
		N	IOTE						
	co sh ter in se hu re Fo wl ta us W air er	omponent to avoid rependent of indicate when the result indicate when the result indicate when the result in its parated from the aircraph, compliance and next corded on DA Form 2408 orm 2408-15) in terms of onent. For the main rothich do not normally having data from the losing the component is reframe hours that the intered in block 8 of the ecord of the inspection is	nould be maintained with the pat inspections. The record is enext inspection is due to the component so that the when the component of the inspection will be 3-16 (or in the continuation D of operating time on the cord or mast and main drives have a DA Form 2408-16, mained aircraft DA Form 2408-1 installed on an aircraft, the pattern of the special inspection is due will be aircraft DA Form 2408-18. Installed on an aircraft of the pattern of the special inspection another aircraft is not the special inspection is due will be aircraft is not the special inspection another aircraft is not the special inspection in the special inspection another aircraft is not the special inspection in the special inspection another aircraft is not the special inspection in the special inspection and the special inspection another aircraft is not the special inspection in the special inspection and the special inspecti	ds in ne is or oe A n- oft n- ed 8. ne oe					
6			000 and below, with operating from service and replaced.	time of					
3	EVERY 12	200 HOURS							
	Main rotor	mast removed for disasse	embly and inspection.						
6	inspection	, fluorescent penetrant i	and perform complete disas nspect yoke, trunnion, and nion, and balance tail rotor ass	bearing					

AIRC	RAFT INSPECTION	CHECKSHEET	TYPE OF INSP (Daly, Intermediate, etc.) SPECIAL	PAGE NO. OF PAGE NO. 28 25				
	AIRCRAFT AND SE	RIAL NO.	INSPECTION NO.	DAT	DATE OF INSPECTION			
AREA NO.	REQUIREMENT EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET		
	This Inspection abeen accomplished est the 1200 horses	nall						
2	SIX MONTHS							
	a. Inspect portable fi	re extinguisher. R	efer to TM 1-1500-204-23	series.				
	b. Drain hydraulic reservoir and inspect inside bottom for corrosion. Refer to paragraph 7-56. Inspect drained hydraulic fluid for moisture or contamination. Flush in accordance with paragraph 7-7 if evidence of moisture, or other contamination, or if bottom of reservoir is corroded.							
	c. Inspect and test co TM 1-1500-204-2		e (ground) in accordance	with				
	d. Inspect and check ground.	refueling receiver	for grounding strap and	proper				
2	EVERY 12 MONTH	S						
	n. Check magnetic s graph 8-224.	tandby compass fo	or compensation. Refer to	para-				
	ensate if necessa	etic compass set (/ ery. Refer to TM 1	AN/ASN43) for accuracy. 1-6605-202-12.	Comp-				
	c. Delete.							
		eterioration of robb	N's) for bonding separation per components. Refer to n aircraft.)					
All Areas		THS, OR WHENEVER HELICOPTER IS TRANSFERRED, ED, PLACED IN STORAGE, OR REMOVED FROM STOR-						
	Check and account the helicopter is in sto	ile						

AIRCR	AFT INSPEC	TION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. NO. OF F		0. OF PAGES 28	
Al	RCRAFT AN	ID SERIAL NO.	INSPECTION NO.	DATE (	OF INS	PECTION	
AREA No.	REQUIRE- MENT EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET	
2	EVERY 1 ACCOMPL	CTION,					
	Inspect and	d test OAT/FAT gage. Refe					
2	EVERY 24 MONTHS OR NEAREST SCHEDULED INSPECTION, ACCOMPLISH THE FOLLOWING:						
	a. Perform						
	<b>b.</b> First aid	kit inspections. Refer to	ΓM 55-1500-204-25/1.				
All Areas	24 MONTH	HS					
	Weight aird		and balance records check. F	Refer to			
	LIGHTNIN	G STRIKE INSPECTION					
	a. Genera	I requirements when the h	elicopter is struck by lightning	:			
	rc pi	otor systems, and static of	and exterior, the landing ge- ground wire for burn marks, n temperature stress, to determ ss.	cracks,			
	` '	ace the path of the lightnir magnetometer.	ng strike to the extent possibl	e using			
	ì		pass for accuracy (the dec an indicator of the severity				
	(4) Ins	pect wiring in tunnel areas	s and exposed areas for bums	S.			
	(5) Ins	spect antennas for bums a	and pitting.				
	(6) Inspect all electrically operated components and lighting systems for damage.						
	(7) Inspect communications and navigation equipment for damage.						

AIRO	CRAFT INS	PECTION CHECKSHEET	TYPE OF INSP (Daily, Intermediate, etc.) SPECIAL	PAGE NO. 27	NO.	OF PAGES
	AIRCRAI	T AND SERIAL NO.	INSPECTION NO.	DATE O	F INSF	PECTION
AREA NO.	REQUIRE MENT EVERY	-	ITEM		STA- TUS	RECORDED ON WORKSHEET
	(10) F (11) F (13) P (14) R (15) Specific system (1) Ins (2) Re (4) Re (4) Re	the preceding steps (1) occurred, proceed as follow ench test all avionics and Perform a continuity check Perform a Voltage Standing antennas, antenna cables, a Perform aground run operation behavior to the flight control systems and the flight control systems are any damage and repusing standard maintenance are requirements whenever limits are processed for damage such flowers and the flight control systems are processed for damage such flowers and the flight control systems are processed for damage such flowers and the flowers are processed for damage such flowers and processed flowers and performs a system of the flight control systems and the flowers are processed for damage such flowers and flowers and flowers and flowers and flowers and flowers and flowers are processed flowers.	through (7) reveal major damages:  electrical systems and component on all wiring and cables.  g Wave Ratio (VSWR) check of and connectors.  s/replacements as required.  conal check on the aircraft. Function and all avionics, electrical, lightion systems.  lace damaged components as required practices.  ghtning strike is evident on main och as burns, pitting, skin separation scrap damaged blade(s).  return for overhaul.  ext higher assembly if required) in stem located above the servo-cylin oly, mast Assembly and transmit	on all onally hting, quired rotor n, etc.		
		damaged aul.				
	<b>c.</b> Specific	stem:				
	<b>(1)</b>	n, etc.				
	<b>(2)</b> T					
	<b>(3)</b> R	emove and condemn pitch	change links, and crosshead bea	aring.		

AIRCRA	FT INSPECTION	CHECKSHEET	TYPE OF INSP (Daily intermediate, etc.) SPECIAL	PAGE NO. 28		OF PAGES 28	
All	RCRAFT AND SEF	RIAL NO.	INSPECTION NO.	DA	DATE OF INSPECTION		
AREA NO.	REQUIREMENT EVERY		ITEM		STATUS	RECORDED ON WORKSHEET	
	(4) Inspect cr Replace	aging.					
	<b>(5)</b> Remove 9						
	(6) Replace a	any magnetized	tail rotor driveshaft hanger bearin	ngs.			
	wheeling	g assembly, mair	ower assembly, splined adapter, n driveshaft and tail rotor drivesha etism. Replace as necessary.				
		oil cooler and coessary.	oil cooler filter assembly for da	mage.			
		s drive train iter d return for overh	ns show magnetism, remove trai	nsmis-			
		neeling assembly and return for ov	v shows magnetism remove engil erhaul.	ne as-			
			support installation, pylon, and on for damage. Replace if necessa				
4	•	ating in heavy ft from unprepare	sand or dust conditions, or who	enever			
	a. Deleted.						
		•	duction fairing seal and firewall to Replace defective seal.	induc-			
	<b>c.</b> Inspect engine	e plenum chamb	er for freedom from air leaks.				
	MWO 1-1520-22		HOURS AFTER COMPLIANCE NTIL ALL CONTAMINANTS HAVE 1.				
	<b>a.</b> Inspect fuel con 241-23.	ontrol filter. Refe	r to TM 55-2840-231-23 or TM 55	-2840-			
	• ,	ed (purge) air from fuel system at engine nozzle. Refer to TM 55-0-231-23 or TM 55-2840-241-23.					

AIR	CRAFT INSPECTION SHEET	ON CHECK-	TYPE OF INSP (Daly, Intermediate, etc.) SPECIAL	PAGE NO. 28.1	N	O. OF PAGES 28	
A	IRCRAFT AND SEF	RIAL NO.	INSPECTION NO.	DA	TE OF	INSPECTION	
AREA NO.	REQUIREMENT EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET	
	WITH MWO 1-15	20-228-50-48 AI	OURS AFTER COMPLIAI ND UNTIL ALL CONTAI ROM FUEL SYSTEM.				
	a. Inspect engine for TM 55-284	-23 A ,					
	b. Test engine fuel 23 A , or TM	pump bypass v I 55-2840-241-	valve. Refer to TM 55-284 2.	10-231-			
	c. Bleed (purge) ai ence:	r from entire fue	l system in the following	sequ-			
	(1) At airframe m 1-1520-228-		r. After compliance with l	MWO			
	(2) At engine fue or TM 55-28	el pump filter. Ro 40-241-23 <b>©</b> .	efer to TM 55-2840-231-2	3A,			
	(3) At engine not 2840-241-23	zzle. Refer to TN	∄ 55-2840-231-23 🔼 , or	TM 55-			
	EVERY 24 MONT	HS OR NEARE	ST SCHEDULED INSPE	CTION.			
	a. Inspect entire fu and proper oper	el system (sump ation as follows	removed) for contamina :	ition			
		ell interior for da paragraph 10-5	mage, deterioration, or a	ctiva-			
	(2) Inspect fuel sh Refer to para		oreign material in fuel pa	th.			
	(3) inspect shuto 10-45.	off valve for prop	per rigging. Refer to para	agraph			
	(4) Test fuel low	level switch. Re	fer to paragraph 10-26.				
			pressure switch for prop 149b and 9-162.	er oper-			
		eceiver and lany n fall into fuel ce	ard for damage (plastic c ·II).	oating			
	(7) Test fuel filter	switch for prope	er operation.				
			und, clean and inspect fu 1520-228-23, Chapter 10				
	10 HOURS AFTE	R CLEANING F	UEL SYSTEM.				
	a. Inspect engine or TM 55-2840	fuel pump filter. 0-241-2 <b>C</b> .	Refer to TM 55-2840-231	l-23 A ,			
	b. Inspect engine to or TM 55-2840-	fuel control filter -241-23 <b>C</b> .	r. Refer to TM 55-2840-23	1-23 <b>A</b> ,			

AIRCRAFT INSPECTION CHECK- SHEET		TYPE OF INSP (Daly, Intermediate, etc.) SPECIAL	PAGE NO 28.2	NO. OF PAGES 28			
AIRCRAFT AND SERIAL NO.		INSPECTION NO.	DA	TE OF INSPECTION			
AREA NO.	REQUIREMENT EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET	
		mounted fuel fi 520-228-50-48.	tter element. After compl	iance			
	d. Inspect Fuel Qu	antity and Low I	Level Warning System.				
	WHENEVER WA' FUEL CELL	TER OR CONTA	AMINATION IS PRESEN	T IN			
		MWO 1-1520-22	airframe mounted fuel filt 8-50-48) for contaminati				
	BLEEDING OF E	NTIRE FUEL SY	STEM REQUIRED.				
	m. Fuel lines have and fuel nozzle. well as main fue	This includes fu	nywhere between boost p el pressure sensing lines	oump as			
1	b. Engine flameout due to fuel exhaustion.						
	c. Engine has been motored without fuel in tank.						
	d. Engine has been shut down with emergency fuel shutoff.						
		. When any filter, drain or bleed plug, (except sump valve has been loosened or opened without boost pump ON).					
4			SCAVENGE OIL FILTER ED (POPPED), AFTE 8-50-44.				
	NOTE  If filter bypass (red button) is showing, reset indicator, ground run engine, and reinspect. If indicator is not showing after ground run, aircraft may be released for operations. If indicator is showing after ground run, change engine oil, and replace scavenge filter element.						
3	SWASHPLATE SUPPORT AT 1200 (±150) HOURS AND EVERY 50 (±5) HOURS THEREAFTER.						
	Inspect swashplat	Inspect swashplate support. Refer to paragraph 5-148.					
		U mount suppo	OTE rt or launcher adapter I stem must be foresight				
		IPPORT, PYLO	OMPONENTS ARE INST N ASSEMBLY EJECTOR TALLED).				
	Perform boresight 16-58.1 through		accordance with paragra	ph			
<u></u>	<u> </u>				11		

AIRCR	AFT INSPECT	TION CHECKLIST	TYPE OF INSP (Daily,	PAGE NO	NO.	OF PAGES
			Intermediate, etc.) SPECIAL	28.3		28
AIF	AIRCRAFT AND SERIAL NO. INSPECTION NO. DATE OF INSPE		OF INSPEC	CTION		
AREA NO.	REQUIRE- MENT EVERY		ITEM		STA- TUS	RECORDED ON WORKSHEET
			NOTE			
	Whenever PDU mount support or launcher adapter is removed or reinstalled, the system must be boresighted  EVERY 30 DAYS WHEN ATAS COMPONENTS ARE INSTALLED (PDU					
		SUPPORT, PYLON R ADAPTER INSTA	N ASSEMBLY, EJECTOR LLED).	RACK AND		
	Perform bo through 16		in accordance with paragrap	h 16-58.1		
	ANY TIME TRANSMISSION EXTERNAL OIL FILTER INDICATOR PIN HAS BEEN ACTUATED (POPPED) (AFTER COMPLIANCE WITH MWO 1-1520-228-5051).					
			NOTE			
	If filter bypass (red button) is showing, reset indicator, ground run transmission and reinspect. If indicator is not showing after ground run, aircraft may be released for operations. If indicator is showing after ground run, change transmission oil and replace filter element and repeat ground run.					
		TRANSMISSION SSION IS REPLACE	OIL IS CHANGED A D.	ND WHEN		
	Clean filter	bowl and replace filt	er element (if external filter is	installed).		

## SECTION V. OVERHAUL AND RETIREMENT SCHEDULE

## 1-61. INTRODUCTION.

- **a**. Overhaul and retirement schedule. This section lists units of operating equipment that are to be overhauled or retired at the period specified. Removal of equipment for overhaul may be accomplished at the inspection nearest the time when overhaul is due unless otherwise specified in TM 1150032823.
- **b.** Overhaul interval. The maximum authorized operating time or calendar interval of parts prior to removal for overhaul at category of maintenance authorized in accordance with Maintenance Allocation Chart.
- c. Retirement Schedule. The operating time or calendar interval specified for removal, condemnation, and disposal of parts in accordance with applicable directives.



TM 1152032823 should be referred to concerning mutilation/destruction of items when they have reached the established life expectancy (finite life) before the items are forwarded for property disposal.

#### NOTE

Items replaced on a calendar basis (for the purpose of overhaul or retirement) will not be listed on DA Form 240816, Component Installation and Removal Record, but will be listed on DA Form 240818, Equipment Inspection List, for scheduling purposes.

## **OVERHAUL AND RETIREMENT SCHEDULE**

## Model OH-58A/C Helicopter

			Overhaul Interval	Retirement Interval
Area		Part Number and Item	(Hours)	(Hours)
2	602C0001-8	Pilot and Copilot Seat Covers		24 Months
Main Rotor 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	206-010-102-9 206-010-102-013 206-010-102-121 206-010-123-1 206-010-155-7 206-010-155-15 206-011-140-1 206-011-100-1 206-011-100-5 206-011-100-23 206-011-100-131 206-011-100-143	Grip Assembly Grip Assembly Grip Assembly Pin, Strap Retainer Pin, Strap Retainer Fitting Assembly Fating Assembly Frtting Assembly Hub Assembly	1200 1200 1200	4800 4800 4800 400 1200 400 1200 1200
3 3 3 3 3 3 3	206-011-113-1 206-011-113-103 206-011-147-1 206-011-147-5 206-011-154-101 206-011-154-105 206-011-250-3 206-011-250-113	Trunnion Assembly Trunnion Assembly Strap Assembly Strap Assembly Strap Assembly Strap Assembly Strap Assembly Blade Assembly Blade Assembly		2400 4800 1200 1200 1200 1200 2400 2400

			Overhaul Interval	Retirement Interval
Area	a	Part Number and Item	Hours)	(Hours)
<b>Mair</b> 3	n Rotor Controls 206-001-194-1 A / C	Lower Collective Tube Assembly		4800
3 3 3 3	206-001-524-11 A /C 206-010-407-1 206-010-450-5 206-010-450-7 206-010-450-9	Lower Collective Tube Assembly Collective Idler Link Assembly Swashplate and Support Assembly Swashplate and Support Assembly Swashplate and Support Assembly	ON CONDITION ON CONDITION ON CONDITION	4800 4800
3 3 3 3 3 3	206-010-452-1 206-010-454-1 206-010-467-1 206-010-452-5 206-010-454-5 206-101-454-109	Support, Swashplate Assembly Sleeve, Swashplate Assembly Collective Lever Assembly Support, Swashplate Assembly Support, Swashplate Assembly Sleeve, Swashplate Assembly Sleeve, Swashplate Assembly	ON CONDITION	4800 4800 4800 4800 4800 4800
Eng		,		
4 4 4 4	206-061-432-1 A 206-061-432-39 C 6874201 A 6874201 A'	Blower Assembly Oil Cooler Blower Assembly Oil Cooler Engine Turboshaft750 Engine, Turboshaft (Suffix B Serial	ON CONDITION ON CONDITION	
4	6887191	Numbers Only Engine, Turboshaft	2	1000 1800
Arm	nament			
5	P7911-2 CS	Impulse Cartridges		36 Months 3
	Rotor and Drive System			
6 6	206-010-750-5 206-010-750-5	Blade Assembly Blade Assembly (Serial Numbers TLL8000 and below only)		1200 900
6	206-010-750-109 206-016-201-111 206-011-803-5 206-011-812-5 206-011-819-101 206-040-400-7	Blade Assembly Blade Assembly Trunnion Assembly Trunnion Assembly Unlimited Yoke Assembly4800 Gearbox Assembly	ON CONDRIION	1200 2400 2400
	206-040-400-9 206-040-402-003 206-040-371-111 (SKCP2348-5)	Gearbox Assembly Gearbox Assembly Main Driveshaft Assembly	ON CONDRTION ON CONDITION	5000

## 1-68 Change 26

#### NOTES

All retirement life components will have a Demil code of "L" and be mutilated.

Δ

The complete -131 and -143 hub assembly has no overhaul or retirement interval. It does contain retirement items listed on this schedule. For record keeping purposes the -131 and -143 hub assembly will be treated as a time change component. Hub assemblies will be recorded on the aircraft time change DA Form 2408-16, with the lowest retirement life components as the driver for time change requirements.

A

Applies to any engines having the letter B as part of the suffix.

Not to exceed 8.5 years from the date of manufacture (shelf life), or 36 months from the date of opening the sealed cartridge container (installed life), or 10 Installations and/or removals from the ejector rack. Explosive life is not additive and therefore cartridge replacement is required whenever any of these conditions are reached.



Main rotor hub assemblies P/N 206-011-100-131 or earlier may contain the 206-011-113-1 or -103 trunnion. The 206-011-100-143 hub assembly should only have the -103 trunnion. Replacement of main rotor trunnion P/N 206-011-113-1 has been controlled at overhaul of the main rotor hub. When operating time of the -1 trunnion is unknown due to no records, field units may replace the trunnion on P/N 206-011-100-131 hubs at 1200 hours since last main rotor hub overhaul. The P/N 206-011-100-23 or earlier hubs may be operated to next scheduled main rotor overhaul. When part number or serial number of the installed trunnion cannot be determined, the unit may be operated to next required special (magnetic particle) trunnion inspection.

## CHAPTER 2

## AIRFRAME

Structural repairs described in this chapter are intended for use in conjunction with TM 1-1500-204-23. General Aircraft Maintenance Manual. The damage limits provided in this chapter on bonded panels are not intended to red X the helicopter. The limits are to provide guidance for scheduling repair or replacement at the next scheduling maintenance interval. When damage limits, particularly bond voids in bonded panels are exceeded. the responsible maintenance authority will establish a recurring special instruction on the damaged area until the damaged to the structure is corrected. If the damage is in the area that requires engineering authority for repair, engineering should be contacted in writing with a description of damage. If depot assistance will be required, unit should contact ATCOM, AMSAT-I-MDO, with your requirements. The limitations in the following

note should be observed when performing structural repair on the airframe.

## NOTE

Repair at AVUM is limited to minor sheet metal cracks, scratches, corrosion, and loose or missing hardware. These repairs can be accomplished using the airframe repairman's tool kit and portable hand tools. If any extensive damage occurs or major repair is required, repairs shall be accomplished by AVIM. Repair at AVIM is limited to repair of sheet metal cracks, scratches, corrosion holes, and loose or missing hardware. If major damage occurs requiring jigs and fixtures, repairs shall be accomplished by next higher maintenance level.

## **SECTION I. FUSELAGE**

## 2-1. FUSELAGE.

**2-2. Description** — **Fuselage**. The fuselage consists of three main sections; the forward section, which demands from the robin nose to the bulkhead aft of the passenger compartment, the aft section, which extends from the bulkhead aft of the passenger compartment to the tailboom, and tailboom section. The foward section utilizes aluminum honevcomb and sheet metal structures for the major load carving elements. The forward section provides for pilot and passenger seating, fuel cell enclosure, and pylon support. The aft section utilizes an aluminum and honeycomb semimoncoque construction and provides a deck for engine installation, a compartment under the engine deck for electrical equipment and hard points for Air-To Air Stinger (ATAS) missile system CS . Refer to figure FO-1 for structural station diagram. Refer to table 2-1 for Repair Materials.

## 2-3. DOOR ASSEMBLIES-CABIN.

2-4. Description — Door Assemblies. Four entrance doors (1 and 2, figure 2-1 A ) (1 and 2, figure 2-2E) (6 and 7, figure 2-2.1 S ) are provided for access to the cabin. The doors are of sheet metal construction with stretched acrylic windows. A latch assembly, which may be operated from either side, secures the doors in the closed position. In an emergency, doors may be jettisoned by pulling the emergency release handle on the inside of each door forward support. Door lock devices were incorporated by MWO 55-1500-204-30-1.

They consist of a strap, fastener, and a stud to hold the inside door handles of the left and right rear doors, and the left front door, in the locked position when the helicopter is secured on the ground. Also, there are two door lock angles and a padlock for the outside of the right front door. The door vents have aluminum tubing running through drilled holes in each vent.

## 2-5. Inspection — Door Assemblies.

- **a.** Inspect door for cracks, dents or damage, and seals for condition and security.
  - **b.** Check hinges for condition and wear:
- (1) Check crew door hinges for condition and wear. Lock for bent or broken spring (19, figure 2-3). Inspect washer detent (14) for elongation of pivot hole, and for mutilated detent edges. Inspect hinge-half (34) for loose rivets, for bent, twisted or cracked pivot point. Pin (20) shall not be bent. Pivot hole diameters shall not exceed 0.198 inch. Door hinge shall not bind or squeak. Ensure door is properly aligned with latches. Check doors for fore or aft looseness. Doors shall not rattle or jar loose at extremes of travel. Inspect supporting structure for cracking, distortion and tears. No cracking or tears permitted.
- (2) Check passenger door hinges for condition and wear, Look for bent bolt (33), cracked or bent hinge-halves. No cracking or bending permitted. Door hinges shall not bind or squeak. Ensure doors align with

#### TM 55-1520-228-23

latches without forcing door up or down. Pivot holes shall not exceed 0.198 inch diameter. Inspect supporting structure for cracking, distortion and tears. No cracking or tears permitted. Check doors for excessive fore or aft looseness. Door hinges shall be sufficiently tight to prevent door from rattling or jarring loose at extremes of travel.

- (3) Inspect the pivot pin holes. The holes are serviceable if the largest diameter of the hole does not exceed .210 inches. If that dimension is larger, the door hinge pivot holes can be repaired if the holes can be rebored to .375 inches (maximum) maintaining the original center.
  - (a) Remove door from aircraft.
- **(b)** Carefully rebore the hole, maintaining the center, to prevent binding from misalignment of the hinge pins. (It might be necessary to fabricate a drill jig to locate the hole on the original center.)
- (c) Using chemical conversion coating, alodine (38) the area in and around the new hole.

- (d) Coat spacer, sleeve P/N NAS 42 DD6-8 with epoxy and press into hinge.
  - (e) Allow epoxy to dry and reinstall door.
- c. Inspect snap vents for security in windows, cracks, and operation.



Door assembly may open In flight and separate from aircraft If latch assembly is Improperly adjusted.

## **CAUTION**

Door assembly may open in flight if latch assembly is improperly adjusted. Armament will fire through door when door is open.

**d.** Inspect latches for broken or loose handles, loose mountings, proper latching, and adjustment.

## 2-2 Change 23

Table 2-1. Repair Material

		COMMERCIAL		
ITEM	DESCRIPTION	GAGE	DESIGNATION	SPECIFICATION
1	Aluminum Alloy Block	0.125	7075-T6	QQ-A-250/13
2	Aluminum Alloy Honeycomb	0.375	3.1 1/8 0.0007	MIL-C-7438
3	Aluminum Alloy Honeycomb	0.500	3.1 1/8 0.0007	MIL-C-7346
4	Aluminum Alloy Honeycomb	1.000	3.1 1/8 0.0007	MIL-C-7438
5	Aluminum Alloy Honeycomb	1.000	8.1 1/8 0.0020	MIL-C-7438
6	Aluminum Alloy Honeycomb	1,250	3.1 1/8 0.0007	MIL-C-7438
7	Aluminum Alloy Honeycomb	1.250	5.7 3/16 0.0020	MIL-C-7436
8	Aluminum Alloy Honeycomb	1.250	8.1 1/8 0.0020	MIL-C-7438
9	Aluminum Alloy Rod	7.500	2024-T351	QQ-A 225/6
10	Aluminum Alloy Sheet	0.008	2024-T3	QQ-A-250/5
11	Aluminum Alloy Sheet	0.012	2024-T3	QQ-A-250/5
12	Aluminum Alloy Sheet	0.016	2024-T42	QQ-A-250/5
13	Aluminum Alloy Sheet	0.016	7075-T6	QQ-A-250/13
14	Aluminum Alloy Sheet	0.016	2024-T3	QQ-A-250/5
15	Aluminum Alloy Sheet	0.020	2024-T3	QQ-A-250/5
16	Aluminum Alloy Sheet	0.020	2024-T42	QQ-A-250/5
17	Aluminum Alloy Sheet	0.025	2024-T3	QQ-A-250/5
18	Aluminum Alloy Sheet	0.025	2024-T42	QQ-A-250/5
19	Aluminum Alloy Sheet	0.032	2024-T3	QQ-A-250/5
20	Aluminum Alloy Sheet	0.032	2024-T42	QQ-A-250/5
21	Aluminum Alloy Sheet	0.032	7075-T6	QQ-A-250/13
22	Aluminum Alloy Sheet	0.032	5052-H34	QQ-A-250/8
23	Aluminum Alloy Sheet	0.040	2024-T42	QQ-A-250/5
24	Aluminum Alloy Sheet	0.040	6061	QQ-A-250/11
25	Aluminum Alloy Sheet	0.040	2024-T3	QQ-A-250/5
26	Aluminum Alloy Sheet	0.040	7075-T6	QQ-A-250/13
27	Aluminum Alloy Sheet	0.050	2024-T3	QQ-A-250/5
28	Aluminum Alloy Sheet	0.050	7075-T6	QQ-A-250/13
29 30	Aluminum Alloy Sheet Aluminum Alloy Sheet	0.050 0.063	2024-T42	QQ-A-250/5
31	Aluminum Alloy Sheet	0.063	2024-T3 7075-T6	QQ-A-250/5 QQ-A-250/13
32	Aluminum Alloy Sheet		7075-16 7075-T6	
33	Aluminum Alloy Sheet	0.064 0.071	2024-T3	QQ-A-250/13 QQ-A-250/5
33 34	Aluminum Alloy Sheet	0.071	7075-T6	QQ-A-250/13
35	Aluminum Alloy Sheet	0.080	7075-T6 7075-T6	QQ-A-250/13
36	Aluminum Alloy Sheet	0.090	7075-16 7075-T6	QQ-A-250/13
37	Acrylic Plastic Sheet	0.060	7070 10	MIL-P-25690
38	Acrylic Plastic Sheet	0.100		MIL-P-25690
39	Acrylic Plastic Sheet	0.125		MIL-P-25690
40	Foam Nopcofoam	0.120	G304/G306	WIIZ 1 20000
41	Glass Fabric		Type A	
42	Glass Fabric		Type C	
43	Phenolic Sheet	1.000	.,,,,,	
44	PhenolicSheet	0.15625		
45	Rubber	0.125	Type A/Gr 40	MIL-R-6855
46	Steel, Corrosion Resistant	0.012	302	MIL-S-5059
47	Steel, Corrosion Resistant	0.015	Cond A	MIL-S-6721
		3211347		

Table 2-1. Repair Material (Co
--------------------------------

ITEM	DESCRIPTION	COMMERCIAL GAGE	DESIGNATION	SPECIFICATION
48 49	Steel, Corrosion Resistant Steel, Corrosion Resistant	0.020 0.032 321/347	T1 Cond A	MIL-S-6721 QQ-S-766
50 51 52 53 54	Steel, Corrosion Resistant Steel, Corrosion Resistant Titanium Sheet Titanium Alloy Sheet Styrofoam	0.040 0.063 0.025 0.012	301 301 Type I	MIL-S-5059 MIL-S-5059 MIL-T-9046 MIL-T-9046

- **e.** Inspect the inside door handle locking straps, fasteners, and studs for damage or wear (figure 2-6).
- **f.** Check the outside of right front door for the door lock angles. They should be free of cracks or damage (figure 2-8).
- **g.** Inspect for proper installation/condition of door vent locks (precut aluminum tubing) (figure 2-9).

## 2-6. Adjustment - Door Assemblies.

- a. Remove pin (8, figure 2-3),
- **b.** Adjust roller assembly (9) clearance for 0.090 to 0.140 inch from the rear wall of the striker housing (1) with latch in closed position. Refer to figure 2-3, detail C.
- **c.** Align hole in roller assembly (9) with slot in rod (10) and insert pin (8).
- **d.** Peel shim (3) on striker (4) as required for smooth operation of the latch with as little door panel deflection as possible with no door rattle.

## 2-7. Removal — Door Assemblies.

- a. Open door and support to prevent damage.
- **b.** Remove cotter pin (23, figure 2-3), nut (22), washers (12), belleville washers (21), plates (14), spacers (13), and bolt (11 or 33) from hinge points. Remove door assembly.

## **NOTE**

Crew doors may be jettisoned for ease of maintenance instead of removing the bolt from hinge points.

#### **NOTE**


Plates (14) and bolt (11) are only on doors with hold open latch. Removed doors must have the helicopter aerial number stenciled on the inside of the door if the door will be reinstalled. Doors are not interchangeable from one helicopter to another without adjustment.

## 2-8. Removal - Door Seals.

- a. Remove blind type rivets from retainer plate.
- **b.** Remove damaged seal and clean adhesive residue to bare metal.
- **c.** Wipe area with a clean cloth dampened in toluene (C 150) and wipe with clean dry cloth.
- **2-9.** Disassembly Door Assemblies.
  - a. Removal of crew door latch assembly.


## **NOTE**


Disassemble latch only to the extent necessary for repair or replacement.



- passenger Door
   Step Cover
- 4. Avionics Compartment Door
- 5. Forward Transmission Fairing Inspection Door
- Transmission Induction Fairing Access Door
- 7. Engine Cowl Side Panel
- 8. Oil Tank Drain Access Door
- 9. Transmission Oil Level Access Door
- 12. Access Panel Structural
- 13. Tailboom Inspection Panel Structural
- 14. External Power Connector Access Door
- 15. Connector Receptacle (Ground)
- 16. Inside Panels
- 17. Horizontal Stabilizer Panels

Figure 2-1. Access Panels, Doors, and Ballast Installation






- 1. Crew Door
- 2. Passenger Door
- 3. Step Cover
- 4. Avionics Compartment Door
- 5. Forward Transmission Fairing Inspection Door
- 6. Transmission Induction Fairing Access Door
- 7. Engine Cowl Side Panel
- 8. Oil Tank Drain Access Door
- 9. Transmission Oil Level Access Door
- 10. Engine Oil Filler Cap Access Panel

- 11. Fuel Tank Filler Cap
- 12. Access Panel Structural
- 13. Tailboom Inspection Panel Structural
- 14. External Power Connector Access Door
- 15. Tailboom V/R Flight Controls Access Cover
- 16. Tail Rotor Driveshaft Cover
- 17. Connector Receptacle (Ground)
- 18. Inside Panel
- 19. Horizontal Stabilizer Panels

Figure 2-2. Access Panels and Doors C



- 4.
- 6.
- 8.
- Crew Door
  Passenger Door
  Access Panel
  Connector Receptacle (Ground)

- External Power Connector Access Door Tailboom Inspection Panel Transmission Induction Fairing Access Door Oil Tank Drain Access Door

- Tail Rotor Driveshaft Cover
  Tailboom V/R Flight Controls Access Cover
  Avionics Compartment Door
- 16.
- 17. Step Cover

Figure 2-2.1. Access Panels and Doors CS (Sheet 1 of 2)




Figure 2-2.1. Access Panels and Doors CS (Sheet 2)




Figure 2-3. Door Installation (Sheet 1 of 2)




Figure 2-3. Door Installation (Sheet 2)

- (1) Remove pin (1, figure 2-4] securing handle (2) to spindle (3). Remove handle.
- (2) Remove screws (4) from escutcheon assembly (5). Remove escutcheon assembly and shim (6).
- (3) Remove cotter pin (7), pin (8), and lift out bellcrank (9) and spindle (3).
- (4) Remove pin (10) from bellcrank and pull out spindle (3).
- (5) Remove two screws (11), washers (12), and remove escutcheon (13), handle (14), and spindle (15). Remove screw (16) from handle (14) and remove spindle (15) from handle. Remove retaining ring (32) and remove handle (14) from escutcheon (13).
- (6) Remove seven screws (17) and washers (18) from support (19).
  - (7) Pull support (19) clear of door.
- (8) Remove cotter pin (20) and pin (21) from rod (28).
- (9) Remove washer (29) from link (22) and remove link from lever (30).
  - (10) Release spring (27) and remove rod (28).
- (11) Remove pin (23) and remove roller assembly (24).
- (12) Remove cotter pin (25), pin (26), and rod (31).
  - 13) Lift lever (30) free of support (19).
  - **b.** Removal of passenger door latch assembly.

## NOTE

# Disassemble latch only to the extent necessary for repair or replacement.

- (1) Loosen screw (5, figure 2-5) and remove two screws (1). Remove escutcheon (3). Remove retaining ring (4) and separate handle (2) from escutcheon (3).
- (2) Remove guard (6) from door. Knock out pin (11) and pull out spindle (12) from bellcrank (9),

- (3) Remove cotter pin (8) and pin (7). Remove bellcrank (9) and receptacle (10) from inside door.
- (4) Remove two screws (28), washers (27), and remove escutcheon (26), handle (29), and spindle. Remove screw (30) from handle (29) and remove spindle (32) from handle. Remove retaining ring (31) and remove handle (29) from escutcheon (26).
- (5) Remove seven screws (16) and washers (17) from support (15).
  - (6) Pull support (15) clear of door.
- (7) Remove cotter pin (21) and pin (22) from rod (18).
- (8) Remove washer (23) from link (24) and remove link from lever (25).
  - (9) Release spring (14) and remove rod (18)
- (10) Remove pin (19) and remove roller assembly (20).
- **(11)** Remove cotter pin (33), pin (34), and rod (13).
  - (12) Lift lever (25) free of support (15).


## 2-10. Repair or Replacement — Door Assemblies.

- a. Replace door latch assemblies as follows:
  - (1) Inspect all parts for obvious damage

#### NOTE

When replacing door hinge, door must be fitted to the helicopter to ensure proper hinge positioning.

- (2) Replace all parts that are damaged or corroded.
  - b. Repair stud tearout as follows: (figure 2-6)
- (1) Remove strap assembly (1), stud (2), and blind rivnut (4).
  - (2) Clean hole to minimum size.



17. Screw

18. Washer

19. Support

21. Pin

22. Link

23. Pin

20. Cotter Pin

24. Roller Assembly

26. Pin

28. Rod

27. Spring

29. Washer

32. Retaining Ring

30. Lever

31. Rod

9. Belicrank

10. Pin

11. Screw

12. Washer

14. Handle

15. Spindle

16. Screw

13. Escutcheon

Figure 2-4. Latch Assembly — Crew Door

1. Pin

2. Handle

3. Spindle

4. Screw

6. Shim

8. Pin

7. Cotter Pin

5. Escutcheon Assembly





Figure 2-5. Latch Assembly - Passenger Door (Sheet 1 of 2)



2-1




Figure 2-6 Repair - Stud Tearout and Door Hinge (Sheet 1 of 3)




Figure 2-6. Repair — Stud Tearout and Door Hinge (Sheet 2)





Figure 2-6. Repair - Stud Tearout and Door Hinge (Sheet 3)

- (3) Add one 0.040 x 3 x 3 contour formed aluminum doubler centered along strap centerline over stud location and bond to door.
  - (4) Install blind rivnut (4).
- (5) Install strap assembly (1) and stud (2) into rivnut.
- c. For replacement of door lock angles for the outside of the right front door, fabricate (1560-OH-58-100-1 and -2) from angle material. Deburr and round corners with 1/8-inch radius (figure 2-8).
  - d. Repair of door hinge area:
- (1) Cracks cannot exceed 0.750 inch above the upper existing rivet or 0.750 inch below existing rivet or extend into the centerline of door inner skin hat section. Stop drill all cracks with No. 40 drill.
- (2) Fabricate doubler, figure 2-6, and bend to match door hat section. Position doubler on door and

- locate two holes for existing door hinge rivets centered about the centerline of doubler. Mark and trim off excess doubler material. Doubler should not extend over the door edge or over the crest of hat section. Locate remaining rivet holes and drill holes in doubler. Sand door area and mating surface of doubler with 180 grit sandpaper (C124) and wipe area with clean cloth saturated with Methyl-Ethyl-Ketone (MEK) (C107).
- (3) Bond doubler in place, using (C19) adhesive, install rivets through doubler and door, install door hinge, and prime and paint as required (reference TM 55-1500-345-23).
- **2-11.** Repair Passenger Entrance SCUFF PLATES. Debond scuff plate and remove the two forward inboard rivets. Do not remove the two aft rivets. Cut through the aft section of the scuff plate at station 96.22 (figure 2-7). Remove the debonded and damaged scuff plate from the aircraft structure. Thoroughly clean the scuff plate and any bonding material remaining on the airframe with MEK (C107)








Figure 2-8. Right Front Door

or abrasive cloth (C45). Reshape the damaged scuff plate and install on aircraft bonding it with adhesive (C19) and with as many cherry rivets, (CR 2249-4) as necessary to retain scuff plate to the airframe.

#### 2-12. Installation — Door Seals.


- **a.** Clean new seal with toluene (C150), abrade with sandpaper (C123) and clean seal again.
- **b.** Apply adhesive (C10) using fiber brush (C31), to seal and door frame.
- **c.** Air dry at room temperature for a minimum of one hour.
- **d.** Press seal firmly into place against door and apply pressure for a minimum of two hours.
  - **e.** Using blind type rivets, install retainer.

## 2-13. Alternate installation — Door Seals.

- **a.** Clean edge of door with MEK (C107), abrade with sandpaper (C124) and clean door edge with MEK (C107) again.
- **b.** Apply adhesive (C10) using fiber bristle brush (C31) to seal and door edge.
- **c.** Press firmly into place on door and apply pressure for a minimum of two hours.

## 2-14. Assembly — Door Assembly.

- a. Installation of crew door latch assembly.
- (1) Position end of lever (30, figure 2-4) in hole in support (19).
- (2) Press pin (21) on link (22) into inside arm in lever (30) and lock in place with washer (29).



2. All dimensions are in inches.

Figure 2-9. Door Vent Locks

- (3) Insert rod (28) through holes in support (19) and attach springs. Align hole in rod with link (22) and insert pin (21). Lock in place with cotter pin (20).
- (4) Position end of roller assembly (24) in rod (28) and secure with pin (23).
- (5) Attach rod (31) to outside arm of lever (30) with pin (26) and cotter pin (25).
- (6) Align hole in bellcrank (9) with hole forward end of rod (31), attach with pin (8) and cotter pin (7).
- (7) Guide support (19) into place in door and attach with seven screws (17) and washers (18).
- (8) Install handle (14) into escutcheon (13) and secure with retaining ring (32). Secure spindle (15) to handle (14) with screw (16).

To correct fit of handle (2), peel shim (6) to move handle inboard or outboard.

- **(9)** Guide spindle (15) into lever (30) ensuring outside arm on lever is up and install escutcheon (13) with two screws (11) and washers (12).
- (10) Ensure bellcrank (9) is pointing with large square hole down and install spindle (3) and pin (10).
- (11) Place shim (6) over spindle (3) and guide through escutcheon assembly (5). Install escutcheon assembly (5) with three screws (4).
- (12) Install handle (2) horizontally and install pin (1) from above.
- b. Installation of passenger door latch assembly
- (1) Position end of lever (25, figure 2-5) in hole in support (15).
- (2) Press pin (22) on link (24) into inside arm in lever (25) and lock in place with washer (23).
- (3) Insert rod (18) through holes in support (15) and attach springs. Align hole in rod with link (24) and insert pin (22). Lock in place with cotter pin (21).
- (4) Position end of roller assembly (20) in rod (18) and secure with pin (19).

- (5) Attach rod (13) to outside arm of lever (25) with pin (34) and cotter pin (33).
- (6) Align hole in bellcrank (9) with hole in forward end of rod (13), attach with pin (7) and cotter pin (8).
- (7) Guide support (15) into place in door and attach with seven screws (16) and washers (17).
- (8) Install handle (29) into escutcheon (26) and secure with retaining ring (31). Secure spindle (32) to handle (29) with screw (30).
- **(9)** Guide spindle (32) into lever (25), ensuring outside arm on lever is up and install escutcheon (26) with two screws (28) and washers (27).
  - (10) Install receptacle (10).
- (11) Install bellcrank (9) to rod (13) with pin (7) and cotter pin (8).
- (12) Insert spindle (12) in bellcrank (9) and install pin (11).
- (13) Insert handle (2) through escutcheon (3) and install retaining ring (4).
- (14) Position guard (6) and install assembled door handle over spindle (12). Align holes and install attaching screws (1). Tighten screw (5).

#### 2-15. Installation — Door Assemblies.

# CAUTION

Door assemblies are not directly interchangeable from one helicopter to another. Adjustment is required.

- a. Position door in hinge fittings
- **b.** Install bolt (11 or 33, figure 2-3), washers (12), spacer (13), plates (14), belleville washers (21), and nut (22).

Plates (14) and bolt (11) are only on doors with hold open latch. Ensure that the helicopter serial number stenciled on the inside of the door matches the serial number of the helicopter. Matching the door to the helicopter will ensure a proper fit with no further adjustment necessary. If a new door is installed, stencil the serial number of the helicopter on the inside of the new door.

**c.** Torque nut (22) to 16 INCH-POUNDS and install cotter pin (23).

### **NOTE**

Install crew doors if jettisoned (paragraph 2-32).

# 2-16. INSTRUMENT PANEL, SHROUD AND CONSOLE.

**2-17. Description** — **Instrument Panel, Shroud and Console.** The instrument panel is mounted on the respective console and contains all instruments for the pilot and copilot. The instrument panel is mounted by mounting screws located around edge of panel. The instrument panel is rigidly mounted and no adjustments are required.

# 2-18. Cleaning — Instrument Panel, Shroud and Console.

a. Remove moisture and loose dirt with a clean, soft cloth.



Drycleaning solvent is flammable and its fumes are toxic. Provide adequate ventilation. Do not use near a flame.

- **b.** Remove grease, fungus, and ground-in dirt with a clean, lint-free cloth dampened with drycleaning solvent (C62).
- **2-19.** Inspection Instrument Panel, Shroud and Console. Visually inspect panels, shrouds and consoles for surface scratches, cracks, loose or missing rivets or mounting screws, wrinkles, warpage, and evidence of corrosion.

# 2-20. Removal — Instrument Panel, Shroud and Console.

- a. Ensure all electrical power if OFF.
- **b.** Disconnect all electrical receptacles and hoses from instruments.
- **c.** Cover all receptacles and hoses to prevent entrance of foreign particles.
  - d. Cover openings in instruments.
- **e.** Remove mounting hardware from instrument panel, shroud or console and lift the components from the helicopter.

# 2-21. Repair – Instrument Panel, Shroud and Console.

Repair cracks. Refer to TM 55-1500-204-25/1.

- **b.** Replace loose and missing rivets and mounting screws.
- **c.** Remove corrosion if present. Refer to TM 43-0105.
- **d.** Touch up paint if damaged or deteriorated, using primers (C118) **A**, (C116) **C** and lacquers (C91) **A**; and (C89 or C90 **C** in accordance with TM 55-1500-345-23.

# 2-22. Installation — Instrument Panel, Shroud and Console.

- **a.** Position console in place and install mounting hardware.
- **b.** Position instrument panel on console and install mounting hardware,
- **c.** Connect electrical receptacles to instruments. Refer to Chapter 8.
- **d.** Position shrouds as applicable and install mounting hardware.

### 2-23. BEAM UPPER CABIN ROOF.

**2-24. Description** — **Beam Upper Cabin Roof.** The beam is installed under the cabin roof between the bulkheads at station 73.0 and 130.0. The beam is

constructed of aluminum alloy forgings and extrusions and provides support for the pylon mount,

- **2-25.** Inspection Beam Upper Cabin Roof. Inspect upper beam for loose, sheared or missing rivets, cracks, and evidence of corrosion.
- **2-26.** Removal Beam Upper Cabin Roof. Removal of upper beam must be accomplished at depot maintenance.

#### 2-27. Repair — Beam Upper Cabin Roof.

- a. Repair is limited to replacement of loose, sheared or missing rivets and removal of corrosion, Refer to TM 55-100-204-25/1 and TM 43-0105,
- **b.** Repair of cracks in upper beam must be accomplished at depot maintenance.

#### 2-28. JETTISON MECHANISM.

**2-29. Description** — **Jettison Mechanism**, The jettison mechanism (details A and B, figure 2-3) consists of a handle and rod assembly to facilitate emergency exiting of helicopter,

### 2-30. Inspection — Jettison Mechanism.

- a. Inspect handles for cracks or bends,
- b. Inspect rods for bends or corrosion
- **c.** inspect crew door rods for a minimum of 0.500 inch extension through door hinges.
- d. Ensure that handle is properly safetied with copper lockwire (C98). Refer to figure 2-3, detail D,

#### 2-31. Removal — Jettison Mechanism.



Removal of jettison mechanism rods will release spring loaded door hinges.

- **a.** Remove cover plates and screws over rear door units.
  - b. Remove handles and rods

- 2-32. Repair or Replacement Jettison Mechanism. Replace defective handles and/or rods with serviceable items.
- 2-33. Installation Jettison Mechanism (figure 2-3). Install jettison mechanism as follows:
- **a.** Install rods ensuring they engage door hinge, Ensure crew door rod extends a minimum 0.500 inch through door hinge.

### NOTE

To keep from bending rods, remove inspection plates and assist rod tip through rod guides and door hinge.

In the event stop screw (5) contacts crew upper jettison rod preventing 0.500 inch minimum engagement of rod at lower hinge half, file head of stop screw as required to obtain minimum engagement.

- b. Install handles with bolts, nuts, and washers.
- c. Attach rods to handles and lockwire (C98) handle to bulkhead.

# 2-34. COWLING AND FAIRINGS ENGINE AND TRANSMISSION.

**2-35. Description** — **Cowling and Fairings,** Cowling and fairings are used to protect and provide easy maintenance access to engine compartment, intake and exhaust tailpipe areas, and top of main transmission.

# 2-36. TRANSMISSION FAIRINGS ASSEMBLY.

#### 2-37. Description — Transmission


Assembly. The transmission fairing is in two sections consisting of forward and induction failings, Induction section provides for air intake to the particle separator. On helicopters, serial number 70-15244 and subsequent, and helicopters incorporating MWO 55-1520-228-30/9 acrylic plastic inlet plenum inspection windows (10, figure 2-10) are installed in the induction fairing (2). These windows make unnecessary the removal of induction fairing and particle separator for inlet plenum inspection. Helicopters with MWG 55-1520-228-30/10

accomplished will have reverse inlet flow fairings (2, figure 2-11) over induction fairings. These fairings reduce the possibility of engine flameout due to snow ingestion. The OH-58C forward transmission fairing (1) has flame spray metal coating on part of inner and outer skin. Metal coating provides conductive surface for APX-100 antenna.

# 2-38. Inspection — Transmission Fairing Assembly.

a. Inspect fairing for cracks, tears, and damage.

- **b.** Inspect hinges and fittings for wear, damage, and serviceability.
- **c.** Inspect windows for abrasions, scratches, cracks, holes or other damage that impedes visual inspection of the inlet plenum or that permits outside air or material to enter. Refer to TM 55-1500-204-25/1 for repair.
- **d.** Inspect rubber seal on top and sides of forward firewall assembly for tears and bond failure.



- 1. Forward Fairing
- 2. Induction Fairing
- 3. Engine Cowl
- 4. Exhaust Stacks
- 5. Aft Fairing

- 6. Cowl Side Panel
- 7. Fastener
- 8. Snap-Open Latch
- 9. Screw
- 10. Inlet Plenum Inspection Window

Figure 2-10. Engine and Transmission Cowling A

- 1. Forward Transmission Fairing
- 2. Reverse Inlet Flow Fairing
- 3. induction Fairing
- 4. Screw
- 5. Screen
- 6. Exhaust Stack
- 7. Engine Cowl
- 8. Screens
- 9. Screw
- 10. Aft Fairing
- 11. Fastener
- 12. Cowl Side Panel
- 13. Snap-Open Latch
- 14. Access Door
- 15. Screw
- 16. Fastener 17. Infra-Red Shields
- 18. Access Door




Figure 2-11. Engine and Transmission Cowling ©

To prevent access door (6 and 9, Figure 2-1) skin fractures caused by the snap open latch contacting edge of cutout when snapping open, latch cutout length may be extended by filing 0.188 inch from aft edge of cutout.

2-39. Removel - Transmission Fairing Assembly



Protect compressor inlet port opening and governor control rod on left side when the induction fairing is removed.

#### NOTE

Reverse inlet flow fairing, if installed, must be removed before removing either forward transmission fairing (1, figure 2-10) or induction fairing (2). Forward fairing (1) must be removed before removing induction fairing.

- **a.** Loosen fasteners (7) securing the forward section of fairing (1). Lift fairing from helicopter.
- **b.** Loosen fasteners securing induction fairing (2).

### **NOTE**

# Armor plate may be removed to aid in removal of fairing.

- **c.** Unlatch access doors (6 and 9, figure 2-1) on each side of induction fairing and remove screws attaching induction fairing to roof deck.
  - **d.** Remove bleed air lines from particle separator.
- **e.** Unlatch engine cowl panels (6, figure 2-10) to stain access to internal screws. Remove screws (9) attaching induction fairing to particle separator and forward firewall.

# 2-40. Removal — Transmission Fairing Assembly

#### NOTE

Reverse inlet flow fairing (2, figure 2-11), if installed, must be removed before removing either forward transmission fairing (1) or induction fairing (3). Forward transmission fairing must be removed before induction fairing is removed.

- **a.** Unlatch access doors (6 and 9, figure 2-2) to remove bolt attaching lower edge of reverse inlet flow fairing (2, figure 2-11) to induction fairing (3).
- **b.** Loosen fastener, remove attaching bolts and screws. Remove reverse inlet flow fairing (2).
- **c.** Open forward fairing inspection doors (6, figure 2-2). Disconnect glideslope and APX-100 antenna cables inside doors. Refer to TM 11-1520-228-20-1.
- **d.** Loosen fasteners (16, figure 2-11) and remove forward transmission fairing (1).

## NOTE

Protect compressor inlet port opening and governor control rod on left side when induction fairing (3) is removed.

e. Loosen fasteners securing induction fairing (3).

## **NOTE**

# Armor plate may be removed to aid in removal of induction fairing.

- **f.** Unlatch access doors (14) on each side of induction fairing and remove screws attaching fairing to top of deck.
  - Remove bleed air lines from particle separator.
- **h.** Unlatch engine cowl side panels (7, figure 2-2) to gain access to screws inside. Remove screws attaching the particle separator to the forward firewall which is part of induction fairing on forward firewall.
  - i. Remove induction fairing (3, figure 2-11).

- **2-41.** Repair Transmission Fairing Assembly.

  A Refer to TM 55-1500-204-25/1 for repair.
- 2-42. Repair Transmission Fairing Assembly (figure 2-12).
- **a.** Repair areas that are not flame-spray metalized using standard repair methods. Refer to TM 55-1500-204-25/1

Remove minimum amount of flamespray metalized surface necessary to accomplish repairs.

- **b.** Repair edges, fastener attachment areas, and door hinge areas of flame-spray metalized surfaces as follows:
- (1) Use 80 grit sandpaper (C123) to remove metalized coating, if required in repair area,
  - (2) Use standard repair procedures.
- **c.** Repair other flame-spray metalized areas, if authorized by engineering.
- 2-43. Installation Transmission Fairing Assembly.

# CAUTION

Exercise care to prevent damage to the rubber seal on forward firewall during installation of induction fairing assembly.

- **a.** Position induction fairing assembly on forward firewall and align mounting holes.
  - b. Install screws securing fairing to roof deck
  - c. Install bleed air lines on particle separator,
- d. Install screws securing particle separator to forward firewall.
  - e. Tighten fasteners on fairing.
- f. Position forward section in place and tighten fasteners to secure fairing. If reverse inlet flow fairing

- is to be installed at this time, do not tighten fastener at top edge of forward transmission fairing, adjacent to main rotor mast opening.
- g. Connect glideslope and APX-100 antenna cables inside inspection door (5, figure 2-2) on forward fairing. Refer to TM 11-1520-228-20-1.
- h. Install reverse inlet flow fairing (2, figure 2-11), if required. Place fairing (2) over forward transmission fairing (1). Tighten fastener and install three bolts and five screws. Install bolt on bottom edge through open access door (14) of induction fairing (3).

### 2-44. ENGINE COWLING.


- 2-45. Description Engine Cowling. The engine cowling (3, figure 2-1 A) figure 2-11 C) is constructed of aluminum alloy and is removable for engine change. Cowling access panels are provided with snap-open fasteners which permit inspection without removing the cover unit.
- **2-46. Inspection** Engine Cowling. Inspect engine cowling for cracks, dents, and damage.

## 2-47. Removal — Engine Cowling.

- a. Remove four screws and unlatch four fasteners attaching upper cowling (3, figure 2-10 \(\bar{\mathbf{A}}\))
  (7, figure 2-11 \(\bar{\mathbf{C}}\) to forward and aft firewalls.
- **b.** Open cowling side panels (6, figure 2-10 **A**) (12, figure 2-11 **C**) and disconnect anticollision light electrical lead.
- c. Disconnect engine oil vent hose from right side engine exhaust stack.
- **d.** Remove nuts from exhaust stack clamps and exhaust stacks (4, figure 2-10 **A**) (6, figure 2-11 **C**) from engine exhaust collectors.
- e. Remove engine cowling (3, figure 2-10 A)(7, figure 2-11 C)) from helicopter and exhaust stacks (4, figure 2-10 A (6, figure 2-11 C) from cowling openings at the same time.

#### 2-48. Repair — Engine Cowling.

a. Sheet metal repair will be accomplished as outlined in TM 55-1500-204-25/1.






Figure 2-12. Forward Fairing Repair

#### TM 55-1520-228-23

- **b.** Repair engine cowling side panel screens (8, figure 2-11) with aluminum alloy sheet (23, table 2-1). Make hole pattern to match existing screen.
- **c.** Upper engine cowling assemblies P/N 206-061-804-63 with deteriorated royalite on screen assemblies, P/N 206-062-817-1, will be repaired as follows:
- (1) Remove screen assemblies from cowling and remove deteriorated layer of royalite from screen.
- (2) Fabricate doubler the same size as screen O.D. from 300 series, 1/2 hard stainless steel,  $.025 \times 5/8$  inch.
- (3) Reinstall screen and doubler to cowling, picking up original holes, with 3/32" MS20426AD rivets. Install rivets wet with zinc chromate primer.

### 2-49. Installation - Engine Cowling.

Position engine exhaust stacks (4, figure 2-10 A) (6, figure 2-11 C) in engine cowling (3, figure 2-10 A) (7, figure 2-11 C) openings and place both on helicopter.

- **b.** Position cowling (3, figure 2-10 A) (7, figure 2-11 C) on forward and aft firewalls and install four screws and latch four fasteners attaching upper cowling (3, figure 2-10 A) (7, figure 2-11 C) to firewalls.
- **c.** Install engine exhaust stacks (4, figure 2-10 **A** (6, figure 2-11 **C** ) on engine exhaust collector. Refer to paragraph 4-61.
  - d. Connect anticollision light electrical lead.
- e. Close and fasten engine cowl side panels (6, figure 2-10 A ) (12, figure 2-11 C ).
- **2-50.** Rework Engine Cowling (AVIM). OH-58A/C aircraft with the IR suppressor stacks may require the following rework:

# WARNING

Remove cowl prior to trimming of exhaust cutouts to preclude foreign materials from falling into the engine exhaust collectors. Keep exhaust collector openings covered to the maximum extent possible.

**a.** Remove engine cowling (paragraph 2-47) and exhaust cones (paragraph 4-58). Retain the attaching hardware for reinstallation.

- **b.** Temporarily reinstall and fasten down the engine cowling, insert from the top and position replacement suppressor stacks on engine exhaust collector. Note any areas of interference between the stack sides and exhaust port cutouts in the engine upper cowl and compress stack insulation. Locally remove material from the cowl exhaust port cutouts as required to provide a minimum of 0.032 inch clearance in all areas.
- If cowl exhaust cutouts require material removal to provide required clearance, determine if cutout support doubler width is decreased to less than 0.250 inch width and/or if doubler attach rivets have less than 0.140 inch edge distance. Less than 0.140 inch rivet edge distance necessitates additional trimming to remove the rivet hole. Doubler width of less than 0.250 inch in any area necessitates removal of the doubler and fabrication of a new doubler 0.500 inch wide to reinforce the new shape cutout. The new doubler to be fabricated from 0.032 inch aluminum QQ-A-250/5, and attached with sheet. MS20470AD3-4 rivets. Apply primer (C116), to reworked areas as required.
- **d.** Reinstall engine cowling (paragraph 2-49) and exhaust stacks (paragraph 4-61).

### 2-51. DRIP PAN AND FRAME ASSEMBLY.

**2-52. Description - Drip Pan and Frame Assembly.** The frame and drip pan are installed aft of the engine pan and provide mounting surfaces for the oil cooler and two drive shaft hangers. The frame is constructed of aluminum honeycomb core and aluminum facings with two ply fiberglass edging. Refer to paragraph 2-223 for drip pan drain installation.

# 2-53. Inspection - Drip Pan and Frame Assembly.

- **a.** Inspect for loose, sheared, or missing rivets, evidence of corrosion and security.
- **b.** Inspect honeycomb frame assembly for delamination, punctures, dents, cracks, buckles, and other damage.
- **2-54. Repair Drip Pan and Frame Assembly.** Refer to paragraph 2-172 and TM 1-1500-204-23 for repairs.

#### 2-55. PASSIVE DEFENSE. A

**2-56. Description - Passive Defense.** A Two pieces of armor plate are located in the forward section of the engine compartment for protection of the engine compressor section. These are mounted on the forward firewalls, one on each side of the engine compressor. Refer to paragraph 2-124 for additional armor panel information.

# 2-57. Inspection - Passive Defense.

- a. Inspect armor plates for security of mounting.
- b. Inspect for damage resulting from enemy fire. Replace Armor plate.

# 2-58. Removal - Passive Defense. A

- 58. Removal Passive Defense.
- a. Open engine cowling (7, figure 2-1) on side requiring armor plate.
- b. At forward firewall remove two nuts, washers, and screws attaching plate to firewall stiffener.
- c. Remove two nuts, washers, and screws attaching two brace assemblies to firewall support. Remove armor plate assembly.
- **2-59. Disassembly Passive Defense** A Armor plate is removed from angle and brace assemblies by removing two nuts and washers at each brace assembly. 2-60. Repair or Replacement- Passive Defense. ORepair is limited to replacement with like serviceable item.
- **2-61.** Reassembly Passive Defense. A Position brace assembly on serviceable armor plate and secure with two nuts and washers on each brace assembly.
- **2-62. Installation Passive Defense**. A Position armor plate assembly in firewall mounting supports
- b. Install two screws, washers, and nuts securing brace assemblies to firewall support.
- c. Where armor plate assembly seats in firewall support install two screws, washers, and nuts. Close engine cowling.

#### 2-63. AFT FAIRING.

- **2-64. Description** Aft Fairing. The aft fairing (5, figure 2-10 A ) (10, figure 2-11 C) encloses the oil cooler, oil cooler blower fan, and the oil tank.
- **2-65. Inspection Aft Fairing**. Inspect for cracks, dents, damage, and interference with the tail rotor driveshaft coupling disc. If interference with coupling disc is present refer to AVIM maintenance for repair.

**2-66. Removal - Aft Fairing**. Unlock fasteners (7, figure 2-10) attaching aft fairing to firewall and remove aft fairing (5) from helicopter.

# 2-67. Removal - Aft Fairing.

- a. Remove aft screw (10, figure 2-11) and unlock fasteners (11).
  - b. Remove aft fairing (10).
- **2-68 Repair Fairing**. To prevent damage to aft fairing by tubing, cut out honeycomb as shown in figure 2-12.1 Fill edges of cut out with two part EA934 as shown. Reference TM 1-1 500-204-23 for additional repair.

# 2-69. Installation - Aft Fairing. A



- a. Position aft fairing assembly to aft firewall and align mounting holes.
- b. Install and lock three unlock fasteners securing aft fairing to aft firewall and tighten.

## 2-70. Installation - Aft Fairing.



- a. Position aft fairing (10, figure 2-11) to aft firewall. Align mounting holes.
  - b. Close fasteners (11) and install screws (9).

#### 2-71. ACCESS DOORS AND PANELS.


**2-72. Description - Access Doors and Panels.** Access doors and panels consist of the avionics compartment door, external power receptacle door and inspection plates for access to and maintenance of components.

#### NOTE

Panels secured by screws or bolts are considered structural and will be In place for jacking, hoisting, towing, and flight. Panels that are cracked, bent, or having enlarged fastener holes will be replaced. Structural panels will be Installed with all fasteners In place.

### 2-73. AVIONICS COMPARTMENT DOOR.

**2-74. Description** - **Avionics Compartment Door**. The avionics door A (4, figure 2-1 0 ) (4, figure



#### VIEW LOOKING INBOARD RPH SIDE FWD

Figure 2-12.1 AF Fairing Repair

2-2 C 2-2.1 CS ) is on left side aft of the cabin doors and provides ready access to the battery and avionics equipment. This door is secured by two push type latches. Push inboard on two latches to release door.

### 2-75. Inspection - Avionics Compartment Door.

- **a.** Inspect door for damage, cracks, and wear.
- **b.** Inspect hinges and latches for wear, damage, and serviceability.
- c. Inspect quick release pins (18, Figure 2-2.1 S) for wear, damage, and serviceability.

- **2-76.** Removal Avionics Compartment Door. Open door and remove screws, washers, and nuts from hinge points; remove door.
- **2-76.1.** Removal Avionics Compartment Door. Open door (16, Figure 2-2.1). Remove quick release pin (18) from devises (20) and hinge (19). Disconnect snap hook (21) from mount plate. Remove door (16).
- **2-77. Repair Avionics Compartment Door**. Repair will be accomplished according to procedures outlined in TM 1-1500-204-23 (Series)
- **2-78. Installation Avionics Compartment Door**. A Position door in hinges and install screws, washers, and nuts.

- **2-781.** Installation Avionics Compartment Door. Position hinges (19, Figure 2-2.1) in devises (20). Install quick release pins (18) through devises (20) and hinge (19). Connect snap hook (21) to mounting plate. Close and latch door (16).
- **2-79. EXTERNAL POWER RECEPTACLE ACCESS DOOR.** Inspect external power receptacle access door (14, Figure 2-1 A) (14, Figure 2-21 C) for locking, security, and damage.

Panels secured by screws or bolts are considered structural and will be In place for Jacking, hoisting, towing, and flight Panels that are bent, cracked, or have enlarged fastener holes will be replaced. Structural panels will be Installed with all fasteners in place.

- **2-80. INSPECTION PANELS**. Inspection panels (refer to Figure 2-1 0, A and 2-2 1 C), secured with screws or fasteners, are provided for inspection and maintenance of the helicopter.
- **2-81.** Removal Inspection Panels. Remove screws attaching panels to structures.
- **2-82. Installation Inspection Panels**. Position inspection panel in opening and install screws to attach panel to structure.

#### **CAUTION**

- Use of excessive length screws may cause damage to Internal components or parts of the helicopter structure. Ensure that only specified size screws are used.
- To avoid machine screw damage to tall rotor connecting link, do not reinstall screw which secures the center post cover assembly (and cover) at water line 37.55 (third screw up from bottom left side of center post).

To prevent inadvertent future installation of screw, nut plate should be removed and a 1/2 inch square of 0.023 inch thick aluminum bonded over exterior of holes with adhesive (C19). On OH-58C aircraft the lower left screw hole has been eliminated from the heater duct on the center post to prevent inadvertent installation of screw in thislocation.

- 2-3. CREW AND PASSENGER SEATS.
- 2-84. PILOT AND COPILOT SEATS.
- **2-5. Description Pilot and Copilot Seats**. The pilot and copilot seats are constructed of tubing and raschel knit material. Each seat is equipped with back cushions, safety belts, shoulder harness, and inertial reel and strap.
- 2-86. Inspection Pilot and Copilot Seats.
  - a. Inspect seat netting.
- (1) Deterioration ao discoloration which indicates a strength decrease to the point where it affects integrity of the seat(s) is not allowed.
- (2) Tears, cuts, or holes greater than one inch in length or diameter are not allowed.

- b. Inspect cushions for tears and fraying. Comfort is the determining factor for replacement of the seat back cushions.
- c. Inspect raschel seat covers for installation date, markings and service life criteria. Refer to TM1-1500-204-23.

cover tension must be maintained to ensure support for **2-87.** Removal - Pilot and Copilot Seats. Remove screws, washers and nuts securing seat bottom (21, figure 2-13) to supports.

### 2-88. Repair - Pilot and Copilot Seats.

a Tears, cuts or holes less than 1.000 inch in length or diameter in netting may be repaired by a darning procedure which picks up at least 0.250 inch of good material adjacent to or surrounding the cut, tear or hole. While mending, the thread tension should be maintained so as to produce a mend which disturbs as little as possible the natural lines of the seat netting adjacent to the mend. Type 1 thread (C149) or equivalent is used for repairs. This should be used only as a temporary repair, until new raschel covers can be installed.

b. Replace raschel kit seat covers as follows:

### NOTE

Utilize seat cover manufacturer's Installation Instructions, provided.

(1) Remove nylon cord securing bottom seat cover. Remove cover from seat support.

### CAUTION

Additional pull cords may be used. Use tools with smooth Jaws for damping cords Serrated laws will damage the cord. Do not use safety wire. Damage can result to the grommets. Contact between metal reinforced area of the cover and the seat frame (bottom area of seat) Is not cause for rejection If the reinforced area is Inboard of tube center.

- (2) Install cover on seat support and secure with new nylon cord laced through reinforcing eyes. Tighten to desired tension.
- (3) The seat shall not deflect more than 2.000 inches with a load of approximately 166 pounds acting downward and uniformly distributed over the top panel. This may be accomplished by using an occupant, shot bags, or other high density material. Care should be

taken when using shot bags or other high density material to place them in such a manner as to represent an occupant.

### **NOTE**

Raschel covers may stretch after initial Installation. Seat occupant 2-89. Installation - Pilot and Copilot Seats

- a. Install seat back cushions (23, figure 2-13) by mating snap fasteners with fasteners on seat back support.
- b. Install seat bottom (21) on seat support with screws and washers.
- c. Refer to figure 2-31 for honeycomb panel repair.

#### 2-90. PASSENGER SEATS.


**2-91. Description - Passenger Seats**. The passenger seats are constructed of aluminum honeycomb panels and form an integral part of the airframe. The center panel of the seat back is removable to gain access to the fuel cell. Seats are equipped with shoulder harness, safety belts and cushions. Seating is provided for two passengers or without seats, space is provided for cargo.



If helicopter Is to be flown with passenger seat belts removed, passenger seat and back cushions must be removed.

### 2-92. Inspection - Passenger Seats.

- a. Inspect panels for cracks, dents and damage.
- b. Inspect cushions for cleanliness, tears, fraying and loose or damaged fabric or metal fasteners.
- c. Inspect cushion restraining loops, tabs and safety ties for proper installation, condition and security. Ensure seat belts are through loops and safety tied with nylon cord through slot in end fitting.
- d. Inspect tape fastener on cushion support structure for damage, cleanliness and security. Fastener tape which fails to hold cushion in position should be replaced.
- e. Cushions with damaged or worn tape fasteners, restraining loops or tabs should be replaced.



- Lap Belt Assembly
   Shoulder Harness
- 4. Cushion Assembly
- 5. Bolt
- 6. Nut
- 7. Washer
- 8. Bolt

- 10. Reel Assembly
- 11. Screw
- 12. Screw
- 13. Washer
- 14. Nut
- 15. Bolt
- 16. Washer

- 18. Screw
- 19. Washer
- 20. Screw
- 21. Cushion Assembly
- 22. Lap Belt Assembly
- 23. Cushion Assembly
- 24. Shoulder Harness

Figure 2-13. Seats and Restraint Installation

### 2-93. Removal — Passenger Seats.

- **a.** Remove seat cushions (1, figure 2-13) as follows:
- (1) Remove nylon cord safety ties from restraining loops and seat belt and fittings.
- (2) Lift cushion to release fabric and metal fasteners.
- (3) Slide restraining loops off of the seat belts and remove cushion.
  - b. Remove back cushion (4) as follows:
- (1) Remove nylon cord safety ties from restraining loops on the bottom of cushion and the seat belt end fittings.
- (2) Remove screws and washers which secure tabs on top of cushion to the bulkhead.
- (3) Pull cushion to release snap and fabric fasteners.
- (4) Slide restraining loops off of the seat belts and remove cushion.

### 2-94. Repair — Passenger Seats.

- **a.** Honeycomb panel repair is accomplished as outlined in paragraphs 2-179 and 2-184.
- **b.** Seat cushion repairs. Refer to TM 55-1500-204-25/1 for repair.
- c. Remove damaged/worn tape fasteners from seat structure.
- (1) Using a blunt scraper (plastic or wood) work edge of tape fastener loose and pull tape fastener from seat structure.
- (2) Remove adhesive residue using cheesecloth (C37) dampened with toluene (C150).
- (3) Cut tape, fastener, hook (C140) or tape fastener, pile (C141) to length; either item may be installed on seat structure as required for the cushion. Apply adhesive (C12) following directions on container and press tape fastener, hook or pile into position. Refer to figure 2-15.

- (4) Allow adhesive to cure before engaging tape fasteners.
- **d.** Seat belt anchor damage repair and prevention. Repair any negligible honeycomb panel damage per directions in paragraph 2-179. To prevent further damage from seat belt anchor fittings, add doublers to areas subject to damage (figure 2-16).
- (1) Fabricate doublers (two required) from 0.040 inch thickness type 302 stainless steel, to approximate size 2.0 x 1.8 inches.
- **(2)** Form doublers to shape of top of seat panel (figure 2-16).
- (3) Clean up areas where doublers will be installed. Bond doublers in place, using adhesive (C19).

# 2-95. Installation — Passenger Seats.

### NOTE

Inspect cushion and corresponding attachment on the aircraft to ascertain that the fastener hook is installed in one location and the fastener pile in the other. Either hook or pile maybe installed in any location. The installation must be such that a hook and pile mate at each fastener location. If necessary replace seat fasteners. Refer to paragraph 2-94.

- **a.** Position seat and back panels and secure in place with screws and washers.
  - **b.** Install seat cushion (1).
- (1) Feed seat belts through loops on corners of cushion.
- (2) Position cushion and secure metal and fabric fasteners.

Ensure seat belts are through restraining loops of both seat and back cushions before installing safety ties. Safety ties are required in four places.

- (3) Install new nylon cord (C48) safety ties cut to a length of 15 inches. Sear ends and feed cord through both loops (one from seat and one from back cushions) and slot in seat belt end fitting. Tie in a square knot, tie an additional overhand knot in each end and pull down against square knot.
  - c. Install back cushion (4).
- (1) Position cushion and install screws with washers through grommets in tabs on back of cushion to bulkhead. Refer to figure 2-15.
- (2) Feed seat belts through respective restraining loops on bottom of cushion.
  - (3) Fasten metal and fabric fasteners.
- (4) Install safety ties. Refer to step (3) for seat 'cushion installation.

#### 2-96. RESTRAINT EQUIPMENT.

# WARNING

Cotton restraint equipment is not authorized.

**2-97. Description** — **Restraint Equipment.** The crew and passenger restraint systems consist of shoulder harness and safety belts for each location. In addition, each pilots shoulder harness is connected to an inertia reel by a webbed strap.

2-98. SEAT BELTS.

2-99. Description — Seat Belts. Seat belts for pilot, copilot, and two passengers are secured to seat structure at each position.

2-100. Inspection — Seat Belts.

- **a.** Inspect belts for cuts, fraying and loose stitching and for buckle condition. Ensure that doublers (item 10, figure 2-14) are bonded adjacent to the four seat belt hinge supports. Refer to TM 55-1500-204-25/1.
- **b.** Check to ensure correct installation of webbing retarder spring. Refer to TM 55-1 500-204-25/1.
- **c.** Inspect ends of upper and lower seat belt support assemblies P/N 206-032 -153-3 and 206-032-153-1 for evidence of proper crimping. If seat belt support assembly crimps appear insufficient to keep pins captive, apply adhesive (C1) or equivalent to the end of the seat belt support assemblies so as to retain hinge pins while maintaining hinge movement.

### 2-101. Removal — Seat Belts.

# WARNING

If helicopter is to be flown with passenger seat belts removed, passenger seat and back cushions must be removed.

- **a.** Removal aft seat belts (passengers).
- (1) Remove nylon cord safety ties from seat belt end fittings.
- (2) Remove bolts (5, figure 2-13), washers (16), and nuts (6) at attach fitting.
- (3) Slide belt end fitting from cushion retainer loops and remove belt (2).

- **b.** Removal forward belts (pilot or copilot).
- **(1)** Remove nut (2, figure 2-14), washer (3), bolt (6).
- (2) Remove nut (8) from bolt (6) on bulkhead support fitting (9).
- (3) R e m bolt (6) with washer (3) and remove seat belt.

## 2-102. Installation - Seat Belts.

## **WARNINGS**

Seat belt end fittings must be through seat and back cushion retainer loops The loops must be secured to the end fitting with a nylon cord safety tie.

- **a.** Installation aft seat belts (passenger).
- (1) Position belts so release latch lever is as shown on figure 2-13.






Figure 2-14. Crew end Passenger Seat Belt Installation (Sheet 1 of 2)




BULKHEAD INSTALLATION, LOOKING DOWN INSTALL HINGE ASSEMBLIES AND HARDWARE AS SHOWN.




SEAT INSTALLATION, LOOKING AFT INSTALL HINGE SUPPORT ASSEMBLIES AND HARDWARE AS SHOWN.

206070-302-2

Figure 2-14. Crew and Passenger Seat Belt Installation (Sheet 2)






NOTE: Location measurement typical both sides showing area to be stripped.

Fasten tabs here with new bulkhead screws.

All dimensions are in inches.
 Location measurements typical both sides.

Figure 2-15. Fastener Tape Location



VIEW A-A (LOOKING FORWARD)

NOTE: All dimensions are in inches.

(RIGHT SIDE INSTALLATION SHOWN; LEFT SIDE INSTALLATION SIMILAR)

Figure 2-16. Installation of Doubler to Passenger Seat Panel

- (2) Slide seat belt end fitting through seat and back cushion retainers.
- (3) Insert bolt (5) through stationary fitting (from the outboard side), mount seat belt end fitting, place washer (16) on bolt and secure with nut (6).
- (4) Secure seat and back cushion retainer loops to seat belt end fittings, use new nylon cord (C48) safety ties cut to a length of 15 inches, sear ends. Feed cord through both loops and slot in end fitting. Tie cord in a square knot, put an additional overhand knot in each end of cord, slide down against square knot, and pull tight.

# b. Installation — forward seat belts (pilot or copilot).

- (1) Position belts so release latch lever is as shown on figure 2-13.
- (2) Install bolt (6, figure 2-14) through support (7) and belt end fitting (1). Install washer (3) and secure with nut (2).
- (3) Secure belt to bulkhead support fitting by installed bolt (6) through support (9) belt end assembly (1). Install washer (3) and secure with nut (8).

### 2-103. SHOULDER HARNESS.

**2-104. Description** — **Shoulder Harness.** Web type shoulder harness is provided for each crew member and passenger seat. The forward harness attaches to an inertia reel and passenger harness is secured to a support assembly.

## 2-105. Inspection — Shoulder Harness.

Inspect strap for cuts, fraying and loose stitching and buckle condition. Refer to TM 55-1500-204-25/1.

**b.** Check to ensure correct installation of webbing retarder spring. Refer to TM 55-1500-204-25/1.

#### 2-106. Removal - Shoulder Harness.

**a.** Remove aft shoulder harness (3, figure 2-13), by removing soundproof blanket and remove screw, washer, and nut securing harness to support assembly.

**b.** Remove forward shoulder harness (24) by removing bolt (8), washer (7), and nut (6) attaching harness to inertia reel strap assembly (9).

#### 2-107. Installation - Shoulder Harness.

- **a.** Install aft shoulder harness (3, figure 2-13) at support assembly with screw, washer, and nut and install soundproof blanket.
- **b.** Install forward shoulder harness (24) over seat support assembly and secure with bolt (8), washer (7), and nut (6) to inertia reel strap (9).

#### 2-108. INERTIA REEL.

**2-109. Description** — **Inertia Reel.** An inertia reel, with a manually operated control handle, is incorporated on copilot and pilot seats. The inertia reel is a mechanical restraining device designed to hold pilot in a normal seated position during any maneuver which would tend to pitch the pilot forward. Each reel is connected to a shoulder harness with a web strap. An automatic locking mechanism, a webbing roller, and a manual control are incorporated in each unit.

## 2-110. Inspection — Inertia Reel.

- **a.** Inspect reel assembly (10, figure 2-13) for cracks and damage to housing.
- **b.** Inspect shoulder harness for security of attachment to seat and to reel webbing. Inspect inertia reel for security and attachment to floor structure.
- c. Place manual control handle in AUTO position Disconnect shoulder harness from real webbing attach spring scale to end of reel webbing and, while watching scale, slowly pull length of webbing out of inertia reel. The tension indicated should be not less than 2 initially nor more than 6 pounds when the final increment is pulled out of the reel
- **d.** Cycle control handle from AUTO to MANUAL several times as the reel webbing is being reeled in and out. The reel shall positively lock and hold each time the handle is moved to MANUAL.

### 2-111. Removal - Inertia Reel.

a. Remove forward panels to gain access.

- **b.** Disconnect control assembly (17, figure 2-13) from seat.
- c. Remove bolt (8), washer (7), and nut (6), attaching shoulder harness (24) to strap assembly (9).
- **d.** Remove screws (11 and 12), washers (13), and nuts (14), securing reel assembly (10) to airframe.
- **2-112. Repair Inertia Reel.** Replace if inertia reel fails inspection.

#### 2-113. Installation - Inertia Reel.

- a. Secure reel assembly (10, figure 2-13) to airframe with screws (11 and 12), washers (13), and nuts (14). Secure control assembly (17) to reel assembly (10) and lockwire (C95) knurled nut.
- **b,** Install shoulder harness (24) to strap assembly (9) with screw (8), washer (7), and nut (6).
- c. Secure control assembly (17) to seat with screw (18), washer (19), and lockwire (C95) knurled nut.
  - d. Install forward seat panels.

### 2-114. INERTIAL REEL STRAP.

- **2-115. Description Inertia Reel Strap.** A web strap is used to connect inertia reel to shoulder harness.
- 2-116. Inspection Inertia Reel Strap.

# CAUTION

If strap is dirty, do not attempt to clean. Even soap and water cleaning will lower strength and damage beyond repair.

- **a.** Inspect strap for broken or frayed stitching and cuts, especially where strap is retained in main shaft. Refer to TM 55-1500-204-25/1.
- **b,** Inspect for end fitting (2, figure 2-17) wear; hole in end fitting shall measure 0.265 to 0.270 inch.

#### 2-117. Removal — Inertia Reel Strap.

**a.** Remove access tab (4, figure 2-17) from spring shield (3) on power spring end of inertia reel assembly.

# CAUTION

The power spring exerts a strong turning force on the main shaft. Care must be taken to prevent shaft from disengaging hex wench and winding in rapidly.

- **b.** Fully extend strap (5) and retain in extended position by inserting a 7/32 hex wench through access into mainshaft socket. (See view A-A.)
- **a.** Push end of strap (5), in direction of arrow, (detail A), through slot in main shaft so that strap retaining insert (6) is loosened.

#### NOTE

Observe method of retaining strap in main shaft slot with strap retaining insert.

- **d.** Remove strap retaining insert (6) and withdraw strap (5) from inertia reel (1).
- e. Place strap retaining insert (6) into slot in main shaft so that main shaft will lock against insert. Remove hex wrench.


## 2-118. Installation - Inertia Reel Strap.

a. Insert 7/32 hex wrench through access into main shaft socket, Relieve force on and remove strap retaining insert (6, figure 2-17).

# CAUTION

The power spring exerts a strong turning force on the main shaft. Care must be taken to prevent shaft from disengaging hex wrench and winding in rapidly.

**b.** Insert strap (5) through slot in main shaft and lock in place with strap retaining insert (6). (See detail A, figure 2-17).






Figure 2-17. Inertia Reel Strap Assembly Installation

6. Strap Retaining Insert

install insert on single groove side of shaft.

**c.** Remove hex wrench and reinstall access tab (4) spring shield (3).

## 2-119. FRAME ASSEMBLY (SEAT).

Refer to paragraph 2-83.

- **2-120.** Inspection Frame Assembly. Inspect pilots and copilots seat frame assembly for cracks, breaks, and security of mounting. No cracks are permitted.
- **2-121.** Removal Frame Assembly. Remove screws (20, figure 2-13) and washers (19). Remove frame assembly.
- **2-122. Repair Frame Assembly.** Repair is limited to replacement of parts not meeting inspection requirements.
- **2-123. Installation Frame Assembly.** Position frame assembly to floor and install washers (19) and screws (20).

### 2-124. ARMOR PANELS.

**2-125. Description - Armor Panels.** The crew is protected against enemy fire by armor panels. The panels are bolted in place on the outboard and back sides of each seat and under each seat support. The outboard section is hinged at the rear for easy entry to and exit from the helicopter. A latch is provided to keep this panel in proper position during flight.

### **NOTE**

On helicopters S/N 72-21070 and subsequent, and helicopters incorporating MWO 55-1520-228-30-16, an Improved pilots seat armor panel installation is incorporated to improve the crashworthiness of the pilots seat.

2-126. Inspection — Armor Panels.

## WARNING

Armor panel can interfere with collective control if latch is excessively worn or loose.

**a.** Inspect all panels for security of attachment. Ensure latch pins extend into fitting a minimum of 0.250 inch below outboard edge of hole.

- **b.** Visually inspect each panel for surface damage:
- (1) Evidence of a hit by any ballistic projectile requires replacement of panel.
- (2) Visible cracks longer than 0.250 inch are not acceptable.
- (3) Small chips, not more than 0.250 inch diameter, at edges of ceramic faces of panel are acceptable and do not require repair.
- (4) Damage that results in loose nylon cloth shield and/or loose neoprene rubber edge moulding mark loose areas for rebonding.
- **(5)** Check delamination between non metallic backing and ceramic facing.

# 2-127. Removal (Temporary) — Armor Panels.

Remove bolts (16, figure 2-18) and washers (4) on each armor seat back panel (17). Remove panels.

- **b.** Remove screws (1) and washers (2) which attach armor plate hinge to airframe or remove screws (3), washers (4), and nuts (5) which attach hinge (6) to armor plate on each armor panel (14). Remove panels. Reinstall screws (1) and washers (2) which attach armor plate hinges to airframe.
  - c. Remove seats. Refer to paragraph 2-87.
- **d.** Remove honeycomb structure plates under seats. Remove screws (18) and (7) and washers (2), and remove armor panels from underside of structure plates.

## **WARNING**

Ensure Weight and Balance Records are updated to show true helicopter configuration when changes are made to the armor installation. In some cases, with armor removed, ballast will have to be added to maintain CG within limits to meet mission requirements.

**2-128.** Removal (Permanent) — Armor Panels. Crew left and right armor side panels, seat back armor panels, compressor armor, may be removed at the discretion of the unit commander. Applicable weight and balance changes shall be made to the helicopter Weight and Balance Records. Removed armor will be added to the helicopter inventory record.




Figure 2-18. Pilot and Copilot Armor Installation

**2-129. Cleaning — Armor Panels.** Clean armor panels with drycleaning solvent (C62). Wipe dry with dry clean cloth.

## 2-130. Repair or Replacement — Armor Panels.

- **a.** Repair is limited to replacement of any panel not meeting inspection criteria outlined in paragraph 2-126.
- **b.** Rebond loose nylon cloth shield or neoprene rubber edge moulding with adhesive (C17.1).

### 2-131. Installation — Armor Panels.

- **a.** Position seat back panels (17, figure 2-18) in place and install bolts (16) and washers (4).
- **b.** Position armor panels (14) in airframe and install screws (1) and washers (2).
- **c.** Install armor seat panels (19) to structure plates with screws (18 and 7) and washers (2). Install structure plates to airframe.
  - d. Install seats. Refer to paragraph 2-89.

### 2-132. WINDSHIELDS AND WINDOWS.

**2-133. Description** —**Windshields** and **Windows.** The windshield, door windows, and lower windows are constructed of acrylic plastic. The skylight windowe in the roof are constructed of tinted polycarbonate plastic.

### NOTE

Some windshields are constructed of polycarbonate plastic.

**2-134.** Inspection — Windshield and Windows. Inspect for abrasions, scratches, cracks, holes, distortion or other damage. Refer to Figure 2-19, 2-20, and 2-21 for critical areas and repair limits.

## 2-135. Removal — Windshields and Windows.

a. Windshield (figure 2-23) A C Round Glass.

#### NOTE

Refer to paragraphs 2-385 and 2-367 for removal of windshield deflector assembly and to paragraph 2-356 for removal of doublers and aircraft equipped with the wire strike protection system.

#### NOTE

# Do not remove rivets from left BL9 (upper wire-strike area).

- (1) Remove rivets securing retainers by grinding or filing rivet heads and removing rivets.
- (2) If right windshield is being removed, remove free air temperature gage.
- (3) Clean adhesive residue from supports and retainer strips by scraping with a piece of acrylic plastic.

### CAUTION

Do not remove plate (5) from helicopter. Retainer (2) and windshields (3) and (10) are secured under plate (5) with rivets. Remove only rivets securing retainer and damaged windshield. Removal of plate requires depot level maintenance.

#### NOTE


Cap (11) must be removed from helicopter to remove any windshield. Retainers (2), (9), and (12) are secured under cap.

- (1) Remove rivets securing cap (11). Remove cap from helicopter.
- (2) Remove rivets securing windshield under plate (5).
- (3) Remove rivets from retainers securing damaged windshield. Remove retainers.
- (4) If right forward windshield is being removed, remove free air temperature gage (4).

#### **CAUTION**

If heat is required to soften old adhesive, use head lamp only. Do not exceed 250°F (121°C) to avoid damaging other windshields or windows.

**(5)** Remove damaged windshield. If required use heat lamp to soften adhesive under plate (5).



Scratches and pits may be polished out to the extent that vision is not distorted. Distortion of vision is cause for replacement. Cracks, holes, or other damage may be temporarily repaired, if vision of crew members will not be impaired, by stop drilling, patching, or other approved methods (refer to TM 1-1500-204-23), but window must be replaced at the earliest opportunity.

AREA 3 Scratches and pits are permitted in this area provided they are not so numerous or form such a pattern as to be objectionable to the viewer. Cracks, holes, or other damage may be temporarity repaired by stop drilling, patching, or other approved methods (refer to TM 1-1500-204-23), but window must be replaced at the earliest opportunity.

Scratches and pits are permitted in this area, providing the structural integrity of the window is not impaired. Cracks, holes or other damage may be repaired by stop drilling, patching, or other approved methods (refer to TM 1-1500-204-23). Window need not be replaced providing vision is not seriously impaired and window is waterproof.


206032-113

Figure 2-19. Windshields and Cabin Roof Windows — Critical Areas Diagram

AREA C




Round Glass.



AREA A Scratches and pits may be polished out to the extent that vision is not distorted. Distortion of vision is cause for replacement. Cracks, holes, or other damage may be temporarily repaired, if vision of crew members will not be impaired, by stop drilling, patching, or other approved methods (refer to TM 55-1500-204-25/1), but window must be replaced at the earliest opportunity. AREA B Scratches and pits are permitted in this area provided they are not so numerous or form such a pattern as to be objectionable to the viewer. Cracks, holes, or other damage may be temporarily repaired by stop drilling, patching, or other approved methods (refer to TM 55-1 500-204-25/1), but window must be replaced at the earliest opportunity. AREA C Scratches and pits are permitted in this area, providing the structural integrity of the window is not impaired. Cracks, holes, or other damage may be repaired by stop drilling, patching, or other approved methods provided structural integrity is not impaired (refer to TM 55-1 500-204-25/1). Window need not be replaced providing vision is not seriously impaired and window is waterproof.

Figure 2-20. Windshields and Cabin Roof Windows — Critical Areas Diagram CFlat Glass



NOTE: All dimensions are in inches.

Area A

Scratches and pits may be polished out to the extent that vision is not distorted. Distortion of vision is cause for replacement. Cracks, holes, or other damage may be temporarily repaired. if vision of crew members will not be impaired, by stop drilling, patching, or other approved methods (refer to TM 55-1500-204-25/1), but window must be replaced at the earliest opportunutiy.

Area B Scratches and pits are permitted in this area provided they are not so numerous or form such a pattern as to be objectionable to the viewer. Cracks, holes, or other damage may be temporarily repaired by stop drilling, patching, or other approved methods (refer to TM 55-1500-204-25/1).


Area C
Scratches and pits are permitted in this area, providing the structural integrity of the window is not impaired. Cracks, holes, or other damage may be permanently repaired by patching only. Window requires replacement if the 2.000 inch area cannot be repaired by patching (refer to TM 55-1500-204-25/1).

Scratches and pits are permitted in this area, providing the structural integrity of the window is not impaired. Cracks, holes. or other damage may be repaired by stop drilling, patching, or other approved methods provided structural intergity is not impaired (refer to TM 55-1500-204-25/1), and vision is not seriously impaired.

206032.115

Figure 2-21. Windows - Critical Areas Diagram

Area D




Use sealing compound (C131) between glass and structure.


- 1. Retainer
- 2. Retainer
- 3. Forward Windshield
- 4. Free Air Temperature Gage
- 5. Plate
- 6. Retainer

- 7. Retainar
- 8. Skylight
- 9. Retainer
- 10. Side Windshield
- 11. Cap
- 12. Retainer

206032-116.1

Figure 2-22. Windshields and Cabin Roof Windows Replacement (Sheet 1 of 4) C Flat Glass





## VIEW LOOKING DOWN, LEFT SIDE

### NOTE

Remove only rivets securing glass. Removal of place permitted only by depot level maintenance.





Figure 2-22. Windshields and Cabin Roof Windows Replacement (Sheet 3 C Flat glass



Flat Glass Figure 2-22. Windshields and Cabin Roof Windows Replacement (Sheet 4)

- **(6)** Clean adhesive residue from supports and retainers with a plastic scraper.
  - c. Windows.
- (1) Remove rivets securing retainer strip to nose structure and remove lower window.
- (2) Remove rivets securing retainer strip to roof and remove roof window.
- 2-136. Repair Windshields and Windows.

# CAUTION

# Do not use solvent on windows or windshields,

- **a.** Repair acrylic plastic windshields and/or windows in accordance with TM 55-1500-204-25/1.
- **b.** Repair polycarbonate windows and/or windshields as follows:
- (1) Stop drill at each end of crack using a No. 40 drill.
- (2) Lightly sand area to be repaired with sandpaper (C125) about 0.750 inch beyond crack for adhesive application,
- (3) Wipe area with dry, clean, cloth to remove residue.
- (4) Cut section of fiberglass cloth (C71) to extend a minimum of 0.500 inch around crack or area to be repaired.
- **(5)** Apply one brush coat of urethane adhesive (C20) to repair area and lay fiberglass over repair area.
- (6) Rub patch lightly to assure adhesion to repair area and brush another coat of adhesive over
- (7) Allow to cure for 48 hours. (Handling strength is developed in 24 hours.) Accelerated cure time will be two hours under a heat lamp at  $160^{\circ}$ F ( $71^{\circ}$ c).
- **C.** Repair water leaks by using a small bead of sealing compound (C131) on the affected area.

**d.** Minor scratches and mild distortion in area B of the cabin roof windows may be removed by using a small pad of cheesecloth (C37), with a small amount of brasso (C30), Work small areas of window at a time.

# 2-136.1. REPAIR-DOOR FRAME/WINDSHIELD FRAME ASSEMBLY. (ROUND GLASS)

### NOTE

Repair of left and right door frame is identical except for the doubler on the left door frame. For this repair only the left door frame assembly is shown.

#### NOTE

Door frames do not have to be damaged to install nut piates and nutstrips.

#### NOTE

Only MS 20600 rivets will be used except metal to metal splices.

#### NOTE

Do not remove rivets from left BL9 to right BL9 (upper wirestrike area). Cut skylight retainer to follow conture of doubler.

- a. Prepare aircraft for door frame repair as fallows: Refer to figure 2-23.1.
- (1) Remove windshield (1) and skylight window (2). Refer to para 2-135. Remove blind rivet lock rings by grinding or filing rivet heads and removing rivets.
- (2) Remove crew door jettison mechanism (3). Refer to para 2-28. Remove door (4).
  - (3) Remove copilot seat (5). Refer to para 2-87.
- (4) Remove armor panel (6) under copilot seat. Refer to para 2-127.
- (5) Remove windshield defog nozzle (7) and air outlet duct (8) on copilot side of aircraft. Refer to para 13-35.
- (6) Remove doubler (9) P/N 206-031-112-627 from left door frame. Remove blind rivet lock rings by grinding or filing rivet heads and removing rivets.

- (7) Outdoor sealas required.
- **b.** Remove fiberglass doorframe section as follows: Refer to figure 2-23.1.
  - (1) Remove rivets on BL 17 splice.
  - (2) Remove door upper pivot point.
- (3) Insert a piece of scrap metal between fiberglass section and metal door post.

### **CAUTION**

Use extreme care when cutting fiberglass section to prevent damage to metal doorframe.

- (4) Using a hacksaw cut fiberglass door frame section at WL44 and station 64.
  - (5) Remove fiberglass section.
- **c.** Install channel nut strip and nut plates on removed fiberglass section as follows: Refer to figure 2-23.1.
  - (1) Clean removed fiberglass section.
  - (2) Inspect removed fiberglass section.
- (3) Repair any damage to fiberglass section or metal frame per TM 1-1500-204-23.

#### **NOTE**

BL9R to BL17R channel nut strip is not applicable after MWO 55-1520-228-50-33.

- (4) Make aluminum strips for areas BL9 to BL17 and station 64 to station 79 for the center of the frame. Lightly lubricate strip and install with temporary fasteners. Fill rivet holes with epoxy between the following areas: fiberglass section, station 64 to station 79, WL 39 to WL44, and BL9 to BL17.
- (5) Install nutplates on curvature areas as follows:
- **(a)** Using a #10 drill bit, drill nutplate holes every 2.0 inch in center of frame.
- **(b)** Drill and countersink nut plate mounting holes.

- (c) Install fiberglass with CCR264SS-3-X rivets.
- (6) Install fiberglass frame with temporary fastener.
- (7) Cut channel nutstrip to fit the following areas: station 61 to station 79, WL39 to hinge point, hinge point to WL69.5, and BL9 to BL17.

#### NOTE

Allow enough channel at each end of channel nutstrip for trimming.

- (8) Position channel nutstrip in the center section of the frame.
- (9) Mark two holes at either end of channel nutstrip. Remove channel nutstrip and drill marks with a #40 drill bit.
- (10) Reposition channel nutstrip in center of frame and hold in place with temporary fastener.
- (11) Mark fiberglass frame to match channel nuts. Remove channel nutstrip and use #10 drill bit to drill holes.
- (12) Remove fiberglass frame and install channel nutstrip and retaining screws. Trim channel at ends as required.

#### NOTE

Complete all channel nutstrip areas prior to step (13).

- (13) Place a piece of cellophane tape on metal frame in areas to be spliced to prevent adhesive from bending the fiberglass and metal frames. Install fiberglass section, doubler, door jettison mechanism, hinge socket and splice where cut. Use epoxy repair kit (C12.1) for splice. Refer to figure 2-23.1.
- (14) Install cut fiberglass frame with temporary fasteners.
- (15) Drill and countersink mounting holes using a #40 drill bit (approximately every 6 inches).
- (16) Install CCR265SS-3-X rivets in mounting holes.
- (17) Remove retailing screws,

- **d.** Install nutplates to bottom of windshield frame from BL2L, WL44, station 19 to station 46 WL39, BL25L, and BL4R, WL44 station 19 to station 46, WL39, BL25R as follows:
- (1) Enlarge existing rivet holes to match nutplate hole.
  - (2) Drill and countersink nutplate mounting holes.
  - (3) Install nutplate with CCR64SS-3-X rivets.
- (4) Install nutplates to match wirestrike angle clips from BL4R to BL2L.
- **e.** Clean up all repair areas by removing all clippings, filings and sealant residue.
- **f.** Install windshield defog nozzle and air outlet duct on copilot side of aircraft. Refer to para 13-37.
- **g.** Install armor panel under copilot seat. Refer to para 2-131.
  - **h.** Install copilot seat. Refer to para 2-89.
- i. Install skylight and retainer. On inboard area of retainer, install with #6 screws, washers and nuts. Install 6 rivets at aft end of skylight retainer. Install #8 screws where nutplates were installed.

# **NOTE**

All screws will be sealed with sealant (C129).

Cut retainer to match wirestrike doubler.

- j. Install windshield and retainer per para 2-137.
- k. Install doors per para 2-15.
- I. Touch-up paint as required refer to TM 55-1500-345-23.
- **m.** Check Compass Compensation (Swinging) refer to TM 1-1500-204-23.

2-137. Installation - Windshield and Windows.

# **CAUTION**

Exercise care when installing retainer strips to prevent bending or damage.

#### **NOTE**

Damaged door frames should be repaired per para 2-136.1, prior to installation of windshields.

Refer to paragraph 2-364 for installation of windshield deflector assembly on aircraft equipped with the wire strike protection system.

**a.** Windshield (figure 2-23) . . A C Round Glass.

#### NOTE

Space replacement windshields are polycarbonate and will require trimming prior to installation. When trimming the windshield, do not trim the inboard side; however, all other sides must be trimmed. Center the windshield using the inboard side as a reference and trim all other sides as required. Improper centering of the windshield is a major cause of distortion.

- (1) Trim windshield to assure proper fit. Refer to TM 1-1500-204-23.
- (2) Ensure fit and expansion gap by placing windshield on supports.
- (3) Remove windshield and apply a thin even coat of adhesive (C16) to mating surfaces of window supports.

- (4) Position windshield on supports. Fill all void areas between edge of windshield and supports with sealant (C131).
- (5) Apply a thin even coat of sealant (C131) to mating surface of center windshield post retainer strip and secure retainer to center windshield post with screws, washers and nuts.
- **(6)** Apply a thin coat of sealant (C129) to upper wirestrike area BL9 to BL0.
  - (7) Secure all remaining retainers to structure.
- (8) Trim adhesive squeeze-out with sharpened piece of plastic.
- **(9)** Install free air temperature (FAT) gags if right windshield is being installed.




Figure 2-23. Windshield Replacement A C Round Glass




Figure 2-23.1. Door Frame/Windshield Frame Assy Repair (Sheet 1 of 4)




Figure 2-23.1. Door Frame/Windshield Frame Assembly Repair (Sheet 2).




Figure 2-23.1. Door Frame/Windshield Frame Assembly Repair (Sheet 3).




Figure 2-23.1. Door Frame/Windshield Frame Assembly Repair (Sheet 4).

b. Windshields (figure 2-22) C Flat Glass

#### **NOTE**

Windshield mounting area under permanently installed plate (5) must be thoroughly cleaned before installing new windshield.

- **(1)** Place windshield in frame under plate (5). Mark and remove for trimming if necessary.
- (2) Trim windshield so that it does not ride an radius of supports.
- (3) Temporarily install windshield. Tape in place with masking tape (C140) or equivalent.
- (4) Temporarily install retainer (2) over windshield and under plate (5).
- **(5)** Temporarily install remaining retainers and cap(11).
- (6) Carefully check alignment of all retainers and cap (11). Ensure that retainers (2) are aligned with plate (5).
- (7) Using holes in plate, retainers, and cap as a guide, drill rivet holes through windshield using No. 30 drill with special point (figure 2-24).
  - (8) Remove cap, retainers, and windshield.
- **(9)** Enlarge holes in windshield using No. 27 drill with special point (figure 2-24).
- (10) Apply a thin, even coat of sealing compound (C131) to mating surfaces on window supports, retainers, and plate (5, figure 2-22).
- (11) Position windshield. Fill voids between windshield and frame with sealing compound (C131).
- (12) Install windshield, retainers, and cap with rivets.
- (13) Trim sealing compound squeeze-out with sharpened piece of plastic.
- (14) Install free air temperature gage (4) if installing right forward windshield.

- c. Windows (figures 2-21, 2-22, and 2-25).
- (1) Trim window to assure proper fit. Refer to TM 55-1500-204-25/1.
- (2) Apply a thin even coat of sealing compound (C131) to mating surface of window support.
- (3) Position window an supports. Fill all void areas between edge of window and supports with sealing compound (C131).

#### NOTE

When installing new roof windows, do not install rivets through retainer and window. Install only the rivets attaching the retainer to the structure.

#### **NOTE**

To prevent cracking of new plexiglass windows, enlarge the rivet holes in the window to the next oversize as compared to the rivet holes in the metal retainers,

#### **NOTE**


Lower window (chin bubble) retaining strips, left and right, may be reinstalled using bulbed cherrylock rivets, or Cherry Max rivets. Nose cap center skin panel is attached with solid rivets which are inaccessible for bucking and may be replaced with the same type rivets.

(4) Trim sealing compound squeeze-out with sharpened piece of plastic.

#### 2-138. CARGO PLATFORM

# CAUTION

To prevent damage to the floor of the passenger compartment, no cargo will be placed on the floor of the helicopter. The cargo platform will be installed whenever cargo is to be carried.






Figure 2-24. Special Drill Point for Drilling Plexiglas




Figure 2-25. Window Replacement A CRound Glass

**2-139, Description - Cargo Platform (figure 2-26).** A platform may be installed in the passenger area for cargo handling. The platform is a two piece construction of plywood sheeting. Provisions are made for mounting to existing fuselage hardware.

# 2-140. Removal - Cargo Platform.

- **a.** Disengage four quick-disconnect pins from fittings on each section of platform and carefully remove platform from passenger section.
- **b.** Install passenger seat cushions. Refer to paragraph 2-95.
- **c.** Install passenger seat safety belts. Refer to paragraph 2-102.

# 2-141. Installation - Cargo Platform,

- **a.** Remove passenger seat cushions. Refer to paragraph 2-93.
- **b.** Remove passenger seat belts. Refer to paragraph 2-101.
- **c.** Position platform in passenger compartment with notched end forward and butted against the canted center post.
- **d.** Align aft platform fittings with existing seat belt fittings and attach each section with two quick-disconnect pins.
- **e.** Align forward platform fittings with install provisions on canted center post and door post and attach each section with two quick-disconnect pins.

# 2-142. AUXILIARY EQUIPMENT.

**2-143. Description - Auxiliary Equipment.** The locations of auxiliary equipment within the cabin are shown in figure 2-27.

# 2-144. MAP AND DATA CASE.

- **2-745. Description Map and Data Case.** The map and data case is mounted on the aft side of the canted center post. The case has an ashtray attached to one side.
- **2-146.** Removal Map and Data Case. Remove four screws (12, figure 2-27) and washers (11). Remove case (16) from canted center post.

**2-147.** Installation - Map and Data Case. Position case (16) on mount and install four screws (12) and washers (11).

#### 2-148. ASH TRAY.

- **2-149.** Removal Ash Tray. Remove two screws (17, figure 2-27), washers (14), and nuts (13) attaching ash tray (15) to map case.
- **2-150. Installation Ash Tray,** Position ashtray on map case and install with two screws (17), washers (14), and nuts (13).

# 2-151. POCKET ASSEMBLY.

- **2-152. Description Pocket Assembly.** The pocket assembly is mounted on the forward side of the canted center post between the pilot and copilot seat.
- **2-153. Inspection Pocket Assembly,** Check for fraying and loose stitching, tears in fabric and security of mounting.
- **2-154.** Removal Pocket Assembly. Remove four screws attaching pocket assembly (8, figure 2-27) to canted center post.
- **2-155. Repair Pocket Assembly.** Refer to TM 55-1500-204-25/1 for repairs.
- **2-156. Installation Pocket Assembly.** Position pocket assembly and install screws into nutplates on center post.

# 2-157. DUST AND MOISTURE BOOTS.

- **2-158. Description Dust and Moisture Boots.** The flexible boots (7 and 9, figure 2-27) are attached to cockpit floor and serve to protect the pilots and copilots collective and cyclic control stick installation from dirt, dust, and/or other foreign matter.
- **2-159. Inspection Dust and Moisture Boots.** Inspect boots (7 and 9, figure 2-27) for loose or missing screws, fraying, tears, deterioration, and/or other damage.
- **2-160.** Removal -Dust and Moisture Boot. Refer to paragraph 11-44.
- **2-161. Repair Dust and Moisture Boot.** Repairs not permitted. Replace boot.




Figure 2-26. Cargo Platform Installation




Figure 2-27. Auxiliary Equipment

**2-162.** Installation — Dust and Moisture Boot. Refer to paragraph 11-47.

# 2-163. SOUNDPROOFING BLANKETS.

- 2-164. Description Soundproofing Blankets (figure 2-27). The cabin interior is covered with blankets of soundproofing material to reduce noise level for crew and passengers during operation. Blankets are attached to structure by hook-and-pile and snap-type fasteners. Blankets may be removed for access to equipment for maintenance purposes.
- **2-165.** Inspection Soundproofing Blankets. Inspect soundproofing blankets for missing snaps, loose fastening tape, tears in cloth, and improper fit, or deterioration.
- **2-166.** Removal Soundproofing Blankets. Remove blanket section and/or control cover by detaching snaps and/or fasteners as applicable.
- 2-167. Cleaning Soundproofing Blankets.

# CAUTION

#### Do not submerge in water.

- a. Remove dirt, dust, oil, and grease by wiping with cloth dampened with denatured alcohol (C59).
- **b.** Allow to air dry for three to five minutes and repeat step a. as necessary until stains are removed,

# 2-168. Repair or Replacement — Soundproofing Blankets.

- a. Repair cuts or tears
- (1) Cut a patch from fiberglass cloth (C46) large enough to overlap all sides of the tear or cut.
- (2) Apply a thin, even coating of adhesive (C46) to back of patch. Allow to dry until tacky.
- (3) Center patch over tear or cut with adhesive side against blanket.
- (4) Apply firm, even pressure to patch in such a manner that it will adhere securely to blanket without wrinkles or irregularities,

- **b.** Replace missing or damaged buttons and sockets.
- (1) Cut a patch from cloth (C46) large enough to overlap all sides of the damaged area around button or socket.
- (2) Center patch over damaged area and sew securely in place with thread (C148)
- (3) Install new button or socket, using press and dies.
- **2-169.** Installation Soundproofing Blankets. Install blanket section and/or cover by securing fasteners and/or tape in proper areas.

# 2-170. FUSELAGE ASSEMBLY (HONEYCOMB PANELS AND SHELL ASSEMBLY).

2-171. Description — Honeycomb Panels and Shell Assembly. Honeycomb panels constructed of 5052 aluminum alloy core with glass cloth and/or aluminum alloy facing are utilized throughout the helicopter. The transmission and engine fairings, cabin nose, and lower shell are the primary locations of fiberglass faced panels. Aluminum alloy faced panels are utilized in the cabin roof, lower shell, seat supports, vertical fin, and floorings. Refer to figures 2-28 through 2-39 for panel locations and repair limits.

# 2-172. Inspection — Honeycomb Panels and Shell Assembly.

# CAUTION

When internal corrosion or contamination (fuel, oil, water, etc.) is discovered, affected skins or core must be completely cut out. Failure to comply with this requirement will result in failure of the repair and/or progressive core degeneration.

**a.** Inspect honeycomb panels for delamination, punctures, dents, cracks, voids, corrosion, or contamination and other damage.






Figure 2-28. Honeycomb Panels — Upper Cabin Roof Repair (Sheet 1 of 2)





NOTE: All dimension are in inches.

#### **GENERAL CONSTRUCTION**

OUTER SKIN 0.012 2024T3 SMOOTH INNER SKIN 0.008 2024T3 SMOOTH

CORE 0.500 THICK ALUMINUM HONEYCOMB

EDGING FIBERGLASS EDGING 1 PLY

#### **REPAIR LIMITS**

# STD EXCEPT:

- a) No major repairs in hatched area without AVSCOM engineering approval
- b) Note critical mounting surfaces.

Figure 2-28. Honeycomb Panels — Upper Cabin Roof Repair (Sheet 2)





Figure 2-29. Honeycomb Panel — Forward Lower Cabin Shell Repair (Sheet 1 of 5)



FOWARD HALF

**GENERAL CONSTRUCTION** 

INNER SKIN 0.012 X 2024T3 SHEFFIELD OR 5WL OUTER SKIN 0.012 X 204T3 SMOOTH CORE 1.000 THICK ALUMINUM HONEYCOMB

# DAMAGE LIMITS:

#### STD EXCEPT:

- a) No major repairs in hatched area without AVSCOM engineering approval
- b) Engineering approval required for repairs in typical detail A
- c) Note critical mounting surfaces above and on following pages

206032-120-2

Figure 2-29. Honeycomb Panel - Forward Lower Cabin Shell Repair (Sheet 2)




Figure 2-29. Honeycomb Panel - Forward Lower Cabin Shell Repair (Sheet 3)






Figure 2-29. Honeycomb Panel - Forward Lower Cabin Shell Repair (Sheet 4)





# FORCE GRADIENT MOUNTING (MAG BRAKE)-NOT SHOWN ON SKETCH

RIGHT - Four inserts to match magnetic brake mount one located at BL 13.14, FS 68.06

LEFT - Four inserts to match magnetic brake mount one located at BL 19.09, FS 61.63

206032-120-5

Figure 2-29. Honeycomb Panel — Forward Lower Cabin Shell Repair (Sheet 5)





Figure 2-30. Honeycomb Panel - Aft Lower Cabin Shell Repair (Sheet 1 of 4)



NOTE: All dimensions are in inches.

# AFT HALF GENERAL CONSTRUCTION:

OUTER SKIN 1 PLY FIBERGLASS INNER SKIN 2 PLY FIBERGLASS

CORE 1.000 THICK ALUMINUM HONEYCOMB

# **DAMAGE LINITS:**

# STD EXCEPT:

- a) No major repairs in hatched area without AVSCOM engineering approval
- b) Note critical mounting surfaces above and on following pages

206032-121-2

Figure 2-30. Honeycomb Panel - Aft Lower Cabin Shell Repair (Sheet 2)




Figure 2-30. Honeycomb Panel - Aft Lower Cabin Shell Repair (Sheet 3)




Figure 2-30. Honeycomb Panel — Aft Lower Cabin Shell Repair (Sheet 4)




Figure 2-31. Honeycomb Panels - Crew Seat and Bulkhead Repair (Sheet 1 of 3)





Figure 2-31. Honeycomb Panels — Crew Seat and Bulkhead Repair (Sheet 2)



# REPAIR LIMITS STD EXCEPT:

Minor repairs only such as stop drilling cracks are acceptable. Repairs which add doublers etc., therefore increasing stiffness are not allowed.

Figure 2-31. Honeycomb Panels - Crew Seat and Bulkhead Repair (Sheet 3)





Figure 2-32. Honeycomb Panels — Passenger Seat Structure Repair (Sheet 1 of 4)



NOTE: All dimensions are in inches.

# GENERAL CONSTRUCTION:

UPPER SKIN 0.020 7075T6 SMOOTH LOWER SKIN 0.016 7075T6 SMOOTH

CORE 0.500 THICK ALUMINUM HONEYCOMB

EDGING FIBERGLASS EDGING 2 PLY OUTBOARD EDGES

0.016 INNER SKIN FORWARD AND AFT


# REPAIR LIMITS:

STD EXCEPT:

No major repairs in hatched area without AVSCOM engineering approval

206032-123-2

Figure 2-32. Honeycomb Panels - Passenger Seat Structure Repair (Sheet 2)



NOTE: All dimensions are in inches.

GENERAL CONSTRUCTION

FORWARD SKIN 0.064/0.045/0.020 7075T6 (CHEM-MILL STEPS)

AFT SKIN 2 PLY FIBERGLASS


CORE 0.500 THICK ALUMINUM HONEYCOMB

EDGING SAME AS AFT FACE

REPAIR LIMITS: STD EXCEPT:

No major repairs in hatched area without AVSCOM engineering approval. 206032-123-3

Figure 2-32. Honeycomb Panels — Passenger Seat Structure Repair (Sheet 3)



#### GENERAL CONSTRUCTION:

OUTER SKIN R.H. 0.032/0.016 2024T3 DOUBLER (CHEM-MILL) OUTER SKIN L.H. 0.064/0.032 2024T3 DOUBLER (CHEM-MILL)

INNER SKIN 1 PLY FIBERGLASS

CORE 0.500 THICK ALUMINUM HONEYCOMB

EDGING INNER SKIN EXTENSION

#### REPAIR LIMITS:

Left Side - AVSCOM engineering approval only

Right Side - Standard repair

206032-123-4

Figure 2-32. Honeycomb Panels — Passenger Seat Structure Repair (Sheet 4)





Figure 2-33. Honeycomb Panels - Passenger Seatback Bulkhead Repair (Sheet 1 of 2).



SECTION A-A

NOTE: All dimensions are in inches.

GENERAL CONSTRUCTION:

FORWARD SKIN 0.012 2024T3 SMOOTH AFT SKIN 0.008 2024T3 SMOOTH

CORE 0.500 THICK ALUMINUM HONEYCOMB EDGING FIBERGLASS EDGING 1 PLY ALL EDGES

REPAIR LIMITS:

STD EXCEPT:

No major repairs in hatched area without AVSCOM engineering approval

206032-124-2

Figure 2-33. Honeycomb Panels — Passenger Seatback Bulkhead Repair (Sheet 2)





Figure 2-34. Honeycomb Panels — Seatback Electrical Shelf Repair (Sheet 1 of 2)



GENERAL CONSTRUCTION:

UPPER SKIN 0.008 2024T3 LOWER SKIN 0.008 2024T3

CORE 0.500 THICK ALUMINUM HONEYCOMB

EDGING 1 PLY FIBERGLASS EDGING

REPAIR LIMITS: STD

206032 -125-2

Figure 2-34. Honeycomb Panels — Seatback Electrical Shelf Repair (Sheet 2)





Figure 2-35. Honeycomb Panels — Aft Fuel Cell Bulkhead Repair (Sheet 1 of 2)



SECTION B-B

#### GENERAL CONSTRUCTION:

FWD SKIN 0.008 2024T3 SMOOTH AFT SKIN 0.008 2024T3 SMOOTH

CORE 0.375 THICK ALUMINUM HONEYCOMB 1 PLY FIBERGLASS EDGING

**EDGING** 

#### REPAIR LIMITS

- a) No major repairs in hatched area without AVSCOM engineering approval
- b) Note critical mounting surfaces

206032 -126-2

Figure 2-35. Honeycomb Panels - Aft Fuel Cell Bulkhead Repair (Sheet 2)





Figure 2-36. Honeycomb Panels – Lower Aft Fuselage Repair (Sheet 1 of 2)



#### GENERAL CONSTRUCTION

INNER SKIN 1 PLY FIBERGLASS OUTER SKIN 1 PLY FIBERGLASS

CORE 0.125 THICK ALUMINUM HONEYCOMB

#### REPAIR LIMITS:

STD EXCEPT:

Between FS 143 and FS 167 (Antenna area]

#### **ANTENNA**

If antenna is operative, repairs using nonmetallic materials may be made

If antenna is inoperative, remove and replace or consult electronics personnel .206032-127-2

Figure 2-36. Honeycomb Panels – Lower Aft Fuselage Repair (Sheet 2)





Figure 2-37. Honeycomb Panel - Electrical Compartment Floor Repair (Sheet 1 of 2)



SECTION B-B

TYP. FWD, AFT AND R.H. EDGES

#### GENERAL CONSTRUCTION

UPPER SKIN 0.012 7075T6 RIGIDIZED LOWER SKIN 0.008 7075T6 RIGIDIZED

CORE 0.500 THICK ALUMINUM HONEYCOMB

EDGING 1 PLY FIBERGLASS EDGING

#### REPAIR LIMITS:

STD

#### INSTALLATION:

Compartment floor panel may be reinstalled using blind rivets throughout, or the lower skin on each side of the airframe must be loosened sufficiently to gain access for bucking. However, blind rivets must be utilized in any event along STA. 167 due to inaccessibility for bucking rivets. (SEE TM 55-1500-204-25/1.)

206032-128-2

Figure 2-37. Honeycomb Panel - Electrical Compartment Floor Repair (Sheet 2)





Figure 2-38. Honeycomb Panels – Oil Cooler Support Repair (Sheet 1 of 2)



#### **GENERAL CONSTRUCTION:**

UPPER SKIN 0.032 2024T3 SMOOTH LOWER SKIN 0.020 2024T3 SMOOTH

CORE 1.250 THICK ALUMINUM HONEYCOMB


EDGING 2 PLY FIBERGLASS EDGING

REPAIR LIMITS

No major repairs without AVSCOM engineering approval

206032-129-2

Figure 2-38. Honeycomb Panels - Oil Cooler Support Repair (Sheet 2)



GENERAL CONSTRUCTION

#### 206-022-133 ONLY

SKIN 0.040/0.030/0.010 2024T3 SMOOTH (CHEM-MILL)

CORE 1.250 THICK ALUMINUM HONEYCOMB UPPER AND LOWER

L.E. 0.012 2024T3 SMOOTH
T.E. 0.016 2024T3 SMOOTH
CORE SEAL 1 PLY FIBERGLASS

#### REPAIR LIMITS:

#### FIN:

#### STD EXCEPT:

No major repairs in hatched area without AVSCOM engineering approval. Note critical mounting surfaces.

SHEET METAL REPAIRS FOR TRAILING EDGE AND LEADING EDGE.

#### ANTENNA: (Crosshatched area)

If antenna is operative repairs using nonmetallic materials may be made. If antenna is inoperative, remove and replace or consult electronics personnel.

206022-5-1

Figure 2-39. Honeycomb Panels — Vertical Fin Repair (Sheet 1 of 2)




Figure 2-39. Honeycomb Panels - Vertical Fin Repair (Sheet 2)

#### NOTE

Sounding method for identifying bond separation should not be used within a dented area. Limits established for dents shall apply.

- **b.** Presence of bonding separation or void in a honeycomb panel can be detected by use of a sounding device (half-dollar or other like substitute). Tapping the metal covered surface of the panel will produce a dead or flat sound where bond separation (void) exists. Outline the area using a grease pencil.
- c. The above tapping procedure in fiberglass honeycomb panels, sometimes results in a false indication of a void due perhaps to differences in thickness of the fiberglass layers, previous repairs, etc. When a void is suspected, further test the area by cutting the fiberglass skin in the middle of the suspect area using a hole saw not larger than the diameter of a half-dollar. When cutting the fiberglass skin, cut as little core material as possible; drill only deep enough to cut through the skin. If the area is void, the cut skin layer (wafer) will be loose. If the wafer remains bonded to the core material, no void is present. If no void is indicated, the test area must be repaired. Repair as follows: Clean the area by sanding with 100 grit sandpaper followed by 400 grit sandpaper. Add a minimum of two layers of fiberglass, each layer overlapping the test area or previous layer by approximately one inch. Bond the fiberglass using (C66 or C19). This test procedure may also be used on honeycomb panels with metal skins. If no void is found, the test area must be repaired by sanding as indicated above, then add a metal doubler as described in paragraph 2-187.

#### NOTE

Every effort should be made toward maintaining the highest standards of cleanliness possible and following the recommended general instruction repair procedures. In all repairs, the precautionary measures regarding inspection for water, fuel, and oil contamination and resultant corrosion must be taken.

2-173. Repair - Honeycomb Panels - General.



Before making any structural repair refer to Maintenance Allocation Chart, Appendix B, to determine the level of maintenance responsible for a specific repair.

#### NOTE

Damage to honeycomb panels may be repaired by the following recommended methods within the limits described. The methods are a guide to obtain a repair which allows the panel to perform to its original design capability.

### 2-174. PREPARATION OF BONDING SURFACES.

- **a.** Clean foreign material from parts to be bonded with clean cheesecloth (C37) moistened with MEK (C107).
- **b.** Thoroughly sand surfaces to be bonded or to which filler is to be applied with silicon carbide wet or dry sandpaper (C125 or C126) to remove all surface finish, primer, and foreign material.
- **c.** Mask off sanded surface area to protect surrounding area from cleaning solution.
- **d.** Wipe sanded area with clean cheesecloth (C37) moistened with MEK (C107). Change cheesecloth frequently until all evidence of residue has been removed.
- **e.** Immediately coat cleaned surface (metal only) with adhesive promoter A934BX or A934BY; allow a minimum of 30 minutes drying time.
  - f. Remove all tape from masked area.
- **g.** Protect surface from contamination until final bonding is accomplished, using clean wrapping paper.

#### **NOTE**

Prebend (composite) material does not require cleaning per above instruction. Remove "peel ply" only and bond.

# 2-175. PREPARATION OF HONEYCOMB CORE PLUG. (AVIM)

- **a.** Cut a core plug (use only clean material of the same type as original) to fit the damaged area allowing approximately **0.200** inch gap for adhesive at the edges.
- **b.** Flush the plug with MEK (C107) and dry immediately with dry filtered air.
- **c.** Apply a film of adhesive (C19) (0.020 to 0.030 inch) to a piece of Tedlar (area to be equal to surface area of plug).
- **d.** Place the core plug on the adhesive, apply firm contact to 5 psi pressure and allow adhesive to cure.

#### NOTE

This will seal the core cells and provide a better bonding surface. If both panel skins are affected, both sides of plug should be sealed.

**e.** Protect the core plug from contamination until ready for use.

# 2-176. CLEANING OF HONEYCOMB CORE CAVITY. (AVIM)

a. Remove all loose debris from cavity.

### CAUTION

Use filtered air with pressure not to exceed 30 psi.

- **b.** Flush cavity using MEK (C107), acetone (C2) or aliphatic naphtha (C22) and dry immediately with clean, filtered, dry, compressed air.
- **c.** Protect cleaned cavity from contamination until ready for subsequent operation.

### CAUTION

Any core or skin contaminated by fuel, oil, water, corrosion or debris must be cut out.

### 2-177. Removal of Paint and Primer from Honeycomb Panels. (AVIM)

Trichloroethylene and vapor degreasers are not to be used to clean or strip any surface adjacent to a damaged area. Use only MEK (C107) or acetone (C2) to remove paint from skins and edging or exposed adhesive bond lines.

#### NOTE

Excessive application of MEK (C107) or acetone (C2) can affect bonding agents. Strip these areas by wiping rather than soaking.

- **a.** Conventional finishes (varnishes, alkyd enamels, zinc chromate primer, etc.).
- (1) Mask off area to be stripped using tape (C143).
  - (2) Brush apply MEK (C107)
- (3) Remove lifted paint with a stiff fiber bristle brush (C31).
- (4) Final clean wipe with clean cheesecloth (C37) moistened with MEK (C107).
  - **b.** Acrylic finishes.
- (1) Mask off area to be stripped using tape (C143).
- (2) Remove paint using silicon carbide sandpaper (C125) or finer.
  - c. Epoxy finish.
- (1) Mask off area to be stripped using tape C143).
- (2) Remove paint using non-silicon sandpaper C125) or finer.
- (3) Wipe with clean cheesecloth (C37) until all evidence of residue has been removed.

2-178. Negligible Honeycomb Panel Damage – Limits and Repair.

#### **NOTE**

Damage classified as negligible does not require repair.

- 2-179. Limitations Negligible Honeycomb Panel Damage.
- **a.** Nonsharp dents up to **5** percent of panel thickness provided:
- (1) Total damage shall not exceed 5 percent of panel area.
- (2) Edge of any dent must be at least 1.000 inch from any structural member, fitting, control support and from the panel edge bevel. Dents closer than 1.000 inch shall be considered as one dent.
- **b.** Nonsharp dents up to **10** percent of panel thickness provided.
  - (1) Diameter does not exceed 0.500 inch.
- (2) No more than three dents can be encompassed by a 4.000 inch diameter circle.

#### NOTE

Dents closer than 1.000 inch (edge to edge) shall be considered as one dent.

(3) The edge of any dent must be at least 1.000 inch from any structural member, fitting control support or the panel edge bevel.

#### **NOTE**

Edge separation and detectable voids (bond failure or delamination) may never be classified as negligible damage. Refer to paragraphs 2-181 or 2-185 for limitations and repair procedures.

2-180. Repair — Negligible Honeycomb Panel Damage.

### CAUTION

Do not oversand fiberglass skin. Weakening of serviceable panel area will occur.

#### **NOTE**

This repair applies to either aluminum or fiberglass faced panels and is optional (for appearance only).

- **a.** Prepare bonding surface per instructions in paragraph 2-173.
- **b.** Apply adhesive (C19) and blend to undamaged surface. Allow cure time as required.
  - c. Refinish as necessary.

**2-181. Definition** — **Minor Panel Damage.** Punctures, sharp dents, creases, dents to only one skin and core exceeding **10** percent of the panel thickness but not exceeding **0.600** inch diameter after cleanup.

#### 2-182. Limitations — Minor Panel Damage.

- **a.** Maximum diameter of hole after cleanup shall not exceed **0.500** inch. Refer to figure 2-40.
- **b.** No more than two such areas shall be encompassed by a **4.000** inch diameter circle and any two damaged edges shall not be closer than **1.000** inch. Damage closer than **1.000** inch shall be considered as one area.
- c. Edge of cleanup shall be a minimum of **3.000** inches from any attachment point or insert attaching a structural member, fitting, or control support or as noted on the illustration for a specific panel.
- **d.** The edge of the cleanup shall be a minimum of **3.000** inches from any panel edge or cutout or as noted on the illustration for a specific panel.

#### NOTE

All damage exceeding the above must be treated as major damage.




Figure 2-40. Honeycomb Panels — Minor Damage Repair

2-183. Repair — Minor Panel Damage.

# CAUTION

Removal of damaged or voided areas in honeycomb panels must be accomplished with care, so as not to further damage the surrounding area. Exercise extreme care to prevent damage to inner skin. Use of pointed or sharp tools to extract the loosened, damaged core from the panel will be accomplished with caution.

- **a.** Protect the opening to prevent entry of cleaning agents and solvents.
- **b.** Remove paint and primer from an area extending **3.000** inches beyond the edge of damage.

## CAUTION

Any core or skin contaminated by fuel oil, water, corrosion or debris must be cut out.

- **c.** Cut away skin and core to remove all damaged and contaminated material.
- **d.** Flush cavity with MEK (C107) or acetone (2). Dry promptly with clean, dry, compressed air.

- e. Fill cavity with adhesive (C19).
- **f.** When adhesive has cured, sand to contour and refinish.
- 2-184. Major Panel Damage Limits and Repair. (AVIM). Refer to figure 2-41.
- **2-185. Definition Major Panel Damage**, All punctures, voids or dents that require a cleanup hole in excess of **0.500** inch diameter,

#### NOTE

Restrictions as outlined in figures 2-28 thru 2-39 for specific panels will take precedence over these limits.

- 2-186. Limitations Major Panel Damage.
- a. Maximum length of clean up of **5.000** inches in any direction,
- **b.** Maximum of two repairs per panel that shall be separated by **5.000** inches between edges of cleanup.
- c. Total damage not to exceed **12.000** square inches when only one skin and core is affected or **10.000** square inches when both skins are affected.
- **d.** Edge of cleanup shall be a minimum of **3.000** inches from any attachment point or insert attaching a fitting or control support or as noted on the illustration for a specific panel.
- e. The edge of the clean up shall be a minimum of 3.000 inches from any panel edge or cutout or as noted on the illustration for a specific panel,

#### NOTE

When damage exceeds the above limits, repairs may be accomplished only with the approval of and per instructions of qualified AVSCOM engineering authority.

#### 2-187. Repair — Major Panel Damage.

- **a.** Protect the opening to prevent entry of cleaning agents and solvents.
- **b.** Remove paint and primer from an area extending **3.000** inches beyond the edge of damage.




Figure 2-41. Honeycomb Panels — Major Damage Repair (Sheet 1 of 2)




Figure 2-41. Honeycomb Panels - Major Damage Repair (Sheet 2)

 ${f c.}$  Cut away skins and core to remove all damaged and contaminated material. Use a minimum of  ${f 0.500}$  inch radius at corners,

### CAUTION

Any core or skin contaminated by fuel, oil, water, corrosion. or debris must be cut out.

#### NOTE

Where damage is limited to one skin, the opposite skin may be left intact provided cleanup operations do not cut into the skin.

- d. Flush the cavity with MEK (C107) or acetone(C2). Dry promptly with clean, dry, compressed air,
  - e. Fill the cavity as follows:
- (1) Damage of 1.000 inch or less in diameter may be filled with adhesive (C19) and smoothed to contour of skins.

- (2) Damage exceeding 1.000 inch in diameter to be filled with a core plug of like honeycomb material, Seal top and bottom surfaces of plug with adhesive (C19) and allow to cure. Refer to paragraph 2-175 for preparation of honeycomb core plug,
  - f. Patch skin as follows:
    - (1) Fiberglass skins.

#### NOTE

Fiberglass skin repairs should be accomplished after core plug has cured.

(a) Prepare a patch of fabric layers (equal to number of plies lost) to provide a minimum of a 1,000 inch overlap outside the damaged skin trim and to provide a minimum of 1.000 inch overlap over each proceeding layer.

- **(b)** Saturate the first patch with epoxy resin (C66). Apply resin to the exposed filler and to the exposed clean area of the panel around the damage.
- **(c)** Fit the impregnated patch into place. Smooth out air pockets and wrinkles.

#### **NOTE**

### Ensure that adequate resin is forced through the patch ply in the core area.

(d) Saturate each succeeding ply with resin and brush coat the entire area with resin and apply the patch. Work each ply to remove the wrinkles and entrapped air prior to application of the next ply. Minimum number of plies to be the same as existing skin.

### CAUTION

Use of a vacuum bag will remove resin from patch area unless adequate seal is accomplished.

- **(e)** Cover repair with cellophane and apply firm contact pressure to the patch with shot bags, clamps, vacuum bag or other suitable means.
  - (2) Metal skins.

#### **NOTE**

Repair any hole or dent caused by seat belt anchor bolt. Refer to figure 2-14.

(a) Cut a skin patch (prebend, i.e., composite bond material), sufficiently large to provide a 1.500 inch overlap outside of the damaged skin trim; remove the peel ply protecting the adhesive and apply adhesive (C19) evenly to the patch 0.020 to 0.030 inch thick. Minimum patch thickness to be that of existing skin.

#### NOTE

Where the panel is curved, the skin patch must be shaped to match,

- (b) Install skin patch over the repair area.
- (c) Add NAS1738B4-1 rivets or equivalent around patch in the overlapped area at a maximum

spacing of **1.500** inches and with 2D edge distance. Rivets are to be installed within the pot life of the adhesive.

**(d)** Apply pressure to the patch in the cavity area to ensure a good bond.

# 2-188. HONEYCOMB PANEL MINOR EDGE DAMAGE - LIMITS AND REPAIR. (AVIM)

2-189. Limitations — Honeycomb Panel Minor Edge Damage (figure 2-42).

#### **NOTE**

The following minor edge damage criteria applies only to those panels with a fiberglass skin on the edge bevel.

- **a.** Damage is restricted to fiberglass edge and core (metal skins and doublers are not damaged).
- **b.** Damage to the core does not extend more than **0.500** inch inside the inboard edge of the bevel (top) after cleanup.
- c. Maximum length of damage shall not exceed 2.000 inches after cleanup.
- **d.** Maximum number of repairs not to exceed three per panel with a minimum of **2.000** inches between edges of cleanup.

## 2-190. Repair — Honeycomb Panel Minor Edge Damage (figure 2-42).


- **a.** Protect the opening to prevent entry of cleaning agents and solvents.
- **b.** Remove paint and primer for an area extending three inches beyond the edge of damage.

### CAUTION

Any core or skin contaminated by fuel, oil, water, corrosion or debris must be cut out.

**c.** Cut away edge skin and core to remove all damaged and contaminated material.


#### FIBERGLASS SKINNED PANELS



NOTE

Two-part adhesive (C19) should be used for making fiberglass wet layup repairs when a bond to metal is required. Exercise care to ensure that cloth is thoroughly impregnated.

#### METAL SKINNED PANELS WITH METAL EDGE BEVEL




EDGE REPAIR B

206032-132.1

Figure 2-42. Honeycomb Panels - Edge Damage Repairs (Sheet 1 of 2)

### METAL SKINNED PANELS WITH FIBERGLASS EDGE BEVEL



Two-part adheisve (C19) should be used for making fiberglass wet layup repairs when a bond to metal is required. Exercise care to ensure that cloth is thoroughly impregnated.

EDGE REPAIR C

#### TYPICAL RIVET PATTERN COMPOSITE BOND PATCH (RIVET WITHIN POT LIFE OF ADHESIVE)




Figure 2-42. Honeycomb Panels — Edge Damage Repairs (Sheet 2)

- **d.** Fill damaged area with adhesive (C19). Blend to undamaged surface and allow to cure.
- e. Prepare patch layers of fabric to equal number of plies lost, provide a minimum of a 1.000 inch overlap outside the damaged skin trim, and to provide a minimum of 1.000 inch overlap over each preceding layer.
- **f.** Saturate the first patch with epoxy resin (C66). Apply resin to the exposed core or filler and to the exposed clean area of the panel around the damage,
- **g.** Fit the impregnated patch into place. Smooth out air pockets and wrinkles.

#### NOTE

### Ensure that adequate resin is forced through the patch ply in the core area.

h. Saturate each succeeding ply with resin and brush coat the entire repair area with resin and apply the patch. Work each ply to remove the wrinkles and entrapped air prior to application of the next ply. Minimum number of plies to be the same as existing skin.

### CAUTION

# Use of a vacuum bag will remove resin from patch area unless adequate sealing is accomplished.

i. Cover repair with tedlar (C145) and apply firm contact pressure to the patch with shot bags, clamps, vacuum bag, or other suitable means.

# 2-191. HONEYCOMB PANEL MAJOR EDGE DAMAGE - LIMITSAND REPAIR. (AVIM)

### 2-192. Limitations — Honeycomb Panel Major Edge Damage (figure 2-42).

- a. The following extensive edge damage criteria applies when panel edge bevel skin is metal or when any metal skin or doubler has been damaged.
- b. Damage does not extend more than 0.500 inch inside the inboard edge of the bevel (top) after cleanup.

- c. Maximum length of damage shall not exceed **1.250** inches provided no more than two edge fasteners are affected after cleanup.
- d. Maximum number of repairs net to exceed 2 per panel with a minimum of 2.000 inches between edges of cleanup.

#### NOTE

When damage exceeds the above limits, repairs may be accomplished only with approval and per instruction of qualified AVSCOM engineering authority,

### 2-193. Repair — Honeycomb Panel Major Edge Damage (figure 2-42).

- **a.** Protect the opening to prevent entry of cleaning agents and solvents.
- **b.** Remove paint and primer from an area extending **3.000** inches beyond the edge of damage.

### CAUTION

Any core or skin contaminated by fuel, oil, water, corrosion or debris must be cut out.

- **c.** Cut away edge skin and core to remove all damaged and contaminated material. Use a minimum of **0.500** inch radius at all corners of cleanup.
- **d.** If damage is confined to one skin, the opposite skin may be left intact provided cleanup can be accomplished without damage to the opposite skin.
- **e.** Clean cavity with MEK (C107) or acetone (C2), Dry immediately with clean, dry, compressed air,
- f. Repair fiberglass skin as follows:
- (1) Prepare patch layers of fabric, equal to number of plies removed, to provide a minimum of a 1.000 inch overlap outside the damaged skin trim and to provide a minimum of 1.000 inch overlap over each preceding layer,
- (2) Saturate the first patch with epoxy (C66). Apply epoxy to the exposed core or filler and to the exposed clean area of the panel around the damage.

(3) Fit the impregnated patch into place. Smooth out air pockets and wrinkles.

#### NOTE

When fiberglass must be bonded to metal, use adhesive (C19). Exercise care to ensure that fiberglass is thoroughly impregnated.

(4) Saturate each succeeding ply with resin and brush coat the entire repair area with resin and apply the patch. Work each ply to remove the wrinkles and entrapped air prior to application of the next ply. Minimum number of plies to be the same as existing skin.

#### NOTE

Use of a vacuum bag will remove resin from patch area unless adequate sealing is accomplished.

- **(5)** Cover repair with tedlar (C145) and apply firm contact pressure to the patch with shot bags, clamps, vacuum bag, or other suitable means.
  - g. Metal skin repair is as follows:

#### **NOTE**

Metal skin patch must be prebend (composite bond) material. Type and thickness is to be the same as original. Where damage is sustained by the external edge doubler, the skin patch thickness must equal the skin and the doubler.

(1) Prepare a patch to extend 1.500 inches beyond edge of cleanup and to the edge of the panel.

#### NOTE

Where edge bevel skin is metal, the patch must be formed to conform to the edge bevel.

(2) Remove peel ply (composite bond protective cover) and apply adhesive (C19) to the patch (0.020 to 0.030 inch thick).


- (3) Install the patch and rivet in place. Use row of rivets through patch and skin only. Rivet spacing to be the same as panel attachment rivets with a minimum of 2D edge distance. Rivets must be installed within the pot life of the adhesive.
- **(4)** Apply pressure to the patch in the cavity area to ensure a good bond.

#### 2-194. INSERT REPLACEMENT. (AVIM)

Damaged inserts may be replaced per figure 2-43.

#### 2-195. Install Rubber Pad Below Fuei Receiver.

- **a.** The following procedure will prevent damage caused by the fuel cap. This preventive process should not be performed on damaged areas. Damage areas shall be repaired in accordance with applicable repair procedure in this chapter and TM 1-1500-204-23, prior to installing the protective rubber pad.
- **b.** Use the center of the fuel receiver as a half way mark, measure 5.250 inches on both sides of the center point and form a 10.500 inch square. Mark outside border using masking tape (C143).
- **c.** Sand area inside tape with sandpaper (C124) to scuff the surface. Wipe area with MEK (C107) and a lint free cloth (C37).
- **d.** Cut a 10-inch square pad (45, table 2-1) of rubber and cut one edge to the contour of fuel receiver retainer. Bevel all edges approximately 1/8 inch. Reference Appendix D, figure D-175.
- **e.** Apply adhesive (C8) to the pad and affix to helicopter with contoured cut around fuel receiver retainer. Follow instructions provided on adhesive container for curing time.
- **f.** After the pad is in place tape around the pad with masking tape (C143) leaving a 1/4 inch border. Apply sealing compound (C131) under all edges and along the outside edge of the rubber pad.
  - **g.** Remove tape and allow 6 to 8 hours to cure.
- **h.** Restencil any partially covered markings IAW TM 55-1500-345-23.







Figure 2-43. Honeycomb Panels — Installation of Inserts (Sheet 1 of 4)






Figure 2-43. Honeycomb Panels - Installation of Inserts (Sheet 2)








Figure 2-43. Honeycomb Panels - Installation of Inserts (Sheet 3)









206032-133-4

Figure 2-43. Honeycomb Panels — Installation of Inserts (Sheet 4)

2-196. FUEL CELL SUPPORT. (AVIM) (FIGURE 2-44).

2-197. Cleaning - Fuel Cell Support.

WARNING

Aliphatic Naphtha Is flammable and toxic. It can Irritate and cause bums. Use only In well ventilated area, away from heat or flame. Wear gloves and goggles. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

Clean fuel cell supports with dean wiping rag dampened with aliphatic naphtha (C22).

**2-197.1 Inspection- Fuel Cell Support**. Inspect for dents, holes, rips, and voids between the supports and mark with soft lead pencil.

2-197.2 Repair-FuelCeliSupport.

a. Repair dents and holes less than 0.500 inch in diameter in fuel cell support as follows:



Epoxy adhesive can cause severe bums to skin and eyes and may cause an allergic reaction to skin and respiratory reactions Avoid inhalation. Thoroughly wash skin area with waterless hand cleaner followed by soap and water and Immediately flush eyes with water for 15 minutes In all cases get immediate medical attention. When working with epoxy adhesive, wear approved rubber gloves, chemical goggles, respirator with organic vapor cartridge, and protective clothing. Use in a well ventilated area.

(1) Fill dents with adhesive (C12) and smooth surface to contour of surrounding area. Allow to cure 4 hours at 700 to 80°F (21.1 to 26.70C).




Figure 2-44. Fuel Cell Support.

- (2) Seal holes less than 0.500 inch diameter with adhesive (C12) and smooth surface to contour of surrounding area.
- b. Repair dents and holes larger than 0.500 inch in diameter in fuel cell support while installed in helicopter as follows:

#### NOTE

A plug of common Styrofoam may be used as a suitable substitute, not to exceed 4.000 Inches in diameter.

(1) Cut out damaged area and smooth edges of surrounding area.

# WARNING

Abrading, machining, buffing, or grinding of epoxy resin may release fibers that are a health hazard If Inhaled Into the lungs. Work Involving these operations shall be done by keeping resin wet or by using air-exhausted workbench.

- (2) Cut plug of nopcofoam (C107.1) and apply epoxy resin (C66) to bottom side and allow to cure before inserting.
- (3) Apply epoxy resin (C66) to edges and insert plug and apply epoxy resin (C66) over top and surrounding area. Smooth to contour of surrounding area. Allow epoxy to cure 24 hours at 700 to 800F (21.1 0 to 26.7°C).

#### **NOTE**

Coated foam fuel cell support may be cut at any place necessary to allow access to lower body shell. To replace removed section, follow applicable preceding steps according to size of pieces removed.

c. Repair fuel cell support defect as follows:



Adhesive is flammable and toxic. It can Irritate and cause bums. Use only in well ventilated area, away from heat or open flame. Wear gloves and goggles. In case of contact, Immediately flush skin or eyes with water for at least 15 minutes. Get immediate medical attention for eyes.

#### NOTE

Spray application of adhesive may be thinned with anphtha (C24.1).

(1) Apply three coats of adhesive (C15) to exposed foam or damaged area only. Allow adhesive to dry for 10 minutes between each coat and after final third coat.



Aromatic naphtha is flammable and toxic. It can irritate and cause burns. Use only in well-ventilated areas, away from heat or open flame. Wear gloves and goggles. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

(2) Remove excess adhesive with dean wiping rag dampened with aromatic naphtha (C24. 1).

#### **CAUTION**

Prevent damage to airframe, use care when removing supports. Solvent shall not be use to remove supports. Fuel cell supports are bonded to airframe with sealing compound on underside four corners, periphery of sump cutout, and around openings of conduits. Any repair plugs previously installed in support(s) will be bonded to airframe.

d. Remove damaged fuel cell support from airframe with putty knife.

# WARNING

Methyl-ethyl-ketone (MEK) Is flammable and toxic. It can Irritate and cause bums. Use only In well-ventilated areas, away from heat or open flame. Wear rubber gloves and goggles. In case of contact, immediately flush skin or eyes with water for a least 15 minutes. Get Immediate medical attention for eyes.

e. Remove old sealing compound from airframe with wiping rag dampened with methyl-ethyl-ketone (MEK) (C107).



Sealing compound Is flammable. Do not use near heat, open flames, or sparks. Overexposure can cause Irritation of skin and eyes, headache, nausea, vomiting, and systemic problems. Thoroughly wash skin area with soap and water and Immediately flush eves with water for 15 minutes. In all cases get Immediate medical attention. Wear approved protective gloves and goggles & Avoid breathing of vapors and prolong or repeated skin contact.

- f. Apply sealing compound (C130) to underside of fuel cell support (1, 2, 3, or 4) at four corners, on periphery of sump cutout and around openings of conduits.
- g. Install support(s) to airframe. Remove excess sealing compound.

#### 2-198. FIREWALL.

**2-199. Description - Firewall. Firewall** constructed of titanium sheet (52, table 2-1) are provided at the forward and aft ends of the engine.

#### 2-200. Repair - Firewall.

a. Repair firewall as follows:

- (1) Smooth contour dents, nicks, and scratches that do not penetrate the firewall may be classified as negligible damage. Inspect with fluorescent penetrant type of inspection (MIL-I-6868).
- (2) Install repairs with monel rivets or standard dose tolerance steel fasteners. Install gasket material (C25) between repairs to provide fire tight seal.
  - b. Replace asbestos chafing strips as follows:
  - (1) Remove strip and dean to bare metal.
- (2) Clean metal with toluene (C150) and wipe dry with clean cloth.
- (3) Clean strip with toluene and apply adhesive (C6) to strip and firewall. Allow adhesive to cure at 700 to 800F (21.1 to 26.7°C) for 24 hours or heat with a heat lamp for 1 hour at 120°F (48.70C).
- (4). Press strip to firewall and apply pressure until cured.
- c. Repair silicone rubber seals on forward and aft firewall. If seals are damaged or loose, rebound or replace as follows:
  - (1) Remove adhesive residue.
- (2) Using 80 grit sandpaper (C123), roughen bonding surface of seal and firewall.
- (3) Clean bonding surface of seal and firewall with cloth dampened with toluene (Cl 50).
  - (4) Wipe dry with clean dry cloth.
- (5) Brush a thin coat of adhesive (C33) on both surfaces.
- (6) Press coated surfaces together. Maintain contact 24 hours to obtain handling strength. Maximum strength is obtained in 3 to 5 days.

#### 2-201. ENGINE PAN.

**2-202. Description - Engine Pan**. The engine pan and stiffeners are constructed of titanium sheet. It is a load bearing firewall and is located below the engine between stations 130 and 167.

#### 2-203. Damage Classification - Engine Pan.

- a. Negligible damage.
- (1) Nicks, corrosion, and scratch damage are limited to a cumulative total of 10% of the pan thickness.
- (2) Smooth dents that are not gouged and less than 0.025 inch in depth.
- b. Reparable damage. Damage exceeding negligible damage limits shall be repaired using standard repair procedures for titanium, using monel rivets or dose tolerance steel fasteners. Install gasket material (C25) between repairs to provide fire-tight seal.

#### 2-204. AFT FUSELAGE ASSEMBLY.

**2-205. Description** – **Aft Fuselage Assembly.** The aft fuselage assembly provides the deck for the engine mount provision, attachment fittings for the tailboom, a compartment under the engine deck for electrical equipment, and hard points for ATAS missile system mounting **CS**.

#### 2-206. Inspection - Aft Fuselage Assembly.

- a. Remove inspection plate on right side of fuselage at tailboom attaching point.
- **b.** Inspect aft fuselage attachment fittings for loose rivets, nicks, scratches, cracks, corrosion or pitting. Nicks and scratches in excess of **0.002** inch depth require repair. All cracks and corrosion damage require repair.
- c. Inspect aft fuselage fairing visually for cracking. All cracks must be repaired.
- d. Inspect section assembly skin for cuts, tears, cracking, wrinkling, and loose or missing rivets.

#### NOTE

Some wrinkling on either side of helicopter below WL 61.76 is permitted unless wrinkles cross a rivet pattern. Wrinkling above WL 61.76 which cross rivet patterns, or which are characterized by permanent creasing and abrupt changes in profile require higher level maintenance.

**e.** Inspect stiffeners for security of attachment and straightness by looking through avionics compartment door.

#### 2-207. Repair - Aft Fuselage Assembly. (AVIM)

- **a.** Refer to figure 2-36 and TM 55-1500-204-25/1 for repair of aft fuselage fairing.
- **b.** Refer to TM 55-1500-204-25/1 for repair of aft section assembly skin and repair of stiffeners.
- **c.** For repair of aft fuselage tailboom attachment fittings proceed as follows:
- (1) Remove access door from right side of fuselage just forward of tailboom attachment point to gain access to fittings.

- (2) If corrosion or mechanical damage resulting from screwdrivers, wrenches, over-length door screws, etc., is evident, remove paint from fittings using MEK (C107).
- (3) Remove corrosion and inspect fittings for pitting. Pitting in excess of 0.002 inch must be dressed out.
  - (4) Clean up nicks and scratches.
- (5) Repair limits for corrosion or mechanical damage are as follows (if limits are exceeded, retrograde helicopter in the usual manner):
- (a) Minimum wall (web) thickness after cleanup is 0.100 inch.

#### WARNING

There must be no abrupt changes in profile or sharp edges after cleanup.

(b) A maximum of 0.050 inch may be removed from upper edges of lower fittings (check DA Form 2408-15, Historical Record for Aircraft) including large area closest to bulkhead. No feathered edges are permitted; if previous repair did not exceed the 0.050 inch repair criteria, fitting can be repaired to 0.050 inch. If 0.050 inch is exceeded, replace fitting.

#### NOTE


Ensure adequate edge distance between forward rivets and edge of fitting after cleanup.

**(c)** If it is necessary to clean up thick portion of fitting near corner joint, minimum wall thickness of fitting at midpoint of corner radius is **0.120** inch after cleanup (figure 2-45).

#### NOTE

Inside corner radius where walls intersect aft section of fitting should be approximately 0.090 inch (figure 2-45).

(d) Small nicks, scratches, etc., in upper left hand longeron and fitting not to exceed 0.005 inch deep may be blended out and repainted. Damage to upper right hand longeron and fitting may be blended



AREA A-Minimum Wall Thickness 0.120

AREA B-Minimum Wall Thickness 0.090

206032435

Figure 2-45. Tailboom Attachment Fitting Repair

out and repainted provided depth does not exceed **0.010** inch. Damage to upper right hand angle (stringer) directly behind tailboom inspection panel plate nuts may be blended out and repainted provided damage does not exceed **0.015** inch deep. Rivets in upper longeron having head damage in excess of **0.035** inch depth must be replaced.

- (6) Record repair of mechanical or corrosion damage on DA Form 2408-15, Historical Record for Aircraft. Include an estimate of edge thickness removed.
- (7) Fittings must be repainted after removal of corrosion products and cleanup.

# 2-208. BALLAST INSTALLATION. (Figure 2-1.)

**2-209. Description** — **Ballast Installation.** Two ballast installations are provided for weight and balance applications. The forward location is fuselage station 30.60, which is forward of the instrument panel. The aft location is the aft end of the tailboom, boom station 182.41.

**2-210. Inspection** — **Ballast Installation.** Inspect ballast installation for security.

#### 2-211. Removal - Forward Ballast A

- a. Remove APX-72 transponder from mount,
- **b.** Remove four screws securing APX-72 mount and ballast to shelf.
- c. Remove ballast as required to facilitate maintenance.

#### 2-212. Removal — Forward BallastC

- a. Remove four screws securing ballast to shelf.
- **b.** Remove ballast as required to facilitate maintenance.

#### 2-213. Installation — Forward Ballast A

- **a.** Reinstall APX-72 mount and ballast with four screws. A maximum of **15** pounds may be used.
  - b. Install APX-72 transponder in mount.

**2-214.** Installation - Forward Ballast. C Reinstall ballast with four screws.

#### 2-215. Removal - Aft Ballast.

- a. Remove four bolts, twelve washers, and four nuts securing ballast to tailboom.
- b. Remove ballast as required to facilitate maintenance.
- **2-216. Installation Aft Ballast**. Reinstall aft ballast on tailboom with four bolts, twelve washers, and four nuts. A maximum of 10 pounds of ballast may be used.
- **2-217. FITTING ASSEMBLY ARMAMENT** (Hard Points).
- **2-218. Description Fitting Assembly** Armament (Hard Points). Armament hard points are those structural load bearing points used for attachment of armament system. Refer to figure 16-1 A and figure 16-16 CS
- **2-219.** Inspection Fitting Assembly Armament (Hard Points). E Visually inspect all hard points for evidence of physical damage, wear, cracks, and corrosion.
- **2-220.** Removal Fitting Assembly Armament (Hard Points).
- a. Remove fitting (detail A, figure 16-1) from seat hardpan by removing six screws and six washers.
- b. Remove fitting (detail B) from seat hardpan by removing four bolts and four washers.
- c. Remove fitting (detail D) from center post by removing three screws and three washers.

#### NOTE

# Do not remove or disturb shims on center-post. They are a permanent production Installation.

- d. Remove fitting (detail C) from seat back panel by removing three screws and three washers.
- e. Remove stop assembly (detail E) from seat hardpan by removing three screws and three washers.
- **2-221.** Repair or Replacement Fitting Assembly Armament (Hard Points). Repair is limited to replacement of any part that fails inspection. Refer to TM 43-0105 for corrosion removal.
- 2-222. Installation Fitting Assembly Armament (Hard Points).

Remove passenger seat cushion only. Helicopter may be equipped with either full length or two piece seat and seat back cushions. I two piece seat and seat back cushions are Installed only the left side cushions need to be removed to install gun. Refer to paragraph 292.

NOTE

- a. Install fitting (detail A, figure 16-1) to inserts near center of seat hardpan with six screws and six washers.
- b. Install fitting (detail B) to inserts on left side of seat hardpan with four bolts and four washers.
- c. Install fitting (detail D) to inserts on left side of center post with three screws and three washers.

#### NOTE

Soundproofing blanket has tear away flaps to facilitate Installation of fittings (details C and D) without removal of blanket.

d. Install fitting (detail C) on seat back shelf with three screws and three washers.

#### **CAUTION**

Failure to Install the following stop can result In damage to the helicopter when gun Is depressed.

- e. Install stop assembly (detail E) to insert on seat hardpan with three screws and three washers.
- 2-223. DRAIN INSTALLATION.
- **2-224. Description Drain Installation**. The aft fuse-lage drain installation consists of metal tube

assemblies attached to drip pan assembly and routed to exterior of helicopter. A flexible rubber hose attachd at end of metal tube serves as a grommet through fuselage skin opening.

#### 2-225. TUBE ASSEMBLY (Metal).

- **2-226. Description Tube Assembly (Metal)** Refer to paragraph 2-224.
- **2-227.** Inspection Tube Assembly (Metal). Inspect tubing for dents, kinks, end deep scratches.
- **2-228.** Removal Tube Assembly (Metal). Disconnect tube assembly from drip pen, remove attaching clamp, and remove tube from helicopter.
- **2-229.** Repair Tube Assembly (Metal). Replace tubing having dents, kinks, or twisted areas.
- 2-230. Installation Tube Assembly (Metal).
- **a.** Position tube assembly to drip pan assembly and tighten fittings. Ensure that end fittings are held to prevent kinking or twisting of tube asssembly when installing.
  - b. Install attaching clamp.

#### 2-231. TUBE ASSEMBLY (Flexible).

- **2-232.** Description Tube Assembly (Flexible). Refer to paragraph 2-224.
- **2-233.** Inspection Tube Assembly (Flexible). Inspect rubber tube for cuts and general deterioration.
- **2-234.** Removal Tube Assembly (Flexible). Pull off rubber tube from open end of metal drain tuba protruding through fuselage skin opening.
- 2-235. Repair Tube Assembly (Flexible). Replace tube not meeting inspection.
- **2-236.** Installation Tube Assembly (Flexible). install rubber tube on metal tuba end and position properly through fuselage skin opening.

# 2-237. AVIONICS COMPARTMENT FLOOR.

**2-238. Description - Avionics Compartment Floor.** The floor panel is installed in the aft fuselage between stations 130.0 and 167.0. Panel construction is aluminum alloy honeycomb core with aluminum facings and one ply fiberglass edging. The floor panel has provisions for battery tiedowns and installation of electrical and flight instrument components. Refer to figure FO-1 for station location.

**2-239.** Inspection - Avionics Compartment Floor. Inspect honeycomb panel for dents, cracks, voids, punctures, delamination, and/or other damage.

## CAUTION

When removing rivets from panel, care must be taken to preclude driving rivet stems into lower aft fuselage panel (figure 2-36).

#### **NOTE**

The weight of the transmission and engine should be removed from the airframe, or the fuselage should be supported prior to removal/replacement of avionics compartment floor.

- **2-240.** Removal Avionics Compartment Floor. If repair is impractical and the panel must be removed, remove the door, electronics equipment and battery, and then drill out rivets attaching panel to bulkheads and longerons, etc.
- **2-241.** Repair Avionics Compartment Floor. If the contaminated area can be isolated and removed, the panel may be repaired by insertion methods described in paragraph 2-174.
- **2-242. Installation Avionics Compartment Floor.** Avionics compartment floor panel may be installed using blind rivets throughout, or the lower skin on each side of the airframe must be loosened sufficiently to gain access for bucking. However, blind rivets must be utilized in any event along station 167 due to inaccessibility for bucking rivets. (Refer to TM 55-1500-204-25/1.) After panel has been installed, install battery, electronics gear, and attaching components, then reinstall the door.

#### SECTION II. TAILBOOM

#### 2-243. TAILBOOM

**2-244. Description - Tailboom.** The tailboom is a basic monocoque structure which means it has no longitudinal skin stiffeners or longerons. The tailboom skin is considered primary structure with the exception of the first 10 inches from its attaching point where the loads are redistributed by means of four intercostal load carrying members. The tailboom is attached to the fuselage by four bolts. The tailboom supports the tail rotor driveshaft, tail rotor gearbox, tail rotor assembly, vertical, and horizontal stabilizers. Helicopters with MWO 55-1520-228-30-24 accomplished have an aluminum alloy, one-piece, non-hinged, tail rotor driveshaft cover. Helicopters with MWO 55-1520-228-50-25 accomplished have an aluminum alloy, two-piece, hinged, tail rotor driveshaft cover.

#### 2-245 Inspection - Tailboom.

#### **NOTE**

Manufacturing irregularities and skin distortions which are aft of the horizontal stabilizer, excluding dents and creases. will be considered insignificant provided the irregularities do no exceed 0.090 inch depth when measured with a straight edge and standoff, and providing the change in profile is gradual.

Manufacturing irregularities and skin distortions which are forward of the horizontal stabilizer, excluding dents and creases, will be considered insignificant provided the irregularities do not exceed 0.060 inch depth when measured with a straightedge and standoff, and also providing the change in profile is gradual.

- **a.** Inspect the entire tailboom for localized buckling and bending.
- (1) Inspect driveshaft cover (if installed). Refer to paragraph 2-255.
  - (2) Open or remove driveshaft cover (if installed).
- **b.** Inspect for scratches and creases. Any scratch or crease which obviously exceeds the thickness of the

paint will be inspected using a 5 power magnifying glass and/or dye-penetrant.

#### NOTE

Scratches not in excess of 0.005 inch depth and at angles greater than 45 degrees from the longitudinal axis of the tailboom may be blended out provided they do not exceed one-sixth the circumference of the tailboom, and provided they are not also accompanied by creasing. Scratches not in excess of 0.010 inch depth and at angles less than 45 degrees from the longitudinal axis may also be blended out. No limit on length or number of longitudinal scratches provided damage is not clustered.

- **c.** Visually inspect the entire tailboom for large dents or creases. Any dent or crease which obviously causes misalignment of the tailboom or driveshaft is nonreparable except at depot level of maintenance. A tailboom with these deficiencies will be replaced.
- **d.** Inspect the entire tailboom for reparable dents. Not more than two smooth dents per bulkhead section, neither dent exceeding 1.000 inch in diameter, separated by at least 90 degrees but not more than 120 degrees about the circumference of the tailboom will be permitted. Other damage must be repaired. (Only minor dimpling and peening is permitted forward of horizontal stabilizer to tailboom station 42.59.)

#### NOTE

In general there are no limitations to the number of minor dimples or peenings provided this damage is not clustered. Dimpling or peening is any dent 0.125 to 0.250 inch in diameter, which does not tear or significantly scratch the skin.

- **e.** Inspect the entire tailboom assembly for loose or missing rivets. Loose or missing rivets must be replaced.
- **f.** Inspect the entire tailboom for cracks, especially the area around the tailrotor driveshaft

hanger bearing brackets and the tail rotor gearbox mounting pad. Cracks must be repaired.

#### WARNING

Punctures and bullet holes must be repaired prior to the next flight.

- **g.** Inspect the tailboom for punctures, bullet holes, etc.
- **h.** Inspect the area around the 90 degree gearbox for corrosion. Corrosion must be removed and area repainted. Refer to TM 43-0105 for repairs.
- i. Inspect tailboom repairs for buckling between rivets. Inspect patches for creasing and cracks. Inspect for missing or loose rivets.
- **j.** Inspect the tailboom for skin crinkling, i.e., localized buckling of the skin with sharp changes in profile. This usually involves skin rippling or wrinkle overlap.

#### **NOTE**

If major buckling or crinkling occurs at any tailboom station as the result of a hard landing or pylon induced vibrations, and is not a result of an external strike, the tailboom, less serviceable items, will be suspected of overstress and replaced.

- **k.** Inspect the tail rotor hanger bearing support brackets for cracks and bends. A bent bracket maybe straightened by finger pressure. There are no repairs permitted. Elongation of holes in excess of **0.270** inch diameter requires replacement.
- **I.** If installed, inspect access cover (6, figure 2-48 or 7, figure 2-49) and adjacent skin for creasing, cracks, or dents. If damaged, remove cover and inspect bulkheads and web for damage.

#### 2-246. Torque Requirement — Tailboom.

- **a.** Remove inspection plate on right side of fuselage at tailboom attaching point.
- **b.** Torque four tailboom attaching bolts **375 TO 415 INCH-POUNDS** after maintenance test flight and after **100** hours of flight following tailboom installation. Repaint (C132) slippage marks.

- c. Install inspection plate with screws. Maximum screw length, excluding head, must not exceed **0.376** inches.
- 2-247. Damage Limits Tailboom.

# CAUTION

The tailboom must be replaced if damage is extensive enough that tailboom misalignment is suspected.

- a. Damage which does not exceed 10% of tailboom circumference in height and 30% of tailboom circumference in length maybe repaired by patching. (Circumference to be measured at aft end of damage.)
- **b.** A maximum of **two** damaged areas per stress section of the tailboom is permitted. Example: A line drawn around the circumference of the tailboom must not touch more than **two** damaged areas.
- **c.** Damaged areas must be a minimum of **8.000** inches apart.
- **d.** Total damage to the tailboom is not to exceed **5%** of the tailboom area (approximately **160** square inches).
- **e.** If damage is located forward of tailboom station 43.00, between tailboom station 78.00 and 99.00 or aft of tailboom station 172.00, determine if bulkheads, supports, fittings, etc., have sustained damage. Damage to these parts is cause for tailboom replacement. Refer to figure 2-47.
- **f.** If installed, access cover (6, figure 2-48 or 7, figure 2-49) Damage Limits. Cover is acceptable without repair if the following damage limits are not exceeded:
  - (1) Dents are not sharp.
  - (2) Skin is not gouged.
  - (3) Not more than one dent per station plane.
- (4) Dents no closer than 2.000 inches to one another or edge.
  - (5) Dents no deeper than 0.020 inch.

- **g.** Bulkheads, web, and tailboom skin adjacent to access cover Damage Limits.
  - (1) Bulkheads. No damage allowed.
- (2) Web. No damage allowed in web within 1.000 inch of a bulkhead, external skin, or cover.
- (3) No damage allowed above the web in tailboom skin.

#### 2-248. Removal - Tailboom.C

### CAUTION

Use care not to damage VOR antenna (7, figure 2-48 or 8, figure 2-49) while removing tailboom. Supports shall be placed so they will not contact antenna. Antenna shall not be used as handhold.

#### NOTE

The tailboom may be supported by placing one support under the forward position and one support under the aft end immediately forward of the vertical stabilizer. Refer to figure 2-46.

- **a.** Remove vertical fin if required. Refer to paragraph 2-267.
- **b.** Remove inspection panel (13, figure 2-1 A, figure 2-2 from right side of fuselage just forward of tailboom attachment point. Remove aft engine fairing. Refer to paragraph 2-65.
- **c.** If installed, remove tail rotor driveshaft cover (4, figure 2-48 or 4 and 5, figure 2-49). Refer to paragraph 2-254.
- **d.** Disconnect and tag tailboom electrical antenna and electrical leads.

#### NOTE

Mark antenna leads to assist in proper installation.

e. Disconnect tail rotor pitch change tube.

**f.** Disconnect tail rotor driveshaft just forward of tailboom attachment point (paragraph 6-155). On helicopters with MWO 55-1520-228-50-25 accomplished, refer to paragraph 6-170.

## CAUTION

Tailboom may rotate to the right if vertical fin is not removed.

- **g.** Disconnect the tailboom and remove nuts (6) and washers (4) from four attaching bolts (1, 2, 3). With a plastic mallet, carefully drive the four bolts out and separate tailboom from aft fuselage. Refer to figure 2-46.
- **h.** If tailboom is to be replaced, remove all serviceable components from existing tailboom for reinstallation.

#### 2-249. Repair — Tailboom.


#### NOTE

Tailboom repair is limited to patching of minor damage. All repairs must be in accordance with accepted sheet metal practices. Refer to TM 55-1500-204-25/1.

#### NOTE

Ensure tailboom skin repairs do not interfere with fit of tail rotor driveshaft cover (4, figure 2-48 or 4 and 5, figure 2-49) if installed.

- **a.** Accomplish minor skin damage repairs as follows:
- (1) Clean up damaged skin using a minimum 0.125 inch radius.
- (2) Prepare a patch of aluminum alloy sheet (27, table 2-1) and shape to contour of tailboom. The patch must extend a minimum of 3.000 inches forward, 3.000 inches aft, 1.000 inch below and 1.000 inch above the damaged area.
- (3) Prepare patch and tailboom skin for bonding as follows:
- (a) Clean areas to be bonded with MEK (C107).



- 1. Bolt, NAS626-23 (Head Aft) 2. Bolt, NAS626-20 (Head Aft)
- 3. Bolt, NA-S626-20 (Head Aft)
- 4. Washers, (Under bolt heads with csk toward bolt heads)
- 5. Washer, as required between fittings and nut so that not less than one thread and not more than three threads are showing. Troque 375 TO 415 INCH-POUNDS.
- 6. Nut
- 7. Shim

Figure 2-46. Tailboom Removal/Installation

# DETAIL **A** TYPICAL REPAIR FOR MINOR DAMAGE




Figure 2-47. Tailboom Damage Limits and Repair

- **(b)** Sand surfaces lightly with sandpaper (C125) to remove all surface finish
- (c) Wipe sanded areas with a clean cloth moistened with MEK (C107), then wipe dry with a clean cloth before MEK evaporates.
- (4) Apply adhesive (C19) to patch and position patch over damaged area.
- (5) Install a minimum of three rows of NAS173813 rivets running circumferentially and a minimum of one row of rivets running longitudinally in the patch. Rivets are to be installed within pot life of adhesive (C19).

### NOTE


# Rivet size and spacing to be the same as skin lap joints.

**b.** Replacement of Tail Rotor Driveshaft Hanger Bearing Support Brackets. (AVIM)



If more than one support bracket requires replacement, replace one at a time. If original vertical position of driveshaft cannot be determined with  $\pm\,0.030$  inch, tailboom must be returned to depot for installation of bracket using alignment fixture.

- (1) Obtain dimensions between driveshaft and tailboom at support bracket to be replaced. If support bracket is being replaced due to elongation of mounting holes, position driveshaft at approximately center of elongation prior to obtaining dimensions.
- (2) Manufacture a shim block, of phenolic or other soft material, to fit contour of tailboom and driveshaft using dimensions obtained in substep (1).
- (3) Place shim block between driveshaft and tailboom as near as possible to support bracket being replaced. Ensure that shim block fits snugly with no excessive pressure on driveshaft or tailboom.



- Snapring
   Grommet

- Grommet
   Fastener
   Driveshaft Cover
   Driveshaft Hanger Bearing Support Bracket
   Access Cover (If Installed)
   VOR Antenna (If Installed)

- 8. Clip

Figure 2-48. Tailboom Assembly (MWO 55-1520-228-30-24 Accomplished)




Figure 2-49. Tailboom Assembly (MWO 55-1520-228-50-25 Accomplished)

**(4)** Remove bolts attaching driveshaft hanger to support bracket.

#### NOTE

When removing some support brackets, it may be necessary to remove driveshaft hanger attaching bolts from adjacent hangers to provide sufficient clearance. These bolts must be properly reinstalled prior to marking location of holes to be drilled in support bracket.

- (5) Rotate driveshaft hanger to provide clearance and remove screws attaching support bracket to tailboom. Remove support bracket from tailboom.
- **(6)** Position new support bracket on tailboom and install attaching screws.
- (7) Rotate driveshaft hanger until mounting holes for driveshaft hanger are in vertical alignment with support bracket. Allow driveshaft to seek its normal lateral position. Hold driveshaft against shim
- **(8)** Using a hole-finder, mark location of holes to be drilled in support bracket from driveshaft hanger mounting holes.
  - (9) Remove support bracket from tailboom.

# CAUTION

Drill press should be used for drilling support bracket to ensure holes are drilled parallel.

- (10) Drill two holes 0.252 ( $\pm 0.001$ ) inch in support bracket. Deburr holes and prime with primer (C118).
- (11) Position support bracket on tailboom and install attaching screws.
- (12) Ensure that holes in support bracket and mounting holes in driveshaft hanger are aligned within 0.030 inch. If holes do not align within tolerance, tailboom must be replaced.

#### NOTE

If interference is encountered between the safety pin on the forward end of the long tail rotor driveshaft and the bearing support bracket, material up to 0.120 inch on a 1.000 inch radius may be removed from the bracket to provide clearance.

- (13) Install driveshaft hanger attachment bolts and perform driveshaft alignment check. Refer to paragraph 6-127.
- (14) Make entry in helicopter historical records (DA Form 2408-15) that support bracket has been replaced. Each individual support bracket may be replaced three times in the field. Replace tailboom if support bracket required replacement more than three times. Send damaged tailboom to depot for repair.
  - c. Repair of tail rotor gearbox mount. (AVIM)
- (1) Fabricate a plate from sheet metal approximately **0.500** inch thick, the same size as the tailrotor gearbox base, with a true surface over the entire face. Drill four holes in plate to match gearbox mounting holes.
- (2) Clean paint to bare metal to 1.000 inch diameter area around mounting bolt holes where parts are missing or loose. Use sandpaper (C126) or MEK (C107).
- (3) Clean area where paint was removed with MEK (C107). Allow to dry.
- (4) Apply double-faced tape (C139) around mounting hole(s) on bottom of metal plate to hold washer(s) in position and to keep plate from being bonded to washer(s).
- **(S)** Attach washer(s) in position on plate to match mounting area on tailboom and apply a maximum **0.020** inch thickness film of adhesive (C19) to exposed surface of washer(s).
- **(6)** Tailbooms with MWO 55-1520-228-50-25 accomplished, prepare laminated shims in accordance with paragraph 6-203., step h.
  - (7) Align and position plate on tailboom

(8) Coat four bolts with lubricant (C111) and install to align washers and plate. Do not tighten bolts, allow plate to rock during bolt installation, or clamp plate to tail boom. Place a 10 pound weight on plate to apply pressure on washers during curing time.

#### NOTE

Steps (9) through (11) do not apply after accomplishment of MWO 55-1520-228-50-25.

- (9) Fabricate a second plate from steel metal approximately 0.250 inch thick and approximately 2.000 inches larger than first plate, with a true surface over its entire face. Attach a sheet of sandpaper (C124) to surface of plate.
- (10) Allow adhesive to cure and remove bolts and first plate.
- (11) Draw sandpaper side of second plate over washer(s) in short smooth strokes until a flat, solid contact is made at all four points.
- (12) Position first metal plate on washers to check for plate contact at all four points. Use a flashlight and shim to check for solid contact. Plate must not rock.
- (13) Install dissimilar metal tape (C139) to surface of bonded washers.

#### **NOTE**

The top surfaces of bonded washers with dissimilar metals tape installed must be in the same plane within 0.002 inch and parallel within 0.001 inch across their diameter.

(14) Prime and touch-up paint on tailboom

# WARNING

Cleaning solvents are flammable and toxic. Use only in well-ventilated area. Avoid skin contact and inhalation of vapors. Protect eyes with safety glasses.

#### NOTE

Helicopters with MWO 55-1520-228-50-25 accomplished, use one radius block (P/N 206-032-004-27) on left side and one radius block (P/N 20-042-21-8) on the right side. Refer to Appendix D for fabrication instructions.

(15) Missing Radius Blocks - Fabricate new radius blocks (P/N 206-032-004-27) in accordance with Appendix D. If the T/R gearbox was previously installed with the radius blocks missing, inspect the doublers for any damage caused by the forward mounting nuts of the gearbox. Nicks and scratches on doublers not exceeding 0.008 inch deep may be repaired using 400 grit sandpaper (C126). Also sandpaper (C126) the mounting surface of a newly fabricated radius block and clean with MEK (C107), After the MEK has dried, remove the MEK residue with a clean dry cloth. Clean mounting area of radius block on tailboom per substep (16) following. Bond in place per substeps (17) and (18) following.

- (17) Apply a film of adhesive (C19) to exposed mating surface of radius block(s) and position them inside tailboom under forward tail rotor gearbox stud holes. Install two bolts coated with lubricant (C111) to align radius blocks to doubler. Tighten nuts on bolts sufficiently to apply a 10 pound damping force on radius block(s) during cure time. Allow adhesive to cure, then remove bolts.
- (18) Prime and touch up paint in radius block areas as required.
- **d.** Repair of access cover (6, figure 2-48 or 7, figure 2-49) is not allowed. Damaged cover will be replaced.
- e. Repair of bulkheads, web, and tailboom skin adjacent to access cover
- (1) No repair to bulkheads allowed. Request disposition from AVSCOM engineering.

- (2) No repair to web allowed within 1.000 inch of a bulkhead, external skin, or the cover. Request disposition from ATCOM engineering. Other damage maybe repaired by accepted sheet metal practices.
- **(3)** No repair to tailboom skin allowed above the web. Request disposition from ATCOM engineering. Other damage may be repaired by accepted sheet metal practices.

### 2-250. Installation — Tailboom.

- **a.** If not previously accomplished, inspect at fuse-lage tailboom attachment fittings for condition. Look for loose rivets, cracking, and pitting. Fittings should be repainted if necessary.
- **b.** Check aft fuselage bulkhead for cracking, and also check the tailboom attachment holes, both fuselage and tailboom, for excessive wear.

# **NOTE**

Maximum diameter of the aft fuselage and/ or tailboom attachment holes as a result of elongation, wear or rework, must not exceed 0.383 inch diameter.

The four nylatron chafing pads installed on the front bulkhead of the tailboom are to be attached with adhesive (C9). Plug any existing exposed rivet holes.

- **c.** Ensure shim (7, figure 2-46) is securely bonded to tailboom with adhesive (C9).
- **d.** Position tailboom against aft fuselage and place suitable supports at each end of tailboom as shown in figure 2-46.

#### **CAUTION**

Ensure correct bolt is installed in correct hole. Refer to figure 2-46.

**e.** Align tailboom and aft fuselage attachment holes. Install bolts (1, 2, and 3, figure 2-46) from tailboom side with a washer (4) under the head of each bolt (countersink side toward bolt head). Install new washers (5) and new nuts (6) and torque **375 TO 415 INCH-POUNDS** 

flight following tailboom replacement and repaint (C132) slippage marks.

#### NOTE

Install washers (5) between fitting and nut so that not less than 1 thread and not more than 3 threads are showing.

- f. Connect antitorque control tube.
- g. Connect electrical wiring and antenna leads.
- **h.** Connect tail rotor driveshaft. Refer to paragraph 6-157.

# CAUTION

Ensure proper length screws are installed in access panel to avoid contact between screws and structure. Length of screw excluding head must not exceed 0.375 inch.

- **i.** Install aft engine fairing. Refer to paragraph 2-66.
- Remove tailboom supports.
- **k.** Install vertical fin if required. Refer to paragraph 2-269.
- **I.** Install tail rotor driveshaft cover, as required. Refer to paragraph 2-257.
- m. Install access plates (13, figure 2-1 A, figure 2-2 C).

### 2-251. TAIL ROTOR DRIVESHAFT COVER.

**2-252. Description** — **Tail Rotor Driveshaft Cover.** Helicopters with MWO 55-1520-226-30-24 accomplished have a one-piece aluminum alloy cover that encloses long tail rotor driveshaft. The cover is not a primary tailboom structure and maybe removed under special conditions. The purpose of the cover is to improve the reliability of the tail rotor driveshaft, bearings, and reduce maintenance requirements. It is attached to the tailboom by fasteners that secure to clips which are riveted to the left and right side of the tailboom.

**2-253. Description - Tail Rotor Driveshaft Cover.** Helicopters with MWO 551520228-50-25 accomplished have a two-piece hinged aluminum alloy cover that encloses tail rotor driveshafts. The cover provides protection to the tad rotor driveshaft and bearings, and reduces maintenance requirements. It is attached to the left side of tailboom by hinges. Hinge halves are riveted to the tailboom and tail rotor driveshaft cover. Clips and fasteners secure the cover to the right side of the tailboom.

#### CAUTION

To prevent possible injuries to personnel and damage to the helicopters, the tail rotor driveshaft cover will be closed for ground run.

2-254. Removal - Tail Rotor Driveshaft Cover.

#### **CAUTION**

Use care not to damage tail rotor driveshaft cover(s) or tailboom skin when removing cover.

**a.** On helicopters with MWO 55-1520-228-30-24 accomplished, loosen fasteners (3, figure 2-48) on both sides of tail rotor driveshaft cover and remove from tailboom.

# NOTE

The helicopter may be flown without tail rotor driveshaft cover(s) installed at the discretion of the unit commander.

It may be necessary to use a scrap piece of hinge pin or similar material to drive the hinge pin out.

- **b.** On helicopters with MWO 55-1520-228-50-25 accomplished, loosen fasteners (1, figure 2-49). Open covers (5 and 4). Disconnect lanyard (18) securing aft cover (5) to support (14). If forward cover (4) is removed, remove screw from cover (7) at the end of forward hinge (9). Cut lockwire at ends of hinges (9) and remove hinge pins (10) from hinges (9).
- **c.** When the helicopter is to be flown without the tail rotor driveshaft cover installed, the following will apply:
- (1) A weight and balance calculation on DD Form 365-C shall be accomplished to update weight and balance records.

(2) On helicopters with MWO 55-1520-228-30-24 accomplished, antichafe tape (C112) shall be removed from tailboom. Replace antichafe tape when tail rotor driveshaft cover is reinstalled.

# 2-255. Inspection - Tail Rotor Driveshaft Cover.

- **a.** Inspect driveshaft cover (4, figure 2-48, or 4 and 5, figure 2-49 for condition of paint.
- **b.** Inspect driveshaft cover for damage, cracks, dents, tears, scratches and corrosion.
- **c.** On helicopters with MWO 55-1520-228-30-24 accomplished:
- (1) Inspect driveshaft cover fasteners (3, figure 2-48) for damage or corrosion. Missing fasteners are not permitted.
- (2) Inspect clips (8) mounted on tailboom for cracks, deformation, loose rivets, corrosion, or damage. These conditions are not permitted.
- (3) Inspect pressure sensitive (antichafe) tape (Cl 12), on tailboom for deterioration, tears, delamination, or embritlement. These conditions are not permitted.

#### NOTE

Aircraft with driveshaft cover lower edges flared outboard, which allows clearance eliminating chafing on tailboom, do not require installation of chafing tape.

- **d.** On helicopters with MWO 55-1520-228-50-25 accomplished:
- (1) Inspect driveshaft cover fasteners (1, figure 2-49) and hinge halves (9) for damage and corrosion. Missing fasteners or loose rivets in hinge halves are not permitted.
- **(2)** Inspect tailboom clips (11) and hinge halves (9) for cracks, deformation loose rivets, or damage. These conditions are not permitted.
- **(3)** Inspect the 14 chafe pads (12) on tailboom for deterioration, separation, loose rivets, or embrittlement. These conditions are not permitted.

# 2-256. Repair - Tail Rotor Driveshaft Cover.

**a.** Repair or replace tailboom clips (8, figure 2-48 or 11, figure 2-49) that do not meet inspection requirements.

- **b.** Replace damaged or missing fasteners (3, figure 2-48 or 1, figure 2-49) on driveshaft cover.
- **c.** On helicopters with MWO 55-1520-228-30-24 accomplished, replace pressure sensitive (antichafe) tape (C112), that does not meet inspection requirements.

#### NOTE

Aircraft with driveshaft cover lower edges flared outboard, which allows clearance eliminating chafing on tailboom, do not require installation of chafing tape.

- **d.** On helicopters with MWO 55-1520-228-50-25 accomplished:
- (1) Replace damaged tailboom hinge halves (9) and pads (12) that do not meet inspection requirements.
- (2) Replace damaged cover hinge halves (9) and doubler (13) that do not meet inspection requirements.
- **e.** Repair driveshaft cover skin in accordance with TM 55-1500-204-25/1.
- 2-257. Installation Tail Rotor Driveshaft Cover

# CAUTION

Use care not to damage tail rotor driveshaft cover or tailboom skin when installing cover.

- **a.** On helicopters with MWO 55-1520-228-30-24 accomplished:
- (1) Place driveshaft cover (4, figure 2-48) on tailboom. Ensure cover is on outboard side of clips (8) to prevent damaging clips.
- (2) Align cover fasteners (3) to clips (8) and lock in place on left and right side of driveshaft cover.
- **b.** On helicopters with MWO 55-1520-228-50-25 accomplished:
- (1) Place aft cover (5, figure 2-49) on tailboom. Align hinge halves. Install aft hinge pins (10) forward

- to aft. Leave cover (5) hinged open at this point. Position forward cover (4) on tailboom. Align hinge halves. Install hinge pin (10).
  - (2) Use lockwire (C96) to retain hinge pins
- (3) Align cover fasteners (1) with clips Lock fasteners.
- **(4)** Attach lanyard (18) on aft cover (5) to support (14) with shouldered bolt (16) and washer (17).


#### 2-258. HORIZONTAL STABILIZER.

- **2-259. Description Horizontal Stabilizer** (figures 2-50 and 2-51). The horizontal stabilizer is constructed of aluminum and mounted through the tailboom. The stabilizer is supported and secured by plates on each side.
- **2-260.** Inspection Horizontal Stabilizer. Inspect horizontal stabilizer, support plates, and tailboom attaching points for cracks, dents, and damage. Check for loose or worn rivets, missing screws, and navigation lights for security and condition of lens.

#### 2-261. Removal - Horizontal Stabilizer.

- **a.** Remove screws and washers attaching two upper supports to tailboom and stabilizer.
- **b.** Disconnect position light wires at terminal block.
- **c.** Remove screws and washers attaching two lower supports to tailboom and stabilizer.
- **d.** Slide stabilizer out of tailboom taking care not to damage the surface.
- **e.** If stabilizer is to be replaced, remove the position lights and wiring from existing stabilizer for reinstallation.
- 2-262. Repair Horizontal Stabilizer. Refer to TM 55-1500-204-25/1 for repairs.
- 2-263. Installation Horizontal Stabilizer.
- **a.** Slide stabilizer into tailboom, taking care not to damage the surface.

Figure 2-50. Horizontal Stabilizer and Vertical Fin Installation (Sheet 1 앜 2



- 1. Nut
- 2. Washer
- 3. screw 4. Nut
- 5. Washer
- 6. Screw
- 7. Lower Support
- 8. screw
- 9. screw
- 10. Upper Support 11. Horizontal Stabilizer

206022-6-2

Figure 2-50. Horizontal Stabilizer and Vertical Fin Installation (Sheet 2)




Figure 2-51. Vertical Fin Installation

**b.** Install lower supports (7, figure 2-50) attaching with screws (3 and 9) to tailboom and horizontal stabilizer.

#### **NOTE**

# Start all screws first and then complete tightening to keep from stripping screws in misaligned holes.

- **e.** Connect position light wires at the terminal block and ensure wire is serviceable and clamped.
- **d.** Install upper supports (10), attaching with screws (3, 8, and 9).
- **e.** Install nut (4), washer (5), and screw (6) through upper and lower supports (7 and 10) and horizontal stabilizer (11).
  - f. Install nut (1), washer (2), and screw (3),

# 2-264. VERTICAL FIN AND SUPPORTS.

2-265. Description — Vertical Fin and Supports (figures 2-50, through 2-53.) The vertical fin is of aluminum honeycomb construction and provides a mount for the tail skid and radio antennas. The vertical fin is attached to the tailboom by means of forward and aft vertical fin supports. These supports are of aluminum construction and are classified as major structural members.

#### 2-266. Inspection — Vertical Fin and Supports.


- a. Upper leading and trailing edge.
- (1) Punctures of any size are not acceptable unless repaired.
- (2) Chips not to exceed 0.250 inch diameter and less than 10% of the total area shall be considered negligible.
- (3) Open cracks of any length are not acceptable. Open cracks must be repaired.
- (4) Hair line cracks less than 1.000 inch in length shall be considered negligible.
- (5) Scratches not to exceed 0.005 inch depth, and not more than 1.000 inch in length shall be considered negligible. All other damage must be

repaired, or the assembly removed and replaced with a serviceable vertical fin.

- b. Lower leading and trailing edges.
- (1) Smooth dents which are not gouged and of less than 3.000 inches in diameter and 0.300 inch deep are acceptable. Dents within one inch of one another (edge-to-edge) are to be considered as one dent.
- (2) Nicks and scratches not more than 0.002 inch in depth and of any length, will be considered negligible.
- (3) Corrosion pitting not to exceed 0.002 inch in depth, and not more than 10% of the total area will be considered negligible.
  - (4) No cracking or punctures will be permitted.
- (5) Loose or missing rivets will be unacceptable.
- (6) Any damage beyond the aforementioned limitations must be repaired, or the assembly must be removed and replaced with a serviceable vertical fin.
- **c.** Honeycomb area will be inspected as specified in paragraph 2-172. Limitations will be as specified in paragraphs 2-179 and 2-187.
- **d.** Antenna leads and couplers will be inspected for security and condition. Do not turn couplers.
- **e.** Mounting bolts will be inspected for damaged threads, cracking, and security. Missing bolts must be replaced.
- **f.** Forward and aft vertical fin supports will be inspected for cracking, security of attachment, corrosion, and damage. 'No cracking, loose or missing rivets, or damage beyond the repair limitations specified in figure 2-52 and 2-53 will be permitted.

### 2-267. Removal — Vertical Fin and Supports.

- a. Disconnect VHF and FM antenna cables at vertical fin.
- **b.** Remove four bolts attaching vertical fin to forward and aft supports. Refer to figure 2-51.
- c. Removal and replacement of forward and aft vertical fin supports is not authorized. Loose or



NOTE: All dimensions are indicated in inches.

#### FORWARD VERTICAL FIN SUPPORT 206-031-417

TYPE OF DAMAGE

MAXIMUM DAMAGE AND REPAIR DEPTH

MECHANICAL

Smooth damage exceeding 0.010 inch shall be blended out. Cleanup depth or repairs shall not exceed minimum dimension shown above.

CORROSION

Repair areas after cleanup shall not exceed minimum dimensions shown above.

MAXIMUM AREA PER FULL DEPTH REPAIR

2.000 Sq. In.


NUMBER OF REPAIRS

Four

#### NOTES:

- 1. Blend out reparable damage with 400 grit abrasive paper (C126).
- 2. Coat all repair areas with chemical conversion coating (alodine) (C38) and apply zinc chromate primer (C118).

Figure 2-52. Repair Limits — Forward Vertical Fin Support



NOTE: All dimensions are indicated in inches.

# AFT VERTICAL FIN SUPPORT 206-031-418

TYPE OF DAMAGE	MAXIMUM DAMAGE AND REPAIR DEPTH
MECHANICAL	Smooth damage exceeding 0.010 inch shall be blended out. Cleanup depth or repairs shall not exceed minimum dimension shown above.
CORROSION	Repair areas after cleanup shall not exceed minimum dimensions shown above.
MAXIMUM AREA PER FULL DEPTH REPAIR	2.000 Sq. In.
NUMBER OF REPAIRS	Four

# NOTES:

- 1. Blend out reparable damage with 400 grit abrasive paper (C126).
- 2. Coat all repair areas with chemical conversion coating (alodine) (C38) and apply zinc chromate primer (C118).

Figure 2-53. Repair Limits — Aft Vertical Fin Support

damaged rivets will be replaced one at a time in accordance with instructions contained within TM 55-1500-204-25/1

2-268. Repair — Vertical Fin and Supports. Vertical fin and supports will be repaired in accordance with instructions contained in figures 2-39, 2-52, and 2-53, except that only fiberglass repairs will be permitted to the upper forward and aft trailing edges, and nicks, scratches, or pitting in the lower forward and at trailing edges may be blended out provided that not more than 10 percent of material thickness must be removed for cleanup.

#### NOTE

To gain access to antenna couplers, remove rivets and remove trailing edge of vertical fin or cut a small hole in the fiberglass behind the connectors.

2-269. Installation — Vertical Fin.

# CAUTION

The lower aft bolt may require an additional thin washer next to the recess washer if the bolt bottoms out on the ballast weight.

#### NOTE

This step applies to vertical fin installation on tailbooms P/N 206-032-004-1 which have not been modified for installation of vertical fin with bolts and nuts. Refer to figure 2-50.

- a. Position fin on tailboom and install four bolts of proper length and eight washers, two longest bolts forward, The recessed washers are installed next to head of bolts and the thin washers between the fin and mount. Torque bolts 50 T0 70 INCH-POUNDS.
- **b.** The following steps apply to vertical fin installation on tailbooms P/N 206-032-004-51 which have been modified for installation of vertical fin with bolts and nuts. Refer to figure 2-51.
- (1) Place countersunk washers (2) on four bolts (1) with recessed side of washers toward bolt heads. Place four bolts (1), with washers installed, through holes in vertical fin.

- (2) Place one thin aluminum washer (3) on each of four bolts (1) on inboard side of vertical fin.
- (3) Position vertical fin on tailboom and install special washers (4) and nuts (5). A minimum of one and a maximum of two washers (4) must be installed on each bolt (1) between the nut and the tailboom structure. Install the special washers (4) with the radius toward the tailboom structure. Torque bolts 50 TO 70 INCH-POUNDS.
- c. Connect VHF and FM antenna cables at vertical fin, Slide rubber nipples over connections and secure at both ends with nylon thread (C149) to prevent gasses from fouling connections.

### 2-270. TAIL SKID.

- **2-271. Description Tail Skid.** A tubular, steel, tail skid is attached to the lower section of the vertical fin. The purpose of the tail skid is to warn the pilot of a tail-low attitude when landing. Refer to figure 2-51.
- **2-272. Inspection Tail Skid.** Inspect tail skid for buckles, c-racks, dents, and security of attachment,
- **2-273.** Removal Tail Skid. Remove attaching spring pin with suitable drift pin and withdraw tail skid from vertical fin.
- **2-274.** Repair Tail Skid. If the tail skid becomes loose at its mounting point, the following procedures may be utilized for field repair.
  - a. Remove the tail skid.
- **b.** Apply sealing compound (C129) to tail skid in the area of attachment to the vertical fin.
- **2-275. Installation Tail Skid.** Position tail skid in vertical fin and install spring pin.

#### NOTE

Should the spring pin hole be worn to a degree where loss of the pin is imminent, the pin may be replaced with a screw and self-locking nut. It is acceptable to install the screw in the worn hole as there is no requirement to enlarge the retainer hole to the next size. Maximum allowable torque of screws is 35 INCH-POUNDS including drag torque.

### 2-276. SUPPORT — TAILLIGHT.

**2-277. Description** — **Support, Taillight.** The support is of glass fabric construction and provides a mount for the taillight assembly. Refer to figure 2-54.

# 2-278. Inspection — Support Taillight.

**a.** Inspect support (1, figure 2-54) for cracks and damage. Check for loss, missing screws (2), taillight (5), for security and condition of lens.

# 2-279. Removal — Support, Taillight.

- **a.** Disconnect gearbox chip detector wire, VHF and FM antenna cables at vertical fin and remove taillight assembly (5, figure 2-54) from support (1). Disconnect taillight (5) from wire and connector.
- **b.** Remove screws (2) attaching support to tailboom (6). Pull gearbox chip detector wire and VHF and FM antenna cables through and free of grommet hole in support. Ensure that taillight and grommet (4)




Figure 2-54. Support, Taillight Installation

are not secured to the support (1), before removal of support.

**2-280.** Repair — Support, Taillight. Repair damage to support glass fabric material in accordance with TM 55-1 500-204-25/1.

### 2-281. Installation - Support, Taillight.

**a.** Insert gearbox chip detector wire and VHF and FM antenna cables through grommet (4, figure 2-54) hole in support (1).

#### NOTE

Shim between fin support (7) and taillight support (1) on installation with washers (3) (Maximum allowable 0.025 inch, maximum number of washers 3).

- **b.** Position support (1) on tailboom (6) and secure in place with attachment screws (2).
- **c.** Install taillight assembly (5) on rear of support (1).

#### SECTION III. PYLON

## 2-282. PYLON SUPPORTS (Figure 2-55).

**2-283. Description** — **Pylon Supports.** The main transmission is supported on each side by a pylon support link on the cabin roof and attached by clevis arrangement to the roof and by spindle to the transmission.

#### 2-284. Inspection — Pylon Supports.

- **a.** Inspect pylon supports for cracks, scratches, security of attachment, and evidence of elongation in self-aligning bearing.
- **b.** Inspect pylon support links and support fitting for nicks, scratches, and minor damage.
- **c.** Inspect bearings for security, loose teflon inserts, and check that bolts are installed in the support link with heads inboard toward the transmission.

### 2-285. Removal - Pylon Supports.


**a.** Remove transmission or use adequate overhead hoist for transmission support. Refer to paragraph 6-71.

- **b.** Remove bolts (18, figure 2-55), nuts (21), and washers (19 and 20) attaching pylon support links (11) to forward and aft pylon support fittings (6 and 12).
- **c.** Remove pylon support links from transmission by removing cotter pins (7), nuts (8), and washers (9).
- **d.** Remove nuts (25), washers (26), and bolts (27) securing forward and aft pylon support fittings (6 and 12) to roof structure.

# CAUTION

Do not remove shims under pylon support fittings (6 and 12). If shims are not bonded, identify for reinstallation in same location. Loss or mixing of shims will require depot maintenance for transmission alignment.

- **2-286.** Cleaning and Inspection Pylon Supports. (AVIM) Accomplish the cleaning and inspection of pylon supports as follows:
- **a.** Clean all parts with drycleaning solvent (C62). Dry with clean, dry air.



- 1. Pylon Support Spindle (Ref)
- 2. Washer
- 3. Transmission Mount Support
- 4. Isolation Mount
- 5. Isolation Mount Cover
- 6. Aft Pylon Support Fitting
- 7. Cotter Pin
- 8. Nut
- 9. Washer
- 10. Bearing, Pylon Support Link
- 11. Pylon Support Link
- 12. Forward Pylon Support Fitting
- 13. Bolt
- 14. Washer
- 15. Nut, Cotter Pin

- 16. Bearing, Drag Pin (Ref)
- 17. Drag Pin Assembly (Ref)
- 18. Bolt
- 19. Washer
- 20. Washer, Recessed
- 21. Nut
- 22. Bearing, Support Fitting
- 23. Fitting, Forward Support
- 24. Shims
- 25. Nut
- 26. Washer
- 27. Bolt
- 28. Bushing, Pylon Support Link
- 29. Bolt

Figure 2-55. Pylon Support Link and Fitting

- **b.** Inspect bearing (10, figure 2-55) in pylon support link and bearings (22) in fittings (6 and 12) and bolts (18) for smoothness of operation, looseness, and general condition. Maximum allowable play of each bearing is 0.010 inch axial.
- **c.** Inspect bushings (28) in pylon support link for excessive wear. I.D. of each bushing shall not exceed 0.438 inch. Inspect for scoring on inside surface of bushing. Scoring or damage to inside surface of bushing must not exceed 0.002 inch.
- **d.** Remove all paint from the pylon support link in preparation for magnetic particle inspection.
- **e.** Inspect pylon support links (11, figure 2-55) with magnetic particle inspection paying particular attention to the area around attaching points. (Refer to TM 55-1500-335-23.) Any crack is reason for rejection.
- (1) Circular field using central conductor through pylon support link bearing hole, magnetize at 1,600 amperes. Inspect hole I.D. and surrounding area.
- (2) Longitudinal field by placing half the link perpendicular to the coil axis and magnetize at 6,000 ampere-turns. (Requires 2 inspections.)

# 2-287. Repair — Pylon Supports. (AVIM)

- **a.** Replace pylon support links (11, figure 2-55) found defective by magnetic particle inspection. Refer to TM 55-1500-335-23.
- **b.** Replace bearings (10) in pylon support links (11), and support fitting bearing (22) in fittings (6 and 12) which do not meet inspection requirements.
  - **c.** Press staked bearing from support link of fitting.
- **d.** Remove any burr edges visible on the bearing housing by use of a fine or medium grade abrasive cloth (C45 or C55).
- **e.** Prime mating surfaces of bearing and link or fitting housing with wet zinc chromate primer (C118) just prior to bearing installation.

#### **CAUTION**

When extreme interference fit occurs at the beginning of the press fit operation, stop and determine the cause. Do not stake the bearing unless the cause can be eliminated or satisfactorily remedied.

- **f.** Align the bearing and housing so that the bearing will not be cocked. Seat the bearing into the housing using a suitable press.
- g. Pregrooved bearing outer races will be staked to the pylon support link assembly (both sides) using tool (T33). Bearings in the support fittings must be staked (both sides) using tool (T27). After staking, the gap between the staked lip of the outer bearing race and the chamfered area of the staked assembly or fitting shall be less than 0.008 inch. After staking, the breakaway torque of the bearing must be less than 6 INCH-POUNDS. If bearing is too tight after staking, spin bearing inner race at 80 to 120 rpm until proper torque is obtained.
- **h.** Replace bushings (28) in pylon support links which do not meet inspection requirements.
- i. Press damaged or worn bushings from pylon support links.
- **j.** Coat mating surfaces with zinc chromate primer (C118) and press new bushing into support link. Line ream two bushings 0.437 to 0.438 inch diameter.
- **k.** Nicks, scratches, and minor damage incurred in service may be dressed out to a maximum depth of 0.010 inch in the attach point areas and 0.020 inch elsewhere. No more than two repairs in each of the attach point areas. Minimum radius of any repair is 0.500 inch. Imperfections as a result of forging and machining during manufacture are not cause for rejection. Touch up bare spots with zinc chromate primer (C118).

## 2-288.Installation — Pylon Supports.

#### **CAUTION**

Only steel support fittings are to be installed on the OH-58C and OH-58A with 720 engine and all replacements are to be steel on any OH-58A/C. Only steel supports are to be used. No aluminum links are to be used on OH-58A/C aircraft.

a. Secure forward and aft pylon support fittings (6 and 12, figure 2-55) to roof structure using bolts, washers, and nuts. Torque nuts 120 TO 145 INCH-POUNDS A or 120 TO 160 INCH-POUNDS C. Apply a thin bead of sealing compound (C131) around each pylon support fitting.

#### NOTE

Short leg of pylon support link must be instailed forward to insure proper alignment of transmission drag pin and pylon isolation mount.

**b.** Attach pylon support links (11) to fittings (6 and 12) with bolts (18), washers (19 and 20), and nuts (21). Torque nuts **460 TO 510 INCH-POUNDS.** 

# 2-289. PYLON ISOLATION MOUNT AND TRANSMISWMJ MOUNT SUPPORT.

**2-290. Description - Pylon isolation mount and Transmission Mount Support.** The main transmission is supported and attached at its lower rear section by an isolation mount (4, figure 2-55) which dampens pylon to fuselage vibrations, and limits pylon rock. Movement of the transmisson and isolation mount is limited by means of a drag pin (17), which extends down into a plate on the deck. Contact between the drag pin and its static stop produces a noise known as spike knock.

**2-291.** Inpection - Pylon Isolation Mount (P/N 206-030-539-3) and Transmission Mount Support. See paragraph 2-292 for pylon isolation mount, P/N 206-030-539-5 and -101.

- **a.** Inspect isolation mount P/N 206-030-539-3 as follows:
- (1) Inspect cover (5, figure 2-55) for security. Wipe excess oil from cover and inspect for tears and cuts. None are permitted.
- (2) If isolation mount cover is deteriorated or torn remove cover and visually examine clevis (13, figure 2-57) area and elastomeric dampers for separation while flexing elastomeric dampers by means of the clevis. Due to the stiffness of the mount, laterial rocking of the mast assembly may be necessary exercise extreme


care to prevent damaging the transmission mount support. Refer to paragraph 2-294, d. and 2-296 for repair limits and procedures.

#### NOTE

If cover (5, figure 2-55) has been contacted by the main driveshaft housing, as evidenced by grooving and/or tearing, refer to AVIM for main driveshaft inspection. If swashplate to cowling or main driveshaft to isolation mount contact occurs, the following inspections will be complied with: Hard Landing Inspection, Pylon Whirl Inspection, to include special inspection of main driveshaft assembly and the drag pin assembly must be removed from transmission assembly for a detailed inspection. The four drag pin assembly mounting studs will be replaced.

- **(3)** Verify drag pin bolt (13, figure 2-55) is properly installed and in right direction.
- (4) inspect drag pin for condition and security. (Refer to transmission inspection, paragraph 6-70.) Look for obviously bent or broken pin. Typically the four drag pin mounting studs will fail before the drag pin. Consequently nicks and dents are not critical.
- **b.** Inspect the transmission mount support as follows:
- (1) Inspect transmission mount support for security of attachment.
- (2) Inspect the transmission mount support stop on the cabin roof. Normally the upper edges of the stop will tend to round out as a result of impact with the drag pin. Impact damage along upper edge of static stop must not exceed 0.100 inch depth as indicated in figure 2-56. Cumulative area of damage is not significant.


# 0.100 MAX DAMAGE FORE AND AFT STOPS



NOTE: All dimensions are in inches.

206032-141

Figure 2-56. Damage Limits — Transmission Mount Support Stop



Identify bolt (4) when removed for installation in same location because bolts may be of different lengths.

- 1. Bolt
- 2. Washers
- 3. Neoprene Boot
- 4. Bolt
- 5. Washer
- 7. Shim
- 6. Mount
- 9. Nut
- 10. Cotter Pin
- 11. Bolt
- 12. Gasket
- 13. Clevis14. Drag Pin

Figure 2-57. Pylon Isolation Mount Installation (P/N 206-030-639-3)

# 2-292. Inspection — Pylon Isolation Mounts, P/N 206-030-639-6 and -101 and Transmission Mount Support.

- **a.** Refer to paragraph 2-295 for repair limits and procedures. Inspect these isolation mounts as follows:
- (1) Remove oil on and around mount with a clean, dry cloth. (These mounts do not have top neoprene covers.)

#### **NOTE**

If top surface of mount has been contacted by the main driveshaft coupling, as evidenced by grooving, refer to AVIM for main driveshaft inspection. If swashplate to cowling or main driveshaft isolation mount contact occurs, the following inspections will be complied with: Hard Lending Inspection, Pylon Whirl Inspection, to include special inspection of main driveshaft assembly and drag pin, assembly must be removed from transmission assembly for a detailed inspection. The four drag pin assembly mounting studs will be replaced.

(2) Inspect drag pin bolt, drag pin, and transmission mount support in accordance with paragraph 2-291.

# 2-293. Removal - Pylon Isolation Mount and Transmission Mount Support.

- a. Remove pylon isolation mount as follows:
- (1) Remove main driveshaft (paragraph 6-10). install lift hook (S16) or clevis on main rotor mast nut and support transmission with hoist to prevent tipping of transmission.
- (2) Remove nut (9, figure 2-57) and remove bolt (1) which passes through pylon drag pin (14), washers (2), and mount (6, figure 2-57 or 5, figure 2-59).
- (3) Remove cover from inside upper cabin roof beam assembly.

# CAUTION

Do not remove shims under isolation mount. If shims become debonded measure, and record on DA Form 2408-15, shim thickness and location. Loss of shims or improper shimming will require realignment by depot level maintenance.

#### NOTE

Identify bolt (4, figure 2-57) when removed for installation in same location because the bolts may be of different lengths.

- (4) Remove four bolts (4) which pass through isolation mount and cabin roof.
- **(5)** Remove mount (6, figure 2-57) or yoke (5, figure 2-59) from roof.
- **b.** Remove transmission mount support as follows:
- (1) Install lift hook (S16) or clevis on main rotor mast nut and support transmission with hoist to prevent tipping of transmission.
- (2) Remove nut (9, figure 2-57), bolt (1), and washers (2) if not previously accomplished.
- (3) Remove cover from inside upper cabin roof beam assembly, then remove six bolts and washers from on top of cabin roof.
  - (4) Remove transmission mount support.
- **2-294.** Inspection Pylon Isolation Mount (P/N **206-030-639-3)** and Transmission Mount **Support.** See paragraph 2-295 for pylon isolation mount, P/N 206-030- 539-5 and -101. Inspect mount P/N 206-030-539-3 as follows:
- **a.** Wipe up oil spillage, etc., then remove isolation mount neoprene boot (3, figure 2-57).

#### TM 55-1520-228-23

- b. Visually examine devis area and elastomeric dampeners for bonding separation while flexing elastomeric dampeners by means of the devis. Due to the stiffness of the mount, lateral rocking of the mast assembly may be necessary; exercise extreme care to prevent damaging the transmission mount support.
- c. Remove mount in accordance with paragraph 2- 293 and fluorescent penetrate inspect the housing and devis. Refer to TM 55-1500-335-23.
- d. Repair or replace the isolation mount if any of the following conditions exist:

### NOTE

Cure dates are embossed on elastomer surface, usually on the right rear surface inside. Typical cure dates are 670, 270, 171, 172, and 572. Whenever an Isolation mount problem is reported, Include cure date of mount, etc.

- (1) Rubber dampers oil saturated.
- (2) Rubber dampers excessively cracked and/or broken. Cracks must not exceed 0.100 inch in depth.
  - (3) Loose and/or tom front boot (around devis).
- (4) Loose, missing, or improperly seated center damper screws.
- (5) Clevis (13) permanently deformed or cracked. No repair authorized.
- (6) Clevis holes worn excessively. Hole diameter should not exceed 0.504 inch.
- (7) Check yoke dimension of 0.626 to 0.632 inch between inside faces of yoke. Replace yoke if dimension exceeds 0.633 inches.
- (8) Excessive bonding separation between rubber dampers and housing. Bonding separation should not exceed 0.250 square inch in each of the four active areas of the forward and aft dampers, nor should it exceed 1.000 square inch per assembly.

- 2-295. Inspection-Pylon Isolation Mounts (P/N 206-30-539-5 and -101) and Transmission Mount Support. Inspect these isolation mounts as follows:
- a. Remove mount and mount support in accordance with paragraph 2-294. Clean oil from mount with dean, dry cloth. (These mounts do not have top neoprene covers.)
- b. Remove cotter pins (1, figure 2-59), nut (2), washers (3), and bolts (4).
- c. Remove yoke (5) from molded assembly (6).
- d. Remove screws (7) from side brackets (8 and 9).
- e. Remove front boot (10) by carefully inserting a knife-edge between front boot and molded assembly (6) at sealant line. Care must be taken in order that elastomeric sections in line with sealant are not cut or damaged. Carefully pull front boot off center plate of molded assembly.

#### **NOTE**

Temporary repairs on the front boots which are not deteriorated from age or oil saturation may be rebonded with sealing compound (C131) after thoroughly cleaning with aliphatic naphtha (C22).

- f. Remove screws (11) from side brackets (8 and 9). Inspect for corrosion inside mount assembly surfaces of the top and bottom plates and inside walls of brackets (8 and 9). Pitting corrosion and white-gray surface oxidation exuding from aluminum plate surfaces and crevices in the bond areas are causes for removal and replacement of the isolation mount.
- g. Remove rear cover (12) by inserting a knifeedge between cover and molded assembly (6) at sealant line.
- h. Inspect mount as outlined in table 2-2. Do not remove top or bottom plates of molded assembly (6).

Table 2-2. Inspection of Transmission Isolation Mount (206-030-539-5 and -101)

PART	INSPECTION FOR	ACTION	
Front Boot (10, figure 2-59)	Cuts or tears in elastomeric boot around clevis.	Remove and replace boot if cuts or tears are evident.	
Molded Assembly (6), yoke (5), and side brackets (8 and 9)	Metal-to-rubber bond separation: flex-cracks (Surface cracks of rubber due to flexing)	Replace entire mounting if separation exceeds a total of 2.500 square inch area or if flex crack exceeds 0.500 inch deep.	
	Nicks, gouges, and, corrosion in metal parts	Replace entire mount if nicks or gouges are evident in critical areas. In noncritical areas, nicks and gouges up to <b>0.030</b> inch deep may be polished out. After polishing, apply coating (C38), and paint with primer (C116).	
	Wear of the <b>0.4995</b> to <b>0.5000</b> inch diameter clevis hole.	Replace yoke if hole diameter exceeds <b>0.5005</b> inch.	
	Slight damage or deterioration of oil resistant coating.	Permissible, provided bond separation and flex-crack limits are met.	
	Cracks in critical areas (i.e. yoke, center plate of molded assy, side brackets, top and bottom plates) remove screws (7) and deflect boot (10) away from mount. This will permit the fluorescent penetrant inspection of the center plate.	Fluorescent penetrant inspection for cracks. Replace entire mount if cracks are evident. Refer to TM 55-1500-335-23.	
	Dimension of <b>0.625</b> to <b>0.626</b> inch between faces of yoke.	Replace yoke if dimension exceeds <b>0.633</b> inch.	
	Deformed metal parts.	Replace entire mount if metal is deformed.	
Bearings (13)	Clearance between spherical bearing and outer bearing ring.	Replace entire mount if radial clearance exceeds <b>0.006</b> inch.	
	Slight damage to or oil deterioration of oil resistant coating on flexing element.	This is permissible provided bond separation and flex-crack limits are met.	

#### TM 55-1520-228-23

- i. Before replacing front boot (10) dean all unbonded metal mounting surfaces of molded assembly (6) with aluminum wool (C23) and remove as much as possible of the old adhesive from boot (10) with a stiff brush. Apply Ecobond 45 (C5) **0.002 to 0.005** inch thick on mounting surfaces of boot (10), top and bottom plates of assembly (6) and side brackets (8 and 9). Apply athin bead of sealing compound (C130) along the outside edges of mounting surfaces of boot (10), top and bottom plates of assembly (6), and side brackets (8 and 9).
- j. Position front boot (10) over spherical bearings (13) in molded assembly (6). Install screws (7).
- k. Before replacing rear cover (12) dean all metal mounting surfaces with solvent (C52). Old adhesive must be completely removed. Apply sealing compound (C130) 1/16 inch thick to mounting surfaces of molded assembly (6) to include side brackets (8 and 9) and top and bottom plates.
- I. Position rear cover (12) and install screws (11) finger tight.
- m. Allow sealing compound (C130) to cure at room temperature for 12 to 24 hours, then tighten screws (11) and clean off excess sealant. Add a bead of sealant (C129) around mating surfaces of front and rear covers and the mount to prevent moisture entering the mount.
- n. Inspect yoke (5, figure 2-59) using the magnetic particle method. Magnetize yoke with longitudinal field at 5000 ampere-turns. Rotate 90 degrees and repeat inspection. Refer to TM 55-1500-335-23.
- o. Place yoke (5) over spherical bearings (13) (clevis holes face down). Install washers (3), bolts (4), and torque nuts (2) 150 TO 225 INCH-POUNDS. Secure with cotter pins (1) as shown in figure 2-59.

# 2-296. Repair Pylon Isolation Mount and Transmission Mount Support

- a. Repair pylon isolation mount P/N 206-030-539-3 as follows:
- (1) Replace neoprene boot (3, figure 2-57) if deteriorated, punctured, cracked, or excessively loose on housing.
- (2) Nicks and gouges up to 0.030 inch deep in housing and devis may be blended out, and touched up with alodine (C38) or epoxy polyamide primer (C116).

- (3) Remove burrs, etc., from attachment bolt hole flats.
- (4) Loose or torn front boots which are not also deteriorated from age or oil saturation may be rebonded with sealing compound (C130). Surfaces to be bonded must be carefully cleaned with MEK (C107), aluminum oxide coating removed from adjacent surfaces with sandpaper (C126), and recleaned with MEK. MEK must not contact active damper areas. Use sealing compound sparingly.
- (5) Isolation mounds which have tom and deteriorated front boots around the clevis may be repaired by fabrication of a new boot, provided the isolation mount is otherwise serviceable. Proceed as follows:
- (a) Remove defective boot with the aid of needle-nose pliers and other suitable hand tools.
- (b) Remove screw/plate fasteners located on either side of devis 180 degrees apart. Remove all rubber and rubber-like residue with sturdy putty knife, or similar tools. Clean screw/plate fasteners with MEK (C107). Refer to figure 2-58.
- (c) From a 1-1/2 inch thick low density urethane foam sheet (C152), cut two each blocks measuring approximately 1 x 1-3/4 x 1-1/2 inches as shown in figure 2-58. Place one block on each exposed devis section in a wrap around manner and apply masking tape (C143) to hold in place. Refer to figure 2-58.
- d. Apply enough sealing compound (C130), to fill recessed void around the devis base above the restraining urethane foam in a sufficient amount to flow about 1/8 inch deep to each screw plate fastener.

#### NOTE

For this application only, drycleaning solvent (C62) may be added to sealant. This practice Is specifically prohibited In other applications. Mix 100 parts by weight of base compound, 10 parts by weight of accelerator, and 12 parts by weight of ethylene glycol monobutyl ether (C63). Carefully fold material for five minutes. Avoid violent agitation and air entrapment. Skin contact should be avoided.

#### 2-140 Change 24




Figure 2-58. Pylon Isolation Mount Repair




Figure 2-59. Pylon Isolation Mount (P/N 206-030-539-5 and -101)

- **(e)** Allow compund to cure **48** hours. Inspect for edge separation attributable to excessive shrinkage. Also inspect for voids attributable to solvent, or air entrapment. Once compound has cured urethane foam should be carefully cut free from sealant and remove. Removal of urethane foam will facilitate subsequent inspection for leakage.
- (f) Isolation mount is ready for installation following sealing compound cure and inspection.
- **(6)** Loose bottom plates may be rebonded to mount using adhesive (C19) or equivalent. Ensure surfaces to be bonded are thoroughly cleaned with MEK (C107) prior to application of bonding adhesive (C19).
  - **b.** Repair transmission mount support as follows:
    - (1) Dress out dents and gouges, etc.
    - (2) Repaint as necessary.
- 2-297. Cleaning Pylon Isolation Mount and Transmisdon Mount Support. Except in cases of prolonged oil saturation and damage as indicated by crazing, cracking, separation, and softness, oil may be wiped clean after removal of mount from helicopter. Use a clean, dry cloth, or a cloth dampened with a mild solution of cleaning compound (C43). Do not immerse. Cleaning solution must be completely removed with clean water and mount dried thoroughly prior to reinstallation. Transmission mount support will be wiped clean with rag, and oil removed from oil pan with a rag, sponge, or any suitable means.

# **2-298.** Installation — Pylon Isolation Mount and Transmission Mount Support.

**a.** Install pylon isolation mount (figure 2-57) as follows:

Early Isolation Mounts (P/N 206-030-639-3) had two washers bonded to inside faces of clevis in lieu of machined bosses. Do not install isolation mount on helicopter without these washers in place.

(1) Wipe oil and dirt from mount and mount area with a clean, dry cloth.

#### NOTE

Identify bolt (4, figure 2-57) when removed from installation in same location because the bolts may be of different lengths.

- (2) When shims are not bonded, they may be rebonded using adhesive (C19). Clean surfaces with MEK (C107). Apply a small amount of adhesive around outside edges of shims and bond in place. Adhesive should not be applied under or between shims as this would increase thickness.
- (3) Position isolation mount (figure 2-57 or 2-59) on cabin roof and insert bolts (4, figure 2-57) through mount and roof into nut plates. Torque bolts 50 TO 70 INCH-POUNDS and lockwire (C96).
- (4) Insert bolt (1) with washer (2) through right side of isolation mount clevis (13) and drag pin (14). Install washer (2) and nut (9) and torque 480 TO 690 INCH-POUNDS. Secure with cotter pin (10).
- **(5)** Apply a thin bead of sealing compound (C131) to form a seal between mount and cabin roof. (Isolation mount P/N 206-030-539-3 only).
- (6) Install upper cabin roof beam cover using eight screws and washers,
  - (7) Fasten upper roof blanket assembly.
- (8) Reinstall transmission assembly, main driveshaft assembly, etc.
  - **b.** Install transmission mount support as follows:
    - (1) Remove debris from mounting surface.
- (2) Position static stop on upper cabin roof and align mounting holes,
- (3) Insert six bolts with one washer on each bolt into mounting hole.
- (4) Install six nuts, one on each bolt, via opening in upper cabin roof beam.
- (5) Install upper cabin roof beam cover using eight screws and washers,
  - (6) Fasten upper roof blanket assembly.
- (7) Reinstall transmission assembly, main driveshaft assembly, etc.

#### 2-299. TRANSMISSION SUPPORT STRAPS.

**2-300. Description.** There are four transmission support straps which transmit and distribute loads from the pylon and pylon supports to the cabin roof beam and the associated support structure. After removal of cabin roof sound-proof blanket the two forward support straps are readily visible. The aft support straps are visible only after removal of structural panels. Refer to figure 2-60.

#### 2-301. Inspection — Transmission Support Straps.

- **a.** Inspect the two forward support straps for cracks especially in critical area. Refer to figure 2-60.
- **b.** Remove structural panels (1 and 2) and inspect the two aft support straps especially in critical areas.

#### NOTE

The most critically loaded is the left rear support strap.

#### 2-302. ENGINE MOUNTS.

**2-303. Description** — **Engine Mounts.** The engine mounts (figure 2-61) are attached to the top of the engine deck. Alignment of the engine is accomplished using shims under each leg of each mount.

### 2-304. Inspection — Engine Mounts.

- **a.** Inspect mounts for movement or damage to legs. Bends, bolt hole elongation, and cracks are cause for immediate replacement of legs.
- **b.** Check for nicks, gouges, scratches, or chafing on the tube area of the mounts.

### 2-305. Removal — Engine Mounts.

### WARNING

Engine must be supported during replacement of one or more of the mounts.

#### **CAUTION**

If engine mounts are removed, do not remove the bonded shims. These shims

directly affect engine to transmission alignment. If removal is required, mark the shims for propar location and to prevent loss or intermixing. Loose shims will be immediately rebonded back in place using adhesive (C19) or equivalent. In the event any shims become lost, a complete fuselage alignment must be accomplished to determine the proper thickness of the shims. "Loss or intermixing of shims will require depot maintenance for engine alignment. This task requires special factory tooling."

- **a.** Remove anti-ice control and install engine lift tool (T40) on anti-icing control pad and connect to hoist. Apply only enough lift to hold engine in place.
- **b.** Disconnect hose clamps attaching hardware to mounts.
- **c.** Remove structural panels above electrical shelf (figure 2-60).
- **d.** Remove bolts (4), washers (5 and 6), and nuts (7, figure 2-61) attaching engine mounts to airframe. Discard nuts (7).
- **e.** Remove mounts from service desk making sure that shims do not come loose from deck.

#### 2-306. Inspection — Engine Mounts.

- **a.** Inspect engine mount and weld areas using magnetic particle inspection. Refer to TM 55-1500-335-23.
- (1) Inspect engine mount legs (1 and 2, figure 2-61) using direct electrical contact with copper braided pads, magnetized at 800 amperes.
- (2) Inspect with longitudinal field at 4,000 ampere-turns.
- **b.** Check for wear or elongation of bolt holes and spindle attaching hole. Maximum bolts hole diameter 0.255 inches, maximum spindle hole diameter 0.380 inches. Inspect engine mount (figure 2-63).
- **c.** Check for wear of the airframe bolt holes by checking for side play between mount and airframe around the bolt. Bolt must be finger loose for this





Figure 2-60. Transmission Mount Support and Access (Sheet 1 of 3)



UPPER CABIN ROOF BEAM INSTALLATION - REF

206032-60-2

Figure 2-60. Transmission Mount Support and Access (Sheet 2)





Figure 2-60. Transmission Mount Support and Access (Sheet 3)



- 1. Side Mounts
- 2. Lower Mount
  3. Shims (Permanent) (6 places)
  4. Bolt (Typical 6 places)

- 5. Washer (Typical 6 places)
- 6. Washer (Typical 6 places)7. Nut (Typical 6 places)

Figure 2-61. Engine Mounts




Figure 2-62. Engine Mount Leg — Wear and Damage Limits



# 206-061-104-3 ENGINE MOUNT FITTING

# DAMAGE LOCATION SYMBOLS

TYPE OF DAMAGE	MAXIMUM E	DAMAGE AND REPAIL	R DEPTH			
MECHANICAL	0.005 in.	∑ 0.010 in.	0.050 in.			
CORROSION	0.003 in.	0.010 in.	0.025 in.			
MAXIMUM AREA PER FULL DEPTH REPAIR	20% of area	10% of surface area	25 % of area			
EDGE CHAMFER	0.010 in.	0.020 in.	0.030 in.			
NOTE: Applicable for both sides of flange threads.  Thread damage that does not exceed a depth of one-third of thread and length of one-quarter inch (one damage per bolt) is acceptable.						

206061-93

Figure 2-63. Engine Mount — Wear and Damage Limits

check. Maximum side play is **0.010** inches. If excessive play is present due to airframe wear, engineering approval is required for a special repair.

2-307. Repair – Engine Mounts. See figures 2-62 and 2-63.

### 2-308. Installation — Engine Mounts.

a. Position mount legs over shims and secure with bolts, two washers, and new nut. Length of bolt holding mount leg to airframe is determined by thickness of shims. Refer to table 2-3. Attach engine mount to engine mount fittings. Refer to paragraph 4-22.

Table 2-3. Engine Mount Leg Attaching Bolts

SHIM THICKNESS	BOLT SIZE
FWD LEGS:	
0.190 to 0.077 in.	AN174-6A
(0.50 to 0.20 ems)	
0.076 to 0.000 in.	AN174-5A
(0.20 to 0.000 ems)	
REAR LEGS	
0.190 to 0.098	AN174-6A
(0.50 to 0.25 ems)	
0.097 to 0.000 in.	AN174-5A
(0.25 to 0.00 ems)	
LOWER LEGS:	
0.190 to 0.087 in.	AN174-10A
(0.50 to 0.22 ems)	
0.086 to 0.000 in.	AN174-7A
(0.21 to 0.00 ems)	

### b. Torque nut to 90 INCH-POUNDS

### NOTE

Two different type nuts may be found on this installation; the earlier NAS679 (sheet metal stamped) and the later MS21042 (forged). While either nut is acceptable, the reduced hex (0.3125 inch wrenching nut) MS21042 is

preferred. Neither nut may be reused in this application and both require retorque after the first 50 hours of operation. Nuts need not be replaced at retorque. This special application has taken into account tare or drag torque. Torque wrench reading must be 90 INCH-POUNDS.

- **c.** Install hose clamp into the same area from which removed.
- **d.** Lower hoist to slacken cable and remove lift tool.
  - e. Install anti-ice control.

### 2-309. SEAL FILLER ASSEMBLY.

**2-310.** Description — Fire Suppressant Foam Assemblies, Two foam assemblies are located on the aft side of the bulkhead at FS130. The larger foam assembly is in the avionics compartment. The other assembly is below the floor. These foam assemblies reduce the fire hazard if incendiary rounds penetrate the fuel cell from the rear.

### 2-311. Removal — Seal Foam Assembly.

- a. Upper foam assembly —disconnect the battery and remove two cord assemblies. Disconnect wires on the battery relay then disconnect battery vent lines. Remove foam assembly. Some helicopters have an AN/ARC-51 radio installed on a shelf mounted against the upper part of the bulkhead. The foam assembly may be removed from these helicopters by cutting the foam upward from a point midway along the cutout for the radio mount bracket and folding the sides. Seal all cuts with sealing compound (C131). Equivalent methods may be used to remove the foam assembly. However, do not cut the assembly in any manner that permits removal of a section of foam material.
- **b.** Lower foam assembly remove the radio antenna under the avionics compartment floor and remove cord assembly. Remove foam assembly.
- **2-312.** Inspection Seal Foam Assembly. Inspect foam assemblies for cuts, tears, and water saturation.
- **2-313.** Repair Seal Foam Assemblies. Air dry and cover tears with sealing compound (C131).

### 2-314. Installation - Seal Foam Assemblies.

- a. Upper foam assembly sprinkle talcum powers (C135) on forward side of the foam assembly and mount against bulkhead at FS 130 in the avionics compartment. Secure the two cord assemblies and attach the relay leads and vent lines. Ensure that the scarf on the forward battery vent line faces forward and the scarf on the aft vent line faces aft. Connect battery. For those aircraft with the AN/ARC-51 radio installed on a shelf mounted against the bulkhead, new foam assemblies must be reworked (figure 2-64). In addition, they may be cut to permit installation. Cut the foam upward from a point midway along the cutout for the radio mount bracket and fold the sides to install the assembly. Before sealing the assembly, mount the foam assembly in the aircraft to ensure that the length of cut is adequate for installation without cracking the protective seal on the outside surface. Some additional cutting may be required. Do not cut the foam assembly in any manner that permits removal of a section of foam material. Remove and seal all cut areas with sealing compound (C131).
- **b.** Lower foam assembly sprinkle talcum powder (C135) on forward side of the foam assembly and mount against the bulkhead at FS 130 below the avionics compartment floor. Secure cord assembly and replace the antenna. Connect battery,

### NOTE

The upper and/or lower fire suppressant foam assemblies may be removed in noncombat areas at the discretion of the unit commander. Applicable weight and balance changes shall be made to the helicopters Weight and Balance Records. Removed foam assemblies and cords will be retained as flyaway equipment and appropriately marked.

# 2-315. LANDING GEAR SUPPORT FITTINGS.

**2-316. Description -** Four identical landing gear fittings are bolted to the lower fuselage. These fittings are used to install the landing gear and the float landing gear.

**2-317.** Removal — Remove the bolts, nuts, and washers, securing the fittings to the airframe. Note that the bolts are not all the same length.

### 2-318. Inspection.


- a. Corrosion cannot effect more than 20% of surface area.
- **b.** Corrosion pits cannot be wider than **0.060** inch and must be separated by at least **0.200** inch.
- **c.** Wear on the fittings caused by contact and chafing from rivet collars on the landing gear cannot exceed **0.025** inch.

### 2-319. Repair.

- a. Strip fitting and remove corrosion using an aluminum oxide cloth (C45). (Do not use ferrous materials on aluminum.) Not more than 10% of local thickness can be removed.
- **b.** Remove all burrs and sharp corners created by damage to the fitting.
- **c.** Clean repaired area with Turco (C21), then treat with alodine (C38) and reprime with primer (C116).
  - d. A corroded area may be repaired only once,

### 2-320. Installation.

- **a.** Use proper length of bolt and install nuts when required. Ensure bolts are installed in correct location, Install a washer under the head of each bolt and under each nut.
- **b.** Apply a thin bead of sealant (C129) to the mating surfaces of the fitting and airframe in order to prevent water from entering the fitting recessed areas.



NO SCALE 206032-142

Figure 2-64. Rework Necessary if AN/ARC-51 is Mounted to Bulkhead, Seal, Foam Assembly (Fire Suppressant Foam Assemblies)

### SECTION IV. WING

(Not applicable)

### SECTION V. EXTRUSION CHART

(Not applicable)

### SECTION VI. WIRE STRIKE PROTECTION SYSTEM

# 2-321. WIRE STRIKE PROTECTION SYSTEM (WSPS).

### NOTE

WSPS configuration designated A also applies to OH-58C (Round Glass). WSPS configuration designated applies only to OH-58C (Flat Glass).

2-322. Description - WSPS (Figure 2-65) Figure 2-66 The WSPS provides protection against impacts with horizontally strung mechanical and power transmission cables. The basic system consists of an upper cutter/deflector, a windshield protector/deflector/cutter, and a lower cutter/deflector.

# 2-323. SAWTOOTH BLADES, CUTTER DEFLECTORS (UPPER AND LOWER).

- 2-324. Description Sawtooth Blades, Cutter Deflector Upper and Lower. The sawtooth blades (1 and 8, figure 2-65 A) and (1 and 8, figure 2-66 C) provide abrasion of wires leading into primary wire cutting blades.
- 2-325. Inspection Sawtooth Blades, Cutter Deflector, (Upper and Lower). Inspect the sawtooth blades (1 and 8; figure 2-65 A) and (1 and 8, figure 2-66 C) for impact damage and/or shedding of the rubber coating. Sawblades with missing or damaged teeth (one or more) are to be replaced without repair.
- 2-326. Removal Sawtooth Blades, Cutter Deflector (Upper).
- a. Remove rivets (1, figure 2-67 A) (9, figure 2-77 C retaining sawblade.

- **b.** Remove upper sawblade (2, figure 2-67 **A**) (10, figure 2-77 **C**).
- **2-327.** Removal Sawtooth Blades Cutter Deflector (Lower).
- **a.** Remove rivets (1, figure 2-67) retaining sawblades.
- **b.** Remove sawblade (3) and clean sealant residue. Refer to TM 43-0105.
- 2-328. Repair Sawtooth Blades, Cutter deflector (upper and lower). Damaged or missing rubber coating due to deterioration can be replaced using sealing compound (C130).
- 2-329. Installation Sawtooth Blades Cutter Deflector (Upper).
- a. Install sawblade (2, figure 2-6 A (10, figure 2-77 C) with teeth facing cutter throat.
- **b.** Install rivets (1, figure 2-67 (9, figure 2-77))
- c. Mask aluminum deflector on each side of the sawblade and coat sawblade teeth with a minimal application of sealing compound (C130). Allow sufficient time for sealing compound to set before removing masking.
- 2-330. Installation Sawtooth Blades, Cutter Deflector (Lower).
- **a.** Install sawblade (3, figure 2-67) with teeth facing cutter throat.
  - **b.** Install rivets (1).




Figure 2-65. Wire Strike Protection System (WSPS) Configuration A




Figure 2-66. Wire Strike Protection System (WSPS) Configuration




Figure 2-67. Removal - Sawblade, Cutter Deflector (Upper and Lower)

- c. Mask aluminum deflector on each side of sawblade and coat the sawblade teeth with a minimal application of sealing compound (C130). Allow sufficient time for the sealing compound to set before removing masking.
- **d.** Prime/paint as required. Refer to TM 55-1500-345-23,

# 2-331. CUTTER BLADES (UPPER AND LOWER).

- **2-332.** Description Cutter Blades (Upper and Lower). The cutter blades (3 and 7, figure 2-65 A, 3 and 7, figure 2-66 ) provide the primary wire cutting mechanism, consisting of wedge type cutting blades positioned to provide the necessary mechanical advantage to cut the wires/cables while minimizing load input into the airframe.
- 2-333. Inspection Cutter Blades (Upper and Lower). Inspect the cutting blades for evidence of reduced sharpness due to nicks, abrasions and/or shedding of the rubber coating. Blades with any nicks or abrasions on the cutting edge are to be replaced.

### 2-334. Removal - Cutter Blades (Upper).

- a. Remove capscrews (1, figure 2-68 A (1, figure 2-78 C, washers (2) and nuts (3) of the blade to be removed. Cutter throat blade removal may require removal of entry guide blade(s) (4, figure 2-68 A 4, figure 2-78 C),
- **b.** Remove entry guide blade(s) (4, figure 2-68 **A**, 4, figure 2-78 **C**), and cutter blades (8) from the cutter assembly, noting position of shims (5, figure 2-68 **A**, 5, figure 2-78 **C**) and (9) (shims may have been utilized to centralize the cutter blades).
- **c.** Clean sealant from the shim(s) and cutter assembly. Refer to TM 43-0105.

### 2-335. Removal - Cutter Blades (Lower).

- **a.** Remove capscrews (1, figure 2-68), washers (2) and nuts (3) of the blade to be removed.
- **b.** Remove entry guide blades (6) and cutter blades (10) from the cutter assembly, noting position of shims (7) and (11) (shims may have been used to centralize the cutter blades).
- c. Clean sealant from the shim(s) and cutter assembly. Refer to TM 43-0105.

**2-336.** Repair - Cutter Blades (Upper and Lower). Damaged or missing rubber coating due to deterioration can be replaced by applying a thin coat of sealing compound (C130).

### 2-337. Installation - Cutter Blades (Upper)

- a. Apply sealing compound (C130) to the entry guide blades (4, and cutter blades 8, figure 2-68 A and figure 2-78 C) and (8) and position in cutter assembly (12, figure 2-68 A, figure 2-78 C) shims must be installed on the same side of the blade noted during removal.
- b. Install capscrews (1, figure 2-68 A, figure 2-78 washers (2), and nuts (3), Where cutter throat blades have been removed check gap of junction of aft portion of cutter throat blades maximum allowable gap is 0.020 inch.
- c. Clean excess sealant and prime as required. Refer to TM 55-1500-345-23.

### 2-338. Installation - Cutter Blades (Lower).

- **a.** Apply sealing compound (C130) to the entry guide blades (6, figure 2-68) and cutter blades (10) and position in cutter assembly (13) shims must be installed in the same side of the blade noted during removal.
- **b.** Install capscrews (1), washers (2), and nut (3) where cutter blades have been removed. Check gap of junction of aft portion of cutter throat blades maximum allowable gap is **0.020** inch.
- **c.** Clean excess sealant and prime/paint as required. Refer to TM 55-1500-345-23.

# 2-339. STRUT ASSEMBLIES (UPPER AND LOWER).

2-340. Description - Strut Assemblies (Upper and Lower). The strut assemblies (2, figure 2-64 A) 2, figure 2-66 (9) and (9) provide the necessary lateral support to the cutter/deflector assemblies during asymetric loading.

# 2-341. Inspection - Strut Assemblies (Upper and Lower).

a. Inspect the strut assemblies for paint deterioration, superficial paint scratches, and light corrosion. No moderate or heavy corrosion allowed,




Figure 2-68. Removal — Cutter Blades (Upper and Lower)

- **b.** Inspect the strut assemblies for cracks particularly in the welded areas and the formed tab ends. Strut assemblies showing evidence of any cracks must be replaced.
- c. Inspect the strut assemblies for deformation at the strut/deflector attachment area and the foot pad area. Strut assemblies showing evidence of permanent deformation must be replaced.
- **d.** Inspect strut assemblies for tube straightness. Maximum allowable bow over strut length is **0.060** inch. Strut assemblies exceeding this maximum must be replaced.
- **e.** Inspect the security of the strut assemblies. Loose rivets must be replaced.

### 2-342. Removal — Strut Assembly, Upper.

- **a.** Remove rivets (1, figure 2-69) securing strut assembly foot pads to the aircraft.
- **b.** Remove strut attachment bolt (3, figure 2-69) washers (4) and nut (5).

Clean sealant from strut assembly foot pads. Refer to TM 43-0105.

### 2-343. Removal — Strut Assemblies, Lower.

- **a.** Remove rivets (2, figure 2-69) securing strut assembly foot pads to the doubler (8). To remove the lower strut assembly foot pad rivets, the lower cutter assembly must be removed from the aircraft. Refer to paragraph 2-337.
- **b.** Remove strut attachment bolt (3), washer (4), and nut (5).

Clean sealant from strut assembly foot pads. Refer to TM 43-0105.

### 2-344. Repair — Strut Assemblies.

- a. Paint deterioration or superficial paint scratches in accordance with TM 55-1500-345-23.
- ${f b.}$  Light corrosion clean and repair area as per TM 43-0105.

### 2-345. Installation — Strut Assemblies, Upper.

- **a.** Attach strut assemblies (6, figure 2-69), to the cutter assembly, using strut attachment bolt (3), washer (4), and nut (5).
- **b.** Apply sealing compound (C129) to the strut feet. Reposition the struts and rivet the feet into position. Reinstall and tighten **strut attachment bolt** (3), washer (4), and nut (5).

### 2-346. Installation — Strut Assemblies, Lower.

- **a.** Attach strut assemblies (7, figure 2-69) to the cutter assembly, using strut attachment bolt (3), washer (4), and nut (5).
- **b.** Locate each strut foot, position over holes and mark through from underneath. Remove and drill holes. Clean and deburr.
- **c.** Reposition the struts and rivet feet into position. Reinstall and tighten strut attachment bolt (3), washer (4), and nut (5).
- **d.** Prime/paint as required. Refer to TM 55-1500-345-23.

### 2-347. UPPER CUTTER ASSEMBLY.

2-348. Description — Upper Cutter Assembly, The mechanical cutter/deflector consists of a sawtooth equipped deflector section (1, figure 2-65 A, figure 2-66 C, providing deflection/abrading feature leading into the primary cable cutting mechanism-wedge type cutting blades (3, figure 2-65 A, 3, figure 2-66 C), positioned to provide the necessary mechanical advantage to cut the wires/cables while minimizing load input into the airframe.

### 2-349. Inspection - Upper Cutter Assembly.

- **a.** Inspect the cutter assembly for paint deterioration, superficial paint scratches, and light corrosion. No moderate or heavy corrosion allowed, Scratches, nicks, or gouges, to a depth of **0.010** inch may be repaired.
- **b.** Inspect the sawblade. Refer to paragraph 2-325.

Inspect the cutter blades. Refer to paragraph 2-333.




Figure 2-69. Removal - Strut Assemblies (Upper and Lower)

- **d.** Inspect the deflector assembly for cracks and permanent deformation. Deflector assemblies showing evidence of any cracks and/or permanent deformation must be replaced. Scratches, nicks, and gouges to a depth of 0.010 inch may be repaired.
- e. Inspect the security of the upper cutter assembly. Loose rivets must be replaced.
- **f.** Inspect the surrounding support structure for evidence of permanent deformation. If permanent structural deformation exists replace the entire cutter assembly.

### 2-350. Removal - Upper Cutter Assembly.

- **a.** Remove forward lower entry guide blade (1), shim (2, figure 2-70 **A**, figure 2-79 **C**), per paragraph 2-334.
- **b.** Remove strut attachment bolts (3, figure 2-70 A figure 2-79 C ) washers (4), and nut (5) from deflector.
- c. Remove lower mounting capscrews (6, figure 2-70 A figure 2-79 C) washers (7), and nuts (8).
- **d.** Remove the cutter assembly (9, figure 2-70 **A**, figure 2-79 **C**) noting position of shims (10), if installed.
- **e.** Clean sealant from shims (10) mounting channel (11) and cutter assembly (9, figure 2-70 A figure 2-79 C), Refer to TM 43-0105.

### 2-351. Repair — Upper Cutter Assembly.

- a. Paint deterioration or superficial paint scratches in accordance with TM 55-1500-345-23.
- **b.** Light corrosion Clean and repair area in accordance with TM 43-0105.
  - c. Sawblade Refer to paragraph 2-328.
  - d. Cutter blades Refer to paragraph 2-336
- **e.** Using sandpaper (C106) remove scratches to maximum depth of 0.010 inch. Prime/paint in accordance with TM 55-1500-345-23.

### 2-352. Installation - Upper Cutter Assembly.

- a. Position the cutter assembly (9, figure 2-70 A, 9, figure 2-79 into the top end of the channel (11), Check the gap between the outer sides of the channel and the cutter assembly cheek plates. Shim as required, Ensure that the cutter assembly is positioned centrally within the channel and perpendicular to the airframe. Ensure the back of the cutter is flush with the end of the channel and that the front end is pushed down and bottoming in the channel
- **b.** Locate the second hole from the forward end of the cutter cheek plate (12) and drill through the cheek plate (12) and through the channel (11). Align using a capscrew (6).
- **c.** Pull the cutter back until it bottoms in the channel and drill through the cutter cheek plates (12) and channel (11) at the aft lower hole position. Align using a capscrew (6).
  - d. Drill the remaining cutter attachment holes
- **e.** Remove, clean, and deburr the cutter assembly.
- **f.** Apply sealing compound (C131) to cutter assembly (9), and shims (10). Use sealing compound (C129) on airframe doubler mounting surfaces, Position cutter and shims. Install capscrews (6), washers (7), and nuts (8).
  - g. Clean off excess sealant.
- **h.** Install strut attachment bolt (3), washers (4), and nut (5).
- i. Install forward lower entry guide blade (1) and shim (2). Refer to paragraph 2-337.
- j. Prime/paint in accordance with TM 55-1500-345-23.

### 2-353. DOUBLERS, UPPER CUTTER.

### 2-354. Description — Doublers.

The doublers (5, figure 2-65 **A**, 5, figure 2-66 **C**) provide additional structural support, distributing wire cutting loads to the canopy frame members.




Figure 2-70. Removal — Upper Cutter Assembly

### 2-355. Inspection — Doublers.

- a. Inspect the doublers for paint deterioration, superficial paint scratches, and light corrosion. No moderate or heavy corrosion allowed. Scratches, nicks, or gouges to a depth of 0.006 inch may be repaired.
- **b.** Inspect the doublers for cracks and permanent deformation. Doublers showing evidence of any cracks and/or permanent deformation must be replaced.
- c. Inspect the security of the doubler. Loose rivets must be replaced.

### 2-356. Removal — Doublers.

- a. Remove strut assemblies (1, figure 2-71 A 1, figure 2-77 C) as per paragraph 2-342.
- **b.** Remove 5 A and 3 C aft capscrews (6), washers (7), and nuts (8).
- Remove left and right side upper soundproofing blankets.
- d. Cover windshield and overhead windows with suitable material to prevent damage. Mask edges.
- e. Remove the FM ARC114 antenna. Mask mounting holes.




Figure 2-71. Removal – Doublers A

f. Cover back of circuit breaker panel with suitable material to prevent metal particles from entering electrical area. Mask over cable access holes to instrument panel and the ram air inlet grill.

## CAUTION

Care must be exercised when drilling out rivets to prevent damage to electrical wiring.

- a. Remove doubler rivets (3).
- **h.** Remove doubler (4 and 5, figure 2-71  $\mathbf{A}$ , figure 2-77  $\mathbf{C}$ ).
- i. Clean sealant from the helicopter. Refer to TM 43-0105.

### 2-357. Repair - Doublers.

- a. Paint deterioration and/or superficial paint scratches in accordance with TM 55-1500-345-23.
- **b.** Light corrosion Clean and repair area as per TM 43-0105.
- **c.** Using sandpaper (C124) remove scratches to a maximum depth of 0.006 inch. Prime/paint in accordance with TM 55-1500-345-23.

### 2-358. Installation - Doublers.

- a. Position doublers (4 and 5) so that flanges cover the five aft bolt holes (figure 2-71 A) and three aft bolt holes (figure 2-77 C) in the cutter assembly (2, figure 2-71). Ensure that edge distance is maintained.
- **b.** Trim the doubler flanges as required to match cutter assembly and to clear the FM ARC 114 antenna base.
- c. Position one doubler and holding firmly in place, drill the forward hole through the doubler flange by back drilling through the cutter cheek plates (9). Repeat for other doubler. Secure doublers in place using capscrew (6) and nut (8).
- **d.** From inside the cockpit area, locate and mark the FM ARC 114 antenna cable access holes. Locate all other rivet holes with a hole finder and drill.

- **e.** Remove one doubler and with the other doubler held firmly in position with clecos, drill the four (A) two C) remaining holes in the doubler flange by back drilling through the cutter cheek plates. Repeat for other doubler.
- **f.** Remove the doublers. Cut and dress the antenna cable access hole and enlarge the antenna mounting bolt holes. Clean and deburr.
- g. Apply sealant (C129) to the base of the doubler and position using cleco fasteners. Install the five aft capscrews (6) and three aft capscrews (6), washers (7), and nuts (8). Install rivet fasteners (3).
- **h.** Clean access sealant from the doubler. Refer to TM 43-0105.
- i. Install the FM ARC 114 antenna. Apply sealing compound (C130) around the base of the antenna.
  - i Install strut assemblies as per paragraph 2-345.
- k. Prime/paint in accordance with TM 55-1500-345-23.
- I. Remove the circuit breaker panel and glareshield covering and thoroughly clean up the cockpit interior.
- **m.** Remove the windshield and overhead window covering, close the circuit breaker panel and reinstall soundproofing blankets.

# 2-359. WINDSHIELD DEFLECTOR ASSEMBLY.

2-360. Description — Windshield Deflector Assembly. The windshield protector/deflector/cutter, consisting of a sawtooth equipped aluminum extrusion, provides deflection mechanism into the upper cutter while simultaneously abrading thus weakening the wire/cable and provides additional structural support for the upper cutter mounting.

# 2-361. Inspection — Windshield Deflector Assembly.

a. Inspect the deflector assembly for paint deterioration, superficial paint scratches, and light corrosion. No moderate or heavy corrosion allowed. Scratches, nicks, or gouges in the channel and/or insert only to a depth of **0.010** inch maybe repaired,

- **b.** Inspect the security of the windshield deflection system paying particular attention to the clips at the base of the windshield, If clips or windshield deflector components show evidence of any cracking or permanent deformation due to impact they must be replaced. Inspect for gaps between the clips and the base of the windshield. No gaps are permitted; trim and/or replace as required. Inspect the sawtooth blade for impact damage and/or shedding of rubber coating. Sawblades with missing or deformed teeth (one or more) shall be replaced.
- **c.** Inspect the windshield deflector, Figure 2-65 item 4, to make sure it is properly installed:
- (1) Inspect the base of the deflector to make sure the channel, Figure 2-72 item 10, does not extend past the angle clip, Figure 2-72, item 12.
- (2) Inspect the base of the deflector to make sure the insert, Figure 2-72 item 4, does not extend past the angle clip, Figure 2-72 item 12.
- (3) If either the channel or the insert extends past the angle, the affected part must be reworked. See Figure 2-72.1, Detail A, for a correctly installed assembly.
- 2-362. Removal Windshield Deflector Assembly. Refer to paragraphs 2-365 and 2-367,

### 2-363. Repair - Windshield Deflector Assembly.

- **a.** Paint deterioration or superficial paint scratches in accordance with TM 55-1500-345-23.
- **b.** Light corrosion -Clean and repair area as per TM 43-0105,
  - c. Sawblade Refer to paragraph 2-328.
- **d.** Using sandpaper (C124) remove scratches to a maximum depth of **0.010** inch. Prime/paint as required in accordance with TM 55-1500-345-23,
- 2-364. Installation Windshield Deflector Assembly. Refer to paragraphs 2-366 and 2-368.

### 2-365. Removal - Sawtooth Insert.

- a. Remove insert retaining screws (1), washers (2) and nuts (3) (figure 2-72 A) retaining screws (12), washer (13), and nuts (14) (figure 2-79 C
- **b.** Remove insert assembly  $(4\mathbf{A})$  (15 **C** from channel 10) **A** (11). **C**

### 2-366. Installation - Sawtooth Insert.

- a. Position insert assembly (4, figure 2-72 A). (15, figure 2-79 into channel (10) A and (11) C. Ensure assembly is bottoming in the channel and the mounting holes are aligned.
- **b.** Install insert retaining screws (1), washers (2), and nuts (3) **A** and retaining screws (12), washers (13), and nut (14) **C** Note sawteeth should face forward.

Prime/paint as required. Refer to TM 55-1500-345-23.

- **2-366.1. REWORK SAWTOOTH INSERT.** If insert (Figure 2-72, item 4) is found to extend 'beyond channel (Figure 2-72.1, Detail C), rework the parts as described below:
- **a.** Inspect the Channel (Figure 2-72, item 10) to make sure it does not extend past the angles (Figure 2-72, item 12). If the channel extends past the angles rework the channel first, refer to paragraph 2-361 (C).
- **b.** Scribe a line at the end of insert, flush with the end of the channel.
- **c.** Remove screws retaining the insert in the channel. Remove insert from channel.
- **d.** Trim end of insert to line so that it no longer protrudes.
- **e.** Prime and paint rework area of insert to match existing finish.
  - f. Re-install insert using existing fasteners.


### 2-367. Removal - Channel.

- **a.** Remove insert assembly as described in paragraph 2-365,
- **b.** Remove upper cutter assembly as described in paragraph 2-350.
- **c.** Cover windshield and overhead windows with suitable material to prevent damage. Mask edges,
- **d.** Remove all cable clamps from the wire bundles running down the windshield center post and the forward clamp on the circuit breaker panel. Lower bundles as far as possible without disconnecting.


- e. Cover back of circuit breaker panel with suitable material to prevent metal particles from entering electrical area. Mask over cable access holes to instrument panel and the ram air inlet grill.
- f. Remove rivet (5, figure 2-72 A, (16, figure 2-79 C) at lower end and rivets (6) A and (17) at the upper end of channel (10) A and (11) C
- g. Remove channel attachment screws (7), washers (8), nuts (9), remove channel (10) . Remove channel attachment rivets (16) and channel (11)
- h. Remove rivets (11)-A and (18) C retaining lower angle clips and remove clips (12) A and (19) C
- i. Clean sealant from helicopter, angle clips, and channel. Refer to TM 43-0105.

### 2-368. Installation — Channel A.

- **a.** Using a template and a hole finder, locate and drill the lower twelve holes in the windshield center post through the template.
- **b.** Position the template on channel (10, figure 2-72) and transfer the holes from the template to the channel section.
- **c.** Position the channel (10) using cleco fasteners. Ensure channel is centrally located. Back drill the remaining holes in the channel.
- **d.** Countersink to accommodate retaining screws (7).



DETAIL A



206900-554

Figure 2-72. Removal – Sawtooth Insert/Channel Assembly Deflector Assembly A

- e. Locate existing rivet hole at lower end of channel. Countersink to accommodate NAS rivet.
- **f.** Locate existing holes (2 each) at upper end of channel, Countersink to accommodate NAS rivet.
- g. Remove the channel (10), deburr, and clean out all metal particles. Reposition the channel using screws as temporary dowel pins. Trim lower end of channel to clear ram air inlet grill as required, Trim upper end of channel to match cutter assembly/doubler as required.
- **h.** Apply a bead of sealing compound (C131) to channel (10) along its entire mounting surface to prevent entry of water between the channel and the retainer.

### NOTE

Examine windshield retainer for signs of separation from the windshields. If separation exists remove the retainer and reseal using sealing compound (C130). Allow sealant to cure until tack free.


- i. Install the channel (10) using screws (7), washers (8), and nuts (9). Start at the lowerendof the channel and work up.
- **j**. Install rivet (5) at lower end of channel applying sealing compound (C131) under the head.
- **k.** Install rivets (6) at the upper end of the channel using extension piece shown in figure 2-76. Apply sealing compound (C131) under the heads.
- I. Position lower angles (12) firmly against the channel (10) and using a hole finder locate the six lower windshield retaining strip rivet positions and drill through. Remove, clean, and cleco one angle into position and locate the three holes in channel (10). Remove and drill through. Repeat for other angle. Apply sealing compound (C131) to the angle mounting surfaces and install the angles.
- **m.** Clean excess sealant from channel (10) and angle clips (12), Refer to TM 43-0105.
- **n**. Install upper cutter assembly as per paragraph 2-352, steps f. through j.
- **o.** Install insert assembly, Refer to paragraph 2-366.

- **p**. Prime/paint as required. Refer toTM 55-1500-345-23.
- q. Install wire/cable clamps using existing hardware and reposition the wire bundle. Remove the circuit breaker panel and glareshield covering and thoroughly clean up the cockpit interior to remove all metal particles.
- r. Remove the windshield and overhead window covering and close the circuit breaker panel.
- **2-368.1. REWORK CHANNEL.** If the channel (Figure 2-72, item 10) is found to extend beyond angles (Figure 2-72, item 12) rework the parts as described below:
- **a.** Remove screws (items 1, 2, 3) retaining the insert in the channel (item 10). Remove insert from channel.
- **b.** Scribe a line at the end of the channel flush with the end of the tie down angles.
- **c.** File channel until it is flush with the end of the angles.
- **d.** Prime and paint the rework area to match existing finish.
- **e.** Reinstall insert and visually inspect to ensure that it does not protrude above channel as outlined in paragraph 2-366.1. If condition exists, rework in accordance with instructions in paragraph 2-366.1.
- **f.** Refer to Figure 2-72.1, Detail B, for an example of an incorrectly installed channel.

### 2-369. Installation - Channel C.

- **a**. Position channel (11, figure 2-79) on windshield centermost, File lower end of channel (11) as required to ensure that end is flush on helicopter, Trim the upper end of channel (11) to maintain **0.100** inches from antenna base, If channel step lower end does not butt against lower edge of centermost retaining strip, mark, and record distance of step from retaining strip.
- **b.** Using template and a hole finder, locate and drill the center row of holes running between the windshields andthefive holes aft of the centermost on the cabin roof. If required, lower end of template must extend beyond centermost retaining strip the distance recorded in step d.

- **c.** Position the template on channel (11) and transfer the holes from the template to the channel section.
- **d.** Position the channel (11) using cleco fasteners. Ensure channel is centrally located and check hole alignment.
- **e.** Remove channel (11) and countersink holes to accommodate rivets. Deburr and clean out all metal particles.
- **f.** Apply a bead of sealing compound (C130) along entire channel mounting surface to prevent entry of water between the channel and the retainer.
- **g.** Install the channel using rivets (16 and 17) using extension piece shown in figure 2-76. Start at the lower end of the channel and work up.
- h. Position lower clips (19, figure 2-79) firmly against the channel (11) and using a hole finder locate the four lower windshield retaining strip rivet positions and drill through. Remove, clean, and cleco



Incorrectly Installed insert Requiring Trimming, for

**DETAIL C** 

Windshield Deflector.

Correctly Installed Insert, Channel and Angles, for Windshield Deflector.

DETAIL A

# Channel Angles, Left and Right Fastener (Screw, Nut and Washer), Typical Trim insert in area indicated so that it is flush with angles Trim channel in area indicated so that it is flush with angles

Figure 2-72.1. Rework-Channel and Insert.

Incorrectly Installed Channel Requiring Trimming,

**DETAIL B** 

for Windshield Deflector.

one clip into position and locate the four holes in channel. Remove and drill through. Repeat for other clip. Apply sealing compound (C131) to the clip mounting surfaces and install the clips.

- i. Clean excess sealant from channel (11) and clips (19). Refer to TM 43-0105.
- **j.** Install upper cutter assembly as per paragraph 2-352, steps f. through i.
  - k. Install insert assembly as per paragraph 2-366.
- I. Prime/paint as required. Refer to TM 55-1500-345-23.
- **m.** Install cable clamps using existing hardware and reposition the wire bundle. Remove the circuit breaker panel and glareshield covering and thoroughly clean up the cockpit interior to remove all metal particles.
- **n.** Remove the windshield and overhead window covering and close the circuit breaker panel.

### 2-370. LOWER CUTTER ASSEMBLY.

2-371. Description — Lower Cutter Assembly. The mechanical cutter/deflector (lower) consists of a sawtooth equipped deflector section; providing deflection/abrading feature, leading into the primary cable cutting mechanism wedge type cutting blades positioned to provide the necessary mechanical advantage to cut the objective wires/cables while minimizing load input into the airframe.

### 2-372. Inspection — Lower Cutter Assembly,

- **a.** Inspect the cutter assembly for paint deterioration, superficial paint scratches, and light corrosion. No moderate or heavy corrosion allowed. Scratches, nicks, or gouges to a depth of **0.010** inch must be repaired.
- **b.** inspect the sawblade. Refer to paragraph 2-325.
- **c.** Inspect the cutter blades. Refer to paragraph 2-333.
- **d.** Inspect the deflector assembly for cracks and permanent deformation. Deflector assemblies showing evidence of any cracks and/or permanent deformation must be replaced.

- **e.** Inspect the security of the lower cutter assembly. Loose rivets must be replaced.
- **f.** Inspect the surrounding support structure for evidence of permanent deformation. If permanent structural deformation exists replace the entire cutter assembly.

### 2-373. Removal - Lower Cutter Assembly.

Support cutter when removing the last few screws to prevent damage to the support structure and to prevent the cutter dropping from the aircraft.

- **a.** Remove screws (1, figure 2-73) installing cutter assembly.
  - **b.** Remove screws (3) and antenna (4).
  - c. Remove panel assembly (5).

### 2-374. Repair — Lower Cutter Assembly.

Paint deterioration or superficial paint scratches as per TM 55-1500-345-23.

- **b.** Light corrosion clean and repair area as per TM 43-0105.
  - c. Sawblade refer to paragraph 2-242.
  - d. Cutter blade refer to paragraph 2-336.
- **e.** Using sandpaper (C124) remove scratches to a maximum depth of **0.010** inch. Prime/paint as required in accordance with TM 55-1500-345-23.

### 2-375. Installation — Lower Cutter Assembly.

- **a.** Remove stiffener (6, figure 2-73) from existing panel and utilize panel as template.
- **b.** Position the template on top of panel (5), and cleco together through the cutter and antenna mounting holes. Ensure the forward center hole is perfectly aligned. Drill the panel outer holes. Transfer the two drain holes from template to the panel only if required. Trim the fore and aft edges of the panel to match the template if necessary. Remove the panel, deburr and prime in accordance with TM 55-1500-345-23.




Figure 2-73. Removal — Lower Cutter Assembly

- **c.** Position the cutter assembly (2) on the panel (5) and cleco through the four cutter mounting holes. Check fore and aft alignment and clamp. Locate the panel outer holes and match by back drilling through the panel into the cutter assembly doubler and strut feet. Remove and deburr.
- **d.** Wing existing screws loosely attach the antenna (4) to panel (5) by the two rear mounting screws (3). Position the panel and connect the antenna cable. Loosely install the remaining four antenna mounting screws (3) and the aft seven panel mounting screws (1).
- **e.** Position cutter assembly (2) and loosely install the two forward mounting screws (1), and the two aft mounting screws (1). Check the cutter alignment, install and tighten the panel forward center screw first to ensure the cutter alignment is maintained. Install and tighten the remaining panel, cutter and antenna mounting screws (1).
- **f.** Prime/paint as required. Refer to TM 55-1500-345-23.

# 2-376. BREAKAWAY TIP - LOWER CUTTER ASSEMBLY.

2-377. Description — Breakaway Tip. The lower cutter assembly features a breakaway tip (10, figure 2-65) designed to shear when relatively large ground contact forces are experienced and before helicopter structural damage is incurred. However, the tip shear rivets are chosen to withstand the smaller forces experienced during wire strikes, and the tip will still effectively deflect wires/cables into the cutter blades.

### 2-378. Inspection — Breakaway Tip.

- a. Inspect the tip assembly for paint deterioration, superficial paint scratches, and light corrosion. No moderate or heavy corrosion allowed. Scratches, nicks, gouges to a depth of **0.006** may be repaired.
- **b.** Inspect the security of the breakaway tip, paying particular attention to the rivets. If there is evidence of loose or deformed rivets, replace rivets.
- **2-379.** Removal Breakaway Tip. Remove bolts (1, figure 2-74), washers (2), and nuts (3) and remove tip assembly (4).

### 2-380. Repair — Breakaway Tip.

- **a.** Paint deterioration or superficial paint scratches in accordance with TM 55-1500-345-23.
- **b.** Using sandpaper (C124) remove scratches to a maximum depth of **0.006** inch. Prime/paint as required in accordance with TM 55-1500-345-23.

### 2-381. Installation — Breakaway Tip.

- **a.** Position tip assembly (4, figure 2-74) and install nuts (3), washers (2), and bolts (1).
- **b.** Prime/paint as required. Refer to TM 55-1500-345-23.

### 2-382. STIFFENERS, LOWER CUTTER.

**2-383. Description** — **Stiffeners.** The stiffeners (6, figure 2-65) provide additional structural support, distributing wire cutting loads to the surrounding airframe.

### 2-384. Inspection — Stiffeners.


- **a.** Inspect stiffeners for cracks and permanent deformation. Stiffeners showing evidence of cracks and/or permanent deformation must be replaced.
- **b.** Inspect the security of the stiffeners. Loose rivets must be replaced.
- c. Inspect the surrounding support structure for cracks and permanent deformation.

### 2-385. Removal — Stiffeners.

- **a.** Remove lower cutter assembly as per paragraph 2-327.
  - **b.** Remove rivets (1, figure 2-75) and stiffener (2).
- **2-386.** Repair Stiffeners. No repair, authorized.


### 2-387. Installation — Stiffener.

- **a.** Forward bearing plate stiffener (4, figure 2-75). Locate stiffener assembly and attach loosely to the helicopter through the forward center hole position using a screw and proceed as follows.
- (1) Transfer two additional nut plate holes to helicopter structure.




206900-5%

Figure 2-74. Removal — Breakaway Tip



206900.557

Figure 2-75. Removal — Stiffeners



0.116

EXTENSION PIECES FOR CHERRY LOCK TOOL MODEL G55-MAKE FROM 1/4-INCH MILD STEEL ROD

206900-558

Figure 2-76. Work-Aids - WSPS - Channel Installation

- (2) Transfer stiffener assembly mounting holes.
- (3) Remove stiffener assembly and countersink two mounting holes.
  - (4) Install stiffener assembly using rivets (1).
  - b. Cutter support stiffeners (2).
- (1) Locate stiffeners to be replaced in their respective positions on the existing panel assembly. Attach to the panel using screws through the antenna and/or cutter predrilled position holes. Due to the floating anchor nuts, the stiffeners can move slightly on the template; therefore, use a square to ensure

correct 90 degree alignment between the stiffeners and the template, then tighten locating screws. Backdrill the stiffener mounting holes, the nut plate mounting holes, and the nut plate screw holes. Remove the stiffeners and trim both ends sufficiently to allow proper fit to the aircraft ensuring correct hole edge distance is maintained. Countersink or dimple holes as required to match existing dimpled holes on aircraft.

- (2) Place cutter support stiffeners into their respective positions and install.
- **c.** Install panel assembly and cutter assembly. Refer to paragraph 2-375, step d.




Figure 2-77. Removal – Doublers and Saw Blade C




Figure 2-78. Removal - Strut Assembly, Cutter Blades




Figure 2-79. Removal - Channel, Sawtooth Insert and Upper Cutter Assemble

# CHAPTER 3 ALIGHTING GEAR

### 3-1. GENERAL.

This chapter provides all the essential information for personnel to accomplish maintenance on the standard, high, and floating alighting gears.

# Premaintenance Requirements for Alighting Gear

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	None

Condition	Requirements
Test Equipment	None
Support Equipment	(S14) (S4)(S16)
Minimum Personnel Required	Three
Consumable Materials	(C18) (C19) (C20) (C21) (C22) (C38) (C41) (C45) (C88) (C116) (C117) (C129) (C131) (C143) (C144)
Special Environmental Conditions	None

### SECTION I. LANDING GEAR

### 3-2. STANDARD LANDING GEAR.

**3-3. Description** — **Standard Landing Gear.** The standard landing gear assembly consists of two tubular aluminum alloy main skid tube assemblies and two curved aluminum alloy crosstube assemblies. The landing gear is attached to the fuselage structure with four strap assemblies. Provisions are made on the skid tubes for installing ground handling trucks and two rings are provided for towing. Each skid tube is provided with replaceable skid shoes which absorb the wear caused by normal ground contact of the helicopter.



Landing gear crosstubes will be inspected after a hard landing or overloading to determine if excessive crosstube spread has occurred.



The maximum weight which can be added to each standard gear skid tube is seven (7) pounds. No weight can be

mounted on cross tubes. Exceeding this weight will result in failure of the aircraft cross tube at the fuselage attach location.

### NOTE

Skid tube assemblies and crosstube assemblies are fully interchangeable with components having identical part numbers except as stated below.

Skid tube assemblies P/N 206-052-118-31 and -32 may replace lower dash numbered skid tube assemblies when changed as a set and usad with double wheel truck assemblies.

Skid tube assemblies P/N 206-052-118-9 and -10 and crosstube assemblies P/N 206-052-103-1 and -3 can be matched with components having identical part numbers or skid tube assemblies P/N 206-052-118-13, -14, -31, and 32 and crosstube assemblies P/N 206-052 -103-5 and -7.

**3-4. Cleaning Standard Landing Gear.** Refer to paragraph 1-18 and TM 55-1500-344-23 for cleaning procedures.

### 3-5. Inspection Standard Landing Gear.

- a. Inspect crosstubes for excessive spread as follows:
- (1) Raise and level helicopter on jacks (S14) so that landing gear is relieved of weight. Refer to paragraph 1-38.
- (2) Determine center of either crosstube by measurement between bearing straps. Drop a plumb line from center of crosstube to ground. Refer to figure 3-1.
- (3) Measure from plumb line to center of each skid at crosstube attachment point. Normal dimension is **37.250** inches. If any measurement exceeds **38.250** inches between skid center lines, replace defective crosstube.
- b. Inspect crosstubes for scratches, nicks, and dents.

### NOTE

# Scratches, nicks, and dents of less than 0.005 inch depth are considered negligible.

- (1) Circumferential scratches that exceed **0.005** inch depth and not exceeding a 45 degree arc many be polished out to the limits shown in figure 3-2.
- (2) Longitudinal scratches and nicks of any length that exceed **0.005** inch depth may be polished out to the limits shown in figure 3-2.
- (3) Dents limits are the same as those specified for nicks. No sharp dents are permitted.
- c. Inspect skid tube and saddle for scratches, nicks, and dents.
- (1) Circumferential scratches and nicks are not to exceed **0.025** inch depth and arc of 90 degree.
- (2) Scratches, scuffs, and nicks running longitudinally may be of any length but are not the exceed **0.025** inches depth.
- (3) Smooth dents are not to exceed **0.250** inch depth and **1.000** inch diameter.

- (4) Corrosion damage is not to exceed **0.250** inch depth over an area greater than 1/4 the tube circumference by **3.000** inches in length.
- (5) Bond failure between midpoint doubler and the tube shall not exceed 20% of doubler area.
- (6) Inspect fitting's part number 206-052-106-1 for U bent or cracked lugs, replace as needed.
- d. Inspect skid shoes for wear, damage, and security.
  - e. Inspect tow rings for security and damage.
- f. Inspect crosstube strap rubber cushions for cracks, deterioration, and embrittlement. This type of deficiency is cause for cushion replacement. To bond replacement cushions, use adhesive (C9). Inspect for fuselage shift on skid crosstubes. Some shift is acceptable, except when clearance between crosstube upper saddle and spacer pins is **0.010** inch or less.
- g. Inspect fitting assemblies (figure 3-3) for corrosion and damage:
- (1) Corrosion cannot effect move than 20% of a surface area.
- (a) Corrosion pits cannot be wider than **0.060** inch, and should not be more than 15% of local depth or thickness.
- (b) Each pit must be separated by at least **0.200** inch.
- (c) No more than 14 pits are permissible in a **1.000** inch area.
  - (d) A corroded area may only be repaired once.
- (2) Wear on the fitting assemblies caused by hard contact and chafing from rivet collars may be up to a maximum of **0.025** inch.
- h. Inspect the four support fittings to ensure that the sealant bead around the mounting edge of the fittings still maintains a water barrier. If the sealant (C129) is missing or needs replacement, remove water inside the fitting and dean, then apply another bead after installation

### 3-2 Change 24




Figure 3-1. Determining Crosstube Center (Typical)

i. Inspect saddle for loose rivets and cracks. Replace cracked saddle; replace loose rivets.

### NOTE

Modified crosstubes will have two rivets securing the strap assembly to the crosstube. These two rivets will be located on the transverse centerline (perpendicular to the longitudinal axis of the crosstube) and flush with the surface of the strap assembly, there should not be any rivets present on top of the assembly along the longitudinal centerline (parallel to axis of the crosstube). Another method is to check for two holes on top of the strap assembly. These holes are the location of the rivets for the unmodified No rivets should be present. crosstube. Removal of some paint may be necessary to determine if rivets are present.

Unmodified crosstubes will have four rivets securing the strap assembly. These rivets will be flush with the surface of the strap assembly. If crosstube is unmodified, proceed to corrective procedures in paragraph 3-28, step c.

The four large Pin and Collar rivets prominent on the strap assembly are not affected.

j. If crosstubes are removed from aircraft, inspect strap assembly attached to the crosstube for wear, damage and security. Verify strap assembly has been modified.

### 3-6. Removal Standard Landing Gear.

### CAUTION

Do not move helicopter for 25 minutes after power has been removed from the AN/ANS-43 compass to preclude damage to the compass. However, if helicopter must be moved before 25 minutes has elapsed, apply power to the compass and allow a 5 minute warmup time. The helicoopter may then be moved without damage to the gyro with power applied.

- a. Raise helicopter using jack (S1 4) or hoist (S12) and shackle (S16) to allow removal of landing gear from helicopter. Refer to paragraphs 1-36.6, 1-38 and 1-42.
- b. Remove bolts and washers at each strap assembly which secure crosstubes to structure.






Figure 3-1.1. Modified Crosstube





**ITYPE OF DAMAGE** 

**MAXIMUM DAMAGE AND REPAIR DEPTH** 

**NICKS AND SCRATCHES** 

0.014

0.012

0.008

Figure 3-2. Standard Landing Gear Crosstube Inspection Limits

c. Remove four cap assemblies.

### NOTE

Identify caps as to location for reassembly of landing gear.

- **3-7.** Repair Standard Landing Gear System (figure **3-4).** Refer to paragraphs 3-15, 3-21 and 3-28 for repair procedures.
- 3-8. Installation Standard Landing Gear.

### NOTE

Remove paint at fuselage and crosstube mounting points to ensure good electrical ground. Perform the Inspection required In paragraph 3-5, step h.

Verify strap assembly attached to the crosstubes have been modified. Refer to paragraph 3-5, step j.


a. Position landing gear and carefully lower helicopter to sear four mounting points of structural beams (fitting assemblies) on bearing straps of crosstubes. Make sure that the fitting assemblies are centered between the rivets on the crosstubes.

### NOTE

When replacing fittings, apply adhesive (item 17, table 1-2) prior to Installation.


Whenever replacing fitting assembly, apply a bead of sealant (C129) to the mounting edges after Installation.

3-4.2 Change 24



206052-22

Figure 3-3. Standard Landing Gear Fitting Assembly



No patches allowed on doublers. Damage in this area exceeding negligible limits requires repair by splicing entire doubler length using 0.120 inch 2024T3 or scrap tube with undamaged doublers. All dimensions are In Inches..



206052-23

Figure 3-4. Standard Landing Gear - Skid Tube Repair Limits

- **b.** Install four cap assemblies at correct location, and secure each assembly to plate nuts in fuselage with bolts and washers.
- **c.** Lower helicopter then remove jacks and hoist shackle (if applicable).

# 3-9. SKID TUBES — STANDARD LANDING GEAR.

# **CAUTION**

The maximum weight which can be added to each standard gear skid tube is seven (7) pounds. No weight can be mounted on cross tubes. Exceeding this weight will result in failure of the aircraft cross tube at the fuselage attach location.

- **3-10.** Description Skid Tubes Standard Landing Gear. The skid tubes consist of two tubular aluminum alloy skid tube assemblies. Each skid tube is provided with replaceable skid shoes.
- **3-11. Cleaning Skid Tubes Standard Landing Gear.** Remove dirt, mud, and/or other foreign material from skid tubes using cleaning compound (C41) and water.
- **3-12.** Inspection Skid Tubes Standard Landing Gear. Refer to paragraph 3-5, step c. for inspection of skid tubes.

# 3-13. Removal — Skid Tubes — Standard Landing Gear.

- **a.** Raise helicopter so that the skid tube may be removed. Refer to paragraphs 1-36f, 1-38 and 1-42.
  - **b.** Remove screws from saddles of skid tubes.
  - **c.** Pull end of crosstubes from sockets of saddles.

# 3-14. Acceptance/Rejection Criteria — Skid Tubes — Standard Landing Gear.

- a. Negligible damage.
- (1) Circumferential scratches and nicks in the skid tubes not exceeding a depth of 0.025 inch and an arc length of 90 degrees.
- (2) Scratches and scuffs and nicks running longitudinally in the skid tube maybe of any length but not to exceed a depth of 0.025 inch.

- (3) Smooth dents in the skid tubes which do not exceed 0.250 inch in depth and 1.000 in diameter.
- (4) Corrosion damage not exceeding 0.025 inch depth over an area not exceeding 1/4 the circumference by 3.000 inches in length.
- **(5)** Scratches, dents, and nicks of any depth and length aft of the aft crosstube saddle.
- **(6)** Scratches, dents, and nicks of any depth and length in the curved portion only of the tube forward of the forward crosstube saddle.
  - b. Reparable damage.
- (1) Scratches, scuffs, and nicks exceeding **0.025** inch deep may be repaired by patching. Refer to paragraph 3-15 and figure 3-5.
- (2) Smooth or sharp dents exceeding 1.000 inch diameter and 0.250 inch in depth but not to exceed **2.000** inches in diameter maybe repaired by patching. Refer to paragraph 3-15 and figure 3-5.
- **(3)** Holes in skid tubes up to a diameter of 2.000 inches through one surface of the tube only may be repaired by patching.
- (4) Scratches, dents, and holes in excess of the **2.000** inch limit may be repaired by splicing in a new section of tube. (Refer to paragraph 3-15, step b., and figure 3-6.)
- **(5)** Damage resulting in a bond failure between the midpoint doubler and the tube up to 20% of the doubler may be repaired. Refer to paragraph 3-15.
- (6) Damage resulting in a bond failure between the midpoint doublers and the tube in excess of 20% of the doubler area necessitates replacement of the doubler. Refer to paragraph 3-15.
  - c. Damage requiring replacement.
- (1) Damage to the skid tube in excess of reparable damage limits necessitates replacement.
- **(2)** Damage to the skid tube within 3.000 inches of the crosstube saddie and in excess of the negligible limits necessitates replacement.

#### 3-15. Repair-Skid Tubes— standard Landing Gear.

a. To repair by patching proceed as follows:





Figure 3-5. Skid Tube Patch Repair (Typical)

- **(1)** Polish out scratches, trim and smooth hole (figure 3-5).
- (2) Fabricate a patch from 0.090 inch aluminum alloy sheet or unserviceable tube of required size.
- (3) Lay out rivet hole pattern and form patch to fit contour of skid tube (figure 3-5).
- (4) Securely clamp patch in place on skid tube and drill rivet holes, using a No. 10 drill.
- (5) Secure patch in place using 3/16-inch diameter blind type rivets.
- **(6)** Apply primer (C117) and lacquer (C88) in accordance with TM 55-1500-345-23.
  - b. To repair by insertion proceed as follows:

#### NOTE

Dents and holes on either top or bottom side of skid tube, which are greeter then two inches across in any direction, shall be repaired by inserting a splice of new tubing. Such repairs are restricted to areas shown in figure 3-4.

- (1) Cut out damaged portion of skid tube with metal saw.
- (2) Fabricate an insert of required length from tube of 0.083 inch wall thickness or from scrap tube as shown in figure 3-6.
  - (3) Fabricate splice plate as follows.
- (a) Cut four plates to required dimensions as shown in figure 3-6 from sheet stock 0.090 inch thick or use material salvaged from unserviceable tube.
- **(b)** Form two plates to fit the outside diameter of skid tube and two plates to fit inside diameter of tube.
- (4) Apply a coat of sealing compound (C131) to plates and tubes.
- (5) Layout rivet hole pattern on upper splice and lower side of tube.
- **(6)** Maintaining proper alignment, securely clamp splice plates and tubes together.






Figure 3-6. Skid Tube Insertion Repair (Typical)

- (7) Drill rivet holes in plates and tubes with a No, 13 drill. Countersink lower holes with 100-degree countersink, Install blind rivets in upper half of splice and flush rivets in lower half.
- (8) Apply touchup coat of primer (C117) and lacquer (C88) in accordance with TM 55-1500-345-23.
  - c. Doubler repair with bond failure of 20% or less,
    - (1) Rebond doubler with adhesive (C19).
- (2) Install three additional blind rivets equally spaced on each side of doubler,

**d.** Doubler repair with bond failure of more than 20%.

206052-25

- (1) Bond new doubler with adhesive (C19).
- (2) Install three additional blind rivets equally spaced on each side of doubler.
- **e.** Repair skid tube at tow fitting attachment points as follows:
- (1) Fabricate two doubler plates (figure 3-7 and 3-8), one each for inboard and outboard sides.





Figure 3-7. Tow Ring Repair



#### TOW RING ATTACH POINT REINFORCEMENT

- 1. OUTBOARD AND INBOARD PLATES SAME SIZE
- 2. FOR TOW RING HOLE SIZE SEE FIGURE 3-7
- 3. MATERIAL: 4.000 X 2.000 X 0.120 INCH 2024 T3-ALUM.
- 4. CONTOUR TO FIT SKID TUBE
- 5. ATTACH TO SKID TUBE WITH 0.188 DIA CHERRY RIVETS

206052-27

Figure 3-8. Tow Ring Doubler Plate

- **(2)** Drill the center holes in doublers; refer to figure 3-7 and 3-8 for hole size and location.
- (3) Layout rivet pattern on doubler plates (figure 3-8). Do not drill doubler plates at this time.
  - (4) Contour doubler plates to fit skid tubes.
- **(5)** Temporarily tape inboard and outboard doubler plates in place. Ensure doubler plates do not interfere with the skid shoes.
- (6) If interference exists between skid shoes and doubler plates; trim material from doubler plate to give

approximately **0.125** inches clearance and adjust rivet pattern as required.

- (7) Clean up tow ring mounting hole area.
- (a) Flourescent penetrant inspect hole area. Refer to TM 55-1500-335-23.
- **(b)** Polish out scratches; trim and smooth tow ring mounting hole.
- (c) Repair local skid tube damage if required. Refer to paragraph 3-15, step a.

- **(8)** Install doubler plates to skid tube as follows: Refer to TM 1-1500-204-23.
- (a) Securely clamp doubler plates to skid tube aligning two ring mounting holes.
- **(b)** Drill rivet holes. Remove doubler plates and deburr.
- (c) Secure doubler plates in place with rivets; applying sealing compound (C131) under head of rivet.
- **(9)** Seal edges of doubler plate with sealing compound (C131).
- (10) Prime (C117) and lacquer (C88) area of repair. Refer to TM 55-1500-345-23.
- **(11)** After installation of doubler plates install two ring fittings as follows:
- (a) Install tow ring fitting in skid tube. Installone bushing NAS 75-4-024 over outboard end of tow ring fitting.

#### NOTE

- If bushing (NAS 75-4-024) is too long, remove excess material; if too short use next longer bushing (NAS 75-4-025). Bushing should be flush with doubler plate.
- (b) Install bolt (P/N AN 4-5) until threads bottom finger tight. Measure clearance between head of bolt and skid tube.

#### NOTE

# If clearance exceeds 0.126 inches use next shorter bolt (P/N AN 4-4).

- (c) Reinstall bolt with two washers and recheck for proper fit to ensure bolt has proper thread engagement. An acceptable alternative is one washer in contact with skid tube and one washer under bolt head.
- (d) Remove bolt and washers; coat bolt threads with adhesive (C18) and then install bolt and washers.

# 3-16. Assembly — Skid Tubes — Standard Landing Gear.

- **a.** Insert ends of skid tubes into sockets of saddles (figure 3-9).
- **b.** Install screws through saddles of skid tubes. In the event it is impossible to align all of the holes,

position the assemblies in the most advantageous position. These skid tube saddle holes which do not align may be elongated (use rat-tail file) to provide for bolt installation. Maximum elongation permitted is **0.090** inch. Hole diameter shall not exceed 0.408 inch.

**c.** Lower helicopter and remove jacks. Refer to paragraphs 1-38 and 1-42 (if applicable).

# 3-17. SKID SHOE ASSEMBLY — STANDARD LANDING GEAR.


### **CAUTION**

The maximum weight which can be addad to each standard gear skid tube is seven (7) pounds. No weight can be mounted on cross tubes. Exceeding this weight will result in failure of the aircraft cross tube at the fuselage attach location.

- **3-18. Description Skid Shoe Assembly Standard Landing Gear.** The standard landing gear has two skid tubes with four skid shoes on each. An improved skid shoe configuration maybe installed. It has three skid shoes per skid tube.
- **3-19.** Inspection Skid Shoe Assembly Standard Landing Gear. Refer to paragraph 3-5 for inspection of skid shoe assembly.
- 3-20. Removal Skid Shoe Assembly Standard Landing Gear (Figure 3-9).
- **a.** Raise helicopter so that the skid shoe assembly may be removed. Refer to paragraphs 1-38 and 1-42.
- **b.** Remove four screws securing each skid shoe to the skid tube and remove skid shoes. On improved skid shoe configuration, the forward shoe has 12 screws.
- **3-21.** Repair— Skid Shoe Assambly-Standard Landing Gear. Minor dents, nicks, and scratches that do not exceed 0.010 inch in depth are considered negligible. Repair is by replacement of skid shoes.

# 3-22. Assembly — Skid Shoe Assembly — Standard Landing Gear.

- **a.** Install four screws to secure each skid shoe to the skid tube. On improved skid shoe configuration, the forward shoe has 12 screws.
- **b.** Lower helicopter and remove jacks. Refer to paragraphs 1-38 and 1-42 (if applicable).



AN5-6A bolts are alternate for MS27039-11 and MS27039-13 screws.

A ply drag torque plus 60-85 inch-pounds w en AN5-6A bolts are used.

Hole ma be elongated to maximum dimension of 0.344 or alignment.

Figure 3-9. Removal of Skid and Skid **Shoe (Standard Gear)** 

### 3-22.1. ALTERNATE FULL LENGTH SKID SHOE.

### 3-22.2. Cleaning - Full Length Skid Shoe.

- a. Clean skid shoe surface with drycleaning solvent (C62).
  - **b.** Dry skid shoe with a wiping rag (C119.1).
- 3-22.3. Inspection Full Length Skid Shoe. Inspect alternate skid shoe for worn runner surface or cracks at the skid shoe attachment points. If cracks at the attachment points are observed, or skid shoe runner is worn to a point of unserviceability; replace skid shoe.

#### 3-22.4. Removal - Full Length Skid Shoe.

- a. Raise helicopter until skid tube is approximately 6-10 inches off the ground. Refer to paragraph 1-38 or 1-42 (if applicable).
- b. Remove seven nuts on quick coupler clamps securing skid shoe to skid tube. Refer to figure 3-9.1.
  - c. Remove skid shoe from skid tube.

### 3-22.5. Installation - Full Length Skid Shoe.

- a. Raise helicopter until skid tube is approximately 6-10 inches off the ground. Refer to paragraph 1-38 or 1-42 (if applicable).
- **b.** Remove the original skid shoes if installed. Refer to paragraph 3-20.

#### NOTE

Fill the original skid shoe screw holes with adhesive, silicone (C18 or equivalent) to prevent water or debris from entering the skid tube.

Clamps shall be facing inboard.

- c. Clamp the full length skid shoe onto the skid tube. The quick coupler clamp nuts should not be fully tightened at this time. All quick coupler clamp nuts should be facing inboard.
- d. Lower helicopter to the ground and torque the quick coupler clamp nuts to 60 INCH-POUNDS using the sequence in figure 3-9.1.
- e. Make appropriate log book entries and weight and balance computations.

### 3-23. CROSSTUBES - STANDARD LANDING GEAR.

- 3-24. Description Crosstubes Standard Landing Gear. The standard landing gear consists of two curved aluminum alloy crosstube assemblies
- 3-25. Inspection Crosstube Standard Landing Gear. Refer to paragraph 3-5 for inspection of crosstubes.
- 3-26. Acceptance/Rejection Criteria Crosstubes - Standard Landing Gear. Refer to figure 3-2 for damage limits to crosstubes.

# 3-27. Removal/Disassembly - Crosstubes -Standard Landing Gear.

- a. Remove standard landing gear in accordance with paragraph 3-6.
- **b.** To separate skids from crosstubes proceed as follows:
  - (1) Remove screws at saddles of skid tubes.
- (2) Pull ends of crosstubes from sockets of saddles.

### 3-28. Repair - Crosstubes - Standard Landing Gear.

a. The only repair permitted to a crosstube is to polish out scratches and nicks that do not exceed the limitations provided in figure 3-2 and paragraph 3-5, step b.



Figure 3-9.1. Alternate Full Length Skid Shoe

- **b**. Replace loose or missing rivets attaching strap assembly to crosstube as necessary.
- **c**. Replace strap assembly/modify crosstube as follows:

#### **CAUTION**

Use care not to enlarge any holes in strap assembly or crosstube when removing rivets.

#### NOTE

Unmodified strap assembly requires removal of four rivets.

- (1) Drill out the two attaching rivets.
- **(2)** Apply heat, not in excess of 1800 F to strap assembly to loosen strap from crosstube.
  - (3) Remove strap assembly.

#### NOTE

Use plastic or acrylic tools to remove sealant, do not use metal.

(4) Clean all sealant from strap assembly and crosstube.

#### **NOTE**

# Proper preperation of holes is critical.

- **(5)** Clean out and deburr all rivet holes (internally and externally).
- **(6)** Inspect area around each of two rivet holes in strap assembly for corrosion. Check for rivet hole elongation, fretting, improper installation, cuts, gashes or dents.

(7) Inspect each rivet hole in crosstube for cracks using fluorecent penetrant. If cracks are found, replace crosstube assembly.

#### NOTE

Strap assembly Is made of titanium. To assure an adequate bond it is important strap surface is properly prepared. It may be necessary to grit blast bonding surface of strap to ensure an adequate bond. Refer to TM 1-1500-204-23 for adhesive data.

- (8) Align serviceable strap assembly in place on crosstube. Mark location with felt tip pen, observe correct longitudinal and lateral locations.
- (9) Bond strap assembly in place with adhesive (C1 9).

#### NOTE

Selection of rivets that have correct grip length for total thickness (starp and crosstube thickness) Is critical.

Strap assembly may have four rivet holes. Install rivets In fore and aft holes only.

**(10)** While adhesive is wet, install two rivets, P/N M7885/3-6-04 wet with epoxy primer (C116), to secure strap assembly to crosstube.

### **WARNING**

MIL-S-8802CLB2 adhesive is flamable and toxic. Good general ventilation Is normally adequate. Skin and eye protection is required. Avoid all sources of ignition.

- (11) Apply a bead of sealing compound (C131) around the outer mating edge of the strap and crosstube. If required, fill top rivet holes with sealant (C131).
- (12) Allow adhesive and sealing compound to cure.

# WARNING

Paint and primer are toxic and flammable. They can irritate skin and cause burns. Use only In well-ventilated area away from heat and open flame. Wear rubber gloves and goggles. In case of contact, Immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

- (13) Apply primer (C117) and lacquer (C88) on all exposed areas of the crosstube in accordance with TM 55-1500-345-23.
- **3-29. Repair Fitting Assembly.** Refer to paragraph 3-5, step g. for corrosion and damage limits. Repair as follows:
- **a.** Strip part and dean off surface corrosion, a maximum of **0.005** inch maybe removed.
- (1) Remove corrosion using aluminum oxide -cloth (C45).
- (2) Do not use ferrous materials on aluminum.
- (3) Clean with alcoholic phosphoric add solution Turco No. 1 (C21) and treat with alodine coating (C38), then repaint with epoxy polyamide primer (C116).
- **b.** Remove all burrs and sharp corners caused by damage to fitting assemblies.

# 3-30. Installation/Reassembly - Crosstubes - Standard Landing Gear.

- a. Assemble skids and crosstubes as follows:
- (1) Insert ends of crosstubes into sockets of saddles (figure 3-9).
  - (2) Install screws at saddle of skid tubes.
- (3) Apply ahead of sealant (C129) to the top of the saddle.
- **b.** Install standard landing gear in accordance with paragraph 3-8.

# 3-31. LANDING GEAR SUPPORT FITIINGS.

- **3-32. Description.** Four identical landing gear fittings are bolted to the lower fuselage. These fittings are used to install the landing gear and the float landing gear.
- **3-33.** Removal. Remove the bolts, nuts and washers securing the fittings to the airframe. Note that the bolts are not all the same length.

# 3-34. Inspection.

- **a.** Corrosion cannot effect more than 20% of surface area.
- **b.** Corrosion pita cannot be wider than 0.060 and must be separated by at least 0.200 inch.
- **c.** Wear on the fittings caused by contact and chafing from rivet collars on the landing gear control cannot exceed 0.025 inch.

#### 3-35. Repair.

- **a.** Strip fitting and remove corrosion using an aluminum oxide cloth (C45). (Do not use ferrous materials on aluminum.) Not more than 10% of local thickness can be removed.
- **b.** Remove all burrs and sharp corners created by damage to the fitting.
- **c.** Clean repaired area with alcoholic phosphoric add solution Turco No. 1 (C21), then treat with alodine coating (C38) and reprime with epoxy polyamide primer (C116).

# 3-36. Installation.

- **a.** Use proper length of bolt and install nuts when required. Ensure bolts are installed in correct location. install a washer under the head of each bolt and under each nut.
- **b.** Appfy a thin bead of sealant (C129) to the mating surfaces of the fitting and airframe in order to prevent water from entering the fitting recessed areaa. After installation, apply a bead of sealant around the mounting edge of the fittings.

#### 3-37. HIGH LANDING GEAR.

**3-38. Description - High Landing Gear.** The high landing gear is similar to the standard landing gear except that it is constructed of tubing with increased wall thickness. The skid tubes are longer and the crosstubes provide increased height and stance. A right and left side step assembly is mounted on the forward crosstube.

#### NOTE

When replacing standard landing gear with high landing gear, the aircraft must be weighed and the weight and balance record updated.

**3-39. Cleaning - High Landing Gear.** Refer to paragraph 1-18 and TM 55-1500-333-24 for cleaning procedures.

# 3-40. Inspection - Acceptance/Rejection Criteria - High Landing Gear.

- **a.** Raise helicopterapproximately **1.000** inch and level helicopter on jack, so that landing gear is relieved of weight. Refer to paragraph 1-38 and 142.
- **b.** Determine center of either crosstube by measurementbetween bearing straps. Drop a plumb line from center of crosstube to ground (figure 3-1).
- **c.** Measure from plumb line to center of each stud at crosstube attchment point. Normal dimension is **42.000** inches. if any measurement exceeds **43.000** inches from skid center line, replace defective crosstube.
- **d.** Inspect crosstube for scratches, nicks, and dents.

#### NOTE

Scratches, nicks, and dents of less than 0.005 inch in depth are considered negligible.

- (1) Circumferential scracthes and nicks that exceed 0.005 inch depth and not exceeding a 45 degree arc may be polished out to the limits shown in figure 3-10.
- (2) Longitudinal scratches and nicks of any length that exceed 0.095 inch depth may be polished out to the limits shown in figure 3-10.
- **e.** Inspect skid tubes for scratches, nicks, and **dents**.
- (1) Circumferential scratches and nicks are not to exceed **0.005** inch in depth and an arc of 90 degrees.

- (2) Scratches, scuffs, and nicks running longitudinally may be of any length but are not to exceed 0.050 inch in depth.
- **(3)** Smooth dents are not to exceed 0.250 inch depth and 1.000 inch diameter.
- (4) Corrosion damage is not to exceed 0.050 inch depth over an area greater than, 1/4 the tube circumference by 3.000 inches in length.

#### NOTE

Scratches, nicks, and dents of any depth and length aft of the aft crosstube saddle and In the curved portion forward of the forward crosstube saddle are considered negligible, but holes should be plugged to prevent water entrapment.

- **f.** Inspect skid shoes for wear, damage, and security.
  - g. Inspect tow rings for security and damage.
- **h.** Inspect ground handing trucks attachment fittings for security.
- i. Inspect crosstube strap rubber cushions for cracks, deterioration, and embrittfement. This type of deficiency is cause for cushion replacement. To bond replacement cushion use adhesive (C9). inspect for fuselage skid on skid crosstubes. Some shift is acceptable except when clearance between crosstube rivet rows and airframe is **0.010** inch or less.
- **j.** Inspect saddle for loose rivets and cracks. Replace rivets if loose and replace skid tubs if saddle is cracked.

# 3-41. Removal - High Landing Gear.

- **a.** Raise helicopter to ailow removal of landing gear from helicopter. Refer to paragraphs 1-38 and 1-42.
- **b.** Remove bolts and washers from each strap assembly securing the crosstubes to the bottom of the helicopter.
- **c.** Remove the four cap assemblies and identify the strap according to original location.

### **NOTE**

Additional raising of helicopter may be required to allow removal of the landing gear from the helicopter.

**3-42. Repair - High Landing Gear.** Refer to paragraph 3-48,3-87, and TM 1-1500-204-23 for repair procedures.

# 3-43. Installation - High Landing Gear.

### NOTE


# Remove paint at mounting points to ensure good electrical grounding.

**a.** Position landing gear and carefully lower helicopter to seat at four mounting points of structural beams (fitting assemblies) on bearing straps of crosstubes. Make sure that the fitting assemblies are centered between the rivets on the crosstubes.


#### NOTE

# Whenever replacing fitting assembly apply a bead of sealant (C129) to the mounting edges after installation.

- **b.** install four cap assemblies at correct locations. Refer to paragraph 3-61.
- **c.** Install inboard and outboard stepson forward crosstube. Refer to figure 3-11.
- **d.** Lower helicopter and remove hoist and shackle.








NOTE: All dimensions are in inches.

206052-29

Figure 3-10. High Landing Gear Crosstube Inspection Limits



- 1. Crosstube
- 2. Step
- 3. Screw
- 4. Washer
- 5. Nut
- 6. Saddle

- 7. Skid
- 8. Skid Shoe, Fwd
- 9. Screw, Machine
- 10. Washer
- 11. Skid Shoe, Aft
- 12. Ballast Weight

- 13. Screw
- 14. Washer
- 15. Nut
- 16. Cap
- 17. Rivit Blind

Figure 3-11. High Landing Gear Step, Skid Shoe, and Ballast Installation (Sheet 1 of 2)




Figure 3-11. High Landing Gear Step, Skid Shoe, and Ballast Installation (Sheet 2)

# 3-44. SKID TUBES — HIGH LANDING GEAR.

- **3-45.** Description Skid Tubes High Landing Gear. The skid tubes of the high landing gear system are longer than the standard landing gear system and are equipped with only two shoes on each skid tube.
- **3-46.** Inspection Skid Tubes High Landing Gear. Refer to paragraph 3-40 for inspection of skid tubes.

# 3-47. Removal/Disassembly — Skid Tubas — High Landing Gear.

- **a.** Raise helicopter so that skid tubes may be removed. Refer to paragraphs 1-38 and 1-42 (if applicable).
- **b.** Remove bolts and washers at saddles of skid tubes.
- **c.** Pull end of skid tubes from sockets of saddles (figure 3-4).

- 3-48. Inspection Acceptance/Rejection Criteria Skid Tubes High Landing Gear (Figure 3-13).
  - a. Negligible damage
- (1) Circumferential scratches and nicks in the skid tubes not to exceed a depth of **0.050** inch and an arc of 90 degrees.
- (2) Scratches, scuffs, nicks longitudinally in the skid tuba may be of any length but not to exceed a depth of 0.050 inch.
- (3) Smooth dents in the skid tubes which do not exceed 0.250 inch in depth and 1.000 inch in diameter.
- (4) Corrosion damage not exceeding 0.050 inch deep over an area not exceeding 1/4 the circumference by 3.000 inches in length.
- **(5)** Scratches, dents, and nicks of any depth and length in the curved portion only of the tube forward of the forward crosstube saddle.

#### b. Reparable damage

- (1) Scratches. scuffs and nicks exceeding 0.050 inch deep may be repaired by patching.
- (2) Smooth or sharp dents exceeding 1.000 inch diameter and/or 0.250 inch depth, but not to exceed 2.000 inches in diameter maybe repaired by patching.
- (3) Holes in the skid tubes up to a diameter of 2.000 inches through one surface of the tube only may be repaired by patching.
- (4) Scratches. dents, and holes in excess of the 2.000 inch limit may be repaired by splicing in a new section of tubing
  - c. Damage requiring replacement
- (1) Damage to the. skid tube in excess of the reparable limits necessitates replacement,
- (2) Damage to the skid tube within the 3.000 inches of the crosstubes saddles and in excess of the negligible limits necessitates replacement.
- (3) Dent limits are the same as those specified for nicks and scratches in figure 3-10. No sharp dents are permitted.

# 3-49. Repair — Skid Tubes — High Landing Gear.

- a. To repair by patching proceed as follows:
- (1) Polish out scratches, trim and smooth holes.
- (2) Fabricate a patch from 0.156 inch aluminum alloy sheet, or unserviceable skid tube of required side (figure 3-5).
- (3) Lay out rivet hole pattern and form patch to fit contour of skid tube.
- (4) Secure clamp patch in place on skid tube and drill rivet holes using a number 10 drill.
- (5) Deburr and rivet patch in place using 3/16 inch diameter blind type rivets,
- (6) Apply primer (C117) and lacquer (C88) in accordance with TM 55-1500-345-23.

**b.** To repair by insertion, proceed as follows:

#### NOTE

Dents and holes on either top or bottom sides of skid tube, which are greater than two inches across in any direction shall be repaired by inserting a splice of new tubing. Such repairs are restricted to areas shown in figure 3-13.

- (1) Cut out damaged portion of skid tube with metal saw.
- (2) Fabricate an insert of required length from tube of 0.156 inch wall thickness or from unserviceable tube as shown in figure 3-6.
  - (3) Fabricate splice plates as follows:
- (a) Cut four plates to required dimensions as shown in figure 3-6 from sheet stock 0.156 inch thick or use material salvaged from unserviceable tube.
- **(b)** Form two plates to fit the outside diameter of skid tube and two plates to fit inside diameter of tube.
- (4) Apply a coat of 'sealing compound (C131) to plates and tube
- (5) Layout rivet hole pattern on upper splice plates and lower side of tube.
- (6) Maintaining proper alignment, securely clamp splice plates and tubes together.
- (7) Drill rivet holes in plates and tubes with a number 10 drill. Countersink lower holes with a 100-degree countersink. Deburr and install 3/16 inch diameter blind rivets in upper half of splice and 3/16 inch diameter flush rivets in lower half.
- (8) Apply touchup coat of primer (C117) and acrylic lacquer (C88) in accordance with TM 55-1500-345-23.

# 3-50. Installation/Reassembly — Skid Tubes — High Landing Gear.

**a.** Insert ends of skid tubes into sockets of saddles (figure 3-4).

**b.** install screws at saddles of skid tubes. In the event it is impossible to align all the holes, position the assemblies in the most advantageous position. These skid tube saddle holes which do not align may be elongated (use rat-tail file) to provide for bolt installation. Maximum elongation permitted is **0.090** inch. Hole diameter shall not exceed **0.408** inch.



**c.** Lower helicopter and remove jacks. Refer to paragraphs 1-38 and 1-42 (if applicable).

### **WARNING**

Ballast weights must be installed in skid tubes prior to operation of helicopter.

- **d.** If ballast weights are not installed, proceed as follows:
  - (1) Remove cap (16, figure 3-11).
- (2) Drill mounting holes in skid tube (7) and ballast weight (12), refer to figure 3-11 for dimensions.
- (3) Install ballast weights (12), screws (13), washers (14), and nut (15).
  - (4) Install cap (16) using Mind rivets.

#### NOTE

If helicopter has not been weighed with high landing gear and ballast weights installed, it must be accomplished prior to operation.

# 3-51. SKID SHOE ASSEMBLY — HIGH LANDING GEAR

- **3-52.** Description Skid Shoe Assembly High Landing Gear. The skid shoe assemblies of the high landing gear are located on the bottom of each skid tube one long shoe on front and one short shoe on the aft section of each skid tube. Refer to figure 3-11.
- **3-53.** Inspection Skid Shoe Assembly High Landing Gear. Refer to paragraph 3-40 for inspection of skid shoes.

# 3-54. Removal — Skid Shoe Assembly — High Landing Gear.

- **a.** Raise helicopter so that the skid shoe assembly may be removed. Refer to paragraphs 1-38 and 1-42.
- **b.** Remove screws securing each skid shoe to the skid shoes and remove shoes.

# 3-55. Repair — Skid Shoe Assembly — High Landing Gear (AVIM).

- **a.** Minor nicks, dents, and scratches that do not exceed **0.010** inch in depth are considered negligible.
- **b.** Damage to skid shoes in excess of the above negligible limits may be repaired by hot reforming, reshaping, or welding as follows: (Refer to figure 3-14.)
- (1) Excessive dents in attaching skid shoe tab may be hot reformed or reshaped provided dents do not exist within a minimum distance of **2.000** inches of any borium weld bends.

# **CAUTION**

Prior to any welding repair, remove the skid shoe from skid tube to avoid damage to the aluminum skid tuba from excessive heat.

- (2) Remove necessary hardware and detach skid shoe from skid tube.
- (3) Elongated holes in attaching tabs of shoe may be repaired as follows:
- **(a)** Fabricate an appropriate circular or elongated doubler of 4130 steel, **0.050** inch thickness, normalized per MIL-S-18729, as shown on figure 3-14, detail C.
- **(b)** On all repairs requiring welding the cadmium plating should be removed from both surfaces prior to welding.
- **(c)** Secure doubler to shoe tabby welding (arc or gas method), Specification MIL-W-8611, around entire periphery of doubler.

- (4) Severely damaged shoe tabs may be repaired or replaced as follows: Refer to details A and B, figure 3-14.
- (a) Cut off damaged tab parallel to skid tube, or, if damaged tab can be straightened, reshape to original configuration.
- **(b)** If damaged tab has been cut from shoe, fabricate a similar tab from normalized 4130 steel, specification MIL-S-18729, 0.050 inch thickness. Butt weld, specification MIL-W-8611, fabricated tab along cut line of shoe, Grind weld smooth on side adjacent to skid tube.
- (c) If damaged tab has been reshaped to original configuration, fabricate a doubler from same material in preceding step b. Position doubler over existing tab and weld all around contact area of doubler and shoe. Refer to figure 3-14, detail C.

# 3-56. Assembly - Skid Shoe Assembly - High Landing Gear.

- **a.** Install screws to secure each skid shoe to the skid tube.
- **b.** Lower helicopter and remove jacks. Refer to paragraphs 1-38 and/or 1-42 (if applicable).

#### 3-57. CROSSTUBE SUPPORTS.

**3-58.** Crosstube supports (figure 3-12) Description. The crosstube is attached to the fuselage by four supports, two on each crosstube. The forward supports are a rigid type, the aft supports are spring loaded to reduce vibration during flight. The aft support is shown at figure 3-12.

#### 3-59. Crosstube Supports - Removal.

- **a.** Remove two bolts and two washers (3) securing crosstube support to fitting (5).
  - **b.** Remove support (2) from aircraft.
- **3-60.** Crosstube Supports Inspection and Repair.
- **a.** Inspect both fore and aft supports for nicks and damage.

- **b.** If there is any doubt concerning the serviceability of the aft support, disassemble the support and replace all four springs.
- **c.** Install washer between spring and two halves of support as necessary to ensure that strap is a snug fit on the crosstube. Spring dimension with support assembled should be 0.500 to 0.560 inches (refer to figure 3-12). Install cotter pins on the completion of assembly.

### 3-61. Crosstube Supports - Installation.

- **a.** Position strap over crosstube ensuring even contact between strap and crosstube.
  - b. Install two bolts and two washers at each location.

# 3-62. CROSSTUBES - HIGH LANDING

- **3-63. Description Crosstubes High Landing Gear.** The landing gear system is constructed of two tubular curved aluminum alloy crosstubes with increased wall thickness. The crosstube provides increased height and stance and right and left side step assemblies are mounted on the forward crosstube.
- 3-64. Inspection Crosstubes High Landing Gear. Refer to paragraph 3-40.

# 3-65. Acceptance/Rejection Criteria - Crosstubes - High Landing Gear.

- **a.** Remove high landing gear in accordance with paragraph 3-41.
- **b.** To separate skids from crosstubes proceed as follows:
- (1) Remove bolts and washers at saddles of crosstubes.
- (2) Pull ends of crosstubes from sockets of saddles.
- **3-67.** Repair Crosstubes High Landing Gear. The only repair permitted for a crosstube is to polish




Figure 3-12. Aft Crosstube Support Assembly




Figure 3-13. High Landing Gear Skid Tube Repair Limits

out scratches and nicks that do not exceed the limitations provided in figure 3-10.

# 3-68. Assembly — Cross Tubes — High Landing Gear.

- a. Assemble crosstubes and skids as follows:
- (1) Insert ends of crosstubes into sockets of saddles (figure 3-4).
- **(2)** Install high landing gear system in accordance with paragraph 3-43.

# 3-69. INTERCHANGE OF STANDARD GEAR WITH HIGH LANDING GEAR.

- **a.** The purpose of the following instructions is to provide interchangeability of a standard gear with a high clearance skid gear.
- **b.** To perform a skid interchange the following items are required.


QUANTITY	PART NUMBER	NOMENCLATURE
1	206-706-129-1	Kit, high gear tubular skid consisting of:
2	206-050-221-7	Support assembly
2	206-052-105-13	Strap assembly
1	206-052-108-13	Landing gear assembly
4	AN960PD416	Washer
4	NAS1304-13	Bolt

#### NOTE 2

#### NOTE 1 Fabricate doubler of normalized 4130 steel, MIL-S-18729, and of same configuration as Fabricate doubler of normalized removed tab. Grind weld 4130 steel, MIL-S-18729. smooth on side adjacent to skid 0.063 inch thickness and of tube. configuration as same damaged tab. **SEVERELY DAMAGED TAB** MAY BE CUT OFF AND WELD DOUBLER -REPLACED BY BUTT TO DAMAGED SKID WELDING DOUBLER TO SKID SHOE TAB AS SHOWN SHOE AS SHOWN (SEE (SEE NOTE 1) TAB (REF) NOTE 2) BUTT WELD 0.250 0.250 (MINIMUM) SKID SKID SHOE SHOE (REF)-DETAIL B DETAIL A (TAB REPLACEMENT) (TAB REPAIR)

SKID SHOE REPAIR/REPLACEMENT (TYPICAL)

NOTE: All dimensions are in inches.



206052-33

Figure 3-14. Repair of landing Gear Skid Tube Shoes

- **c.** Prepare the helicopter for safe ground maintenance. Refer to paragraphs 1-38 and 1-42 and proceed as follows:
- (1) Remove the existing standard landing gear as outlined in paragraph 3-6. Identify the removed gear assembly and aft crosstube attaching hardware for original installation location and helicopter serial number. Except for the forward crosstube strap assemblies and the helicopter tow rings, retain all removed items in a preserved condition for future reinstallation.
- (2) Remove tow rings attached to the forward ends of the standard gear skid tubes. Retain hardware.
- (3) Using retained hardware, install tow rings on the forward ends of the high gear skid tubes.
- (4) Raise helicopter as necessary to allow installation of high skid gear.
- (5) Place high skid gear in position and lower helicopter onto skid gear.
- (6) Secure forward crosstube with strap assemblies and hardware previously removed.
- (7) Secure aft crosstube with two support assemblies, two restraining strap assemblies, four bolts, and four washers. Refer to figure 3-15.

- (8) Return helicopter to flight configuration.
- **d.** The installation of the high landing gear system in place of the standard landing gear system affects the helicopter basic weight and balance as follows:

Weight change - +63.500 pounds

Moment arm - 73.700 inches

Moment/100 - 46.800 inch-pounds

e. Accomplish chart C entry (DD Form 365C, Basic Weight and Balance Record) to reflect the helicopter basic weight change resulting from the landing gear interchange. Refer to TM 55-405-9.

#### NOTE

Accomplishment of DA Form 2408-5 is not required for skid gear interchange action as this change only concerns the use of special purpose equipment.

**f.** Interchanging a high landing gear with a standard landing gear may be accomplished by reversing the preceding installation instructions and making the necessary DD Form 365C entries to reflect new basic weight change.




Figure 3-15. High Gear Interchange with Standard Gear

### 3-70. GROUND HANDLING TRUCKS.


**3-71. Description - Ground Handling Trucks.** The ground handling trucks, installed for towing the aircraft, consist of dual wheels, support, and a retract/extend lever for positioning the assembly manually (figure 3-16).

### 3-72. Removal - Ground Handling Trucks.

- **a.** Release extend/retract lock and retract wheels. Refer to figure 3-16.
- **b.** Release installation lock and slide wheel assembly aft.

# 3-73. Installation - Ground Handling Trucks.

- **a.** With the wheel assembly retracted, place the assembly over the skid tube,
- **b.** Align the wheel assembly mounting hole with the skid tube fitting arms and slide forward so that arms engage holes. Slide full forward so that installation lock engages the skid tube fitting. Ensure lock is engaged.
  - c. Inflate ground handling truck tires to 90 psi.



TRUCK ASSEMBLY

Figure 3-16. Ground Handling Trucks

# 3-73.1 HANDLE - JACK ASSEMBLY, GROUND HANDLING.

**3-73.2 Description - Jack Assembly.** The jack assembly or actuating handle is used in conjunction with the ground handling trucks for raising helicopter after installation of truck assemblies.

#### **NOTE**

For helicopters equipped with ATAS the jack assembly or handle must be reworked in order to clear the launcher assembly when using ground handling trucks.

# 3-73.3 REWORK - HANDLE, JACK AS-SEMBLY CS

Using existing actuating handle rework per figure 3-16.1




Figure 3-16.1 Rework Jack Assembly

# SECTION II. SKIDS AND STRUTS

(Not applicable)

# SECTION III. FLOAT LANDING GEAR SYSTEM

# 3-74. FLOAT LANDING GEAR.

**3-75. Description** — **Float Landing Gear.** The float landing gear system consists of two streamlined multi-cell, inflatable floats, float support tubes, crosstubes, and necessary fittings required to equip the helicopter for water landings. A triangular plate is mounted on the tail skid for controllability purposes and to protect the tail rotor in the event of a tail low landing on the water. Floats can only be installed after compliance with MWO 55-1520-228-30-21.

**3-76. Cleaning** — Float Landing Gear. Refer to paragraph 1-18 for general helicopter cleaning,

# 3-77. Inspection — Float Landing Gear.

- **a.** Inspect floats daily when in use to ensure inflation pressure of 1-1/2 psi is maintained.
- **b.** Inspect support tubes and crosstubes for mechanical damage and corrosion. Damage must not exceed 10% of the tube wall thickness after cleanup.

**c.** Inspect floats periodically for cuts, tears, security, and deterioration.

#### 3-78. Removal — Float Landing Gear.

- a. Support helicopter with hoist, but do not raise.
- **b.** Remove bolts and washers at straps that attach crosstubes to fuselage.
- **c.** Disconnect electrical connector from bottom of fuselage and install protective cap from dummy connector.
  - d. Raise helicopter off landing gear.

# 3-79. Disassembly - Float Landing Gear.

- a. Remove nuts (22, figure 3-17) and washers (23) that connect forward crosstube and aft crosstube to float support tubes (15 and 16) (view B-B). Remove straps (18 and 30). Remove crosstubes (6 and 5). Remove U-bolt (20). Remove blocks (19 and 29).
- **b.** Remove clamps, screws, washers, and nuts (21) that secure step to float support tubes (15). Remove four steps from float. (Figure 3-17, view C-C.)

# 3-80. Repair — Float Landing Gear.

- **a.** Repair minor holes (pin holes) in floats as follows:
  - (1) Deflate float.
- (2) Clean surface to be repaired with naphtha (C22).
  - (3) Coat surface with urethane adhesive (C20).
- (4) Cover adhesive with teflon tape (C144) smooth out all air bubbles, and tape (C143) teflon tape to hold in place until adhesive is cured.
  - (6) Cure at room temperature for 24 hours.
  - (6) Remove tape and teflon tape (C144).
- **b.** Repair major damage (cuts and large holes) in floats as follows:
- (1) Cut patch from urethane impregnated nylon one to two inches longer than hole to be repaired.

- (2) Clean area of float to be patched and mating surface of patch with naphtha (C22).
- (3) Apply urethane adhesive (C20) to both surfaces, then place bond surfaces together with firm pressure. Smooth out all air bubbles.
- (4) Cure for 24 hours at room temperature with patch held firmly in place.
- **(5)** Remove pressure and clean off excess adhesive with naphtha (C22).

# 3-81. Assembly - Float Landing Gear.

#### **NOTE**

The following steps are typical and are to be accomplished on both floats at the same time.

**a.** Spread float bag flat with filler valves (17, figure 3-17) upright.

#### NOTE

# Partially inflate floats to facilitate assembly of float landing gear.

- **b.** Insert one tube (15) into inboard boots and straps on top of float.
- **c.** Insert one tube (15) into outboard boots and straps on top of float.
- **d.** Attach one tube (16) to center straps on top of float (figure 3-17).

#### NOTE

# Install block (19) with sealant (C129) between both block and support tube and block and crosstube.

- **e.** Insert pins on three blocks (19) into forward holes in support tubes (15 and 16) as shown in figure 3-17, view B-B.
- **f.** Place six U-bolts (20) around support tubes (15 and 16), two in each block.
- **g.** Place forward crosstube (6) on blocks (19). Pins in blocks must engage holes in crosstube. (Figure 3-17, view B-B.)




Figure 3-17. Float Landing Gear (Sheet 1 of 3)




Figure 3-17. Float Landing Gear (Sheet 2)




Figure 3-17. Float Landing Gear (Sheet 3)

- **h.** Attach support tubes (15 and 16) to crosstube (6) as follows:
- (1) Place six strap assemblies (18) over crosstube (6), two on each block to engage U-bolts (20).
  - (2) Install 12 washers (23) and 12 nuts (22).

### NOTE

Tighten nuts (22) only enough to engage pins on blocks in holes in support tubes and crosstube. Final tightening will be accomplished when both crosstubes have been positioned on floats.

#### NOTE

Install block (29) with sealant (C129) between both block and support tube and block and crosstube.

- i. Insert pins on three blocks (29) into aft holes in support tubes (15 and 16) as shown in figure 3-17, view B-B.
- j. Place six U-bolts (20) around support tubes (15 and 16), two in each block.
- **k.** Place aft crosstube (5) on blocks (29). Pins in blocks must engage holes in crosstube (figure 3-17, view B-B).
- I. Attach support tubes (15 and 16) to crosstube (5) as follows:
- (1) Place six strap assemblies (30) over crosstube (5), two on each block to engage U-bolts (20).
  - (2) Install 12 washers (23) and 12 nuts (22).
- (3) Torque all nuts (22) 15 TO 20 INCH-POUNDS plus tare torque.
  - m. Install forward step (10) as follows:
- (1) Slip two clamps (21) over each support tube (15) at slots on float just forward of crosstube (6).
- (2) Attach clamps (21) to forward step (10) with four screws, washers, and nuts.

- n. Install aft step (12) as follows:
- (1) Slip two clamps (21) over each support tube (15) at slots on float between crosstube (6) and crosstube (5).
- (2) Attach clamps (21) to aft step (12) with four screws, washers, and nuts.
  - o. Inflate float as follows:
- (1) Unfasten flaps over float filler valves (17, figure 3-17), Thread fittings of float inflation tool (T10) onto float valves and tighten. Loosen knurled nuts on compartment valves.
- (2) Open valve slightly in pressure line and inflate floats slowly to 1-1/2 psi then shut off pressure valve. Do not inflate quickly and do not over inflate.
- (3) Tighten knurled nuts on compartment valves, disconnect pressure and filler lines. Fasten flaps over compartment valves,

#### 3-82. Installation — Float Landing Gear.

- **a.** Accomplish the following for initial installation.
  - (1) Remove skid type landing gear.
- (2) Retain forward crosstube strap assemblies and hardware for installation on float landing gear.
- (3) Remove two existing aft crosstube support fittings, Retain hardware for installation on float landing gear.

#### NOTE

Identify and save aft crosstube support fittings for reinstallation of skid type landing gear.

- (4) Install two aft crosstube support fittings (25, figure 3-17) with existing hardware.
- **(5)** Temporarily remove two existing forward crosstube support fittings (3) from fuselage.
- (6) Install spacer (7) at fuselage right side support fitting location with two washers and two bolts (8) and existing aft two washers, bolts, and nuts

- (32). The position of the two existing bolts must be reversed so that heads of bolts are in cabin interior.
- (7) Reinstall two existing support fittings (3) on spacers (7 and 24) with eight washers and eight bolts (8).
  - **b.** Position float landing gear under helicopter.
- **c.** Carefully lower helicopter to seat support fittings (3 and 25) on the bearing straps on crosstubes (5 and 6).
- **d.** Attach aft crosstube (5) to support fittings (25) with two straps (4), four washers, and four bolts (31).
- **e.** Attach forward crosstube (6) to support fittings (3) with existing straps and hardware.
- **f.** Remove protective cap from electrical connector on bottom of fuselage and install on dummy connector.

**g.** Connect electrical connector on forward crosstube to electrical connector on bottom of fuselage.

#### **NOTE**

Pressure test floats daily when in use to ensure 1-1/2 psi inflation is maintained.

**h.** Install plate assembly (1) on tail skid (27) with two screws, four washers, and two nuts (28).

#### **NOTE**

Mounting holes are to be drilled in the tail skid as shown in figure 3-17, for initial installation of plate assembly (1).

i. Apply a bead of sealant (C129) to the mounting edges of each support fitting after installation.

# SECTION IV. BRAKES

(Not applicable)

# **SECTION V. SKIS**

(Data not available)

# CHAPTER 4 POWER PLANT

### 4-1. GENERAL.

This chapter provides maintenance instructions for power plant related systems. This includes air induction, exhaust, cooling, oil, accessories, troubleshooting, power controls, rigging of the engine controls, engine replacement and build-up. It does not contain maintenance instructions for the engine itself. Maintenance instructions for T63-A-700 engine are contained in TM 55-2840-231-23

and the T63-A-720 engine in TM-55-2840-241 -23

#### NOTE

Maintenance procedures for both engines are identical except when noted ADH-58A (T63-A-700). © 0H-58C (T63-A-720) and OH-58A with T63-A-720 engine installed after MWO 55-1520-228-50-6 is applied.

# SECTION I. POWER PLANT

# 4-2. POWER PLANT.

4-3. Description — Power Plant. A he helicopter is equipped with a T63-A-700 gas turbine engine (figure 4-1). The engine is designed for low fuel consumption, light weight, minimum size, maximum reliability, and ease of maintenance. The engine is installed aft of the mast and passenger compartment. A two-stage helical and spur gear set is used to reduce rotational speed from 36,000 rpm at the power turbine to 6180 rpm at the output drive spline. The engine cowl aft of the engine air inlet is removable as a single unit or the hinged section the length of the engine on either side may be opened individually. The aft fairing covers the engine oil cooler, provides tail rotor drive shaft access and provides an area for entrance air.

### **NOTE**

When removing the inlet fairings, the addition of one washer is required under the upper forward fastener of the left and right fairing to attain adequate locking tension. Other hardware must be reinstalled in nut plates with additional washers to prevent bottoming in threads.

**4-4. Description** — **Power Plant.** The OH-58C helicopter is equipped with an Allison T63-A-720 gas turbine engine rated at 420 horsepower (figure 4-1 as

modified by figure 4-2). The engine is derated to 317 (five minute limit) and 270 (continuous) horsepower incurring compatibility with the main rotor transmission. The engine is an improved version of the basic engine, The engine incorporates a new bellmouth, new external hoses and tube assemblies, and new cowl side panels. The upper cowl, anti-icing control, firewall, electrical wiring installation, engine pan have been modified. The engine oil cooler is unchanged, the oil tank contains a different top plate and fittings, oil cooler blower and duct have been replaced, and supporting structure modified.

# 4-5. Cleaning — Power Plant.

# CAUTION

Any water, other then minute quantities, must be removed from the plenum chamber if known freezing conditions exist or are expected. Helicopters equipped with an engine cleaning kit must be inspected through the plexiglass windows on each side of the cowling, Look at bottom of chamber and guide vanes. Occasionally it will be necessary to remove the cowling to clear the plenum.

Helicopters serial number 71-20340 and subsequent have engine cleaning provision incorporated in the

particle separator. This consists of a bellmouth spray fitting (5, figure 4-4), tube assembly (2), and attaching hardware. The cleaning solution input fitting (3) is easily accessible through the induction fairing left side access door (6, figure 2-2). A cap (4, figure 4-4) is installed on the input fitting (3) and must be reinstalled after each cleaning operation. This installation permits cleaning solution to be force fed from outside the helicopter, through the bellmouth spray fitting (5) into the engine bellmouth, without having to remove the induction fairing. Refer to TM 55-2840-231-23 A, or TM 55-2840-241-23 for engine cleaning procedure.

4-6. Operational Checks — Power Plant. Operational check of the power plant is performed as outlined in TM 55-2840-231-23 A, TM 55-2840-241-23 Interpower plant is installed on the helicopter. Refer to TM 55-1520-228-10 and TM 55-1500-328-25 for applicable maintenance operational checks.

# 4-7. BUILDUP - POWER PLANT.

# 4-8. Inspection — Buildup — Power Plant.

- a. Inspect hose assemblies and replace if any of the following conditions exist: plies have separated, excessive cold flow, chafing, or if hose is hard and inflexible. Make sure hoses and lines are properly supported and clamps are secure. Discard and replace packings and gaskets at all points of installation requiring packings and gaskets.
- **b.** If engine replacement is caused by an accessory gearbox or bearing failure, etc., and metal contamination of the engine lubrication system is suspected, the following shall be accomplished:

#### NOTE

Do not confuse AOAP laboratory high wear concentration of iron, magnesium, etc., (measured in parts per million) as being metal chip contamination or metal particle contamination.




Figure 4-1. Engine Installation (Sheet 1 of 5)





Figure 4-1. Engine Installation (Sheet 2).



NOTE: All dimensions are in inches.




Figure 4-1. Engine Installation (Sheet 3)

206062-110-3




Figure 4-1. Engine Installation (Sheet 4)

#### TM 55-1520-228-23

- 1. Exhaust Stack
- 2. Exhaust Clamp
- 3. Engine Torque Pressure Hose
- 4. Freewheeling Assembly and Freewheeling Oil Return Hose
- 5. After Filter Sense Hose, Union and Packing
- 6. Before Filter Sense Hose, Reducer and Packing
- 7. Fuel Filter Bypass Warning Switch (ref) and Fuel Pump (ref)
- 8. Fuel Purge Line
- 9. Engine Fuel Inlet Hose, Fitting and Packing
- 10. Engine Oil Outlet Hose, Fitting and Packing
- 11. Engine Oil Inlet Hose, Fitting and Packing
- 12. Engine Oil Pressure Hose
- 13. Accessory Drive Vent Hose, Fitting and Packing
- 14. Oil Tank Vent Hose, Fitting and Packing
- 16. Combustion Chamber Drain Hose
- 16. Accumulator Kit
- 17. Freewheeling Oil Supply Hose
- 18. Aft Engine Mount Leg
- 19. Exhaust Collector Drain Tube
- 20. Heat Shield Drain Tube
- 21. Fuel Pump Seal Drain Tube Union and Packing
- 22. Bellmouth
- 23. Anti-Icing Control Actuator
- 24. Stop Screw
- 25. Governor Shaft Stop Arm
- 26. Bolt
- 27. Screw
- 28. Control Bypas Return Port
- 29. Pump Discharge Port
- 30. Lockwire
- 31. Fuel Filter Bowl
- 32. Restrictor and Packing

- 33. Clip
- 34. Fitting, Engine Mount
- 35. Restrictor and Packing
- 36. Restrictor
- 37. Starter-Generator
- 38. Cooling Duct Starter/Generator
- 39. Tachometer Generators
- 40. Combustion Chamber Drain Tube
- 41. Screw and Washer (5 each)
- 42. Bleed Air Line
- 43. Fitting and Gasket
- 44. Bleed Air Line
- 45. Fitting and Gasket
- 46. Bleed Air Line
- 47. Clamp
- 48. Clamp
- 49. Fitting at Firewall
- 50. Mounting Pad Starter/Generator
- 51. Governor Control Arm
- 52. Bleed Air Fitting
- 53. Nut
- 54. Washer
- 55. Cotter Pin
- 56. Bolt
- 57. Washer
- 58. Washer
- 59. Nut
- 60. Seal

206062-110-5

### Figure 4-1. Engine Installation (Sheet 5)

- (1) Replace oil cooler.
- (2) Remove and clean engine oil reservoir.
- (3) Remove and clean or replace oil lines.

# 4-9. Buildup - Engine Assembly.

- a. Install fuel control level on fuel control shaft.
- b. Install accumulator (16, figure 4-1) A.
- c. Install governor control arm (51), bolt (26), and screw (27) on governor.

#### NOTE


Some governors recently overhauled may require the removal of bolt (26) and screw (27) to obtain 0.010 minimum clearance as specified in paragraph 4-105; step g.

- d. Install starter-generator mounting pad (50) on engine case with new gasket.
- e. Coat tachometer generators (39) drive splines with grease (C77) and install with new gaskets on front of engine.
  - f. Install double lip seal. Refer to paragraph 4-95.
- g. Install freewheeling assembly (4). Refer to paragraph 6-33.

#### **NOTE**


Remove caps or plugs from openings prior to installing the following items.

h. Install drain tubes (19, 20, 21, and 40) and drain hose (15) to existing fittings on engine.




View looking inboard from right side of aircraft.

Figure 4-1.1. Engine Installation oil lines after MWO 1-1520-228-50-44



VIEW LOOKING INBOARD RIGHT SIDE



VIEW A-A

- 1. Clamps
- 2. Accessory Drive Vent Hose
  3. Union and Packing

- 4. Clamps
  5. Engine Oil Outlet Hose
  6. Engine Oil Inlet Hose
- 7. Oil Tank Vent Hose
- 8. Elbow, Nut, and Packing
- 9. Union and Packing 10. Reducer and Packing

Figure 4-2. Engine Installation - T63-A-72 C

## CAUTION

Do not tighten fittings and gaskets (43 and 45) until bleed air lines (42 and 44) are lined up and tightened during engine installation. Use wrench on hex boss of fitting (43) (or hold boss in soft-jaw vise if fitting is old-style round boss configuration) to prevent application of torque to fitting weld joint during assembly. Refer to figure 4-3.

- i. Lubricate new packings with engine lubricating oil and install on fittings, plug, tube adapter, and tube nipple. Install plug-in boss of fitting (43) only to the point that metal-to-metal contact is made between plug hex face and boss. Install tube adapter and tube nipple on fitting (43) in same manner. Install fittings, jamnuts, and gaskets (43 and 45) on engine but do not tighten jamnuts at this time. Refer to figure 4-3 and TM 55-2840-231-23 A, TM 55-2840-241-23.
- j. Install freewheeling oil supply hose (17, figure 4-1) to existing fitting on freewheeling assembly and secure hose to spare engine pad with clamp.
- **k.** Install packing and fitting (13) on engine. Install hose to fitting (13)  $\mathbf{A}$
- I. Install union and packing (3, figure 4-2) on engine accessory case. Install accessory drive vent hose (2) to union
- **m.** Install packing and restrictor (32, figure 4-1) on engine. Install hose (12) to restrictor (32).
- n. Install packings and fittings (14, 11, and 10) on engine.
- (1) Torque fitting (14) to engine, 55 TO 80 INCH-POUNDS.
- (2) Torque fittings (10 and 11) to engine, 75 TO 110 INCH-POUNDS.
  - o. Install hoses on fittings (14, 11, and 10).
- (1) Torque hose to fitting (14), 80 TO 120 INCH-POUNDS.
- (2) Torque hoses to fittings (10 and 11), 150 TO 200 INCH-POUNDS.

- **p.** Install elbow, nut, and packing (8, figure 4-2), union and packing (9), and reducer and packing (10) to engine.
- **q.** Install hoses (5, 6, and 7) to elbow (8), union (9), and reducer (10). Route hoses along right side of engine and secure with clamps, screws, washers, and nuts (1 and 4).
- r. Install packing and union (21, figure 4-1), packing and fitting (9) on fuel pump. Install packing and reducer (6) in the before filter port, packing and union (5) in the after filter port. Install hoses (5, 6, and 9) and tube (21) to fuel pump fittings.
- **s.** Install packing and restrictor (35) on engine. Install hose (3) to restrictor (35).
- t. Install autorelight components from removed engine on replacement engine as follows:

## CAUTION

Ensure that the exciter assembly is the correct type for engine.

- (1) If replacement engine does not have gearbox cover assembly modified around studs used to mount the tube assembly and the control mount bracket, perform the following steps. If cover has been modified proceed with step t.(2).
- (a) Locate second and fourth studs to left of gearbox magnetic plug, when viewed from rear, Leave nut and washer on to protect stud threads.

## CAUTION

Use extreme care to prevent damage to studs.

## NOTE

Remove clamp securing fuel and oil lines as necessary to facilitate installation.

**(b)** Using a hand held power grinder or file, remove outer lip of spot face until flush with washer to form a slot. This is necessary to provide a flat surface for installation of control box bracket.






Figure 4-3. Bleed Air Installation



**VIEW LOOKING AFT** 



(LOOKING INBOARD FROM LEFT SIDE)

- 1. Particle Separator
- 2. Tube Assembly
- 3. Input Fitting
- 4. Cap
- 5. Spray Fitting

Figure 4-4. Engine Cleaning Provision

- (c) Touch up reworked areas with primer (C118).
- (2) Remove two nuts from gearbox studs. Leave washers in place for bracket. Remove one nut from fuel pump mount pad.
- (3) Install control assembly on gearbox, using two reworked stud locations and bottom fuel pump mount stud as bracket mount points. Install two gearbox nuts, and torque 36 TO 40 INCH-POUNDS. Install fuel pump mount nut and torque 70 TO 85 INCH-POUNDS.
- (4) Install Pc Sense to autorelight control tube asssembly A, hose assembly C. Do not obstruct drain hole (size 69 drill, plus or minus 3 sizes) predrilled in lower lateral section (as viewed when installed) of tube. It is necessary to remove outer edge of spot face to form a slot for three tube mounting brackets. Use outboart oil filter housing stud, the top split line stud adjacent to the end data plate and the third stud to the right of the magnetic sump plug. Using a hand-held grinder, file or sharp knife, remove outer edge below washer height, and touch up rework area with primer (C118). Install brackets on top of washers and tighten nuts. (Washer may be eliminated in the event stud length is inadequate.)

## 4-10. METAL TUBE ASSEMBLY.

Refer to TM 55-2840-231-23 A , TM 55-2840-241-23 for inspection and repair.

## 4-11. SECOND ACCUMULATOR.

**4-12. Description-Second Accumulator.** An accumulator and hose assembly are installed in the line between the power turbine governor pressure port and the double check valve.

## 4-13. Inspection-Second Accumulator.

- a. Inspect accumulator for leaks and security.
- **b.** Inspect hose assembly for fraying, weather checking, tears, general deterioration, and security.
- 4-14. Removal Second Accumulator.

Refer to TM 55-2840-231-23 A TM 55-2840-241-23

- 4-15. Repair/Replacement-Second Accumulator. Refer to TM 55-2840-231-23 A, TM 55-2840-241-23 C.
- **4-16.** Installation-Second Accumulator. Refer to TM 55-2640-231-23 **A**, TM 55-2840-241-23.

## 4-17. ENGINE MOUNT FITTINGS.

- **4-18. Description-Engine Mount Fittings.** The engine mount fittings (34, figure 4-1) are installed on the left, right, and lower engine mount pads.
- **4-19. Inspection -Engine Mount Fittings.** Inspect engine mount fittings (34, figure 4-1) for cracks and evidence of corrosion.
- **4-20.** Removal -Engine Mount Fittings. Refer to TM 55-2640-231-23 **A**, TM 55-2840-241-23.

#### CAUTION

Engine must be supported during removal of engine mount fittings from an installed engine.

## NOTE

This procedure applies only to removal of side fittings. Removal of lower engine mount fitting requires engine removal. Refer to paragraph 4-30.

**a.** Remove anti-ice control actuator (23, figure 4-1). Refer to paragraph 4-52. Install lift tool (T40) on anti-ice control actuator engine pad. Connect hoist to lift tool. Apply enough tension to hold engine in place.

## **CAUTION**

Exercise extreme care when removing engine mount legs from engine mount fittings to avoid damage to main driveshaft, tail rotor driveshaft, and engine mount legs.

**b.** Remove cotter pin (55), nut (53), and washer (54) which secures the engine mount to the engine mount fitting (34).

#### NOTE

Bolts attaching engine mount to airframe may need to be loosened to facilitate removal of engine mount from engine mount fitting.

**c.** Remove lockwire and the three bolts (56) and washers (57) which secure the engine mount fitting to the engine mount pad. Remove fitting.

## 4-21. Repair-Engine Mount Fittings.

- a. Replace cracked mount fittings with like serviceable items.
- **b.** Remove corrosion in accordance with instructions contained in TM 43-0105.
- 4-22. Installation-Engine Mount Fittings.

#### **CAUTION**

Inspect to assure the correct bolts (56, figure 4-1) are used to install the engine mount fitting. Do NOT use engine container shipping hardware.

- a. Install engine mount fitting (34, figure 4-1) on engine mount pad and secure with three washers (57) and bolts (56). Torque bolts 100 TO 140 INCH-POUNDS and lockwire (C96).
- **b.** Attach engine mount to engine mount fitting (34, figure 4-1), and secure with washer (54) and nut (53). Torque nut **95 TO 110 INCH-POUNDS** and secure with cotter pin (55). Torque bolts attaching engine mount to airframe. Refer to paragraph 2-308.
  - c. Remove hoist and lift tool (T42) from engine.
- **d.** Install anti-ice control actuator on engine. Refer to paragraph 4-53.

## 4-23. ENGINE ASSEMBLY.

- **4-24. Description -Engine Assembly.** Refer to TM 55-2840-231-23 for information pertaining to the T63-A-700 engine and TM 55-2840-241-23 for T63-A-720 engine. For build-up of the assembly, refer to paragraph 4-7 and to figure 4-1. For installation of electrical cable assemblies on engine assembly, refer to figure 4-5.
- **4-25. Servicing -Engine Assembly.** Procedures for engine oil system servicing are contained in paragraph 1-8.

- **4-26. Adjustment -Engine Assembly.** Refer to TM 55-2840-231-23 **A** , TM 55-2840-241-23 **C**
- **4-27. Troubleshooting-Engine Assembly.** Refer to TM 55-2840-231-23 **A** , TM 55-2840-241-23 **C** .
- 4-28. Maintenance Precautions Engine Assembly.
- **a.** Use extreme caution to prevent dirt and foreign objects from entering the engine. Place temporary covers on all exposed openings. All open hoses and tubing shall be protected with plastic or metal caps. If suitable caps are not available, use commercial grade aluminum foil crimped to fit the particular opening.

#### WARNING

Lubricating oil may cause a skin rash if prolonged contact is allowed. Use solvent in well-ventilated area. Do not inhale vapors, or allow to come in contact with skin, eyes, or clothing. Observe proper fire prevention rules.

#### **CAUTION**

Do not use tape to seal fuel or oil openings. Tape adhesive is soluble in fuel or oil and can cause contamination.

- **b.** Apply lubricating oil (C101) as required to assist in removal of parts during disassembly. On parts to be installed, remove all traces of oil with drycleaning solvent (C62).
- **c.** Protect engine from dust and inclement weather. If practical, perform engine maintenance in closed areas.

## WARNING

The ignition unit contains a very small amount of radioactive material (Cesium-Barium 137) and normally requires no handling precautions. However, severely damaged units that have been broken open must be handled with forceps or gloves, and disposed of in accordance with AR-755-15 and TB 55-1500-314-25.

d. Before removing engine components, disconnect the electrical cable assembly at the




Figure 4-5. Instillation of Electrical Cable Assembly Engine

ignition unit and ground the ignition leads. Refer to figure 4-5.

**e.** Discard used lockwire, preformed packings, cotter pins, gaskets, tabwashers, lockpins, keywashers, and lockwashers.

#### CAUTION

## Use care to prevent damage to lockwire holes.

- f. When removing hoses and electrical lines, remove clamps from brackets. Generally, brackets are left on the engine unless otherwise stated.
- **g.** When disconnecting electrical connectors or hose and tubing fittings, remove clamps on brackets as required to gain slack and avoid damage to connectors and fittings.
- **h.** Remove hose assemblies that may be damaged during removal of engine components.

#### CAUTION

Do not use cadmium-plated tools for any of the disassembly or reassembly procedures given in this manual. Cadmium plating has a tendency to chip. If these chips enter the engine, they will contaminate the lubrication system and cause magnesium parts to deteriorate.

- i. Avoid hanging objects (tools, lights, etc.) on hose assemblies.
- **j.** Care shall be taken to route and clamp hose assemblies securely. Chafing shall be avoided at all times. Proper clamping and chafe pads shall be used at all times.
- **k.** During removal, examine all parts for serviceability. Look for indications that work was incorrectly performed during previous repairs or overhauls. Report such indications in accordance with current practice.
- I. Any bellmouth (22, figure 4-1) containing loose nutplates or (pop-type) rivets used for installing the

nutplates should have the nutplates changed. Contact ATCOM Engineering for rework instructions for installing new nutplates for the OH58A and OH-58C. Ensure bellmouth gasket is not deteriorating, cracking or deformed. Replace gasket, if any of these conditions exist

m. When removing or installing oil, fuel, and air hose assemblies, do not apply torque to the narrow hex nut of the sleeve and nipple. Torque must be applied only to the wide hex nut. When loosening or tightening the wide hex nut, secure the nipple or sleeve to prevent twisting of the hose assembly.

#### WARNING

Prolonged contact with lubricating oil may cause a skin rash. Those areas of skin and clothing that come in contact with lubricating oil should be thoroughly washed immediately. Saturated clothing should be removed immediately. Areas in which lubricating oil is used should be adequately ventilated to keep mist and fumes to a minimum.

## CAUTION

Lubricating oil may soften paint upon contact. If lubricating oil is spilled on painted surfaces, these surfaces should be thoroughly washed.

To ensure total seating of preformed packings, remove identifying paint by carefully rubbing or scraping paint with finger or fingernail. No not use a sharp instrument which could damage the packing.

#### NOTE

Fittings being tightened to prescribed torque should have dry, clean threads.

**n.** Remove protective tape, caps, plugs, and covers as necessary for installation.

## 4-29. Preparation for Removal - Engine Assembly.

## CAUTION

Refer to TM 55-2840-231-23 A, TM 65-2840-241-23 C, and TB 55-9150-200-24 for preservation requirements.

- a. Disconnect battery.
- **b.** Drain oil.
- c. Remove engine cowling and exhaust stacks.
- **d.** Remove passive defense system (armor panels) from engine compartment forward firewall if installed.
- **e.** Disconnect the engine to transmission drive shaft at the freewheeling unit only. Remove the tail rotor drive shaft from the number one and number two disc assemblies.
- **f.** Remove the starter-generator cooling duct (38, figure 4-1) by disconnecting the clamps (47 and 48) at each end. Remove the starter-generator (37) at mounting pad (50).

#### NOTE

When electrical cables and plugs are disconnected from airframe plugs, cables and plugs should be secured to engine in a manner that will avoid interference when removing engine assembly.

If the starter-generator is not to be replaced, do not remove the electrical cables from it.

**g.** Remove the electrical plug at the gas producer tachometer (12, figure 4-5), ground wire from tachometer mounting stud, electrical plugs from two chip detectors (10 and 11), turbine outlet temperature (TOT) cables from the terminal block on the engine fireshield, and two clamps that secure the anticollision and anti-icing actuator cables to the engine.

#### NOTE

When removing fuel and oil hoses, lines and fittings, ensure residual fluids have been drained. Cap all open ports until reinstallation. All parts removed should be inspected for serviceability.

- h. Disconnect the engine oil inlet hose (11, figure 4-1), outlet hose (10), and oil tank vent hose (14) from the aft firewall fitting and disconnect the hose clamps securing the hoses to the engine support legs.
- i. Disconnect engine oil inlet hose (6, figure 4-2), outlet hose (5) and oil tank vent hose (7) from aft firewall fittings. Disconnect clamps (4) securing hose to engine support leg.
- **j.** Disconnect the engine fuel inlet hose (9, figure 4-1) at the lower firewall and disconnect the clamps securing it to the lower support leg.
- **k.** Disconnect the engine oil pressure hose (12) and torque pressure hose (3) from the lower firewall fittings.
- I. Disconnect the large bleed air pressure line (42) from the fitting (43) on upper right section of the diffuser. Disconnect the heater bleed air line (44) from the fitting (45), lower left side of the diffuser. Discard packings.
- m. Disconnect the gas producer control tube from the fuel control lever.
- **n.** Remove the screws and washers (41), inboard row only, attaching the bellmouth (22) to the engine adapter flange.
- **o.** Disconnect the freewheeling unit hoses (4 and 17) and clamp from the fittings on the forward firewall and cap fittings immediately.

## **NOTE**

## If fittings are not capped the main transmission will drain.

- **p.** Disconnect the two fuel differential pressure hoses (5 and 6) from the fuel filter bypass warning switch (7) fittings.
- **q.** Disconnect the linear actuator from the governor control lever.

- **r.** Disconnect the particle separator bleed air line (46) at the firewall fitting (49). Discard packing.
- s. Remove electrical plug at the power turbine tachometer (6, figure 4-5), two ground wires on the tachometer studs, and the terminal at the igniter (7) input stud.
- t. Remove the anti-icing control tube from the engine anti-icing valve.
- **u.** Remove the clamps and ground wire (figure 4-5, section B-B), anti-icing control actuator (23, figure 4-1) and control tube from the pad on top of the engine, store on the lower firewall, electrical cable disconnect is not required.

#### 4-30. Removal - Engine Assembly.

## Premaintenance Requirements for Removal of Engine Assembly

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	AII
Special Tools	(T40)
Test Equipment	None
Support Equipment	(S12)
Minimum Personnel Required	Three
Consumable Materials	None
Special Environmental Conditions	None

- a. Install the engine lifting tool (T40) to the engine anti-icing control pad. Refer to TM 55-2840-231-23P
   A TM 55-2840-241-23P
- **b.** Connect the overhead hoist and take up the slack.

## CAUTION

Exercise extreme care when removing engine mount legs from engine mount fittings to avoid damage to main driveshaft, tail rotor driveshaft, and engine mount legs.

- **c.** Remove engine mounts (1 and 2, figure 2-61) from engine mount fittings (34, figure 4-1).
- d. Carefully lift the engine, being sure that all connections between engine and airframe are disconnected.
- **e.** Remove engine mounting fittings (34) (3 each) and replace with engine stand fittings.
- **f.** Position engine in turnover stand per TM 55-2840-231-23 **A** ,, TM 55-2840-241-23 **C** Remove engine hoist.
- **g.** If required, prepare engine for return to overhaul facility as follows:
- (1) Remove hose (3, figure 4-1) from restrictor (35) on engine, Remove restrictor and packing (35),
- (2) Remove hoses (5, 6, and 9) and tube (21) from fuel pump (7). Remove union and packing (5), reducer and packing (6), fitting and packing (9), union and packing (21) from fuel pump.
- (3) Remove hoses (10, 11, and 14) from fittings on engine.
- (4) Remove fitting and packings (10, 11, and 14) from engine.  $\mathbf{A}$
- (5) Remove hoses (5, 6, and 7, figure 4-2) from elbow (8), union (9), and reducer (10) on engine.
- (6) Remove elbow (8), union (9), and reducer (10) from engine, Discard packings.
- (7) Remove engine oil pressure hose (12, figure 4-1) from restrictor (32). Remove restrictor (32) and packing from engine.
- (8) Remove hose (13) from fitting. Remove fitting and packing from engine.
- **(9)** Remove hose (2, figure 4-2) from union (3) on engine.

- (11) Remove hose (17, figure 4-1) from existing fitting on freewheeling assembly and damp from spare engine pad.

#### **CAUTION**

Use wrench on hex boss fitting (43) (or hold boss In soft-law vise if fitting is old-style round boss configuration) to prevent application of torque to fitting weld joint during disassembly. Refer to figure 4-3.

- (12) Remove fitting, jamnut and gasket (43, figure 4-1), and fitting, jamnut, and gasket (45) from engine. Remove plug from fitting (43) and tube adapter and tube nipple from fitting (45). Discard packings.
- (13) Disconnect drain tubes (19, 20, 21, and 40) and drain hose (15) from existing fittings on engine

#### NOTE

## Cap or plug all openings.

- (14) Remove freewheeling assembly (4).
- (15) Remove tachometer generators (39) from front of engine.
- (16) Remove starter-generator mounting pad (50) from engine.
- (17) Remove screw (27), bolt (26), and governor control arm (51) and retain for installation on the replacement engine.
- (18) Remove fuel control lever from fuel control shaft.
- (19) Remove autorelight components for reinstallation on replacement engine as follows:
- (a) Remove tee assembly from engine being removed and elbow fitting from replacement engine. Install tee fitting in replacement engine and torque jamnut to **55 TO 80 INCH-POUNDS**. Install elbow in removed engine.
- (b) Remove tube assembly and attaching damps. Reinstall nuts on studs.

(c) Remove autorelight control assembly, bracket assembly, and bracket. Reinstall nuts on engine studs.

## 4-31. Inspection Engine Assembly.

- a. Inspect external hoses, tubing, and electrical cables on engine assembly for damage and serviceability before engine assembly is reinstalled in helicopter airframe.
- b. If engine assembly is to be reinstalled, inspect engine assembly in accordance with TM 55-2840-231-23 A, TM 55-2840-241-23 C.
- **4-32. Repair/Replacement Engine.** Refer to TM 55-2840-231-23 A, TM 55-2840-241-23 C for repair of engine and engine furnished components.

## 4-33. Installation Engine Assembly.

#### CAUTION

Prior to installation of engine, ensure that two accumulators and one double check valve are installed on engine to prevent damage to mast and transmission.

#### NOTE

Torque values for lines and fitting are specified in TM 55-2840-231-23 A, TM 55-2840241-23 C and TM 1-1500-204-23.

- a. Install the engine lifting tool (T40) to the engine anti-icing control pad.
  - b. Connect the overhead hoist and take up slack
  - c. Lift engine out of the engine stand.
- d. Remove three engine stand fittings and install three engine mount fittings (34, figure 4-1) using bolts (56) and washer (57) (washer under bolthead). Torque bolts 100 TO 140 INCH-POUNDS and lockwire (C96).
- e. Hoist engine over airframe and lower carefully into position.

#### **CAUTION**

Exercise extreme care when installing engine to engine mount legs to avoid damage to main driveshaft, tail rotor driveshaft, and engine mount legs.

- **f.** Attach engine mounts (1 and 2, figure 2-61) to left, right, and lower engine mount fittings (34, figure 4-1). Install washers (54) and nuts (53). Torque retention nuts **95 TO 110 INCH-POUNDS** and secure with cotter pin (55).
- **g.** Torque bolts attaching engine mounts to airframe. Refer to paragraph 2-308.
- h. Remove hoist from engine, lift tool and remove tool from engine.
- i. Install anti-icing control actuator (23) and control tube on top engine pad. Install clamps and ground (figure 4-5, section B-B).
- j. Install anti-icing control tube to engine anti-icing valve.
- **k.** Install anti-icing control tube to engine anti-icing valve, rotating valve lever 90 degrees clockwise. Torque valve coupling nut **65 to 75 INCH-POUNDS.**
- **I.** Install electrical terminal on the igniter exciter (7) input stud, electrical plug on power turbine tachometer (6), and two ground wires on tachometer.

#### **CAUTION**

Hold the tube nipple with wrench when connecting line (46, figure 4-1) to fitting (45) to prevent installation torque from damaging fitting. Refer to figure 4-3.

m. Connect rigid end of line (46, figure 4-1) to the firewall fitting (49) and to the tube nipple installed with the tube adapter on fitting (45). Torque to 180 TO 200 INCH-POUNDS. Position fitting (45) in engine for best alignment of lines (44 and 46), hold in place and tighten jamnut on fitting (45) 55 TO 80 INCH-POUNDS. Install knurled nut and new packing lubricated with engine oil (C103), between the two expandable washers on the aft side of the beaded end of the bleed air line (44).

Tighten knurled nut maximum hand tight and lockwire (C96) in position.

**n.** Connect governor control lever to linear actuator.

#### NOTE

Refer to TM 1-1500-204-23 for installation of hoses and tubing.

- **o.** Connect fuel filter sense hoses (5 and 6) to fuel filter bypass warning switch (7) fittings:
- **p.** Remove caps from freewheeling unit fittings and install hoses (4 and 17) to fittings. Install clamp to fittings on firewall.
- **q.** Align bellmouth (22) and seal (60) with engine adapter flange. Install screws and washers (41).
- **r.** Connect fuel control lever to gas producer control tube.
- s. Adjust position of fitting 43) per TM 55-2840-231-23 A, TM 55-2840-241-23 . If necessary, line (42) should be bent to obtain proper free state alignment. Hold position of fitting and tighten jamnut 55 TO 80 INCH-POUNDS. Install new packing, lubricated with engine oil, between the two expandable washers on the beaded end of the line (42). Connect line to fitting (43) and tighten knurled gland nut maximum handtight. Install lockwire (C97) between gland nut and plug.
- t. Install new packing, lubricated with engine oil, between the two expandable washers on the lower end of bleed air lines (42 and 44). Connect lines to fitting (52) and tighten knurled gland nuts maximum hand tight (after upper ends of lines are properly positioned). Lockwire (C96) the two gland nuts together.

#### CAUTION

Engine oil pressure hose and engine torque pressure hose may be inadvertently crossed. Do not allow hoses to twist while applying torque. Refer to figure 4-1.

#### NOTE

When connecting oil and fuel hoses do not allow lines to twist when tightening.

- **u.** Connect engine oil pressure hose (12) and torque pressure hose (3) to lower firewall fittings.
- **v.** Connect engine fuel inlet hose (9) to lower firewall fitting and secure with clamps to lower engine support leg.
- w. Prime engine oil pump. Refer to paragraph 1-8. Connect engine oil inlet hose (11), outlet hose (10), and oil tank vent hose (14) to aft firewall fittings. Install clamps to secure hoses to engine support legs.
- **x.** Prime engine oil pump. (Refer to paragraph 1-8.) Connect engine oil inlet hose (6, figure 4-2), outlet hose (5), and oil tank vent hose (7) to aft firewall fittings.
- y. Install clamps (1 and 4) to secure hose (2 and 5) together and hose to engine support leg.
- **z.** Install TOT cables to terminal block on engine fireshield, cannon plugs to the two chip detectors (10 and 11, figure 4-5), ground wire to tachometer mounting stud and electrical plug to gas producer tachometer (12).
- **aa.** Install starter-generator (37, figure 4-1) on mounting pad (50). Install cooling duct (38) and clamps (47 and 48). To prevent cracking duct, do not overtighten clamps. Refer to paragraph 9-43.

## NOTE

## Install compressor section armor (passive defense system) as required.

- **ab.** Connect the engine to transmission driveshaft at the freewheeling unit. Refer to paragraph 6-15.
- ac. Remove covers from exhaust and inlet ports. Install engine cowl and exhaust stacks (1), clamps (2), and accessory drive vent hose (13).
- **ad.** Inspect engine to ensure all installations are complete and secure.

## CAUTION

Ensure combustion chamber drain hose (15, figure 4-1) has been properly torqued and does not rub on the tail rotor driveshaft. Refer to figure 4-6. Drain hose must be snug, restrained from rotation after nut is torqued.

ae. Service engine oil tank. Refer to paragraph 1-7.

- **af.** Lubricate tail rotor driveshaft coupling splines with grease (C77) and install tail rotor driveshaft.
- ag. Rig all controls and perform operational check of engine. Refer to TM 55-2840-231-23 A, TM 55-2840-241-23 C, and TM 55-1520-228-10.

## 4-34. BLEED AIR INSTALLATION.

- **4-35. Description - Bleed Air Installation.** The bleed air lines from the engine supply air for the environmental control as necessary. Bleed air is mixed with outside air to maintain a comfortable environment within the helicopter.
- **4-36. Inspection Bleed Air Installation.** Inspect metal tubes and fittings (figure 4-3) for leaks, nicks, evidence of leakage, and security.
- **4-37.** Removal Bleed Air Installation. Refer to figure 4-3, Bleed Air Installation.
- **4-38.** Repair/Replacement Bleed Air Installation. Repair of bleed air tubings and fittings is limited to replacement of defective parts with the serviceable items.
- **4-39. Installation Bleed Air Installation.** Refer to figure 4-3, Bleed Air installation. Install knurled nut and new packing lubricated with engine oil (C103) between two expandable washers on the aft side of the beaded end of bleed air lines.




Figure 4-6. Combustion Chamber Drain Hose Installation

## SECTION II. COOLING SYSTEM

(Not Applicable)

## SECTION III. AIR INDUCTION SYSTEM

#### 4-40. AIR INDUCTION SYSTEM.

**4-41. Description - Air Induction System.** The engine air inlet system consists of an induction fairing with air inlets on each outboard side. This fairing provides mounting for the particle separator. Removable reverse flow inlet fairing maybe installed over the air inlets on modified induction fairings. These reverse flow fairings minimize ram effect of falling or blowing snow, thus permitting effective operation of the particle separator and preventing engine flame-out caused by ingestion of snow.

#### NOTE

Dirty or clogged air induction system may cause high TOT during start.

#### 4-42. PARTICLE SEPARATOR.

**4-43. Description - Particle Separator.** The particle separator removes dirt and other contaminants from the incoming air and ejects the dirt out eductor tubes on either side of the fairing. This allows cleaned air to enter the engine compressor section.

## Premaintenance Requirements for Removal and Repair of Particle Separator

Condition	Requirements
Model	OH-58A/C
Part No. Serial No.	AII
Special Tools	(T38)
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	One

Condition Requirements

Consumable Materials (C61) (C69) (C107) (C136)

Special Environmental None Conditions

4-44. Cleaning - Particle Separator.

## CAUTION

Do not use water hotter than 140°F (60°C) when cleaning particle separator. Exercise care in all cleaning phases to prevent damage to filter elements. Do not exert any pressure on the swirls.


- a. Ensure eductor tubes are removed
- **b.** Remove trash from interior of particle separator through openings where eductor tubes were installed.
- c. Clean particle separator, using a dishwashing compound (C61) and lukewarm water.
  - d. Rinse with clean water and allow to dry.

#### 4-45. Inspection - Particle Separator.


a. Inspect for cracked, damaged, loose, clogged, or missing filter elements.

## NOTE


Use only light finger pressure to determine security of the swirls in the element tubes. Firm pressure will break the adhesive bond between the swirl and the tube and result in a loose swirl.



Change 8 4-21



VIEW LOOKING INBOARD LEFT SIDE



- 1. Forward Transmission Fairing
- 2. Induction Fairing
- 3. Particle Separator
- 4. Engine Cowl
- 5. Induction Fairing Access Door
- 6. Clamp
- 7. Eductor Tube
- 8. Screw
- 9. Rubber Boot
- 10. Reverse Flow Inlet Fairing

Figure 4-7. Particle Separator (Sheet 2)

- (1) Cracks in filter element tubes are acceptable if no two cracks converge.
- (2) Damage to the swirl vanes is considered negligible if no more than 0.250 inch of the leading or trailing edge of each vane is eroded away or broken off. Jagged tears in the first 0.250 inch of each vane should be trimmed off to prevent further tearing.
- **b.** Inspect for security and condition of mounting screws and nutplates.
- **c.** Inspect case front and rear for cracks, security, and fit. Replace particle separator if cracks exist.
- **d.** Inspect eductor tubes for cracks, distortion, brittleness, restrictions, and security of mounting.
- (1) Damage inboard of mounting requires replacement of eductor tubes.
- **(2)** Damage outboard of mounting which does not affect security of mounting is permissible.
- **e.** If blockage of the ejector system is suspected, inspect as follows:
- (1) Inspect all bleed air lines and fittings from the engine to the particle separator for air leaks.
- (2) With the engine running, check for pressure flow at each of the six eductor tubes (10, figure 4-7, sheet 1). A suggested method is by using a soft rag such as a handkerchief.
- (3) If pressure is not at each of the eductor tubes, check all of the bleed air lines and fittings for possible air leaks.
- (4) if any of the six editor tubes do not have positive pressure present, insert a plastic tube (approximtely 7/16 inch inside diameter) into the eductor tube (10) and over the nozzle (11). Check to make sure the manifold block (12) is not blocked internally (blow into the tube).
- **(5)** if pressure is not present, remove the nozzle and visually check that the nozzle internal passage is not obstructed. Refer to paragraph 4-47.

## **CAUTION**

The nozzle Internal diameter is a precise size; changing its shape or size will result in an engine power loss.

**f.** Inspect rubber boot for security, tears, and deterioration.

#### NOTE

The following is a temporary repair only.

**g.** If boot (9, figure 4-7, sheet 2) fails the preceding inspection, remove boot by cutting boot around the edge of the eductor tube. Retain clamp (6) for later use. Discard cut portion of boot. Clean the remaining portion of the boot and the adjacent part of the eductor with MEK (G107) and seal the area between the eductor tube and boot with sealant (C129).

## NOTE

The exterior of the induction fairing may show signs of improper fit and deteriorating seais by producing "tracks", a indication of air entering through opening or defective seals.

**h.** Inspect particle separator to induction fairing for fit and sealing. If areas of leakage are found, remove particle separator and repair seal. Refer to paragraph 4-46 and 4-47.

#### NOTE

Higher engine wear can be caused by air leakage around the particle separator from deteriorated seals or poor fit of the cowling, allowing erosive material into the engine. Most leakage occurs at the seal between the induction fairing and the forward firewall. However, any opening where air can be drawn into the engine other than through the particle separator must have an adequate seal. Other areas of concern are the engine bellmouth seal and the sides of the induction fairing.

#### TM 55-1520-228-23

i. Inspect the forward firewall seal for fit and sealing. If areas of leakage are found, repair seal. Refer to paragraph 4-47.

## **4-45.1 DELETED**

## 4-46. Removal - Particle Separator.

- **a.** Remove forward transmission fairing (1, figure 4-7, sheet 2). Refer to paragraphs 2-39 A or 2-40 C.
  - **b.** Remove transmission induction fairing (2).
- **c.** On helicopters equipped with the improved particle separator installation proceed as follows:
- (1) If installed, remove attaching hardware and reverse flow inlet fairings.

- (2) Remove clamp (6, figure 4-7) securing rubber boot (9) to each eductor tube (7) on right and left side of induction fairing. If the clamp (6) is missing and the area around the eductor tubes was previously sealed with sealant (C129), scrape off the bulk of the old sealant using a plastic scraper and remove the remaining sealant with MEK (C107) and scouring pad (C109).
- (3) Remove four screws (8) attaching each eductor tube (7) to particle separator (3) on right and left side of induction fairing.
- **(4)** Remove eductor tubes (7) from particle separator (3).
- **d.** Remove 21 screws attaching particle separator (3) to induction fairing (2) (10 from around top, 7 from underneath and 4 from induction fairing side channel into particle separator).
- **e.** Remove particle separator (3) from induction fairing (2).

## 4-47. Repair - Particle Separator.

**a.** Individual filter elements failing inspection in paragraph 4-45 step a. (1) may be blocked off by placing a piece of tape (C136) over the element opening. Separators containing 25 or more damaged two-piece filter elements must be repaired. Separators with 25 or more damaged one-piece elements must be replaced.

## **NOTE**

The majority of particle separators in the field contain reparable two-piece filter elements. Most reparable elements are white (colorless) though some may be other colors except black. All black filter elements are one-piece and cannot be repaired.

**b.** Repair two-piece elements as follows: (AVIM)

#### NOTE

The repair kit contains material to repair 20 filter elements. Determine number of elements to be repaired and order kits accordingly.


- (1) Prepare outlet holes by removing any extraneous epoxy compound which might interfere with outlet installation. (Hole diameter 0.599 to 0.604 inch.)
- **(2)** Place outlet (4, figure 4-8) over installation tool (T38), faired end toward tool, and insert outlet into outlet plate from rear side of housing. Gently push tool until outlet is firmly in place. The outlet groove will firmly seat the outlet in its proper orientation.

- (3) Install the vortex generator in the vortex tube from the front side of panel. Allow center of vortex generator to protrude from vortex tube approximately 0.094 inch.
- (4) Mix resin and hardener completely for at least two minutes. Mix two ounces of AA-9500-1D140 Part A with 0.6 ounce Part B, or mix Part A with Part B in 20:6 ratio by volume.

## NOTE

Installation should be completed prior to mixing epoxy. Compound is usable for approximately 30 minutes.

**(5)** Put mixed epoxy into 2.50 cc syringe with needle attached.



- 1. Vortex Generator Swirls
- 2. Tube Plate (Front]
- 3. Vortex Tube
- 4. Outlet
- 5. Outlet Plate (Rear)

Figure 4-8. Cross-section of Particle Separator

#### TM 55-1520-228-23

- (6) Apply epoxy to each vane of vortex generator to secure it to vortex tube. Apply epoxy completely around outlet to secure it to the outlet plate.
- (7) Position particle separator so outlet tubes are vertical to prevent dripping of epoxy and allow to remain in position for **12 to 24** hours for complete cure of epoxy.
- c. Loose swirls may be repaired at scheduled maintenance periods by pulling the swirls back in place and bonding with fairing compound (C69) thinned to brushing consistency with MEK (C107). Apply mixture carefully with an artist paint brush.
- d. Repair the particle separator to induction fairing seal as follows:
- (1) Clean off seal area to be replaced by scraping off old seal (6, figure 4-7, sheet 1) followed by cleaning with MEK (C107).
  - (2) Peel cover from adhesive side of seal.
  - (3) Install seal to previous seal location.
  - (4) Trim any excess seal (a razor is acceptable).
- (5) Inspect plenum chamber area and remove any foreign or repair material.
- (6) Reinstall particle separator (if removed) and induction fairing. Refer to paragraph 4-48.
  - e. Repair the forward firewall seals as follows:
- (1) Remove both old seals (7 and 8, figure 4-7, sheet 1) from firewall.
- (2) Clean off seal area by scraping off any old seal and sealing material followed by cleaning with MEK.
- (3) The seal (7), P/N 206-062-901-153 will be installed over gaps between the fore and aft firewall flanges (4) Abrade silicone rubber seal with 80 grit abrasive paper. Clean the abraded area with a toluene wetted cloth. Wipe the area dry with a clean dry cloth. (5) Sand off firewall in bonding area to bare metal.

- (6) Clean the area by wiping with a cloth wetted with Aliphatic Naphtha, Type II
  - (7) Wipe the area dry with a clean, dry cloth.
- (8) Brush silicone primer (MIL-P-8585) to the nonsilicone surface to be bonded.
- (9) Air-dry the primer for a minimum of 30 minutes.
- (10) Brush a 10to 15 mil. coating of the mixed adhesive (A4000) (C34) to both surface to be bonded.
- (11) Air-dry the adhesive (A4000) (C34) for a minimum of one hour and not to exceed eight hours.
- (12) Apply seal (7) bead side down, along center of firewall flanges gap. Press together the two adhesive coated surfaces. Apply firm pressure until cured.
- (13) Cure seal application for 24 hours at room temperature for 50 percent holding strength. Maximum cure is 4 to 7 days.

#### NOTE

Use the following If accelerated cure cycle is needed:

TEMPERATURE
120 Degree Max
(Air Circulating Oven)

TIME (HOURS)
18 Maximum Cure

- (14) Install aft seal (8), P/N 206-062-901-157 to aft part of firewall (2) with pro-seal.
- f. An alternate repair method for the particle separator to induction fairing seal is as follows:

## NOTE

## The following alternate repair method may also be used for the forward firewall seals.

- (1) Clean off seal area to be repaired by scraping off any old seal and sealing material followed by cleaning with MEK (C107).
- (2) Mask area where seal is to be applied with tape (C143).

- (3) Apply a bead of room temperature vulcanized (RTV) adhesive (C159) to the seal repair area.
- (4) Cover the uncured RTV with plastic sheet (Cl 60). (To create a parting surface).
- (5) install induction fairing (3, figure 4-7, sheet 1) on particle separator with fasteners finger tight and allow RTV to cure.

#### NOTE

Local application of heat not to exceed 125 degrees Fahrenheit will aid curing. Excessive heat may cause bubbles or poor adhesion.

(6) Remove induction fairing from particle separator and remove plastic sheet.

#### NOTE

Check that RTV has cured and if necessary allow additional time for curing with the plastic sheet removed.

- (7) Trim RTV (a razor is acceptable) and remove masking tape.
- (8) Inspect plenum area and remove any foreign or repair material.
- (9) Reinstall particle separator and induction fairing. Refer to paragraph 4-48.
- g. Removal and replacement of particle separator nozzles is as follows:
- (1) Install a 5/16 extra deep hex socket onto a socket extension and wrench.

#### CAUTION

Use care when removing the nozzle to avoid damage to the rubber boot on the eductor assembly.

## NOTE

Socket must be capable of 2 1/16 inch depth and 1/4 inch diameter or greater clearance. If a standard deep socket is

## used there may be insufficient clearance in eductor tube.

- (2) insert socket wrench into the eductor tube and remove nozzle.
  - (3) Apply loctite to replacement nozzle threads.
- (4) Place nozzle in socket extension and install nozzle in eductor tube.
  - (5) Torque nozzle, 50 to 70 Inch-Pounds.

## 4-48. Installation — Particle Separator.

## **CAUTION**

Ensure particle separator, engine compressor inlet area and the surrounding area is free of all foreign material prior to installation of the particle separator.

- **a.** Position particle separator (3, figure 4-7, sheet 2) in aft section of induction fairing (2).
- **b.** Secure particle separator to induction fairing with 21 screws (10 around top, 7 underneath, and 4 through induction fairing side channel into particle separator). To avoid crushing aft separator wall, apply torque to 10 **TO 12 INCH-POUNDS** to 10 upper screws. Apply torque to 15 **TO 20 INCH-POUNDS** to all other screws.
- c. On helicopters equipped with the improved partitle separator installation, proceed as follows:

## **CAUTION**

## Use care when installing eductor to prevent tearing rubber boot.

- (1) Insert eductor tubes (7) into particle separator (3) and secure each with four screws (8).
- (2) Stretch rubber boot (9) over each eductor tube (7) and secure with clamp (6). If the area between the eductor tube and boot was previously sealed with sealant (Cl 29), clean the remaining portion of the boot and the adjacent part of the eductor tube with MEK (Cl 07) and seal the area with sealant (C129).
- (3) install reverse flow inlet fairings with removed attaching hardware.

#### NOTE

When removing Inlet fairings, addition of one washer is required under upper forward turnlock fastener of left and right fairing to attain adequate locking tension. Other hardware must be reinstalled in nut plates with additional washers to prevent bottoming of thread.

- d. Install induction fairing.
- e. Install forward transmission fairing. Refer to paragraph 2-43.

#### 4-49. ENGINE ANTI-ICING CONTROL

- **4-50. Inspection Engine Anti-icing Control**. The engine anti-icing actuator (1, figure 4-9), located on upper forward section of engine, provides electrical remote control of the engine anti-icing control valve and is energized through the **ENG. DE-ICE** circuit breaker and **ENG. DE-ICE** switch on the overhead console.
- **4-51. Inspection Engine Anti-icing Control**. Actuate **ENG. DE-ICE** switch and observe that actuator responds until it stops of its own accord in ON and OFF positions. Replace if actuator fails to operate. Check for preload. Refer to paragraph 4-53.

## 4-52. Removal Engine Anti-icing Control.

- a. Remove engine cowling.
- b. Disconnect electrical harness from actuator.
- c. Remove pin (11, figure 4-9), washer (9), and cotter pin (8) attaching connecting link assembly (7) to anti-icing valve lever (16).
- d. Remove pin (4), washer (5), and cotter pin (6) attaching tube assembly to actuator level (3).
- e. Remove lockwire, bolts (17 and 19), washers (18 and 20), and spacers (21 and 22). Remove actuator (1) with bracket (15) from engine.
- f. Remove lockwire, loosen screw (2), and remove actuator lever (3).

g. Remove four screws (13) and washers (14) attaching actuator (1) to mounting bracket (15) and remove actuator.

## 4-53. Installation and Rigging Anti-icing Control.

- a. Install four screws (13, figure 4-9) and washers (14) attaching actuator (1) to mounting bracket (15) and lockwire (C96). Actuator travel limit microswitch may be adjusted when required per figure 4-10.
- b. Install bracket (15) with actuator (1) using spacers (21 and 22), washers (18 and 20), and bolts (17 and 19). Torque bolts (17) **40 TO 65 INCH-POUND** and install lockwire (C96). Torque bolt (19) **75 TO 110 INCH POUND** and install lockwire (C96).
  - c. Connect electrical harness to actuator (1).
- d. Loosen jamnut (12), and remove rod end devis (10) from connecting link (7). Count the threads on devis and install jamnut (12) halfway up on the threads of clevis. Install devis into connecting link (7).
- e. Install devis (10) on anti-icing valve lever (16) with pin (11) for trial installation. Install aft end of connecting link (7) to actuator lever (3) with pin (4).
- d. Move connecting link assembly (7) forward to dose anti-icing valve on engine and install lever (3) on serrations of actuator (1). It may be necessary to adjust devis (10) so that lever (3) will fit serrations. Tighten locking screws (2) and install lockwire. Hold valve closed during this operation.

## **NOTE**

In some cases when rigging engine anti-cing actuator and valve, the devis has been found to bottom against base of threads on rod. This may be corrected by shortening threaded portion of clevis to dimensions shown in figure 4-11; protect unprimed area with primer (C118).

g. Remove pin (11, figure 4-9) and adjust devis (10) until pin moves freely in hole. Unscrew devis 1/2 turn to preload seating of valve. Tighten jamnut (12). Actuator switch to on. Check that actuator motor hits internal microswitch and stops before valve hits mechanical stop in full open position.

## 4-24 Change 24




Figure 4-9. Anti-Icing Control





Figure 4-10. Actuator Travel Limit Microswitch Adjustment

h. Secure pins (4 and 11) to connecting link (7) with washers (5 and 9) and cotter pins (6 and 8) and lockwire (C96) locking screw (2) on actuator lever (3).

i. Install engine cowling.



NOTE: All dimensions are in inches.

Figure 4-11. Alteration of Engine Anti-Ice Clevis

## SECTION IV. EXHAUST SYSTEM

## 4-54. EXHAUST SYSTEM.

- **4-55. Description Exhaust System**. The exhaust system consists of two exhaust stacks (1, figure 4-12). The exhaust stacks are held in place by a damp which is located on each side of the engine. Refer to table 4-1, Standard Exhaust Stack.
- **4-56. Inspection Exhaust System**. Inspect the engine exhaust attaching flange area for warping, dents, cracks, and burned spots that would cause a lealking exhaust joint. Inspect exhaust stack clamp for cracks and corrosion.
- **457. Inspection Exhaust System**. Refer to table 4-1.

## Premaintenance Requirements for Removal of Exhaust System

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	None
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	One
Consumable Materials	(C96) (C18)
Special Environmental Conditions	None

## 4-58. Removal Exhaust System

- a. Remove engine cowling. Refer to paragraph 2-46 for P/N 206-061-300.
- b. Open left and right cowl side panels (7, figure 2-1). Remove damps (2, figure 4-12).
  - c. Remove exhaust stacks (1 and 3).
- **4-59. Repair Standard Exhaust System**. Refer to table 4-1.
- **4-60. Repair Infrared Exhaust System**. Refer to table 4-1.
- **4-61. Installation Exhaust System**. Refer to table 4-1
- a. Position exhaust stacks (1, figure 4-12) in engine cowling and install on helicopter. Refer to paragraph 2-49.
- b. Position exhaust stack (1 and 3) and clamp (2) on engine exhaust collector with clamp studs facing outboard.
- c. Install nuts on damp studs and torque **30 INCH POUNDS** with equal amounts of stud threads exposed. Tap around the clamp with a soft faced mallet. Recheck torque. Repeat this procedure until **30 INCH-POUNDS** of torque can be maintained.

#### NOTE

Do not lockwire nuts to clamp at this time.

- d. Deleted.
- e. Ground run helicopter for 10 minutes.

## **NOTE**

During ground run exhaust clamp will seat Into place and 30 INCH-POUNDS torque may be lost.

f. After ground run and with 15 minutes, retorque damp nuts to **30 INCH-POUNDS**. Lockwire (C96) nuts to damp.




Figure 4-12. Engine Exhaust Stack

## Table 4-1. Inspection and Repair of Exhaust Stack

#### Infrared Stack

## **INSPECTION** REPAIR 1. Check for secure installation of exhaust stack to 1. If stack is loose, remove lockwire and torque engine exhaust flange. Inspect exhaust stack clamp nuts to 30 INCH-POUNDS. Ground run clamp for cracks and corrosion. helicopter for 10 minutes. Torque clamps to 30 INCH-POUNDS. Lockwire (C96) nuts to clamp. If clamps are cracked or corroded, replace clamps. 2. Inspect engine exhaust attach flange for 2. Refer to TM 55-2840-231-23 A and TM warping, dents, cracks, and burned spots that 55-2840-241-23 C. would cause a leaking exhaust joint. 3. Visually inspect stainless steel stack interior for 3. Repair stack structures in accordance with TM holes or cracks. 55-1500-204-25/1. Alternately, a patch of steel (item 49, table 2-1) may be welded over openings. Cracks may be fusion welded. NOTE Exhaust stacks must be removed for any welding repair. 4. Visually inspect stack exterior for holes or 4. Holes or breaks maybe sealed by spot welding a breaks in insulation outer jacket. metal patch (item 47, table 2-1) in place. In the event welding equipment is not available, adhesive (C18) may be used to fill holes or breaks until permanent repairs (welding) can be made. 5. Visually inspect the brackets separating the two 5. Broken bracket may be welded by removing the stacks for cracks. adhesive (C18) and the screws/nuts on the outer stack and welding the broken bracket. Broken bracket may be removed and replaced by removing the adhesive (C18) and screws/nuts on the outer stack and removing the two 5/32 inch steel rivets on the inner stack. Replace with new or repaired bracket. Cracked bracket may be welded in place or replaced as described above. Torque bracket nuts 12 TO 16 INCH-POUNDS

or to a maximum of 26 INCH-POUNDS.

Table 4-1. Inspection and Repair of Exhaust Stack (Cont)

INSPECTION	REPAIR
6. Visually inspect the fin stacks.	<ol><li>Broken fins and/or fins pulled away from aluminum stacks may be welded.</li></ol>
	Broken fins and/or fins pulled away from aluminum stacks may also be repaired temporarily with adhesive (C18).
Inspect aluminum stack base plate material for cracks or holes.	7. Cracks may be stop-drilled or fusion welded.
	Holes may be repaired with adhesive (C18) or by fusion welding aluminum (item 25, table 2-1) over the hole.

## NOTES:

## Welding Instructions

- 1. Items to be welded must be cleaned per TM 55-1500-204-25/1.
- 2. Use aluminum alloy rod (C121) for aluminum welds.
- 3. Use steel rod (C122) for stainless steel duct welds.

## Standard Exhaust Stack

INSPECTION	REPAIR
1. Visually inspect stacks for cracks.	1. Cracks may be fusion welded, Refer to TM 55-1520-204-25/1
	NOTE
	Exhaust stacks must be removed for any welding repair.
2. Visually inspect stacks for holes or breaks.	<ol><li>Holes or breaks maybe repaired by spot welding a metal patch (item 47, table 2-1) in place.</li></ol>
	In the event that welding equipment is not available, adhesive (C18) may be used to fill holes or breaks until permanent repairs (welding) can be made.

## NOTES:

## Welding Instructions

- 1. Items to be welded must be cleaned per TM 55-1500-204-25/1.
- 2. Use steel rod (C122) for welds.

## SECTION V. OIL SYSTEM

#### 4-62. OIL SYSTEM.

- 4-63. Description Oil System. The engine oil system (Figure 4-13) consists of a self-seating oil tank with a 11.20 pint capacity. A self-locking drain valve for both oil tank and system drains, an oil cooler, a bypass valve, a check valve, and vent line. Provisions are included for an oil pressure indicator, a temperature indicator, end a combination, low oil cooler bypass valve and caution light. In addition, two engine magnetic chip detectors are connected to a caution light. The oil tank is mounted aft of the engine rear firewall on top of the cabin section.
- 4-63.1. Description -Oil System. After compliance with MWO 1-1500-228-50-44. The engine oil system (Figure 4-13 and 4-13.1) consist of a self-sealing oil tank with an 11.20 pint capacity, self-locking drain valve for both oil tank drain and system drain, oil cooler, a bypass valve, an inline external scavenge oil filter, and vent line. Provisions are included for en oil pressure indicator, a temperature indicator, and a combination, low level oil cooler bypass valve end caution light. In addition, two engine magnetic chip detectors are connected to a caution light. The oil tank and external scavenge oil filter are mounted aft of the engine rear firewall on top of the cabin section.

## **NOTE**

# Refer to applicable instructions in this section for cleaning and maintenance of each component.

## **4-64. OIL TANK**

4-65. Description - Oil Tank Engine oil supply tank (1, Figure 4-13) is a self-sealing 11.20pint capacity container quipped with a sight gage (2), filler neck and cap (3), scupper with drain (4), and fittings for line connections. Tank is mounted aft of blower fan and above tail rotor driveshaft.

## 6-66. Inspection - Oil Tank

- a. Inspect tank for the following:
  - (1) Punctures or leaks.
  - (2) Damaged threads in fittings.
  - (3) Damage which affects capacity or function.
- (4) Loose, missing, or improperly installed hardware.
- b. Inspect sight plugs for discoloration, damage, and proper sealing.

- c. Inspect tank support for cracks and mount area on tank for cracks or damage.
- d. Cracks are permitted in tape on outside surface of tank as long as there is no evidence of leakage.

## 4-67. Removal - Oil Tank


#### NOTE

Cover all openings to prevent system contamination.

- a. Remove aft fairing (5, Figure 2-10 or 10, Figure 2-11) to gain access to oil tank area.
- b. Drian oil into suitable container through overboard drain.
  - c. Remove lines, fittings, end electrical connections.
- d Remove four bolts and washers attaching oil tank to support assembly (5, Figure 4-13).
- 4-66. Repair Oil Tank Repair oil tank in accordance with TM 1-1500-204-23 series.

## 4-69. Installation -Oil Tank

- a. Replace all packings affected by removal. Replace any damaged fittings.
- b. Position tank on support and install four bolts end washers.
  - c. Install fittings and connect lines.
- d. Check drain valve (6, Figure 4-13) for dosed position and service oil tank Refer to paragraph 1-8 for servicing.
- 4-70. Removal Low Level Switch (Figure 4-13).
  - a. Drain engine oil.
- b. Disconnect electrical connection from TB14 and aircraft structure.



- 1. Oil Tank
- 2. Sight Gage
- 3. Filler neck and Cap 4. Scupper
- 5. Support Assembly6. Drain Valve7. Temperature Bulb


- 8. Oil Cooler

- 9. Check Valve
- 10. Low Level Switch
- 11. Selector (Bypass) Valve
- 12. Drain Plug
- 13. Duct Extension
- 14. Cooler Bypass Line Port C
- 15. Drain Tank to Deck Line
- 16. Drain Deck to Union Line

- 17. Drain to Overboard Line
- 18. Drain Pan to Tee
- 19. Hose Assembly
- 20. Bulkhead to Tank Hose
  21. Electrical Cable Assembly
  22. Hose Assembly Port B
  23. Hose Assembly Port A
  24. Hose Assembly Supply

- 25. Screws
- 26. Washers

Figure 4-13. Engine Oil System.



- 1. Filter Housing
- 2. Filter Attach Bolts
- 2A. Washer
- 3. Spacer
- 4. Mounting Tray
- 5 Support Bracket
- 6. Support Bracket Brace
- 7. Support Bracket Bolts
- 8. Scupper Drain Line for Mounting Tray
- 9. Scupper Tray Attach Fitting
- 10. Scupper Drain Line for Oil Tank Drain
- 11. Scupper Drain Tee Fitting12. Oil Supply Line
- 13. Oil Return Line
- 14. Adel Clamp (1 ea)
- 15. Adel Clamp (2 ea)

Figure 4-13.1. Engine Oil Filter External Scavenge Oil Filter.

- c. Disconnect hose (19 and 20) from oil tank plate.
- **d.** Remove plate and low level switch (10) from oil tank as an assembly; discard packing from plate.
- **e.** Remove low level switch (10) from plate assembly.

## 4-71. Installation - Low Level Switch.

- a. Install low level switch (10) on plate assembly.
- **b.** install packing with plate and low level switch into oil tank.
  - c. Connect hose (19 and 20) to oil plate.
- **d.** Connect electrical connectiontoTB14 and aircraft structure.
  - e. Service engine oil.

## 4-71.1. Removal - Oil Tank Support Assembly.

- a. Remove oil tank. Refer to paragraph 4-67.
- **b.** Remove 6 screws (25, figure 4-13) and 6 washers (26) securing support assembly (5) to top cabin section.
  - c. Remove support assembly from cabin section.

## 4-71.2. Installation - Oil Tank Support Assembly.

- **a.** Remove protective finish from support assembly. (5, figure 4-13) and cabin section mating surfaces to ensure electrical bonding ground.
- **b.** Position support assembly (5) on cabin section and align screw holes in support assembly with holes in cabin.
  - c. install 6 washers (26) and 6 screws (25).
  - d. Install oil tank. Refer to paragraph 4-69.

## 4-72. OIL COOLER.

**4-73. Description - Oil Cooler.** The oil cooler (8, figure 4-1 4) is mounted on a duct extension on the oil cooler blower. Return oil from the engine flows through the oil coder, through a one way check valve (9, figure 4-13) and into the return line to the oil tank. In the event of damage to oil cooler, the low level switch (10) will actuate the bypass valve (11) when tank capacity gets down to 1.100 gallons and route oil around the cooler to the tank.

## Premaintenance Requirements for Engine Oil Cooler

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	None
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	One
Consumable Materials	(C81) (C85) (C96)
Special Environmental Conditions	Dust Free

## 4-74. Inspection - Oil Cooler.

- a. Inspect oil cooler for cleanliness of air passages.
- **b.** Inspect oil cooler for unserviceable or damaged fittings, oil passage leaks, and elongated mount holes.
- **c.** Inspect oil cooler top gasket (12, figure 4-14) for damage and security.
- **d.** Remove gasket (12), and ensure that oil cooler top surface is clean; bond new gasket in place with adhesive (C9).

## 4-75. Removal - Oil Cooler.

- **a.** Cut lockwire on drain plug (1, figure 4-14). Remove plug and drain cooler fluid into a suitable container.
  - **b.** Disconnect inlet line (2) and return line (5).
- **c.** Remove reducer(3) and packing(4). Discard packing.
- **d.** Remove check valve (6) and packing (7). Discard packing.
- **e.** Remove 13 bolts (9) and washers (10) attaching oil cooler (8) to duct (11). Remove cooler.




Figure 4-14. Engine Oil Cooler

## 4-76. Cleaning - Oil Cooler.

## CAUTION

Do not attempt to clean an oil cooler which has been installed with an engine which incurred mechanical failure resulting in metal particles in the oil. Condemn oil coolers which have been contaminated with metal particles.

#### NOTE

Do not confuse AOAP laboratory high wear concentration of iron, magnesium, etc., (measured in parts per million) as being metal chip contamination or metal particle contamination.

- **a.** Install plugs in inlet and outlet ports of oil cooler (1, figure 4-15).
- **b.** Install drain plug (4, figure 4-15) and vernatherm control valve (3) if not previously accomplished.
- **c.** Clean the exterior of the oil cooler with drycleaning solvent (C62).

### 4-77. Disassembly - Oil Cooler.

- a. Remove vernatherm control valve (3, figure 4-15). Do not disassemble valve. If valve is known to be faulty or fails to pass inspection at any point in subsequent procedures, replace the valve with a new valve. Discard packing (2).
  - b. Remove drain plug (4) and discard packing (5).

#### NOTE

Further disassembly is not practical because each core is a brazed and welded unit.

## 4-78. Inspection - Oil Cooler.

**a.** Inspect the air fins and air passages for distortion and foreign particles that may obstruct the air flow.

- **b.** Inspect the cooler for damaged and bulged plates, cracked castings and flanges, broken welds, and stripped threads.
- **c.** Inspect for foreign matter inside cooler through four open ports.
- **d.** Inspect area around each of four ports for scoring that could prevent packings from sealing.
- **e.** Inspect the seat on vernatherm control valve (3, figure 4-15) and the mating seat in the oil cooler for rough surfaces that would allow excessive leakage when the valve is seated.
- **f.** Inspect vernatherm control valve (3) for damaged threads and broken spring.
  - g. Test venatherm control valve as follows:
- (1) Submerge valve in water heated to  $160^{\circ}$  ( $\pm 5^{\circ}$ )F (71°C) for 5 minutes. Remove and measure length.
- (2) Submerge valve in water heated to 178° (±5°)F (81°C) for 5 minutes. Remove valve and measure length.
- (3) The minimum increased length between the two measurements must be 0.080 inch. If valve does not pass this inspection replace it with valve which will pass inspection.

## 4-79. Assembly - Oil Cooler.

- **a.** Install vernatherm control valve (3, figure 4-15) with new packing (2). Lockwire (C96) valve.
- **b.** Install drain plug (4) with new packing (5). Lockwire (C96) plug.
- **c.** Install check valve (6, figure 4-14) and new packing (7) in the return port.

## 4-80. Installation - Oil Cooler.

- **a.** Position cooler (8, figure 4-14) on duct (11) with inlet port on right side.
- **b.** Align mounting holes and install 13 bolts (9) and washers (10).
- **c.** Install reducer (3) and new packing (4) in the inlet port.




Figure 4-15. Oil Cooler Assembly

- d. Connect inlet line (2) and return line (5).
- **e.** Ensure that drain plug (1) is installed and lockwired (C96).
  - f. Service system.

# 4-81. OIL SELECTOR (BYPASS) VALVE.

**4-82. Description - Oil Selector (Bypass) Valve.** The oil selector (bypass) valve (11, figure 4-13) is mounted on the rear firewall, right side and either directs oil from engine to oil cooler in normal operation or directs oil from engine straight to oil tank when level drops to 1.100 gallons in oil tank. This prevents total oil loss due to oil cooler damage.

# 4-83. Cleaning - Oil Selector (Bypass) Valve.

- **a** Clean actuator assembly (2, figure 4-16) with clean cloths moistened with drycleaning solvent (C62).
- **b.** Clean parts other !han actuator assembly by washing in drycleaning solvent (C62). Dry parts with a clean, lint-free cloth.

# 4-84. Inspection - Oil Selector (Bypass) Valve.

- **a.** Inspect fittings and threads for damage and serviceability.
- **b.** After installation, check for leaks and security of attachment.

# 4-85. Test - Oil Selector (Bypass) Valve.

- **a**. With engine oil tank empty and ENG OIL switch in the AUTO position and ENG OIL BYPASS circuit breaker engaged, observe that ENG OIL BYPASS warning light is illuminated when power is applied.
- **b.** Place ENG OIL switch OFF and listen for audible valve actuation.
- **c.** Place ENG OIL switch to AUTO and listen for audible valve actuation.
- **d.** Begin filling engine oil tank and observe that ENG OIL BYPASS warning light extinguishes and an audible valve operation is heard when approximately 1.100 gallons of oil have been loaded.

- **e.** Run engine and observe that ENG OIL BYPASS light is not illuminated and that engine oil temperature is stabilized. Oil will bypass the oil cooler below 71°C due to the vernatherm control valve.
  - f. Place ENG OIL switch to AUTO A
- **g.** Note engine oil temperature, then place CAUTION TEST/RESET switch to TEST. Hold in TEST position until a **10°C** rise in engine oil temperature is noted. (This indicates the selector valve is in bypass.)
- h. Place ENG OIL switch to OFF and note that oil temperature returns to original value.

# 4-86. Removal - Oil Selector (Bypass) Valve.

- **a.** Remove the inlet (23, figure 4-13) and outlet lines (14 and 22) at selector (bypass) valve ends.
  - **b.** Remove B nut attaching valve to firewall.
- **c.** Remove electrical connections and remove valve.
  - **d.** Remove fittings (5, 10, and 17, figure 4-16).

# 4-87. Disassembly - Oil Selector (Bypass) Valve. (AVIM)

- **a.** Remove nameplate (1), (figure 4-16).
- **b.** Remove screws (3) and actuator assembly (2) from valve body (12).
- **c.** If installed, remove fittings (5, 10, and 17) Discard packings.
- **d.** Align shaft (19) so that lower shaft key is straight between port C and B.
- **e.** Press out seal (7 or 15) and ball (13) from valve body. Discard packings.
- **f.** Remove shaft (19) from valve body. Remove packing (21) and discard.

# 4-88. Inspection - Oil Selector (Bypass) Valve. (AVIM)

**a.** Inspect all parts for cracks, breaks, and signs of obvious damage or wear.





Figure 4-16. Selector Valve Assembly (Engine Oil System Bypass Valve)




- 1. Inlet Hose
- Filter assembly
   Outlet Hose

- 4. Fitting5. Preformed Packing

- 6. Reducer Fiting
- 7. Preformed Packing
- 8. Bolt
- 9. Washer
- 10 Spacer

Figure 4-16.1 External Scavenge Oil Filter Assembly.



- 1. Filter Bowl
- 2. Filter Head
- 3. Filter Element

- 4. Preformed Packing
- 5. Preformed Packing

Figure 4-16.2 External Scavenge Oil Filter Element.

- **b.** Inspect seals (7 and 15, figure 4-16) for scoring and scratches which could cause leakage.
- **c.** Inspect ball (13) for scoring and scratches which could cause leakage.
- **d.** Inspect valve body (12) for cracks, burrs, and obstructed passages.
- **4-89.** Repair Oil Selector (Bypass) Valve. (AVIM) Repair of oil selector (bypass) valve is limited to removal and replacement of authorized parts as outlined in TM 55-1520-228-23P.

# 4-90. Assembly - Oil Selector (Bypass) Valve. (AVIM)

- **a.** Place seals (7 and 15, figure 4-16) and new packings (6, 8, 11, 14, 16, and 21) on clean, wax-free paper. Lubricate these parts with a light film of silicone grease (C81).
- **b.** Install packing (21) in shaft (19) and install shaft in valve body (12) through port B or port C.
- **c.** Install ball (13) into valve body (12) through port B or port C and engage tang of shaft (19) in slot in ball.
- **d.** Install new packing (8) on seal (7). Install new packing (14) on seal (15). Position seals in valve body and push seals in until they contact ball.
- **e.** Install serviceable mount fittings (5, 10 and 17) with new packings (6, 11, and 16) on valve body in psitions illustrated. Secure fittings with screws (4, 9, and 18) and lockwire (C96) screws.
- **f.** Position acutator assembly (2) on valve body (12). Rotate shaft (19) if necessary to engage slot in output shaft of actuator assembly (2). Install screws (3) and lockwire (C96).
  - g. Install nameplate (1).
- **h.** If a new valve body (12) was installed, stamp port locations (A, B, and C, figure 4-16) on the upper side of the body with permanent ink (C85).

### 4-91. Installation - Oil Selector (Bypass) Valve.

- **a.** If not installed, install serviceable mount fittings (5, 10, and 17, figure 4-16) and new packings (6, 11, and 16) on valve body in positions illustrated. Secure fittings with screws (4, 9, and 18) and lockwire (C96) screws.
- **b.** Position valve in firewall and secure with washers and hex nuts.

**c.** Connect electrical connector and three lines to valve and install lockwire (C96).

# 4-92. OIL SUPPLY SYSTEM HOSES, FITTINGS, AND TUBING.

The hoses and tubing used in the oil supply system are light-weight assemblies incorporating permanent fittings. The hoses located near the engine are provided with fire shields. The oil cooler bypass line is of aluminum construction.

# 4-93. Inspection - Oil Supply System Hoses, Fittings, and Tubing.

- **a.** inspect oil lines for kinks, uniformity of diameter, breaks, and freedom from interference with adjoining structure or other components. Replace defective oil lines.
- **b.** inspect fittings and hardware for cracks, crossed threads, obstructions in opening, burrs, or other damage.
- **4-94.** Repair/Replacement Oil Supply System Hoses, Fittings, and Tubing. Replace all damaged fittings. Replace all seals, packings, self-locking nuts, cotter pins, and lockwire when they are removed from a unit.

# 4-95. INTERSYSTEM OIL LEAKAGE.

- **4-96. Description Intersystem Oil Leakage.** Occasionally, intersystem oil leakage may occur internally between the freewheeling assembly and engine oil systems through the accessory gearbox shaft seals. Evidence of this is a high engine oil level coupled with a low transmission oil level.
- **4-97. Inspection Intersystem Oil Leakage.** Check Engine and Transmission oil ievels.

# 4-98. Repair/Replacement - Intersystem Oil Leakage.

**a.** Remove freewheeling unit from gearbox. Refer to paragraph 6-25.

# **CAUTION**

Do not pry between seal cavity in the gearbox housing and seal. Be careful not to damage the gearshaft or contaminate the shaft bearings.

**b.** Remove both accessory gearbox seals, one from each end. Seal replacement tool kit (6796941).

TM 55-2840-231-23P Aor TM 55-2840-241-23P is available for this purpose. An alternate means of sealing replacement is to drill three holes into metal portion of seal, then after removing clips, shavings, etc., install sheet metal screws in each hole with washers. Seal may now be pried from housing, utilizing a wooden block and suitable pry bar inserted under washers, alternately prying at each screw location.

c. Inspect driveshaft sealing surface for burrs, scratches, sharp edges, etc., which would damage sealing lips.

### **NOTE**

Install replacement seal. Refer to TM 55-2840-231-23P A,TM 55-2840-241-23P.

- d. Inspect replacement seals for condition. Ensure seal lips are not Chipped, tom, or grooved.
- e. Apply light film of grease (C78) to seal lips to aid installation. Ensure secondary sealing surface is inserted into gearbox first, metal surface outboard, then carefully drive (or press) replacement seal in place.
- f. Reinstall freewheeling unit. Refer to paragraph 6-33.
- 4-98.1. EXTERNAL SCAVENGE OIL FILTER AS-SEMBLY After compliance of MWO 1-1520-228-50-44.
- 4-98.2. Description External Scavenge Oil filter Assembly. The external scavenge oil filter is mounted above the tail rotor driveshaft, behind the engine oil tank The in-line oil fitter consists of a 4 micron filter element, oil bypass indicator, and bypass valve. When the filter element becomes cogged, it will give a warning by extending the bypass (red) indicator. The indicator extends when a set differential pressure across the filter is exceeded. When in the reset position, the indicator will be hidden from view.
- 4-98.3. Inspection External Scavenge Oil Filter Assembly.
- a. Inspect fitter assembly for security, condition, leaks, damaged fittings, or broken lockwire.
- b. inspect hoses for kinks, chaffing, and condition. Replace defective hoses.

### **NOTE**

If filter bypass indicator (red button) is showing, reset indicator, ground run engine, and reinspect. If indicator is not showing after ground run, aircraft may be reieased for operation. If indicator is showing after ground run, change engine oil, and replace scavenge filter element

- c. Check for extended oil bypass (red) indicator. If indicator is extended, reset by pressing in.
- 4-98.4. Removal External Scavenge Oil Filter Assembly.

### **CAUTION**

Protective covers shall be used to cover all open ports and lines to prevent contamination by entry of foreign material.

- a. Remove aft fairing (5, Figure 2-10 or 10, Figure 2-11). Place suitable container under scupper drain of aircraft.
- b. Remove hose (1, Figure 4-16.1) from inlet side of filter assembly (2).
- c. Remove hose (3) from outlet side of filter assembly (2).
- d. If necessary, remove reducer (4) and packing (5) from outlet side of lifter assembly (2). Discard packing (5).
- e. If necessary, remove reducer (6) and packing (7) from inlet side of filter assembly (2). Discard packing (7).
- f. Remove filter assembly (2) by removing 3 bolts (8), 3 washers (9), and 3 spacers (10).
- 4-98.5. Cieaning Externai Scavenge Oil Filter Assembly.

# **WARNING**

Drycleaning solvent (C62) is flammable and toxic. It can irritate skin and cause burns. Use in well ventilated area, away from heat and open flame. Wear rubber gloves and goggles. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

Clean exterior of oil filter assembly (Figure 4-16.1) with drycleaning solvent (C62).

- 4-98.6. Repair External scavenge Oil Fiiter Assembly.
- a. Replace oil filter assembly (2, Figure 4-16.1) if damage or corrosion exists.
- b. Replace oil filter element (3, Figure 4-16.2) if unserviceable or damaged. Refer to paragraph 4-98.10.

4-98.7. Installation - External Scavenge Oil Filter Assembly.

#### **NOTE**

All preformed packings shall be coated with lubricating oil (C103 of C103.1)

- a. Install filter assembly (2, Figure 4-16.1) with 3 bolts (8), 3 washers (9), and 3 spacers (10).
- b. If removed, install reducer (6) with new preformed packing (7) coated with lubericating oil (C103 or C103.1) on inlet side of filter assembly (2).
- c. If removed, install reducer (4) with new preformed packing coated with lubricating oil (C103 or C103.1) on outlet side of filter assembly (2).
  - d. Install hose (3) on outlet side of filter assembly (2).
  - e. Install hose (1) on inlet side of filter assembly (2).
  - f. Service oil tank if necessary.
- g. Perform Maintenance Operational Check and leak check external filter assembly.
- h. Reinstall aft fairing (5, Figure 2-10) or (10, Figure 2-11).
- 4-98.8. Removal External Scavenge Oil Filter Element.

### **CAUTION**

Protective covers shall be used to cover all open ports and lines to prevent contamination by entry of foreign materials.

- a. Remove aft fairing (5, Figure 2-10 or 10, Figure 2-11).
- b. Place suitable container under scupper drain of aircraft, cut lockwire, and remove filter bowl (1, Figure 4-16.2) from filter head (2).
- c. Remove filter element (3) from filter bowl (1). inspect per paragraph 4-98.9. Discard filter element (3).
- d. Remove preformed packing (4) from filter bowl (1). Discard preformed packing (4).

### **WARNING**

Drycleaning advent (C62) is flammable and toxic. It can irritate skin and cause bums. Use in well ventilated area, sway from heat and open flame. Wear rubber gloves and goggles in case of contact, immediately flush skin or eyes with water for at least 15 minutes Get medical attention for eyes.

- e. Clean inside of filter bowl (1) using drydeaning solvent (C62) and wiping rags (C119.1).
- 4-98.9 Inspection External Scavenge Oil Filter Element.

Inspect oil filter element (3, Figure 4-16.2) for contamination to determine if any corrective action is needed beyond replacement of element or preformed packings.

4-98.10. Replacement/Installstion - External Scavenge Oil Filter Element.

#### NOTE

All preformed packings shall be coated with lubricating oil (C103 of C103.1)

- a. Coat performed packing (5, Figure 4-16.2) in new filter element (3) with lubricating oil (C103 or C103.1).
  - b. Install filter element (3) in filter bowl (1).
- c. Coat preformed packing (4) with lubricating oil (C103 or C103.1) and install in filter bowl (1).
- d. Install filter bowl (1) into fitter head (2) and hand tighten. Secure with lockwire (C96).
  - e. Service oil tank if necessary.
- f. Perform Maintenance Operational Check and leak check external filter assembly.
- g. Reinstall aft fairing (5, Figure 2-10 or 10, Figure 2-11).

# SECTION VI. IGNITION SYSTEM

(Refer to Chapter 9)

### SECTION VII. POWER CONTROLS

# 4-99. POWER CONTROLS.


4-100. Description - Power Controls. Helicopter uses a conventional control system. Collective pitch of the helicopter rotor establishes power output demand on the engine. For all practical purposes, helicopter rotor speed is held constant by the engine and it's control system.

The fuel control is connected to the twist grip of the pilot and copilot collective pitch sticks. The power turbine governor is interconnected to the collective pitch sticks through a coordinated systems of bell cranks and linkages. Any change in collective pitch resets the governor to a new power demand. This demand is transmitted to the gas producer fuel control, which resets and varies the N1 speed of the gas producer turbine accordingly.

A droop compensator maintains engine rpm (N2) as power demand is increased. The compensator is a direct mechanical linkage between the collective stick and the speed selector lever of the N2 governor. A torque tube has been incorporated with a shear center section to allow collective control in event of droop system failure.

A motor actuated speed trimming device is installed in the linkage between the collective pitch stick and the power turbine governor lever. It is operated by a beeping switch on the pilots collective pitch stick and allows engine output speed to be varied over the normal range. 4-101. Inspection - Acceptance/Rejection Criteria - Power Controls.

- a. Inspect for binding or chafing controls.
- **b.** Inspect all cables, tubes, and bell cranks for security and cotter keys for proper installation.
- c. Inspect torque tube assembly for dents, nicks, scratches, deformation, proper shimming, and loose or missing rivets. Refer to Figure 4-17 for limits. If either riet is loose, replace both rivets.
- (1) Ensure rivets are installed with a coat of wet zinc chromate primer (C118).
  - (2) Do not exceed diameter rivets.
- **d.** Inspect rubber bellows for cracks or deterioration. Ensure inside is not gummy.
- e. Inspect and replace any eroded, damaged, or worn parts of linkage. Replace rod end bearings if radial wear exceeds 0.010 and/or if axial wear exceeds 0.020 inches.



NOTE: All dimensions are in inches.




Figure 4-17. Power Control - Torque Tube Assembly Damage Limits

- f. Inspect linkage at gas producer as follows:
- (1) Inspect lever (4, figure 4-19) and link assembly (3) for elongation of holes and wear.
- (2) Inspect bolt (7), washer (8), and nut (9) for erosion, damage, and wear.
- **g.** inspect tube (1, figure 4-20) for bends, dents, cracks, or missing rivets. Replace defective tube.
- (1) Nicks, scratches, and pitting not to exceed 0.003 after cleanup (no area limit).
- (2) Smooth dents not to exceed 0.028 in depth and not to affect more than 1/4 circumference in any location.

- **h.** Inspect N2 governor arm (6, figure 4-20) for the following:
  - (1) inspect for cracks on clevis tangs.
  - (2) Replace defective governor arm.

# 4-102. Removal - Control Cable Assembly - Power Controls.

- **a.** Gain access to right side of engine by opening hinged section of engine side cowling (7, figure 2-1).
- **b.** Unsnap and remove right hand cover from upper cabin roof beam.

- **c.** Remove cover assembly from center post and retain attaching hardware for reinstallation.
  - d. Remove pilots seat. Refer to paragraph 2-78.
- **e.** Remove clamp (18, figure 4-18), nut (13), washer (19), spacer (20), and screw (21).
- f. Remove clamp (22), nut (13), washer (19), and screw (23) from adapter bracket (24).
- **g.** Remove clamp (25), washer (19), screw (26) and spacer (27).
- **h.** Remove clamp (28) be removing existing hardware. Measure exposed threads between nut (11) and unthreaded area of throttle cable (54) to facilitate approximate position at installation.

#### NOTE

# Use wrench to hold end of control cable when loosening or tightening jamnut.

- i. Remove lockwire and loosen nut (11).
- **j.** Disconnect rod end (6) by removing cotter pin (1), nut (2), washer (3), and bolt (5).
- **k.** Using a tape measure, determine distance between bracket (12) and end of rod end (6) to facilitate approximate position at installation.
- **I.** Remove ball joint (10), adapter (8), and rod end (6) as a unit from end of control cable. If balljoint (10) adapter (8), and rod end (6) are to be disassembled, measure overall length to facilitate approximate position of reassembly.
- **m.** Loosen nut (16) and nuts (17). Remove inboard nuts (16 and 17) from control cable assembly (54) and slip cable outboard from bracket (12). Remove outboard nut (17) from cable.
- **n.** Remove six clamps (29), nuts (13), washers (19), and screws (30) securing control cable assembly (54) to center post structure.
- **o.** Remove clamp (31), nut (13), washer (19), spacer (32), and screw (33) from clamp (34) located in upper cabin roof beam area.
- **p.** Remove clamp (36), nut (13), washer (19), and screw (30).

- **q.** Remove lockwire (39) securing nuts (40 and 42) and loosen nuts.
- r. Disconnect rod end (44) from bellcrank (45), cotter pin (46), nut (47), washer (48), and bolt (49).
- **s.** Remove nut (40), ball joint (41), tube assembly (43), and rod end (44) as a unit from end of control cable assembly (54).
  - t. Remove boot (38) from control cable.
- **u.** Remove aft two nuts (37) at engine fireshield. Remove control cable assembly from fireshield by pulling forward, then remove forward two nuts (37) from control cable assembly.
- **v.** Route control cable assembly (54) through grommets (35) and other existing grommets and remove from helicopter.

# **4-102.1.** Engine Gas Producer Controls Installation. This portion of the gas producer controls is located in the engine bay and mounted on the engine deck, just under the engine fuel control. The control bracket takes the input from the collective twist grip, through the control cable and translates the motion as an input to the engine fuel control.

- **4-102.2.** Gas Producer control Bracket. This bracket functions as a support for the gas producer control tube and the rod end side of the gas producer control pushpull control cable assembly by means of the bellcrank, which is mounted on the bracket. The bracket translates horizontal movement of the cable to a vertical movement at the fuel control lever.
- 4-102.3. Inspection Gas Producer Control Bracket.

#### **NOTE**

There are several alternate bearings which may be used. If a teflon-lined bearing has been used, inspect for signs of possible contamination damage. Also, inspect bolt(s) for sign of turning in the bearing. This is not acceptable. Teflon is subject to damage by grease, oil, jet fuel, hydraulic fluids, etc. It is important to assure the teflon bearing is free to rotate. Refer to para 11-130.f. for data on "spinning-in" of bearings.

**a.** Inspect the bearing in the bracket (53, fig. 4-18) for condition and wear; the bearing must have freedom of movement (rotation) and its I.D. must be free from

wear and damage. Replace bearing if it is worn or damaged. (Note that the bearing is roll-staked in place.)

- **b.** Inspect the mating bolt for condition and wear; replace if the plating is worn. Replace any worn or damaged bolts.
- **4-102.4 Gas Producer Control Bellcrank.** The I.D. which mates with the bolt (11, fig. 4-19) is a relatively loose fit; the critical points to check are the bolt holes which mate with the AN173 series bolt.

### **NOTE**

If a teflon lined bearing was used in the gas producer bracket, there is a possibility the bellcrank may be turning on the bolt. This is not acceptable.

# 4-102.5 Inspection - Gas Producer Control Bellcrank.

**a.** Inspect the bellcrank bolt holes for wear and oondition.

#### NOTE

Pay particular attention to the bolt holes which mate with the AN173 and AN174 bolts.

- **b.** Inspect all bolts for condition and wear; replace any worn bolts.
- **4-102.6 Gas Producer Control Tube.** This tube assembly takes the output from the control cable (through the bellcrank) and inputs the control motion to the engine fuel control lever which is mounted on the fuel control.

# 4-102.7 Inspection - Gas Producer Control Tube.

- **a.** Inspect the rod end bearings (44 and 55, fig. 4-18) for wear, condition, and freedom of motion. Replace any worn/defective bearings.
- **b.** Inspect rod end bearings I.D. for condition and wear.
- **c.** Inspect the tube-fixed end bolt hole for condition and wear. Replace any tube assembly if the part is worn.
- **d.** Inspect mating bolts for condition and wear; replace any worn bolts.

#### 4-102.8 Fuel Control Lever.

The (airframe) engine fuel control lever is mounted on the fuel control and has serrations on the fuel control. The fuel control lever is the "throttle" lever for the fuel control.

# 4-102.9 Inspection - Fuel Control Lever.

- **a.** Inspect the fuel control lever for condition and wear; replace if worn.
- **b.** Inspect the AN173 series bolt which mates with the tube for condition and wear. Replace if the plating is worn.

# 4-102.10 Balljoint Connector - Power Controls.

4-102.11 Description - Balljoint connector. On either end of the Gas Producer Controls Installation Cable Assembly is a Balljoint Connector. The Balljoint Connector has been installed to provide for some degree of misalignment from the easily curved flex cable to the rigid attach point at each end. For design purposes the Ballioint Connector provides ±4 degrees of movement, but has a total movement capability about its theoretical center of translation of ±8 degrees. To accommodate the movement, the Ballioint Connector incorporates two internal curved surfaces (at either end) and an internal ball. This ball and its two mating concave surfaces provides the means for an otherwise rigid end to have a degree of flexibility. The design point at manufacture/assembly is for a movement capability of 0.005 inches maximum under a ±5 lb. load.

# 4-102.12 Inspection - Balljoint Connector - Power Controls.

- **a**. Disconnect the Gas Producer Controls Cable (54, figure 4-18) at the rod end at the bellcrank (45) located on the engine deck so that the cable is free to operate under no load.
- **b.** Position one person at the collective stick twist grip. Slowly operate the twist grip back and forth and check that the internal portions of the Balljoint Connector (41) are not excessively worn.
- c. What should be expected is a movement at the rod end and no slop in the Balljoint (41). Slowly rotate the collective twist grip in both directions and verify there is no lost motion due to the Balljoint (41) mechanism.

#### TM 55-1520-228-23

- **d.** Check for wear and/or slop of the Balljoint Connector (10) at the pilot's collective stick (4) side of the system.
- **e.** Slowly rotate the twist grip in both directions and check that no linear motion is "lost" due to wear in the Balljoint (10).
- f. Internal wear of the Balljoint Connector is indicated by cable mechanism movement, but no immediate translation effect at the output side. This is more readily detected by quickly moving the twist grip back and forth. What will be occurring is the internal looseness or wear at the concave portions of the assembly where they mate against the internal ball.
  - **g.** Adjust the Ball joint if required as follows:
- (1) Disassemble the Balljoint. Inspect both sides of the internal portions for condition and wear, where they mate against the ball. Inspect the ball for condition and wear.
- (2) No obvious flat spots should exist on any of the surfaces of either the ball and/or its two end-mating surfaces. These surfaces should be smooth and free from surface defects which would prevent smooth operation.
- (3) If no wear is present, reassemble the Balljoint. Tighten the assembly until there is no free play. Verify elimination of free play by holding the wrenchflat side fixed and then push in and pull out at the threaded side.

- (4) Inspect that the threaded side still has freedom of movement about its linear axis. Specifically, the assembly must not be tightened against the ball. There should be at least ±4 degrees of angular movement. There should be no evidence of the internal ball binding.
- **4.102.13** Repair Balljoint Connector Power Controls. No repair is allowed. Replace the Balljoint Connectors (10 or 41, figure 4-18) if defective.

# 4-103. Installation - Control Cable Assembly - Power Controls

# **CAUTION**

Ensure cable routing does not take sharp bends or twists during attaching clamp installations which will result in loss of freedom of cable operation. Do not bend to radius smaller than seven inches.

- **a.** Position new power control cable assembly (54, figure 4-18) to helicopter ensuring proper routing through grommets (35) and other existing grommets on center post and upper cabin roof beam.
- **b.** Install outboad nut (17) on power control cable assembly and insert assembly through bracket (12). Position cable end from bracket at the same distance predetermined in paragraph 4-102, step k. Do not tighten nuts at this time.




Figure 4-18. Gas Produce Control Installation (Sheet 1 of 3).





Figure 4-18. Gas Producer Control Installation (Sheet 2)





20.	Spacer
21.	Screw
22.	Clamp
23.	Screw
24.	Adapter
25.	Clamp
26.	Screw
27.	Spacer
28.	Clamp
29.	Clamp
30.	Screw
31.	Clamp
32.	Spacer
33.	Screw
34.	Clamp
35.	Grommet
36.	Clamp
37.	Nut
38.	Boot

39. Lockwire 40. Nut 41. Balljoint Connector 42. Nut 43. Rigid Connecting Link 44. Rod End Bearing 45. Bellcrank 46. Cotter Pin 47. Nut 48. Washer 49. Bolt 50. Rigid Connecting Link 51. Rod End Bearing 52. Lever, Engine Control 53. Bracket 54. Control Cable Assembly 55. Copilot Throttle Control Linkage 56. Collective Jackshaft

57. Pilot Throttle Control Arm

206061-97-3

Figure 4-18. Gas Producer Control Installation (Sheet 3)

### **NOTE**

Seal nut assembly (16) has an interior felt seal/screper. As a part of MWO 55-1520-228-50-26 the felt seal/scraper was removed and throttle friction sleeve P/N 206-064-714-101 installed. It is acceptable to use the original felt seal /scraper when the friction sleeve is not available. The seal nut assembly (16) must have provisions for lockwire. Locally drilled nuts are acceptable without regard to location and size of safety wire hole if function of nut is not impaired. Seal nut assembly shell be safetied in accordance with TM 55-1500-204-25/1.

c. Install inboard nut (17) and nut (16). Do not tighten nuts at this time. If balljoint (10), adapter (8),


and rod end (6) were disassembled, reassemble to previously recorded dimension. At least 1/4 inch of threads on balljoint (11) and rod end (6) must be engaged in adapter (8). Tighten nuts (7 and 9). Lockwire (C96) nuts (7 and 9) to adapter (8).

**d.** Install nut (11), ball joint (10), nut (19), adapter (8), nut (7), and rod end (6) of control cable. Assemble to previously recorded dimension. At least 1/4 inch of threads on cable end must be engaged in balljoint.

### **NOTE**

Use wrench to hold end of control cable (54) when loosening or tightening jamnut.

**e.** Tighten nut (11) against balljoint (10) and lockwire (C96).



206061-98-1




Figure 4-19. Power Controls - Gas Producer N1 (Sheet 2)




Figure 4-20. **Power Controls** Droop Compensator N2 (Sheet 1 으

1. Tube Assembly	11. Hex Nut	22. Nut	33. Bolt
2. Torque Tube Assembly	12. Slotted Adjusting Screw	23. Cotter Pin	34. Washer
3. Bellcrank	13. Washer	24. Washer	35. Nut
4. Linear Actuator	14. Jamnut	25. Bolt	36. Bolt
5. Stop Screw (Lower)	15. Rod End	26. Nut	37. Washers
6. Stop Screw (Top)	16. Bracket	27. Bolt	38. Nut
7. Governor Arm	17. Washer	28. Washer	39. Washer
8. Governor Arm	18. Shim	29. Nut	40. Bolt
(if installed)	19. Washer	30. Bolt	41. Washer
9. Stop Arm	20. Bolt	31. Washer	42. Nut
10. Eyebolt (if installed)	21. Bracket	32. Nut	43. Bellcrank

206062-124-2

Figure 4-20. Power Controls - Droop Compensator N2 (Sheet 2)

#### **NOTE**

The following step will be performed after MWO 55-1520-228-50-26 has been accomplished.

- **f.** Adjust screw (24, figure 11-1) to provide **0.750 TO 1.500 INCH-POUNDS** friction measured at the throttle twist grip.
- **g.** Install copilot throttle control tube rod end (55, figure 4-18) in clevis of throttle arm (21, figure 11-1). Install bolt (5, figure 4-18) through throttle arm control tube rod end (55, figure 4-18) and control cable rod end (6). Secure with washer, nut (2), and cotter pin (1).
- **h.** Tighten nuts (16 and 17) securing cable assembly to bracket (12) and lockwire (C96).
- i. Install clamp (18) using nut (13), washer (19), spacer (20), and screw (21).
- j. Install clamp (22) to adapter (24) using nut (13), washer (19), and screw (23).
- **k.** Install clamp (25) using screw (26), washer (19), and spacer (27).
  - **I.** Install clamp (28) using existing hardware.
- **m.** Install six clamps (29) securing control cable assembly (54) to center post using nuts (13), washers (19), and screws (30).
- **n.** Install clamp (31) to clamp (34) using nut (13), washer (19), spacer (32), and screw (33).
- **o.** Install clamp (36) using nut (13), washer (19), and screw (30).
- **p.** Install forward two nuts (37) on cable assembly and insert cable through engine fireshield then install aft two nuts (37) on cable assembly. Tighten nuts.

**q.** Install boot (38) on control cable end.

**r.** Install nut (40), balljoint (41), nut (42), tube assembly (43), and rod end (44). At least 1/4 inch of threads on cable end must be engaged in balljoint.

# **NOTE**

When installing bellcrank (2, figure 4-19) or (3, figure 4-20), tighten nut fingertight plus one castellation and install cotter pin. Check bellcrank for freedom of movement.

- **s.** Position bellcrank (45) and throttle controls as described in paragraph 4-104.
- t. Adjust tube assembly (43) if required to position rod end (44) in bellcrank (45). Check witness hole in the tube assembly for adequate thread engagement. Adjust rod end (6) or reposition other parts of the cable assembly if required to obtain correct location of rod end (44).
- **u.** Torque nuts (40 and 42). Install lockwire (C96) from balljoint (41) to nut (42) and from balljoint (41) to nut (40) as shown in detail B of figure 4-18.
- **v.** Install rod end (44) to bellcrank (45) using bolt (49), washer (48), and nut (47). Secure with cotter pin (46).
- **w.** Check control cable assembly for satisfactory freedom of operation.
- **x.** Tighten seal nut assembly (16). If friction sleeve is installed, tighten to obtain desired throttle friction. LockWire (C96) nut assembly (16) to bracket (12) or nut (17).

- **y.** Check both twist grips for satisfactory operation through full range.
- **z.** Perform adjustment of gas producer (N1). Refer to paragraph 4-104.
  - aa. Install pilots seat. Refer to paragraph 2-88.
- **ab.** Install center post cover assembly using retained hardware.
- **ac.** Install right hand cover on upper cabin roof beam by snapping into place.
- **ad.** Close hinged section of right hand engine side cowling (7, figure 2-1).

# 4-103.1. Adjustment - Throttle Friction After MWO 55-1520-228-50-26.

### **NOTE**

There are two ways to add throttle friction after MWO 55-1520-228-50-26. One is by torque of the nut, P/N 206-064-714-101, on gas producer cable which compresses a nylatron sleeve over the cable tube end; the other method is by use of the friction clamp, (26, figure 11-1), which adds friction to the throttle arm. These two function devices have been provided as part of the power droop kit to prevent inadvertent throttle roll off during engine power-onoperations. Note, that a one degree movement at the pilots twist grip will result in an approximate 30 horsepower change.

- **a.** Initial friction will be added by torque of the nut, P/N 206-064-714-101, on the throttle cable.
- **b.** If this does not provide enough system friction, tighten the screw on the friction clamp, (24, figure 11-1).
- **c.** The nut be safetied as in paragraph 4-103. The lockwire installs between the hole in the ball joint connection and the jam nut.

4-104. Adjustment - Gas Producer (N1).

#### NOTE

When checking aircraft in service, rigging is acceptable if pointer is not more than 5/64 inch below the 30 degree mark.

Improper rigging will cause variations in engine speed at idle.

**a.** Rotate twist grip to full increase position and then back right to idle detent position. Maintain the twist grip in the idle position during accomplishment of the next two steps.

#### NOTE

Design of the idle detent button may allow the button to partially pop out. Continue turning twist grip open until button pops out all the way. Make all rigging adjustments using the pilot twist grip.

Rigid connecting link (1, figure 4-19) maybe connected to the upper hole in the bellcrank arm (2) if necessary for correct rigging.

**b.** Position bellcrank (2) as illustrated in figure 4-19, detail D, and connect rigid connecting link (1) to bellcrank (2). If control cable assembly (54, figure 4-18) requires adjustment, back off nut (7) and adjust rod end bearing (6). Use a wrench to hold control assembly adapter (8) when loosening or tightening nut. Recheck position of twist grip to assure grip is against idle detent stop, then check position of bellcrank (2, figure 4-19); install lockwire (C96) between nut (7, figure 4-18) and adapter (8). Install lockwire (C96) between nut (9) and adapter (8).

- c. Set arm (5, figure 4-19) exactly at 30 degree position on quadrant (6), install arm (4) and position as illustrated in figure 4-19, detail D. Install nut (12) on lever and torque 40 to 60 inch-pounds. Adjust connecting link (3) to correct length and connect to lever (4) with bolt (7), washers (8), and nut (9) inboard. Tighten nut (9) fingertight plus one castellation and install cotter pin.
- d. Rotate pilot twist grip to full increase position. Check that fuel control lever is in firm contact with fuel control N1 maximum speed stop. Check that arm (4) does not contact throat of clevis on rigid connecting link (3).
- e. Slowly rotate twist grip from full increase to idel detent postion. The pointer on the fuel control quadrant must be exactly on the 30 degree mark for initial rigging setup. When checking aircraft in service, rigging is acceptable if pointer is no more than 5/64 inches below 30 degree mark.
- f. Release idle detent and rotate twist grip to full closed position. Check that fuel control lever is in contact with fuel control minimum stop.

g. Slowly rotate twist grip from full closed to idle detent position. Check that pointer on fuel control quadrant is no more than 5/64 inches below the 30 degree mark.

#### NOTE

The copilot/observer twist grip does not have an idle detent stop and will normally give greater travel tward cut off when rotated to the idle stop position. This increased travel results from wear in the throttle control system and is aggravated by friction including that added by the throttle friction devices. If copilots twist grip will not achive idle rigging tolerances, inspect for wear in system including arm (25, in figure 11-1) and associated parts in the pilot stick.

h. Check with copilot twist grip to assure that fuel control lever contacts both minium and

maximum stops and that pointer on fuel control quadrant is no more than 5/64 inch below the 30 degree mark when copilot twist grip is rotated to idle detent from either the full increase or full closed position.

- i. Rig the gas producer fuel control. Refer to TM 55-2840-231-23 A, TM 55-2840-241-23 C.
- **j.** Check system for smoothness by turning pilots twist grip. If twist grip forces are considered objectionable by the pilot, the following twist grip force values may be used as a guideline.
- (1) Primary Method: Atach a spring scale on the nut of the balljoint connector of the control cable at view BB, figure 4-19. Spring scale must be attached parallel to the control cable. Control cable is located under the seat at the base of the pilot collective stick. Force required to rotate pilots twist grip must not exceed 20 pounds breakaway from the full closed position. Force required after initial breakaway, to idle position will not exceed 11 pounds. After passing the idle position, force will not exceed 7 pounds throughout range to full open position. The operation will be smooth through the entire range.
- (2) Alternate Method: Check twist grip forces by wrapping tape (C136), or equivalent about the pilot twist grip to prevent da rnage to cork, then wrap cord (C49), around grip in direction to increase throttle. Spiral the wrappings, except for the first several wrappings which will overlap to prevent slippage. Attach spring scale to looped end of cord and pull straight out to unwrap the cord, and advance the throttle. Maximum forces shallnot exceed 30 pounds breakaway, 18 pounds from breakaway to detent position, and 12 pounds after passing idle position.

### NOTE

If proper torque is not attainable, repeat system rigging procedure. Check throttle cable for sharp bends, or improper clamping.

Torque for twist grip will increase as temperatures decrease below 0°F (-18°C). Ensure that rubber boot (detail B, figure 4-19) is in good conditon and that control assembly (10, figure 4-19) is clean. If the inside of the boot is deteriorated replace the boot.

- **k.** Complete rigging check; refer to TM 55-2840-231-23 **A**, TM 55-2840-241-23 **C**. If rigging is not correct the control system must be inspected more thoroughly and corrective action taken. Inspect the control system in detail as follows:
- (1) Inspect lever (4, figure 4-19), clevises on link (3), bellcrank (2), link (1), and all pins or bolts connecting them for wear. Replace all worn parts.
- (2) Repeat paragraphs above to determine if looseness is within limits. If looseness exceeds the 5/64 inch limit on the indicator quadrant, remove pilots seat to inspect the control cable, rod end, pin, twist grip lever, and supporting clamps for wear or looseness which will result in lost motion in the control system. Replace parts which are worn excessively. Also inspect cable for freedom of operation. Check to be sure that cable is routed so it does not take sharp bends. If dual controls are installed, remove copilots seat also and inspect for wear in the N1 control system. Replace excessively worn parts.

### NOTE

Make rigging adjustments using the pilots twist grip. Recheck the linkage movement using the copilot twist grip.

#### NOTE

Engine performance check is required for rigging adjustments of the fuel control.

- **I.** Rig power turbine governor (N2) controls prior to performing the following checks and adjustments.
- m. Perform idle speed check and adjustment in accordance with TM 55-2840-231-23 A, TM 55-2840-241-23 C. Gas producer (N1) speed must be between 62%-64% N1 with generator switch OFF.

# WARNING

Never attempt to adjust N1 idle speed by adjusting rigid connecting link (3, figure 4-19). Pointer must be at 30 degrees or within the specified limits. N1 idle speed must be adjusted by the idle speed adjusting screw. Failure to comply with this warning can result in an engine flameout. Refer to TM 55-2840-231-23 A, TM 55-2840-241-23

### NOTE

Set idle speed at approximately 63% N1 to allow for seasonal temperature changes. Engine performance check is not required for idle speed adjustment. Dual control installation requires an idle speed check from the copilot side also. Idle speed must repeat.

- n. Check idle speed with generator off
- 4-105. Adjustment Power Turbine Governor.

# CAUTION

Adjustment of the power turbine governor controls is a critical flight safety

#### NOTE

Rig collective pitch controls before rigging governor controls.

- a. Disconnect rod end (5, figure 4-20) from lever.
- **b.** Adjust tube assembly (1) to a length of **38.400** inches and install forward end (adjustable) in center hole of torque tube assembly (2). Firewall boot must be installed. Connect tube (1) to bellcrank (3).
- **c.** Before connecting actuator to arm (7 or 8), check stroke of actuator for **1.500** inches travel from full retraction to full extension. (See view A-A.) If necessary adjust as follows:

#### NOTE

If the aircraft is equipped with actuator P/N 206-062-721-1 (vendor P/N 65A120) adjust according to par (1) through (3).

If the aircraft is equipped with actuator P/N 206-062-721-11 (vendor P/N 7185-1) adjust according to par (4) and (5).

The two actuators are sufficiently similar that the illustration in figure 4-20, view A-A and detail A may be used. View B-B and index items 11-13 apply only to the 206-062-721-1.

(1) Run actuator to approximately midpoint of travel. Failure to do this will damage the internal stops if the actuator screw (12) is adjusted.

#### NOTE

All adjustments to actuator stroke must be done with actuator at approximately the midpoint of travel. Adjusting screw (12) should not be allowed to rotate when nut (11) is loosened.

- (2) Back off hex nut (11) and remove washer (13) from pin. Do not operate actuator with washer or nut removed.
- (3) Turn adjusting screw (12) clockwise to increase travel and counterclockwise to decrease travel. Be sure to replace nut every time before checking travel of actuator stroke. Do not overtorque locknut. One full revolution of the slotted adjustment screw changes the stroke 0.114 inches in each direction. Adjust stroke to 1.500 inches from full retract to full extend.
- (4) Run actuator to midpoint of travel. Do not make stroke adjustments when the actuator is at a limit position.
- (5) Turn the 13/16 inch hex shaped extension on the actuator (largest hex on side of actuator where the smaller hex rod protrudes) clockwise to increase travel or counterclockwise to decrease travel. One full turn of the adjustment changes the stroke 0.083 inches. Adjust the stroke to 1.500 inches travel from full retract to full extend.
- **d.** Install forward rod end of actuator (4) in center hole of bellcrank (3).
- e. Install governor arm (7 or 8) on shaft approximately 90 degrees to centerline of indicator on stop arm (9) on the shaft. Install nut (22) on shaft end and torque 40 TO 50 INCH-POUNDS.

# **CAUTION**

To prevent internal damage to actuator (4) hold shaft motionless while turning jamnut (14) or rod end (15). Use a wrench at the end of the shaft. The 206-062-721-1 has wrench flats or a hex at the rod end of the shaft. The 206-062-721-11 has a hex shaped shaft.

**f.** Loosen jamnut (14) on actuator. Be sure to hold shaft when loosening jamnut. Move GOV RPM switch to DECR, fully extending actuator. Check length between centerlines of rod end holes for a maximum of **15.750** inches with actuator still unconnected to lever (7 or 8).

# **NOTE**

Initially install rod end at outboard hole of arm.

g. Move collective stick to full up position and lock. Move GOV RPM switch to full INCR. Move arms (7 or 8 and 9) so that stop arm (9) is **0.010** inch from touching maximum RPM stop screw (6). Adjust rod end (15) to fit and temporarily install bolt (25), washers (24), nut (26) finger tight. Move collective to full down position and lock. Move GOV RPM switch to full DECR. Back out minimum rpm stop screw (5) and adjust to provide **0.010** inch minimum clearance from stop arm (9). There is no minimum rpm stop setting. The minimum rpm stop screw may be removal in order to obtain proper rigging clearances.

# NOTE

With collective controls full up or full down and with actuator at full increase or full decrease, actuator must contact its internal stops before governor stop arm (9) contacts maximum or minimum rpm stops. Ensure that 0.010 inch minimum clearance is maintained between the stop arm and the max stop screw. There is no maximum clearance from governor stops.

# CAUTION

To prevent internal damage to linear actuator (4), hold shaft motionless while turning jamnut (14) or rod end (15). Ex-

cessive contact with governor minimum and maximum rpm stop will result in damage in the slotted area of torque tube (2).

h. With actuator in full decrease, run engine with collective pitch in the full down position. Check minimum rpm for 98% A, 95% C with GOV RPM switch in DECR position and then check for 105% A, 102% C maximum with switch in INCR. Adjust if required by adjustment of the actuator stroke, and rod end, reference paragraph 4-105 a and f. One full turn of adjustment equals 1/2% rpm change on each end (high and low) at the same time. One full turn of the rod end (15) equals 1/2% rpm. Hold hex on shaft and tighten jamnut (14) after final adjustment. Inspect witness hole at shaft end for adequate thread engagement of rod end (15).

### **NOTE**

For inspection purposes on operating aircraft, the aircraft is considered satisfactory for flight if the maximum N2 RPM available with the collective full down and linear actuator at maximum increase is 104% to 105% A or 101% to 103%.

i. If a condition occurs where 98% to 105% A, 95% to 102% C RPM is not attainable with the collective full down, it is permissible to adjust the maximum and/or minimum rpm stop. If the maximum rpm stop is contacted with the collective full down and with full increase, damage to the torque tube (2) will result when the collective is raised to the full up position. Therefore, rigging in accordance with step g. is very important. Maximum limit for increasing the maximum rpm stop screw is for the screw to be even with the governor housing.

### NOTE

Normal operating speed of N2 is 103% A to 100% C. However, if the helicopter is flown to altitude the N2 will be noted to decrease. A minimum of 104% A, 101% C is required on the ground to permit the pilot to maintain 103% A 100% C as altitude increases. In addition approximately 1% decrease in N2 speed can occur due to changes in ambient temperatures. The purposes of rigging to 105% A 102% C is to assure the 104% A 101% C i is available throughout the normal range of ambient conditions.

- **j.** After final adjustments are complete, check maximum stop (6) and minimum stop (5) on governor for **0.010** inch minimum clearance. There is no maximum clearance.
- (1) Secure governor stop (6) and bolt (10) with lockwire (C95).
- (2) Install bolt (25), washers (24), nut (26), and tighten finger-tight plus one castellation, secure with cotter pin (23).
- (3) Ensure rod end (15) is centered in governor arm (7 or 8) before securing jamnut (14).
- (4) Eyebolt lower stop (10, figure 4-20) may be used on OH-58A but maybe removed if necessary for rigging requirement. When the eyebolt is used, a jamnut (not illustrated) must be installed to secure lower stops (5 and 10), The eyebolt is not used on OH-WC. When the eyebolt is not installed a lower atop screw similar to the max stop screw (6) is installed.

#### NOTE

tf further adjustment is required after maintenance operational check, perform procedures as outlined in Paragraph 4-105, step c. Refer to TM 55-1500-328-25.

#### **NOTE**

Some governors recently overhauled may require the removal of bolt (8) and screw (5) to obtain 0.010 minimum clearance as specified in paragraph 4-105, step g.

**4-106.** Adjustment — Droop Compensation (N2). The N2 power turbine governor should maintain any selected speed throughout the collective travel range. In actual operation, N2 may temporarily overspeed or underspeed the rpm selected for a period of approximately two to five seconds, if the collective is moved abruptly. The twist grip should not normally be used to control overspeed except in case of fuel control or governor malfunction. If the rpm comes back to the previous setting, no adjustment is required; if not the droop compensation rate must be adjusted as follows:

### **NOTE**

Droop due to improper adjustment of fuel control will not be corrected by droop compensation.

Since droop rate rigging may affect the rpm range and amount of contact with minimum and maximum rpm stops on the governor, these items must be inspected and adjusted if necessary after each droop rate adjustment.

For droop compensator system inspection criteria refer to para 4-101.

a. Underspeed when collective is raised and overspeed when collective is lowered. Move rod end (15) to inboard hole of arm (8). Recheck compensation. If this did not provide sufficient compensation, move forward end of tube assembly (1, figure 4-20) to upper hole in torque tube assembly (2). Install bolt (36), washers (37 and 39), nut (38) finger-tight plus one castellation and secure with cotter pin (23). Recheck for droop correlation. If this did not provide sufficient compensation, move forward end of linear actuator (4) into upper hole of bellcrank (3). Install bolt (30), washers (31), nut (32) finger-tight plus one caste nation and secure with cotter pin (23). Repeat this procedure to check for correlation. If the above adjust-

ments do not provide proper droop compensation, replace governor.

- **b.** Overspeed when collective is raised and underspeed when collective is lowered. Move rod end (15, figure 4-20) to outboard hole of arm (8). Install bolts (36), washer (37 and 39), nut (38) finger-tight plus one castellation and secure with cotter pin (23). Recheck for droop correlation. If this did not provide sufficient compensation, move forward end of tube assembly (1) to lower hole in torque tube assembly (2). If this did not provide sufficient compensation, move forward end of linear actuator (4) into lower hole of bellcrank (3). Install bolt (30), washers (31), nut (32) finger-tight plus one castellation and secure with cotter pin (23). Repeat this procedure to check for correlation. If the above adjustments did not provide proper droop compensation, replace governor.
- **4-107.** Troubleshooting Power Controls. For troubleshooting, refer to TM 55-2840-231-23 A, TM 55-2840-241-23 C.

4-108. Removal — Power Controls.

### **CAUTION**

Do not twist power control cable in housing and do not remove cable from housing as this assembly will fall apart. Refer to figure 4-19.

- **a.** Rigid cable and connecting link bellcranks are removed by removing attaching bolts and clamps.
- **b.** Remove torque tube assembly (2, figure 4-20) as follows:
- (1) Remove two bolts (20) and two washers (19) that attach bracket (21) to fuselage.
- (2) Remove bracket (21), washer (17), and shim (18) from torque tube assembly (2).
- (3) Remove torque tube assembly (2) with washer (17) from bracket (16).
- (4) Remove washer (17) from torque tube assembly (2).

# CAUTION

Any visible indication of fretting, corrosion or wear is cause for replacement of bolt (7 and 11, figure 4-19). Bolt (7) will be installed with head outboard to preclude chafing of oil hoses and tubing. Install nut (9) finger-tight plus one castellation, then install cotter pin. Install nut (13) on bolt (11) finger-tight.

#### NOTE

When installing bellcrank (3, figure 4-20), tighten nut finger-tight plus one castellation and install cotter pin. Check bellcrank for freedom of movement.

### 4-109. Installation - Power Controls.

- **a.** Secure all tubes, cables, and bellcranks in position with proper bolts, nuts, clamps, and other necessary hardware.
- **b.** Install torque tube assembly (2, figure 4-20) as follows:
- (1) install torque tube assembly (2) in bracket (16) with one washer (17).
- (2) Install one washer (17) and bracket (21) on torque tube assembly (2).
- (3) Temporarily install bracket (21) to fuselage with bolts (20) and washers (19).
- (4) Slide torque tube assembly (2) toward bracket (16). Using a feeler gage, take a measurement of the amount of clearance (gap) between bracket (21) and washer (17).

# CAUTION

Peel shim (18) must provide a clearance of 0.003 to 0.020 inch to provide freedom of movement of torque tube assembly.

(5) Obtain shim (18) that equals clearance measurement. Peel shim (18) to obtain a clearance of

- **0.003 to 0.020** inch to provide freedom of movement of the torque tube assembly (2) on final installation.
- (6) Remove bolts (20) and washer (19) from fuselage to free bracket (21).
- (7) remove bracket (21) and washer (17) from torque tube assembly (2).
- (8) Install previously fitted shim (18) and washer (17) on torque tube assembly (2).
- (9) Install bellcrank (43) on torque tube (2), bolt (40), washer (41), nut (42) finger-tight plus one castellation and secure with cotter pin (23).
- (10) Install bracket (21) on torque tube assembly (2). Secure bracket (21) to fuselage with bolts (20) and washers (19). Seal bracket (21) and bolts (20) with sealing compound (C130).
- (11) Ensure a clearance of 0.003 to 0.020 is still present between washer (17) and bracket (21).

# 4-110. GOVERNOR CONTROL LINEAR ACTUATOR.

**4-111. Description - Governor Control Linear Actuator.** The linear actuator is a motor-actuated device operated by a GOV RPM (beeper) switch on the pilot collective stick and allows engine output speed to be varied over a normal range.

# NOTE

The linear actuator maintenance is limited in this section. For more complete instructions, refer to Chapter 9.

- **4-112.** Cleaning Governor Control Linear Actuator. Clean exterior surfaces with a clean, lint-free cloth dampened with drycleaning solvent (C62).
- 4-113. Inspection Governor Control Linear Actuator.
- **a.** Inspect cover assembly visually for dents and scratches.
- **b.** Inspect rod end bearings visually and manually for loose bearings. refer to paragraph 9-93.

# 4-114. Removal - Governor Control Linear Actuator.

- **a.** Disconnect all electrical power from helicopter. Remove screw holding cover. Remove cover and disconnect electrical connectors from actuator. Protect ends of wires with electrical tape.
- **b.** Remove cotter pins, nuts, and bolts from rod end bearings and remove actuator.

- **4-115.** Installation Governor Control Linear Actuator.
- **a.** Install forward end of linear actuator (4, figure 4-20) into center hole of bellcrank (3). Install bolt (30), washers (31), nut (32) finger-tight plus one castellation and secure with cotter pin (23). Install linear actuator rod end (15) into governor arm (7), bolt (25), washers (24), nut (26) finger-tight plus one caste nation and secure with cotter pin (23). Ensure rod end (15) is centered on governor arm (7).
- **b.** Connect electrical wire connector and secure with washers and nut (not illustrated). Install protective cover with screw.

# **CHAPTER 5**

# **ROTORS**

#### 5-1. MAIN ROTOR ASSEMBLY.

- Description Main Rotor Assembly. The 5-2. main rotor assembly is a two bladed, semirigid, seesaw type rotor with underslung mounting. The blades are mounted in the hub assembly grips with through bolts, which have hollow shanks for installation of weights to balance the hub. After balancing, the bolts must be kept with their respective rotor hub grips. Blade alignment is accomplished by adjustment of Made latches, which engage the root end of the blade. The blade grips are retained on the hub yoke by means of tenion/torsion strap assemblies. Changes in blade pitch angle are made by turning the grips on the yoke; each grip has two pitch change bearings. Two types of hubs may be used; either oil or grease lubricated. With oil lubrication, oil reservoirs, with sight gages, are provided for pitch change bearings in the two grips and for two pillow block bearings utilized with the flapping axis trunnion. With grease lubrication, grease fitting and relief valves are used for the same purpose. The rotor blades are all metal, five piece assemblies consisting of an extruded aluminum alloy nose block, aluminum alloy trailing edge, and an aluminum honeycomb filler (figure 5-1).
- **5-3. Operational Check Main Rotor Assembly.** Maintenance operational checks shall be performed in accordance with TM 55-1520-228-MTF and TM 55-1500-328-25.

### 5-4. Inspection - Main Rotor Assembly.

- a. Visually inspect main rotor hub (figure 5-2) for cracks, nicks, scratches, and gouges. The main rotor hub is not serviceable if cracks are found. Using a flashlight, carefully inspect bottom of yoke assembly for cracking adjacent to trunnion bearing bores. inspect for cracks between pillow block and T-handle work aid hole. Inspect pitch horns for cracking adjacent to trunnion bearings.
- **b.** Inspect grip assemblies for cracks adjacent to outboard strap retention bolt. Visually inspect the visible outside surfaces of the grip tang blade bolt holes for cracks. Inspect pitch horn to grip retaining bolts for evidence of looseness.
- **c.** Inspect main rotor retaining nut (2, figure 5-1), for damage and security in locking.

- **d.** Inspect blade retention bolts (3) for visible damage, evidence of corrosion, and security of attachment.
- **e.** Inspect grip seal areas for evidence of leakage. With oil lubricated hub some oil leakage is normal. Replace seals when loss of oil is equivalent to the amount in the reservoir sight glass for a two-hour flight duration.
- **f.** With oil lubricated hub replace grip seal if no oil is visible in the grip sight glass reservoir after helicopter has not operated for a period of 24 hours. (Except for arctic operation.)
- **g.** Inspect main rotor hub grip dust shield for deformities. Cracks may be repaired using sealing compound (C131). No other deformities allowed.
- **h.** inspect pillow block retention bolts for damage, evidence of corrosion, and security of mounting (movement of slippage marks).
- i. Inspect the main rotor blades in accordance with paragraph 5-99.

#### NOTE

Any grease leakage other than weeping during high ambient temperatures or at the first run-up after servicing, is cause to replace the seals on the main rotor greaseable hub pillow blocks and/or grips.

### 5-5. Troubleshooting - Main Rotor Assembly.

- **a.** Refer to table 5-1 for troubleshooting procedures.
- **b.** Refer to paragraphs 5-3,5-4,5-6, and 5-23 for specific testing and mechanical procedures for adjusting the main rotor.

### NOTE

Before using table 5-1, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 5-1, notify the next higher level of maintenance.

# Table 5-1. Troubleshooting - Main Rotor Assembly

#### CONDITION

TEST OR INSPECTION

# **CORRECTIVE ACTION**

1. Vertical 1:1 vibration increasing with airspeed (approximately 6-1/2 per second).

STEP 1. Rotor blades out of track.

Check rotor blades tracking. Refer to paragraph 5-255.

STEP 2. Check friction on swashplate uniball. Refer to paragraph 5-113.

Adjust swashplate friction. Refer to paragraph 5-113.

- 2. Lateral 1:1 vibration
  - STEP 1. Spanwise unbalance (normally vibration increasing with rpm in hover).

Check for spanwise balance of main rotor. Refer to paragraph 5-6, step a. If static balance check becomes necessary, refer to paragraph 5-9.

STEP 2. Chordwise unbalance (normally vibrations increase).

Check for chordwise balance of main rotor. Refer to paragraph 5-6, step g. If static balance check becomes necessary, refer to paragraph 5-9.

STEP 3. End play in excess of 0.004 inch on main rotor trunnion. Refer to paragraph 5-6.

Adjust trunnion centering. Refer to paragraph 5-52.

STEP 4. Excessive wear and play in swashplate and support assembly. Refer to paragraph 5-112.

Replace swashplate and support assembly. Refer to paragraphs 6-114 and 5-121.

- 3. 2/rev vibration (approximately 13 per second).
  - STEP 1. Check friction on swashplate uniball. Refer to paragraph 5-113.

Adjust swashplate friction. Refer to paragraph 6-113.

STEP 2. Check for excessively loose control linkage or swashplate parts. Refer to paragraphs 5-156 and 5-112.

Adjust or replace control linkage. Refer to paragraphs 5-48 and 5-155.

Replace swashplate parts. Refer to paragraph 5-118.

# Table 5-1. Troubleshooting - Main Rotor Assembly (Cont)

#### CONDITION

TEST OR INSPECTION

### **CORRECTIVE ACTION**

STEP 3. Check for loose or improperly torqued tailboom attachment bolts. Refer to paragraph 2-377.

Retorque bolts 375 TO 415 INCH-POUNDS. Refer to paragraph 2-378.

STEP 4. Check for loose blade latch bolt/nuts. Refer to paragraph 5-57.

Retorque trailing edge latch nuts 75 TO 95 FOOT-POUNDS. Use care not to disturb blade alignment. Refer to paragraph 5-60.

STEP 5. Check for deteriorated or seperated pylon isolation mount; also for worn transmission to isolation mount attachment bolt or bearing. Refer to paragraphs 2-291 and 2-294.

Replace defective parts. Refer to paragraph 2-296.

4. Spike knocking.

STEP 1. Spike knocking will not be encountered in normal service with serviceable isolation mount except in cases of extremely rough air or excessively abrupt maneuvers. Spike knocking may be encountered in normal service if the isolation mount is deteriorated.


Replace isolation mount. Refer to paragraphs 2-293 and 2-298.

- 5. Autorotation rpm high (low pitch setting on blades too low).
  - STEP 1. Pitch links too short. Refer to paragraphs 5-158 and 5-255.

Adjust pitch links. Refer to figure 5-52 and paragraphs 5-158 and 5-255.

- 6. Autorotation rpm low (low pitch setting on blades too high).
  - STEP 1. Pitch links too long. Refer to paragraphs 5-158 and 5-255.

Adjust pitch links. Refer to figure 5-52 and paragraphs 5-168 and 5-255.




- 1. M/R Hub and Blade Assembly
- 2. M/R Mast Nut 3. Blade Bolt
- 4. Latch Nut
- 5. Bolt
- 6. Washer
- 7. Nut
- 8. Pitch Link Assembly
- \*9. Nut
- \*10. Spring Washer
- \*11. Washer

- \*12. Packing
- \*13. Grip Reservoir
- \*14. Fitting
- \*15. Packing
- \*16. Sight Glass \*17. Packing
- \*18. Bolt
- \*19. Plug
- \*20. Sight, Plug
- 21. Pillow Block Housing
- 22. Cotter Pin
- \* These items are for oil lubricated hubs only. See figure 1-5, detail B and C.

206011-252

Figure 5-1. Main Rotor Assembly (Typical)






Figure 5-2. Main Rotor Hub Surface Repair Limits.

# 5-6. Alignment and Balance - Main Rotor Assembly (Installed).

# Premaintenance Requirements for Alignment and Balance of Main Rotor Assembly (Installed)

Condition	Requirements		
Model	OH-58A and OH-58C		
Part No. or Serial No.	AII		
Special Tools	None		
Test Equipment	Protractor/straight edge feeler gage		
Support Equipment	None		
Minimum Personnel Required	One		
Consumable Materials	(C115)(C120) (C102) (C96		

# CAUTION

Balance weights at the inboard trailing edge and at the leading edge tip caps must not be removed or changed in the field. Spanwise balance should be accomplished by addition of weights to the blade attach bolts.

### NOTE

The need to spanwise balance main rotor blades will be indicated by a 1:1 lateral vibration. 1:1 vibrations are rpm sensitive, not airspeed sensitive.

**a.** To spanwise balance main rotor blades, add two wraps of one-inch tape on one blade at station 208.07. Refer to figure 5-32. (If lateral is mild, use one wrap.) If this is worse, remove the tape and put it on the opposite blade. Add tape in one wrap or 1/2 wrap

increments until the smoothest high rpm level is reached. Recheck low rpm, 97% A, 94% C N2 rpm level.

#### NOTE

If the rotor cannot be balanced by use of tape, it is probable that the rotor is out of chordwise balance. Check chordwise balancing.

**b.** If rotor vibration was corrected by spanwise procedure, remove tape and install quantity of lead weight, equal to 10.8 times the weight of the tape, in the hollow shank of the appropriate blade bolt (3, figure 5-1).

#### NOTE

The amount of lead weight to be installed in the blade bolt to compensate for one wrap of one-inch wide masking tape is 28 grams or one ounce.

- c. Carefully remove cap from blade bolt (3, figure 5-1), and place weight in blade bolt. Record the amount of weight added. Replace cap and operate helicopter at 103% A, 100% C N2 rpm to confirm that the correct amount of weight has been added,
- d. Check main rotor trunnion for centering in the yoke, prior to sweeping blades. Position a combination square on bottom outboard edge of yoke parallel to chordwise axis. Take a feeler gage reading between blade of square and mast. Record reading. Take a similar reading from opposite side of yoke, If the reading indicates the trunnion is off center more than 0.003 inch, proceed to the following step,
- **e.** Remove main rotor hub and blade assembly in accordance with paragraph 5-8.

# CAUTION

Balance weights at the inboard trailing edge and at the leading edge tip caps must not be removed or changed in the field, Chordwise balance should be accomplished by aft sweep of the blade.

**f.** If centering of trunnion is required, refer to paragraph 5-48.

#### NOTE

Before sweeping a main rotor blade, loosen the nut on-blade bolt (3, figure 5-1) to prevent binding. After blade has been swept, torque nuts 200 TO 220 FOOT-POUNDS plus drag torque valve.

 ${f g}$ . If chordwise balance is required, as determined in preceding steps, sweep one blade slightly aft as follows:

#### **CAUTION**

Blade sweep adjustments are sensitive. Do not exceed a maximum of three points turn on the nuts (4, figure 5-1). Record all adjustments made on DA Form 2406-16, M/R HUB. Do not sweep blades forward.

### NOTE

Hold blade latch retainer as near vertical as possible.

If using the vibrex to balance, you may exceed 3 points as long as you ensure thread exposure of latch bolt is as specified in TM 1-1500-204-23.

- (1) Index, with a pencil mark, position of latch nut (4, figure 5-1) on the leading edge side of the main rotor blade and loosen nut approximately 1/2 point.
- (2) Torque latch nut (4) on the trailing edge side of the main rotor blade to 75 TO 95 FOOT-POUNDS.
- (3) Torque latch nut (4) on the leading edge side of main rotor blade to 75 TO 95 FOOT-POUNDS.
- (4) If condition is worse, remove sweep and sweep the opposite blade aft 1/2 point. Sweep until the best low rpm lateral vibration level is obtained.
- (5) Recheck the high rpm level and sweep blades aft as indicated by amount of vibration noted.

# NOTE

After all adjustments have been completed, ensure the thread exposure of latch bolt (13, figure 5-11) is as specified in TM 1-1500-204-23 beyond the self-locking element of nut (9).

- **5-7. Repair Main Rotor Assembly.** Refer to specific components for maintenance instructions.
- 5-8. Removal Main Rotor Assembly.

# Premaintenance Requirements for Removal of Main Rotor Assembly

Condition	Requirements
Model	OH-58A and OH-58C
Part No. or Serial No.	AII
Special Tools	(T12) (T7) (T8) (T9)
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	Two
Consumable Materials	(C96)
Special Environmental Conditions	None

#### WARNING

Do not allow main rotor blades to rotate pitch change axis. If blade is inadvertently allowed to rotate on the pitch change axis beyond 90 degrees, the main rotor grip retention strap shall be replaced.

**a.** Code pitch link assemblies (1, figure 5-6) for reinstallation in same position. Disconnect pitch link assemblies from pitch horn (7) by removing cotter pin (2), nut (3), washers (4), and bolt (5) from clevis (6).

# NOTE

Secure loose links with protective padding to prevent damage to links.

**b.** Secure main rotor blade pitch horns (7) to yoke (8) with T-Handle and install nut and washer.

- **c.** For local fabrication of work aid T-Handle, refer to figure 5-8.
- d. Install blade tiedown on main rotor blade to guide rotor during removal.

# CAUTION

Main rotor must be perpendicular to the mast when using the power wrench (T2) to loosen or tighten the mast nut.

- **e.** Remove bolt (9, figure 5-6), washer (10), nut (16), and mast nut lock (11). Remove mast nut (12) using standard tools or power wrench (T7), adapter (T8), and socket (T9). Refer to figure 5-7.
- 5-9. Alignment and Balance (Static), Main Rotor Assembly.

# Premaintenance Requirements for Alignment and Balance of Main Rotor Assembly (Static)

Condition	Requirements
	_
Model	OH-58A and OH-58C
Part No. or Serial No.	AII
Special Tools	(T8) (T13) (T42)
Test Equipment	Protractor
Support Equipment	None
Minimum Personnel Required	Two
Consumable Materials	(C149) (C143) (C96)
Special Environment Conditions	None

# WARNING

Do not allow main rotor blades to rotate on pitch change axis. If blade is inadvertently allowed to rotate on the pitch change axis beyond 90 degrees, the main rotor grip ratention strap shall be replaced.

#### NOTE

Check main rotor trunnion for centering in the yoke prior to sweeping blades. Refer to paragraph 5-42.

- a. Align main rotor as follows:
- (1) Place main rotor hub and blade assembly on a stable level table with a steel top. Place two parallel supports on stand beneath main rotor. Supports may be aluminum bars approximately 2 x 3 x 12 inches long or suitable substitute.

### NOTE

Place a block of wood against the heads of rotor blade retention bolts and tap the block, moving the grips outward of the hub to ensure blade grips are fully seated.

(2) Support each main rotor blade at approximately precone angle of the yoke with adjustable stands. Install main rotor blade positioning locks from balancing kit (T42).

# NOTE

Precone angle is found by moving blade tip up or down so the blade retaining bolt turns freely in the grip assembly.

- (3) Place bubble protractor on yoke (chordwise), set bubble to level and tighten setscrew, Adjust both main rotor blade grips to zero pitch angle with the yoke. Set bubble protractor on grip blade bolt boss while adjusting grips to ZERO pitch angle.
- (4) Position scope support (T28) and scope assembly (T13) on main rotor hub trunnion and yoke. Refer to figure 5-10.
- (5) Check scope for ZERO adjustment. Sight through scope at an object approximately 50 feet

away. Draw a straight vertical line on object that will line up with vertical crosshair. Loosen clamp screws on scope assembly and rotate scope 180 degrees on tube axis. Tighten clamp screws. Vertical crosshair should line upon drawn line. If vertical crosshair does not align with drawn line, draw a second vertical line on object that will align with vertical crosshair. Measure one-half the distance between the two previously drawn lines and draw a third vertical line between two existing lines. Adjust screw marked "L" on side of scope to align vertical crosshair with third drawn line. Rotate scope 180 degrees on tube axis and check that crosshair aligns with third drawn line. If not, repeat above step until satisfactory.

- **(6)** Check blade alignment by sighting on head of alignment pin (figure 5-10) located on upper surface of each blade tip.
- (7) Loosen nut (5, figure 5-11) on blade being swept to prevent binding. Adjust nuts (9) to sweep blade as required to align center of alignment screw head with vertical crosshair of scope.

#### CAUTION

Ensure blades are not binding when sweep adjustments are made. Raise blade tip off stand each time sweep adjustment is made.

- (8) Reverse scope assembly on mount. Check and adjust opposite blade assembly.
- (9) Determine drag of nuts (9), and torque nuts 75 TO 95 FOOT-POUNDS plus nut drag torque value. Do not allow blade latch retainer to rotate against wear pads. Hold blade latch retainer as near vertical as possible.
- (10) Determine drag of blade bolt nuts (5) and torque 200 TO 220 FOOT-POUNDS plus nut drag torque value.
- (11) After torqueing nuts, repeat alignment check and readjust if necessary. Remove scope and scope Support.

#### NOTE

The following alternate method may be used to align the main rotor blades using a nylon cord and mirror in place of scope.

- (12) Attach a thin nylon chord (C149) between alignment pins at tip of each blade. Draw the line tight and secure in place with masking tape (C143).
- (13) Check that each blade grip is on **ZERO** pitch angle in relation to the yoke. (See substep (3).)
- (14) Adjust nuts (9, figure 5-11) to sweep blade as required to locate nylon cord over both blade bolt holes as shown in view A of figure 5-10. Loosen nut (5, figure 5-9) on blade being swept to prevent binding.
- (15) The vertical position of the cord in relation to the blade bolt is determined with a small mirror. Lay the mirror on the flat machined surface of the blade grip. View, with one eye, the cord, the mirror image of the cord, and the alignment point on the blade bolt. When all three reference points are aligned at both blade bolts, the main rotor blades are aligned.

#### WARNING

In performing the following procedures, do not allow main rotor blades to rotate on pitch change axis. If blade is inadvertently allowed to rotate on the pitch change axis beyond 90 degrees, the main rotor grip retention strap shall be replaced.

- b. Balance main rotor as follows:
- (1) Align main rotor blades, if not previously accomplished, and service grips and pillow block reservoirs.
- (a) Support main rotor blades while carefully removing nuts, washers, and T-handles. Do not allow blades to rotate.
  - (b) Install balance tool pitch horn lock.
- (2) Set up tools to accomplish balance procedure in accordance with TM 55-4920-201-14.
- (3) Check chordwise balance and correct imbalance by sweeping one blade aft as follows:

#### **NOTE**

Blade sweep adjustments are sensitive. Do not exceed a total of three points turn on nut (9, Figure 5-11). Index nuts to blade latches with pencil or paint marks and record all changes made on DA Form 2408-16 for main rotor hub

- (a) Loosen blade bolt nut (5, Figure 5-11) in blade to be swept.
- (b) Loosen front nut (9) and tighten rear nut (9) the same amount to sweep blade aft. Do not sweep blade forward.
- (c) Recheck cordwise balance end repeat step (2) as required. Do not exceed a total of the points turn on nut (9).
- (d) Torque nut (9) 75 to 95 FOOT POUNDS plus nut drag torque value.
- (e) Torque nut (5) 200 to 220 FOOT POUNDS plus nut drag torque value.

#### NOTE

After all adjustments are complete, ensure thread exposure of latch bolt (13 Figure 5-11) Is as specified in TM 1-1500-204-23 beyond self-locking element of nut (9).

- (4) Check spanwise balance and correct imbalance as follows:
  - (a) Remove cap from bolt (1) of light blade.
- (b) Add lead weight to hollow shank of blade bolt (1) to balance rotor spanwise.
  - (c) Reinstall cap.
- (d) Support main rotor blade while removing pitch horn lock
- (e) Install T-handles and secure with lockwire (C96) to trunnion bearings.

Premaintenance requirements for Installation of

5-10 Installation - Main Rotor Assembly.

Main Rotor Assembly		
Condition	Requirements	
Model	OH-58A and OH-58C	
Part No. or Serial No.	All	
Special Tools	(T12) (T7) (T8) (T9)	
Test Equipment	None	

Support Equipment	None
Minimum Personnel Required	Two
Consumable Materials	(C22) (C51) (C53) (C84) (C96) (C129)
Special Equipment Condition	None

#### **CAUTION**

To prevent entry of contaminants Into mast assembly and transmission, ensure mast cap plug (2, Figure 5-9) is installed and sealed with compound (C129).

#### **CAUTION**

If screw (26, Figure 5-4) protrudes above washer (17), do not Install mast nut (12, Figure 5-6) until condition is corrected.

#### NOTE

The static stop shims should be checked and adjusted before installation of the hub. This includes new or overhauled hubs; and reinstallation of serviceable hubs.

- a. Visually inspect condition of screw (26, Figure 5-4) washer (17) and special nut (12, Figure 5-6). Any evidence of scoring of screw head; gouging or scoring on washer or nut is cause for replacement.
- b. Using metal scale or straightedge ruler, determine if head either screw (26) protrudes above top surface of washer (17). This is accomplished as follows:
- (1) Hold edge of scale on surface perpendicular to washer.
- (2) Move scale across surface of washer, paying particular attention to area of screw heads.
- (3) If for any reason, scale catches on screw head; screw is unserviceable.
- Clean mast threads, splines, and cone set with solvent (C22).

- (1) Examine mast and trunnion splines for nicks, burrs, and scratches.
- (2) Examine trunnion cone mating surface. Tapered surface should be smooth with no high spots. If necessary, use India stone (C84) and dress surface to a depth not to exceed **0.003** inch after cleanup.
- (3) Inspect cone assembly (15, Figure 5-6) for burrs, nicks, grooves, or scratches. Remove high spots on mating surface using India stone (C84).
- (4) Inspect main rotor trunnion (Figure 5-3, sheet 2) for correct master spline position.
- d. Apply light coat of corrosion preventive compound (C51) to splines and recess provided for cone assembly (15).
  - e. Install sling (T12) on main rotor assembly.

#### WARNING

Do not allow main rotor blade to rotate on pitch change axis. If blade is inadvertently allowed to rotate on pitch axis beyond 90 degrees, main rotor grip retention shall be replaced. Rotor mast must be aligned directly over mast to avoid damage to mast threads.

#### NOTE

#### Install split cones as matched set only.

f. Position cone assembly (15) with bevel side up on mast and carefully lower main rotor assembly into position. Apply small amount of corrosion preventive compound (C53) to mast threads, install mast nut (12). Torque mast nut (12) 250 to 275 FOOT POUNDS to align

with mast nut lock (11). If using power wrench (T7), adapter (T8) and socket (T9) refer to Figure 5-7. Install mast lock nut (11, Figure 5-6), bolt (9), washer (10), and nut (16). Torque nut (16) to 80 INCH-POUNDS.

#### NOTE

No further retorqueing Is required unless mast nut is once again removed. If low mast nut torque is suspected after Initial torque and helicopter has been in operation, the applicable check is to remove all torque and retorque 250 FOOT POUNDS minimum, 275 FOOT POUNDS maximum. within these limits; retorque as near as possible to 275 FOOT POUNDS.

#### CAUTION

Ensure static stop (1, Figure 5-12) has been properly shimmed for tight fit with 0.002 to 0.004 inch interference fit; and is property seated In place on fitting (16), prior to torquing of bolt (2). Refer to paragraph 5-56.

- g. Position one blade up to gain access to previously installed static stop (1, Figure 5-12). It maybe necessary to remove lockwire and loosen bolts for alignment of static stop. Torque bolts (2) to 175 INCH POUNDS and lockwire (C96) together. Repeat procedure for opposite static stop.
- h. Carefully remove T handle and install pitch link assembly. Refer to paragraph 5-158.
- i. Perform tracking procedures for main rotor blades. Refer to paragraph 5-255.

#### Section I. MAIN ROTOR HUB

#### 5-11 MAIN ROTOR HUB.

5-12 Description - Main Rotor Hub. The main rotor hub assembly provides for attachment and control of main rotor blades. The hub assembly consists of grips, yoke, trunnion, pitch hems, blade bolts, strap bolts, and blade latches, pillow block, hub ring, static stops, and associated parts. Two types of hub maybe used; either oil or grease lubricated. With oil lubrication, oil reservoirs with sight gages, are provided for pitch change bearings in the two grips and for two pillow block bearings utilized with flapping axis trunnion. With grease lubrication, grease fittings and relief valves are used for the same purpose.

#### NOTE

For maintenance of main rotor hub refer to ap plicable instructions contained in this section for each component.

#### TM 55-1520-228-23

# Premaintenance Requirements for Disassembly of Main Rotor Hub

Condition	Requirements
Model	OH-58A and OH-58C
Part No. or Serial No.	All
Special Tools	(T31) (T36) (T46)
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	Two Men
Consumable Materials	(C96) (C146) (C22) (C102) (C131) (C104) (C51) (C126) (C55) (C116) (C118) (C107) (C124) (C77) (C38) (C45)
Special Environmental Conditions	None

#### WARNING

Do not interchange parts from one hub assembly to another. Yoke, grip, trunnion, and pillow block bearings can be replaced only at AVIM level of maintenance. Grip may be removed for grip seals replacement.

# 5-13. Cleaning and Corrosion Protection - Main Rotor Hub.

**a.** Spot clean the main rotor hub with naphtha (C22).

#### NOTE

Corrosion protection procedures are to be accomplished at overhaul and/or when the main rotor hub is disassembled for any reason.

 ${\bf b.}$  The following instructions are applicable in their entirety to the main rotor hubs.

#### NOTE

Cover (6, figure 5-12) is bonded onto the blade grip (13) latch bolt lugs with sealing compound (C131).

All parts are to be thoroughly cleaned with aliphatic naphtha (C22); ensure all parts are thoroughly dry before installing.

- **c.** Apply corrosion preventive compound (C51) to the following parts:
- (1) The inner diameter of latch bolt (12, figure 5-12) holes in main rotor grip (13) lugs.
- (2) The inner diameter of pin holes in strap fittings (16). Also to the outer diameter of fittings but NOT the area that will be sealed.
- (3) The mating area of the main rotor yoke (28) and radius ring (17).
- (4) The inner diameter of holes in each end of straps (14).
- (5) The outer diameter of pins (15) and shanks of bolts (12).
- (6) The mating surfaces of grip, strap fitting, and strap assembly.

#### 5-14. GRIPS - MAIN ROTOR.

**5-15. Description - Grips, Main Rotor.** The main rotor hub grips (13, figure 5-12) provide for attachment of the rotor blades to the main rotor hub. The blade grips are retained on the hub yoke by tension/torsion strap assemblies. Changes in blade pitch angle are made by turning the grips on the yoke. Each grip has two pitch change bearings (34). Oil reservoirs or grease fittings provide lubrication of the pitch change bearings.

#### 5-16. Removal - Grips, Main Rotor (AVIM).

### NOTE

Identify parts for reinstallation on same side if both rotor grips are removed.

- **a.** Remove main rotor assembly. Refer to paragraph 5-8.
- **b.** Remove main rotor blades. Refer to paragraph 5-100.
  - c. Remove lockwire and T-handle.
- **d.** Remove static stop (1, figure 5-12) by removing bolt (2), washer (3), shim (4), and stop (5).
  - e. Remove nut (7), latch retainer (8), and spring (9).
- f. Remove nut (10) using socket wrench (T31), washers (11), and bolt (12).

#### CAUTION

When grip is removed from yoke in the fdlowing step, do not allow weight of yoke to rest on hub shield (22). Lay yoke on side.

- g. Slide grip(13) and pitch horn (20) off yoke (28).
- 5-17. Disassembly Grips, Main Rotor (AVIM).
- a. Remove three nuts (27, figure 5-12), bolts (18), washers (19), and remove pitch horn (20). Remove seal (21) and packing (29), from pitch horn and discard.
- **b.** Insert a wooden or aluminum dowel **2.125 x 12** inches through grip and into retainer (23). Rock dowel and retainer a few times to break seal. Remove retainer by withdrawing dowel, and discard seal (24) and packing (25).
- **c.** Remove bearings (34) and spacer (35, figure 5-12). Apply heat lamp to grip if required. Use thermomelt (C146) to indicate temperature and prevent overheating.
- **d.** If hub is grease lubricated, remove grease fitting (40) from grip (13) only if replacement is required.

#### CAUTION

Do not heat grip to temperature in excess of 200°F (93°C).

- 5-18. Inspection Grips, Main Rotor (AVIM).
- **a.** Inspect grip brings for apparent damage caused from excessive wear, pitting or overheating. Check for damage to rollers or races.
- **b.** Visually inspect the inner and outer surfaces of the grip tangs for cracks at the outboard side of the blade bolt holes at the interface of the inside hold diameter and adjacent radius.
- **c.** Inspect grip in accordance with figure 5-13. Visually check grip for corrosion, pitting, and general condition. If hub is grease lubricated, inspect grease fitting for clogs, corrosion, or damage.
- **5-19.** Cleaning Grips, Main Rotor (AVIM). Clean seal bore in grip (13, figure 5-12) and packing groove in retainer (23) with aliphatic naphtha (C22).
- 5-20. Repair Grips, Main Rotor (AVIM).

#### NOTE

Refer to figure 5-13 as necessary in performing following repair procedures.

- **a.** Repair of the grip is accomplished by sanding the grip with sandpaper (C126) and polishing with crocus cloth (C55).
  - b. Apply epoxy primer (C116) to repaired areas.
- **c.** If hub is grease lubricated, repair of grease fitting is limited to replacement of unserviceable grease fitting with serviceable like items.
- 5-21. Repair Grip Buffer Plate (AVIM).
  - a. Bond loose buffer plate as follows:
- **b.** Sand buffer plate in area to be bonded with sand-paper (C124) and wipe dry with a cloth moistened with MEK (C107).
  - c. Clean bond area on grip with MEK (C107).

- d. Apply a light brush coat of primer (C118) to buffer plate surface to be bonded. Air dry primer at room temperature for **30 to 50** minutes.
- e. Mix adhesive (C19) per manufacturers instructions. As soon as possible after mixing adhesive, apply to each faying surface extending approximately 1/16-inch past edge diameters of buffer plate. Press parts together: 'firmly ensuring buffer plate is aligned with blade bolt holes in grip. Remove excess adhesive with MEK (C107). Apply bond line pressure over full bond region throughout the cure cycle. Cure for two hours at temperature of 160° to 180°F (71° to 81°C) or for 45 to 55 minutes at 190° to 2100F (88° to 99°C). During cure cycle, check for edge voids and fill as necessary.

#### 5-22. Assembly Grips, Main Rotor (AVIM).

#### NOTE

Grips shall be replaced In pairs of the same part numbers.

a. Install bearings (34) and spacer (35, figure 5-12). Apply heat to grip if required. Use thermomelt (C146) to indicate temperature and prevent overheating.

### **CAUTION**

Do not heat to temperature In excess of 200oF (93°C).

b. Refer to figure 5-14 to determine the correct outboard seal configuration. The latest configuration can be used to replace the earlier parts on any main rotor hub. The older seal assembly (3) and retainer (6) must be used together. If correct parts are not available, replace the entire outboard seal retainer assembly. If is not necessary for both outboard grip seals to be identical.

#### NOTE

A locally fabricated tapered plug type work aid may be used to facilitate Installation of excluder or seal on retainer.

(1) Clean grooves in retainer (4, 5, 6) and seal bore in grip with naphtha (C22) and dry.

#### NOTE

For ease of Installation steps (2) and (3) may be reversed depending on type of M/R hub.

(2) Install new excluder (2) on retainer (4 or 5) or install new seal as assembly (3) on retainer (6). Refer to figure 5-14 for correct installation.

### 5-14 Change 24

- (3) Install new packing (1) under lip of excluder (2) as shown in figure 5-14.
- (4) Coat outboard packing groove of retainer (4, 5, or 6) with sealing compound (C131) and install new packing (7) in groove. Coat packing with sealing compound.
- (5) Coat seal bore in grip (13, figure 5-12) with sealing compound (C131). Install assembled outboard seal retainer assembly with packing (7, figure 5-14) outboard (toward rotor blade) and fully seat to end of grip seal bore.
- (6) Cure sealing compound for 72 hours at room temperature (70° to 80°F). Accelerated cure is 1 hour at 700 to 80°F (21° to 27°C) followed by 2 hours at 175°  $(79^{\circ}C): + 5^{\circ}$ .
- c. Apply a thin coat of sealing compound (C131) to outside diameter of new seal (21) and inside diameter of pitch horn (20). Coat lip of new seal with lubricant (C1 04) and install inboard face of pitch horn. Ensure mating surfaces of pitch horn (20) and grip (13) are wiped dean and dry.
- d. Install new packing (29, figure 5-12) in outboard face of pitch horn (20). Position pitch horn on grip (13) and secure with three bolts (18), three washers (19) (next to bolt heads), three washers (26) and three nuts (27). Torque nut to **100 TO 140 INCH-POUNDS**.
- e. Apply slippage marks using torque seal (C47) or other suitable paint across bolt threads, washer and nut to grip.
- f. If hub is grease lubricated, install grease fitting (40) on grip (13). Apply unreduced primer (C11 6) to threads of grease fitting and install in grip while wet.

### 5-23. Installation Grips, Main Rotor (AVIM).

### **NOTE**

Prior to performing any installation procedures, Inspect yoke (paragraph 5-52 and accomplish corrosion control paragraph 5-13).

a. Install strap, pin, fitting and ring per paragraphs 5-36 and 5-13. On oil lubricated hub apply lubricating oil (C102) to grip bearings (34, figure 5-12), spacers (35), and to the bearing surfaces and seal bores on yoke (28). On grease lubricated hub hand pack grip bearings, coat yoke bearing spindles and lightly lubricate yoke seal bores with grease (C77). Install grip on yoke.

- **b.** Inspect and install bolt and blade latch retainer in accordance with para 5-55.
- **c.** Service main rotor hub in accordance with paragraph 1-9.

#### NOTE

Do not torque or lockwire bolts (2, figure 6-12) until main rotor hub and blade assembly is installed on mast. Leave bolts (2) just loose enough to slide or lightly tap the stops laterally for alignment to the mast but do not allow the inboard T/T strap fitting to rotate. Install T-handles and secure with lockwire (C96) to trunnion bearings.

**d.** Install main rotor blades. Refer to paragraph 5-106.

#### 5-24. PITCH HORN - MAIN ROTOR.

- **5-25. Description Pitch Horn, Main Rotor.** The pitch horn is a component of the main rotor hub and is used to transmit control inputs to the blade grip.
- 5-26. Removal Pitch Horn, Main Rotor. (AVIM)
- **a.** Remove main rotor assembly. Refer to paragraph 5-8.
- **b.** Remove the blade in accordance with paragraph 5-100.
- **c.** Remove the grip in accordance with paragraph 5-
- **d.** Remove pitch horn in accordance with grip disassembly instructions listed in paragraph 5-17.
- **e.** if hub is grease lubricated, remove relief valve (41, figure 5-12) from pitch horn (42) only if necessary.

- **5-27. Cleaning Pitch Horn, Main Rotor.** Clean pitch horn with aliphatic naphtha (C22) and wipe with dry clean cloth.
- **5-28. Inspection Pitch Horn, Main Rotor.** Inspect pitch horn as shown in figure 5-15.
- **5-29.** Repair Pitch Horn, Main Rotor (AVIM). Repair by sanding with sandpaper (C126) and polishing with crocus cloth (C55). Refer to figure 5-15. If hub is grease lubricated repair of relief valve is limited to replacement of unserviceable item with serviceable like item.
- **5-30.** Installation Pitch Horn, Main Rotor (AVIM). Install pitch horn in accordance with grip assembly instructions listed in paragraph 5-22 and 5-23. If hub is grease lubricated, install relief valve (40, figure 5-12) on pitch horn (42). Apply unreduced primer (C116) to threads of relief valve and install while wet.

# 5-31. HUB STRAP/PIN/FITTING AND RING - MAIN ROTOR.

- **5-32. Description Hub Strap/Pin/Fitting and Ring.** The strap/pin/fitting and ring are components of the main rotor hub that provide for attachment of main rotor hub assembly to the blade assembly.
- 5-33. Removal Hub Strap/Pin/Fitting and Ring Main Rotor.
- **a.** Remove main rotor hub and blade assembly in accordance with procedures listed in paragraph 5-8.
- **b.** Remove blade in accordance with procedures listed in paragraph 5-100.
- **c.** Remove/disassemble grip in accordance with procedures listed in paragraphs 5-16 and 5-17.

#### CAUTION

#### Do not hammer on end of strap assembly.

- **d.** To remove strap assembly (14, figure 5-12), perform the following steps: (AVIM)
  - (1) Move strap assembly (14) inboard.
  - (2) Push pin (15) out of fitting (16).
- (3) Remove strap assembly (14), fitting (16) and ring (17).

### 5-34. Inspection - Hub Strap/Pin/Fitting and Ring - Main Rotor.

a. Inspect strap in accordance with the following steps:

#### NOTE

# Strap assembly must be replaced if any of the following inspections fail.

(1) Urethane rubber for deterioration and bulging especially on inboard surfaces near bushings (spool). Bulging may be accepted on any strap assembly provided bulging does not exceed 0.150 inch above normal contour. Refer to figure 5-16. Bulging not to exceed 0.250 inch may be accepted on strap assemblies prior to serial number 13336. Bulging may be measured by laying a straight edge across the bulge parallel with normal contour or by determining the difference in width at point of bulge with width at normal contour. A micrometer may be used for this purpose.

#### NOTE

Deviations from a straight contour other than bulging are acceptable. Due to the tapered construction of strap legs width comparison measurements must be taken in close proximity to bulge.

(2) Permanent displacement and obvious looseness of the spool in strap assembly. Wires next to the spools visible for more than **0.090** inch at any one spot, measured perpendicularly to the pin bore and directly outward from the top edge of chamfer. This separation

is the result of shortcomings in bonding at the spool rather than urethane deterioration.

- (3) Not more than 10 loose wire ends shall be visible next to each spool. Loose wire ends can result from terminal points of winding at time of manufacture.
- (4) Wire exposure in any other area is not permitted. Exposure would indicate cracking and other forms of urethane deterioration. Urethane deterioration may result from damage, long term oil saturation, and/or improper cure at time of manufacture. Deterioration of the urethane cover may permit wires to cross internally and rub against one another. Rubbing and fretting may result in long term breakage of wires.
- (5) A permanent twist is acceptable provided bulging is within limits. Strap stiffness may vary from strap to strap when flexed in the unloaded condition.
- **(6)** Grease or oil contamination resulting in swelling/severe deterioration of the urethane coating is cause for rejection.
- (7) Inspect spool bore using a ten power glass. Look for cracking and pitting. No cracking permitted. Pitting will not exceed **0.002** inch in depth.
- (8) Spool bore for wear. Large hole for a maximum 0.877 inch diameter and small hole for a maximum 0.752 inch diameter.
  - b. Inspect pin in accordance with figure 5-17.
  - c. Inspect fitting in accordance with figure 5-18.
  - d. Inspect ring in accordance with figure 5-19.

# 5-35. Repair - Hub Strap/Pin/Fitting and Ring - Main Rotor (AVIM).

#### NOTE

# Repairs are not authorized for the strap or pin.

- **a.** To repair fitting, polish with crocus cloth (C55). Refer to figure 5-18.
- **b.** To repair ring, polish with crocus cloth (C55). Refer to figure 5-19.

# 5-36. Assembly - Hub Strap/Pin/Fitting and Ring/Static stop - Main Rotor. (AVIM).

- **a.** Apply a coat of sealing compound (C131), to the mating area of the yoke (28, figure 5-12) and the flange of fitting (16), and themating area of ring (17) and fitting (16).
- **b.** insert ring (17) at inboard end of yoke (radius end of outside diameter facing outboard).
- **c.** Insert strap (14) through outboard end of yoke spindle (small hole inboard).

#### NOTE

The P/N 206-011-147-5 and P/N 206-011-154401 tension/tofaion straps are fully interchangeable in pairs only.

- **d.** Position fitting (16), over inboard end of strap and insert pin (15).
  - e. Seat fitting in yoke by pulling strap outboard.
- f. Permit excess sealing compound (C131) soueeze out to remain in place.
- g. Determine that milled (flat) surface of fitting (16) is positioned torward yoke (28) base and shim static stops as follows: Place shims (4) on static stop (1). Use shims of correct thickness provide 0.002 to 0.004 inch interference fit between static stops (1) and fitting (16). Position rubber atop (5) in flat surface of fitting (16) and install static stop (1) with washers (3) and bolts (2). Secure bolts (2) so that static stops are not loose. Static stop to mast adjustment bolt (2) torque will be accomplished when hub assembly is installed on helicopter.
  - h. install the grips. Refer to paragraph 5-23.
  - i. Install the blade. Refer to paragraph 5-106.
- **j.** Install the main rotor hub and blade. Refer to paragraph 5-10.

#### NOTE

Ensure stop (5) and static atop (1) are property aligned, shimmed, and installed before sealing compound (C131) on fitting (16) cures

#### 5-37. TRUNNION - MAIN ROTOR.

**5-38. Description - Trunnion - Main Rotor.** The trunnion is the center of the pitch axis and is housed by pillow blocks. The pillow blocks are attached to the main rotor hub yoke, which couples the main rotor blades.

#### 5-39. Cleaning - Trunnion - Main Rotor.

- **a.** Clean trunnion (7, figure 5-4) and associated exposed potions with naphtha (C22).
- **b.** A soft fiber bristle brush (C31) may be used to scrub parts for cleaning.
- **5-40.** Inspection Trunnion Main Rotor. Inspect trunnion (7, figure 5-4) exposed portions in accordance with figure 5-3. Inspect trunnion (figure 5-3, sheet 2) for correct master spline position.
- **5-41.** Repair Trunnion Main Rotor. Repair trunnion (7) exposed portions in accordance with figure 5-3.

### 5-42. Adjustment - Trunnion - Main Rotor (AVIM).

- **a.** The preferred method is to locally manufacture a work aid per Figure 5-20.
  - (1) Position the yoke on a flat surface.
- (2) Tighten the two set screws (8) alternately until the set screws bottom.
- (3) Position work aid (figure 5-20) in trunnion (7). Ensure work aid is properly seated.
- (4) Apply thumb and index finger pressure to work aid during measuring process to eliminate any looseness between work aid and trunnion. Attach a dial indicator work aid and rotate work aid so that dial indicator pointer is against the machined surface of either pillow block.
- (5) Adjust the dial indicator to read zero, then rotate the work aid to the opposite pillow block machined surface. Take and record setting.
- (6) A maximum tolerance of 0.003 inch is allowed to property center the trunnion on the pitch axis.


#### TM 55-1520-228-23

- (7) If trunnion is not centered within 0.003 inch, adjust set screws (8) alternately and equally until limits are satisfied.
- (8) Torque each adjusting screw (8) 115 to 130 inch pounds plus drag torque. Recheck centering.
- **(9)** Attach a spring scale to washer (17) through one of the two holes provided.
- (10) Rotate trunnion (7) to approximately 45 degrees from its normal position.
- (11) With a steady upward pull on the spring, take and record reading as the trunnion passes through the approximate mid-point of travel.
- (12) The pull required shall not exceed 5 0 pounds (maximum 50 inch-pounds rotational preload).

#### NOTE

If trunnion friction is excessive or ratcheting occurs, disassemble and check for rough surface on mating faces of screws (8), thrust plugs (9), wear plates (if used), and inner faces of pillow blocks. All mating surfaces must be smooth (32 micro-inches or better), square, free from burrs and sharp edges. There must be a coating of lubricant on all mating surfaces.

- (13) After trunnion adjustment procedures are completed, apply primer (C115) and sealant (C120) to setscrews (8). Do not remove setscrews (8) to apply primer and sealant, capillary action will cause it to flow into threaded area.
- (14) Install main rotor blades. Refer to paragraph 5-106.
- (15) Check alignment and balance (static). Refer to paragraph 5-9.
- (16) Install main rotor hub and blade assembly. Refer to paragraph 5-10.
- (17) Perform tracking on main rotor hub blade assembly. Refer to paragraph 5-255.



AREA A AREA B AREA C

**MAXIMUM DEPTH** 

**TYPE OF DAMAGE** 

NICKS, SCRATCHES, SHARP DENTS AND CORROSION


See Note No. 2

0.030 In. Before and After Repair

0.020 In. Before and After Repair

#### NOTES:

- 1. These limits apply with bearing sleeves removed from spindles.
- 2. Area Ano defects or repairs permitted in the radii. That is not removable with crocus cloth (C55).
- 3. Nicks and dents on the splines may be cleaned up to one third of the spline depth for half the length of the spline. A maximum of three splines may receive cleanup.
- Damage to the spindle (area C) must not reduce overall diameter of bearing support surface. Rework limited to removal of sharp edges from nicks and scratches.
- 5. Permitted damage and repairs consisting only of localized small nicks, pits, or dents, and longitudinal scratches should not exceed 10% surface area on each spindle.
- 6. Adjoining or continuous damage shall not exceed 0.250 square inch area with no more than two such areas diametrically opposed per spindle.
- 7. Repair area, except splines and spindles, will be coated with epoxy polyamide primer (C116).
- 8. No cracks permitted.



#### **VIEW LOOKING DOWN**

#### NOTE

This inspection is not applicable to trunnion that has Serial Number starting with prefix "HB-"

#### NOTES:

- Viewing trunnion from above, visually inspect that the master spline is centered approximately 14 degrees counterclockwise from the axis through the trunnion splines. The spline groove immediately clockwise to the master spline is centered on the axis of the splines.
- 2. Trunnion with mislocated master spline must be replaced.




Figure 5-4. Main Rotor Hub Trunnion and Pillow Block (Sheet 1 of 4)




Figure 5-4. Main Rotor Hub Trunnion and Pillow Block (Sheet 2)





Figure 5-4. Main Rotor Hub Trunnion and Pillow Block (Sheet 3)



P/N 206-011-156-101

DETAIL F




Figure 5-4. Main Rotor Hub Trunnion and Pillow Block (Sheet 4)




Figure 5-5. Removal - Trunnion Bearing Inner Race






Figure 5-6. Removal - Main Rotor Assembly



- 1. Input Crank Handle
- 2. Knurled Ratchet Indexer
- 3. Power Wrench
- 4. Drive Bar
- 5. Retaining Nut
- 6. Trunnion
- 7. Socket
- 8. Reaction Torque Adapter



Main rotor must be perpendicular to the mast when using the power wrench (T7) to loosen or tighten the mast nut.

#### NOTE

Torque nut to 250 FOOT-POUNDS. Wait 3 minutes. Monitor torque loss.


Retorque nut to 250 FOOT-POUNDS and monitor torque indicator for 1 minute.

Retorque if torque loss occurs in the 1 minute interval.

Back off holding pressure between wrench and torque adapter to zero.

Remove wrench and adapter and check for alignment of lock with nut splines.

Figure 5-7. Main Rotor Mast Nut Torqueing




1. All dimensions are in inches.

2 Fabricate from 4130 Steel Nut NSN5310-00-167-1332 Washer NSN5310-00-167-0835.

206011-259

Figure 5-8. T-Handle Work Aid



- 1. Main Rotor Mast
- 2. Cap-Plug, Protective

Figure 5-9. Main Rotor Mast Protective Cap - Plug




Figure 5-10. Alignment — Main Rotor Assembly




Figure 5-11. Removal - Main Rotor Blade





Figure 5-12. Replacement of Main Rotor Hub Grip Seals and Bearings



#### **DAMAGE LOCATION SYMBOLS**


TYPE OF DAMAGE	MAXIMUM	DAMAGE AND REP	AIR DEPTH
MECHANICAL DAMAGE	0.010 in. before and after repair	0.020 in. before and after repair	0.030 in. before and after repair
CORROSION DAMAGE	0.005 in. before and after repair	0.010 in. before and after repair	0.015 in. before and after repair
MAXIMUM AREA PER FULL DEPTH REPAIR	See Note 1	1.000 sq. in.	Not Critical
NUMBER OF REPAIRS	Not Critical	Not Critical	Not Critical
EDGE CHAMFER TO REMOVE DAMAGE	0.020 in. before and after repair	0.040 in. before and after repair	0.060 in. before and after repair
BOLT HOLD AND BORE DAMAGE	0.002 in. for	1/4 circumference	See Note 2


### NOTES:


- 1. Area of repair on surfaces mating with blade should not exceed one-half of any quadrant.
- 2. Maximum I.D. of blade bolt holes 1.525 in., maximum I.D. of strap retaining bolt holes 0.880 inch.
- 3. No cracks are permitted in any areas.
- 4. All dimensions are in inches.
- 5. Main rotor grip bearing surface (I.D.) not to exceed 4.005 in. 206011-263

Figure 5-13. Main Rotor Grip - Damage Limits

- 1. Packing 568-331S59
- 2. Excluder \$30769
- 3. Original Seal Assembly S30128-332G5
- 4. Retainer 206-011-129-3
- 5. Retainer 206-011-129-1
- 6. Original Retainer 206-010-107-1
- 7. Packing MS29561-230








### NOTE

Original retainer (6) and seal (3) should be used together. Do not mix with later configuration parts. See text for specific information.

Figure 5-14. Main Rotor Seal (Outboard) Retainar Assembly



### Notes:

- 1. Area A is restricted to one pair per lug. Minimum radius of repair is 0.050 inch
- 2. Area B may have two repair areas on the arm and one on each segment between pitch horn to grip lugs. Minimum radius of repair is 0.350 inch.
- 3. Any damage and / or subsequent cleanup to sealing surfaces of reservoir, mount, and inboard grip seal, requires flush and flat surface to prevent possible leakage.
- 4. Repair areas must be coated with chemical conversion coating (C38) followed by primer (C116).
- 5. No cracks permitted.
- 6. All dimensions are in inches.
- 7. Maximum allowable 0.120 inch.

Figure 5-15. Inspection and Repair Limits - Pitch Horn - Main Rotor




Figure 5-16. Torsion - Tension Strap (Sheet 1 of 2)




Figure 5-16. Torsion - Tension Strap (Sheet 2)



TYPE OF DAMAGE

MAXIMUM DEPTH

SCRATCHES THROUGH
CORROSION PROTECTIVE
COATING

FLAKING OF CORROSION PROTECTIVE COATING

CORROSION PROTECTIVE COATING WORN THROUGH AT ANY POINT

**EVIDENCE OF CORROSION** 

CRACKS

None Allowed


None Allowed

None Allowed

None Allowed

None Permitted

Figure 5-17. Inspection and Repair Limits - Main Rotor Hub Pin



TYPE OF DAMAGE	MAXIMUM DEPTH
NICKS, SCRATCHES, SHARP DENTS	0.002
CORROSION	0.002
MAXIMUM AREA PER FULL DEPTH REPAIR	0.250 Inch Square
NUMBER OF REPAIRS	One Inside and One Outside
EDGE CHAMFER	0.020
BORE DAMAGE	0.0005 For 1/4 Circumference

### NOTES:

- 1. No cracks are permitted.
- 2. All dimensions are in inches.

206011-268

**DAMAGE AREA** 

Figure 5-18. Inspection and Repair Limits - Main Rotor Hub Fitting




TYPE OF DAMAGE	DAMAGE AREA	
NICKS, SCRATCHES, SHARP DENTS	0.002	
CORROSION	0.002	
NUMBER OF REPAIRS	Two	
EDGE CHAMFER	0.010	

### NOTES:

- 1. Coat repaired areas with chemical conversion coating (C38)
- 2. All dimensions are in inches.

Figure 5-19. Inspection and Repair limits - Main Rotor Hub Ring



NOTE: MAKE WORK - AID FROM ALUMINUM BAR STOCK

Figure 5-20. Modified Work-Aid for Trunnion Centering,

- **b.** The alternate method for trunnion centering will consist of using main rotor mast work-aid P/N 206-010-332. Refer to Figure 5-21.
- (1) To satisfactorily adjust trunnion friction, refer to paragraph 5-42 steps b (1) thru b (7).
- (2) Mount yoke on main rotor mast work aid (P/N 206-010-332).
- (3) Position a combination square on bottom outboard edge of yoke (in plane parallel to chordwise axis). Refer to figure 5-21.
- (4) Measure gap with feeler gage between blade square and mast. Record reading.
- **(5)** A maximum, tolerance of 0.003 is allowed to properly center trunnion on pitch axis.
- (6) If trunnion centering is not within limits, adjust setscrews (8) alternately and equally until limits are satisfied.

#### **NOTE**

Ensure that the trunnion friction load and trunnion centering requirements are satisfied before returning rotor hub to serviceable status.

- (7) After trunnion adjustment procedures are completed, refer to paragraph 5-42, substeps b.(13) thru b.(17).
- 5-43. Removal Trunnion Main Rotor (AVIM).
- **a.** Remove main rotor hub assembly. Refer to paragraph 5-8.
- **b.** Remove main rotor blades. Refer to paragraph 5-100.

### **CAUTION**

Bearing (11, figure 5-4) and bearing inner race (15) become separated when pillow block (6) is removed from yoke. Ensure bearing (11) and inner race (15) are mated to the same side, when pillow block (6) is removed and installed.

- c. Remove nuts (5), washers (4), bolts (1), bushings (3), and washers (2), cut lockwire and remove filler plug (13). Remove and discard packing (14). Slide pillow block (6) off trunnion; repeat process to remove pillow block from opposite side.
- **d.** To avoid contamination of bearing (11) in pillow blocks (6), cover with barrier paper (C26) or equivalent.
- **e.** Remove screws (26, Figure 5-4) and washer (17).




Figure 5-21. Main Rotor Hub Trunnion Centering

# 5-44. Disassembly — Trunnion — Main Rotor (AVIM).

a. Turn adjusting setscrews (8, figure 5-4) to push thrust washers (9) out of trunnion (7). Remove adjusting setscrews (8) by continuing to turn in same direction.

### NOTE

If replacement of bearing (11) is not required, omit substeps b.(1) thru b.(5).

- **b.** Remove inner bearing race (15) from trunnion (7) as follows:
- (1) Remove sealant from trunnion spindle on inboard side.
- (2) Install bearing puller attachment (T46) between trunnion (7) and inboard face of inner bearing race (15). See figure 5-5.

- (3) Fabricate a pressing sleeve work aid (figure 5-22) that will clear the inner bearing race (15) inner diameter.
- (4) Place pulling attachment on a hydraulic press or equivalent. See figure 5-5.

# CAUTION

Ensure that bearing pulling attachment edges do not contact trunmon spindle during pressing operation.

(5) Install fabricated pressing sleeve work aid on trunnion spindle and apply pressure to pressing sleeve work aid. Ensure that trunnion (7, figure 5-4) is not allowed to drop when trunnion separates from bearing inner race (15).

# 5-45. Cleaning - Trunnion - Main Rotor (AVIM).

**a.** Clean trunnion (7), setscrews (8), thrust washers (9), bearing inner race (15), washer (17), and bushings (3) with aliphatic naphtha (C22).


**b.** A soft fiber bristle brush (C31) may be used to scrub parts for cleaning.

#### NOTE

If circumstances prevent part to be assembled and reinstalled with 72 hours of cleaning, coat with corrosion preventive (C72) and cover with barrier paper (C26) or equivalent.

# 5-46. Inspection - Trunnion - Main Rotor (AVIM).

- **a.** Inspect trunnion (7. figure 5-4) in accordance with figure 5-3.
- **b.** Damage or wear to bearing inner race (15, figure 5-4) will result in replacing the bearing assembly (11).
- **c.** Damage, wear, or cracking on thrust washer (9) will warrant replacement.
- d. Damage or wear on setscrew (8) will warrant replacement.



NOTE: Make work-aid from aluminum bar stock.

Figure 5-22. Work-Aid for Trunnion Spindle Inner Bearing Race Removal

e. Deleted.

**5-47.** Repair - Trunnion Main Rotor (AVIM). Repair trunnion (7, figure 5-4) in accordance with figure 5-3.

### 5-47.1 INSTALLATION/REPAIR - TRUN-NION THRUST PLATES - MAIN ROTOR.

#### NOTE

Trunnion thrust plug wear plates may be installed on any main rotor head.

- a. Trunnion thrust plates maybe installed/maintained as follows:
- (1) Locally fabricate wear plates P/N 206-010-159-101 per figure 5-4, sheet 3, detail D.
- (2) Shorten thrust plug 0.1 inch per figure 5-4, sheet 3, detail E, (new P/N after modification is 206-010-110-105).
- (3) Install and adjust as required per paragraph 5-48.

#### 5-48. Assembly - Trunnion - Main Rotor (AVIM).

- **a.** Seal center portion of hollow setscrew (8, figure 5-4) with sealing compound (C131). Ensure that sealant does not interfere with the wrenching action on either end.
- **b.** Install setscrews (8) in trunnion (7) through bore of spindle.

#### NOTE

Steps c. (1) and c. (2) may be omitted if the bearing inner race (15) was not removed from trunnion (7) during disassembly.

- **c.** Install bearing inner race (15) to trunnion spindle as follows:
- (1) Heat inner bearing race (15) to a temperature not to exceed 275°F (135°C). Remove inner bearing race (15) from heat and press on trunnion. Check to ensure that outboard ends of race are flush with outboard ends of trunnion spindle. Repeat process for installing the opposite side bearing inner race.
- (2) After trunnion (7) and bearing inner race have cooled to room temperature, assure that trunnion assembly is clean. Apply a bead of sealing compound (C131) around inboard end of bearing inner race (15).

#### **CAUTION**

Use of standard length plug/washer with the thrust plate may result in interference between the mast and the adjustment screw. Thrust plug 206-010-110-3 which is 0.810 inch long, must be used without wear plates. If wear plates are used the thrust plug 206-010-110-105 which is 0.1 inch shorter must be used. Local modification of the-3 to the-105 is permissible. See Figure 5-4.

- **d.** Apply a light coat of grease (C77) to new packing (10), all surface of thrust washer/plug (9), wear plates, if used, and bores of trunnion (7). Install wear plates, if used, into outboard ends of trunnion between adjusting screw (8) and thrust (9). Install thrust washer/plug (9) into outboard ends of trunnion (7).
  - **e.** To install trunnion pillow blocks, refer to paragraph 5-84.
    - f. Deleted.
  - **g.** To adjust trunnion centering, refer to paragraph 542.

## **CAUTION**

After installation of screws (26, Figure 5-4) use a straight edge to determine if screws protrude above surface of washer (17). If So, these screws are unserviceable and must be removed and replaced.


- a Install waaher(17, Figure 5-4) and screws (26).
- 5-49. YOLK/SHIELD MAIN ROTOR HUB.
- **5-50. Description-Yoke/Shield-Main Rotor Hub** The yoke/shield contains assemblies which retain the blades inside the yoke and provides for changes in pitch angle.
- 5-51. Removal —Yoke/Shield— Main Rotor Hub.
- **a.** Remove main rotor hub blade assembly in accodance with procedures listed in paragraph 5-8.
- **b.** Remove blade in accordance with procedures listed in paragraph 5-100.
- **c.** Remove grips in accordance with procedures listed in paragraph 5-16.
- **d.** Remove main rotor hub strap/pin/fittings and rings in accordance with Procedures listed in paragraph 5-33.

- 5-52. Inspection Yoke/Shield Main Rotor Hub (AVIM).
  - **a.** Inspect yoke in accordance with figure 5-23.

#### NOTE


False brinelling is a wear condition that occurs when rolling element bearings move back and forth through small angles The lubricant la forced from under the ball or roller and metal-to-metal contact occurs wear and fretting follow. False brinelling can appear similar to brinelling but moat often exhlbits two or three overlapping depressions under each rolling element.

- (1) False brinelling is acceptable to a maximum depth of **0.0015** inch on main rotor yoke bearing journals. No limit as to number of false brinelling marks, or quadrant of locations. There should be no attempt to polish out the marks.
- (2) Inspect depth of false brinelling by using a work aid similar to that shown in figure 5-22.1.
- **b.** Inspect shield (22, figure 5-12) for cracks. Determine that sealing lip of shield is not bent or distorted. No cracks are allowed in the dust shield assembly.
- 5-53. Repair Yoke/Shield Main Rotor Hub (AVIM).
  - a. Repair yoke as follows
- (1) To repair areas A and C of figure 5-23 use sandpaper (C126) and polish with crocus cloth (C55).
  - (2) To repair area B refer to Note 2 of figure 5-23.
  - **b.** Shield replacement procedures areas follows
    - (1) Remove shield and sealant if required.



YOKE BRINELL DEPTH INSPECTION

Figure 5-22.1. Yoke Brinell Depth Inspection with Work Aid.



0.010

0.005

## NOTES:

- 1. Area A may have one repair par sagmant except the segment at the base of the yoke which may hove two repairs per aide. Minimum radius of repair is 0.350 inch.
- 2. Area B should not be damaged in excess of that removable with crocus cloth (C55). (Trunnion area will not be repaired.) Area B includes sleeve P/N 206-010-245-101. Bearing wear or corrosion wear cannot exceed 0.0015 inch.
- 3. Area C may have six repair areas. No repairs should overlap. Minimum radius of rapairs is 0.350 inch
- 4. Ail Repairs, except seal and bearing areas, will be coated with epoxy polyamide primer (C116).
- 5. No cracks permitted.

CORROSION

6. All dimensions are in inches.

NICKS, SCRATCHES, SHARP DENTS

206011-273

0.020

0.010

See Note 2

Figure 5-23. inspection and Repair Limits- Yoke — Main Rotor

(2) Install shield on yoke as follows:

#### **NOTE**

## Do not allow weight of yoke to rest on shield.

- (a) Abrade shield lightly in area to be bonded with abrasive paper (C123), and wipe with cloth moistened with MEK (C107). Wipe dry with clean cloth. Clean bond area of yoke with MEK and wipe dry.
- **(b)** Apply thin even coat of sealing compound (C131) to mating surface of shield and yoke and allow sealing compound to dry to a tacky stage (evidenced by adhering but not transferring to finger when touched).
- **(c)** Install shield (lip facing outboard) on yoke and press parts firmly together. Ensure shield is seated firmly on yoke. Fair out sealant squeeze-out and air cure for a 4-hour minimum.

## 5-54. Installation — Yoke/Shield — Main Rotor Hub (AVIM).

- **a.** Install straps/pins in accordance with procedures in paragraph 5-36.
- **b.** Install grips in accordance with procedures in paragraph 5-23.
- **c.** Install blades in accordance with procedures in paragraph 5-106.
- **d.** Install main rotor hub and blade assembly. Refer to paragraph 5-10.

# 5-55. BOLT AND BLADE LATCH RETAINER.

- **5-56. Description Bolt and Blade Latch Retainer.** Bolt and blade latch retainer provides the means of adjusting the blade latches for blade alignment.
- **5-57.** Inspection Bolt and Blade Latch Retainer. Inspect bolt and blade latch retainer for cracks, wear, corrosion, and security of mounting. Refer to figure 5-24.

#### NOTE

Blade latch retainer stops may contact wear pads in normal operation. No maintenance required if visual inspection reveals no obvious damage to retainer stops or wear pads that impair their function.

- 5-58. Removal Bolt and Blade Latch Retainer.
- **a.** Remove main rotor assembly. Refer to paragraph 5-8.
- **b.** Remove nut (7, figure 5-12), blade latch retainer (8) and spring (9).
- **c.** Use socket wrench (T31) to remove nut (10) and washer (11).
  - **d.** Remove bolt (12), with remaining hardware.
- **5-59.** Repair Bolt and Blade Latch Retainer. Repair bolt and blade latch retainer in accordance with figure 5-24.
- **5-60.** Installation Bold and Blade Latch Retainer. Install main rotor blades in accordance with paragraph 5-106.
- **a.** Clean inside diameter of strap bolt holes in grips with naphtha (C22) and dry. Corrosion preventive compound (C51) per para 5-13.
- **b.** Install bolt(12) through grip and strap with locking recess in bolt head mated to pin in grip. Clean corrosion preventive compound from threads of bolt (12) with naphtha (C22). Install washer(11) and nut (10). Torque nut to **180 FOOT-POUNDS** using socket wrench (T31).

### NOTE

Ensure that there is no metal contact between the latch retainer prongs (8) and the main rotor blade wear pads prior to applying torque.

**c.** Install sprint (9) latch retainer (8), and nut (7). Torque nut (7) **75 TO 95 FOOT-POUNDS** plus frictional torque of nut on bolt measured prior to contact of nut to mating parts.

### **NOTE**

After all adjustments have been completed, ensure the aft end of bolt (13, figure 5-11) has thread exposure as specified in TM 55-1500-204-25/1 beyond the self-lock element of nut (9).

**d.** Check alignment of hub blade assembly. Refer to paragraph 5-6.



AREA A AREA B

TYPE OF DAMAGE

NICKS, SCRATCHES, SHARP DENTS

0.030

See Note 2

CORROSION

0.015

## NOTES:

- Area A may have two repair areas. Minimum radius of repair is 0.350 inch. Accomplish repair using sandpaper (C126) and polish with crocus cloth (C55). Any repair to the latch retainer where there is contact with blade wear pad must be smooth and contoured to prevent possible damage to the wear pads.
- 2. Area B shall not have damage in excess of that which penetrates the bolt coating.
- 3. Repair of nicks and dents on the strap bolt threads should not exceed ONE THIRD OF THE THREAD DEPTH AND A LENGTH OF ONE THREAD.
- Repairs on the blade latch retainer must be coated with epoxy polyamide primer (C116).
- 5. All dimensions are in inches.

206011-274

Figure 5-24. Inspection and Repair Limits — Bolt and Blade Latch Retainer — Main Rotor

### 5-61. STATIC STOP - MAIN ROTOR HUB.

- **5-62. Description-Static Stop-Main Rotor Hub.** The static stop (figure 5-25) is a component of the main rotor hub which limits movement of strap fittings and provides contoured surface between mast and hub assemblies.
- 5-63. Removal Static Stop Main Rotor Hub.
  - **a.** Position blade up to gain access static stop.
- **b.** Remove static stop (1, figure 5-12) by removing bolt (2), washer (3), shim (4), and stop (5).
- **5-64.** Inspection-Static Stop—Main Rotor Hub. Inspect static stop in accordance with figure 5-25.
- 5-65. Repair Static Stop Main Rotor Hub.

### **CAUTION**

Contact of mast and wear plate on the static stop would cause damage to the mast.

#### NOTE

Make sure the plate and its adhesive squeeze-out do not enter the radius of the static stop (in the area where the stop contacts the mast). Contact of mast to adhesive squeeze-out will probably cause the plate to pop-off.

- **a.** Repair using sand paper (C126) and polish with crocus cloth (C55).
- **b.** Rebond wear strip on P/N 206-011-121-103 as follows:
- (1) Remove old adhesive from static stop and wear strip. Clean bonding surfaces with MEK (C107).
- (2) Bond wear plate to static stop using adhesive (C11).
- 5-66. Installation Static Stop Main Rotor Hub.
  - **a.** Place shim (4, figure 5-12) on static stop (1).

### NOTE

Use shims (4, figure 5-12) of correct thickness to provide 0.002 to 0.004 inch interference fit between static stop and fitting (16).


**b.** Apply a bead of sealing compound (C131) around exposed end of strap fitting (16) and mating surface of yoke (28). Ensure that strap fitting is fully seated when applying sealing compound. Do not permit sealing compound to contact radius ring or strap.

- **c.** Position stop (5) on flat horizontal surface of fitting (16) and install static stop (1) with bolts (2) and washers (3).
- **d.** The stop adjustment must be accomplished when hub is installed on helicopter.

### **CAUTION**

Ensure static stop (1, figure 5-12) has been properly shimmed for tight fit with 0.002 to 0.004 inch interference fit, and is properly seated in place on fitting (16) prior to torqueing of bolts (2). Refer to paragraph 5-66.

- e. Align radius of static stop with center of mast.
- **f.** Torque bolts (2) to **175 INCH-POUNDS** and lockwire (C96) together.
- **g.** Repeat installation procedures for opposite static stop.
- 5-67. GRIP RESERVOIRS AND SIGHT GLASS OIL LUBRICATED MAIN ROTOR HUB.
- **5-68.** Description Grip Reservoir and Sight Glass Oil Lubricated Main Rotor Hub. Blade grips on the hub are lubricated with oil from grip reservoirs. 011 level can be checked through transparent covers and sight glasses.
- **5-69.** Inspection Grip Reservoirs and Sight Glass Oil Lubricated Main Rotor Hub. Inspect sight glass for oil contamination. When water is present, the oil has a dirty milky appearance.
- 5-70. Removal Grip Reservoirs and Sight Glass Oil Lubricated Main Rotor Hub.
- **a.** Place wiping cloths under reservoir (13, figure 5-1) to catch excess fluid.
- **b.** Remove nut(9), spring washer (10), washer(11), and packing (12).
- **c.** Remove bolt (18) and packing (17). Remove reservoir (13), sight glass (16), and packings (15).
- 5-71. Inspection Grip Reservoirs and Sight Glass Oil Lubricated Main Rotor Hub.
- **a.** Inspect sight glasses for nicks, cracks, and scratches. Replace defective parts.
- **b.** Inspect for leaks between reservoir (13, figure 5-1) and pitch horn.
- **c.** Inspect seals for cuts and serviceability. Replace defective parts.



	DAMAGE AREA	
TYPE OF DAMAGE	MAXIMUM DEPTH	
NICKS, SCRATCHES, SHARP DENTS	0.020	
CORROSION	0.010	
MAXIMUM AREA PER FULL DEPTH REPAIR	Not Critical	
NUMBER OF REPAIRS	Not Critical	
EDGE CHAMFER	0.060	

### NOTES:

- Coat repaired area with chemical conversion coating (C38) then apply epoxy polyamide primer (C116).
- 2. No cracks permitted.
- 3. All dimensions are in inches.

206011-275

Figure 5-25. Inspection and Repair Limits — Main Rotor Hub Static Stop

**5-72.** Repair — Grip Reservoirs and Sight Glass — Oil Lubricated Main Rotor Hub. Repair is limited to replacement of unserviceable seals and sight glass with serviceable like items.

## 5-73. Installation — Grip Reservoirs and Sight Glass — Oil Lubricated Main Rotor Hub.

- **a.** Position packing (15, figure 5-1) on reservoir (13) and packing (15) on sight glass (16); position reservoir and sight glass on pitch horn,
- **b.** Install packing (17) on bolt (18) and insert bolt through sight glass and reservoir.
- **c.** Install packing (12), washer (11), spring washer (10), and nut (9). Tighten nut until nut makes contact with spring washer, continue tightening nut one-half turn to slightly compress spring washer.
- **d.** Fill reservoir at filler plug (14) with lubricating oil (C102). Work out air and fill one-half full level on sight glass (16). Install filler plug.

## 5-74. PILLOW BLOCK - MAIN ROTOR YOKE.

**5-75.** Description — Pillow Block — Main Rotor Yoke. Oil lubricated hubs have pillow blocks with sight glass which provide for observing oil level in the pillow block reservoir. A filler plug is provided for filling the reservoir with oil. Grease lubricated hubs have a grease fitting which provides for servicing of the hub. The pillow block includes two bearings that are utilized with the flapping axis trunnion.

## 5-76. Cleaning — Pillow Blocks — Main Rotor Yoke.

- **a.** Clean exposed portion of pillow block (6, figure 5-4) and associated parts with naphtha (C22).
- **b.** A soft fiber bristle brush (C31) may be used to scrub parts for cleaning.
- 5-77. Inspection Pillow Block Main Rotor Yoke.

WARNING

Inspect bolt (22, figure 5-4) P/N MS 21250-04018 for correct washer under

bolt head. If washer (21) P/NMS9482-10 is not installed condemn and replace bolt (22), nut (25) and washer with correct configuration. Refer to paragraph 5-84.

- **a.** Inspect exposed portions of pillow block (6, figure 5-4) in accordance with figure 5-28,
- **b.** Pitting caused by rust or corrosion on pillow block bolts is not acceptable. To replace, refer to paragraph 5-78.
- **c.** Pitting caused by corrosion on pillow block sight glass assembly is not acceptable. To replace, refer to paragraph 5-78.
- **d.** Inspect for oil discoloration forming a distinct line that may be mistaken for oil level, or oil level cannot easily be verified. If oil discoloration line has formed, replace sight glass and packing. Refer to paragraph 5-78.
- **e.** Inspect sight glass for nicks, scratches, and crazing. To replace, refer to paragraph 5-78.
- **f.** Inspect for leaks between sight glass and pillow block. If leaking, replace seal. Refer to paragraph 5-82.
- **g.** Inspect for leaks between pillow block and trunnion. If leaking, replace seal. Refer to paragraph 5-79
- **h.** Inspect pillow block for cracks. If cracked, replace pillow block. Refer to paragraph 5-79,
- i. If hub is grease lubricated, inspect grease fitting for clogs, cracks, corrosion, or damage. Replace defective parts. Refer to paragraph 5-84,
- j. Inspect pillow block retention bolts (1 and 22) and nuts (5 and 25) for slippage. If slippage marks indicate that bolt or nut have moved condemn, replace bolt (1 or 22) and nut (5 or 25). Refer to paragraph 5-84,

### 5-78. Repair — Pillow Block — Main Rotor Yoke.

**a.** Repair exposed portions of pillow block (6, figure 5-4) in accordance with figure 5-28.

## WARNING

## Installation torque of pillow block nuts depends on configuration.

- **b.** Replace pillow block nuts (1 or 22) one at a time to avoid disturbing trunnion centering. Refer to paragraph 5-84 for specific requirements.
- c. To replace pillow block sight glass, cut lockwire. Remove and replace sight glass(18, figure 5-4) and packing (19). Coat new packing (19) with oil (C102), install packing on sight glass, install sight glass on pillow block. Remove filler plug (13), discard packing (14) and service pillow block reservoir with oil (C102), to indicate one-half full on sight glass indicator. Install new packing (14) on filler plug (13). Coat packing (14) with oil (C102) and install on pillow block. Torque filler plug (13) 25 TO 35 INCH-POUNDS. Torque sight glass (18) 30 TO 40 INCH-POUNDS and lockwire (C96) from filler plug to sight glass.

# 5-79. Removal — Pillow Block — Main Rotor Yoke (AVIM).

- **a.** Remove main rotor hub assembly. Refer to paragraph 5-8.
- **b.** Remove main rotor blades. Refer to paragraph 5-102.

## CAUTION

Bearing (11, figure 5-4) and bearing inner race (15) become separated when pillow block (6) is removed from yoke. Ensure bearing (11) and bearing inner race (15) are mated to the same side, when pillow block (6) is removed and installed.

- **c.** Remove nuts (5 or 25), washers (21 or 4), bolts (1 or 22), bushings (3 or 23), and washers (2 or 21). Cut lockwire, remove filler plug (13) and discard packing (14) on oil lubricated hub. Slide pillow block off trunnion and repeat process to remove pillow block from opposite side.
- **d.** To avoid contamination of bearing (11) in pillow blocks (6), cover with barrier paper (C26) or equivalent.

## 5-80. Disassembly – Pillow Block — Main Rotor Yoke (AVIM).

**a.** Place pillow block (6) on a clean flat surface. Install bearing puller (T16) in pillow block to remove seal (12), refer to figure 5-26, for proper positioning of seal puller. Remove and discard seal (12, figure 5-4).

#### NOTE

## If replacement of bearing (11) is not required, omit step b.

- **b.** Remove pillow block bearing (11) as follows:
- (1) Place pillow blocks (6) on a clean, flat surface with inboard face down. Apply heat lamp to outboard side of pillow block. Heat pillow block at a distance of **8 to 10** inches from lamp. Heat pillow block for a duration of **10 to 15** minutes using cotton gloves (C76) to prevent injury to hands; remove pillow block from heat lamp areas. Remove bearing(11) by tapping outboard side of pillow block with a rawhide mallet or equivalent, while holding pillow block suspended above work table.
- (2) If pillow block bearing (11) was not completely removed using the above process, the bearing may be removed using puller (T16) as illustrated in figure 5-26.
- **c.** Remove sight glass (18, figure 5-4) from pillow block. Remove and discard packing (19).
- **d.** On grease lubricated hub remove grease fitting (20) only if replacement is required.

## 5-81. Cleaning — Pillow Block — Main Rotor Yoke (AVIM).

- **a.** Clean pillow block (6, figure 5-4) and bearing (11) with naphtha (C22).
- **b.** A soft fiber bristle brush (C31) may be used to scrub parts for cleaning.

## 5-82. Inspection — Pillow Block — Main Rotor Yoke (AVIM).

- **a.** Inspect pillow block (6) in accordance with figure 5-28.
- **b.** Pitting caused by rust or corrosion on pillow block bolts (1, figure 5-4) is not acceptable.




Figure 5-26. Removal — pillow Block Seal

- **c.** Pitting caused by corrosion on pillow block sight glass assembly is not acceptable.
- **d.** Deterioration, breaks, wear-through, or cuts are not acceptable on pillow block teflon pads (16).
- **e.** Inspect for oil discoloration forming a distinct line that may be mistaken for oil level, or oil level cannot be easily verified. If oil discoloration line has formed, replace sight glass and packing.
- **f.** Inspect sight glass for nicks, scratches, and crazing.
- **g.** Inspect for leaks between sight glass and pillow block. If leaking, replace packing.
- **h.** Inspect for leaks between pillow block and trunnion. If leaking, replace seal.
- i. Inspect pillow block for cracks. If cracked, replace pillow block.
- **j.** If hub is grease lubricated, inspect grease fitting for clogs, cracks, corrosion, or damage. Replace defective parts. Refer to paragraph 5-84.
- **k.** If used, inspect straight bushing (3) for worn or damaged plating and corrosion. Wear, damage, or corrosion which exceeds the plating thickness is not acceptable.
- I. If used, inspect special washers (2) and bolts (1) for evidence of wear or interference between the washer I.D. and the radius under the bolt head. This condition is unacceptable and the bolts must be replaced. (This inspection is not required when flanged bushing (23) is used.) Replace washer if coating on face (next to pillow block) is visibly worn or damaged.
- **m.** Inspect bushing (23) for worn or damaged epoxy coating on surfaces which contact the pillow block. Damage or wear to an extent which would permit metal-to-metal contact with the pillow block or prevent proper seating of the pillow block bolts is not acceptable.

# 5-83. Repair — Pillow Block — Main Rotor Yoke (AVIM).

- **a.** Replace defective sight glass or grease fitting per paragraph 5-84.
- **b.** Replace defective teflon pads (16) per paragraph 5-84.
- c. Repair damage per figure 5-28. Use sandpaper (C126) then polish with crocus cloth (C55). Apply chemical conversion coating (C38) then apply epoxy primer (C116) to repaired areas.
- **d.** Pillow block wear discs may be installed as follows:

### NOTE

Pillow block 206-011-102-117 is the same as 206-011-102-11 but has an integral stainless steel wear disc. Local incorporation of the wear disc is acceptable to repair worn pillow blocks or to improve serviceability on any rotor head.

- (1) Remove, disassemble, clean, and inspect pillow block per para. 5-79 thru 5-82 (seal and bearing must be removed).
- (2) Determine that depth of damage in thrust plug contact area does not exceed **0.030** inch. Pillow block must be scrapped if damage exceeds **0.030** inch after cleanup. Treat rework damage area with alodine.
- (3) Locally fabricate wear disc 206-011-156-101 from 0.032 inch thick 1/4 hard 301 CRES (MIL-S-5059) per figure 5-4, sheet 4, detail F. Exact thickness (0.025 to 0.035 inch acceptable) and material (any steel acceptable) are not critical within reason. Wear disc must be flat within 0.001 inch, free from burrs and sharp edges, and smooth (32 micro-inch) on the side which contacts the thrust plug.
- (4) Degrease the pillow block and wear disc to assure a good bond. Bond the disc in the pillow block thrust plug contact area using adhesive (C11). Do not build up excessive bond thickness and center the plate within 0.06 inch. Apply pressure with a C-clamp to assure a good bond. Remove adhesive squeeze out with a clean cloth. Allow adhesive to cure.

## 5-84. Assembly — Pillow Block — Main Rotor Yoke (AVIM).

- **a.** Ensure that center portion of hollow setscrews (8, figure 5-4) is sealed with sealing compound (C131).
- **b.** Coat new packing (10) with lubricating oil (C102) and install on thrust washer (9) in spindle outboard end of trurnnion (7).

## CAUTION


Bearing (11, figure 5-4) and bearing inner race (15) become separated when pillow block (6) is removed from yoke. Ensure bearing (11) and bearing inner race (15) are mated to the same side, when pillow block (6) is removed and installed.

**c.** Install bearing (11) in pillow block as follows:

### NOTE

If replacement of bearing (11) is not required, omit step c.

- **d.** The use of a local manufactured work aid is recomended for installation of bearing inner race, see figure 5-27 for details. Place pillow block (6, figure 5-4) on a clean, flat surface with inboard face up. Apply heat lamp, at a distance of **8 to 10** inches from pillow block. Heat pillow block for a duration of **10 to 15** minutes using cotton gloves (C76) to prevent injury to hands; remove pillow block from heat lamp area. Place a wood block on hydraulic press base, and the pillow block on top of wood block. Place work aid (figure 5-27) in bearing and press bearing (11, figure 5-4) into pillow block (6). Ensure that bearing (11) is seated to bottom of pillow block (6) bearing cavity.
  - e. Install seal (12) in pillow block as follows:
- (1) Apply a thin film of sealing compound (C131) to O.D. of seal (12) and I.D. of pillow block seal recess.



NOTES: Make work-aid from aluminum bar stock.

All dimensions are in inches.

206011-277

Figure 5-27. Work-Aid for Installing Bearing On Main Rotor Yoke Pillow Block


- (2) On oil lubricated hub press seal (12) in pillow block with seal part number visible and backup spring toward bearing.
- (3) On grease lubricated hub, press seal (12) in pillow block with seal lip visible (backup spring exposed) and seal part number towards bearing.
- (4) Ensure seal is seated in recess and wipe off excess sealant.
- (5) Apply a light coat of lubricant to bearing and lip of seal, Use oil (C102) for oil lubricated hub or grease (C77) for grease lubricated hub.
- f. Prior to installing teflon pad (16), abrade pillow block pad surface with sandpaper (C126). Remove sanding residue with MEK (C107). Apply adhesive epoxy (C12) to faying surface of pillow block and teflon pad. Position pad on pillow block, using care to


ensure alignment. Remove excessive adhesive squeeze-out with cheesecloth (C37) moistened with MEK. Apply firm pressure to pad and cure adhesive for 24 hours at 70° to 95°F (21° to 35°C). An alternate cure method is to apply firm pressure to pad and heat pad area. The heat shall be from 145° to 155°F (63° to 68°C) for 30 minutes.

## CAUTION

Do not apply corrosion preventive compound to wear pads (16) or the mating surface of the yoke. Clean these surfaces prior to installation.

**g.** Prior to installing pillow block (6) to main rotor yoke, apply corrosion preventive compound (C50) on all faying surfaces of yoke and pillow block (6). Coat





## GREASE LUBRICATED

### **OIL LUBRICATED**

\*\*\*\*\*\*\*\*\*\*

	AREA A	AREA B	
TYPE OF DAMAGE	MAXIMUM DEPTH		
NICKS, SCRATCHES, SHARP DENTS	0.010	0.030	
CORROSION	0.005	0.015	

### NOTES:

- 1. Each lug is restricted to one repair area. Minimum radius of repair is 0.500 inch.
- The cylindrical portion of area A may have two repair areas. Each repair should not exceed 0.250 inch square and must have a minimum radius of repair of 0.250 inch.
- 3. Area B may have one repair area. Minimum radius of repair os 0.350 inch.
- 4. Coat repair areas with chemical conversion coating (C38).
- 5. No cracks permitted.
- 6. No repair authorized in area under bolt head,
- 7. All dimensions are in inches.

206011-278

Figure 5-28. Inspection and Repair Limits — Pillow Block — Main Reservoir

trunnion spindle bearing inner race (15) with a light coat of oil (C102) for oil lubricated hub or grease (C77) for grease lubricated hub. Place trunnion (7) in main rotor yoke between pillow block openings and carefully slide pillow blocks (6) into yoke openings and on each end of trunnion (7).

## CAUTION

Bearing (11) and bearing inner race (15) become separated when pillow block (6) is removed from yoke. Ensure bearing (11) and bearing inner race (15) are mated to the same side, when pillow block (6) is removed and installed.

### **NOTE**

After pillow blocks (6) are installed a bead of adhesive (C17) may be applied to pillow block at main rotor yoke mating surface to prevent corrosion.

**h.** Install pillow block retention hardware (High strength) as follows:

#### **NOTE**

Flanged bushing (23) P/N 206-011-128-1 replaces straight bushing (3) P/N 206-010-170-1 and washer (2) P/N 206-010-171-1. Bushing (23) may be used with standard (1, 4, and 5) hardware. It is recommended that bushing (23) and high strength (21, 22 and 25) hardware be used for reassembly.

(1) Install bushing (23) in pillow block (6).

## WARNING

High strength bolt (22) P/N MS21250-04018 will be used only with countersunk washer (21) P/N MS9482-10 and high strength nut (25) P/N EB048. The same type hardware should be used at all four (4) locations on the main rotor hub. Before installing nuts make certain bolt and nut threads are clean, dry, free of burrs, lubricants, corrosion preventive compound, or paint.

- (2) Install countersunk washer (21) on bolt (22). The countersunk washer (21) will always be used under the head of bolt (22).
- (3) Install bolt (22) with washer (21) through bushing (23) and through pillow block (6) and yoke. Install washer (21) and nut (25) on bolt (22). Repeat procedure for other locations.

## CAUTION

Check for proper grip length of bolt (22). Sufficient thread must be available to allow compression (0.020 inch maximum) of wear pad (16). If required, add one washer (4) P/N AN690-416 or AN690-416L under nut (25).

- **(4)** Torque nut (25) P/NEBO48 on bolt (22) P/N MS21250-04018 (12 point head) to 140 TO 150 INCH-POUNDS.
- (5) Apply slippage marks using torque seal lacquer compound (C47) or other suitable paint across bolt head and washer to pillow block and across bolt threads, nut, and washer to yoke.
- i. Install pillow block retention hardware (standard) as follows:

### **NOTE**

Flanged bushing (23, figure 5-4) P/N 206-011-128-1 replaces straight bushing (3) P/N 206-010-170-1 and washer (2) P/N 206-010-071-1. Bushing (23) may be used with standard (1, 4, and 5) hardware or high strength (21, 22 and 25) hardware. It is recommended that bushing (23) and high strength (21, 22 and 25) hardware be used for reassembly.

- (1) Install straight bushing (3) or flanged bushing (23) in pillow block (6).
  - (2) Install washer (2) if used, on bolt (1)

### NOTE

Washer (2, figure 5-4) is used only with straight bushing (3) and, when used, is to be installed with plastic face next to the pillow block.

- (3) Install bolt (1) with washer (2), if used, through bushing (3 or 23) and through pillow block (6) and yoke. Install washer (4) and nut (5) on bolt (1). Repeat for other locations.
- **(4)** Torque nut (5) P/N MS21042L4 on bolt (1) P/N NAS1304-13 to **55 TO 65 INCH-POUNDS.**
- (5) Apply slippage marks using torque seal, lacquer compound (C47), or other suitable paint across bolt head and washer to pillow block and across bolt threads, nut, and washer to yoke.
- j. Oil lubricated hub. Install new packing (19) to sight glass (18) coat packing with oil (C102) and install on pillow block. Torque sight glass assembly 30 TO 40 INCH-POUNDS.
- **k.** Grease lubricated hub. Install grease fitting (20) on pillow block. Apply unreduced primer (C116) to threads of grease fitting prior to installation.
- I. Oil lubricated hub. Service pillow block reservoir with oil (C102), work out air by tipping rotor hub back and forth. Fill reservoir until sight glass indicates one-half full.
- **m.** Oil lubricated hub. Install new packing (14) to filler plug (13), coat packing with oil (C102) and install on pillow block. Torque filler plug (13) **25 TO 35 INCH-POUNDS** and lockwire (C96) from filler plug to sight glass.
- **n.** Grease lubricated hub. Lubricate pillow blocks with grease (C77) until grease is purged past seals.
- **o.** Adjust trunnion centering. See paragraph 5-42.

### 5-85. MAIN ROTOR BLADE BOLT.


- **5-86. Description Main Rotor Blade Bolt.** The blade bolt (figure 5-29) secures the main rotor blades to the grip assemblies.
- **5-87.** Removal Main Rotor Blade Bolt. Remove blade bolt in accordance with paragraph 5-100.

**5-88.** Inspection — Main Rotor Blade Bolt. Inspect the blade bolt in accordance with figure 5-29.

#### NOTE


If the blade bolt exceeds repair limits, or is otherwise damaged, it shall be replaced with a serviceable item.

5-89. Repair — Main Rotor Blade Bolt.



Bolt repairs are not authorized if main rotor hub from which it was removed has been subjected to sudden or abrupt stoppage.

- a. If a new bolt cannot be obtained, a replacement bolt from another hub assemby can be used after removing the dry film lubricant with MEK (C107) and performing the following inspection:
- (1) Inspect bolt using magnetic particle method. Refer to TM 43-0103 (AVIM).
- **(2)** Roll bolt on a surface plate to check for bending. The bolt shank should not be bent more than 0.0015 inch.
- **b.** Remove scratches, scars, and nicks by polishing with crocus cloth (C55). Refer to figure 5-29 for additional repair procedures and limits.
- **c.** Remove nicks and dents in bolt threads. For bolt thread measurement and repair, refer to TM 55-1500-204-25/1.
- **d.** Install new blade bolt cap (18, figure 5-11) and packing (19).
- **e.** Apply solid film lubricant (C105) to the bolt. Allow the lubricant to dry.
  - f. Balance main rotor blade.
- **5-90.** Installation Main Rotor Blade Bolt. Refer to paragraph 5-106 for blade bolt installation.



**TYPE OF DAMAGE** 

NICKS, SCRATCHES, SHARP DENTS

0.010

AREA A

See Note 2

**MAXIMUM DEPTH** 

CORROSION 0.005

NOTES:

- 1. Area A may have one repair. Minimum radius of repair is 0.250 inch.
- Scratches and scrapes on area B must not exceed that removable by polishing with crocus cloth (C55). After cleanup, recoat bolt with solid film lubricant (C105).
- Repair of nicks and dents on the bolt threads must not exceed 1/3 of the thread depth. Length of the repair should not exceed 0.250 inch. The threads may have only two repair areas.
- 4. No cracks permitted.
- 5. Bolt will be inspected internally for pitting and plugged drain hole.
- 6. All dimensions are in inches.

206011-279

Figure 5-29. Inspection and Repair Limits — Blade Bolt — Main Rotor

## 5-91. MAIN ROTOR PITCH HORN TRUNNION.

- **5-92. Description Main Rotor Pitch Horn Trunnion.** The pitch horn trunnion provides for changes in pitch to the main rotor blades.
- 5-93. Inspection Main Rotor Pitch Horn Trunnion.
- **a.** Check axial play between rod end bearing and barrel of trunnion (33, figure 5-12). Axial play is not to exceed **0.010** inch. Check general condition of trunnion.
  - **b.** Inspect barrel of trunnion assembly for damage.
- 5-94. Removal Main Rotor Pitch Horn Trunnion.

## **WARNING**

Do not allow main rotor blades to rotate on pitch change axis. If blade is inadvertently allowed to rotate on this pitch change axis beyond 90 degrees, the main rotor grip retention strap must be replaced.

- **a.** Index pitch link assemblies (1, figure 5-6) for reinstallation in same position. Remove bolt (5) and disconnect pitch link. Secure main rotor blade pitch horns to yoke with lockwire (C97) to prevent grips from turning on yoke.
- **b.** Remove bolts (32, figure 5-12) securing trunnion assembly (33) to pitch horn.

#### **CAUTION**

Permanent deformation of pitch horn is prohibited. The temporary change in trunnion gap as a result of spreading must not exceed 0.034 inch.

#### NOTE

The splitline gap in the trunnion housing, with no trunnion or work aid in place, should not exceed 0.120 inch.

c. Remove trunnion assembly from pitch horn using a work aid to spread trunnion housing.

#### NOTE

Fabrication of work aid is recommended to allow removal and installation of trunnion with less possibility of damage to pitch horn. (See figure 5-30.) Insert tangs of tool into slot and tighten screw until trunnion can just be pulled out. Immediately release screw tension and remove tool.

Roller bearings in trunnion barrels may have a feel of ratcheting and drag in rotation, due to angular mounting.

- 5-95. Installation Main Rotor Pitch Horn Trunnion.
- **a.** Position trunnion in pitch horn using work aid (figure 5-30) and align slots in trunnion with holes in pitch horn. Install bolts (32, figure 5-12), washers (31), and nuts (30). Torque nuts to 50 TO 70 INCH-POUNDS.
  - **b.** Lubricate trunnion in accordance with figure 1-5.
- c. Position clevis end of pitch link assembly (1, figure 5-6) on trunnion. Install washer (4) under head of bolt (5) and install bolt through pitch link clevis and trunnion bearing with head of bolt inboard. Install one of two washers (4), as required, under nut (3) to locate nut for installation of cotter pin (2).




Figure 5-30. Work Aid — Removal and Installation of Pitch Horn Trunnion

## **SECTION II. MAIN ROTOR BLADES**

### 5-96. MAIN ROTOR BLADES.

**5-97. Description** — **Main Rotor Blades.** Main rotor blades are of all metal construction with an aluminum alloy honeycomb core, aluminum skins and nose block. All structural components are joined by metal-to-metal bonding. The blades are set in hub grips at a preconing angle and secured by a single retaining bolt in each grip. A trim tab is provided on the trailing edge for tracking adjustments.

## 5-98. Cleaning — Main Rotor Blades.

- **a.** To maintain a protective coating as required, clean blades with a dishwashing compound (C61).
- **b.** Thoroughly rinse with water and dry with clean cloths.

## 5-99. Inspection — Acceptance/Rejection Criteria — Main Rotor Blade.


- **a.** Inspect main rotor blades for scratches, nicks, dents, erosion of leading edge, and evidence of bond failures. In the event blades are damaged, refer to AVIM.
- **b.** Inspect around screw heads in area of inertia weights for cracks in paint and evidence of corrosion which is noticeable as blisters and/or raised areas in the paint.
- **c.** Inspect for cracks in the tip cap area in the bond material at Station 208.07 (figure 5-31). If the paint is cracked, remove paint with a clean cloth dampened with MEK (C107) and fine crocus cloth (C55). Wash area thoroughly and inspect metal where paint was cracked. If tip cap is cracked, the blade assembly is unserviceable and will be forwarded for depot level maintenance.

#### **CAUTION**


Dye penetrant solutions and MEK will de-

teriorate bond material and corrode metal. Do not squeeze, move, or distort tip cap in any way for purpose of inspection.

- **d.** If exposed bond material is cracked, check for voids by using a coin and tapping lightly along blade within 1/4-inch from edge (figure 5-31) and listen for a change in tone resulting from the tapping sound. A good bond will sound solid and tight, a void will sound hollow and empty. If a void does exist, the blade assembly is unserviceable and will be forwarded to depot level maintenance.
- **e.** Edge voids in the area of station 208 (figure 5-31) not in excess of **0.120** inch are acceptable. Edge voids in the bond line on the tapered section of the tip cap not in excess of **0.080** inch are acceptable. Repair in accordance with repair procedures. Those blades which exceed **0.120** inch or **0.080** inch should be returned for depot maintenance. If cracks or corrosion are evident in the area of the inertia or tip weight screws, the blade assembly is unserviceable and will be forwarded for depot level maintenance.
- **f.** Inspect for nicks, notches, scratches, and dents as follows:
- (1) Nicks and scratches anywhere on the surface of skins or trailing edge strip that are not in excess of 0.008 inch in depth after polishing are acceptable.
- (2) Nicks and scratches in the skins in excess of 0.008 inch in depth must be patched.
- (3) Nicks or scratches in the doublers or grip plates that are not in excess of 0.012 inch in depth are acceptable if polished out. No nicks or scratches are allowed to either grip pads or wear pads. Normal wear is acceptable on wear pads.
- (4) Nicks and notches in the extreme trailing edge of the blade that are 0.120 inch depth or less must be polished out over a distance of at least two



## TOP VIEW OF ROTOR BLADE



**CROSS SECTION OF BOND AREA** 

NOTE: All dimensions are in inches.

206011-281

Figure 5-31. Main Rotor Blade — Bond Area Inspection

inches each side of the nick or notch. In the area outboard of the trim tab; a depth of **0.250** inch maybe polished out over a distance of **4.000** inches on either side.

(5) In the outboard three feet of the blade, any dent in the skin that does not tear the skin, produce a void, or affect flight characteristics, is acceptable.

### NOTE

The sound produced when tapping the tip cap area outboard of station 208.9 is hollow due to styrofoam filler material used in tip cap and does not indicate void.

- (6) Dents in the skin inboard of a station three feet from the tip of the blade that are not in excess of **0.060** inch depth are acceptable.
- (7) If a nick or scratch exists in a sharp dent in the skin, the total depth of both must not exceed 0.060 inch. If the nick or scratch cannot be polished out it must be cut out and patched.
- (8) Small nonsharp dents in tip assembly (6, figure 5-32) that do not affect flight characteristics are permissible. If leading edge of swept tip is worn through from abrasion, tip assembly must be replaced.
- (9) Polish out acceptable nicks and scratches spanwise only, using 180 grit sandpaper (C124) or finer. Polish to a surface finish of 63 rms or better removing only enough material to remove nick or scratch. Aluminum wool (C23) may be used on aluminum surfaces.
  - g. Inspect for edge voids as follows:

### NOTE

A void is defined as an unbended area. Many subdefinitions are often given such as lack of adhesive, gas pocket, misfit, etc. This manual makes no distinction among these but groups them in the one general term "void".

(1) Viewing the blade at the butt end, no voids are acceptable within **0.500** inch of the leading edge or trailing edge of any doubler. Other voids not longer than **1.000** inch nor deeper than **0.350** inch are acceptable provided they are sealed.

#### **NOTE**

Balance weight and support (10, figure 5-32) are for balancing blade only after depot repairs have been made to blades.

- (2) No voids are allowed under the balance weight support, grip pad, or wear pads. Bond separation of the wear pads and grip pads can be rebonded in accordance with paragraph 5-104.
- (3) Edge voids under the spar closure not deeper than 0.150 inch nor longer than 0.750 inch are acceptable provided they are sealed.
- (4) Edge voids 0.060 inch maximum depth of one bond line and not in excess of 10 percent of the total length of that bond line are acceptable. Single edge voids of 0.600 inch maximum depth and 2.000 inches maximum length are acceptable on doublers. Edge voids are not acceptable in the outboard five inches of each finger of the doubler.
- (5) Voids between the skin and core in a 3.000 inch wide area running adjacent to the trailing edge extrusion, not wider than 0.500 inch nor longer than 1.000 inch, with a minimum width of 1.000 inch of good bond between them are acceptable. Total area of all voids shall not exceed 5.00 square inches.
- (6) Edge voids between the edge of the skin and the trailing edge extrusion or spar that are less than 0.060 inch wide by any length or less than 0.120 inch width by 7.000 inches long are acceptable.
- (7) Voids other than edge voids between the skin and the trailing edge extrusion which do not exceed 0.180 inch in width by 10.000 inches long are acceptable.
- (8) A void between the skin and the trailing edge closure (at the butt end) not deeper than **0.120** inch and longer than **1.000** inch is acceptable.
- (9) Voids between the skins and trailing edge extrusion not in excess of **0.180** inch in width by **10.000** inches long are acceptable.
- (10) Voids between the skin and core 1.000 inch maximum width (chordwise) by 25.000 inches long are acceptable. Voids within 1.000 inch of each other are considered to be one void.




Figure 5-32. Inspection — Main Rotor Blade

- (11) Voids between the skin and spar not wider than 0.250 inch are acceptable. Voids not longer than 0.380 inch by 2.000 inches are acceptable provided spacing between void centers exceeds 6.000 inches. Edge voids a maximum of 0.080 inch are acceptable provided they are sealed.
- (12) Edge voids between the edge of the skin and the trailing edge extrusion that are less than 0.080 inch width by any length or 0.190 inch width by 10.000 inches long are acceptable provided they are sealed.

h. Inspect for corrosion in area of screws securing inertia weight as follows: (Refer to figure 5-33.)

#### **NOTE**

Do not attempt to tighten or remove screws as they were bonded in place at original installation. If screws or weights are loose, replace blade.

- (1) Inspect blades with paint and with filler covering screws, and adjacent areas for corrosion which will be noticeable as blisters or raised areas, and for cracks in paint adjacent to screw heads.
- (2) If corrosion or cracks are evident, strip finish from affected areas as follows:
- (a) Using masking tape (C143) mask off area to be stripped.
- **(b)** Using sandpaper (C124 or C125), remove the finish by sanding in a spanwise direction only.
- **(c)** Remove the masking and feather all the paint edges by sanding.
- **(d)** If no corrosion or cracks are found, clean, and refinish stripped area.
- i. Inspect blades for paint and filler worn or flaked from screw heads and adjacent areas as follows:
- (1) Inspect for evidence of corrosion or cracks in the area adjacent to screw heads. If questionable areas are found use dye penetrant. If corrosion exists, remove blade from service. Clean corroded area by wiping with a clean cloth dampened with MEK (C107). Do not saturate area. Dry with clean cloth and coat with primer (C118). Return blade to depot for evaluation and repair.

- (2) Screw heads may exhibit a degree of rust; this condition does not require rework.
- (3) If no corrosion or cracks are found, clean and refinish bare area.
- j. Inspect for leading edge erosion and corrosion as follows:
  - (1) Clean the blade.
- (2) Inspect the main rotor blade leading edge for evidence of erosion. If present, it will be most pronounced at the blade tip and extend inboard a distance of three or four feet from the tip. The visible signs will be a wearing away of the blade paint finish revealing the blade spar. When erosion is found the area should be thoroughly inspected for signs of corrosion (exfoliation). This will be evidenced by pitting of the spar or flaking and/or scaling of the spar material.
- (3) Where erosion along the leading edge has resulted in the start of corrosion, the blades must be removed from the helicopter and repaired.
- **k.** Inspect grip pads for security, damage, and corrosion.

### **NOTE**

Corrosion pitting is not permitted in grip pad area, surface corrosion can be cleaned up with scouring pad (C109). Area-under-grip-pads is a controlled dimension, and metal removal by sanding is not permitted.

- I. Inspect paint condition; condition of paint on spar leading edge is unimportant as abrasion will remove paint in a few hours of flight.
- m. Inspect the retention bolt hole bushing for corrosion. If corrosion is present, remove with scouring pad (C109). Inside diameter of bushing shall not exceed 1.525 inches after cleanup. Depot replacement of bushing is required if this diameter is exceeded.
- (1) It is not necessary to remove all pits during cleanup, providing all corrosion and corrosion products are removed.
- (2) Pitting 0.005 inch in depth is not permitted on any area of bushing after cleanup.




Figure 5-33. Repair Dimensions — Main Rotor Blade Corrosion

- (3) For the critical area of blade bushing, refer to figure 5-34, detail A.
- (4) Pitting that exceeds 20% of the critical area is not permitted. Any pit that exceeds 0.100 inch diameter in critical area is not permitted.
- (5) After any repair to blade bushing, clean bolt hole with naphtha (C22) and apply corrosion preventive compound (C50) on all areas of blade bushing.
- n. Inspect balance weight and support for corrosion. Pits not exceeding 0.040 inches are acceptable. Corrosion should be removed using sandpaper (C124). Care should be taken not to damage the trailing edge of blade. Reworked area should be coated with epoxy polyamide primer (C116) and a top coat of acrylic lacquer (C89).
- Inspect for corrosion around and under wear pads, maximum pit corrosion depth in this area is
   0.010 inches.
- **p.** Inspect doublers for condition, corrosion, and separation/delamination.

## CAUTION

Do not use sharp pointed tool or feeler gage to pry between doublers to check for separation/delamination.

(1) Inspect the doublers on the blade, both top and bottom for condition.

#### NOTE

The outermost plate, or that furthest from the blade, is called the grip plate or doubler No. 1. The doubler closest to the blade skin is doubler No. 8.

(2) Around each edge of the doublers should be a layer of filler material. Check to assure the filler material is in place and in good condition. Loss of filler material, or a broken surface of filler material will eventually cause corrosion, and result in doubler separation.

- (3) If filler material is not in place perform the following:
- (a) Check the doubler and/or blade for condition.
- **(b)** If no corrosion is evident, clean up the area.
- (c) Treat unprotected metal areas, and then coat with epoxy polyamide primer (C116).
- (d) Retreat the doubler area, refer to paragraph 5-105.
  - (e) Refinish the blade surface.
- (4) Check the filler material around each of the eight doublers, both top and bottom of the blade. Check for signs of blisters or paint cracks which would be indicative of subsurface corrosion.
- (5) Inspect each doubler for signs of separation/delamination; no separation is permitted. Check each of the eight doublers, at both leading edge and trailing edge, especially doublers No. 7(24, figure 5-32) and No. 8, (3) at both the top and bottom of the blade.
- **(6)** If doubler separation is suspected, it maybe confirmed by ultrasonic inspection by a qualified inspector or tapping by an experienced inspector.
- (7) Treat the doubler area; refer to paragraph 5-105. Refinish the blade surface as required.
- **q.** Inspect blade drain hole located on lower outboard side, see Figure 5-33.1, to assure drain hole is free of obstructions.

## CAUTION

Use a non-metallic probe (tooth pick or plastic rod) to probe the drain hole.

5-100. Removal — Main Rotor Blades.

# CAUTION

Do not change the position of latch nut (9, figure 5-11) on the leading edge of the blade. The position of nuts will aid in realignment of the blades.

- a. Remove nut from blade bolt (1, figure 5-11). Loosen blade latch retaining nut (9) on trailing edge of blade and turn latch (11) to horizontal position.
- **b.** Use sufficient personnel to steady both blades and to hold blade being removed. Hold blade at preconed angle and in alignment while removing blade bolt (1) and while removing blade (6) from grip (3).




Figure 5-33.1. Main Rotor Blade Drain Hole




Figure 5-34. Repair Areas — Main Rotor Blades

### **NOTE**

Blade retention bolt (1) is easily removed when blade is aligned with grip and pressure is removed from bolt.

## **NOTE**

If original bolt is unserviceable, a new bolt (1, figure 5-11), may reinstalled. If a new bolt cannot be obtained, refer to paragraph 5-88 and 5-89 for alternate procedure.

**c.** Repeat procedure to remove opposite blade.

**d.** Prepare and package reparable blades that are to be shipped in wood or metal containers as follows:

#### **NOTE**

Do not return main rotor blades for overhaul or repair that are obviously scrap.

- (1) Tape all holes, bullet damage, tree damage, foreign object damage, etc., to protect the interior of the blade.
- (2) Clean the blade to ensure removal of soil, oil, or grease with dishwashing compound (C61).

## 5-101. Cleaning — Main Rotor Blades Prior to Refinishing.

- **a.** Protect all openings to prevent entry of refinishing materials.
  - b. Degrease with naphtha (C22).
- c. Using cloth pads soaked with MEK (C107), strip lacquer finish from blade. Do not remove primer except in areas where the primer is cracked or deteriorated or in areas where the metal appears to be corroded or otherwise damaged. Remove primer in these areas down to bare metal using cloth pad soaked with MEK. The process consits of wetting the surface with the MEK soaked pad and then scrubbing with a piece of cloth until surface has dried or paint has been removed. If the paint is not removed repeat application of MEK followed by cloth rub until paint is removed.
- **d.** After corrosion pits have been removed and reparable nicks and scratches have been polished out, remove surface oxidation from the entire blade by scrubbing thoroughly with cloth and a solution of neutral soap.
- **e.** Rinse thoroughly with clean running water until there is a continuous unbroken film of water on the surface.
- **f.** Apply phosphoric acid solution (C21) using a clean cloth or brush. Rub briskly for approximately **40 to 60** seconds.
- **g.** Rinse the blade thoroughly with clean running water end wipe dry with clean cloths.

#### NOTE

From completion of this step through final paint, surfaces of blades are not to be handled with bare hands.

**h.** On all bare aluminum, apply brush or spray (using brush solution) application of chemical conversion coating (C38). If not available, use application of 10% solution of chromic acid (C39). Thoroughly dry the cleaned surfaces.

### 5-102. Repair — Main Rotor Blades — Corrosion.

**a.** Using a micrometer caliper or equivalent, measure the chordline dimension (figure 5-33,

dimension A) of the blade immediately adjacent to the area(s) of corrosion that will be cleaned up. This measurement minus a maximum of **0.125** inch cleanup at the leading edge will determine that remaining leading edge thickness is within limits.

#### **EXAMPLE:**

Measured Dimension A
Maximum Cleanup Allowed

Minimum Dimension A
Measurement to the
Deepest Part of Cleaned
Up Area.

13.009 Inch
0.126 Inch

- **b.** Using sandpaper (C123) or equivalent, sand the corroded area(s) as follows:
  - (1) Hand-sand only.
- (2) Accomplish all sanding in spanwise direction.
- **(3)** Sand to the depth required to remove the effects of corrosion. (Create a smooth surface.)
- (4) Blend and fair sanded area into adjacent areas so as to maintain the shape of the air foil.

### NOTE

### Do not sand the skin to spar butt joint.

- **c.** Remove the sanding residue with naphtha (C22).
- **d.** Support the blade in a horizontal position, leading edge down. Swab the sanded area(s) with alcoholic phosphoric acid solution (C21). Allow the swabbed area(s) to remain dampened with the acid for a minimum of **10** minutes; then wipe the excess acid from the blade with dry cloths. Allow the blade to air dry for **20** minutes.

### **NOTE**

Do not allow the alcoholic phosphoric acid solution to touch painted surfaces. It is not mandatory but maybe advisable to wear rubber gloves when using alcoholic phosphoric acid (C21) solution.

- **e.** Apply a coat of wax to the blade. Use non-siliconized wax so as not to interfere with blade future repairs and/or subsequent refinishing.
- **f.** Record the location and depth of cleanup for future reference.
- 5-103. Repair Main Rotor Blades (Patching) (AVIM). Refer to figure 5-34.

#### NOTE

## All sanding of blades must be in spanwise direction.

- **a.** Defects in skins (holes, dents, nicks, etc.) that will fit within a **2.000** inch maximum diameter circle are reparable by patching if they are not nearer to the trailing edge strip, spar, or doublers than the minimum dimensions for a particular area as indicated in figure 5-34.
- **b.** Remove paint from repair area with MEK (C107). Dry with a clean cloth.
- **c.** Prepare a patch one inch larger than the hole to be covered (not to exceed three inches in diameter). Patch may be fabricated from bare aluminum. Deburr and blend out edges. Sand bond area of patch and blade with sandpaper (C126).
- **d.** Remove skin just inside circled area, disturbing honeycomb core as little as possible.
- **e.** Deburr edges of hole, making sure skin is free of scratches and nicks.
- **f.** Clean bond area on patch and blade with MEK (Cl 07). Dry with clean cloth.

#### NOTE

## Area must be clean, dry, and free of grease, oil, or wax.

- **g.** Apply adhesive (C19) to patch area around hole. Apply patch to blade under slight pressure to make sure any voids in bond are worked out. Blend out excessive adhesive.
- h. Patch may be held in place while curing with flat pressure plate and rubber bands. Allow to cure at 60°F (16°C) or above until firm (adhesive resists fingernail penetration.). Overnight curing is usually sufficient. To

accelerate curing time, apply heat to the area with a 200-watt lamp placed **12** inches from patch. Heat should be applied until adhesive is firm (will resist fingernail penetration).

- i. Refinish patch and adjacent area. Refer to paragraph 5-105.
- **j.** To prevent entry of moisture, seal all acceptable edge voids with fairing compound (C69).
- 5-104. Repair Main Rotor Blades Wear and Grip Pads.

#### NOTE

Replacement of old wear pad with a new wear pad must be accomplished by depot level maintenance.

- **a.** Rebond loose wear pads as follows:
- (1) Remove loose wear pad (12, figure 5-32) by gently tapping pad, using care not to damage the grip plates. If tapping fails to loosen pad, apply head and repeat tapping. Do not heat area above 200°F (93°C).
- (2) After pad has been removed, remove as much of the old adhesive as possible from blade by sanding with sandpaper (C124).
- (3) Wipe bonding surface on blade and wear pad with a clean cloth dampened with MEK (C107). Wipe dry using clean cloth.
- **(4)** Apply adhesive (C19) to mating surfaces of blade and wear pad.
- (5) Rebond wear pad to blade, using 5 to 30 psi pressure, apply with clamps at a temperature of 70° to 90°F (210 to 35°C) for 24 hours or 90 minutes at 140° to 160°F (60° to 71 °C).
- **(6)** Remove clamps and clean away excessive adhesive squeeze-out. Wipe area clean with a clean cloth dampened with MEK (C107).
  - **b.** Rebond loose grip pads as follows:

### NOTE

Replacement of old grip pad with new grip pad must be accomplished by depot level maintenance.

- (1) Remove old pad (1, figure 5-32) by prying loose, using an aluminum or hardwood wedge, being very careful not to damage blade.
- (2) Remove all old adhesive from blade by sanding with sandpaper (C124).
- (3) Wipe bonding surface of blade with clean cheescloth (C37), dampened with MEK (C107). Wipe dry with a dean cloth,
- (4) Coat adhesive surface of grip pad and mating surface of blade with adhesive (C19).
- (5) Place pad on blade around retention bolt hole. Position a bar over grip pad. Place damps over bar and tighten. Allow adhesive to cure for 24 hours at 70° to 95°F (21° to 35°C) or 60 to 70 minutes at 140° to 160°F (60° to 71°C).
- (6) Remove clamps and bar. Clean up excessive adhesive squeeze-out.
- (7) Wipe area dean with cheesecloth (C37) dampened with **MEK** (C107).

## 5-105. Refinishing — Main Rotor Blade (AVIM).

#### NOTE

The original blade finish included an abrasion and corrosion resistant coating (C6).

- **a.** Inspect the edges of the doublers and joint areas of the blade to determine if the coating has been damaged.
- **b.** If the coating is undamaged, refer to TM 55-1500-345-23.
- **(1)** Mixing ratio of ooating (C6) is by weight 100 parts of base to 140 parts of hardener.
  - (2) Thoroughly mix to a uniform gray color.
- (3) To thin, add 13% to 15% (by weight) of primer (C116) to mixed coating (C6).
- (4) Thin to a sprayable consistency by adding MEK (C107) in an amount not to exceed 50% by volume of mixed coating(C6). Add the MEK in small amounts, with constant stirring. The pot life of the thinned Coating is approximately three hours. (Refer to TM 55-1500-345-23 for application procedures.)

- (5) Thickness of finish after drying will be as follows:
- (a) Surface areas that receive three coats of coating, 6.500 to 12.000 mils.
- **(b)** Surface areas that receive one coat of coating, **3.500 to 6.000** mils.

5-106. Instailation - Main Rotor Blades.

**a.** Loosen blade latch retaining nut (9, figure 5-11) on trailing edge of hub and turn latch to horizontal position.

#### **CAUTION**

When installing blade in grip, use sufficient personnel to hold and align blade to prevent damage to blade.

#### NOTE

The manufacturers deta plate is bonded to the top of the main rotor blade. inatall the blade with the top up This places the leading edge on the same side of grip (3) as the pitch horn (7).

**b.** When installing blade in grip, use sufficient personnel to hold and align blade, Clean the blade retention bolt holes, and recesses in the inboard faces of the blade grip tang with naphtha (C22). Visually inspect the inner and outer surfaces of the grip tangs for cracks at the outboard side of the blade bolt holes at the interface of the inside hole diameter and adjacent radius. Apply corrosion preventive compound (C50) to fill recesses (I.D. edges of grip pads to bolt hole edges). Install blade into grip and align bolt holes. Apply corrosion preventive compound (C50) generously to the bolt holes in the grip tangs and blade. Place chamfered washer (2, figure 5-11) on blade retaining bolt (1) and apply a generous amount of corrosion compound to the bolt shank (not the threads). Insert bolt through grip (3) and blade. Install washer (4) and nut(S). Wipe off any excess corrosion preventive compound using naphtha (C22).

### NOTE

Corrosion preventive compound may be applied over solid film lubricants, paints, and electroplated coatings when necessary. refer to paragraph 5-13.

- c. Install opposite blade in same manner.
- **d.** Align and balance blades. Refer to paragraph 5-6 and 5-9.

**5-107.** Painting Requirement - Main Rotor Blade. Refer to TM 55-1500-345-23.

#### SECTION III. MAIN ROTOR CONTROLS

### 5-108. MAIN ROTOR CONTROLS.

**5-109. Description - Main Rotor Controls.** The main rotor controls provide for support and control of the movement of the main rotor blades and consist of four major components as follows:

- a. Swashplate and support assembly.
- b. Pitch link assembly.
- c. Idler link assembly and collar set.
- d. Collective lever and link assembly.

### **NOTE**

For maintenance of the main rotor controls, refer to applicable instructions contained in this section for each major component.

## 5-110. SWASHPLATE AND SUPPORT ASSEMBLY.

5-111. Description - Swashplate and Support Assembly (Figure 5-35). The swashplate and support assembly encircles the mast directly above the transmission. The swashplate is mounted on a universal support (pivot sleeve) which permits it to be tilted in any direction. Movement of the cyclic control stick results in a corresponding tilt of the swashplate and the main rotor. Movement of the collective pitch lever actuates the sleeve assembly which raises or lowers the swashplate and transmits collective control to the main rotor. The cyclic controls are properly coordinated with collective control by action of the mixing lever at the base of the control column.

### CAUTION

Do not allow solvents or lubricants to contact teflon bearings of swashplate assembly.

## Premaintenance Requirements for Swashplate and Support

Condition	Requirements
Model	OH-58A and OH-58C
Part No. or Serial No.	All
Special Tools	(T27)
Test Equipment	Spring Scale
Support Equipment	None
Minimum Personnel Required	Two Men
Consumable Materials	(C9) (C51) (C55) (C96) (C97) (C107) (C118) (C129) (C62) ■
Special Environmental Conditions	None

## 5-112. Inspection - Swashplate and Support Assembly.

**a.** Inspect swashplate for evidence of grease leakage at seals.

## **NOTE**

Swashplate and support assemblies equipped with cap, P/N 206-010-444-1, may vent grease past the lower seal on first flight after lubrication. This excess grease must be removed.

- **b.** Check swashplate and support assembly for freedom of operation. Check collective vertical movement and cyclic tilting movement of the inner ring on collective sleeve spherical ball as follows:
- (1) Cut lockwire and free lower end of boot (16, figure 5-36).

- (2) Tilt swashplate inner ring forward. Inspect side walls of pivot sleeve (2, figure 5-35) bearing slot for signs of wear through teflon bearing material. Inspect top outboard edges of bearing (5) for evidence of physical damage and wear through teflon bearing material. Tilt swashplate inner ring aft and repeat inspection on opposite side of pivot sleeve.
- (3) If sleeve slots and/or bearings do not pass inspection, replace swashplate and support assembly.
- **c.** Inspect swashplate and support assembly for minor nicks, scratches, and gouges. Ensure that drain holes on base of support assembly (12) are open and free of foreign matter.
- **c.1**. Inspect swashplate support for cracks.

## **WARNING**

To prevent injury to personnel, secure main rotor blades with tiedowns.

(1) Raise collective control to gain access to the base of the swashplate support assembly (12, figure 5-35).


## **WARNING**

Dry-cleaning Solvent is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area away from heat and open flame. Wear rubber gloves and goggles. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

## CAUTION

When using Dry-cleaning Solvent for cleaning, use care to prevent contamination of adjacent parts.

- (2) Thoroughly clean swashplate support base (12, figure 5-35). Use solvent (C62).
- (3) Visually inspect full circumference of fillet radius where cylindrical (slider) portion joins support base (area immediately below area C, figure 5-48). Pay particular attention to aft side of swashplate support assembly. Use a 10 power magnifying glass.
- (4) If a crack is suspected, confirm by performing a fluorescent penetrant inspection of suspect area. No cracks allowed.
- **(5)** If no crack is found, lower collective control, inspection is complete.



1.	Outer Ring Assembly	9.	Seal	17.	
2.	Pivot Sleeve	10.	Inner Ring	18.	Lockwire
3.	Packing	11.	Bearing	19.	Seal (Upper)
4.	Сар	12.	Swashplate Support Assembly	20.	Seal (Lower)
<b>5</b> .	Bearing	13.	Collective Lever Link	21.	Grease Fitting
6.	Сар	14.	Lever Assembly	22.	Grease Fitting
<b>7</b> .	Laminated Shim	15.	Seal	* * *	e e e e e e e e e e e e e e e e e e e
8.	Bearing	16.	Retainer Ring	: f	

Figure 5-35. Swashplate and Support Assembly (Sheet 1 of 2)




Figure 5-35. Swashplate and Support Assembly (Sheet 2)

- d. Check for looseness at the following points:
- (1) Pivot sleeve (2) to lever assembly (14), 0.016 inch maximum vertical movement at pivot point; 0.042 inch maximum side play movement at pivot point.
- (2) Collective lever link (131 at attachment points to lever assembly(14) and swashplate support aasembly (12).
- e. Check self-aligning bearing in swashplate inner and outer ring arms (2 and 3, figure 5-37) for radial and/or axial wear. If radial and/or axial wear exceeds 0.020 inch, bearing must be replaced.
- **f.** If inspection is satisfactory, reinstall boot (16, figure 5-36) and double wrap lockwire (C96). If maintenance is required, reinstall boot and double wrap lockwire as last maintenance step.

# 5-113. Adjustment — Swashplate and Support Assembly.

**a.** Adjust friction of swashplate inner ring to pivot sleeve spherical ball and inspect associated controls as follows:

## CAUTION

Do not allow main rotor blade to rotate on pitch change axis. If blade rotates on the pitch change axis beyond 90 degrees, the main rotor retention strap must be replaced.

(1) Remove pitch links (8, figure 5-1).




Figure 5-36. Collective Lever, Idler Link, and Collar Set Installation (Sheet 1 of 2)





Figure 5-36. Collective Lever, Idler Link, and Collar Set Installation (Sheet 2)



- Collective Lever
   Inner Ring
   Outer Ring

- 4. Bearing5. Bolt6. Washer

- 7. Shim
- 8. Inner Cap 9. Support

Figure 5-37. Swashplate Friction Adjustment

(2) Disconnect control tubes from swashplate inner ring (2, figure 5-37).

#### **NOTE**

The 6 pounds value for breakaway torque differs for AVUM and AVIM. This allows AVUM longer trouble free operation of this item.

- (3) Disconnect idler link (11, figure 5-36) from outer ring (29).
- (4) Check friction adjustment of bearings (5 and 11, figure 5-35). Place swashplate in level position on pivot sleeve and attach a spring scale to self-aligning bearings in swashplate outer ring arm. Pull vertically with scale to cause swashplate to tilt on pivot sleeve. Note pounds of breakaway torque required to tilt swashplate at various points throughout travel, If force is not within the range of 24 to 32 pounds, adjust friction. The difference of breakaway torque at the various points checked must not exceed 6 pounds within the range.
- (5) Repeat check with spring scale three or more times to ensure that accurate values are obtained. The values for forward and aft lateral friction must both fall within the range of 24 to 32 pounds. If the forward and aft friction and lateral friction vary appreciably, suspect dragging bearings (5).
- **b.** Check for binding and dragging of pivot sleeve bearings. Disconnect control tube at forward end of lever assembly (14). Grasp lever assembly (14) and move vertically through full range of travel. Collective movement of the swashplate pivot sleeve (2) will be smooth with no dragging as it moves on the swashplate support (12).
- **c.** Check for binding and dragging of bearings (8). Rotate swashplate outer ring on swashplate assembly. If resistance to turning is not smooth and moderate throughout **360** degree rotation in both directions, replace swashplate and support assembly.
  - **d.** Adjust swashplate friction as follows:
- (1) Cut lockwire and remove eight bolts (5, figure 5-37). Index position of bearing (4).

# CAUTION

Bearing (4) can be installed in eight different positions. Bearing must be index marked before removal and installed in exactly the same position from which removed to ensure smoothness of operation of the cyclic flight controls.

#### **NOTE**

Shim (7) is a segment shim. Shims with the angle cut (45 degrees) are 0.003 inch thick. The shims with the square cut (90 degrees) are 0.002 inch thick.

- (2) Remove bearing (4) and shim (7).
- (3) Prior to adjusting shim thickness to adjust swashplate friction, clean teflon bearing surfaces of uniball bearing (4), inner cap (8), and shims (7). Use clean cloth lightly dampened with MEK (C107).
- (4) Remove lamination from shim (7) to increase friction. Use a thicker shim to decrease friction.

# CAUTION

Do not chase threads in holes for bolts (5). These are helicoil threads. If threads are not satisfactory, replace swashplate.

#### NOTE

Ensure that both shim halves (7) are of identical thickness.

(5) Reassemble shims and bearings in swashplate. Temporarily install four threaded studs into inner ring (2) as a work aid for shim alignment; studs should be about 4 inches long. Install shims using studs for alignment. Ensure shims (7) are not deformed during installation. Install bearing (4) over studs. Install four bolts (5) and four washers (6) with recessed side of washer next to bolt head and torque to 40 INCH-POUNDS in sequence opposite each other. Remove four work aid studs and install remaining four bolts (5) and washers (6) with recessed side of washer next to bolt head and torque

- **to 40 INCH-POUNDS** in saquence opposite each other. Apply a final torque of **50 TO 70 INCH-POUNDS** to all eight bolts in sequence opposite each other.
- **(6)** Check friction. If required, repeat shim adjustment procedure. Refer to paragraph 5-113.
  - (7) Lockwire (C96) heads of bolts (5) in pairs.
  - e. Install pitch links (8, figure 5-1).
- **f.** Connect control tubas to swashplate inner ring (2, figure 6-37).
- **g.** Connect idler link (11, figure 5-36) to outer ring (29).

# 5-114. Removal - Swashplate and Support Assembly.

- **a.** Remove main rotor hub and blade assembly. Refer to paragraph 5-8.
- **b.** Disconnect two cyclic control tubas from swashplate inner ring (1, figure 5-38).
- **c.** Disconnect collective control tube from collective lever (2).
- **d.** Remove cotter pin (3), nut (4), and washers (5 and 6). Disconnect idler link (19) from stud on swashplate outer ring (8) and remove washer (7).
  - e. Cut lockwire to free upper end of boot (9).
  - f. Loosen two nuts (10).
- **g.** Remove cotter pin (11), nut (12), washer (13), and specer (14). Remove bolt (15), washer (16), and specer (17).
  - h. Remove lever (18) and idler link (19).
  - i. Lift collar set (24) off over mast (20).
- **j.** Remove lockwire from bottom of boot (9) and lift boot off over top of mast. Remove retainer ring (25).
- **k.** Remove eight nuts (21) and washers (22) from studs in top of transmission case and carefully lift swashplate and support assembly (23) off overtop of mast.

# 5-115. Disassembly - Swashplate and Support Assembly (AVIM).

- **a.** Remove collective lever (29, figure 5-39) as follows:
- (1) Cut and remove lockwire from two screws (26). Remove screws (26), washers (25), and pins (27) from collective lever (29).
- (2) Remove cotter pins (12 and 31), nuts (11 and 30), washers (10 and 24), and bolts(13 and 23). Remove collective lever (29) and link (21) from Support (8).
- (3) Lockwire spacers (19) to link (21) to prevent their separation.
- (4) Lift inner and outer rings (7 and 42) with pivot sleeve (2) from support (8).
- **b.** Remove outer ring (42) from inner ring (7) as follows:
- (1) Cut and remove lockwire from eight bolts (33) and eight bolts (35).
- (2) Remove bolts (36), washers (36), and outer cap (34) with seals (38) from outer ring (42). Remove seals (38) from outer cap (34) and discard seals (38).

### NOTE

The top half of bearing set (4) can be installed in eight different positions. Bearings (4) must be index marked before removal and if reused, installed in the same position from which removed to ensure smoothness of operation. Index mark parts with a felt tip pen or paint in such a manner that marks will not be removed during cleaning or repair procedures.

- (3) Remove bolts (33), washers (32), top half bearing set (4), shims (39), and inner cap (40) from outer ring (42). Measure and record shim (39) thickness for reinstallation.
- (4) Carefully work outer ring (42) from inner ring (7). Remove duplex bearings (41) and lower seal (38) and discard seal (38).




Figure 5-38. Removal — Swashplate and Support Assembly




Figure 5-39. Swashplate and Support Assembly (Sheet 1 of 3)




Figure 5-39. Swashplate and Support Assembly (Sheet 2)




Figure 5-39. Swashplate and Support Assembly (Sheet 3)

P/N 206-010-456-1.

midseal).

**c.** Remove inner ring (7) from pivot sleeve (2) as follows:

#### NOTE

# Bushing (17) and slider bearings (18) must be maintained as a matched set.

- (1) Remove cotter pins (15), nuts (16), bushings (17), slider bearings (18), and bolts (5) from slot in pivot sleeve (2) and inner ring (7). Discard packing (6).
- (2) Raise pivot sleeve (2) in inner ring (7) and remove lower half bearing set (4) from inner ring.
  - (3) Remove pivot sleeve (2), from inner ring (7).
- **d.** Remove upper and lower sleeve bearings (1) from pivot sleeve (2).

# 5-116. Cleaning — Swashplate and Support Assembly (AVIM).

- **a.** Clean all parts except teflon bearings with drycleaning solvent (C62). Dry with filtered compressed air. Do not allow duplex bearings (41, figure 5-39) to spin while drying.
- **b.** Clean teflon bearing surfaces with a clean cloth lightly dampened with MEK (C107).

# 5-117. Inspection — Swashplate and Support Assembly (AVIM).

**a.** Visually inspect parts for damage and corrosion in accordance with figures 5-41 through 5-46, and 5-48 and for excessive wear in accordance with figure 5-40.

#### **CAUTION**

Do not chase threads in holes for bolts (33, figure 5-39) in inner ring (7) with standard 1/4-28 tap. These are helicoil inserts. If threads are not satisfactory, replace helicoil inserts. Do not chase threads in holes for bolts (35) in outer ring (42) with standard 1/4-28 tap. These are formed threads made with a special tool. If threads are not satisfactory, replace outer ring (42).

**b.** Check threads in eight threaded bolt holes in inner ring (7) and outer ring (42) for damage. Check stud (44) in outer ring for thread damage or looseness.

- **c.** Inspect grease fitting (37) for damage and security.
- **d.** Inspect spherical bearings (14,22, and 43) in inner ring (7), collective lever (29) and outer ring (42) for axial and radial play. If looseness exceeds **0.020** inch axial or radial replace bearings.
- **e.** Inspect matched duplex bearings (41) closely for minute indications of pitting, brinelling, spalling, or scoring of bearing surfaces on the races or the balls.
- **f.** Inspect teflon lined bearings or bushings (1, 3, 4, 9,18, and 20) for fabric looseness or teflon penetration. If teflon shows damage or fiberglass base is exposed, replace bearings or bushings. Damage up to **0.005** inch depth and no more than **0.4** square inches is allowed to the top surface of the upper portion of the bearing set.

#### NOTE

If any bearing of bearing set (4) does not meet the inspection criteria, the complete set must be replaced.

- **g.** Inspect inner ring (7), outer ring (42), pivot sleeve (2), link (21), collective lever (29), and support (8) for nicks, scratches, sharp dents, and corrosion.
- **h.** Inspect the following parts by fluorescent penetrant method (code F) if the accompanying records and/or physical appearance of component indicates that the component has been subjected to an accident or incident outside of the realm of normal usage. Refer to TM 55-1500-335-23.

ITEM NO.	NOMENCLATURE	CODE
2	Pivot Sleeve	F
44	Stud (bolt)*	F
7	Inner Ring	F
8	Swashplate Support	F
21	ldler	F
27	Pin	F
29	Lever	F
l 42	Outer Ring	F
40	Inner Cap	F
34	Outer Cap	F

<sup>\*</sup> Do not press stud out of outer ring; penetrant inspect visible portion.





Figure 5-40. Swashplate and Support Assembly — Limits Chart



TYPE OF DAMAGE

NICKS, SCRATCHES, SHARP DENTS

CORROSION

AREA A

AREA B

MAXIMUM DEPTH


0.010

0.030

#### NOTES:

- Area A is restricted to one repair area per lug. Minimum radius of repair is 0.500 inch.
- 2. Area B may have two repair areas, but should not overlap. Minimum radius of repair area is 0.350 inch.
- 3. Coat repair areas with chemical conversion coating (C38).
- 4. No cracks are permitted.
- 5. All dimensions are in inches.


Figure 5-41. Inspection and Repair Limits — Lever



	AREA A	AREA B MAXIMUM DEPTH	AREA C
TYPE OF DAMAGE NICKS, SCRATCHES, SHARP DENTS	0.010	0.030	0.040
CORROSION	0.005	0.015	0.020

- 1. Area A is restricted to one repair per lug. Minimum radius of repair is 0.500 inch.
- Area B may have three repair areas per lug. No repairs should overlap. Minimum radius of repair is 0.350 inch.
- 3. Area C may have two repairs per surface. Minimum radius of repair is 0.350 inch. Seal groove maximum depth of 0.020 inch after a smooth contour cleanup.
- Surface should only receive minor damage that when repaired will not inter rupt the function of the seal.
- 5. Repaired areas should be coated with chemical conversion coating (C38).


Figure 5-42. Inspection and Repair Limits — Inner Ring



	AREA A	AREA B	AREA C
TYPE OF DAMAGE		MAXIMUM DEPTH	I
NICKS, SCRATCHES, SHARP DENTS	0.010	0.030	0.060
CORROSION	0.005	0.015	0.030

- 1. Area A is restricted to one repair per lug. Minimum radius of repair is 0.500 inch.
- 2. Area B may have three repair areas per arm. No repairs should overlap. Minimum radius of rapair is 0.350 inch.
- 3. Area C may have four repair areas. No repairs should overlap. Minimum radius of repair is 0,350 inch.
- 4. This surface should receive only minor damage which when repaired will not interrupt the function of the seal.
- 5. Repaired areas should be coated with chemical conversion coating (C38).
- 6. Replace stud if threads are damaged.
- 7. All dimensions are in inches.


Figure 5-43. Inspection and Repair Limits — Outer Ring



	AREA A	AREA B	AREA C
TYPE OF DAMAGE		MAXIMUM DEPTH	
NICKS, SCRATCHES, SHARP DENTS	0.010	0.030	See Note 3
CORROSION	0.005	0.015	

- Area A is restricted to one repair area per lug. A repair must have e minimum radius of 0.500 inch.
- 2. Repairs in area B must have e minimum radius of 0.350 inch. Repairs should not overlap, nor exceed three in number.
- 3. Area C must not have any damage that penetrates the hard anodized flame sprayed surface in the active bearing area.
- 4. Repairs on areas A and B should be coated with chemical conversion coating (C38).
- 5. Retirement interval is 4800 hours.

Figure 5-44. Inspection and Repair Limits — Collective Sleeve



TYPE OF DAMAGE

NICKS, SCRATCHES, SHARP DENTS

CORROSION

AREA A

AREA B


MAXIMUM DEPTH

0.010
0.030
0.035

### NOTES

- 1. The idler may have two repair areas per cylinder and one on the web.
- 2. Repair areas should not overlap.
- 3. Minimum radii for repairs are: A = 0.500, B = 0.350.
- 4. Coat all repaired areas with chemical conversion coating (C38).
- 5. No cracks are permitted.
- 6. Retirement interval is 4800 hours.
- 7. All dimensions are in inches.

Figure 5-45. Inspection and Repair Limits - Collective Lever Link (Idler)



TYPE OF DAMAGE	MAXIMUM (	DEPTH
NICKS, SCRATCHES, SHARP DENTS	0.010	0.030
CORROSION	0.005	0.010

- 1. Area A is limited to one repair area per lug. Minimum redius of repair is 0.050 inch.
- 2. Area B may have two repair areas per segment. No repair should overlap. Minimum redius of repair b 0.350 inch.
- 3. Coat all repair areas with chemical conversion coating (C38).
- 4. No craoks are permitted.
- 6. Retirement interval is 4800 hours.
- 6. All dimension are in inches.

206010-182

AREA B

Figure 5-46. Inspection and Repair Limits — Collective Lever

# 5-118. Repair — Swashplate and Support Assembly (AVIM).

- **a.** Polish out acceptable nicks, scratches, sharp dents, and corrosion as follows: (Refer to figures 5-42 through 5-50.)
- (1) Polish out acceptable damage with sandpaper (C126) and blend into surrounding surface.
- (2) Treat repaired areas with chemical conversion coating (C38).
- **b.** Replace all worn or damaged parts that exceed limits specified in figures 5-40 through 5-50. If inner ring (7, figure 5-39) seal area (5, figure 5-40) and inner cap (40) seal area (2, figure 5-40) are grooved or have been reworked, position a new seal (38, figure 5-39) in the grooved area to ensure lip of seal contacts the entire ring or cap circumference.
- **c.** Replace defective duplex bearings (41). Duplex bearings must be replaced as a serial numbered matched set only.
- **d.** Replace defective bushing (3, 9, 20, and 28) by pressing bushing from part with suitable tools. Remove zinc chromate primer from part with MEK (C107). Coat shank of new bushings with wet unreduced zinc chromate primer (C118) and press flush into part. Remove excessive squeezed out primer. If new bushings (28) are installed in collective lever (29), they must be line reamed to **0.3750** inch minimum to **0.3755** inch maximum I.D. after installations. (Refer to items 11 and 15, figure 5-40.)
  - e. Install new seals (38) as follows:
- (1) Fabricate a disc or sleeve or slightly less outside diameter than seal case for pressing new seals into position.
- (2) Apply a light film of adhesive (C9) to the metal outside diameter of three seals (38).

#### NOTE


Heating outer cap (34) and outer ring (42) with a heat lamp will facilitate seal installation. Do not exceed a temperature of 285°F (141°C) or a 2-hour time limit.

(3) Press one seal (38) into outer cap (34) with metal face of seal to the top and lip of seal down. Press a second seal (38) into cap (34) with metal face of seal down and lip of seal up. Maintain a dimension of **0.030 to 0.060** inch between bottom of lower seal and lower surface of outer cap (34). Check to ensure that the four **0.063** inch holes in outer cap (34) are not obstructed by seals.

#### NOTE

# Refer to notes on figure 5-39 to ensure proper seal installation.

- (4) Press one seal (38) to lower inside flange of outer ring (42) until fully seated with metal face down and lip seal up. Coat lip of seal with grease (C77).
- **f.** If bearings (14, 22, and 43) and bearing in idler link (11, figure 5-36) are defective or worn more than **0.020** inches parallel to bolt hole axis, replace as follows:
- (1) Remove unserviceable spherical bearings by supporting the assembly in an arbor press using a suitable size sleeve (I.D. slightly larger than O.D. of bearing being removed) and pressing on the outer race of the bearing using a sleeve slightly smaller than the bearing outer diameter.
- (2) Coat new bearing outer race surface with sealing compound (C120). Press new bearing into assembly using anvil of tool (T27).
- (3) Secure spinning portion of tool (T27) in drill press chuck. Center bearing below spinning tool with bearing supported on anvil.
- (4) With drill press turning 250 to 350 rpm, apply sufficient hand pressure to drill press feed in 10 second increments so roller wheels of the spinning tool roll without interruption around the pregrooved bearing outer race. After each 10-second increment, inspect for correct displacement of outer race metal into hole chamber of parent assembly.
- **(5)** Turn bearing over and repeat operation on other side of bearing.
- (6) Breakout of misalignment torque on bearings after installation must not exceed 10 pounds. An acceptable method for checking this torque is to install an NAS 1305-27D bolt through the




TYPE OF DAMAGE	MAXIMUM DEPTH
NICKS, SCRATCHES, SHARP DENTS	0.010 0.030
CORROSION	0.005 0.015

- 1. Area A is restricted to one repair area per lug. Minimum radius of repair is 0.050 inch.
- 2. Area B may have three repair areas. No repair areas may overlap. Minimum redius of repair is 0.350 inch.
- 3. Repair areas should be coated with chemical conversion coating (C38).
- 4. No cracks are permitted.
- 5. All dimensions are in inches.

206010-183


AREA B

Figure 5-47. Inspection and Repair Limits — Pylon (Idler) Link



- 1. Area A is restricted to one repair area per lug. Minimum radius of repairs is 0.500 inch.
- Area B may have three repairs, none overlapping. Minimum radius of repair is 0.350 inch.
- 3. Area C must not have any damage that penetrates the hard anodized surface. Minor scratches may be cleaned up with crocus cloth. Maximum material removal is 0.0005 inch.
- 4. Repairs on areas A and B should be coated with chemical conversion coating (C38).
- 5. No cracks are permitted.
- 6. Retirement interval is 4800 hours.
- 7. All dimensions are in inches.


Figure 5-48. Inspection and Repair Limits — Support Pylon (Swashplate)



	AREA A	AREA B
TYPE OF DAMAGE	MAXIMUM DEPTH	
NICKS, SCRATCHES, SHARP DENTS	0.005	0.030
CORROSION	0.005	0.015

- 1. Area A may have one repair area per lug. Face minimum radius of repair is 0.500 inch.
- 2. Area B may have two repair areas par collar. Repairs should not overlap. Minimum radius of repair is 0.350 inch.
- 3. Nicks and dents on the splines may be cleaned up to ONE THIRD OF THE SPLINE DEPTH FOR HALF THE LENGTH of the spline. A maximum of three splines may receive cleanup.
- 4. No cracks are permitted.
- 5. All dimensions are in inches.

Figure 5-49. Inspection and Repair Limits — Collar Set — Pylon (Swashplate)



### DAMAGE LOCATION SYMBOLS

\_\_\_\_

TYPE OF DAMAGE AND REPAIR DEPTH

MECHANICAL 0.010 in. before and after repair

CORROSION 0.005 in. before and 0.010 in. after

repair

MAXIMUM AREA PER 0.100 sq. in.

**FULL DEPTH REPAIR** 

NUMBER OF REPAIRS Not critical

EDGE CHAMFER 0.030 in.

NOTE: Bore damage not to exceed 0.002 inch for full circumference.

Figure 5-50. Outer Cap — Damage Limits

bearing and install a cotter pin in the end of the bolt. Bottom bolt head against bearing and hook a scale through head of cotter pin. Pull scale and note force required to move bearing inner race. If the reading is in excess of 10 inch-pounds, the bearing may be burnished by spinning at 60 to 100 rpm for one to two minute periods until a satisfactory torque reading is obtained. Do not allow assembly to overheat (staked area not uncomfortable to touch due to heat).

5-119. Assembly – Swashplate and Support Assembly (AVIM).

# WARNING

If swashplate and support assembly P/N 206-010-460-9 is being installed, ensure that TB 55-1520-228-20-24 has been applied.

Swashplate and support assemblies containing cap P/N 206-010-466-1 are lubricated through a grease fitting in the outer ring. The grease is forced up through the duplex bearing, and vented outboard through the four holes in the cap.

Swashplate and support assemblies containing cap P/N 206-010-444-1 must be lubricated through a grease fitting in the cap. The grease if forced down through the duplex bearing and out through the lower seal.

# CAUTION

Sweshplate and support assemblies may have either cap, P/N 206-010-441-1 or P/N 206-010-456-1 installed. Either cap may be used, If cap P/N 206-010-456-1 is used, a midseal is required (38, figure 5-39). If cap P/N 206-010-444-1 is used, the bottom seal is installed with lip pointing down (20. figure 5-35). When assembling any configuration of swashplate, the correct number of seals and their installation must correspond to the cap used to ensure proper lubrication. See lubrication instructions, figure 1-5

#### **NOTE**

The following installation procedure applies to swashplate and support assembly P/N 206-010-450-5, which contains cap P/N 206-010-456-1. Swashplate and support assemblies P/N 206-010-450-7 and -9 contain cap assembly P/N 206-010-444-1 and do not have a midseal. In addition, the lower seal is installed with the lip pointing down. See figure 5-35, detail B.

When cap assembly P/N 206-010-444-1 is installed, retainer P/N 206-010-351-1 is not required and cannot be installed.

- **a.** Install two serviceable sleeve bearings (1, figure 5-39) into pivot sleeve (2),
- **b.** Support inner ring (7) on wooden blocks to allow sleeve (2) to hang free when installed. Install pivot sleeve (2) and lower two halves of bearing set (4) into inner ring (7). Ensure bearing halves are fully seated in inner ring (7).
- **c.** Secure inner ring (7) and pivot sleeve (2) as follows:

# CAUTION

To prevent contact with and damage to bearing set (4), ensure slider bearings (18), are properly installed with flange of bushing (17) facing inboard.

- (1) Install new packings (6) on bolts (5) and insert into inner ring (7) and pivot sleeve (2). Position slider bearings (18), bushings (17), and nuts (16) on shank of bolts (5) from the pivot sleeve side.
- (2) Torque nuts (16) to 60 TO 86 INCH-POUNDS (plus friction drag of nut) and secure with cotter pins (15). Ensure that tangs of cotter pins will not contact pivot sleeve (2) or support (8) when installed.
- (3) Position inner ring (7) and pivot sleeve (2) on support (8).

- **d.** Clean serviceable duplex bearings (41) with drycleaning solvent (C62) and dry with filtered compressed air. Do not allow bearings to turn while drying. Hand-pack duplex bearings (41) with grease (C77).
- **e.** Lubricate bore of outer ring (42) and shaft of inner ring (7) with grease (C77).
- **f.** Check duplex bearings (41) to ensure they are a matched serial number set; position bearings face to face (etched "V" on outer races aligned) and install into outer ring (42). The base of the "V" can point either up or down.
- **g.** Position outer ring (42) with duplex bearings (41) and seal (38) installed, onto inner ring (7). Apply equal pressure to both inner and outer races of duplex bearing.
- **h.** Apply a film of preservative compound (C51) to mating surface of outer cap (34) and outer ring (42).
- i. Position outer cap (34) on outer ring (42) and install eight bolts (35) and washers (36). Ensure recessed side of washers are next to heads of bolts. Do not torque bolts at this time.

# On 206-010-441-1 cap assembly, place grease fitting opposite stud in the outer ring.

- **j.** Install inner cap (40), shims (39), and top half of bearing set (4) as follows:
- (1) Locate and identify index marks applied to top half of bearing set (4) if original bearing is being reused.
- (2) Temporarily install four threaded studs, evenly spaced into inner ring (7) as work aid for shim (39) and bearing (4) alignment; studs should be about 4 inches long.
- (3) Apply a thin coat of adhesive (C9) to mating surfaces of inner cap (40) and inner ring(7). Install seal (38) in outer cap (34).
- (4) Lightly grease (C77) lips of seals (38) in outer cap (34) and install inner cap (40) over the 4 studs onto the inner ring (7). Take care not to distort or change the position of the lips of seals (38).

- (5) Install shims over the 4 studs into the top of inner cap (40). Use same amount of (thickness) of shims as removed during disassembly. Assure each segment of shims are equal thickness. This is to be used as a starting point and may be changed during friction adjustment.
- (6) Install top half of bearing set (4) to shims (39) and inner cap (40). Align index marks if applicable.

#### NOTE

# Do not intermix bolts (33 and 35); damage to threaded inserts will result.

- (7) Install fours bolts (33) and washers (32) with recess of washers next to bolt head and torque to 40 INCH-POUNDS in sequence opposite to each other. Remove four work aid studs and install four remaining bolts (33) and washers (32), torque to 40 INCH-POUNDS in sequence opposite of each other. Apply final torque of 50 TO 70 INCH-POUNDS to all 8 bolts (33) in sequence opposite of each other. Secure bolts with lockwire (C96) after friction adjustment is checked.
- (8) Tighten eight bolts (35) in outer cap (34) evenly until reaching a torque of 50 TO 70 INCH-POUNDS. Secure bolts with lockwire (C96).
- **k.** Check that outer ring (42) will rotate on inner ring (7) through **360** degrees rotation in both directions with moderate friction and no rough spots.
- I. Install collective lever (29) and link (21) as follows:
- (1) Insert two spacers (19) into link (21) and position between center bushings in collective lever (29). The word "TOP" is embossed on the lever to indicate proper position. Install bolt (23), washer (24), and nut (30). Torque nut (30) to 95 TO 110 INCH-POUNDS plus friction drag torque of nut and secure with cotter pin (31).
- (2) Position collective lever (29) and link (21) to support (8). Secure link (21) to support (8) with bolt (13) washers (10), and nut (11). Torque nut (11) to 95 TO 110 INCH-POUNDS plus friction drag torque of nut and secure with cotter pin (12).
- (3) Position collective lever (29) to pivot sleeve (2) and install pins (27). Secure pins (27) with screws (26) and washers (25). Torque screws (26) to 20 T0 25 INCH-POUNDS and lockwire (C96) to collective lever (29).

**m.** Fasten swashplate and support assembly to work bench. Use C clamps, or drill two holes in work bench and bolt support (8) directly to bench. Accomplish the following:

#### NOTE

For swashplate and support assembly equipped with cap, P/N 206-010-444-1, lubricate duplex bearing (41) through grease fitting in the cap with grease (C77) until a small amount of grease flows from the lower seal. Lip on lower seal points down.

- (1) Purge-lubricate duplex bearings (41) through grease fitting (37) with grease (C77) until grease flows from one or more of the four holes in outer cap (34). Rotate outer ring (42) 360 degrees in 90 degree increments, repeating the above procedure each increment.
- (2) Check collective (vertical) operation of swashplate and support assembly for smooth movement with no binding or hard spots.
- (3) Check for clearance between the support (8) and pivot sleeve (2). Grasp pivot sleeve (2) and attempt to move it laterally on support (8). If clearance is 0.020 inch or more, replace sleeve bearings (1).
- (4) Check for friction adjustment and adjust as required. Refer to paragraph 5-120.
- 5-120. Adjustment Swashplate and Support Assembly (AVIM).

### NOTE

The following specifications and procedures apply to buildup only. For AVUM adjustment, refer to paragraph 5-113.

- **a.** Fasten swashplate and support assembly to work bench. Drill at least two holes in work bench and bolt swashplate support (8, figure 5-39) directly to bench.
- **b.** Tilt and rotate swashplate outer ring (42) several times as necessary to seat bearings (4) to pivot sleeve (2).

- **c.** Place swashplate in a level position on pivot sleeve and attach a spring scale to either of the selfaligning bearings in outer ring (42) tang.
- **d.** Pull scale vertically (upward smooth process; DO NOT JERK SCALE) to tilt outer ring on pivot sleeve and NOTE POUNDS of friction on scale.
- **e.** The values for forward, aft and lateral friction adjustment range shall be from **24 to 32** pounds indicated on scale.

#### NOTE

The 4.000 pounds value for breakaway torque differs for AVUM and AVIM. This allows AVUM longer trouble free operation of this item.

- **f.** The variation of breakaway torque at the forward, aft and lateral positions checked shall not exceed **4.000** pounds within the friction range.
- **g.** Repeat check three or more times at each position to insure proper friction adjustment.
- **h.** A friction adjustment in excess of **24 to 32** pounds or a variation of breakaway torque in excess of **4.000** pounds is not acceptable. Refer to paragraph 5-117.
- 5-121. Installation Swashplate and Support Assembly.

# WARNING

If swashplate and support assembly P/N 206-010 -450-9 is being installed, ensure that TB 55-1520-228-20-24 has been applied.

Swashplate and support assemblies containing cap P/N 206-010-456-1 are lubricated through a grease fitting in the outer ring. The grease is forced up through the duplex bearing and vented outboard through the four holes in the cap.

Swashplate and support assemblies containing cap P/N 206-010-444-1 must be lubricated through a grease fitting in the cap. The grease is forced down through the duplex bearing and out through the lower seal,

The following installation procedure applies to swashplate and support assembly P/N 206-010-450-5, which contains cap P/N 206-010-456-1. Swashplate and support assemblies P/N 206-010-450-7 and -9 contain cap assembly P/N 206-010-444-1 and do not have a midseal. In addition, the lower seal is installed with the lip pointing down. See figure 5-35, detail B.

When cap assembly P/N 206-010-444-1 is installed, retainer P/N 206-010-351-1 is not required and cannot be installed.

- a. Lower swashplate and support assembly over mast and position on transmission studs with collective pitch lever at the one o'clock position. Install eight nuts (21, figure 5-38) and washers (22). Torque nuts (21) 120 TO 140 INCH-POUNDS.
- b. Position retainer ring (25) on swashplate. Position boot (9), lever (18), and collar set (24) on mast. Install two washers (32, figure 5-36) and bolt (33). install bolt in collar set (18) and install washer (31) on bolt and secure with nut (17). Ensure that bolt (15, figure 5-38) is properly positioned in the groove provided in the mast and that two spacers (14 and 17) and washers (13 and 16) are in place. Torque nut (12) 100 TO 140 INCH-POUNDS. Torque nuts (10) 50 TO 70 **INCH-POUNDS.** Install cotter pin (11). Apply sealant (C129) to cover space between collar halves and prevent foreign matter entry. Encircle entire area.

#### NOTE

Heads of all bolts to be installed in direction of rotation except bolts through collar set (24) which are to be installed with bolt heads toward lever (18) to ensure proper clearance.

Install bolt to connect lever (18) and idler link (19) if not previously accomplished. Spacers, washers, torque, and cotter pin requirements are the same as the call out for bolt (15) in step b.

d. Install washer (7) first, then attach idler link (19) to outer ring of swashplate. Install washers (6 and 5) and install and torque nut (4) 60 TO 65 INCH-POUNDS. Install cotter pin (3).

e. Secure boot (9) to swashplate and collar set with double wrap lockwire (C96).

#### **CAUTION**

Ensure sealing compound is applied only to the outer edge of the assembled seal, plate liner, and mating area of the top case.

#### NOTE

The following step is required if mast assembly is installed or seal made by sealing compound is suspected of being defective.

f. Apply a bead of sealing compound (C131) to the outer edge of assembled seal plate and liner, and mating area of top case. When sealing compound is dry, remove excess, using sharpened plastic scraper. Do not use metal scraper. Refer to figure 6-17.

#### **NOTE**

Ensure that support assembly base drain holes are open and free of foreign matter.

- g. Attach collective control tube (31, figure 5-38) to collective lever (2) using bolt (30), washers (28), nut (27), and cotter pin (26).
- h. Attach two cyclic control tubes (32, figure 5-38) to swashplate inner ring (1) using bolts (29), washers (28), nuts (27), and cotter pins (26).
- i. Install main rotor hub and blade assembly. Refer to paragraph 5-10.
- j. Lubricate swashplate until grease is vented through the cap if cap 206-010-456-1 is installed or through the lower seal if cap 206-010-444-1 is installed. Refer to figure 5-50.

#### 5-122. PIVOT SLEEVE.

5-123. Description — Pivot Sleeve. The swashplate assembly is mounted on the pivot sleeve (2, figure 5-39) and permits the swashplate assembly to be raised or lowered and tilted in any direction with corresponding movement transferred to the main rotor.

**5-124. Inspection** — **Pivot Sleeve.** Inspect pivot for wear, cracks, nicks, dents, and corrosion.

**5-125. Removal** — **Pivot Sleeve (AVIM).** Refer to paragraph 5-114.

#### 5-126. Repair — Pivot Sleeve (AVIM).


- a. Refer to figure 5-44 for repair limits.
- **b.** No cracks are permitted. Replace pivot sleeve.
- **c.** The following rework of the pivot sleeve assembly may be accomplished to facilitate ease in future removal of bearings, (Refer to figure 5-51.)
- (1) Mark lower casting of pivot sleeve directly opposite nameplate and at center point of sleeve shoulder if bearings (1, figure 5-39) are removed for

any reason. Do not mark any part of the vibro-etched serial number on sleeve.

#### **NOTE**

Hole to be drilled in shoulder of sleeve casting in the following step will facilitate future removal of lower bearing and preclude damage to sleeve casting. Make certain bearing has been removed from groove of sleeve prior to drilling hole.

(2) Drill a 1/8 (0.125) inch-diameter hole in sleeve casting at point marked. Chamfer hole on both sides  $0.015 (\pm 0.010)$  inch, and brush alodine chemical conversion coating (C38) over the hole area.



NOTE

ADDITION OF GROOVES AND HOLE IN PIVOT SLEEVE WILL FACILITATE FUTURE REMOVAL OF BEARINGS AND PRECLUDE DAMAGE TO SLEEVE CASTING.

Figure 5-51. Rework of Pivot Sleeve Assembly

- (3) When reinstalling lower bearing into sleeve, allow one end of bearing to slightly overlap the hole. (This will permit ease of bearing removal when inserting appropriate tool into hole.)
- (4) After bearing has been installed in sleeve, fill the 1/8-inch hole with proseal 890 adhesive (C17) to prevent entrance of water or foreign particles into the sleeve. Allow adhesive to cure before installation.

Shallow grooves to be made in two slotted holes of sleeve spherical ball in the following step, will facilitate future removal of upper bearing and preclude damage to sleeve casting.

- (5) Mark exact center point of lower slotted holes in spherical ball of sleeve. File or cut two grooves 0.110-0.125 inch deep and 0.115-0.135 wide at points marked, one in each of the two slotted holes (Figure 5-51). DO NOT exceed 0.125 inch depth.
- **(6)** Remove any sharp edges or burrs, if in vicinity of grooves. Wipe inner and outer surface of sleeve thoroughly with clean industrial cloth to ensure complete removal of all metal particles.
  - (7) Brush alodine (C38) on new cut grooves,

### 5-127. Installation — Pivot Sleeve. (AVIM).

- a. Refer to paragraphs 5-119 and 5-121.
- **b.** Refer to paragraph 5-113 for friction adjustment of inner ring to pivot sleeve.

### 5-128. LEVER.

**5-129. Description** — **Lever.** The lever (5, figure 5-36) transfers idler link (11) movements to the collar set (18) resulting from inner ring position changes.

#### 5-130. Inspection — Lever.

- **a.** Inspect lever for wear, cracks, nicks, dents, and corrosion.
- **b.** Refer to paragraph 5-161 for additional inspection requirements.

**5-131. Removal** — **Lever.** Refer to paragraph 5-114.

#### 5-132. Repair — Lever.

- a. Refer to figure 5-41 for repair limits.
- **b.** No cracks are permitted; replace lever.

**5-133. Installation** — **Lever.** Refer to paragraphs 5-119 and 5-166.

#### 5-134. INNER RING.

- **5-135. Description Inner Ring.** The inner ring (28, figure 5-36 and 7, figure 5-39) is a stationary component of the swashplate assembly, and through linkage transmit cyclic inputs to the main rotor.
- **5-136. Inspection Inner Ring.** Inspect inner ring for nicks, dents, wear, cracks, and corrosion. Refer to paragraph 5-117 for additional inspection requirements.
- **5-137.** Removal Inner Ring (AVIM). Refer to paragraphs 5-114 and 5-115.

#### 5-138. Repair Inner Ring (AVIM).

- **a.** Refer to figure 5-42 for repair limits and paragraph 5-118.
  - **b.** No cracks are permitted; replace inner ring.
- **5-139. Installation Inner Ring (AVIM).** Refer to paragraphs 5-119 and 5-121.

### 5-140. OUTER RING.

- **5-141. Description Outer Ring.** The outer ring (29, figure 5-36 and 42, figure 5-39) is a rotating component part of the swashplate assembly, and through linkage transmits pitch control to main rotor blades.
- **5-142. Inspection Outer Ring.** Inspect outer ring for nicks, dents, wear, cracks, and corrosion. Refer to paragraph 5-117 for additional inspection requirements.
- **5-143.** Removal Outer Ring (AVIM). Refer to paragraphs 5-114 and 5-115.

### 5-144. Repair — Outer Ring.

- a. Refer to paragraph 5-118 for repairs.
- **b.** Refer to figure 5-43 for repair limits.
- **c.** No cracks are permitted, replace outer ring.
- **d.** Detection of any loosening of drive link stud (44, figure 5-39) is cause for condemning the outer ring assembly (43).
- **5-145.** Installation Outer Ring (AVIM). Refer to paragraphs 5-119 and 5-121.

# 5-146. SUPPORT ASSEMBLY (SWASHPLATE).

- **5-147. Description Support Assembly (Swashplate).** The support assembly (8, figure 5-39 supports the swashplate assembly.
- **5-148.** Inspection Support Assembly (Swashplate). Inspect support assembly for nicks, dents, cracks, wear, and corrosion.
- **5-149.** Removal Support Assembly (Swashplate). Refer to paragraph 5-114.
- 5-150. Repair Support Assembly (Swashplate).
  - **a.** Refer to figure 5-48 for repair limits.
- **b.** No cracks are permitted, replace support assembly.
- 5-151. Installation Support Assembly (Swashplate). Refer to paragraph 5-121.

### 5-152. PITCH LINK ASSEMBLY.

- **5-153. Description Pitch Link Assembly.** Pitch link assemblies are used to transmit changes of pitch from the swashplate assembly to each individual blade.
- 5-154. Inspection Pitch Link Assembly.
- **a.** Inspect pitch linkage tubes (8, figure 5-1) for cracks, scratches, and dents, and for evidence of corrosion.

- **b.** Check linkage tube nut (7), washer (6), and bolt (5) and cotter pin (22) for security.
- 5-155. Removal Pitch Link Assembly

### WARNING


Do not allow main rotor blade to rotate on pitch change axis. If blade rotates on pitch change axis past 90 degrees the main rotor retention strap must be replaced.

- **a.** index pitch iink assembly (8, figure 5-1) for reinstallation in same position.
- **b.** Remove cotter pin, nuts, washers, and bolts securing clevis ends of pitch link assemblies to main rotor pitch horn trunnion and swashplate outer ring. (Figure 5-6.)
- **c.** Secure main rotor blade pitch horns to yoke with T-handie work aid.

#### NOTE

The T-handle work aid is fabricated locally in accordance with figure 5-8.

- **d.** LockWire (C97) the T-handle to trunnion bearing to prevent backout.
- 5-156. Inspection Acceptance/Rejection Pitch Link Assembly.
- **a.** To aid in assembly and installation procedures, measure and record the distance between the center of the upper and lower bolt holes.
- **b.** Disassemble pitch links and check pitch tubes for damage (refer to figure 5-53.) Proceed with the following:
- (1) Check the tubes at the end and outside diameter surfaces of the swaged area, from the ends of the tube to 0.750 inch in, using a three-power magnifying glass. Check for cracks, pitting, and corrosion. If cracked, the tube wiii be rejected.
- **(2)** Visually inspect each of pitch change tubes for mushrooming. if mushrooming is visually evident, replace tube.



### **CAUTION**

ENSURE THAT DECAL (4) IS POINTING UP.

### NOTES:

- 1. Apply corrosion preventive compound (C51) to all threads at each reassembly.
- 2. Torque jamnut (2 and 5) 150 to 200 inch-pounds.
- 3. Secure jamnut (2) with 0.032 inch lockwire.
- 4. Use dimension that is most convenient, to determine maximum limit for each clevis.
- 5. All dimensions are in inches.

Clevis
 Jamnut

- 3. Tube
- J. IUDE
- 5. Jamnut
- 6. Clevis

206010-188-1

Figure 5-52. Pitch Link Assembly — Preliminary Dimensions Prior to Tracking (Sheet 1 of 2)




Figure 5-52. Pitch Link Assembly — Maximum Dimensions (Sheet 2)

Inspection should only be performed while pitch change links are disassembled and not while pitch change links are installed on aircraft.

- (3) Clean the threaded shank of each clevis with MEK (C107) and inspect for cracks using a minimum 10-power magnifying glass; observe closely the valley of the threads.
- **(4)** Visually inspect clevis ends for bonding, note for elongation, exposed portion of clevis threads for condition and proper engagement.
- (5) Inspect all main rotor pitch link assemblies upper clevis (1) for wear in clevis area contacted by aligning ear of pitch horn bearing. Wear not exceeding 0.005 inch deep is permissible, provided lower clevis does not contact swashplate outer ring horns. When worn to a maximum limit, rotate the pitch link assembly 180 degrees to unworn side of the upper clevis.
- **c.** Apply corrosion preventive compound (C51) to the threads of the clevises, ends of tube, and the mating surfaces of both locks and nuts before reassembling the pitch links.

#### 5-157. Repair — Pitch Link Assembly.

**a.** Remove all scratches within prescribed limitations with wet or dry type sandpaper (C125) or finer to obtain a smooth scratch free surface.

#### NOTE

# Repair area is to have a minimum radius of 0.005 inch.

- **b.** Apply one coat of epoxy polyamide primer (C116) to repaired area.
- **c.** Replace pitch link tubes and clevis that exceed limits indicated in figure 5-53.
- **d.** Replace clevis ends containing mutilated threads (rough tool marks, tearing, etc.). Replace clevis if holes are elongated more than **0.003** inch.

### 5-158. Installation — Pitch link Assembly.

a. Remove T-handle work aid.

- **b.** Secure each pitch link assembly (8, figure 5-1) which meets inspection requirements to pitch horn trunnion assembly and two swashplate outer ring (3, figure 5-37).
- **c.** Refer to index marks for reinstallation of pitch link assemblies (8) in the same position.
- **d.** Torque nuts (18, figure 5-6) **100 TO 140 INCH-POUNDS** and install cotter pin (17). Perform test flight in accordance with TM 55-1500-328-25.

#### NOTE

Steps e. through k. must be completed only if assemblies or pitch change components are replaced.

- **e.** The following instructions apply to pitch link assembly P/N 206-010-360-3. In this installation, the upper clevis has fine threads and the lower clevis has coarse threads.
- (1) If pitch link tubes, clevis ends, nuts or complete assemblies are being replaced, apply corrosion preventive compound (C51) to the clevis threads, ends of tube, and to the top surface of nuts (2 and 5, figure 5-52).

### NOTE


In performing the following preliminary clevis adjustment, measure from the center of the upper clevis bolt hole to the bottom of the nut as shown in figure 5-52.

- (2) Set the upper clevis (1) between 2.280 and 2.320 inches. Set the lower clevis (6) between 26.500 and 26.520 inches.
- (3) Install pitch link assemblies (8, figure 5-1) to swashplate and main rotor blade pitch horns. Either clevis may be adjusted for alignment purposes.

#### NOTE


#### Observe color dots and install pitch link as coded.

**f.** After adjustment, replace any corrosion preventive compound (C51) that may have been rubbed off during adjustment.



### TYPICAL CONTROL LINK ASSEMBLIES AND CLEVISES

### **DAMAGE LOCATION SYMBOLS**



TYPE OF DAMAGE	MAXIMUM DAMAGE AND REPAIR DEPTH

MECHANICAL	0.005 in. before and after repair	0.005 in. before and after repair	0.010 in. before and after repair
CORROSION	0.0025 in. before and 0.005 in. after repair	0.0025 in. before and 0.005 in. after repair	0.005 in. before and 0.010 in. after repair
MAXIMUM AREA PER FULL DEPTH REPAIR	0.100 sq. in.	0.250 sq. in.	1.000 sq. in.
NUMBER OF REPAIRS	One per lug	2 per zone	Not critical
EDGE CHAMFER	0.020 in.	0.020 in.	0.040 in.
BORES	0.002 in. for 1/4 circumference		

### THREAD:

Depth: 1/3 of thread Length: 1/4 inch Number: Two per segment

NOTE: Repair width at any section shall not exceed one-third of tube circumference.

All dimensions are in inches.

Figure 5-53. Pitch Link Assembly — Damage Limits

- g. Ensure bolts, washers, and nuts are installed with bolt heads inboard on the main rotor pitch change horns and with bolt heads in direction of rotation on the swashplate. Use washers as required for proper bolt position and for correct cotter pin installation. There must be a washer under the head of the bolt and under the nut. Use two under nut if required,
- h. Torque nuts (7) 100 TO 140 INCH-POUNDS and install cotter pin (22).
- i. Adjust main rotor blade minimum pitch angle to-0.750 degree as follows:
- **(1)** Place collective in full down position, then place cyclic in neutral position.
  - (2) Install rigging bolt
- (3) For pitch link assembly P/N 206-010-360-3.
- (a) Adjust pitch link (1, figure 5-52) to obtain -0.750 degree main rotor blade pitch angle measure on the grip tang.

# Do not exceed the maximum dimensions shown in figure 5-52.

- **(b)** Align clevis (1 and 6) to center on self aligning bearings in swashplate and main rotor blade pitch horn. Torque nuts (2 and 5) **150 T0 200 INCH-POUNDS.** Lockwire (C96) nut (2), apply corrosion preventive compound (C51) to top surfaces of nuts (2 and 5). Lockwire required at only one end,
- j. Repeat step i. for opposite blade and install cotter pins in four bolts attaching pitch link assemblies to swashplate and main rotor blade pitch horns. Remove rigging bolt.
- **k.** Track main rotor blades. Refer to paragraph 5-255.

### 5-159. IDLER LINK AND COLLAR SET.

**5-160.** Description — Idler Link and Collar Set. The idler link and collar set transfers mast movement to the swashplate outer ring.

#### 5-161. Inspection — Idler Link and Collar Set.

- **a.** Visually inspect idler link, lever and collar for obvious damage and for proper installation. Check the assembly for security of attachment.
- **b.** Check bolt (1, figure 5-36) for security. It should not be possible to turn bolt (1) with fingers.
- **c.** Without disassembly, look for metal-to-metal contact between lever (5), idler link (11), or collar set (18). Metal-to-metal contact is an indication that the teflon pad has worn through, been knocked loose, or that a bushing has been broken.
- d. Maximum allowable radial play between spacer (12) and lever (5) at each of four places is 0.025 inch. Clamp dial indicator to collar set for inboard spacers, and to lever for outboard spacers.
- **e.** Visually inspect the collar set for cracking or permanent deformation, especially the area adjacent to the slot in the rear collar. Look for heavy scoring, threading, and pitting.
- **f.** Inspect boot (16) for cuts, tears, and deterioration.
- g. If radial looseness between spacers and lever, etc., exceeds **0.008** inch, a disassembly inspection and reversal of the lever (5) is required at the periodic inspection, (Invert lever (5) such that its top becomes its bottom, but the outboard bushings remain outboard.)

#### NOTE

Temporarily mark the lever (5) making it possible to determine which side of the lever had been up and which bushings were outboard. Disassembly inspection is also required if there is visual indication of metal-to-metal scoring of bushing or lever surfaces.

# 5-162. Removal — Idler Link Assembly and Collar Set.

a. Loosen two nuts (17, figure 5-36) then remove cotter pin (15), nut (14), washer (13), and spacer (12). Remove bolt (1), spacer (3), and washer (2),

# WARNING

Do not attempt to remove or install bolt (1) between lever end collar set before loosening nuts (17), nor use force for either removal or installation (slight tapping with plastic or rawhide mallet permitted.)

- **b.** Remove cotter pin (6), nut (7), washer (8), and washer (9). Remove idler link (11) from stud on outer ring (29), then washer (10). Remove lever and link as an assembly.
- **c.** Remove nuts (17) and attaching hardware securing collar set to mast. Remove collar set (18).
- **d.** Remove hardware securing lever (5) to link (11).
- **5-163.** Cleaning Idler Link Assembly and Collar Set. Clean the collar set. spacers, and idler link with MEK (C107). Wipe with clean dry cloth .

# 5-164. Inspection (Disassembly) – Idler Link Assembly and Collar Set.

- **a.** After disassembly, determine if metal-to-metal scoring has occurred.
- **b.** If radial looseness of any spacer has exceeded **0.016** inch as measured in idler link and collar set, replacement of all four lever bushings and both idler link bushings is recommended.

# 5-165. Repair or Replacement — Idler Link Assembly Collar Set.

- **a.** Check self-aligning bearing in idler link (11, figure 5-36). If inner ball portion of bearing can be moved **0.020** inch or more parallel to the bolt hole axis, replace bearing. Refer to paragraph 5-118, step f.
- **b.** For repair limits of components of the idler link assembly and collar set, refer to figures 5-40, 5-46, and 5-48.
- **c.** Replace bushings in idler lever (5, figure 5-36) as follows:
- (1) Remove bushings from lever. Refer to TM 56-1500-322-24.

(2) Install new bushings with A4 metal set (C12) maintaining a minimum dimension of 2.625 between bushing surfaces.

#### NOTE

Do not allow metal-set to coat bearing surfaces.

- **d.** Replace bushings in idler link (11, figure 5-36) as follows:
- (1) Remove bushings from link. Refer to TM 55-1500-322-24.
- (2) Install new bushings, apply unreduced zinc chromate (C118) to faying surfaces of bushing and link, Refer to TM 55-1500-322-24.

5-166. Installation — Idler Link Assembly and Collar Set.



Ensure collar set serrations are properly seated in mast serrations. Collar set must slide freely into position. Do not force.

**a.** Inspect two halves of collar set (18, figure 5-36) to ensure they are a matched set,

#### NOTE

The set numbers will be vibro-etched. either on top of the collars or on the edges adjacent to the bolt holes.

- **b.** Check the milled groove in mast (4) to ensure it crosses **five** serrations only.
- **c.** Slide the collar set halves (one at a time) down into mast serrations; then install bolts (33), with two washers (32), under bolt heads.

#### **NOTE**

Bolt heads must be on the same side of the collar set as the lever (5).

**d.** Install one washer (31) under each nut (17). Do not tighten nuts at this time.

- **e.** Ensure collar set has been properly positioned with respect to lever (5), idler link (11), and outer ring (29).
- **f.** After verifying that bolt (1) is serviceable, i.e., not bent, cross threaded, or worn excessively, position washer (2) and spacer (3) on bolt (1). Axial scoring must not exceed **0.005** inch depth. Radial scoring must not exceed **0.003** inch depth. Bolts damaged beyond these limits must be replaced.

In general, bolt wear patterns, resulting from minute flexures or movement without sharp edges, burrs, or abrupt changes in profile, are permitted. Localized polishing or wear of cadmium plating is permitted.

**g.** Look through hole in collar set to visually verify alignment and absence of metal chips, etc., then carefully insert bolt (1) through lever (5) and collar set (18).

#### NOTE

Ensure that bolt (1) is properly positioned in groove provided in mast (4), and bolt head is in direction of rotation.

- h. Install spacer (12), washer (13), and nut (14).
- i. Torque nut (14) **100 TO 140 INCH-POUNDS**, plus free running torque required for self-locking nut.
- **j.** Torque nuts (17) **50 TO 70 INCH-POUNDS**, plus free running torque required for self-locking nut.
  - k. Install cotter pin (15) in bolt (1).
- **I.** Install washer (37), and spacer (38) on bolt (36). Insert bolt (36) through lever (5) and idler link (11).

#### **NOTE**

Ensure that bolt head is in direction of rotation.

m. install spacer (39), washer (40), and nut (41).

- **n.** Torque nut (41) **100 TO 140 INCH-POUNDS**, plus free running torque required for self-locking nut.
  - o. Install cotter pin (42) in bolt (36).

### **CAUTION**

Ensure washer (9), is installed between idler link (11) and washer (8).

- **p.** install washer (10) on outer ring of swashplate and attach idler link (11).
- **q.** Install washers (9 and 8), and torque nut (7) **60 TO 85 INCH-POUNDS.** 
  - r. Install cotter pin (6).
- **s.** Apply sealant (C129) to cover spacer between collar halves. Encircle entire area around mast to prevent entry of foreign matter.

#### NOTE

Heads of all bolts are to be installed in direction of rotation except bolts through collar set (18), which are installed with bolt heads toward lever (5) to ensure proper clearance.

# 5-167. COLLECTIVE LEVER AND LINK ASSEMBLY.

**5-168.** Description — Collective Lever and Link Assembly. The collective lever is used in conjunction with the cyclic control to control pitch inputs to rotor blades.

# 5-169. Inspection (Installed) — Collective Lever and Link Assembly.

- **a.** Visually inspect all parts for evidence of corrosion, nicks, dents, scratches, and excessive wear.
- **b.** Check self-aligning bearing in collective lever (19). If inner ball portion of bearing can be moved **0.020** inch or more parallel to the bolt hole axis, replace bearing.

### 5-170. Remove Collective Lever and Link Assembly.

- **a.** Remove screw (21, figure 5-36), washer (22), and pin (20) attaching collective lever (19) to pivot sleeve.
- **b.** Remove bolt (23), washers (24), nut (26), and cotter pin (35) securing collective lever.
- **c.** Remove hardware (same as step b.) securing link (25) to swashplate support. Remove link.

### 5-171. Inspection — Collective Lever and Link Assambly.

#### **NOTE**

Using a 10-power magnifying glass, inspect for cracks in collective lever and link assembly.

- **a.** Inspect collective lever link (idler) in accordance with figure 5-45.
- **b.** Inspect collective lever in accordance with figure 5-46

### 5-172. Repair — Collective Lever and Link Assembly.

**a.** Repair of the collective lever and link is limited to removal of nicks, scratches, dents, and corrosion from

surface area. Refer to figures 5-45 and 5-46 for repair limits

**b.** No cracks are permitted. Replace defective assembly.

5-173. Installation — Collective Lever and Link Assembly.

#### **NOTE**

The word "TOP" is embossed on the lever assembly to indicate proper installation.

- **a.** Prior to assembling collective lever (29, figure 5-39) and link (21), ensure bushings (3, 9, and 28) and bearings (1 and 22) are installed on pivot sleeve (2) and lever (29).
- **b.** Install lever assembly (29) to support assembly (8) with link (21) using bushings (20), spacers (19), bolts (13 and 23), washers (10 and 24), and nuts (11 and 30).
- **c.** Torque nuts (11 and 30) **95 TO 110 INCH-POUNDS** and install cotter pins (12 and 31).
- **d.** Install collective lever (29) to pivot sleeve (2) using pins (27), washers (25), screws (26), and lockwire (C96) screws to lever.

### SECTION IV. TAIL ROTOR

### 5-174. Tail Rotor.

**5-175. Description** — Tail Rotor. The tail rotor counteracts torque applied to the helicopter under power. The tail rotor system consists of the hub and blade assembly, a yoke assembly, trunnion, and the blade pitch change mechanisms.

### **NOTE**

Helicopters are delivered with a balance wheel installed as part of the tail rotor to facilitate dynamic balancing of the tail rotor. A balance wheel can be used on prior helicopters by installing parts illustrated in figure 5-54, detail B.

- **5-176. Cleaning Tail Rotor.** Spot clean the rail rotor with naphtha (C22). Wipe with dry clean cloth.
- **5-177. Inspection Tail Rotor**. Refer to paragraphs 5-182 and 5-204.
- **a.** Inspect rotor blades for nicks, dents, scratches, or looseness.
- **b.** Inspect control linkage for obvious damage and security.
- **5-178.** Troubleshooting Tail Rotor. Troubleshoot the tail rotor in accordance with table 5-2.




Figure 5-54. Tail Rotor Removal/Installation (Sheet 1 of 2)

- 1. Link
- 2. Pitch Horn
- 3. Nut
- 4. Washer
- Crosshead
- 6. Pin
- 7. Control Tuba
- 8. Knurled Nut
- 9. Liner
- 10. Washer
- 11. Nut
- 12. Static Stop
- 13. Bumper 14. Shim
- 15. Pin
- 16. Key

- 17. Spacer
- 18. Gearbox Shaft
- 19. Tail Rotor Blade
- 20. Bolt
- 21. Washer
- 22. Nut
- 23. Nut
- 24. Cupped Washer
- 25. Shims
- 26. Balance Wheel
- 27. Bolt
- 28. Washer
- 29. Washer
- 30. Nut
- 31. Cotter Pin

206011-285-2

Figure 5-54. Tail Rotor Removal/Inatallation (Sheet 2)

### NOTE

Before using table 5-2, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 5-2, notify the next higher level of maintenance.

5-179. Alignment and Balance — Tail Rotor (with Balance Wheel).

### **NOTE**

When balancing is completed, there can be bolts, washers, and nuts installed in both the spanwise and chordwise directions.

- **a.** Perform spanwise balancing as follows:
- (1) Observe the amount of vibration at the pedals and horizontal stabilizer at 100% to 103% A 97% to 100% C N2 for reference.
- (2) Place a two-inch strip of one-inch wide masking tape (C143) near the tip of one blade (30 inches from center line of hub) and compare the vibration. If vibration is not reduced by the first twoinch strip of masking tape, remove the tape and perform the same procedure on the opposite blade.
- (3) If vibration is reduced but not acceptable try a four-, six-. eight-, or 10-inch strip of masking tape until vibration is reduced to minimum.

(4) Install a bolt (27, figure 5-54), washers (28 and 29), and nut (30) in the balance wheel (26) hole aligned spanwise (lengthwise) with the blade.

#### NOTE

Length of bolt (27) is determined by number and combination of washers used. Washers (29) should be placed alternately on either side of balance wheel (26). The combination of bolt, washers, and nut is to equal the same inch/gram imbalance as that exerted by the tape on the rotor. (Refer to table 5-3.) Use a maximum of 4 bolts per balance wheel.

- **b.** Perform chordwise balancing as follows:
- (1) Observe the amount of vibration at the pedals and horizontal stabilizer at 100% to 103% A 97% to 100% C N2 for reference.
- (2) Install a bolt (27) and nut (30) in one of the balance wheel (26) holes that are aligned chordwise (fore and aft) with the rotor blades and compare the vibration. If vibration is not reduced, remove the bolt and nut and perform the same procedure using the opposite hole in the balance wheel.
- (3) If vibration is reduced, add washers (28 and/or 29) until vibration is reduced to minimum.

### Table 5-2. Troubleshooting — Tail Rotor Assembly

#### CONDITION

**TEST OR INSPECTION** 

### **CORRECTIVE ACTION**

- 1. High frequency vibration felt through tail rotor control pedals.
  - STEP 1. Blade out of balance. Refer to paragraph 5-179.

Balance tail rotor blade. Refer to paragraphs 5-179 and 5-202.

STEP 2. Worn or loose blade bearing. Refer to paragraph 5-244.

Replace bearings and/or blades. Refer to paragraphs 5-245 and 5-246.

STEP 3. Bent pitch change link. Refer to paragraph 5-177.

Replace pitch change link. Refer to paragraphs 5-183 and 5-188, step k.

STEP 4. Loose retaining nut. Refer to paragraph 5-188.

Retorque retaining nut 45 TO 50 FOOT-POUNDS. Refer to paragraphs 5-183 and 5-188.

STEP 5. Loose pitch change link bearing. Refer to paragraphs 5-183 and 5-188.

Replace pitch change link. Refer to paragraphs 5-183 and 5-188.

STEP 6. Worn pitch change tube. Refer to paragraphs 5-183 and 5-188.

Replace defective part. Refer to paragraphs 5-183 and 5-188.

STEP 7. Worn tail rotor flapping bumper. Refer to paragraph 5-183 and 5-188

Replace worn bumper. Refer to paragraphs 5-183 and 5-188.

- 2. Inability to make normal right and left turns in flight.
  - STEP 1. Improper tail rotor rigging. Refer to paragraph 11-105

Refer to paragraph 11-94 for rigging procedures and paragraph 5-179 for alignment.

Table	5-3.	Balance	Weight	Conversion
-------	------	---------	--------	------------

ITEM NO.	NOMENCLATURE	WEIGHT	ARM	UNBALANCE
1.	Masking Tape, one inch wide. a. Two inch length b. Four inch length c. Six inch length	0.18 gm 0.36 gm 0.54 gm	30 inch 30 inch 30 inch	5.4 in/gin 10.8 in/gin 16.2 in/gin
2.	AN3-3A bolt	2.9 gm	1.25 inch	3.7 in/gin
3.	AN3-4A bolt	3.41 gm	1.25 inch	4.4 in/gin
4.	AN3-5A bolt	3.86 gm	1.25 inch	4.4 in/gin
5.	NAS679A3 nut	1.27 gm	1.25 inch	1.6 in/gin
6.	AN960- 10 washer	0.9 gm	1.25 inch	1.1 in/gin
7.	AN970-3 washer	5.0 gm	1.25 inch	6.2 in/gin
8.	MS21042L3 nut	0.81 gm	1.25 inch	1.0 in/gin

5-180. TAIL ROTOR HUB AND BLADE ASSEMBLY. (Prior to compliance with MWO 55-1520-228-50-25.)



Parts of the improved tail rotor (after MWO 55-1520-2283-50-25) although similar cannot be used on the standard tail rotor (before MWO 55-1520-228-50-25.) The following parts must always be used together to assure safe operation: hub, and blade assembly P/N 206-011-801 series (used before MWO 55-1520-228-50-25).

Yoke Assembly P/N 206-011 -802-1 or-105
Trunnion P/N 206-011 -803-5
Blade Assembly P/N 206-010-750-5 or-109



TB 55-1520-228-20-29 required all yoke assemblies, P/N 206-011-802-1, to be modified prior to issue. Thus only P/N 206-011-802-105 should be received from supply. If a yoke (-1 series) or a tail rotor assembly which includes a yoke (-1 series) is received from supply, return it, citing the TB.

### **NOTE**

Refer to paragraph 5-227 if MWO 55-1520-228-50-25 has been complied with.

**5-181. Description** — **Tail Rotor Hub and Blade Assembly.** The tail rotor hub and blade assembly consists of an aluminum alloy forged yoke and

aluminum alloy blades. The blades are mounted in the yoke by means of spherical bearings which are mounted in the grip plates on the pitch change axis. The spherical bearings provide for pitch change of the blades. The yoke and blade assembly is mounted on the 90 degree gearbox shaft by a splined trunnion, mounted in bearings within the yoke, to provide a flapping axis for the assembly. At time of assembly, spanwise balance is accomplished by use of washers on the blade retention bolts, and chordwise balance is attained by adjustment of nuts to shift the position of the trunnion in the yoke,

### 5-182. Inspection — Tail Rotor Hub and Blade Assembly.

- **a.** Inspect rotor blades for nicks, dents, scratches, cracks, and bearing looseness. Refer to paragraph 5-242 and 5-244.
- **b.** Inspect tail rotor hub. Refer to paragraph 5-195.
- **c.** Inspect tail rotor pitch change mechanism. Refer to paragraph 5-207,
- **d.** Inspect tail rotor pitch horn. Refer to paragraph 5-224.
- **e.** Inspect tail rotor hub and blade assembly for security of attachment,
- **f.** Check for correct tail rotor tailboom clearance. Refer to paragraph 5-189, step j.

### Premaintenance Requirements for Tail Rotor Hub and Blade Assembly

Condition	Requirements	
Model	OH-58A and OH-58C	
Part No. or Serial No.	All	
Special Tools	(T44) (T46)	
Test Equipment	Protractor	
Support Equipment	None	
Minimum Personnel Required	Two Men	

Condition	Requirements	
Consumable Materials	(C22) (C38) (C96) (C97) (C107) (C116) (C118)(C143)	
Special Environmental Conditions	None	

### 5-183. Removal — Tail Rotor Hub and Blade Assembly.

- **a.** Disconnect pitch change links (1, figure 5-54) as follows:
- (1) Disconnect pitch change links at crosshead by removing nut (22), bolt (20), and washer (21).
- (2) Disconnect pitch change links at pitch horn by removing nut (23) and cupped washer (24).

### **NOTE**

## A battery terminal puller (T44) may be used to remove crosshead from control tube.

- **b.** Remove nut (3) and washer (4) from end pitch control tube (7). Remove crosshead (5) from control tube and lift pin (6),
- c. Cut lockwire and remove knurled nut (8) and liner (9).
- **d.** Remove shims (25) and balance wheel (26) if installed.
- e. Straighten washer (10) where it is bent over nut (11) and remove nut,
- **f.** Remove washer (10), static stop (12), bumper (13), and shim (14),
- g. Slide tail rotor assembly off gearbox shaft (18) and remove pin (15) and spacer (17).

### **NOTE**

Shim (14) serves to position static stop (12) and ensure blade-to-tailboom clearance. If the hub and blade assembly is to be reinstalled, identify the shim for reuse in the assembly.

### 5-184. Inspection — Tail Rotor Installation Components.

- **a.** Inspect spacer (17, figure 5-54), static stop (12), and knurled nut (8) for damage. Replace components exceeding allowable limits shown in figures 5-55, 5-56, and 5-57.
- **b.** Inspect teflon liner (9, figure 5-54) for excessive wear. Maximum I.D. is **0.642** inches. Liner will be replaced if measurement exceeds **0.642** when measured with knurled nut removed from control tube.
- **c.** Inspect balance wheel (26), nut (11), and nut (3) for obvious damage to include thread damage, corrosion, and cracking. Threads must not be stripped, crossthreaded, or otherwise mutilated. No cracking permitted.
- **d.** Inspect shims (25), shims (14), bumper (13), and washer (10) for obvious damage. Washer (10) will normally be replaced.

#### **NOTE**

- Nut (3) will normally be replaced, but may be reused if it meets the minimum drag torque for used self-locking nuts as specified in table 1-1.
- **5-185.** Repair Tail Rotor Installation Components. Repair is limited to blending out mechanical and corrosion damage with abrasive cloth (C45).

### 5-186. Disassembly — Tail Rotor Hub and Blade Assembly.

- **a.** Remove blade assemblies in accordance with paragraph 5-243.
- **b.** Disassemble tail rotor hub in accordance with paragraph 5-197.

#### NOTE

For repair of tail rotor hub and blade assembly components, refer to the applicable component repair, Sections V and VI.


### 5-187. Assembly – Tail Rotor Hub and Blade Assembly.

- **a.** Assemble tail rotor hub in accordance with paragraph 5-201.
- **b.** Install tail rotor blades in accordance with paragraph 5-246, then balance in accordance with paragraph 5-202.

#### NOTE

In service the only requirement is that there be no metal-to-metal contact between the knurled nut (8) and control tube (7).

5-188. Installation — Tail Rotor Hub and Blade Assembly (with Dynamic Balance Wheel).



Ensure that pin (15, figure 5-54) goes through hole in key (16) and remains in position until tail rotor assembly and static stop are positioned on driveshaft. If for any reason pin (15) should become lodged inside the pitch control tube, or pin location cannot be determined, the pitch control tube must be removed from the helicopter, If pin cannot be dislodged, control tube must be X-rayed to determine if pin is present.

- a. Install spacer (17) against shoulder on tail rotor driveshaft. Align pin hole in driveshaft, slot control tube (7), and hole in key (16). Install pin (15).
- **b.** Align splines and position tail rotor assembly on 90 degree gearbox shaft with leading edge of top blade (19) facing aft. Install shim (14), rubber bumper (13), static stop (12), washer, and nut (11). Torque nut to **45 TO 50 FOOT-POUNDS.**
- **c.** Check tail rotor assembly for freedom of movement on flapping axis. Check each rotor blade for freedom of movement on pitch change spherical bearings.





Figure 5-55. Tail Rotor Spacer — Damage Limits

- **d.** Check for correct rotor flapping angle as follows:
- (1) Place tail rotor blades in vertical position, move rubber bumper (13) outboard over static stop, and check flapping angle along with pitch change axis. The pitch change axis is an extension of a line through the centers of the blade-to-yoke attachment bolts. Flap tail rotor to one extreme position until yoke contacts static stop (12). Place a protractor on blade-to-yoke attachment bolts and record angle. Flap tail rotor to opposite extreme position until yoke contacts static stop; measure and record angle. The total flapping angle must be 12 (±1) degrees.
- (2) If flapping angle is less than 11 degrees, increase thickness of shims (14). If flapping angle is more than 13 degrees, reduce thickness of shims (14). Should flapping angle be more than 13 degrees with all shims removed, remove static stop and surface or machine the inboard end removing no more than 0.020 inch of material. Reinstall static stop and check flapping angle. Adjust and install shims (14) if necessary.

### NOTE

Use only bonded laminates of shim (14). If a thicker shim is required, use a new shim. Laminates are 0.002 inch thick.





### DAMAGE LOCATION SYMBOLS







### TYPE OF DAMAGE

### MAXIMUM DAMAGE AND REPAIR DEPTH

MECHANICAL AND CORROSION

0.005 in.

0.010 in.

0.010 in.

MAXIMUM AREA PER FULL DEPTH REPAIR Not critical

Not critical

1/4 circumference

NUMBER OF REPAIRS

Not critical

Not critical

Not critical


**EDGE CHAMFER** 


**BORES** 

 $0.020 \ \text{in.} \ \text{x} \ 45^{\circ} \ 0.020 \ \text{in.}$ 

0.005 inch for 1/4 circumference

Figure 5-56. Tail Rotor — Static Stop — Damage Limits





### TYPE OF DAMAGE

### MAXIMUM DAMAGE AND REPAIR DEPTH

MECHANICAL AND 0.020 in. 0.020 in below CORROSION depth of knurl

MAXIMUM AREA PER Not critical Not critical FULL DEPTH REPAIR

NUMBER OF REPAIRS Not critical Not critical

EDGE CHAMFER 0.030 in. 0.030 in.

BORES 0.010 inch for 1/4 circumference

THREADS:

DEPTH: 1/3 of thread
LENGTH: 1/4 inch
NUMBER: Two

Figure 5-57. Tail Rotor Knurled Nut — Damage Limits

e. Install balance wheel (26) against nut (11) and torque to approximately 50 INCH-POUNDS,

### CAUTION

Use only knurled nut, P/N 206-010-759-3 (0.875 inch overall length), on helicopters with the balance wheel.

### CAUTION

Too much torque will strip the threads in balance wheel (26),

- **f.** Install liner (9) and knurled nut (8). Hand-tightern nut and measure gap between nut and wheel.
- **g.** Remove knurled nut (8) and install shims (25) to fill gap measured in step f.

#### **NOTE**

Shims (25) are laminated shims. Total thickness of each shim is 0.032 inch with each segment being 0.002 inch.

- h. Install knurled nut (8) and hand-tighten.
- i. Check pitch change mechanism for freedom of movement through operating range
- j. Install pin (6) in pitch control tube and install crosshead (5) over control tube pin. Check for proper location of pin by inserting a piece of lockwire into groove at back of crosshead. Secure crosshead with washer (4) and nut (3). Torque for nut (3) will be drag torque plus 100 TO 150 INCH-POUNDS.
- **k.** Use washers as required under nut (22) to obtain cotter pin engagement or prevent nut bottoming out on threads. Be sure to use one washer under the head of bolt (20). If more than 3 of the thick washers are required to obtain this fit, the next size shorter bolt should be used. Use the same bolt and washers combination on each crosshead to pitch link attachment.
- I. Install pitch change links (1) between blade pitch horns (2) and crosshead (5). Secure links to pitch horn with washers (24), nuts (23), and cotter pins

- (31). Install cupped washers (24), nuts (23), and cotter pins (31). Install cupped washers (24) between nut and pitch link at blade pitch horn. Torque nut (23) 30 **TO 40 INCH-POUNDS.** Install bolt (20) in crosshead end with bolt head in direction of tail rotor rotation and secure with washers (21), nuts (22), and cotter pins (31). Torque nuts (22) **60 TO 80 INCH-POUNDS.** Check links for freedom of movement on bearings.
- **m.** Check rigging of tail rotor control system. Refer to paragraph 11-100.
- n. Check for correct tail rotor to tailboom clearance as follows:
- (1) Turn tail rotor to position on blade tip adjacent to tailboom. Hold right antitorque pedal forward against stop. Flap tail rotor blade toward tailboom and against static stop (12). The trailing edge of tail rotor blade must clear tailboom at closest point with at least 1.500 inches.
- (2) If clearance is not within tolerance, readjustment of thickness of shim (14) may be required to provide the minimum allowable flapping angle.
- **o.** Reposition rubber bumper (13) between static stop and yoke.
- **p.** Bend edge of washers (10) inboard over one flat of static stop. Bend edge of washers (10) at another location, outboard over two flats of nut (11). Refer to figure 5-54, detail A.
- **q.** Lockwire (C96) balance wheel (26) to bent washer (10) and knurled nut (8).

### NOTE

The tail rotor hub and blade assembly must be statically balanced prior to installation on the helicopter. The balance wheel (26) is installed to permit dynamic balancing of the assembly on the helicopter when a high frequency vibretion is found to exist and it is known that the hub and blade assembly is serviceable and is statically balanced. Refer to paragraph 5-179.

5-189. Installation — Tail Rotor Hub and Blade Assembly (without Dynamic Balance Wheel).

### WARNING

Ensure that pin (15, figure 5-54) goes through hole in key (16) and remains in position until tail rotor assembly and static stop are positioned on driveshaft. If for any reason pin (15) should become lodged inside the pitch control tube, or pin location cannot be determined, the pitch control tube must be removed from the helicopter. If pin cannot be dislodged, control tube must be X-rayed to determine if pin is present.

**a.** Install spacer (17) against shoulder on tail rotor driveshaft. Align pin hole in driveshaft, slot in control tube (7), and hole in key (16). Install pin (15).

#### **NOTE**

Do not bend washer (10) or install lockwire or cotter pins until step j.

- **b.** Align splines and position tail rotor assembly on 90 degree gearbox shaft with leading edge of top blade (19) facing aft. Install shim (14), rubber bumper (13), static stop (12), washer (10), and nut (11). Torque nut to **45 TO 50 FOOT-POUNDS.**
- **c.** Check tail rotor assembly for freedom of movement on flapping axis. Check each rotor blade for freedom of movement on pitch change spherical bearings.
- **d.** Check for correct rotor flapping angle as follows:
- (1) Check flapping angle along the pitch change axis. The pitch change axis is an extension of a line through the centers of the blade-to-yoke attachment bolts. Place tail rotor blades in vertical position, move rubber bumper (13) outboard over static stop (12). Flap tail rotor to one extreme position until yoke contacts static stop. Place a protractor on blade-to-yoke attachment bolts and zero protractor. Flap tail rotor to opposite extreme position until yoke contacts static stop; measure and record angle. the total flapping angle must be 12 (±1) degrees.

(2) If flapping angle is less than 11 degrees, increase thickness of shims (14), If flapping angle is more than 13 degrees, reduce thickness of shims (14). Should flapping angle be more than 13 degrees with all shim removed, remove static stop and surface or machine the inboard end removing no more than 0.020 inch of the material. Reinstall static stop and check flapping angle, Adjust and install shims (14) if necessary.

#### NOTE

Use only bonded laminates of shim (14). If a thicker shim is required, use a new shim. Laminates are 0.002 inch thick.

- **e.** Install liner (9) and knurled nut (8). Tighten nut hand-tight.
- **f.** Check pitch change mechanism for freedom of movement through operating range.
- g. Install pin (6) in pitch control tube and install crosshead (5) over control tube and pin. Check for proper location of pin by inserting a piece of lockwire into groove at back of crosshead. Secure crosshead with washer (4) and nut (3). Torque for nut (3) will be drag torque plus 100 TO 150 INCH-POUNDS.

#### NOTE

Use washers as required under nut (22) to obtain cotter pin engagement or prevent nut bottoming out on threads. Use same washer combination on each crosshead to pitch change link attachment.

h. Install pitch change links (1) between blade pitch horns (2) and crosshead (5). Secure links to pitch horn with washers (24), nuts (23), and cotter pins (31). Install cupped washers (24) between nut and pitch link at blade pitch horn. Torque nut (23) 30 TO 40 INCH-POUNDS. Install bolts (20) in crosshead end with bolt head in direction of tail rotor rotation and secure with washers (21), nuts (22), and cotter pins (31), Torque nuts (22) 60 TO 80 INCH-POUNDS. Check links for freedom of movement on bearings.

### NOTE

A rubber or teflon bumper washer may be used between the tail rotor pitch change links and the tail rotor crosshead.

- i. Check rigging of tail rotor control system. Refer to paragraph 11-100.
- **j.** Check for correct tail rotor to tailboom clearance as follows:
- (1) Turn tail rotor to position one blade tip adjacent to tailboom. Hold right antitorque pedal forward against stop. Flap tail rotor blade toward tailboom and against static stop (12). The trailing edge of tail rotor blade must clear tailboom at closest point at least 1.500 inches.
- (2) If clearance is not within tolerance, adjustment of thickness of shim (14) maybe required to provide the minimum allowable flapping angle.
  - k. Reposition rubber bumper (13) between static
- **I.** Bend edge of washer (10) inboard over one flat of static stop. Bend edge of washer (10) at another location outboard over two flats of nut (11). Refer to figure 5-54, detail A.
- **m.** Lockwire (C96) knurled nut (8), and washer (10).

### SECTION V. TAIL ROTOR HUB AND CONTROLS

### 5-190. TAIL ROTOR HUB AND CONTROLS.

- **5-191. Description Tail Rotor Hub and Controls.** The tail rotor hub and control assembly provide for attachment and control pitch movements of the tail rotor blades. The tail rotor hub and control consists of four major components as follows:
  - a. Tail rotor hub.
  - **b.** Tail rotor pitch change mechanism.
  - c. Tail rotor hub trunnion.
  - d. Tail rotor pitch horn.

#### NOTE

For maintenance of the tail rotor hub and control assemblies, refer to applicable instructions contained in this section for each component.

### 5-192. TAIL ROTOR HUB.

- **5-193. Description Tail Rotor Hub.** The tail rotor hub (figure 5-58), consists of an aluminum alloy forged yoke mounted on the 90 degree tail rotor gearbox output shaft by a splined trunnion mounted in bearings of the yoke.
- **5-194.** Cleaning Tail Rotor Hub. Spot clean the tail rotor hub with naphtha (C22). Wipe with clean dry cloth.


### 5-195. Inspection - Tail Rotor Hub.

- a. Inspect hub for scratches, nicks, dents, burrs, cracks, corrosion, and similar surface defects. Scratches and nicks requiring no more than **0.005** inch removal of material in cleanup are permissible. Blend edges of repaired area into surrounding surface to form a smooth contour. Touch up paint as required.
- **b.** Inspect pitch change links (1, figure 5-54) and crosshead (5). Look for contact between pitch change links and yoke assembly. Check bearings for elongated holes, staking, and security; maximum radial play of **0.010** inch, maximum axial play of **0.020** inch. Refer to figure 5-59 for pitch link and crosshead limits.

### NOTE

Pitch change links must be rotated to unworn side, or end to end, whenever pitch change links are worn to maximum limits as a result of crosshead contact.

- **c.** Inspect washer (10) for cracks and general condition for reuse. If in doubt on locking capability, replace.
- **d.** Inspect pitch horn attachment bolt to determine that lockwire does not rub on yoke assembly.
- **e.** Inspect visible portion of trunnion for nicks, scratches, and corrosion.



TYPE OF DAMAGE LOCATION SYMBOLS

### MAXIMUM DAMAGE AND REPAIR DEPTH


0.002 inch for 1/4 circumference

0.010 in. before and after repair	0.030 in. before and after repair
0.005 in. before repair 0.010 in. after repair	0.015 in. before repair 0.030 in. after repair
0.250 sq. in.	0.500 sq. in.
One per tang	Three
0.030	0.060
	after repair  0.005 in. before repair 0.010 in. after repair  0.250 sq. in.  One per tang

206011-287

Figure 5-58. Inspection and Repair Limits — Tail Rotor Hub Yoke

**TRUNNION BORE DAMAGE** 



TYPE OF DAMAGE

NICKS, SCRATCHES, SHARP DENTS

CORROSION

AREA A

MAXIMUM DEPTH

0.010

0.005

NOTES:

- 1. The pitch link may have one repair par end and one on the center section. Minimum radius of repair is 0.500 inch. Repaired areas must be coated with corrosion preventive compound (C38).
- The crosshead may have two repair areas, Repairs must not be on the same lug. Minimum radius of repair is 0.500 inch. Repaired area must be coated with primer, epoxy polyamide (C116) and top coated with acrylic lacquer (C91).
- 3. After repair to the crosshead caused by chafing from the link, fabricate a pad from insulating sheet (C86) to cover repaired area (see detail A). Bond pad with sealing compound (C131). Apply sufficient pressure to assure complete adherance of pad to crosshead. Care must be taken to assure that there will be no interferance between pad and pitch link bearing.
- 4. No cracks are permitted.
- 5. All dimensions are in inches.

Figure 5-59. Inspection Limits Chart — Pitch Link and Crosshead

- f. Inspect visible portion of hub assembly, trunnion, and bearing liners for oil and dirt accumulation, then accomplish the following:
- (1) If oil is flowing or dripping from the output shaft area check oil level and condition of filler cap vent.
- **(2)** Clean accumulated oil from visible portions of the hub assembly in accordance with paragraph 5-194, and continue to operate.
- g. Axial and radial play at the trunnion and thrust bushing found during routine daily inspection is of no concern unless tail rotor vibrations are encountered. Some sliding movement of the thrust bushing in the assembly, slight rotational play between the thrust bushing and trunnion splines, and looseness or rotation of the washer are the result of normal wear and not items of inspection or measurement. There is no requirement to measure axial or radial play in the assembly.

#### NOTE

Inspection for bearing wear is not required except at the specified phased maintenance interval or when troubleshooting; however, loss of preload is not necessarily the cause of vibrations. There is no requirement to adjust tail rotor trunnion preload except at the specified phased maintenance interval.

Wear of the tail rotor trunnion, bearings, and thrust washers is subject to local environment. If excessive unscheduled maintenance from tail rotor vibration is experienced, the frequency of scheduled inspections should be increased.

**5-196.** Removal — Tail Rotor Hub. Remove hub and blade assembly from helicopter in accordance with paragraph 5-183.

### 5-197. Disassembly — Tail Rotor Hub.

- **a.** Remove cotter pin (10, figure 5-60), nut (11), and washers (12).
  - **b.** Remove bushing (13) and bearing liner (14)
- **c.** Remove trunnion (9) from yoke (8) and perform same steps for disassembly of opposite end of trunnion.

**d.** Remove washer (15) and bearing (16) from bearing liner (14), using heat lamp to expand liner.

### CAUTION

When using bearing puller attachments, care should be taken to prevent damage to the trunnion assembly.

**e.** Remove bearing races (26), place sleeve over stud to shield threads. Install puller attachment (T46) under race and use a standard bench press to remove races. Refer to figure 5-5.

### 5-198. Inspection - Tail Rotor Hub.

**a.** Visually inspect all parts for damage or abnormal appearance.

#### NOTE

### Check trunnion serial number for local history.

- **b.** Dimensionally check for indications of permanent deformation or damage to yoke, trunnion, and trunnion bearing housing, as follows:
- (1) Insert a new bolt (1, figure 5-60) completely through yoke bushings to determine if yoke is deformed. Bolt shall be free fitting. Replace entire hub assembly, if yoke fails inspection.
- (2) Inspect trunnion with a straight edge placed along centerline of trunnion, parallel to bearing journals; check for displacement between journals. A bearing surface should not be displaced from the other in excess of **0.001** inch.
- (3) Inspect bearing liner O.D. The O.D. of the cylindrical portion must be round within **0.001** inch.
  - c. Inspect yoke (8) for the following:
- (1) Corrosion and mechanical damage. Refer to figure 5-58 for limits.
- (2) Inspect trunnion bore for fretting and corrosion. Maximum diameter of trunnion bore after cleanup shall not exceed 1.564 inch. An elliptical bore, resulting from damage as described in figure 5-58 is permissible provided maximum diameter (apogee) of ellipse does not exceed the above dimension.




Figure 5-60. Disassembly - Tail Rotor Hub and Blade Assembly

(3) Dimensionally inspect yoke bushing I.D. (eight locations). If I.D. exceeds **0.376** inch, or if fretting or corrosion is present, replace bushings in pairs. Refer to paragraph is 5-200.

### **NOTE**

If the bearing and liner are serviceable, they may be rotated 180 degrees to the unworn side of the teflon bearing and reinstalled during assembly of the hub. Use a vibro-etch to make a mark on the edge of the bearing housing ears. If the tefion bearing had previously been rotated, as evidenced by a vibro-etch marking, replace bearing and liner. Do not interchange bearing location.

- **d.** Inspect teflon liner on thrust bushing assembly (13). Replace bushing if liner is worn through or if severe fretting has occurred.
- **e.** Clean liner (14) with MEK (C107) and inspect teflon bearing liner inside housing for wear-through or severe fretting. Wear usually occurs on one side of teflon liner on the tang end of housing only. Refer to figure 5-61.
- **f.** Inspect outer surface of liner (14, figure 5-60) for mechanical or corrosion damage. Material removal on tangs shall not exceed **0.010** inch and material removal for cleanup on the cylindrical portions shall not exceed **0.015** inch.
- **g.** Inspect trunnion (9) for mechanical and corrosion damage. Replace after **2400** hours.
- (1) Inspect anodized surface for damage (figure 5-62). Reject trunnion if inspection reveals any of the following:
  - (a) Previous repair on anodized surface.
- **(b)** Depth of repair after cleanup exceeds 0.003 inch.
  - (c) Repair area exceeds 0.010 square inch.
- (2) Nicks and dents on stud threads are reparable, provided neither damage nor repair exceeds one-

third of thread depth and all repairs do not total more than one-half of a full thread.

- (3) Inspect trunnion splines; splines may be repaired provided not more than one-third of spline depth or one-half of spline length is exceeded by repair. Reject trunnion if more than three splines are damaged.
- **(4)** Check trunnion stud for security. (If a stud can be moved in the trunnion housing more than 4 degrees with **25 INCH-POUNDS** of torque (using two nuts backto-back) repair trunnion.) Refer to paragraph 5-219,


**h.** Inspect the following parts by fluorescent-penetrant inspection in accordance with TM 55-1500-335-23.


ITEM NO.	NOMENCLATURE
(8, figure 5-60)	Yoke
(4, figure 5-60)	Liner
(9, figure 5-60)	Trunnion
(17, figure 5-60)	Pitch Horn

**5-199.** Cleaning — Tail Rotor Hub. Clean all tail rotor hub assembly parts except teflon bearings with solvent (C62). Dry with clean, dry air. Clean teflon bearings with a clean cloth lightly dampened with MEK (C107).

### 5-200. Repair — Tail Rotor Hub.

- **a.** Repair tail rotor hub yoke in accordance with figure 5-58.
- **b.** Repair tail rotor hub liner bearing housing in accordance with figure 5-61.
- **c.** Repair tail rotor hub trunnion. Refer to paragraph 5-219.
- **d.** Support yoke tangs on a suitable support and press out bushing. (AVIM)
- **e.** Clean out aged primer from bushing hole and apply unreduced primer (C118) to hole in yoke and to O.D. of bushing. Install bushing while primer is wet (bushing flange to face inboard). Ensure that bushing flanges are fully seated (AVIM)





### **TYPE OF DAMAGE**

# DAMAGE LOCATION SYMBOLS MAXIMUM DAMAGE AND REPAIR DEPTH

MECHANICAL DAMAGE	0.010 in. before and after repair	0.015 in. before and after repair
CORROSION	0.010 in. before and after repair	0.015 in. before and after repair
MAXIMUM AREA PER FULL DEPTH REPAIR	0.050 sq. in.	0.250 sq. in.
NUMBER OF REPAIRS	One per ear	Two
EDGE CHAMFER TO REMOVE DAMAGE	0.030 in.	0.030 in.

### NOTES:

- 1. No cracks are permitted.
- 2. No wear through permitted.

Figure 5-61. Inspection and Repair Limits — Tail Rotor Hub Bearing Liner

- f. Insert suitable gage blocks between yoke tangs to compensate for yoke deflection and to maintain 1.120 to 1.124 inch dimension between yoke tangs during reaming operation. Line ream bushings to 0.3750 to 0.3755 inch diameter. Insert a new bolt (1, figure 5-60) through yoke bushings; bolt shall be free fitting. Remove gage blocks. (AVIM)
- g. Rework of yoke assembly (AVIM) is to be accomplished only when required to eliminate interference in the yoke radius area (figure 5-62). Remove only the minimum material to achieve necessary clearance.
- (1) Mark location of interference on pitch horn and yoke.
  - (2) Remove tail rotor blades.

### **NOTE**

Rework of blade pitch bar(s) or yoke assembly or both may be done to relieve interference.

- (3) if interference in yoke radius is minor, chamfer (break) corner of blade pitch horn bar up to **0.060** inch by **45** degrees in locations of contact with yoke chamfer radius, Finish reworked area and smooth all corners to **0.030** inch radius using aluminum oxide abrasive (C45). Touch up reworked areas with epoxy primer (C116),
- (4) Reinstall tail rotor blades and determine if correct clearance can be obtained.
- **(5)** If correct clearance is not obtained, remove and disassemble tail rotor hub assembly.
- (6) Using a straight edge reference, locate and mark where radius intersects 20 degree inner chamfer surface of yoke,
- (7) Rework should not alter the 20 degree flat chamfer surface but should extend the flat surface to relieve interference with blade pitch bar. The rework must extend no farther than necessary to relieve interference and no farther than existing radius, Maintain a minimum of 0.250 inch radius at interface with existing surface(s).

- (8) Remove material in interference area(s) using a half-round file. Do not remove more than 0.035 inch material thickness.
- **(9)** Smooth rework area(s) using aluminum oxide abrasive (C45).
- (10) Temporarily reinstall blade and check that correct contact with blade pitch horn is obtained. Remove blade.
- (11) Touch up reworked areas with chemical conversion coating (C38), and primer (C116).
- (12) Reassembly and install tail rotor assembly.
  - (13) Check rigging.

### 5-201. Assembly — Tail Rotor Hub.

- a. Replace trunnion bearing races (26, figure 5-60). Position race (26) on trunnion (9) with chamfered I.D. of race toward center of trunnion, Press race onto trunnion flush to **0.010** inch below end of trunnion. Repeat on other end of trunnion.
- **b.** Apply zinc chromate primer (C118) to O.D. of bearing (16) and allow to dry. Heat liner (14) with a heat lamp and install bearing in liner. Ensure that bearing seats,
- **c.** Apply solid film lubricant corrosion inhibiting (C100) on O.D. of liner. Install washer (15) (black rubber side showing) in groove of liner (14).
- **d.** Prior to positioning trunnion in yoke, apply chemical coating (C38) to inner diameter of yoke. Position trunnion in yoke (8), then with light finger pressure roll lips of washers (15) outboard and install liner (14) on each end of trunnion.
- e. Install thrust bushing (13) (teflon liner inboard) with nut (11) and washer (12). (One to three washers are required.)
- **f.** Install tail rotor blades in accordance with paragraph 5-246.




Figure 5-62. Tail Rotor Yoke Rework

5-202 Balancing - Tail Rotor Hub and Blade Assembly.

Premaintenance Requirements for Tail
Rotor Hub and Blade Assembly

Notor Hub and Blade Assembly		
Condition	Requirements	
Model Part No. or Serial No. Special Tools Test Equipment Support Equipment Minimum Personnel Required Consumable Materials Special Environmental Conditions	OH-58A and OH-58C All (T41) (T42) (T39) None None One None None	

- a. Set up tool (T41, T39, and T42) to accomplish balance procedures in accordance with TM 55-4920-201-14.
- b. Prior to balancing of tail rotor, ensure washers (23, figure 5-60) are installed on pitch horn (17).

#### **NOTE**

Washers (23) are used as counterweights to compensate aerodynamic pitch forces, do not add or remove washers to achieve balance. Reference Chapter 11, for balance forces - Tall Rotor Control.

- c. Adjust nuts (11) to obtain chordwise balance as follows:
- (1) Back off the nut on the light side; tighten the nut on the heavy side of the tail rotor assembly.
- (2) Maintain rotational preload on trunnion of **20 TO 25 INCH-POUNDS**. No axial play in trunnion permissible.

#### NOTE

To measure rotational preload, fabricate a work aid from 1/2 x 1-1/16 x 5.0 inch brass or aluminum alloy stock as shown in figure 5-60. Position work aid in trunnion, attach a 10-pound pull spring scale to work aid and check preload. Scale should read 5 to 6-1/4 pounds (20 TO 25 INCH-POUNDS rotational preload).

#### NOTE

Use washers (12) as required to obtain alignment of nut slots to cotter pin holes. Maximum of 3 washers allowed under each nut.

- (3) Install cotter pins (21) after chordwise balance is obtained.
  - d. Balance spanwise as follows:

### **CAUTION**

Washer series AN960 and bolts NAS 660631 through NAS 660634 are authorized for all locations. Washer AN 9706 and bolt NAS 130636, are authorized for outboard locations only. The NAS 130636 bolt may contact washer stack-up on pitch horn if used on inboard locations. A maximum of four washers Is authorized for Inboard locations (2 under nut and two under bolt head, or one under nut and three under bolt head). A maximum of six washers is authorized at outboard locations. A minimum of one washer Is always required under nut and one washer Is desired but not mandatory under bolt head when using two washers on any one bolt. At least one full thread of bolt shall be exposed beyond nut. Use minimum length bolt required to ensure only threaded portion of bolt shank is exposed.

### NOTE

Look for interference between pitch horn tangs (ears), balence weights, and yoke assembly. Pitch horn ring bar must contact chamfered inner surface of yoke assembly, either at forward or aft surface of blade assembly. Pitch horn ring bar must not first contact radius at end of machined surface.

(1) Place combinations of washers, (AN 960-616, AN 960-616L and AN 970-6), centered on blade attachment bolts as required to attain balance and to ensure nut does not bottom out on bolt grip. Install bolts with heads from either side but all four blade bolts must be installed from the same side. One method for determining the number of washers to be added or subtracted is to temporarily place the washers on head of bolt until balance is achieved. Prior to installing additional washers on light side of hub and blade assembly ensure excess washers are removed from heavy side. It is advisable to use the same length bolts at corresponding inboard or outboard locations.

### WARNING

Titanium bolts and nuts are no longer authorized for installation on tail rotor hubs. The self-locking feature of the nut destroys the threads on the titanium caries bolt.

- (2) Torque blade bolts with selected balance washers 140 TO 160 INCH-POUNDS.
- (3) Remove balancing tools from tail rotor assembly.

### 5-203. Installation — Tail Rotor Hub.

- **a.** If the tail rotor hub assembly includes the dynamic balance wheel, install the tail rotor hub and blade assembly in accordance with paragraph 5-188.
- **b.** If the tail rotor hub assembly does not include the dynamic balance wheel, install the tail rotor hub and blade assembly in accordance with paragraph 5-189.

### 5-204. TAIL ROTOR PITCH CHANGE MECHANISM.

- **5-206. Description Tail Rotor Pitch Change Mechanism.** The tail rotor pitch change mechanism includes a bellcrank, rod, and lever assembly mounted on the gearbox. The tail rotor pitch change mechanism provides for transferring pitch changes to tail rotor blades.
- **5-206.** Cleaning Tail Rotor Pitch Change Mechanism. Spot clean with naphtha (C22) the control rod (5, figure 5-64). levers (6), idler clevis (25), and Control housing (26).

### 5-207. Inspection — Tail Rotor Pitch Change Mechanism.

- **a.** Inspect for oil leakage around boot and housing to gearbox seal. Inspect boot for cuts, tears, deterioration, and security.
- **b.** Inspect bearings for smooth operation, linkage for ease of operation and mechanism for damage.
- **c.** Inspect for metal-to-metal contact between knurled nut (8), liner (9), and control tube (7, figure 5-54). No metal-to-metal contact permitted.
- **d.** Inspect for excessive rotational looseness of crosshead (5), control tube (7), nut (3), and washer (4). Disassembly inspection of key (16), slot and pin hole in control tube (7) required if movement exceeds **0.200** inch when measured with a dial indicator at approximate center of the head of bolt (20).

### WARNING

There must be no rotational movement between crosshead (5), washers (4), nut (3), and control tube (7). These components must move as an assembly.

**e.** Ensure control housing and trunnion cap assembly are properly sealed.

### 5-208. Removal — Tail Rotor Pitch Change Mechanism.

### **WARNING**

The tail rotor pitch change mechanism must be removed and installed as an assembly, to preclude possibility of damage to components. Alternate procedures will not be used.

- **a.** Remove tail rotor hub and blade assembly in accordance with paragraph 5-183.
- **b.** Remove vertical fin in accordance with paragraph 2-267.
- **c.** Remove cotter pin (15, figure 5-64), nut (4), washer (3), and bolt (1) with washer (2) to disconnect control rod (5) from levers (6).
- **d.** Remove three nuts (27) and washers (28) attaching control housing (26) to tail rotor gearbox.
- **e.** Remove sealing compound at junction of control housing (26) and tail rotor gearbox.
- **f.** Remove pitch change mechanism as an assembly from tail rotor gearbox. Catch pitch key (49) as the tail rotor control tube (37) clears the tail rotor gearbox.
- **g.** To avoid contamination of tail rotor gearbox components and bearings, cover with barrier paper (C26) or equivalent.

### 5-209. Disassembly — Tail Rotor Pitch Change Mechanism.

- **a.** Remove cotter pin (15, figure 5-64), nut (10), washer (9), bolt (7) with washer (8). Remove levers (6).
- **b.** Remove sealing compound at junction of trunnion cap (13) and trunnion (14). Cut lockwire, remove four bolts (11), and washers (12) that attach trunnion cap (13) to trunnion (14). Remove trunnion cap (13).
- **c.** Remove cotter pin (15), nut (16), and washer (17) from control tube (37). Remove control tube (37).
- **d.** Cut lockwire on inboard and outboard locations from boot (18). Remove trunnion (14) with bearing (19)

and remove boot (18).

- e. Remove bearing (19) and seal (20) from trunnion (14).
- **f.** Remove cotter pin (48), nut (24), washer (23), and remove bolt (21) with washer (22). Remove idler clevis (25) from control housing (26).
- **g.** Remove packing (36), retaining ring (29), seals (30 and 32), and bearing (31) from control housing (26). (AVIM)


#### NOTE

Bushings (38) should be removed from control tube (37) for alignment of vent hole or replacement purposes only.

h. Remove bushing (38) from control tube (37).

### 5-210. Inspection — Tail Rotor Pitch Change Mechanism.

- **a.** Inspect levers (6, figure 5-64) for nicks, dents, scratches, and corrosion. Inspect bushings (46 and 45) and bearings (47) for wear or roughness. Refer to figure 5-65 for limits.
- **b.** Inspect trunnion cap (13, figure 5-64) for nicks, dents, scratches, and corrosion. Inspect fitting (40) for damage. Refer to figure 5-65 for limits.
- **c.** Inspect trunnion (14) for nicks, dents, and corrosion; check trunnion spindles for wear. Refer to figure 5-66 for limits.
- **d.** Inspect control housing (26) for nicks, dents, scratches, and corrosion; inspect bolt hole tangs by fluorescent penetrant method. Inspect bearings (34) for roughness. Inspect fitting for damage. Refer to figure 5-66 for limits.
- **e.** Inspect idler clevis (25) for nicks, scratches, dents, and corrosion. Inspect I.D. of bushings. Refer to figure 5-67 for limits.
- **f.** Inspect control tube (37) for mechanical or corrosion damage. Inspect inside each end of control tube to ensure plug corks (39) are installed. Refer to figure 5-68 for limits.



### **DAMAGE LOCATION SYMBOLS**



**TYPE OF DAMAGE** 

MAXIMUM DAMAGE AND REPAIR DEPTH

**MECHANICAL DAMAGE** 

0.003 in. before and after repair

**CORROSION DAMAGE** 

0.0015 in. before and 0.003 in. after repair

MAXIMUM AREA PER FULL DEPTH REPAIR 0.100 sq. in.

0.250 sq. in.

NUMBER OF REPAIRS

One

One per segment

EDGE CHAMFER TO REMOVE DAMAGE

0.003 in.

0.020 in.

SPLINE DAMAGE:

Depth: Length: Number: 1/3 of spline 1/2 of spline Three

THREAD DAMAGE:

Depth: Length: Number: 1/3 of thread 0.025 inch


One per threaded segment

**BEARING LINER DAMAGE:** 

Replace trunnion assembly if scoring or pitting exceeds 0.001 inch depth after cleanup with crocus cloth. No cracking

permitted

Figure 5-63. Inspection and Repair Limits — Tail Rotor Hub Trunnion



- 1. Bolt
- 2. Washer
- 3. Washer
- 4. Nut
- 5. Control Rod
- 6. Lever
- 7. Bolt

- 8. Washer
- 9. Washer
- 10. Nut
- 11. Bolt
- 12. Washer
- 13. Trunnion Cap Assembly
- 14. Trunnion

- 15. Cotter Pin
- 16. Nut
- 17. Washer
- 18. Boot
- 19. Bearing (See note)

Figure 5-64. Tail Rotor - Pitch Change Mechanism ( Sheet 1 of 2 ).






Figure 5-64. Tail Rotor - Pitch Change Mechanism (Sheet 2)






NICKS, DENTS AND SCRATCHES	0.020
CORROSION	0.010
MAXIMUM AREA PER FULL DEPTH REPAIR	*
NUMBER OF REPAIRS	*
EDGE CHAMFER	0.040

\* NOT CRITICAL - LIMITS NOT ESTABLISHED

Figure 5-65. Repair Limtis — Tail Rotor — Pitch Change Mechanism Lever and Cap



<sup>\*</sup> NOT CRITICAL - LIMITS NOT ESTABLISHED




Figure 5-66. Repair Limits — Tail Rotor — Pitch Change Mechanism Housing and Trunnion




Figure 5-67. Repair Limits — Tail Rotor — Pitch Change Mechanism idler Clevis

- **g.** Inspect control tube bushing (38) for wear steps, galling, and fretting. These conditions are not acceptable. Discoloration is acceptable provided area is smooth.
- **h.** inspect pitch key (43) and straight pin (50) for wear or mechanical damage. Refer to figures 5-69 and 5-70 for limits.
- **I.** Inspect tail rotor gearbox lubrication return parts for evidence of dotting.
- **j.** Inspect boot for cuts, tears, holes, and deterioration. Replace boot if it fails to meet inspection criteria.
- **5-211.** Cleaning Tail Rotor Pitch Change Mechanism. Remove sealing compound from cap and trunniom surfaces. Clean all parts with solvent (C62). Dry with filtered compressed air. Do not allow bearings to spin while drying.

### 5-212. Repair/Replacement — Tail Rotor Pitch Change Mechanism (Figure 5-84)

**a.** Replace lever bushings (46 and 45, figure 5-64) that do not meet inspection requirements. Replace lever bearings (47) (AVIM) that are rough or ratchet when turned.

### **NOTE**

If tall rotor pitch change mechanism bushings do not meet Inspection requirements, replace as follows:


- (1) Press out failed bushing. Apply wet unreduced primer (C118) to faying surfaces and install bushing.
- (2) Ream bushing (45) and (46) to **0.2500** to **0.2510** inch diameter after install.
- **b.** Replace trunnion cap (13) that does not meet inspection requirements. Replace fitting (40) when damaged.
- **c.** Replace trunnion (14) that does not meet inspection requirements. Replace trunnion bearing (19) that is rough or ratchet when turned.
- d. Replace control housing (26) that does not meet inspection requirements. Replace housing bearings (31, 33 and 34) that are rough or ratchets when turned. Replace fitting when damaged.

- (1) Press bearing (34), located on the grease fitting side, into the control housing (26) to remove bearing (33).
- (2) Press out bushing (35) and bearing (34) from the removed bearing (33) side of the control housing (26).
- **e.** Replace idler clevis (25) that does not meet inspection requirements. Replace idler clevis bushings (42 and 43) that are worn. Replace bearing (44) that is rough or ratchets when turned.
- **f.** Replace control tube (37) that does not meet inspection requirements. Replace plug corks (38) on each end of tube if deteriorated or missing. Replace control tube bushing (38) if measurable damage is detected on any area of the outer surface.
- **g.** Replace pitch key (46) if it does not meet inspection requirements. Replace straight pin (50) if it does not meet inspection requirements.
- **h.** Replace pitch change boot (18, figure 5-64) that does not meet inspection criteria

#### NOTE

It maybe necessary to remove the vertical fin to obtain clearance to work Refer to paragraph 2-267. Care should be taken when sliding the new boot over trunnion (14) to prevent tearing the boot.

- (1) Remove cotter pin (15), nut (4), washer (3), bolt (1), with washer (2) and disconnect control rod (5) from levers (6).
- (2) Remove cotter pin (15), nut (10), washer (9), bolt (7) with washer (8). Remove levers (6). Cut lockwire on inboard and outboard locations from boot (18). Slide boot over trunnion (14).
- (3) To install the new boot, slide boot (18) over trunnion (14). Lockwire inboard and outboard ends of boot with lockwire (C96). Install levers (6) on trunnion (14) and connect idler clevis with bolt (7), washers (8 and 9), and nut (10). Torque nut (10) 80 TO 90 INCH-POUNDS and install cotter pin (15).
- (4) Connect levers (6) to control rod (5) with bolt (1), washers (2 and 3), and nut (4). Torque nut (4) 80 TO 90 INCH-POUNDS and install cotter pin (15).



### DAMAGE LOCATION SYMBOLS



### TYPE OF DAMAGE

### MAXIMUM DAMAGE AND REPAIR DEPTH

TYPE OF DAMAGE	MAXIMUM DAMAGE AND REPAIR DEPTR			
MECHANICAL AND CORROSION	0.010 in. before and after repair	0.002 in. before and after repair	0.001 in. before and after repair	
MAXIMUM AREA OF FULL DEPTH REPAIR	0.010 in.	1/4 Circumference	Not critical	
NUMBER OF REPAIRS	1/Seg Lg	Not critical	Not critical	
EDGE CHAMFER	0.030 in.	0.030 in.	0.030 in.	
BORES				

1/4 in.


THREADS DEPTH: 1/3 Thread

LENGTH:

NUMBER

Two 206011-296

Figure 5-68. Repair Limits — Tail Rotor – Pitch Change Mechanism Control Tube




NICKS, SCRATCHES, AND DENTS

**NOT CRITICAL - LIMIT NOT ESTABLISHED** 

**MAXIMUM AND MINIMUM WEAR** 

AS PER ILLUSTRATION

Figure 5-69. Wear limits - Tail Rotor - Pitch Change Mechanism Pitch Key



NICKS, SCRATCHES, DENTS, AND PITS NEGLIGIBLE EXCEPT ON END; 0.001 OR LESS AFTER REPAIR MUST BE SMOOTH IN AREA OF CONTACT WITH KEY (NO PRECEPTIBLE DEPTH)

**WEAR - NO PRECEPTIBLE WEAR STEPS** 

Figure 5-70. Wear Limits - Tail Rotor - Pitch Change Mechanism Straight Pin

5-213. Assembly - Tail Rotor Pitch Control Mechanism. (Figure 5-64)

#### NOTE

Ensure hoie in bearing (31, Figure 5-64) aligns with grease fitting In housing (26), and lip of seals (30 and 32) are facing away from gearbox. Ensure ilp of seal (20) faces towards gearbox This will allow purging and prevent grease from being pumped into gearbox.

a. Install bearing (31), and seals (30 and 32), retaining ring (29), and packing (36) in control housing (26).

### **NOTE**

Ensure vent hole in bushing (36) and control tube (37) are ciean and unobstucted.

- b. Apply wet unreduced zinc chromate primer (C118) on faying section of control tube (37) that will mate with bushing (38). While zinc chromate primer is still wet install bushing (38) on control tube (37) and align by insurting a piece of lockwire (C97) into bushing and control tube hole until zinc chromate dries.
  - c. Install control tuba (37) through control housing (26)
- d. Handpack bearing (19), with lubricant (C77) then press bearing (19) into trunnion (14) with etched "V" pointing inboard.

### NOTE

If new bearing (19), P/N 204-011-769-1 is not etched, it may be Installed In either direction.

- e. Install seal (20) in trunnion (14) with seal lip slightly recessed in trunnion.
- f. Install boot (18) on control housing (26) with lockwire (C96). Install trunniion assembly (14) and lockwire to boot (18).
- g. Install washer (17) and nut (16) on control tube and torque nut (16)45 to 65 inch pounds and install cotter pin (15).

#### NOTE

If unable to align cotter pin hole using correct torque (45 to 65 inch pounds), one additional washer (17) may be used.

- h. Install trunnion cap (13) with four washers (12), and four bolts (11), torque bolts (11) to 28 inch pounds and lockwire (C96) in pairs. Apply seating compound (C131) around mating surface slot of trunnion and cap.
- i. Install idler clevis (25) to control (26) with bolt (21), bushing (41), washers (22) and (23), and nut (24). Torque nut (24) 80 to 90 inch pounds and install cotter pin (48).
- j. Install lever (6) on trunnion (14) and attach idler clevis (25) with bolt (7), washers (8 and 9), and nut (10). Torque nut (10) 60 to 90 Inch pounds and install rotter pin (15).
- 5-214. Installation tail Rotor Pitch Change Mechanism. (Figure 5-64)

### Warning

Prior to installing pitch change mechanism ensure cotter pin is installed in the tail rotor output shaft retaining nut. The head of the cotter pin must be Installed from the center of the nut with the head positioned in one of the slots on the output shaft. One tang of the cotter pln shall be bent Inboard and the other bent outboard and cut flush at the edge of the nut.

- a. Install packing (36, Figure 5-64) into control housing (26). Position pitch key (49) into control tube (37) and slide pitch change mechanism assembly control tube into tail rotor gearbox until control housing (26) is completely in place with tail rotor gearbox. Install three washers (28), three nuts (27), and torque to 75 inch pounds
- b. Connect lever (6) to control rod (5) with bolt (1), washers (2 and 3), and nut (4). Torque nut (4) 80 to 90 inch pounds and install cotter pin (15).

- **c.** Clean exterior of control housing (26) and tail rotor gearbox junction with MEK (C107). Apply a bead of sealing compound (C131) to the circumferential junction slot.
- **d.** Install tail rotor hub and blade assembly. Refer to paragraph 5-188.
  - e. Rig tail rotor controls. Refer to paragraph 11-94.

### 5-215.TAIL ROTOR HUB TRUNNION.

- **5-216. Description Tail Rotor Hub Trunnion.** The trunnion, (9, figure 5-60) splined to the tail rotor gearbox shaft, drives the tail rotor hub and blades.
- **5-217.** Removal Tail Rotor Hub Trunnion. Remove trunnion from tail rotor hub in accordance with paragraph 5-197.
- **5-218. Inspection Tail Rotor Hub Trunnion.** (AVIM) Refer to paragraph 5-198 and figure 5-63.

### 5-219. Repair — Tail Rotor Hub Trunnion.

- **a.** Remove grease, oil, etc., by soaking with solvent (C62). Scrub the inboard ends of the stud with a fiber brush (C31) to remove all traces of zinc chromate primer. Thoroughly clean the outboard ends of the stud and lockring joint.
- **b.** Place the trunnion assembly upright under a head lamp, then flood the top stud lockring joint area and the cavity at the inboard end of the bottom stud with primer (C114). Allow primer to penetrate the joint area for approximately 15 minutes. Rotate the trunnion assembly and repeat the procedure.

### **CAUTION**

#### Do not use heat lamp in next operation.

- **c.** Remove heat lamp. Flood the previously primed area with sealant (C120). Allow trunnion to cure overnight before installing in tail rotor assembly.
  - **d.** Refer to figure 5-63 for inspection and repair limits.

**5-220. Installation** — **Tail Rotor Hub Trunnion.** Install the trunnion in the tail rotor hub in accordance with tail rotor hub assembly procedures in paragraph 5-201.

### 5-221. TAIL ROTOR PITCH HORN.

**5-222. Description** — **Tail Rotor Pitch Horn.** The tail rotor pitch horn assembly (17, figure 5-60) transfers pitch change movement to the tail rotor blades.

### 5-223. Removal — Tail Rotor Pitch Horn.

- **a.** Remove tail rotor blade in accordance with paragraph 5-243.
- **b.** Cut lockwire and remove two bolts (19, figure 5-60), and washers (18).
  - c. Remove pitch horn (17).
- **5-224.** Inspection Tail Rotor Pitch Horn. Inspect the tail rotor pitch horn stud for burrs, damaged threads, and for straightness. Ensure that the stud retaining pin is point staked adjacent to the pin hole.
- 5-225. Repair Tail Rotor Pitch Horn.

#### **NOTE**

For pitch horn repair limits refer to figure 5-71.

Polish out nicks and gouges with fine India stone (C84). Blend repair area into surrounding areas.

- **5-226. Installation Tail Rotor Pitch Horn.** Refer to figure 5-60.
- **a.** Assemble bolts (19) and washers (18) in pitch horn.
- **b.** Fill area of pitch horn that mates with blade with sealing compound (C131).
- **c.** Install pitch horn (17) on blade (7) and torque bolts (19) to **30 TO 40 INCH-POUNDS.** Do not lockwire at this time.

- **d.** Apply a smooth coat of sealing compound (C131) to all remaining unpainted surfaces of blade butt adjacent to pitch horn (17). Blend into squeezed out sealing compound around pitch horn.
- **e.** Allow one hour for the sealing compound to setup.

### CAUTION

Ensure that the pitch horn attachment bolt lockwire does not contact yoke.

f. Torque attachment bolt (19) to **30 T0 40 INCH-POUNDS.** and install lockwire (C96).

5-227. TAIL ROTOR HUB AND BLADE ASSEMBLY. (After compliance with MWO 55-1520-228-50-25.)

### WARNING

Parts of the standard tail rotor (before MWO 66-1 620-228-50-26) although similar, cannot be used on the improved tail rotor (after MWO 55-1620-228-50-26). The following parts must always be used together to assure safe operation:

5-228. Description — Tail Rotor Hub and Blade Assembly. The tail rotor hub and blade assembly consists of an aluminum alloy forged yoke and stainless steel blades. The blades are mounted in the yoke by means of spherical bearings which are mounted in the grip plates on the pitch change axis. The spherical bearings provide for pitch change of the blades. The yoke and blade assembly is mounted on the 90 degree gearbox shaft by a splined trunnion, mounted in bearings in the yoke, to provide a flapping axis for the assembly. At the time of assembly, spanwise balance is accomplished by use of washers on the blade retention bolts, and chordwise balance is attained by use of washers on the trunnion bearing housing.

### Premaintenance Requirements for Tail Rotor Hub and Blade Assembly

Condition	Requirements	
Model	OH-58A and OH-58C	
Part No. or Serial No.	All	
Special Tools	(T46) (T44)	
Test Equipment	None	
Support Equipment	None	
Minimum Personnel Required	Two	
Consumable Materials	(C17) (C11) (C38) (C22) (C45) (C37) (C55) (C94) (C62) (C50) (C84) (C77) (C96) (C91) (C102) (C100) (C110) (C107) (C118) (C115) (C143) (C116) (C126) (C154) (C127) (C124) (C131)	
Special Environmental Conditions	None	

### 5-229. Removal - Tail Rotor Hub and Blade Assembly.

- **a.** Remove cotter pins (10, figure 5-72), nuts (8), washers (9), and bolts (16).
- **b.** Remove cotter pins (15), nuts (14), cupped washers (13), and thin washers (12). Remove pitch links (11).
- c. Remove nut (17) and washer (18). Pull crosshead (20) from control tube (26) with the use of a suitable puller (T44). Remove pin (19) from crosshead (20) or control tube (26).
- **d.** Cut and remove lockwire from knurled nut (21) and balance wheel (23). Remove knurled nut (21), liner (7), shims (22), and balance wheel (23). Knurled nut and balance wheel are threaded onto the tail rotor gearbox shaft.
- **e.** Straighten tabs on special washer (5) and remove nut (6). Remove special washer (5), static stop

(4), rubber bumper (3), and shim (2). Discard special washer (5).

# **NOTE**

Shim (2) serves to position static stop (4) and the positioning for tail rotor blade-to-tailboom clearance. If the hub and blades are to be reinstalled, identify the shim during removal for reuse during installation.

- **f.** Slide tail rotor hub and tail rotor blades (1) from the tail rotor gearbox shaft and remove spacer (25).
  - g. Remove pin (28) from control tube (26).

# **NOTE**

Review Overhaul and Retirement schedule in Chapter 1.

# 5-230. Disassembly – Tail Rotor Hub and Blades.

- **a.** Identify mated tail rotor blades (9, figure 5-73) to hub (2) location before removal to ensure correct installation if the same blades and hub are to be reused.
- **b.** Identify each bolt (7 and 8), nut (10), and washers (3, 4, 5, and 6) combinations to each installed location to prevent a possible change in spanwise balance.
- **c.** From one tail rotor blade (9), remove nuts (10), washers (3, 4, 5, and 6), and bolts (7 and 8). Pull tail rotor blade (9) from hub (2), then remove opposite tail rotor Made in the same manner. Bolts, washers, and nuts should be installed in hub or tail rotor blade to ensure correct location and stackup for installation.
- **d.** Refer to paragraph 5-252 for inspection/repair of tail rotor blades.
- 5-231. Disassembly Tail Rotor Hub.

# NOTE

Review overhaul and retirement schedule in Chapter 1 and retire all items scheduled for retirement. If tail rotor hub

is being disassembled for replacement of defective part(s) instead of overhaul, disassemble only to extent necessary to replace defective part(s).

If there is evidence of an accident or incident damage, perform step b. of paragraph 5-233, prior to disassembly of tail rotor hub.

- **a.** Cut lockwire and remove bolts (11, figure 5-74), washers (12), and weights (13) from each side of yoke (1). Weights and extra washers were selected for balance. Tag and secure for use during balance.
- **b.** Remove housings (9) from each side of yoke (1). Thrust plugs (6) and shims (5) may remain in housings or on end of trunnion (3). Remove plugs and shims.
  - Remove trunnion (3) from yoke (1).

# 5-232. Cleaning — Tail Rotor Hub.

a. Clean tail rotor hub parts with solvent (C62).



Cleaning solvents are flammable and toxic. Use only in well-ventilated area. Avoid skin contact and inhalation of vapors. Protect eyes with sefety glasses.



# Do not spin bearings while drying.

- **b.** Dry parts with filtered compressed air and lint-free clean cloths. Remove sealant using a plastic scraper and a cloth dampened with MEK (C107).
- **c.** Remove paint from metal parts using general remover (C110).
- **d.** After parts are cleaned the following corrosion prevention treatment should be accomplished.
- (1) Wash all ferrous parts in a clean rinse of solvent (C62).
- (2) Each part shall be covered with a protective coating of corrosion preventive compound (C50).

# 5-233. Inspection — Tail Rotor Hub.

- **a.** If there is no evidence of accident or incident damage, proceed with normal component repair or overhaul, as required.
- **b.** If there is evidence of accident or incident damage, check for free movement of trunnion in yoke before disassembly.
- **c.** Parts, components, or assemblies found worn or defective beyond reparable limits shall be scrapped.
- **d.** Tolerance and limits set forth in the illustrations for wear and damage limits are the maximum acceptable. Parts exceeding these limits shall be scrapped unless otherwise indicated.

### NOTE

Limit charts are provided to show the required fit between mating parts. It is not intended that all dimensions listed on limits chart be checked as a prescribed overhaul procedure; however, parts that show evidence of wear or physical damage must be checked dimensionally.

- **e.** Inspect parts dimensionally and replace parts that are not within inspection limits. (Refer to figure 5-75).
- **f.** Inspect yoke (1, figure 5-74), trunnion (3), and lousing (9) for mechanical damage and corrosion. Refer to figures 5-75 through 5-78. If seal (7) and bearing (8) removal is necessary from housing (9), remove as follows:
- (1) Fabricate a steel plug 0.750 inch in diameter by 4 to 5 inches long. Ends of plug must be square in relation to the shank in the plug.
- (2) Fill the bearing housing (9) cavity approximately one-half full of high viscosity grease.
- (3) Support the flat portion of bearing housing (9) (grease fitting side) on a suitable flat surface. Position housing so that grease fitting (10) is off edge of surface and will not be damaged.

- **(4)** Insert the fabricated plug into bearing, then strike the plug a sharp blow with a hammer. This will start the bearing (8) moving out of housing. Replenish grease as required so that the plug will not contact the bearing housing base (9).
- (5) Repeat steps (1) thru (4) on opposite bearing housing.
- **(6)** Install serviceable trunnion bearings as indicated in steps (7), (8), and (9).
- (7) Press bearing (8) into bearing housing (9). Press against markings on end of bearing until outer edge of bearing is 0.150 inch below edge of bearing housing.
- **(8)** Press seal (7) into bearing housing (9) with lip of seal facing inboard as installed on hub.
- **(9)** Repeat steps (7) and (8) on opposite bearing housing.
- **g.** Inspect bearing liners (4, figure 5-74), of trunnion (3) for wear. (Refer to figure 5-78 for wear limits.) Replace liner if wear limits are exceeded as follows:
- **(1)** Remove bearing liner (4) from trunnion (3), using a two-jaw puller.
  - (2) Repeat step (1) on other side of trunnion.
  - (3) Install bearing liners (4) as follows:

#### NOTE

To aid in installing bearing liners (4), locally fabricate two trunnion bearing liner plugs and a trunnion centering shaft. (See figure 5-79).

- (4) Install fabricated trunnion centering shaft into trunnion to prevent distortion when pressing bearing liner onto trunnion spindle.
- (5) Apply a film of lubricating oil (MIL-L-46152) to spindles of trunnion (3) and inner liners (4). Apply a heat lamp to inner liners until heated. Position bearing liner (4) on trunnion spindle with large chamfered inner surface of liner facing inboard. (See figure 5-74 view A).

**(6)** Press bearing liner (4) part way onto trunnion spindle. Remove from press and install locally fabricated plug into bearing liner. Press bearing liner onto trunnion (3) spindle until outboard edge of liner is flush with plug.

### NOTE

# Dimension from end of trunnion spindle to outboard edge of bearing liner must be 0.128 to 0.138 inches.

- (7) Reverse trunnion and leave bearing liner plug in place to prevent installed bearing liner from moving while installing opposite bearing liner.
- (8) Using second bearing liner plug as a guide, press opposite bearing liner on trunnion spindle as outlined in steps (4) thru (6).
- **(9)** Clean inboard chamfered edges of bearing liners (4) and trunnion (3) spindle with naphtha (C22). Wipe dry with clean dry cloth before evaporation of naphtha.
- (10) Apply a fillet of sealant (C17) around trunnion spindle to fill void between trunnion (3, figure 5-74) and chamfered edge of bearing liners (4). (See figure 5-74 view A).
- (11) Cure sealant at 150 degrees Fahrenheit (66 degrees Celsius) for 3 hours prior to further assembly.
- **h.** Inspect insert (14, figure 5-74) in yoke (1) for damaged threads and security. Return yoke assembly to next higher level of maintenance if insert (14) is damaged or loose.
  - i. Inspect grease fitting (10) for damage and security.
  - j. Inspect data plate (15) for condition and security.
- **k.** Inspect bushings (2) in yoke (1) for looseness, inside diameter greater than **0.377** inch, fretting, or removal of cadmium plating. If these limitations are exceeded, replace bushings.
- **I.** Inspect the following parts by fluorescent-penetrant inspection in accordance with TM 55-1500-335-23.

ITEM NO.	NOMENCLATURE
(1, figure 5-74)	Yoke
(3, figure 5-74)	Trunnion
(9, figure 5-74)	Housing


#### NOTE

It is not necessary to remove protective coating from trunnion (3) or housing (9) for fluorescent-penetrant inspection.

- (1) Remove polyamide epoxy primer from yoke (1). Refer to paragraph 5-232, step c.
- (2) Fluorescent-penetrant inspect parts. Parts found to be cracked shall be replaced.
  - (3) Clean parts. Refer to paragraph 5-232.
- (4) Prime and paint yoke after all repairs have been accomplished. Refer to paragraph 5-235, step c.

# 5-234. Repair — Tail Rotor Hub.

- **a.** Polish out acceptable damage to housing (figure 5-76) with 400 to 600 grit paper (C126 or C127) or abrasive cloth (C45).
- **b.** Polish acceptable damage to trunnion (figure 5-78) with a fine India stone (C84).
- **c.** Polish out damage on yoke (figure 5-77) that is less than 0.005 inch with 400 to 600 grit paper (C126 or C127) or abrasive cloth (C45). If damage is **0.005** inch or greater return assembly to next higher level of maintenance for repair and shot peening.
- **d.** Apply chemical conversion coating (C38) to all repaired aluminum surfaces. Apply brush cadmium plating solution C94) to all repaired steel surfaces that were previously plated.
- **e.** Touch up repaired areas on previously painted surfaces with one coat of primer (C116) and two coats of acrylic lacquer (C91) in accordance with TM 55-1500-345-23.



	AREA A	AREA B
TYPE OF DAMAGE	MAXIMUM DEPTH	
NICKS, SCRATCHES, SHARP DENTS	0.010	0.030
CORROSION	0.005	0.015
NATES.		

- 1. Area A may have one repair area. Minimum radius of repair is 0.050 inch.
- 2. Area B may have one repair area on each side of the center cross piece. Minimum radius of repair is 0.350 inch.
- The shank of pitch horn stud should not be damaged in excess of what can be cleaned up with crocus cloth (C55). Damage and subsequent cleanup on the stud threads must not exceed 1/3 OF THE THREAD DEPTH. A maximum of 2 threads may be damaged.
- 4. Repaired areas of surfaces A and B must be coated with primer (C115) and top coated with acrylic lacquer.
- 5. All dimensions are in inches.

206011-299

Figure 5-71. Inspection and Repair Limits — Tail Rotor Pitch Horn




Figure 5-72. Tail Rotor Hub and Blade Assembly - Removal/Installation.




Figure 5-73. Tail Rotor Hub and Blade Assembly – Disassembly/Assembly (After compliance with MWO 55-1520-228-50-25)

- 1. Yoke
- 2. Bushing
- 3. Trunnion
- 4. Liner Inner
  - 5. Shim
  - 6. Thrust Plug
  - 7. Seal
  - 8. Bearing Needle
  - 9. Housing Assembly
  - 10. Grease Fitting
  - 11. Bolt (2 Reqd)
- 12. Washer Steel (8 Maximum)

  - 15. Data Plate





Figure 5-74. Hub Assembly - Disassembly/Assembly (After compliance with MWO 55-1520-228-50-25)




NO.	DESCRIPTION	LOCATION	MIN	MAX
1	Bushing	I.D.	0.375	0.377
2	Yoke - Housing Bore	I.D.	1.375	1.376
3	Trunnion - Splines (Between 0.045 inch diame	nter pins) /1.D.	0.952	0.954
4	Housing	I.D.	0.999	1.000
•	O.D.	1.373	1.374	

NOTES: 1 Use pins with one side ground flat to provide clearance between pins and root of spline teeth.

2 All dimensions are in inches.

206011-303

Figure 5-75. Tail Rotor Hub Wear Limits




206-001-814 HOUSING

# **DAMAGE LOCATION SYMBOL**

		7/////2
TYPE OF DAMAGE	MAXIMUM DAMAGE AND REPAIR	R DEPTH
MECHANICAL	0.010 in. before and after repair	NONE
CORROSION	0.010 in. before and after repair	NONE
MAXIMUM AREA PER FULL DEPTH REPAIR	0.200 sq. in.	NONE
NUMBER OF REPAIRS	Not critical	NONE
EDGE CHAMFER	0.020 in.	N/A
	2	206011-304

Figure 5-76. Needle Bearing Housing Damage Limits







Figure 5-77. Yoke Damage Limits



# 206-011-812 TRUNNION WITH SLEEVES INSTALLED

# DAMAGE LOCATION SYMBOL $\otimes$

TYPE OF DAMAGE

MAXIMUM DAMAGE AND REPAIR DEPTH

**MECHANICAL** 

0.005 in. before and after repair

None

CORROSION

0.005 in. before

None

and after repair

**SPLINES** 

Depth - 1/3 Length - 1/2


Number - 3

# NOTES:

 $/1\$  Spline surfaces-nicks and scratches not exceeding 0.005 in. in depth and/or 10 percent of the surface area may be removed by polishing. No pitting allowed on splines.

206011-305

Figure 5-78. Trunnion Damage Limits



- f. Replace damaged or loose grease fitting (10, gure 5-74). Refer to paragraph 5-235, step a.
- g. Replace loose or damaged data plate (15) as llows:
- (1) Record data from damaged data plate. tamp data on replacement data plate using 1/8-inch naracters.
  - (2) Remove damaged data plate from yoke (1).

Cleaning solvents are flammable and toxic. Use only in well-ventilated area. Avoid skin contact and inhalation of vapors. Do not direct compressed air near or directly against skin. Protect eyes with safety glasses.

- (3) Clean area to be bonded.
- (a) Remove old adhesive using cheesecloth (C37) saturated with MEK (C107).

- **(b)** Abrade area to be bonded, lightly using sandpaper (C124).
- **(c)** Clean mating surface of replacement data plate (15) with cheesecloth (C37) saturated with naphtha (C22). Dry parts with cheesecloth.
- **(4)** Mix adhesive (C11) 100 parts A to 22 parts B, using wooden paddle.
- **(5)** Apply adhesive within 30 minutes after mixing, to mating surfaces of yoke (1) and data plate (15)
- **(6)** Place data plate on yoke and fair out adhesive. Adhesive should extend approximately 1/16-inch past the edge of data plate on all sides. Edge voids are not permitted.

# WARNING

Cleaning solvents are flammable and toxic. Use only in well-ventialated area. Avoid skin contact and inhalation of vapors. Do not direct compressed air near or directly against skin. Protect eyes with safety glasses,

- (7) Remove excessive adhesive with cheesecloth (C37) moistened with MEK (C107).
- (8) Apply firm contact pressure and cure adhesive for 24 to 72 hours at 70°F (21°C) or 1 hour at 180°F (83°C).

# 5-235. Assembly - Tail Rotor Hub.


- **a.** Press new grease fittings (10, figure 5-74) in housings (9), as required.
  - **b.** install trunnion (3) in yoke (1) as follows:
- (1) Insert trunnion (3) into yoke (1) and position shims (5) on end of trunnion with thrust plug (6). Apply corrosion preventive compound (C50) to faying surfaces of yoke and housing during final assembly. Install housings (9) into yoke (1) over inner liners (4) on trunnion (3). Use care not to damage seals (7). Loosely install bolts (11) and steel washers (12) to secure housings (9).

- (2) Install fabricated trunnion center shaft (figure 5-79) into trunnion (3) and secure with washer and bolt.
- (3) Establish a pinch fit on trunnion (3) by adding or subtracting shims (5) to obtain a **0.000** to **0.002** inch clearance between the underside of flange on housings (9) and mating surface on yoke (1). Shim both housings.
- (4) Remove fabricated trunnion shaft from trunnion.
- (5) Install weights (13), steel washers (12), and bolts (11) into yoke (1). Torque bolts 30 TO 40 INCH-POUNDS and secure with lockwire (C96).
- **(6)** Purge and lubricate needle bearings (8) at grease fittings (10) with grease (C77) until grease clears seals (7). Remove excess grease and wipe yoke clean with cloths.
  - c. Prime and paint hub as follows:
- (1) Mask all bushings, splines, grease fittings, and data plate with masking tape (C143).
- (2) Treat bare aluminum surfaces with chemical conversion coating (C38).
- (3) Refinish with one coat of primer (C116) and two coats of acrylic lacquer (C91), color No. 36440. Remove masking tape.
- 5-236. Assembly Tail Rotor Hub and Blades.



Cleaning solvents are flammable and toxic. Use only in well-ventilated area. Avoid skin contact and inhalation of vapors, Protect eyes with safety glasses.

**a.** Immediately prior to assembly, clean parts with solvent (C62) and hand-pack bearings with grease (C77). Do not handle or assemble parts which are not lubricated.




MATERIAL: 4130 Steel (MIL-S-6758).

AN5-4A Bolt and AN970-5 Washer. Heat treatment or finish not required.

USE: For centering trunnion in yoke.

TRUNNION CENTERING SHAFT



MATERIAL: 4130 STEEL (MIL-S-6758)

TRUNNION BEARING LINER PLUG FOR TAIL ROTOR HUB ASSEMBLY (206-011-810)

Figure 5-79. Work Aid — Trunnion Centering Shaft and Trunnion Bearing Liner Plug

#### CAUTION

Tail rotor blades must be installed as matched part number pairs only, (IAW para 5-227)

- **b.** Identify tail rotor blades (9, figure 5-73) for correct positioning into hub (2). Also identify bolts (7 and 8), washers (3, 4, 5, and 6), and nuts (10) for correct positioning.
- **c.** Position tail rotor blades (9) into tangs of hub (2) with stud of pitch horn adjacent to trunnion. Align bolt holes in bearings with bushings (1) in hub (2) at both ends.

### NOTE

Ensure indexed parts and washers are reinstalled in original position to prevent change in spanwise balance. The four blade retention bolts may be installed from either side, but all four bolts must be installed from the same side.

- **d.** Install two bolts (7 and 8) with one washer (3) under each bolt head adjacent to yoke and one under each nut(10). Additional washers (4, 5, and 6) to be installed at time of static balancing unless identical parts are being installed in their original positions.
- e. If balancing is not required, torque nuts (10) 150 **TO 175 INCH-POUNDS.**

# NOTE

Balancing is required when tail rotor blades are changed, repaired, trunnion adjustment made, or other causes which may affect balance of the tail rotor hub and blade assembly.

**f.** Balance tail rotor blades. Refer to paragraph 5-238.

# 5-237. Installation — Tail Rotor Hub and Blade.

**a.** Install spacer (25, figure 5-72) agianst shoulder on tail rotor gearbox shaft.

# CAUTION

Ensure that pin (28) goes through hole in key (27) and remains in position until tail rotor hub and blade (1) and static stop (4) are positioned on gearbox shaft.

- **b.** Align pin hole in gearbox shaft with a slot in control tube (26) and hole in key (27). Install pin (28),
- **c.** Align splines in gearbox shaft and tail rotor hub and blade. Install tail rotor hub on gearbox shaft with leading edge of top tail rotor blade facing aft as shown.
- **d.** Install shim (2), static stop (4), special washer (5), and nut (6). Torque nut (6) **580 INCH-POUNDS.**

#### NOTE

Do not install rubber bumper (3) or bend special washer (5) until correct flapping angle and tailboom clearance have been obtained as outlined in following step e.

- **e.** Adjust tail rotor hub and blade (1) for correct flapping angle as follows:
- (1) Position tail rotor hub and blade (1) in vertical position and check flapping angle along pitch change axis. The pitch change axis is an extension of a line through the centers of the tail rotor blades to the attachment bolts.
- (2) Flap tail rotor hub and blade (1) to one extreme position until tail rotor hub contacts static stop (4). Place protractor adjacent to blade attachment bolts; measure and record angle. Flap tail rotor hub and blade (1) to opposite extreme position until tail rotor hub contacts static stop (4); measure and record angle.
- (3) The total flapping angle must be 18 to 19 degrees. If angle is not correct, refer to step (4).

# NOTE

If flapping angle is less than 18 degrees, use larger shim. If flapping angle is more than 19 degrees, peel off shim laminates.

(4) If necessary, to obtain 18 to 19 degrees flapping, adjust thickness of shim (2). Use only

bonded laminates of shim (2). If a thicker shim is required, use a new shim Laminates of shim are **0.002** inch.

- **f.** After correct flapping angle has been achieved, accomplish the following:
- (1) Remove nut (6), special washer (5), and static stop (4).
- (2) Install rubber bumper (3), static stop (4), special washer (5), and nut (6). Insert lockwire (C96) into special washer (5), but do not tighten lockwire at this time.
- (3) Torque nut (6) 580 INCH-POUNDS and bend one edge of special washer (5) inboard over one flat of static stop (4). At another location, bend one edge of special washer (5) outboard over two flats of nut (6). Refer to detail A.

# CAUTION

Exceeding torque of 50 INCH-POUNDS will strip the thread in the balance wheel.

g. Thread balance wheel (23) onto tail rotor gearbox shaft against nut (6). Torque balance wheel to a maximum of 50 INCH-POUNDS.

# CAUTION

Use only knurled nut P/N 206-010-759-3 (0.875 inch overall length) on helicopters with the balance wheel.

- **h.** Install liner (7) and knurled nut (21). Hand tighten nut onto gearbox shaft. Adjust shim (22) clearance as follows:
- (1) Measure the clearance between balance wheel (23) and knurled nut (21). Record measured clearance.
- (2) Adjust thickness of shim (22) to equal measured clearance to within **0.002** inch. Shims (22) are **0.002** inch laminates with total thickness of **0.032** inch Do not exceed a maximum of 10 shims.

- (3) Install measured shims (22), liner (7), and knurled nut (21). lighten knurled nut (21) hand-tight only on gearbox shaft.
- i. Install pin (19) in outboard end of control tube (26) and install crosshead (20) over control tube and pin. Check for proper location of pin (19) by inserting a piece of lockwire into groove at back of crosshead (20).
- **j.** Install washer (18) and nut (17) on outboard end of control tube (26). Torque for nut (17) will be drag torque plus **125 INCH-POUNDS.**
- **k** Install pitch links (11) between crosshead (20) and studs on pitch horns (24), as follows:
- (1) Connect pitch links (11) topitch horns (24) with thin washers (12), cupped washers (13), and nuts (14). Torque nuts (14) **50 TO 60 INCH-POUNDS.**
- (1) Connect pitch links (11) to crosshead (20) with bolts (16) (heads indirection of rotation), washers (9), and nuts (8). Position washers under head of bolts and under nuts. Torque nut (8) 80 TO 100 INCH-POUNDS. Install cotter pin (10).
- **I.** Check pitch change mechanism for freedom of movement with pedals through full operating range.
- **m.** Check tail rotor hub and blades (1) for freedom of movement at flapping axis. Check tail rotor blade bearings for freedom of movement.
- **n.** Check rigging of antitorque control system Refer to Chapter 11.
- **o.** Check tail rotor hub and blade for correct tailboom clearance as follows:
- (1) Turn tail rotor hub and blade (1) to position one blade tip adjacent to tail boom. Hold right tail rotor pedal full forward against stop. Flap tail rotor hub and blade (1) towardtailboom until tail rotor hub contacts static stop (4).
- (2) The trailing edge of the tail rotor blade must clear tailboom at closest point by at least 1.500 inch

- (3) If clearance is not within tolerance accomplish following steps:
- (a) Remove items installed in steps f. through k.
- **(b)** Accomplish procedures speafied in step e. (1) through e. (3). Adjust shim to minimum 18 degree flap.
- (c) Install items specified in steps f. through k.
- **(d)** Accomplish preceding steps o. (1) through o. (3).
- **p.** Secure knurled nut (21) to balance wheel (23) and then secure balance wheel to speial washer (5) with lockwire (C96). Refer to detail B.
  - q. Install cotter pins (10 and 15).
- **r.** Balance tail rotor hub and blade assembly. (Reference para 5-255).

# 5-238. Balancing — Tail Rotor Hub and Blade Assembly.

# Premaintenance Requirement for Tail Rotor Hub and Blade Assembly

Condition	Requirements
Model	OH-58A and OH-58C
Part No. or Serial No.	All
Special Tools	(T41) (T42) (T39)
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	One
Consumable Materials	(C96)
Special Environmental Conditions	None

**a.** Set up tool (T41), (T42), and (T39) to accomplish balance procedure in accordance with TM 55-4920-201-14

b. Prior to balancing of tail rotor, ensure washers (31, figure 5-72) are installed on pitch horn (24).

### NOTE

Washers (23) are used as counterweights to compensate aerodynamic pitch forces, do not add or remove washers to achieve balance. Reference Chapter 11, for balance forces- Tall Rotor Control.

- c. Balance tail rotor hub and blades chordwise as follows:
- (1) Use combinations of weights (13, figure 5-74) and washers (12) as necessary to obtain chordwise balance.

# **NOTE**

Adjustment of chordwise balance will also affect spanwise balance. If necessary, temporarily place washers on yoke to balance spanwise so accurate chordwise readings may be obtained.

(2) Remove bolts (11) from housing (9) and yoke (1) of tail rotor hub and install weight and/or washer combinations under boltheads until chordwise balance is achieved.

# NOTE

Ensure at least one washer (12) remains under head of each bolt (11) after balancing is achieved.

- (3) Use NAS 1304-2H through NAS 1304-8H bolts (11) as required to secure weight/washer combinations. Ensure a minimum of 0.250 inch thread engagement of bolt.
- (4) Torque bolts (11) 30 TO 40 INCH-POUNDS and secure with lockwire (C96) after tail rotor hub and blades are removed from balance tools.
- d. Balance tail rotor hub and blades spanwise as follows:

# **CAUTION**

Washer series AN960 and bolts NAS 660631 through NAS 660634 are authorized for all locations. Washer AN 9706 and bolt NAS 130636, are authorized for outboard locations only. The NAS 130636 bolt may contact washer stackup on pitch horn if used on inboard locations. A maximum of four washers Is authorized for inboard locations (2 under nut and two under bolt head, or one under nut and three under bolt head). A maximum of six washers is authorized at outboard locations. A minimum of one washer is always required under nut and one washer is desired but not mandatory under bolt head when using two washers on any one bolt. At least one full round of bolt thread shall be exposed beyond nut. Use minimum length bolt required to ensure that only the threaded portion of bolt shank is exposed.

- (1) Balance assembly spanwise by using combinations of AN960-616 (6, figure 5-73), AN960-616L (5), AN 970-6 (4), and MS9482-12 (3), washers on tail rotor blade bolts. As a minimum, one MS9482-12 (3) washer must be used under head of each bolt and nut. Use Bell Standard P/N 20-057-6-34 or 20-057-6-36 bolt (7) and 20-057-6-34, 20-057-6-36, 20-057-6-38, or 20-057-6-40 bolt (8) as required to accommodate washer combinations.
- (2) Torque nuts (10) on blade bolts (7 and 8) **150 TO 175 INCH-POUNDS.**

# **NOTE**

Do not rotate trunnion 180 degrees after static balance procedures. Balance and trunnion centering will likely not be the same due to manufacturing tolerances of trunnion.

### Section VI. TAIL ROTOR BLADES

**5-239. TAIL ROTOR BLADES**. (Prior to compliance with MWO 55-1520-228-50-25).

### NOTE

Refer to paragraph 5-248 if MWO 55-1520 - 22850-25 has been complied with.

**5-240. Description - Tail Rotor Blades**. The tail rotor blades are constructed of aluminum alloy and are mounted in the tail rotor yoke assembly by means of spherical bearings. The bearings permit pitch change of the blades.

# Premaintenance Requirements for Tail Rotor Hub and Blade Assembly

Condition	Requirements
Model	OH-58A and OH-58C
Part No. or Serial No.	All
Special Tools	(T23) (T24) (T25) (T26)
Test Equipment	None
Support Equipment	Spray paint equipment
Minimum Personnel Required	Two
Consumable Materials	(C13) (C69) (C124) (C19) (C21) (C22) (C143) (C42) (C38) (C39) (C90) (C92) (C51) (C107) (C116) (C93) (C126) (C128) (C120) (C45) (C61) (C127) (C88) (C123)
Special Environmental Conditions	None

**5-241.** Cleaning — Tail Rotor Blades. To maintain a protective coating when operating in humid salt laden air, clean blades with a dishwashing compound (C61) and water, and dry with clean cloth. Apply an even coat of nonsilicone wax. Do not polish.

5-242. Inspection — Acceptance/Rejection Criteria — Tail Rotor Blades.



Tail rotor blade tips will be inspected for corrosion around rivets; tip blocks will be inspected for cracks and/or debonding.

# NOTE

Any damage in excess of that noted is cause for blade replacement. Refer to figure 5-80 for repair limits.

- **a.** Skin inboard of station 23.0. Inspect for nicks, scratches, and dents as follows:
- (1) Nicks and scratches running within 0 to 15 degrees of the spanline are not to be in excess of 0.006 inch depth and shall be polished out.
- (2) All other nicks and scratches are not to be in excess of 0.004 inch depth and 1.000 inch long and shall be polished out.
- (3) Sharp dents which do not break the skin or remove metal from the blade and are not in excess of **0.010** inch depth and **0.500** square inch in area are permissible.
- (4) Nonsharp dents which are not in excess of 0.030 inch depth and 0.200 square inch in area are permissible.
- **b.** Skin outboard of station 23.0. Inspect for nicks, scratches, and dents as follows:
- (1) All nicks and scratches are not to be in excess of **0.010** inch deep and shall be polished out.
- (2) Sharp dents which do not break the skin or remove metal from the blade, and are not in excess of 0.030 inch depth and 0.200 square inch in area are permissible.
- (3) Nonsharp dents not in excess of **0.060** inch in depth and **1.000** square inch in area are permissible.



Dents should be inspected closely for nicks, scratches, and cracks. Nicks or scratches in dents in excess of limits listed above are cause for blade replacement.

c. Inspection of tail rotor blades for cracks




Figure 5-80. Repair - Tail Rotor Blade

# **NOTE**

Cracks are not acceptable on the tail rotor blade. Any crack is cause for blade replacement.

- (1) Visually inspect entire blade for cracks.
- (2) Inspect both sides of blade in an area approximately 7.000 inches outboard from butt end and 1.500 inches aft of the leading edge. Blades with serial number TLL-8000 and below must be subjected to very critical inspection using 10-power magnification in this area, with complete evaluation of any paint cracks.

# NOTE

Blades with serial numbers starting with TLW are considered above aerial number TLL-8000.



Do not use chemical strippers on blades.

Do not attempt to strip entire blade. This procedure is intended only for small areas of suspected cracks and for the critical area defined in (2), above. Where the critical area has been left clear for inspection, do not use abrasive.

Do not strip proactive primer undercoating from blades.

(3) If cracks are found which may be paint cracks, remove outer layers of paint with MEK (C107) and/or 180 to 400 grit sandpaper (C124, C125, and C126). All sanding must be done in a spanwise

direction only. Remove outer (color) layer of paint only. Do not attempt to remove primer coatings (yellow layers). Evaluate cracks to determine if further work is required. If cracks are still suspected or if cracks are evident in the primer coating in the critical area defined in preceding step (2), or if primer coatings are removed to expose metal, request assistance from AVIM.

- d. Inspection for cracks in critical area (AVIM).
- (1) Suspected cracks which may be only paint cracks and cracks which extend through the primer coatings in a critical area 7.000 inches outboard from the butt end and 1.500 inches aft of the leading edge may be evaluated by removing all paint coatings in the suspected area.
- (2) Blade primer coatings are resistant to chemical removal and the blade adhesive bonds may be damaged by removers. Remove primer by sanding in a spanwise direction only, using 180 to 400 grit sandpaper (C124, C125, and C126). Top coatings may be removed using the coarser grades of abrasive. Succeeding layers near the metal surface must be removed with finer grades. If possible, do not remove chemical film treatment (light grey or clear) from the blade skin. Do not remove any material from the blade skin.
- (3) After removal of paint coatings, inspect area to determine if the suspected cracks are in the metal. Use 10-power magnification and/or dye penetrant or fluorescent penetrant. Refer to TM55-1500-335-23.
  - (4) Reject all cracked blades.
- (5) Treat all bare metal surfaces of serviceable blades with chemical film (C38). See paragraph 5-247.
- (6) On blades with serial number TLL-800 and below, to aid in subsequent inspection, do not apply color coats and primer to a 2-inch diameter area centered 7.000 inches outboard of the butt end and 1.500 inches aft of the leading edge on both sides. To prevent corrosion, paint this area with clear lacquer (C90).
  - (7) Touch up all other areas. See paragraph 5-247.
- **e.** Trailing edge. Scratches, nicks, or dents in the trailing edge should be inspected to the same limits as the same damage to the skin.
  - **f.** Abrasive strip.

# NOTE

if the abrasive strip is worn or cut through, ripped or has bean displaced, the blade should be replaced.

- (1) Dents in the abrasive strip inboard of station 13.0 in excess of **0.006** inch are not acceptable at the extreme leading edge radius.
- (2) Other dents in the abrasive strip should be inspected to the same limits as dents in the skin.
- **g.** Voids under abrasive strip. Voids are not allowed within **0.250** inch of trailing edge and **0.500** inch of inboard and outboard ends of the abrasive strip except as allowed in following steps h. and i. below. Not more than **15%** of all remaining areas of the abrasive strip shall be void.
- h. Voids at the trailing edge of the shell. A void of **0.120** inch maximum side (chordwise) or a minimum of **0.380** inch wide (chordwise) of solid bond is allowed. There shall be no edge voids.
- i. Voids between the shall and the root end retention block.
- (1) Avoid 0.250 inch wide (maximum) at the leading edge is acceptable provided it is sealed. The aft edge of the void must be within 0.150 inch of extreme leading edge of the blade.
- (2) A void (or gap) 0.120 inch wide (chordwise) between the shell and retention block at the trailing edge is acceptable provided it is sealed.
- (3) Edge voids are not allowed between the shell and the retention block except as specified substeps (1) and (2) of this paragraph.
  - **i.** Voids between the shell and tip block.
- (1) A void 0.250 inch wide at the leading edge is acceptable provided it is sealed. The aft edge of the void must be within 0.015 inch of the extreme leading edge of the blade.
- (2) A void (or gap) 0.120 inch wide (chordwise) between the shell and the tip block at the trailing edge is acceptable provided it is sealed.

### 5-243. Removal — Tail Rotor Blades.

### **NOTE**

Hub assembly must be removed from helicopter prior to blade replacement.

- **a.** Index blades as to which side of yoke they are installed in. Ensure that each of the blade retention bolts, nuts, and washers are identified so they can be reinstalled in original positions to prevent change in spanwise balance.
- **b.** Remove two blade-to-yoke bolts (1, figure 5-60) and remove blade from yoke. Remove opposite blade in same manner.

### **NOTE**

If tail rotor blade is to be replaced. remove the pitch horn and reinstall on the new Made.

**5-244.** Inspection — Tail Rotor Blade Bearings, Inspect tail rotor blade bearings for axial and radial play. Axial play must not exceed **0.010** inch. Radial play must not exceed **0.006** inch.

# 5-245. Repair — Tail Rotor Blade Bearings. (AVIM)

- Remove blade from hub.
- **b.** Remove tail rotor blade bearings as follows:
- (1) Place bearing over a suitable support. (See detail A, figure 5-81.)
- (2) Press bearing and sleeve from blade using punch (T23) and pilot (T24).
- (3) Inspect hole in blade for nicks or scratches. Nicks or scratches not exceeding **0.003** inch in depth are acceptable if polished out to original surface finish.
- (4) Strip paint locally around bearing holes and apply chemical film (C38) to bare metal.
  - (5) Determine bearing location.

#### **NOTE**

The following procedure is required to ensure that bearings are properly installed in relation to the chord line. Perform the following inspection with blade identification plate facing up.

- **(6)** Position two supports (T25) on a level surface table. Position the blade holes over the supports (T25) and clamp blades to table. (See detail B of figure 5-81.) Use light pressure on clamp so as not to deflect the blade.
- (7) Mount a dial indicator on a height gage, Measure the height at the high point of blade contour at two locations; 0.500 inch and 22.500 inches from blade tip. Ensure that blade is not defective at the 0.500 inch reading. Record readings and location at which reading was taken.
- **(8)** Subtract the two readings; then divide by 11. This is the quantity of shims (T26) required for use in tool (T20) for bearing location.

### NOTE

If the tip of the blade is lower than the root end, the shims will be used for installing the inboard bearing. If the blade tip is higher than the root end, the shim will be used for locating the outboard bearing.


- (9) Remove clamp tool from blade.
- c. Install new bearings and sleeves as follows:



Sleeve and bearing should be inserted by hand pressure only. Freedom of movement is essential for proper sleeve and bearing location. If required, the sleeve may be sanded lightly to obtain a slip fit.

# NOTE

Only bearings of the same part number are to be installed in any one blade.







Figure 5-81. Replacement - Tail Rotor Blade Bearing (Sheet 1 of 2)






Figure 5-81. Replacement — Tail Rotor Blade Bearing (Sheet 2)

(1) Sand sleeve I.D. with sandpaper (C126). Remove grit residue and apply a coat of unreduced zinc chromate primer (C118) to the blade hole. Install sleeve in blade.

# CAUTION

Retaining compound will pick up contamination and it is mandatory that the compound be kept out of the bearing. Staking of the bearing sleeve shall be performed within 30 minutes after compound application.

- (2) Using a cotton swab soaked in retaining compound (C120) apply a generous amount to sleeve I.D. and bearing race O.D. Install bearing in sleeve,
- (3) Carefully wipe off excess compound to prevent spread to other surfaces.
- (4) Install correct quantity of (T26) shims in base.

# **NOTE**

If shims are used for bearing location, ensure that bearing and sleeve are installed in the correct hole to compensate for a low or high blade tip.

- **(5)** Install housing in a drill press. Set speed for 250 to 350 rpm. Position base under housing.
- (6) Position blade on the base assembly with identification plate facing up. Ensure that blade is seated level on the base. Align bearing bore with pilot pin and roller-stake the sleeve (one side only). Apply rollers of tool to sleeve in about 10-second increments. After each 10-second increment, inspect for correct displacement of sleeve into chamfered edges of bearing race and housing. Refer to figure 5-81, detail D.
- (7) Remove the base and position the base assembly (T21) under the housing. Position the bearing over the base (staked end next to base) and roller-stake the sleeve.

- (8) Install sleeve and bearing in the outer blade hole, following substeps (1) through (7).
- **(9)** Inspect each end of staked sleeves for proper staking.
- (10) Check staking dimensional requirement shown in detail D, figure 5-81.
- (11) Ensure that chamfer on bearing outer race and blade bore is completely filled with staked sleeve.
- (12) Check for looseness of the bearing to sleeve and sleeve to blade. No looseness is permitted.
- (13) Check for overstaking. Insert a 6-inch bar or tube in bearing. Attach pull scale to end of tube and move bearing inner race. Force required to move bearing shall not exceed a 1-pound pull.
- (14) If force required to move bearing exceeds one-pound pull, the bearing may be burnished by spinning at 60 to 100 rpm for one to two minute periods until a satisfactory pull force is obtained. Do not allow bearing to overheat.
  - d. Check bearing alignment as follows:
- (1) Clamp blade to a level surface. Check to ensure that bearing ends are parallel to surface table.
- (2) Install two bolts in the two threaded holes located in the blade root end. Place a bubble protractor on the bolt and level blade chordwise.
- (3) With dial indicator installed on a height gage, measure the high point of contour at **0.500** inch and **22.500** inches from the tip of the blade. Subtract the two readings and record the result.
- (4) Turn blade over and repeat substeps (1), (2), and (3).
- (5) Add the two readings found in steps (3) and (4), and divide by two. Then divide this result by 11. If the final number is greater than **0.008** inch, bearings should be reinstalled in accordance with steps b. through d. with new sleeves.

5-246. Installation — Tail Rotor Blades.



Inspect all tail rotor blades, including new blades, for cracks prior to installation.

# NOTE

As an aid to blade installation, a work aid may be fabricated per figure 5-82 from 0.020 inch aluminum alloy sheet to hold the bearings in alignment.

### **NOTE**

Due to manufacturing processes the tail rotor yoke tangs may be arched open or closed slightly and still be acceptable. If they are closed, they may be opened to accept the blade by inserting a smooth rounded end 0.375-inch diameter rod into each outboard bushing. Apply sufficient force to open the tangs wide enough to accept the blade.

- **a.** Prior to installing blade into yoke apply corrosion preventive compound (C51) to inner race I.D. of bearings (20). If not previously accomplished, install pitch horn assembly, then position rotor blade in yoke (8, figure 5-60) with pitch horn adjacent to trunnion. Refer to paragraph 5-226.
- **b.** Install two bolts (1), washers (2,3,4, and 5) and nuts (6). Torque nuts **140 TO 160 INCH-POUNDS.**

# NOTE

Ensure indexed parts and washers are reinstalled in original position to prevent change in spanwise balance. The four blade retention bolts may be installed from either side, but all four bolts must be installed from the same side.

**c.** Check feathering action of tail rotor blade in the yoke. Force required to move the blade shall not exceed **2-pounds** pull on a **6-inch** arm from centerline of bearings. If more, check for bearing and hub alignment, out of round bolts, and deformed yokes.

**d.** Look for interference between pitch horn tangs (ears), balance weights, and yoke assembly. Pitch horn ring bar must contact chamfered inner surface of yoke assembly, either at forward or aft surface of blade assembly. Pitch horn ring bar must not first contact radius at end of machined surface.

# 5-247. Painting — Tail Rotor Blades,

- **a.** Lightly sand the paint around polished areas using sandpaper (C126).
- **b.** Mask off bearings and the inboard **1/8-inch** of blade.
- **c.** Brush bare areas with chemical conversion coating (C38) or keep bare areas wet with 10% solution of chromic acid (C39) for five minutes.
- **d.** Rinse with clean water and check for a smooth unbroken surface film of water. If water breaks, dry, clean, and reapply chemical conversion coating.
- **e.** Apply one light coat of primer (C116) and allow to air dry for **30** minutes. Spray only those areas which are being refinished.


# **NOTE**

If primer is allowed to dry longer than two hours, finish coat of lacquer will not adhere.

- **f.** Apply a coat of acrylic lacquer (C92) or (C93) color to match surrounding paint.
  - **g.** Remove masking from bearings and blade.
- h. If a fast paint cure is desired, air dry for one hour followed by oven dry for one hour at 180° to 190°F (82° to 88°C).

# 5-248. TAIL ROTOR BLADES (After compliance with MWO 55-1520-228-50-25.)

**5-249. Description** — **Tail Rotor Blades.** The tail rotor blades are all metal assemblies consisting of a stainless steel shell reinforced by a honeycomb filler and stainless steel leading edge abrasive strip. Two spherical bearings are installed in an aluminum alloy retention block to provide for pitch change movement of the blades in the tail rotor hub. The improved tail rotor blades are **1.500** inches longer than previous aluminum blades to provide increased tail rotor thrust.



- **FABRICATION INSTRUCTIONS:**
- 1. Punch marks for the cutout holes are punched 0.375 from the bottom and 0.500 from the side. After the holes are cut, file bottoms of holes.
- 2. To fabricate aid, use 0.020 inch aluminum alloy sheet.
- 3. All dimensions are in inches.

206011-308

Figure 5-82. Work Aid — Tail Rotor Blade Installation

**5-250. Cleaning** — **Tail Rotor Blades.** The following cleaning procedures should be accomplished each week, or more frequently if deemed necessary, to prevent corrosion and extend tail rotor blade service life.

# **WARNING**

Cleaning solvents are flammable and toxic. Use only in well-ventilated area. Avoid skin contact and inhalation of vapors. Protect eyes with safety glasses.

- **a.** Wipe tail rotor blades clean with naphtha (C22) or solvent (C51).
- **b.** Wash tail rotor blades with a mild detergent soap cleaner (C42). Rinse with clean water and wipe dry with clean cloths.
- **c.** Wax tail rotor blade surfaces with wax. Do not use silicone type waxes, as waxes may interfere with future repairs or refinishing.
- **5-251. Removal Tail Rotor Blades.** Refer to paragraph 5-230.
- 5-252. Inspection Tail Rotor Blades.

# **WARNING**

If a crack exists in any location, the blade shall be replaced. All dents shall be closely inspected for nicks, scratches, and cracks. If nicks or scratches exist in dents and the total depth is in excess of that permitted in steps a.(2), a.(3), b.(2), and b.(3) the blade shall be replaced. Loose rivets shall be cause for tail rotor blade replacement.

- a. Skins inboard of station 23. (Refer to figure 5-83.)
- (1) Nicks and scratches running within 0 to 15 degrees of a line parallel to the leading edge and not in excess of 0.004 inch in depth shall be polished out.
- (2) Nicks and scratches running within 15 to 90 degrees of a line parallel to the leading edge and not in excess of 0.003 inch in depth shall be polished out.
- (3) Sharp dents in the skin which do not break the skin or remove the metal, except in the area of the

retention block which are not in excess of **0.010** inch in depth, are permissible.

- (4) Nonsharp dents in skin, except in area of the retention block which are not in excess of **0.030** inch in depth are permissible.
  - b. Skins outboard of station 23.
- (1) Nicks and scratches which are not in excess of 0.004 inch in depth shall be polished out.
- (2) Sharp dents which do not break the skin or remove metal and are not in excess of **0.060** inch in depth are permissible.
- (3) Nonsharp dents, which are not in excess of 0.090 inch in depth are permissible.
  - c. Abrasive Strip.

# **NOTE**

If abrasive strip is cut through, ripped, or has been displaced to cause an abrupt discontinuity, the blade shall be scrapped.

- (1) Dents in the abrasive strip, inboard of station 13.0 in excess of **0.006** inch are not acceptable at the extreme leading edge radius.
- (2) Other dents in the abrasive strip should be inspected to the same limits as dents in the skin. (Refer to steps a. and b.)
- **d.** Scratches, nicks, or dents in the extreme training edge **0.100** inch deep or iess shall be polished out over a distance of at least **1.000** inch each side of the damage.
- (1) Inspect blade tip for loose, missing, damaged or corroded rivets.
- (2) If defects are found, inspect tip per paragraph 5-252e and repiace affected rivets prior to further operation.
  - e. Void Limits
- (1) Voids are not allowed within **0.250** inch of the trailing edge and within **0.500** inch of the inboard and outboard ends of the abrasive strip, except as





Figure 5-83. Tail Rotor Blade



# NOTE

INSTALL REPLACEMENT RIVETS WITH WET EPOXY POLYAMIDE PRIMER

Figure 5-83.1 Tail rotor blade rivet installation

allowed in substeps (3) and (4) below. If more than **15%** of the remaining area of the abrasive strip is void, the blade shall be scrapped.

- (2) At the trailing edge of the shell a void 0.120 inch maximum in width (chordwise) is allowed. Edge voids are not acceptable.
- **(3)** Voids between the shell and the root end retention block.
- (a) A void 0.250 inch wide (maximum) at the leading edge is acceptable provided it is sealed.
- **(b)** A void (or gap), 0.120 inch wide (chordwise) between the shell and the butt block at the trailing edge, is acceptable provided it is sealed.
- **(c)** Edge voids are not allowed between the shell and the retention block except as specified in preceding substeps (1) and (2).
- (4) Voids between the shell and tip block. Inspect for voids by tapping with large coin or tapping hammer. Limits for voids between the shell and tip block are as follows:
- (a) Avoid (or gap) 0.250 inch wide (chordwise) at the leading edge is acceptable but shall be sealed. Seal with adhesive (C19).
- **(b)** Avoid (or gap) **0.120** inch side (chordwise) between the shell and the aft end of the tip block is acceptable but shall be sealed. Seal with adhesive (C19).
- **(c)** With the exception of substeps (a) and (b), voids between the shell and the tip block that are visible at the tip are unacceptable.
- **(d)** Any voids in excess of these limitations shall require replacement of the blade.
- **(e)** Any movement of the tip block outboard of the shell shall require replacement of the blade.
  - (5) Voids between root end doubler and skin.
    - (a) Edge voids are not allowed.
- **(b)** Voids not exceeding **0.500** inch chordwise and 1.000 inch spanwise are acceptable provided **0.250** inch good edge bond exists.
- **f.** Inspect bearings in tail rotor blades for excessive wear or damage. Maximum axial looseness of bearing not to exceed **0.015** inch **(0.190** inch movement at tip) provided no increase in airframe vibrations are encountered.

### NOTE

The 0.190 inch movement at tip measurement is provided as a reference only, and

cannot be measured accurately on the aircraft. Tail rotor blade bearing wear will be indicated by a high frequency vibration.

- **5-253. Repair Tail Rotor Blades.** Repair tail rotor blades in accordance with paragraph 5-245 and as follows:
  - **a.** Seal and bond voids as follows:
- (1) Edge voids under the abrasive strip shall be sealed with adhesive (C13).
- (2) Porosity in the bond line at trailing edge of the shell shall be sealed with adhesive (C19).
- (3) Voids between the shell and the root end retention block shall be sealed with adhesive (C19).
- (4) Voids between the shell and tip block shall be sealed with adhesive (C19).

# **WARNING**

Replacement of blade tip rivets is a flight safety critical task. Rivets are special titanium columbium alloy — No substitution permitted. Corrosion or mechanical damage to the tip rivet holes is cause for blade rejection.

- **b.** Replace defective or missing tip rivets per fig. 5-83.1. Inspect completed repair. If tip block is cracked or tip skin distorted, the blade is not acceptable.
- **c.** Polish out nicks, scratches, and corrosion as follows:
- (1) Mask bearings and inboard edge (1/8-inch) of blade with masking tape (C143).

# WARNING

Cleaning solvents are flammable and toxic. Use only in well-ventilated area. Avoid skin contact and inhalation of vapors. Protect eyes with safety glasses.

- (2) Degrease repair area with naphtha (C22).
- **(3)** Using cloth pads soaked in MEK (C107), strip finish from repair area. Do not remove primer from surface except in areas where the primer is cracked, deteriorated, corroded, or otherwise appears damaged. Remove primer as follows:
- (a) Remove primer in these areas down to bare metal using abrasive cloth (C45) or 180 grit or finer paper (C124 through C127).

#### TM 55-1520-228-23

- (4) Polish out reparable nicks, scratches, and corrosion with abrasive cloth (C45) or 400 grit paper (C126). Polish in spanwise direction.
- (5) Wash area with dishwashing compound (C61). Rinse thoroughly with dean running water. Achieve an unbroken film of water on the surface. Air dry surface.
- (6) If corrosion was present on the aluminum butt block, apply a generous amount of alcoholic phosphoric solution (C21), using a dean cloth or brush. Rub briskly for approximately 40 to 60 seconds.
- (7) Rinse area thoroughly with clean running water and wipe dry with clean cloth.

### NOTE

From completion of Substeps (7) and (8), and until application of final paint finish, surface or repaired area are not to be handled.

- (8) On all bare areas of the aluminum butt block surfaces apply chemical conversion coating (C38).
- (9) If protective paint finish is not to be applied immediately, recommend surface be covered with paper and secured with masking tape (C143).

# **CAUTION**

# Do not use chemical strippers on blades.

- d. Prime tail rotor blades. Refer to paragraph 5-247.
- e. Apply a coat of acrylic lacquer (C88 or C89); color to match surrounding area.

**5-254. Installation - Tall Rotor Blades**. Refer to paragraph 5-236.

# **SECTION VII. TRACKING PROCEDURES (ALL MODELS)**

5-255. TRACKING AND BALANCING ROTOR BLADES AND TROUBLESHOOTING OTHER ROTATING ELEMENTS USING VIBREX 4591 SYSTEM.

5-256. Description. VIBREX 4591 System.

### NOTE

If Vibration Analyzer System test set is used, refer to TM 1-6625-724-13&P.

- a. The VIBREX 4591 system may be used to electronically track and balance main and tail rotor blades and troubleshoot other rotating elements. See Figure 5-84 for view of VIBREX system components.
- b. Description and specifications of the VIBREX 4591 system are presented in Figure 5-85. Using synchronized STROBEX, track is visually displayed by rotor rip Targets. One-per-revolution vibration is measured from an accelerometer mounting laterally on the airframe to indicate conditions of main rotor balance. Another accelerometer, mounted vertically in the front cockpit, reads vertical vibration from out-of-track. The BALANCER

meter indicates amount, and the PHAZOR shows location of the required correction, when interpreted by the Track and Balance charts. Tail rotor balancing is done by mounting an accelerometer near the tail rotor gearbox. Amplitude of vibration is read from the BALANCER meter to indicate the amount of weight change required, and the STROBEX, triggered by the BALANCER, shows Clock Angle that tells where to put the weight. Tail rotor balance charts interpret these readings. To locate sources of vibration other than the rotors, the accelerometer is relocated and the BALANCER filter is tuned to the peak vibration levels. The rpm rate of these vibrations is related to a known component rpm to identify the offending element.

- c. Track and Balance charts, checklist and dock angle corrector tell what to do to rotor, in response to reading from BALANCER, to correct track or balance.
- d. MAGNETIC PICKUP, bracket, and cable are mounted on stationary swashplate of main rotor. MAGNETIC PICKUP delivers an electrical pulse that serves as a trigger for the STROBEX for main rotor tracking, and as a phase reference for the phase meter in the BALANCER.





Figure 5-84. VIBREX 4591 System Components and Carrying Case





#### **MAGNETIC PICKUP**

MAGNETIC PICKUP switch is set to COMMON for all helicopter work, so that both accelerometer inputs are referenced to the same magnetic pickup pulse from the main rotor swashplate. INDEPENDENT is used only if two MAGNETIC PICKUPS are used as on left and right props of an airplane. Then the left accelerometer is compared to the left MAGNETIC PICKUP, and right to right.

# VERIFY TUNE, RPM RANGE AND RPM TUNE.

The heart of the BALANCER is its tuneable electronic bandpass filter. The accelerometer senses not only the one-per-rev of the rotor being worked, but all other vibrations as well. These might be from other rotors, nriper-rev (where n q number of blades), shafts, gears, bearings, engine, etc. The BALANCER filter is tuned, by means of the RPM RANGE switch and RPM TUNE dial, to the one-per-rev of the rotor being worked. The subsequent sections of the BALANCER (measuring amplitude and phase) then deal only with the one-per-rev, all other rates having been electrically rejected.

Tuning of the electronic, bandpass filter, to the exact rotor RPM is accomplished by simple manipulation of the VERIFY TUNE button and RPM TUNE dial. Tuning is important and instructions a refound elsewhere in this TM and on the track and balance charts.

The filter is stagger-tuned which means it has a broad top and sharp skirt characteristic. This gives it considerable tolerance for rpm variation of the ship, while retaining good rejection of other, unwanted, vibration signals. When the VERIFY TUNE button is pushed, the filter is switched to a normal, or sharp peak, configuration. This property is used as a part of the tuning procedure, and for troubleshooting.

### **TROUBLESHOOTING**

If there is an unknown vibratory disturbance, an accelerometer is mounted in the area where the disturbance is felt. Then the RPM TUNE dial is slowly turned until the meter peaks (reads maximum). It is best to peak the meter with the VERIFY TUNE button depressed, because the filter is sharper. The RPM, or vibration rate, of the disturbance is then read directly from the RPM TUNE dial (and RPM RANGE switch).

It is obvious that if the meter reads near zero, there is no vibration, at the indicated rate, of the point to which the accelerometer is attached.

Knowing the vibration rate, the source of the disturbance can usually be located, keeping in mind that it might be shaft rate, blade rate, or multiples thereof, or gear clash rate, etc.

#### **ACCELEROMETER**

Senses vibration from out-of-track or out-of-balance rotors and parts.

# **MAGNETIC PICKUP**

Triggers STROBEX and provides phase reference for PHAZOR

#### STROBEX RECEPTACLE

# **28 VDC POWER**

# **ACCELEROMETER INPUTS**

Channels A and B are identical, but are used as described only to establish a convention and avoid careless errors. These accelerometer inputs are also used for troubleshooting vibrations, in which case the accelerometer may be placed wherever the vibration is felt. Then the RPM TUNE dial is adjusted until the meter peaks, and the RPM (rate) of the disturbance is read directly from the dial.

Channel A accelerometer, typically used to measure lateral one-per-rev for main rotor balance.

Channel B accelerometer, typically used to measure vertical one-per-rev for main rotor track adjustment. Also used for tail rotor balancing.

206900-563-1

PHAZOR RING OF LIGHTS

This is a phase meter which measures the clock angle between the rotor azimuth angle, derived from the MAGNETIC PICKUP, and the oscillating accelerometer


signal. This clock angle, plotted on the chart, tells where to change weight or pitch link to smooth the rotor.

NOTE

#### MAGNETIC PICKUP INPUTS

Magnetic pickup signal from swashplate assembly is used to trigger STROBEX when FUNCTION switch is set to TRACK, and as a rotor azimuth reference against which the clock angle of the accelerometer signal is measured, when FUNCTION switch is set to A or B.

This MAGNETIC PICKUP receptacle is used when two pickups are in use, as for left and right propellers of an airplane.



# **IMPORTANT**

o'clock lights to light.

signals are disconnected and the MAGNETIC PICKUP signal is fed into itself. This causes the 12:00 and 6:00

The 12:00 and 6:00 o'clock lights must be seen or PHAZOR is not ready to use.

206900-563-2

Figure 5-85. Balancer and STROBEX Description (Sheet 2)

# TRIGGER SWITCH

Turns dc power on and off.

#### STROBEX CABLE

Plugs into STROBEX receptacle of BALANCER

### **STROBEX**

The STROBEX TRACKER, MODEL 135 M-11, is a small, hand-held, lightweight point source strobe lampdesigned especially for helicopter blade tracking and balancing, both on-the-ground and in flight. It is used to illuminate retro-reflective targets secured to blade tips for tracking, or on the tail rotor blade grips for balancing. By virtue of the point source narrow, extremely bright, beam it can be used effectively day or night, in all kinds of weather, including bright sunlight.

The 135 M-11 STROBEX TRACKER is used with a 177 M-6A BALANCER for tracking and balancing. It may also be used as a conventional speed measuring strobe, in which case the rpm of shafts, rotors and accessories maybe read directly.

The 135 M-11 STROBEX has a trigger in the pistol grip handle for dc power switching, a five position mode switch, and a 10-turn RPM dial to adjust the flash rate.

Positions A, D, and E operate at low intensity, and to high flash rates, and B and C operate at higher intensity (about 4 times), but to lower maximum flash rates. The lower intensity is adequate for viewing the reflective targets on all but the biggest helicopters in any kind of daylight.

The five modes of operation are:

A — When set to A the STROBEX operates a slave mode, flashing only when commanded by the BALANCER, and is used for main rotor tracking and tail rotor balancing.

The rotating swashplate is fitted with two interrupters (one of which is double because of the PHAZOR). When the BALANCER is set to TRACK the STROBEX will flash twice-per-revolution, illuminating each of the two blade tips when they pass in front of the helicopter (and also when they pass over the tail boom). Thus, the two tip targets will be seen, superimposed, at the front of the helicopter. (They can also be seen over the tailboom, but this is not useful except forground tracking). Since one tip target has a reflective horizontal bar, and the other has a vertical bar, the judgment of track is simple. The reflective targets face inboard so they are viewed from the cabin, either on-the-ground or in flight.

When an accelerometer is secured on the tail rotor gearbox, and connected to the channel B input, and the

BALANCER is switched to B, the STROBEX will flash once-per-rev in response to the vibration signal induced by the out-of-balance rotor.

When a reflective target, secured to the rotor hub, is viewed from a distance with the STROBEX, the target will appear stopped at some angle. This is the clock angle to be entered on the balance chart, and will tell where to change weight.

B — Position B is also used for main rotor tracking where higher intensity light is required. The unique locking oscillator of position B is typically used for the larger rotors with multiple (4 50 angle) blades. In those cases only one single interrupter is secured to the rotating swashplate and the oscillator causes the STROBEX to flash for the other blades. By fine adjustment of the STROBEX RPM control, the blades may be spread for easy resolution

When applied to the two blade rotor systems (BELL), where two interrupters are installed on the swashplate, position B is used for greater light output. The oscillator is set to flash at a rate slightly slower than blade rate (in accordance with the formula on the back of the STROBEX, RPM = blade rate X 0.4).

Then, the interrupter commands the STROBEX before the oscillator, and it operates as if there were no oscillator. In this case, the targets cannot be spread.

The oscillator may beset to double the blade rate, in which case the tip targets will be seen at twice as many positions around the rotor disc. For instance; the target of a two blade rotor are typically seen at 12:00 and 6:00 o'clock (as determined by location of interrupters). If the oscillator is set to double the blade rate, the taigets will also be seen at 3:00 and 9:00 o'clock.

C — This is a free-running oscillator, and is used as a tachometer for speed (rpm) measuring. All external signals are disconnected, and the STROBEX flashes only in response to its internal oscillator. Flash rate is adjustable from 100 to 1,000 rpm (flashes-per-minute).

D — This is also a free-running oscillator, and is used for tail rotor tracking as well as speed measuring. Since there is no MAGNETIC PICKUP mounted on the tail rotor, the flash rate of the free-running oscillator is adjusted to double, or four times, the rotor rate (for a two-blade tail rotor), so the single grip target appears as a stopped image of two or four. Then, by viewing the rotor disc edge-on from the cabin door, reflective tip targets can be seen superimposed for a judgment of track. Flash rate from 1,000 to 10,000 RPM.

E — This is a locking oscillator, like B, but operates at higher rates, and is used for viewing the track of airplane propellers. Requires a MAGNETIC PICKUP input pulse.

206900-563-3

Figure 5-85. Balancer and STROBEX Description (Sheet 3)

- **e.** Accelerometers, accelerometer bracket, and cable. Accelerometers sense the vibration induced by rotors, shafts, fans, bearings, gears, etc.
- **f.** Tip targets are mounted, one on each main rotor blade tip; used for viewing main rotor track.
- **g.** VIBREX tester is used for functional test of the VIBREX 4591 system.
- **h.** STROBEX blade tracker is used for tracking both main and tail rotors, and for measuring clock angle when balancing tail rotors.
- i. Gram scale is used for weighing balance weights.
- **j.** Carrying case is utilized for storing all the equipment.
- **k.** interrupters, two are mounted on the rotating swashplate of the main rotor, 180 degrees apart. Each time an interrupter passes the MAGNETIC PICKUP, an electrical pulse is generated in the pickup. These pulses cause the STROBEX to flash twice-perrevolutiom to illuminate reflective targets on the blade tips for visual tracking.
- **I.** One of the interrupters is double, delivering a double pulse from the MAGNETIC PICKUP, once-per-revolution. This serves as the needed one-per-revolution phase reference signal for the PHAZOR section of the BALANCER.
- **m.** The BALANCER/PHAZOR unit measures amplitude and phase, or clock angle, of the vibration induced by rotors and other components that are out-of-balance or track.

# 5-257. General Notes.



Do not plug the VIBREX 4591 into 110-volt power. The instruments may be damaged. Do not set BALANCER RPM TUNE dial below 100. The circuits are unstable and the readings useless.

- **a.** There are two basics which MUST be understood and mastered to utilize the system effectively:
- (1) Tuning of the BALANCER bandpass filter. This procedure is spelled out in detail and takes but little practice. Follow the instructions carefully.
- (2) A good grasp of the charts. It is important to know the direction in which the move line should go in response to a certain change on the rotor. The Move Line is the line connecting the data points before and after a change on the rotor. Only then can it be determined whether the chart is matched to the helicopter being worked. Chart examples are given, with explanations.
- **b.** It is normal operation for the clock angle to become uncertain and erratic as balance is improved. A "jittery" clock angle is generally an indication of a good balance.
- **c.** When the BALANCER is first plugged in (or power applied), the meter will deflect to full scale for a few seconds. This is normal, and the meter is protected so no damage results.
- **d.** Do not change the connector on the BALANCER DC cable. Use dc adapter No. 3140-9 which is a foot-long cable with a connector atone end to mate with the BALANCER connector, and a connector at the other end to mate to the helicopter.
- **e.** When tracking rotor blades, look directly over top of STROBEX when viewing retro-reflective targets. Those who are sitting or standing to the side of the user will see the targets very dimly, or not at all, because the reflected light returns to the source and not to the observer to the side.
- **f.** A RULE-OF-THUMB: As long as a good clock angle can be measured in the PHAZOR, or with the STROBEX, the balance or track can, and should, be made better. When balance is perfected to the point where the clock angle becomes too unsteady or erratic, it can no longer be determined where to put the weight, and the job must be considered complete.
- g. It may not be possible to achieve a satisfactory ride over a wide speed and load range due to differences in rotor blade characteristics. These differences in flight characteristics are usually revealed when working track with the vertical accelerometer.

- h. Focus of the flash tube in its parabolic reflector is essential. Periodically shine the light on a wall 10 to 20 feet distant and check for a bright spot 1 to 2 feet in diameter. If this is not seen, focus in accordance with instructions in TM 55-4920-243-15.
- (1) "IPS" or maximum velocity as the object passes through the center of its vibratory motion. Knowing frequency, or rpm, this can be related to displacement (roils) or G force (G) as follows:

G (peak) = 
$$\frac{\text{"IPS" x RPM}}{3686}$$

(2) When the filter is properly tuned, there should be no change in either clock angle or "IPS" when the VERIFY TUNE button is pushed. The accelerometer is sensitive only along its cylindrical axis. If shaken radially, it will have little or no output.

# 5-258. Track and Balance Charts.

- a. The charts are the computers that are used to plot the measurement of vibration (clock angle and amplitude) obtained from the BALANCER/PHAZOR (The STROBEX is used to measure clock angle in the case of tail rotors.) The main rotor charts tell the weight or sweep required to balance the main rotor, pitch link, or tab required to track it. Tail rotor charts show amount and location of weight needed to balance.
- **b.** A different chart is provided for each rotor of each helicopter type. A chart (figure 5-86) consists of:
- (1) A clock face (12 radial lines) representing clock angle, or location of the vibration.
- (2) A set of 10 concentric circles representing "IPS", or amplitude of vibration, drawn over the clock face, with zero at the center and 1.0 "IPS" at the outside.
- (3) A graph over the clock face and "IPS" circles, whose axis are geometrically related to the points at which rotor changes (weight, sweep, pitch link, or tab) can be made.

c. The intersection of "IPS" circle and clock angle line defines a point on the charts. From this point, lines to the axes of the graph show amount and location of change or adjustment to accomplish track or balance. The objective is to reduce the vibration to the lowest possible level, or the center of the chart. Clock angle is not important, except as a means of getting there (it tells where to make the change). Low "IPS" (vibration) level is the only important consideration.

# 5-259. MAIN ROTOR CHART EXAMPLES AND CORRECTIONS.

# NOTE


Take balance readings only when blades are in-track.

# 5-260. Reading A Main Rotor Balance Chart (Figure 5-87).

- **a.** Assume a reading of 10:00 o'clock and and 0.6 "IPS",
- **b.** Plot this on the chart, labeling it point No. 1. Sketch lines to the two axes on the chart.
- **c.** The chart calls for about 60 grams in the BLANK BLADE BOLT, and for sweeping the TARGET blade aft about 1 point (1/12th turn),
- **d.** The first move should involve only one change. Weight should be selected, because it is further from the zero line and calls for the greater change.
- **e.** If the move were perfect, the next reading should be at 12:00o'clock and about 0.3 "IPS". Label this point No. 2.
- **f.** Now, a change of 1 point aft on the TARGET blade should reduce the lateral vibration to near zero, Label this point No. 3,

# NOTE

Observe that when weight is added to a blade, the Move Line should be parallel to the weight arrow along the edge of the chart. If sweep is changed, the Move Line should be parallel to sweep axis arrows.



- NOTES:
- 1. Set tabs at trail. Adjust for good track at 100%, flat pitch, on the ground using pitch link only.
- Set BALANCER to 354 RPM. Push TEST button and check that the 12:00 and 6:00 O'Clock lights are lighted. Release button.
- Observe Clock Angle of lighted light, then press Verify Tune button. Adjust RPM Tune dial WHILE BUTTON IS PUSHED to return lights to angle observed BEFORE BUTTON WAS PUSHED. Release button, observe angle, press and adjust again to match new unpushed angle. Repeat until there is no change WHETHER BUTTON IS PUSHED OR RELEASED.
- Record Clock Angle and IPS in section A of chart. Plot to B (label it No. 1). Note indicated changes in C.
- Make changes indicated. Run ship to check result (label it point No. 2). Repeat as required to reduce IPS to 0.2 or less.
- If move line (point No. 1 to No. 2) is not in the correct direction, use Clock Angle corrector No. 3597, and assign new numbers to clock. SEE MANUAL FOR DETAILS.





Figure 5-86. A Main Rotor Balance Chart

					Date Seria	l No:					
			1st	Run	2nd	Run	3rd	Run	4th	Run	5th Rur
		TRACK ach mode									
Α	Clock	k Angle	10:0	00	12:	00	12	:00			
		PS''	0.0	6	0.	3	0	.05			
•	C MOVE	Grams in Blade Bol Grams in Blade Bo	lt Blank	68 (	gms						
		Sweep T Blade Af	-			1 p	oint				]
		Sweep B Blade Af									

- NOTES:
- 1. Set tabs at trail. Adjust for good track at 100%, flat pitch, on the ground using pitch link only.
- Set BALANCER to 354 RPM. Push TEST button and check that the 12:00 and 6:00 O'Clock lights are lighted. Release button.
- Observe Clock Angle of lighted light, then press Verify Tune button. Adjust RPM Tune dial WHILE BUTTON IS PUSHED to return lights to angle observed BEFORE BUTTON WAS PUSHED. Release button, observe angle, press and adjust again to match new unpushed angle. Repeat until there is no change WHETHER BUTTON IS PUSHED OR RELEASED.
- Record Clock Angle and IPS in section A of chart. Plot to B (label it No. 1). Note indicated changes in C.
- Make changes indicated. Run ship to check result (label it point No. 2). Repeat as required to reduce IPS to 0.2 or less.
- If move line (point No. 1 to No. 2) is not in the correct direction, use Clock Angle corrector No. 3597, and assign new numbers to clock. SEE MANUAL FOR DETAILS.



206011-310

Figure 5-87. Reading a Main Rotor Balance Chart

### NOTE

It can be seen that if weight were subtracted from the TARGET blade, it would have exactly the same effect as weight addition to the BLANK. The blade bolts should always be checked, and weight subtracted whenever possible.

5-261. Working With A Helicopter That Does Not Match the Chart (Incorrect Clock Angle) (Figure 5-88). It is very seldom that a chart needs to be corrected, but an explanation of its simplicity is important. The dynamic response (vibration characteristics) of one helicopter of a given type may not be exactly the same as another. This can cause the vibration of the airframe to occur at a different time (or different phase) in response to a given pitch link or weight change. Thus, the helicopter does not match the chart. It is easy to correct the chart. The process is described here:

- **a.** Assume the same reading of 10:00 o'clock and 0.6 "IPS". Label it point No. 1.
- **b.** Make the same 60 gram weight addition to the BLANK blade, as indicated.
- **c.** This time, however, assume the next reading is 12:00 o'clock and 0.6 IPS. Label it No. 2.

## **NOTE**

The Move Line between points 1 and 2 correctly shows a change in sweep (although the amount is not quite correct). The problem, though, is that if the points are traced back to the sweep axis, a change is indicated there, too. THIS CANNOT BE CORRECT. BECAUSE NO CHANGE WAS MADE TO SWEEP.

**d.** Thus, clock angle corrector No. 3597 must be used to make the chart "match" the helicopter as follows:

### **NOTE**

It is not necessary to be concerned about the length of the Move Line because it is quite obvious that too great a change will cause too long a Move Line, etc. DIRECTION of the Move Line is the big concern.

- (1) Place eyelet A of Clock Angle corrector on the first reading.
- (2) Rotate the body of corrector so line A-O lies in the direction move line should have gone (parallel to the weight arrow along the edge of the chart).
- (3) Swing index A-B in the direction the move line did go.
- **(4)** Read the required correction to the clock angle on the chart, and assign new numbers to the clock. In this case, it says to subtract one hour.
- **(5)** Replot points No. 1 and No. 2, on the renumbered clock. Label the new points No. 1 a and No. 2a.

### NOTE

Observe that the new move line No. 1a and No. 2a, is now parallel to the arrow associated with weight change.

- (6) It can be seen that only 30 grams should have been added, and that 1-3/4 points of sweep will be required instead of the 1 originally called for.
- (7) Try both changes at once and see if point No. 3a is right.

# NOTE

Make all subsequent plots on the corrected clock. If there are questions about the validity of the corrected clock, make a substantial change to one blade only. Then, verify that the move line, as a result of that change, is correct (parallel to the arrow associated with the blade change).

If subsequent moves are erratic and inconsistent (appearing to require a different clock angle correction each time), the trouble is probably due to faulty rotor bearings, linkages, dampers, etc. Look for the problem.

# 5-262. READING THE TAIL ROTOR CHART (FIGURE 5-89).

### **NOTE**

The OH-58 must be fitted with balance wheel; Bell Part Number 206-011-716-1 (NSN 1615-00-482-2539). This is a wheel with 12 holes for addition and subtraction of bolts, nuts, and washers for balance weight changes. Some of the older OH-58 models may not yet have this wheel.

The tail rotor chart is used in the same manner as the main rotor charts. Assume a first reading of 2:00 o'clock and 0.6 "IPS". The amount of weight required (9 grams) is read directly from the gram scale on the chart. The location is determined from the sketch at the left of the chart. Do not confuse the hole numbers with the clock face. Notice that the number 12 hole is opposite the TARGET and the numbers are counterclockwise. In this example, the weight is added to hole No. 2 (about the 4:00 o'clock location when viewed relative to the TARGET).

### NOTE

Since the balance wheel is screwed on as a jamnut, its angular position is random. in other words, its number 6 and 12 holes may not line up with the spanwise axis of the rotor. Weight must be added to the closest hole to the indicated location.

# 5-263. Correction of the Tail Rotor Charts.

- **a.** Correction of Amount of Weight. If the move line is longer or shorter than the distance from the first (previous) reading to the center of the chart, less or more weight should be used.
- **b.** Correction of Weight Location. Moving the weight to the next hole clockwise rotates the move line one hour counterclockwise. Therefore, if the move line passes to the left of the center such that the angle from the center to the first point to the second point forms an angle of **30°** (one hour), the weight

should be moved to the next hole counterclockwise (to hole No. 3 from No. 2). If the move line misses to the right of center, the weight should be moved clockwise (to hole No. 1 from No. 2). If the included angle is 1/2 hour (150), the weight should be divided between the chosen hole and the next one (cw or Ccw)

### 5-264. USING THE VIBREX 4591.

In order to use the VIBREX 4591, the helicopter must be fitted as follows:

#### NOTE

The semirigid rotor system of the OH-58 allows balancing of both main and tail rotors. This can be accomplished on-the-ground, so rigging for both should be done at the same time. Readings for both may then be taken on the same ground run of the ship, saving time and engine starts. However, they can be worked separately if desired.

Both rotors are balanced based on ground runs only. After balancing, the ship is flown and the main rotor is tracked, Based on visual in-flight track observations with the Strobex, the determination is made as to whether to make track adjustments with trim-tab or with pitch link. Final adjustment is made using vertical one-per-rev "IPS", and clock angle vibration measurements (from an Accelerometer on the console) using the BALANCER.

### 5-265. MAIN ROTOR.

### 5-266. Necessary Equipment.

Quantity	Equipment Needed	Model Number
1	Balancer/Phazor Strobex Tracker	177M-6A 135M-11

		Model
Quantity	Equipment Needed	Number
4	Orana Caala	47
1	Gram Scale	47
*1	Magnetic Pickup Cable	3319-2
*1	Magnetic Pickup	3030
1	Magnetic Pickup Bracket	3159
*1	interrupter	3380
*3	Accelerometers	4177B
1	Accelerometer Cable	4296-1
*2	Accelerometer Cables	4296-2
*2	Accelerometer Brackets	3382
1	Accelerometer Bracket	3383
1	Tip Target Tape	4270
1	Reflective Targets	3300
1	DC Extension Cable	3529
1	M/R Balance Chart	3411
1	M/R Tracking Chart	3875
1	T/R Balance Chart	3438
1	Checklist	4300A

\*Denotes equipment physically mounted to the helicopter. installation and removal should be double checked.

### **NOTE**

This list should be checked prior to and after balancing to ensure that the proper equipment is on hand before proceeding and that all equipment is removed upon completion.

# 5-267. Attach MAGNETIC PICKUP (Figures 5-90 and 5-91).

Attach MAGNETIC PICKUP Bracket No. 3159.

- **a.** Remove front of "doghouse" in front of transmission.
- **b.** Place MAGNETIC PICKUP bracket No. 3159 over left front pitch horn of the fixed swashplate, from the top, with the 1/4-28 inch studs pointing down.
- **c.** Place bar No. 3160 on studs, from the bottom, and secure the 1/4-28 inch self-locking nuts. Snug the nuts, but **do not tighten so much that it bends the bar.** Use new nuts as required.

**d.** Screw a nut on the MAGNETIC PICKUP. Screw the pickup into the bracket from the bottom, until the end is flush with top of the bracket. Adjust pickup and tighten jamnut later.

# 5-268. Install Interrupters (Figure 5-90 and 5-91).

- **a.** Rotate head so red blade is at 3: 00 o'clock(right side of ship).
- **b.** Install the double interrupter No. 3380-1 in the drain hole in the web of the rotating swashplate that is pointing forward. Insert the 8-32 inch stud from the bottom, with the two vanes pointing down, and oriented radially. Place No. 8 self-locking nut on top and tighten.

### **NOTE**

When the red blade is turned forward, the double interrupter will be over the MAGNETIC PICKUP. This becomes the TARGET blade.

**c.** Turn the red blade to 9:00 o'clock. Install the single interrupter No. 3380-2 in the other drain hole.



The vane of the single Interrupter must lead (arrive over the MAGETIC PICKUP before the supporting screw). If the tip targets appear a couple of feet apart, it is probably because the SINGLE interrupter is backwards.

### 5-269. Adjust MAGNETIC PICKUP Gap.

- **a.** Turn rotor so an interrupter is over the MAGNETIC PICKUP. Using a feeler gage, adjust the pickup to a gap of  $0.060 \pm 0.010$  inch clearance.
- **b.** Turn rotor so the other interrupter is over the pickup and check that its gap is the same 0.060 **± 0.010** inch clearance.
  - c. Tighten jamnut.

NOTES

Check TRACK after each mode  Clock Angle				1st l	Run	2nd	Run	3rd	Run	4tl	h Run	5th Run
A READING												
C MOVE  Grams in Target Blade Bolt  Grams in Blank Blade Bolt  Sweep Target  1.3/4 pt	A	1		10:0	00	12:	00	1:	00			
Blade Bolt Grams in Blank Blade Bolt  C MOVE  Sweep Target  1.3/4 pt			. –	0.0	3	0.	6	0.	05		]	
C MOVE Sweep Target 1.3/4 pt	С		Blade Bol	t		<i></i>						
		MOVE	Blade Bol	lt	60	60 gms		gms				
							1-3/	4 pt				

- 1. Set tabs at trail. Adjust for good track at 100%, flat pitch, on the ground using pitch link only.
- Set BALANCER to 354 RPM. Push TEST button and check that the 12:00 and 6:00 O'Clock lights are lighted. Release button.
- Observe Clock Angle of lighted light, then press Verify Tune button. Adjust RPM Tune dial WHILE BUTTON IS PUSHED to return lights to angle observed BEFORE BUTTON WAS PUSHED. Release button, observe angle, press and adjust again to match new unpushed angle. Repeat until there is no change WHETHER BUTTON IS PUSHED OR RELEASED.
- 4. Record Clock Angle and IPS in section A of chart. Plot to B (label it No. 1). Note indicated changes in C.
- Make changes indicated. Run ship to check result (label it point No. 2). Repeat as required to reduce IPS to 0.2 or less.
- If move line (point No. 1 to No. 2) is not in the correct direction, use Clock Angle corrector No. 3597, and assign new numbers to clock. SEE MANUAL FOR DETAILS.




Figure 5-88. Reading a Main Rotor Balance Chart with an Incorrect Clock Angle

					Date: Serial No:				
_			1st R	un	2nd Run	3rd R	un	4th Run	5th Run
Α	Clock	Angle	2:0	0	2:00				
_	READI	VGS PS''	0.6	3	0.05				
	$\overline{}$						~7		
C		GRAM	S (1)	9 g:	ns	l		į	
	MOVE	DISC HO		#2					

- 1) Read around circular lines from plotted IPS and clock to GRAMS scale, and enter grams.
- 2) Enter clock angle from A.

NOTES: Run ship at 100%, flat pitch, on the ground.

- 1. Set Balancer to 2550 RPM. Direct Strobex at tall rotor hub and observe clock angle of target.
- Then depress Verify Tune button and adjust RPM tune diel to return target to clock angle observed before button was pushed. Release button, observe angle, press and adjust again until clock angle remains the same whether button is released or pushed. ADJUST ONLY WITH BUTTON PUSHED.
- 3. Read clock engle without button pushed, and IPS from Balancer meter WITHOUT STROBEX FLASHING and record in section A of chart. Plot in B (label it point No. 1), and note indicated weight changes in C.
- Make indicated changes, run ship to check result and repeat if required to reduce IPS to 0.2 or lass.
- 5. Look along the move line on the chart (from reading No. 1 to No. 2, chart rotated to bring No. 1 nearest to eye). If it goes directly toward or through the center of the chart the weight was placed in the correct hole. If it misses to the left move the weight to the next hole countsrolockwise from the one chosen. If it misses to the right, move weight to the next hole clockwise. If the error is about 1/2 hour (the angle formed between lines from points No. 1 and No. 2 and point No. 1 and center of chart about 1/2 hour) divide the required weight between the hole chosen and the next hole as determined above. If the move line is too short or too long, use more or less weight.





Figure 5-89. Reading the Tail Rotor Charts







Figure 5-90. Magnetic Pickup and Double Interrupter Installation.



206011-314

Figure 5-91. Single Interrupter Installation

### NOTE

If, after installation is complete and ship is turned up, the targets, as illuminated by the STROBEX, appear too far apart, the SINGLE interrupter may be bent to adjust the positions of the images. They should be within a couple of inches.

# 5-270. Attach Accelerometer.

**a.** Remove nut from stud on upper left of transmission, just below collective scissors, and attach bracket No. 3383.

### NOTE

If the collective is raised, there is room to use a socket on this nut.

**b.** Secure accelerometer No. 4177B to this bracket with its sensitive axis at right angles to ship and connector to the left (9:00 o'clock). (Not radial to mast, )

### NOTE

This main rotor accelerometer may be attached by placing bracket No. 3383 over stud on top of existing nut. Then, run another nut to clamp bracket between the two nuts. This way the first nut need not be removed.

# 5-271. Connect MAGNETIC PICKUP Cable and Accelerometer Cable.

- **a.** Feed MAGNETIC PICKUP and accelerometer cables through hinged door at left, between front cowl and engine access door.
- **b.** Connect cable No. 3319-2 to MAGNETIC PICKUP and cable No. 4296-2 to accelerometer. Close hinged door, pinching cables to secure them. Leave sufficient service loop such that cables will be slack but not loose. Be sure there is enough slack to allow complete and free movement of the swashplate.

# WARNING

The ship will be flown with these brackets and cables attached. Move the controls through all possible positions while turning the head, by hand. Make sure there is not interference, and no binding of cables, nor slack in cables that could possibly be caught in moving or rotating parts of the helicopter. Pay particular attention to swashplates; tie as required.

**5-272.** Attach Tip Targets. Place self-adhesive reflective tip targets No. 4270 under each blade tip (figure 5-92). Clean the area where the targets are to be attached with a non-oily solvent.

### NOTE


Tip target brackets that extend down from the blade tip may be used. The OH-58 uses part number 3428-2. Remove screw in tip-cap, install bracket, and tighten screw.

### 5-273. EQUIP TAIL ROTOR.

### NOTE

OH-58 tail rotors are balanced by adding a bolt, nut, and washers as required to one of 12 holes in the balance wheel (Bell P/N 206-011-716-1, NSN 1615-00-482-2539) on the tail rotor shaft. If the ship is not fitted with this balance wheel, it must be added.

- **5-274. Mount Accelerometer (Figure 5-93).** Remove nut from top stud of tail rotor gearbox flange, and mount accelerometer bracket No. 3382. Mount accelerometer No. 4177B to bracket with its connector up.
- **5-275.** Connect Accelerometer Cable (Figure 5-93). Connect cable No. 4296-2 to accelerometer No. 4177B, and wind cable forward round tailboom. Give it about 3 turns, bringing the last over the horizontal stabilizer and then to the left rear of the ship, **15 or 20** feet to the side of the tail rotor.






Figure 5-92. Tip Targets Installation




Figure 5-93. Accelerometer and Reflective Target Installation



Keep cable snug around tailboom but do not tighten enough to pull cable out of cannon plug.

# **CAUTION**

Pass cable between tailboom and driveshaft, taking care that it cannot foul in shaft or couplings.

### 5-276. Apply Targets (Figure 5-93).

- **a.** At the grip of one blade only, apply a retroreflective target strip No. 3300, so it can be seen from the side of the rotor disc. (This becomes the TARGET blade.)
- **b.** The tail rotor has fixed pitch links, so there is no track adjustment possible, and no need to track it. if, for any reason, it is desired to check track, apply targets as follows:
- (1) Apply a target along the chord of one tip (to be viewed edge-on), and on the opposite tip apply one across the chord.
- **(2)** Since the blade tips are thin, it may be necessary to slit a target into a narrow strip.

# CAUTION

Ensure that targets are centered in the exact same position on each tail rotor blade tip or an incorrect track reading will be seen.

**5-277.** Connect Cables. Plug dc extension cable No. 3529 directly into the outlet in the overhead panel. Route this cable **15 or 20** feet to the side of the tail rotor (left rear of ship). Place BALANCER at the left rear of ship, and connect dc extension cable.

# 5-278. Connect MAGNETIC PICKUP and Accelerometer Cables.

**a.** Plug MAGNETIC PICKUP cable No. 3319-2 into CHANNEL A MAGNETIC PICKUP receptacle.

- **b.** Plug main rotor accelerometer cable No. 4296-2 into CHANNEL A accelerometer receptacle.
- **c.** Plug tail rotor accelerometer cable No. 4296-2 into CHANNEL B accelerometer receptacle.

### NOTE

Coil all four cables as required to remove slack. Tape or tie them together at about their midpoint, so the cables from the cabin area will prevent the tail rotor cable from being drawn into the tail rotor. Arrange cables so instruments can be moved between tail rotor observation location and cabin door for viewing track.

### 5-279. BALANCE ROTORS.

### 5-280. Check Tail Rotor Track.

- **a.** There is no provision to adjust the tail rotor track of the OH-58, because of the fixed pitch links. It can be checked easily, if desired, as follows:
  - (1) Set STROBEX 135M-11 MODE switch to D.
  - (2) Set RPM dial (FLASH RATE) to 510.

### NOTE

Switching the STROBEX, as described, activates its internal oscillator and disconnects any external commands (as from BALANCER, accelerometer, etc.).

- **b.** Run helicopter at **100%**, flat pitch, center pedals, head into wind, on the ground.
- **c.** Stand at the side of the tail rotor and observe the two images of the single grip target. Fine tune RPM dial so the two targets are STOPPED.
- **d.** Move, with BALANCER and STROBEX, to cabin door. (Drag the cables.) Look aft at edge of rotor disc to view the superimposed tip targets, and judge track (left-to-right relation).

### NOTE

If the horizontal bar appears above or below the vertical it indicates that the targets were not placed an equal distance aft of the leading edge of the blade. This is not important, if the difference is only an inch or two; the important observation is the left-toright relation of the vertical to horizontal bars.

**e.** Fine adjustment of RPM knob will position and stop targets as desired. Keep ship running and proceed to check ground track of main rotor.

### **NOTE**

While you are at the cabin door, it is easy to check main rotor track.

**5-281. Take Tail Rotor Balance Readings.** Return to position **15 or 20** feet to left of tail rotor (left-rear of ship),

- **a.** Switch BALANCER Function switch to CHANNEL B and adjust BALANCERtotail rotor rate of 2550 RPM (RPM TUNE dial to 255 and RPM Range switch to X 10).
- **b.** Set STROBEX 135 M-11 MODE switch to position A.
- c. Direct STROBEX at tail rotor disc, and observe the Clock Angle of the retro-reflective target on the grip. The observer must hold the light as near as possible in front of his eyes to see the target brightly.
- **d.** Press VERIFY TUNE button, and adjust RPM TUNE dial, while button is pushed, to return target to angle observed before button was pushed. Release button, observe angle, push button and adjust RPM TUNE dial again to match new unpushed angle. Repeat until there is no change whether button is pushed or released. Adjust RPM TUNE dial only while VERIFY TUNE button is pushed.
- **e.** Read Clock Angle with button released, and "IPS" WITHOUT STROBEX FLASHING. Record in section A of tail rotor balance chart.

### **NOTE**

If reading is off scale, press SCALE 2 button and read second scale.

**f.** Leave ship running, move instruments to left cabin door and proceed to track main rotor.

### NOTE

When the collective is fully down, the helicopter will probably have a severe bounce, and readings will be unsteady and erratic. Pull enough collective to eliminate the bounce and steady the readings.

**5-282.** Check Track of Main Rotor (From Cabin Door). Switch BALANCER FUNCTION switch to TRACK,

- a. Switch STROBEX 135 M-11 as follows:
- (1) MODE switch to A, in which case oscillator is inoperative, and setting of the RPM dial has no effect and is unimportant. Targets will be seen at the head of the ship (track location).

Light is in low intensity mode.

(2) MODE switch to B and RPM dial to about 210. This allows viewing of targets at the head of the ship. Setting RPM dial to about 560 also allows viewing the blades at the side of the ship for viewing advancing and retreating blades (track location).

Light is in high intensity mode.

# CAUTION

# Oscillator MUST be set in MODE A or B except for tail rotor track.

**b.** From near the cabin, direct the STROBEX tracker to the blade tip path at the front of the ship. Sweep up-and-down and in azimuth in a W pattern to find the tip targets. Observe and note the track on the main rotor balance chart.

### **NOTE**

# Pull enough pitch to avoid ground bounce.

**c.** Perfect track is evidenced by a cross, and the vertical relation of the horizontal bar to the vertical bar indicates the obvious.

# **CAUTION**

After each pitch link adjustment, carefully check thread engagement using the dimensions shown on figure 5-52.

### NOTE

If one target appears too far to the right or left of the other (more than a couple of inches), note which one is which direction. Shut the ship down and bend the vertical fin of the SINGLE interrupter in the direction necessary to align targets. Bending the interrupter tab 1/10 Inch will move the target about 3 inches, so it does not take much.

All ground-run track adjustments should be made with pitch link only. Do not work tabs until after intflight observations. One full turn of the link equals one half inch of track.

If Initial track adjustments must be large (1 inch or so) it is often best to turn rodend rather than the pitch-link barrel. Barrel adjustment slow. If track looks okay, keep ship running and proceed as follows. If not, shutdown and adjust

# 5-283. Take Main Rotor Balance Readings.

- **a.** Return instruments to the tail rotor (initial) location. Run ship at **100%**, flat pitch, center controls. Head into wind.
- **b.** Switch BALANCER FUNCTION switch to CHANNEL A (main rotor), INTERRUPTER LOGIC switch to DOUBLE and MAGNETIC PICKUP switch to COMMON.
- **c.** Set BALANCER for main rotor RPM to 354 on RPM TUNE dial and X 1 on RPM Range switch.

## **NOTE**

Pull enough pitch to avoid ground bounce.

- **d.** Press TEST button on PHAZOR and look for the 12:00 and 600 o'clock fights. Until this display is seen with TEST button depressed, the PHAZOR is not ready. If this pattern cannot be seen, check the double and single Interrupters and MAGNETIC PICKUP gap.
- **e.** Release TEST button and observe clock angle of lighted tight in the ring-of-lights.
- **f.** Push VERIFY TUNE button, and adjust RPM TUNE dial while button is pushed, to return light to angle observed before button was pushed. Release, observe angle, push, and adjust again to match new unpushed angle. Repeat until there is no change whether button is pushed or released.
- g. Read clock angle and "IPS" with button released, and record in Data Section of main rotor balance chart.

# 5-284. Make Required Changes and Check Results.

**a.** Shut ship down and make necessary changes as indicated on the balance charts (main and tail rotors).

### **CAUTION**

Make only one change, for the first move. This makes it easier to check the correctness of the chart.

- **b.** Run ship again and repeat readings, and record in Data Section of balance charts.
  - c. Repeat until "IPS" readings are 0.2 "IPS" or less.

# 5-285. INFLIGHT TRACK MAIN ROTOR.

### 5-286. Equip The Ship.

- **a.** Remove accelerometer and cable from tail rotor area.
- **b.** Place instruments in the cabin within easy reach of the copilot seat, bringing the cables in the left rear door. Close door in cables, pulling exposed section tight. Remove dc extension cable and plug BALANCER directly into dc receptacle on the overhead.

- **c.** Check that both main rotor cables (MAGNETIC PICKUP and accelerometer) are dressed safely for flight.
- **d.** Secure an accelerometer (from tail rotor) to the console under a convenient screw head. It must be attached to a rigid part of the structure, and its connector MUST POINT DOWN. (Use bracket No. 3382.) Plug this accelerometer into BALANCER CHANNEL B.

### **CAUTION**

Accelerometer will be removed from tail rotor area before flight.

### **NOTE**

A third accelerometer and cable can be secured to the console at the time of the initial setup, if desired.

5-287. Fly The Helicopter.

#### NOTE

Fly the OH-58 at 60 and 100 knots.

- **a.** Switch BALANCER FUNCTION switch to TRACK. (Everything else the same.)
- **b.** The 135M-11 STROBEX may be used in position A or B.
- **c.** Now, fly the ship and sketch, in the spaces provided on tracking chart, the track observed at 60 and 100 knots. (Do not exceed a reasonable airspeed for the conditions of track, density, altitude, load, etc.)
- **d.** Then, at each of the above airspeeds, switch BAL-ANCER FUNCTION switch to B (vertical accelerometer). Press TEST button and look for 12:00 and 6:00 o'clock lights.
- **e.** Release TEST button and observe clock angle of lighted light in ring-of-lights.
- **f.** Push VERIFY TUNE button, and adjust RPM TUNE dial while button is pushed, to return light to angle observed before button was pushed. Release, observe

angle, push, and adjust again to match new unpushed angle. Repeat until there is not change whether button is pushed or released. After tuning, record clock angle and "IPS" at 100 knots in the spaces provided on inflight tracking chart.

**g.** Land the ship, plot the 100 knots (or highest speed reached) reading on tracking chart, at the intersection of clock angle line and "IPS" circle. (Use B vertical accelerometer for inflight track.)

# **CAUTION**

Track changes affect balance! Check and record balance readings (Channel A) prior to each flight, in space provided. Correct balance as required.

### 5-288. Correct Track.

**a.** If the blades are seen to spread as airspeed is increased (the tip targets show substantially more vertical separation at 100 knots than at 60) use trim-tab. If the blades are out-of-track about the same amount at all airspeeds, use pitch link.

### Knots

60 100

+ T This calls for TAB change.

+ + This calls for PITCH LINK change.

### CAUTION

Use as little tab as possible. Maximum trim tab adjustment per trim tab is not to exceed seven degrees up or down. Excessive tab tends to wash out, and may deteriorate the ride in letdown or other conditions of loading (gross weight), etc.

**b.** Fly the ship again and check results. Repeat if required to reduce B readings (vertical one-per-rev) to 0.2 "IPS" or less. Check all airspeeds.

### NOTE

Trim tab and pitch link changes generate a move line in approximately the same direction Tab is much more airspeed-sensitive, but the direction is about the same.

THERE IS NO CONTROL THAT WILL RE-LIABLY CAUSE THE MOVE LINE TOGO PERPENDICUAR TO THIS. An exception might be worn or loose control linkage (pitch link rod-ends, etc.), which seem to have this effect to some extent.

If this reeve line does not go through the center of the chart, but rather goes tangent to some "IPS" circle (i.e., 3 "IPS"), that is the lowest vertical vibration level attainabls. If that level is not acceptable, it suggests that the mismatch of blades is such that they cannot be made to fly togather satisfactorily. Of course, all remedies should be exhausted before this conclusion is reached, but failure of the move line to go through the center of the clock is a strong indiction of mismatch.

When unbalancing condition exists, the rotor blade should be inspected for damage and conditions that would effect its flight characteristics. If no deficiencies are detected and accessibility is available, main rotor blades should be matched with blades of similar tracking/balancing characteristics.

# 5-289. Two-Per-Rev.

- **a.** Vertical two-per-rev can also be measured from the accelerometer mounted vertically on the console. Simply set the RPM TUNE dial to 706, and RANGE switch to X 1.
- (1) The vertical two-per-rev is unaffected by track or balance.
- (2) Above 100 or 110 knots, the vertical two-per-rev gets rather heavy.
- (3) Vertical two-per-rev varies greatly from helicopter to helicopter.


- **(4)** When the one-per-rev is reduced, vertical two-per-rev becomes more noticeable.
- **b.** It is well recognized that a low frequency masks the feel of a high frequency vibration.
- **c.** Table 5-4 is a tabulation of one- and two-per-rev readings. A considerable variation from these figures can be expected, especially at higher airspeeds, since these numbers are the average of readings from more than a dozen OH-58 helicopters.
- **d.** Two-per-rev work is largely black magic, but it is effected by:
  - (1) Swashplate pivot sleeve.
  - (2) Transmission mount bearing.
  - (3) Landing gear crosstubes.

# 5-280. Troubleshooting.

**a.** If, after balancing and tracking both rotors other vibrations are felt, the VIBREX 4591 system may be used for troubleshooting.

Table 5-4. One- and Two-Per Rev Readings.

# AIRSPEED - KNOTS



- **b.** The source of other vibrations may be determined by securing an accelerometer in the area of noticed disturbance. Then, by tuning the RPM TUNE dial through the range of interest until the "IPS" meter peaks, the RPM (frequency) of the disturbance can usually be determined. (Do the final peaking of the meter with the VERIFY TUNE button pushed.) This is generally the same as, or harmonically related to, the source (forcing function) of the vibration.
- **c.** The accelerometer can often be hand-held with good results while searching with the RPM TUNE dial. Use care to select hard points where the vibration will not be damped (suppressed). Avoid sheet metal panels, etc.
- **d.** To facilitate determination of the offending component, the following operating rpms are printed. Components of the different models may turn at different rpms than those shown here. Refer to the helicopter manual for your particular model.
- **e.** The VIBREX Tester, model 11, provides a complete and simple functional test and calibration of the entire VIBREX 4591 System. Use of the Tester will identify most problems that are likely to occur with the VIBREX (table 5-5).

Assembly	OH-58A Operating RPM	OH-58C Operating RPM
Main rotor	354	354
Main rotor two-per-rev	708	708
Main rotor six-per-rev	2124	2124
Tail rotor	2623	2623
Tail rotor two-per-rev	5246	5246
Tail rotor driveshaft	6173	6173
Oil cooler fan (transmission)	6173	6173
Engine to transmission shaft	6173	6173
Oil pump (transmission)	4344	4344
Hydraulic pump	4344	4344
Tachometer generator		
(transmission)	4344	4344
Sungear (transmission)	1648	1648
Planetary (transmission)	1001	1001
N2 turbine wheel	36010	34158
Torque meter shaft pad	10288	10288
Power turbine governor pad	4309	4309
N2 turbine pinion	5191	5191
Driveshaft pad	6173	6173
N2 tachometer generator	4309	4309

Table 5-5. Troubleshooting the VIBREX 4591 System with the VIBREX Tester, Model 11

SYMPTOMS	PROBABLE CAUSE	CURE
No lights in BALANCER/ PHAZOR.	Dc polarity wrong.	Check polarity (pin B is hot +, pin A is ground).
	Breaker, to circuit in use, is not turned on.	Turn breaker on.
Unsteady tail rotor image when balancing.	Oscillator not in position A.	STROBEX must be in A, when balancing tail rotor.
	Vibration level is very low.	When vibration level is low, clock angle is uncertain. Jittery image is indicator of good balance.

Table 5-5. Troubleshooting the VIBREX 4691 System with the VIBREX Tester, Model 11 (Cont)

SYMPTOMS	PROBABLE CAUSE	CURE
Cannot see targets.	STROBEX out of focus.	Remove rear panel and adjust focus.
	Reflective targets worn or dirty.	Replace, and avoid handling reflective surface. Replace as necessary.
	Flash tube cracked (weak blue flash).	Replace flash tube.
	Not aiming STROBEX correctly and/or not in-line with light source.	Look directly over top of STROBEX, and search in a W pattern along the tip path.
	STROBEX and/or BAIANCER switched to wrong position.	Check settings.
	Protective varnish or coating over reflector material.	Coating kills reflective properties of exposed bead material. <b>Do not coat!</b>
Targets appear scattered when tracking main rotor.	STROBEX oscillator ON.	Check oscillator switch. MUST be in A or B.
	Interrupter assembly bent.	Straighten or replace interrupter.
Do not get TEST pattern in PHAZOR when TEST	MAGNETIC PICKUP gap too large.	Close gap between magnetic pickup and interrupter.
button is pushed.	Faulty MAGNETIC PICKUP cable or MAGNETIC PICKUP.	Check and repair or replace as required. MAGNETIC PICKUP should read about 1000 ohms.
	INTERRUPTER LOGIC switch set incorrectly.	Must be set to DOUBLE.
	Polarity of MAGNETIC PICKUP incorrect.	Pulse should first go negative, then sharply positive where Phazor triggers, then go negative to zero.
	MAGNETIC PICKUP cable plugged into MAGNETIC PICKUP backwards (wrong polarity).	Check that indexing key is correctly lined up. It is not easy, but connector can be plugged in backwards.
	RPM RANGE switch set to wrong range.	Set RPM RANGE to x1.

Table 5-5. Troubleshooting the VIBREX 4591 System with the VIBREX Tester, Model 11

SYMPTOMS	PROBABLE CAUSE	CURE
Meaningless PHAZOR light pattern when working tail rotors.	Normal.	PHAZOR is NOT used for tail rotor work, so don't worry about it.
"IPS" and clock angle readings not repeatable, i.e., restoring weights to original condition does not give same readings.	Mechanical components on rotor are faulty. Bearings, dampers, rod-ends, etc., should all be checked.	Correct or replace faulty components.
False reading on BALANCER "IPS" meter.	When the BALANCER RPM TUNE dial is set below 100 (on any RPM RANGE) the circuitry is unstable and causes false readings on the "IPS" meter.	DO NOT USE BALANCER WITH RPM TUNE DIAL SET BELOW 100.

# 5-291. Alternate Procedure for Tracking Main Rotor Hub and Blade Assembly.

# Premaintenance Requirements for Main Rotor Hub and Blade Assembly

Condition	Requirements
Model	OH-58A and OH-58C
Part No. or Serial No.	All
Special Tools	(T14) (T15) (T29)
Test Equipment	Tracking light
Support Equipment	None
Minimum Personnel Required	Two
Consumable Materials	(C51) (C96)
Special Environmental Conditions	None



The flag method of tracking will not be used on OH-58 helicopters.

### NOTE

Tracking procedures for tail rotor hub and blade assembly are not applicable.

### **NOTE**

The need to track main rotor blades will be indicated by a 1:1 vertical vibration. 1:1 vertical vibrations are airspeed sensitive. For direction in determining and correcting main rotor vibrations, refer to the following test.

**a.** Position rotor blade trim tabs to ZERO degrees, hereafter referred to as trail position. Use tab bending tool (T14) and tab gage (T15).

### **NOTE**

The trim tab gage shall be installed on the outboard edge of the trim tab. Readings are taken facing outboard toward the blade tip.

- **b.** Install target assemblies, tool (T29), one on lower surface of each blade with reflectors pointing toward rotor hub, Use aft screws of tip balance weight support installation. Refer to figure 5-94.
- **c.** Tape or mark a portion of the reflectors to provide a means of identifying each blade during tracking operation,

- **d.** Plug tracking light into receptacle located in aft section of overhead console.
  - e. Operate helicopter at 70 to 75% N2 rpm.
- **f.** Sight the tracking light from inside the rotor disc on the target assembly reflectors. If the reflection does not make one line, adjust the main rotor blades as follows:

### NOTE

Record all changes made in pitch links. The pitch link tubes incorporate national coarse threads in one clevis and national fine threads in the other. This feature permits precision length adjustments of the pitch link without disconnecting either clevis fitting. Use the pitch link tube as a turnbuckle.

(1) Shorten the pitch link attached to the pitch horn of the high blade. Use one full turn on the link to each one-half inch out of track.

# CAUTION

Do not exceed the maximum dimensions shown in figure 5-52. Autorotation is effected by changes in pitch link settings. Do not increase or decrease length of both pitch links during the tracking procedures.

- (2) After track adjustments are complete on assembly P/N 206-010-360-3, apply corrosion preventive compound (C51) to the threads of the upper clevis (1, figure 5-52), lower clevis (6), and to the ends of the tube (3). Torque jamnuts (2 and 5) to 150 TO 200 INCH-POUNDS and lockwire (C96) nut (2), apply corrosion preventive compound (C51) to the top surfaces of nuts (2 and 5). Lockwire required at only one end.
- g. After rotor has been placed in track by adjustment of the pitch link on the high blade, operate the helicopter at 103% A, 100%. C N2 rpm. Apply sufficient collective control to make helicopter light on skids. Maintain 103% A, 100% C N2 rpm and track rotor blades. This is a reference track only. Do not make any tab adjustments at this time.

### **NOTE**

The ground track is a starting point only and does not mean that the rotor is in the best flight configuration.

- **h.** At a stabilized hover, observe the in or out-of-track tip path plane for 1:1 vertical reference. Also observe the possible bounce in the center line of the cockpit area. Corrective action not required at this time.
- i. Check the 1:1 lateral vibration level at high and low beep on the governor actuator. If the amplitude of the lateral is worse at 103% \( \), 100% \( \) N2 rpm, the lateral is probably from spanwise balance. If it is worse at 100% \( \) A , 97% \( \) N2 rpm, the lateral is probably caused by chordwise balance problems.
- **j.** Accelerate into forward flight. If a vertical is present (visual out-of-track of tip path plane and/or a bounce in the center line of the cockpit) and does not increase in hardness as airspeed is gained, note the speed where the vertical comes in and enter an autorotative descent at the idle rpm.
- **k.** The vertical hardness should be more noticeable in letdown. If so, correct by rolling the low blade up two flats as indicated by the high-speed ground-track. If vertical is worse after repeating above step, zero the roll and go down two flats more on the same blade. Continue rolling on whichever blade offers the best vertical level and until the vertical is as smooth as is possible in letdown and flight.

### **NOTE**

Excessive rolling (2 flats or more) can induce chordwise lateral vibrations, so check at IGE hover to determine if lateral level has changed. Correct if required.

I. If the vertical vibration level increases with airspeed, note the vertical speed when the vibration comes in and tab the low blade up, using tab tool (T14) and gage (T15) as indicated by the high speed ground track. One degree of tab will change the vertical threshold about 13 to 17 knots. Excessive tab could increase high-speed two-per-rev vibration levels about 100 knots, so a medium between high-speed

#### NOTES:




Figure 5-94. Main Rotor Blade Tracking Target Installation

1 /rev and 2/rev levels may have to be accepted. Recheck the letdown vertical level.

### NOTE

Maximum trim tab adjustment per trim tab is not to exceed seven degrees up or down.

- **m.** Recheck the lateral vibration in OGE hover at high and low beep settings and smooth out any remaining lateral vibration by using the methods outlined in paragraphs 5-6 and 5-9.
- **n.** Recheck letdown for vibrations if much sweep is necessary, as it can induce a roll vertical in descent.
- **o.** Recheck IGE hover, forward flight, letdown, OGE hover with power and low-gross weight for overall vibration level being satisfactory.

- p. Recheck boost off forces and autorotation rpm. It is recommended that autorotation rpm be checked at low gross weights. Determine autorotation rpm at 55 KIAS: autorotation should be 93% with minimum safe fuel load, one pilot (150 pounds) and with collective full down. Autorotation rpm should be 105% maximum gross weight, Recheck boost-off forces and autorotation rpm, Refer to TM-55-1520-228-MTF.
  - a. If required, correct autorotation rpm as follows:



Do not exceed the maximum dimension shown in figure 5-52. After tracking adjustments are complete torque nuts and lockwire per paragraph 5-291, step f. (2) or (3).

- (1) If autorotation rpm is low, decrease length of both pitch links (figure 5-52) an equal amount.
- (2) If autorotation rpm is high, increase both pitch links (figure 5-52) an equal amount.
- (3) Test fly helicopter to confirm that autorotation rpm is set correctly. (One full turn on the fine thread clevis equals 7 to 12 rpm; the course threads slightly more.) If adjustment is required, adjust both pitch links an equal amount using the pitch link tube as a turnbuckle.



Do not exceed the maximum dimensions shown in figure 5-52. Autorotation is

effected by changes in pitch link settings. Do not increase or decrease length of both links during tracking procedures,

- (4) Torque pressure should be monitored at 103% A, 100% C N2 for 22 to 28 psi A, 23% to 29% C torque for safe autorotational rpm range.
- **r.** If helicopter is rejected due to an abnormal vibration level start over or change one or both blades.
- **s.** If helicopter is acceptable vibration wise, remove reflectors from blade tips and return helicopter to flight configuration.

# **CHAPTER 6**

# DRIVE TRAIN SYSTEM

# 6-1. DRIVE TRAIN SYSTEM.

- **6-2. Description Drive Train System.** This system includes transmission, freewheeling drive unit, freewheeling to transmission driveshaft, oil cooler fan and driveshaft, tail rotor driveshafts, bearing hangers, and tail rotor gearbox. (See figure 6-1.) (See figure 6-25 for fail rotor driveshafts after completion of MWO 55-1 520-228-50-25.)
- 6-3. Troubleshooting Drive Train. Below is a brief summary of drive train troubles which may be encountered in performing maintenance. Conditions and possible causes listed have been limited to those reasonably probable (though not necessarily frequent in normal service) which could become known through pilot reports or by inspection methods applicable in maintenance, and which could be subject to some evaluation at this level, although final corrective action by a higher level might be required in some instances. Conditions involving obvious major damage are omitted, as are those caused by accident or an unusual chain of events which would require information in addition to that available in troubleshooting section and in maintenance instructions for systems and components of the drive train.
- **a.** In transmission troubleshooting, observe the following:
- (1) Low oil level will not cause a low oil pressure indication, provided sump contains enough oil to cover pump inlet. Oil temperature might rise, however. Overfilling, above standard oil level, may cause low pressure indication due to foaming of the oil caused by excessive churning by the gears.
- (2) Effects of an oil leak will depend on its location in system and rate of leakage. An external leak can eventually allow sump to be pumped dry, causing failure of transmission. While oil remains to supply pump, the pressure relief valve would tend to maintain normal system pressures, compensating for leakage. This applies especially to leaks located between pump and relief valve. Leaks occurring

beyond relief valve could cause some indication of low oil pressure. Leakage to interior of transmission, while not affecting oil level, could starve lubrication areas beyond the leak and might affect indicated oil pressure and temperature.

- (3) Cumulative clogging of oil filter screens will not be shown by a gradual drop of indicated oil pressure as it may on some other aircraft oil systems. Pressure relief valve would maintain normal pressure even if filter screens become so clogged as to force oil flow through filter bypass valve.
- **b.** For main driveshaft troubleshooting, apply the following:
- (1) Trouble conditions of main driveshaft can seldom be detected in operation, since there are no reliable indications except possibly in an extreme condition. "Suspected vibration" is only partially accurate as a term for such conditions as dynamic out-of-balance or faulty coupling action. Vibration would result, as well as abnormal stresses and wear, but would be absorbed in structure and pylon mounts or effectively masked by normal vibrations of the helicopter, providing no distinct indication to pilot.
- (2) Driveshaft trouble indications are, therefore, usually those revealed by careful inspection.
- (3) Principle causes of driveshaft trouble are faulty installation procedure and improper lubrication of spherical tooth couplings.
- **c.** For tail rotor drive system troubleshooting, apply same principles as for main driveshaft.

# **NOTE**

Before using table 6-1, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 6-1, notify the next higher level of maintenance.

# Table 6-1. Troubleshooting — Drive Train

# CONDITION

**TEST OR INSPECTION** 

### **CORRECTIVE ACTION**

- 1. Low oil pressure on caution panel or pressure gage, but not on both.
  - STEP 1. Check for faulty caution panel. Refer to paragraph 9-147 A or 9-150 C

Replace faulty caution panel. Return faulty panel to depot maintenance.

STEP 2. Check for faulty pressure gage. Refer to paragraph 8-282 A or 8-291 C

Replace faulty pressure gage. Refer to paragraph 8-290.

STEP 3. Check electrical circuit for faulty wiring. Refer to paragraph 9-147A and 9-150C

Repair faulty electrical wiring.

STEP 4. Check for faulty pressure indicator or transmitter. Refer to paragraphs 8-285, 8-286, 8-287, 8-294, 8-295, and 8-296.

Replace faulty pressure indicator or transmitter. Refer to paragraphs 8-288, 8-289, 8-290, 0-297, 8-298, and 8-299.

- 2. Low oil pressure on both caution panel and pressure gage
  - STEP 1. Check pressure relief valve for adjustment or malfunction. Refer to paragraph 6-273.

Adjust pressure relief valve. Refer to paragraph 6-273.

Replace pressure relief valve. Refer to paragraph 6-276.

STEP 2. Check for leakage and for restriction between pressure relief valve and transmitter.

Repair oil line or clean oil line to remove restriction as required.

STEP 3. Check for faulty oil pump. Refer to paragraph 6-229.

Replace faulty oil pump. Refer to paragraph 6-231.

- 3. No oil pressure with normal oil level in sump.
  - STEP 1. Check for faulty gage or transmitter. Refer to paragraph 8-291

Replace faulty gage or transmitter. Refer to paragraph 8-298.

STEP 2. Check electrical circuits for faulty wiring. Refer to paragraph 8-298

Repair faulty electrical wiring.

# Table 6-1. Troubleshooting — Drive Train (Cont)

### CONDITION

TEST OR INSPECTION

### CORRECTIVE ACTION

STEP 3. Check for faulty oil pump. Refer to paragraphs 6-229 and 6-231.

Replace transmission or replete oil pump only if not damaged internally and oil system not contaminated with metal particles.

STEP 4. Check for faulty pressure indicator or transmitter. Refer to paragraphs 8-285, 8-286, 8-287, 8-294, 8-295, and 8-296.

Replace faulty pressure indicator or transmitter. Refer to paragraphs 8-288, 8-289, 8-290, 8-297, 8-298, and 8-299.

- 4. No oil pressure check reveals no oil supply in transmission sump.
  - STEP 1. Check system to determine cause of oil loss.

Special inspection required, refer to page 1-62.

- 5. High oil pressure.
  - STEP 1. Check for faulty gage or faulty transmitter. Refer to paragraph 8-280.

Replace faulty gage or faulty transmitter.

STEP 2. Check electrical circuit for faulty wiring,

Repair faulty electrical wiring,

STEP 3. Check pressure relief valve for adjustment or malfunction. Refer to paragraph 6-273,

Adjust pressure relief valve. Refer to paragraph 6-273,

Replace pressure relief valve. Refer to paragraph 6-276.

STEP 4. Check for faulty pressure indicator or transmitter. Refer to paragraphs 8-285, 8-286, 8-287, 8-294, 8-295, and 8-296.

Replace faulty pressure indicator or transmitter. Refer to paragraphs 8-288, 8-289, 8-290, 8-297, 8-298, and 8-299.

# Table 6-1. Troubleshooting - Drive Train (Cont.)

### CONDITION

# TEST OR INSPECTION CORRECTIVE ACTION

6. High oil temperature on caution panel or gage but not both.

STEP 1. Check for faulty caution panel or temperature switch. Refer to paragraph 9-154.

Replace caution panel. Return faulty panel to depot maintenance.

Replace faulty temperature switch. Refer to paragraphs 9-156 and 9-158.

STEP 2. Check electrical circuits for faulty wiring.

Repair faulty wiring.

STEP 3. Check area around transmission for obstructed air flow.

Clean cowl opening and sump area.

STEP 4. Check oil cooler for obstructed air passage.

Clean cooler core air passage.

STEP 5. Check oil cooler for internal oil passages. Refer to paragraph 6-256.

Replace cooler If Internally dogged. Refer to paragraph 6-257.

Flush oil lines.

Check transmission filters, pump screen magnetic plug. Refer to paragraph 6-251 and 6-289.

Step 6. Check oil cooler for thermostatic valve malfunction.

Replace oil cooler. Refer to paragraph 6-257.

Step 7. Check for dogged transmission oil jets.

Clean or replace jets. Refer to paragraph 6-284 and 6-73.

Replace transmission If Internally damaged. Refer to paragraph 6-73.

Step 8. Check transmission magnetic plug and filters for evidence of seized bearings or other internal failure.

Replace transmission and oil cooler. Flush external oil lines. Refer to paragraphs 6-73 and 6-257.

6-4 Change 24

# Table 6-1. Troubleshooting — Drive Train (Cont)

# CONDITION

TEST OR INSPECTION

### **CORRECTIVE ACTION**

STEP 7. Check for oil leaks in cooler or oil lines which could cause the thermo bypass valve to operate and bypass cooler. Refer to paragraphs 6-256 and 2-291.

Repair or replace emergency bypass valve. Refer to paragraph 6-237,

Replace oil cooler or oil lines. Refer to paragraphs 6-255, 6-267 or 6-291,

- 8. Oil caution light on.
  - STEP 1. Check caution light circuit for short or faulty wiring

Repair electrical circuit as necessary. Refer to paragraph 9-147 A or 9-150 C

STEP 2. Check for low oil level in sump.

Service transmission with oil. Refer to paragraph 1-10.

STEP 3. Check oil cooler and lines for leaks.

Repair leaks as necessary,

### TRANSMISSION

- 1. Metal chips found on magnetic sump plug or pump screen. Refer to paragraphs 6-289 and 6-290.
  - STEP 1. Internal transmission failure of gears or bearings.

Replace transmission. Refer to paragraph 6-71 and 6-73.

Replace oil cooler and flush piping. Drain and refill with oil. Refer to paragraph 6-257,

- 2. Excessive pylon motion (approx. 1/2/rev.)
  - STEP 1. Pylon mounts worn or installed wrong,

Repair or replace mounts. Refer to paragraphs 2-296 and 2-298.

STEP 2. Loose bearings in pylon link assembly. Refer to paragraph 2-284.

Replace or repair link assemblies. Refer to paragraph 2-287 and 2-288.

- 3. Water in transmission.
  - STEP 1. Water in drain lines.

Clear obstructions from lines. Disconnect lines and purge with compressed air.

# Table 6-1. Troubleshooting — Drive Train (Cont)

### CONDITION

TEST OR INSPECTION

### CORRECTIVE ACTION

### POWER TRAIN SYSTEM

- 1. Main rotor not moving when gas producer (N1) speed reaches 30%.
  - STEP 1. Main rotor tiedown not removed.

#### Remove tiedowns.

STEP 2. Binding or coking of power turbine (N2) engine.

Shut down engine. Repeat start procedure. If no rotation after third attempt, refer to TM 55-2840-231-24 A, TM 55-2840-241-24 C.

### FREEWHEELING UNIT

- 1. Metal chips on magnetic plug.
  - STEP 1. Inspect for evidence of internal failure.

# Replace freewheeling unit.

### MAIN DRIVESHAFT:

- 1. Grease leakage.
  - STEP 1. Cut or torn preformed packing or boot.

Replace packing or boot. (Assemble with care.) Refer to paragraph 6-17.

- 2. Abnormal coupling wear.
  - STEP 1. Faulty lubrication or wrong lubricant. Refer to paragraph 6-13.

Clean and lubricate adapter, or replace driveshaft. Refer to paragraphs 6-14 and 6-15.

- 3. Lubricant breakdown in forward adapter.
  - STEP 1. Misalignment or wrong lubricant. Refer to paragraph 6-14 and 6-15.

Replace driveshaft and associated parts as required. Refer to paragraph 6-13 and 6-15.

# Table 6-1. Troubleshooting - Drive Train (Cont)

### CONDITION

### TEST OR INSPECTION

### **CORRECTIVE ACTION**

- 4. Suspected vibration.
  - STEP 1. Loose engine adapter.

Replace adapter and any worn associated parts. Refer to paragraph 6-14.

STEP 2. Main driveshaft improperly assembled.

Disassemble. Inspect and assemble properly. Refer to paragraph 6-11.

### TAIL ROTOR DRIVE SYSTEM

- 1. Suspected vibration.
  - STEP 1. Worn hanger bearings or couplings. Refer to paragraph 6-127.

Replace hanger assembly.

STEP 2. Misaligned driveshaft hangers. Refer to paragraph 6-127.

Align hangers properly. Refer to paragraph 6-127.

STEP 3. Driveshafts improperly installed.

Check installation. Refer to paragraph 6-118 or 6-166.

- 2. Binding or roughness when manually checked. Refer to paragraph 6-115.
  - STEP 1. Dry or faulty bearing. Refer to paragraph 6-115.

Isolate faulty hanger, bearing or collar by disconnecting shafts. Replace hanger, bearing or collar as required. Refer to paragraph 6-116.

STEP 2. Defective gearbox.

Check gearbox, replace defective unit, Refer to paragraphs 6-183 and 6-187, or 6-203 and 6-205.

# Table 6-1. Troubleshooting - Drive Train (Cont)

## CONDITION

**TEST OR INSPECTION** 

### **CORRECTIVE ACTION**

- 3. Metal chips on gearbox chip detector. Refer to paragraph 6-195.
  - STEP 1. Internal failure of gears or bearings.

Replace gearbox. Refer to paragraphs 6-185 and 6-187 or 6-203 and 6-205.

STEP 2. Faulty wiring or faulty electric chip detector.

Repair electrical circuits as necessary. Check wiring for continuity and grounding. Repair faulty wiring or replace electric chip detector. Refer to paragraphs 6-194 and 6-196 or 6-219 and 6-221.

- 4. Oil leakage at gearbox.
  - STEP 1. Faulty seals or packings.

Replace seals. Replace output seals, Refer to paragraph 6-188 or 6-207 through 6-210. Replace input seals. Refer to paragraph 6-189 or 6-212 through 6-214.

STEP 2. Cracked gearbox housing.

Replace gearbox if cracks are found. Refer to paragraph 6-185 and 6-187 or 6-203 and 6-205.

6-4. Metal Particles Contamination — Transmission, Freewheeling Unit and Tail Rotor Gearbox. Metal particles found in or on oil filters. screens or chip detector plugs may indicate failure of an internal part of the component. The presence of metal particles, however, is not necessarily an indication that the component is no longer serviceable. The quantity, source, form, and type of metal found, together with the service history of the particular component, must be taken into consideration. The time accumulated since the component was new or overhauled, previous failures and the type of operation are important factors in determining the further serviceability of the unit. The particles found may be steel, silver, aluminum, magnesium, copper (bronze) or phenolic in various shapes and quantities. For a detailed explanation of the action made necessary by the presence of each of the possible types of particles in the component, refer to table 6-2.

WARNING

When any particles found are readily identified as fragments of parts, such as gears, nuts, bearings, snap-rings, lockwire, etc, replace contaminated transmission assembly with its oil cooler, contaminated freewheeling unit, or contaminated tail rotor assembly.




Figure 6-1. Drive Train System (Prior to MWO 55-1520-228-50-25)

Table 6-2. Metal Particles Contamination

KIND OF METAL	QUANTITY AND/OR SIZE	ACTION REQUIRED	NOTES
Steel	Fuzz, fine, hair-like particles	None	Result of normal wear. May have exaggerated appearance because of oil
	Particles in splinter or granular form	Perform serviceability check	Usually indicates failure
		Replace component if necessary	
	Thin flakes not exceeding 0.0156 inch in thickness and 0.0625 inch in length. Quantity not to exceed 10 flakes	Perform serviceability check	Small quantity may not indicate bearing failure
	More than 10 flakes not exceeding 0.0156 inch in diameter and 0.2500	Perform serviceability check	Usually indicates failure. May be bearing in one of the accessory quills
	inch in length	Replace component if necessary	of the accessory quills
Aluminum or Magnesium	Particles in granular form or like miniature lathe	Perform serviceability check	May be result of use of these materials as mallets or drifts during
Magricolani	tariinigo.	Replace component if necessary	assembly
Phenolic		Perform inspection for source	Result of the use of mallets and drifts during assembly of bearing retainer
Copper (Bronze)	Particles in granular form	Disassemble component, as required, to determine extent of damage	May indicate excessive wear of bearing cages as result of bearing failure
		Replace component if necessary	
	Small amount in flake form	Perform serviceability check	Result of normal wear
Silver	Small amount of silver flakes	Perform serviceability check	Result of normal wear
	Silver flakes with other metals	Perform serviceability check Replace component if necessary	May be result of internal failure

### 6-5. Identification of Metal Particles.

- **a.** A visual inspection of color and hardness will occasionally suffice to identify the particles. When visual inspection does not positively identify the particle, the kind of particle present may be determined by few simple tests.
- **b.** Equipment to perform tests includes a permanent magnet, sodium chloride, and concentrated nitric acid. Check each as follows:
- (1) STEEL. Isolate steel particles with permanent magnet.
- (2) SILVER. Identify silver by dissolving a particle in a solution of 50% by volume nitric acid. It may be necessary to warm the solution. Add a few drops of 5% by weight sodium chloride solution. A white precipitate identifies silver.
- (3) ALUMINUM. Determine aluminum particles by their reaction to hydrochloric acid. When a particle of aluminum is dropped into hydrochloric (muriatic) acid, it will fizz with a rapid emission of bubbles. The particles will gradually disintegrate and form a black residue.

### **NOTE**

Magnesium and aluminum react similarly in hydrochloric acid. When in doubt, drop particle into nitric acid. Aluminum does not react noticeably in nitric acid.

(4) COPPER OR BRONZE AND MAGNESIUM. Differentiate copper or bronze and magnesium by their respective reactions to nitric acid. When a particle of copper or bronze is dropped into nitric acid, it forms a bright green cloud in the acid. When a particle of magnesium is dropped into nitric acid, it fizzes with a rapid emission of bubbles. Phenolic and aluminum do not react noticeably to nitric acid.

### 6-6. Serviceability Check.

- **a.** The following procedure should be employed if any doubt exists as to the serviceability of the transmission after finding metal particles in the oil.
- (1) Drain transmission, oil cooler, and connecting lines.

(2) Clean chip detector and oil pump inlet screen, and inspect and discard oil filter.



Note condition of packings, seals, and gaskets before reinstallation of units. Replace if damaged.

- (3) Install chip detector, oil pump inlet screen, and new oil filter element.
- **(4)** Service transmission with proper oil. Refer to paragraph 1-10.
- (5) Ground-run helicopter for one hour. Drain oil into a clean container and inspect for chips. Inspect chip detector and filter for chips. If the number of particles has increased, or if any particles are found which may be visually identified as chips or flakes from a bearing or gear, replace the transmission and oil cooler. If the number of particles has decreased and only minute particles are found, continue the transmission and oil cooler in service.
- **b.** The following procedure should be employed if any doubt exists as to the serviceability of the 90-degree tail rotor gearbox.
  - (1) Drain gearbox.
- (2) Flush gearbox with clean oil (C103). Inspect oil for chips.

### **NOTE**

Note condition of packings, seals, and gaskets before reinstallation of units. Replace if damaged.

- (3) Clean chip detector and reinstall with drain plug.
  - (4) Service gearbox with proper oil (C103).
- (5) Ground-run helicopter for one hour. Drain oil into a clean container and inspect for chips. Inspect chip detector for chips. If the number of particles has increased, or if any particles are found which may be visually identified as chips or flakes from a bearing or gear, replace gearbox. If the number of particles has decreased and only minute particles are found, continue the gearbox in service.

# SECTION I. MAIN DRIVESHAFT

# 6-7. MAIN DRIVESHAFT.

- **6-8. Description Main Driveshaft.** A main driveshaft is installed between the freewheeling coupling on the engine and the adapter flange on the transmission input quill. The two main driveshaft configurations are as follows:
- **a.** Main driveshaft (16, figure 6-2, sheet 1) P/N 206-040-100-13 has spherical gear type flexible couplings at each end to permit angular and axial deflections. A spring in each coupling assists centering of shaft during operation. Lubrication is required.
- **b.** Main driveshaft (26, figure 6-2, sheet 2) P/N 206-040-371-111 consists of a center shaft with flexible couplings at each end. The couplings have several rectangular metal frames that flex to permit angular and axial deflection. A hub on the end adapter permits limited operation if a flexframe or bolt fails. No lubrication is required.

### 6-9. Inspection - Main Driveshaft (Installed).

- **a.** Inspect main driveshaft (16, figure 6-2, sheet 1) P/N 206-040-100-13 for the following:
- (1) Loose, missing, or damaged installation hardware.
- (2) Grease leakage. If found, remove and inspect.
- (3) Cracks, scratches, nicks, dents, and corrosion. Refer to paragraph 6-13, step a. for limits.

**b.** Inspect main driveshaft (26, figure 6-2, sheet 2) P/N 206-040-371-111 for the following:

### NOTE

Inspect flex element fasteners visually and by finger pressure only. Evidence of looseness or turning the fasteners by wrench or any other means is cause for replacement of the assembly. Slippage marks are applied by the manufacturer. These may be reapplied if there is no evidence of tampering or relative motion.

- **(1)** Loose, missing, or damaged installation hardware.
- (2) Cracks, scratches, nicks, dents, and corrosion. Refer to paragraph 6-13, step b. for limits


### 6-10. Removal — Main Driveshaft.

- a. Remove main driveshaft P/N 206-040-100-13.
- (1) Remove transmission fairing and open engine cowling to gain access to main driveshaft (16, figure 6-2, sheet 1). Refer to paragraph 2-39 A or 2-40 C.
- (2) From right side of helicopter remove two screws (6) necessary to remove driveshaft cover (8) and cone assembly (18).
- (3) Remove eleven screws (14) securing driveshaft door (5) to aft side of forward firewall (15).

# CAUTION

If main driwshaft is being removed to facilitate maintenance on another component, lubrication of the assembly is not necessary. Compress couplings only enough to release them from mating adapter flange. If couplings are compressed considerably more than required to release them from mating adapter flange, the main driveshaft should be disassembled, inspected, and relubricated.


- (4) Remove four bolts (3), eight washers (2), and four nuts (1) attaching forward driveshaft coupling to input adapter on transmission.
- (5) Remove four bolts (9), eight washers (10), and four nuts (11) attaching aft driveshaft coupling to freewheeling adapter flange.
- (6) Push aft on forward coupling to compress springs and obtain clearance between forward driveshaft coupling and input adapter flange. Move forward end of driveshaft outboard to clear input adapter flange. Move driveshaft assembly aft passing forward coupling through opening and remove from helicopter.




- 3. Bolt
- 4. Gasket
- 5. Door, Driveshaft
- 6. Screw
- 7. Gasket
- 8. Cover, Driveshaft
- 9. Bolt

- 12. Freewheeling Assembly
- 13. Rotor Brake Mounting Studs \*
- 14. Screw
- 15. Forward Firewall16. Main Driveshaft Assembly
- 17. Transmission
  18. Cone Assembly

\*Not used



# LOOKING INBOARD FORWARD, RIGHT SIDE



# LOOKING INBOARD FORWARD, RIGHT SIDE

# MAIN DRIVESHAFT P/N 206-040-371-111

- 19. Screws 20. Delete
- 21. Closure Plate and Gasket
  - 22. Forward Firewall
- 23. Washer
- 24. Screw
- 25. Cover Assembly and Gasket
- 26. Main Driveshaft

- 27. Nut
- 28. Washer
- 29. Quill Adapter
- 30. Bolt
- 31. Bolt
- 32. Freewheeling Unit Adapter
- 33. Washer
- 34. Nut

Figure 6-2. Maim Driveshaft (Sheet 2)





Figure 6-2. Main Driveshaft (Sheet 3)



- 4 MAKE FROM 1/4 INCH STEEL BOLT.
- 5 MAKE FROM 3/16 INCH MILD STEEL.
- 6 BREAK ALL SHARP EDGES, CHAMFER 0.030 INCH X 45 DEGREES.

**WORK AID FOR MAIN DRIVESHAFT** P/N 206-040-371-111 REMOVAL/INSTALLATION

Figure 6-2. Main Driveshaft (Sheet 4)

- (7) If main driveshaft (16) does not require disassembly, cut strips of cardboard or wood of sufficient length to fit between the two couplings (10, figure 6-3). Place material on main input shaft (16) and secure with masking tape (C143). This will aid in preventing the collapse of outer adapters.
  - **b.** Remove main driveshaft P/N 206-040-371-111.

Access to the driveshaft for removal is through the transmission cowling door on the right side. Removal will be easier if the transmission cowling is removed. Tube referred to in par. (6) is the particle seperator bleed air tube illustrated in figure 4-3.

- (1) Open engine cowling to gain access to main driveshaft (26, figure 6-2, sheet 2). Refer to paragraph 2-39 A or 2-40 C.
- (2) Remove screws (24) and washers (23) from main driveshaft cover assembly and gasket (25). Remove main driveshaft cover assembly and gasket (25) from forward firewall (22).
- (3) Remove screws (19) and washers (20) securing closure plate and gasket (21) to forward firewall (22).
- (4) Remove four nuts (34), eight washers (33), and four bolts (31) connecting aft fitting of main driveshaft (26) to freewheeling unit adapter (32).
- (5) Remove four nuts (27), eight washers (28), and four bolts (30) connecting forward fitting of main driveshaft (26) to transmission input quill adapter (32).
- **(6)** Remove tube extending from bottom of centrisep to firewall mounted tee on forward side of forward firewall (22).
- (7) Fabricate work aid (35, figure 6-2, sheet 3) as shown in figure 6-2, sheet 4.
- (8) Install work aid (35, figure 6-2, sheet 3) by positioning lugs of the two tightening screws over head of flexframe nut (36) at aft end of main driveshaft (26).

**(9)** Place the two split-halves of work aid (35) over main driveshaft (26) and attach tightening screws with wing nuts.

### **CAUTION**


Main driveshaft should be compressed only to the extent necessary for removal to avoid damage.

- (10) Free main driveshaft (26) from freewheeling unit adapter (32) and transmission input quill adapter (29) by turning wing nuts of work aid (35) to compress main driveshaft (26).
- (11) Remove main driveshaft (26) and place on suitable work surface.
- (12) Remove work aid (35) from main driveshaft (26).
- 6-11. Disassembly Main Driveshaft P/N 206-040-100-13.
- **a.** Remove retaining ring (6, figure 6-3) from outboard end of coupling (10).
- **b.** Remove retainer ring (15) from inboard end of coupling (10).

## NOTE

After coupling and spur gear have been run together, they should not be changed from their original position to each other or intermixed from transmission end or freewheeling end of main input shaft. Before disassembly, index mark (paint or felt tip marker) in such a manner that marks will not be obliterated during maintenance. Do not use vibro-etch or stamping to mark parts.

- **c.** Remove coupling (10) from driveshaft coupling seal (13) and spur gear (12).
- **d.** Remove shaft centering spring (9) from coupling (10).
- **e.** Remove grease retainer plate (8) with packing (7) from outboard end of coupling (10).



- 6. Retainer Ring 7. Packing 8. Plate, Grease Retainer
- 9. Spring, Shaft Centering
- 14. Packing
- 15. Retainer Ring
- 16. Main Input Shaft
- 17. Nut
- 18. Washer

206040-475

Figure 6-3. Disassembly - Main Driveshaft

f. Repeat steps b. through e. for disassembly of coupling (10) on opposite end of main input shaft (16).

#### **CAUTION**

Do not scratch seal with tools or other rough objects.

- g. Remove three bolts (11), washers, (18), and nuts (17) attaching spur gear (12) to flange on main input shaft (16). Hold nut (17) with wrench to prevent nut from turning with bolts and scoring shaft. Release of shaft from spur gear will also release driveshaft coupling seal (13) which is assembled on end of shaft.
- h. Repeat above instructions for disassembly of coupling assembly on other end of shaft.
- 6-12. Cleaning Main Driveshaft.
  - a. Clean main driveshaft P/N 206-040-100-13.

#### **CAUTION**

Do not use solvent to clean main driveshaft packings or seals.

- (1) Clean all parts with clean wiping cloths dampened with drycleaning solvent (C62).
- (2) If necessary, blow dry ail parts with dry filtered, compressed air before assembly.
  - b. Clean main driveshaft P/N 206-040-371-111.
- (1) Clean all parts with clean wiping cloths dampened with drycleaning solvent (C62).
- (2) If necessary, blow dry all parts with dry, filtered, compressed air before assembly.
- 6-13. Inspection Main Driveshaft (Removed).
  - a. Inspect main driveshaft P/N 206-040-100-13.
- (1) Visually inspect all parts for damage. Inspect the surfaces of coupling (10, figure 6-3) and main input shaft (16) for nicks and scratches. Maximum limits are 0.002 inch deep around entire circumference of 0.005 inch deep, axial or circumferential, but no longer than


one-quarter circumference. Dress out acceptable nicks and scratches with sandpaper (C 125) as required. Apply epoxy polyamide primer (C116. 1) to repaired areas or to all external surfaces including coupling mating surfaces if rework is extensive. Inspect shaft centering spring (9) for a minimum length of one inch with a compression load of 14.5 to 15.5 pounds or a free standing height of 1.900 (±0.100) inches.

- (2) Inspect splines of spur gear (12) for chipped, cracked, worn teeth or evidence of overheating. Inspect spur gear for pitting and corrosion. Maximum corrosion depth shall not exceed 0.002 inch. Chips must be cleaned up within the limits of paragraph 6-13, step a. Spur gear wear limits are listed in figure 6-4, sheet 1.
- (3) Inspect seal grooves in each end of main input shaft (16) and adjacent surfaces to determine that they are not damaged or corroded and surfaces are smooth. Inspect inside diameter of main input shaft for corrosion and pitting. If inside diameter is corroded, proceed as follows:
- (a) Remove surface corrosion and pitting with sandpaper (C125) or (C126). Sandpaper may be attached to a rotary drill bit, or equivalent. Surface may be wet polished using drycleaning solvent (C62). Honing is also an acceptable method for removal of corrosion and minor pitting.
- (b) Inside diameter of main input shaft after cleanup must not exceed 0.843 inch. If main input shaft cannot be cleaned up within these limits, it must be replaced.

#### **NOTE**

Inside diameter must be thoroughly abraded, prior to treatment, to ensure good adhesion.

- (c) After removal of corrosion and pitting, thoroughly clean inside diameter with drycleaning solvent (C62).
- (d) Apply epoxy polyamide primer (C116) to the inside diameter by flowing primer into bore while rotating shaft. Place main input shaft in upright position after ensuring complete coverage of inside diameter. Allow to drain and dry. Second coat, after drying, is required.



MAIN DRIVESHAFT P/N 206-040-100-13

ITEM	NOMENCLATURE		REPLACE
1.	Coupling, Adapter Alignment Seat,	ID	3.4376 Inch
	Spherical Outer		Δ
2.	Adapter		<b>2</b>
3.	Spur Gear	OVER	3.3814 Inch
	(Úse 0.2057 inch diameter pins)	PINS	
4.	Coupling, Shaft Seat, Spherical Inner	ID	1.0915 Inch
5.	Main Input Shaft	OD	1.0880 Inch


# NOTES:

Surfaces B and B to be square with diameters A and A within 0.001 inch TIR.

Maximum allowable depth of wear on face of spline is 0.006 inch determined by measuring from worn to unworn area of spline. To accurately check for excessive wear, a straight edge and wire feeler gage must be used. Refer to figure 6-5.

206040-476-1

Figure 6-4. Damage Limits — Main Driveshaft (Sheet 1 of 2)



# MAIN DRIVESHAFT P/N 206-040-371-111

# **DAMAGE LOCATION SYMBOLS**

TYPE OF DAMAGE		MAXIMUM DAMAGE	AND REPAIR DEPTH	
MECHANICAL	0.001 In. before and after repair	0.005 In. before and after repair	0.005 In. before and after repair	0.015 In. before and after repair
CORROSION	Surface. no pits	0.005 ht. before and after repair	0.005 In. before and after repair	0.010 ht. before and after repair
MAXIMUM AREA PER FULL DEPTH REPAIR	<b>3</b> 0.05 Sq. in.	0.10 Sq. in.	<b>3</b> 0.26 Sq. in.	0.25 Sq. in.
NUMBER OF REPAIRS	One per leg			
EDGE DENTS, NICKS	0.001 ln.	0.010 In.	0.010 ln.	0.025 ln.

# NOTES:

No cracks ara permitted.
 Repairs must be no lass than 1.000 inch apart.
 Repairs not to be within 0.500 in. of bolt hole.
 Faying surfaces must be free of any raised metal areas.

206040-476-2

Figure 6-4. Damage Limits — Main Driveshaft (Sheet 2)

- (4) Roll main input shaft (16) on a flat surface to check for distortion. If main input shaft appears to be distorted, verify by supporting main input shaft between centers and check runout of flanges with a dial indicator. Flange faces (Surfaces B, figure 6-4, sheet 1) to be square within **0.001** inch total indicated reading (TIR).
- (5) Inspect spline teeth of outer coupling in accordance with figure 6-5. Position a metal straight edge against the face of the tooth being inspected. Straight edge must be of sufficient length to span entire tooth. Insert a **0.006** inch wire gage (T47) into wear area to determine the amount of wear. Maximum allowable tooth wear is **0.006** inch. The coupling and its mating spur gear may be reversed on the same end of the main input shaft from which it was removed. This will change the drive side of the coupling and spur gear to the coast side, allowing longer use of the coupling assembly. Couplings with wear in excess of 0.006 inch on both sides of teeth shall be replaced. Visually inspect teeth for cracks, chipping, or evidence of overheating. Chips and nicks must be cleaned up within the limits of paragraph 6-13, step a.
- **(6)** As an aid to detect overheating in operation, paint strips may be applied to the coupling (10, figure 6-3) as follows:
- (a) Clean outer surface of coupling (10) with MEK (C107).

Inadequate cleaning or contact with oil or grease may cause discoloration and false heat indication.


- **(b)** Mask and spray two 1-inch wide strips 180 degrees apart lengthwise on the O.D. of the coupling with zinc chromate primer (C118), or epoxy polyamid primer (C116).
- (7) If overheating of coupling (10) is suspected because of external heat strip indicator or light internal discoloration, examine the external cadmium plating for signs of heat discoloration or blistering. If no external indications are found, the coupling may be considered acceptable.
  - (8) Limits for corrosion pitting are as follows:

- (a) Corrosion on mating surfaces of main input shaft (5, figure 6-4, sheet 1) and spur gear (3) must be cleaned up within the limits shown. Scattered pitting not exceeding **0.002** inch depth is permitted, provided no more than five percent of the mating surface is affected.
- **(b)** Refer to paragraph 6-13, step a. (3)(b), for main input shaft I.D. limits.
- **(c)** Corrosion on spline tooth surfaces must be cleaned up within the wear of paragraph 6-13, step a.(5).
- **(d)** For all other areas, corrosion must be cleaned up within the damage limits of paragraph 6-13, step a.(1).

#### NOTE

Replacement of missing or debonded identification plates is not required. There are normally two ID plates located midpoint of the main input shaft, 180 degrees apart. If these plates become debonded or lost, it is not necessary to replace or rebond them.

- (9) Inspect driveshaft coupling seals (13, figure 6-3) for condition and replace as necessary. If boot portion of seal becomes detached from metal cone, it is not cause for replacement. Boot may be rebonded to metal cone by lightly sanding surfaces to be bonded with sandpaper (C124) and cleaning the areas with MEK (C107). Apply a bead of cement (C36) to flange of cone and press in place on seal.
- (10) Inspect grease retainer plate (8) for damage limits and replace as necessary.
- (a) Maximum mechanical damage is 0.010 inch.
- **(b)** Maximum corrosion damage **0.030** inch before cleanup.
- **(c)** No mechanical damage is permitted in packing seat.



206040-477

Figure 6-5. Spherical Outer Coupling Spline Teeth - Inspection

(11) Inspect parts listed below and show in figure 6-3, using magnetic particle method (Code M) or fluorescent penetrant method (Code F) if the accompanying records and/or physical appearance of component indicates that the component has been subjected to an accident or incident outside the realm of normal usage. Refer to TM 55-1500-335-23.

ITEM NO.	NOMENCLATURE	CODE
8.	Plate, Grease Retainer	F
9.	Spring, Shaft Centering	M
10.	Coupling	М
12	Spur Gear	М
16.	Main Input Shaft	М

- **(a)** Inspect spring, shaft centering (9, figure 6-3) with circular field using 3/4 inch central conductor, magnetize at 500 amperes.
- **(b)** Inspect coupling, outer (10, figure 6-3) with circular field using 1 inch central conductor, magnetize at 1200 amperes.
- **(c)** Inspect spur gear (12, figure 6-3) with circular field using 1 inch central conductor, magnetize at 1500 amperes.
- **(d)** Inspect shaft (16, figure 6-3) with circular field using 3/4 inch central conductor, magnetize at 1200 amperes. Inspect with longitudinal field at 6000 ampere-turns.
- (12) Discard packings (7 and 14) and nuts (17).
  - **b.** Inspect main driveshaft P/N 206-040-371-111.
- (1) Inspect main driveshaft to damage limits shown in figure 6-4, sheet 2.

## **CAUTION**

Main driveshaft assembly is not to be taken apart, and fasteners are not to be disturbed. Disassembly or disturbing fasteners is cause for replacement.

#### **NOTE**

Minimize removal of protective coating during repair. Repair must be within limits shown.

(2) Repair by removing corrosion and damage using abrasive pads (C154).

(3) Damage to protective coating (removal) of base metal may be touched up with zinc chromate primer (C118) and top coated with silver sermetel paint (C156).

### NOTE

Areas left bare, smaller than damage limits shown, will not corrode due to sacrificial properties of original protective coating.

6-14. Assembly — Main Driveshaft P/N 206-040-100-13.

- **a.** Position retainer ring (15, figure 6-3) loosely over main input shaft (16). It will be used later to retain driveshaft coupling seal (13) in coupling (10).
- **b.** Apply a light coating of grease (C79) to packing (14) and install in groove on outer edge of driveshaft coupling seal (13). Install rubber portion of driveshaft coupling seal (13) in groove on main input shaft (16).


# **CAUTION**

The main driveshaft has both lightening holes and bolt holes. Ensure holes in spur gear are aligned with the three smaller holes in the driveshaft.

- **c.** Secure spur gear (12) to main input shaft (16) using three bolts (11), washers (18), under bolt heads only, and nuts (17). Hold nuts (17) with wrench to prevent turning and scoring shaft. Torque bolts (11) 50 TO 70 INCH POUNDS.
- **d.** Apply a light coating of grease (1) (C79) to packing (7) and install in groove of grease retainer plate (8). Install grease retainer plate (8) in coupling (10) and secure with retainer ring (6).
- **e.** Repeat steps a. through d. on opposite end of main input shaft (16).
- **f.** Evenly distribute grease (C79) over spline teeth of couplings (10) to a depth of 0.200 to 0.300 inch. Refer to figure 6-3, detail A. Use work aid (figure 6-6) to smooth grease (C79).
- **g.** Place couplings on work bench with open end up. Install shaft centering spring (9, figure 6-3) in the depression of the grease retainer plate (8).

#### NOTE

Coupling and spur gear shall be indexed together, but may be installed reversed as a unit in the same position relative to transmission or freewheeling unit from which it was removed. Refer to previously applied index marks.



- All dimensions are in inches.
   Make work aid from plexiglass.

206040-478

Figure 6-6. Work Aid For Coupling Grease Distribution

# **CAUTION**

Do not force spur gear into the coupling any further than necessary to seat the driveshaft coupling.

- h. Install spur gear (12) into the coupling (10) while supporting driveshaft coupling seal (13) to ensure proper installation into coupling (10). When driveshaft coupling seal (13) is properly seated, secure with retainer ring (15).
- i. Repeat step h. on opposite end of main input shaft (16).

#### NOTE

If main driveshaft will not be immediately installed, cut strips of cardboard or wood (or any other suitable work aid that will not damage the assembly) of sufficient length to fit between the couplings. This work aid will prevent the collapse of the couplings and subsequent displacement of grease.

- 6-15. Installation Main Driveshaft.
  - a. Install main driveshaft P/N 206-040-100-13.
- (1) Move main driveshaft (16, figure 6-2, sheet 1) forward, passing forward coupling through opening in forward firewall (15). Place aft coupling on freewheeling unit adapter flange and push aft on forward coupling to compress springs. Move main driveshaft (16) inboard to position forward coupling on transmission input quill adapter flange.
- (2) Align forward coupling attachment bolt holes and install four bolts (3), eight washers (2), and four nuts (1). Using torque adapter (T4), torque nuts 50 TO 70 INCH-POUNDS.

### **NOTE**

Install washers (2) and (10) under nuts (1) and (11) as shown in figure 6-2. Do not install washers under the head of bolts, (3) and (9). Do not allow heads of bolts (3) and (9) to rotate when tightening or torquing nuts. Ensure that hex point of bolts do not contact coupling surface.

- (3) Align aft coupling attachment bolt holes and install four bolts (9), eight washers (10), and four nuts (11). Using torque adapter (T4), torque nuts 50 **TO** 70 **INCH-POUNDS.**
- (4) Install driveshaft door (5) and gasket (4) on aft side of forward firewall (15) with 11 screws (14).

# WARNING

Both sections of driveshaft cover must be installed prior to flight as it is part of the forward firewall.

- (5) Bond gaskets (7) to driveshaft cover (8) with proseal 890 (C17) prior to installation of cone assembly (18) to the driveshaft door (5).
- (6) Ensure there is adequate clearance between the lip of the driveshaft rover (8) and the main driveshaft assembly (16). A maximum of 0.260 inch may be filed from lip cover to ensure clearance.
- (7) Install driveshaft cover (8) on driveshaft door (5) with two screws (6).
- (8) Install transmission fairing and engine cowling. Refer to paragraph 2-39 A or 2-40 C.
  - **b.** Install main driveshaft P/N 206-040-371-111.

# NOTE

Original firewall cover (8) and cone assy. (18) cannot be used with drive shaft 208-040-371-111. Remove 7 rivets securing right side of cover (8) to door (5). Position new cover (25) 205-062-902-101 on aft side of door with flange forward and locate rivets. Remove cover, drill rivet holes, and dimple upper rivet hole to clear dimple on door (rivet in this location is flush to allow door to fit on firewall). Install right side of cover (25) on door with 6 rivets MS20613-3C(3/32 Univ. head CRES) and 1 rivet MS20427M3 (3/32 flush Monel). Remove left half of cover assy. (8) from firewall by removing 4 screws (24).

- (1) Install work aid (35, figure 6-2, sheet 3) by positioning lugs of the two tightening screws over head of flexframe nut (36) at aft end of main driveshaft (26).
- (2) Place the two split-halves of work aid (35) over main driveshaft (26) and attach tightening screws with wing nuts.

# CAUTION

Main driveshaft should be compressed only to the extent necessary for installation to avoid damage.

- (3) Compress main driveshaft (26) by turning wing nuts of work aid (35).
- (4) Install main driveshaft (26) between transmission input quill adapter (29) and freewheeling unit adapter (32).

#### NOTE

To facilitate future maintenance and inspections, install main driveshaft so the Serial No. is visible from the aft side. Install main driveshaft through door on right side of cowling or remove transmission cowling.

(5) Line up bolt holes in aft fitting of main driveshaft (26) with freewheeling unit adapter (32) bolt holes.

## NOTE

To aid In alignment, a bolt can be Installed through driveshaft fittings, transmission Input quill adapter, and freewheeling unit adapter before work aid Is removed.

(6) Remove work aid (35) from main driveshaft (26).

#### **NOTE**

Install washers under nuts as shown. Do not Install washers under head of bolts.

(7) Install four bolts (31, figure 6-2, sheet 2) through aft fitting of main driveshaft (26) and freewheeling unit adapter (32). Install eight washers (33) and four nuts (34). Torque nuts (34) 50 TO 70 INCH-POUNDS.

#### NOTE

Install washers under nuts as shown. Do not Install washers under head of bolts.

(8) Install four bolts (30) through forward fitting of main driveshaft (26) and input quill adapter (29). Install eight washers (28) and four nuts (27). Torque nuts (27) 50 TO 70 INCH-POUNDS.

#### **WARNING**

Both sections of driveshaft cover must be installed prior to flight as It is part of the forward firewall.

(9) Install driveshaft cover assembly and gasket (25).

- (a) Install closure plate and gasket (21) on aft side of forward firewall (22). Secure closure plate and gasket (21) with screws (19).
- (b) Install new driveshaft cover (25) 206-062-902-103 on left side of the forward firewall (22) and secure with screws (24) and washers (23).
- (10) Install tube extending from bottom of centrisep to firewall mounted tee on forward side of forward firewall (22).
- (11) Close and secure engine cowling. Reinstall transmission cowling if removed.

# 6-16. SEALS (MAIN DRIVESHAFT P/N 206-040-100-13).

- **6-17. Description Seals**. Preformed spherical driveshaft coupling seals (13, figure 6-3), grease retainer plate (8), and packing (7) are grease retaining components of the flexible coupling (10) installed on each end of the main driveshaft. Couplings are serviced with grease (C79) as required in figure 6-3.
- **6-18. Inspection Seals**. Inspect seals for cuts, tears, and general deterioration.
- **6-19. Removal Seals**. Refer to paragraph 6-11.
- 6-20. Repair/Replacement Seals.
- a. Replace seals as necessary with like serviceable item.
- b. Metal cone becoming detached from boot of drive-shaft coupling seal (13, figure 6-3) is not cause for replacement. Rebond with cement (C36).
- **6-21. Installation Seals**. Refer to paragraph 6-14.

#### SECTION II. CLUTCHES

# 6-22. FREEWHEELING ASSEMBLY.

6-23. Description - Freewheeling Assembly. The freewheeling unit is mounted on the engine gearbox and its shaft is splined directly to the power take-off gear shaft. Engine power is trensmitted to the outer race of the freewheeling assembly, then through the full-phasing sprag elements of the unit which couples the outer race to the inner race shaft. The inner shaft adapts to the transmission driveshaft and the tail rotor driveshaft to provide power to the main and tail rotors respectively. During autorotation the main rotor drives the tail rotor through the inner shaft while the sprag clutch provides a disconnect to the outer race and hence the engine. The freewheeling assembly is lubricated from the transmission lubrication system. Lubrication oil is metered through an orifice fitting, through flexible hoses, to the aft freewheeling assembly housing. After the oil has flowed forward through the freewheeling shafts to the forward housing, it is pumped, by centrifugal action of the outer race, through a flexible return hose to the transmission sump.

# Premaintenance Requirements for Maintenance of Freewheeling Assembly

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	(T32)
Test Equipment	None
Support Equipment	Heat Lamp
Minimum Personnel Required	Two
Consumable Materials	(C6) (C51) (C55) (C59) (C62) (C84) (C101)(C103)(C118) New Packings
Special Environmental Conditions	None

# 6-24. Inspection — Freewheeling Assembly (Installed).

**a.** Inspect vent assembly, lubrication fittings, seals, and hoses for leakage and security.

#### **NOTE**

Oil leekaga at the aft bearing cap of the freewheeling unit shall not exceed one drop per minute and leakage at the forward seal shall not exceed two drops par minute.

**b.** Inspect housing for cracks and security of attachment.

### 6-25. Removal — Freewheeling Assembly.

- **a.** Remove forward short tail rotor driveshaft. Refer to paragraph 6-132.
- **b.** Remove engine to transmission driveshaft. Refer to paragraph 6-10.
- **c.** Remove drain plug (1, figure 6-7) and drain oil from freewheeling unit.
- **d.** Disconnect input oil line from reducer (27) on side of housing (7) on aft end of engine accessory gearbox. Cap or plug openings.
- **e.** Remove cotter pin (2), nut (3), and washer (4) from aft end of freewheeling shaft. Hold front flange with holding tool (T32).
- **f.** Remove nuts (5) and washers (6) securing aft bearing housing (7) to aft end of engine accessory gearcase.
- g. Remove tail rotor drive gear (8) and aft bearing housing (7) together,
- **h.** Remove stud nuts (11) and washers (12) securing freewheeling forward bearing cap to freewheeling case.
- i. Tap aft end of shaft with plastic mallet to remove freewheeling assembly from housing.






Figure 6-7. Freewheeling Assembly (Sheet 1 of 2)





# NOTES:

1 Used on 206-040-238-9 Housing Assembly.

2. All dimesions are in inches.

206040-479-2

Figure 6-7. Freewheeling Assembly (Sheet 2)

The freewheeling shaft assembly (25) is an assembly of components comprised of freewheeling inner race shaft with plug in forward end, forward bearing and seal cap assembly, freewheeling outer race shaft with bearings and clutch assembly. This assembly is removed from freewheeling housing and engine accessory gearbox as a unit. Removal of the freewheeling housing is not recommended unless it is necessary for engine gearbox seal replacement, change of engine or inspection, repair or replacement of the housing.

# 6-26. Cleaning — Freewheeling Assembly.

- **a.** Clean all parts with drycleaning solvent (C62). Dry with dry air.
- **b.** Do not permit bearings to spin when drying with compressed air.
- **6-27.** Inspection Freewheeling Assembly. Inspect the-freewheeling assembly after cleaning for the following:

### **NOTE**

Parts should be inspected immediately after cleaning. Exercise care to avoid getting fingerprints on bearing surfaces.

- a. If freewheeling assembly has been subjected to an overtorque or sudden stoppage, remove assembly and refer to AVIM. If overtorque or sudden stoppage has not occurred, proceed with inspection procedures.
- **b.** Check for mechanical damage to the external surfaces of the assembly and housing.
- **c.** Inspect parts for nicks and scratches. Dress out minor nicks and scratches and apply protective coating where required.
- **d.** Check for free rotation of the input drive and proper operation of the freewheeling clutch, turning the unit by hand. If aft seal (37, figure 6-8) is leaking replace seal and inspect bearings (33, figure 6-8) per paragraph 6-27, step e.

- **a.** Check bearing (33, figure 6-8) for flat or rough spots by holding tail rotor drive gear (38) and rotate housing (34) with bearing installed.
- **f.** Visually inspect splines for wear, cracks, and damage. When wear is indicated, refer to figure 6-9.

# 6-28. Disassembly — Freewheeling Assembly. (AVIM)

- **a.** Remove retaining ring (1, figure 6-8) from end of shaft (9). Remove vent valve housing (3) or plug (41) (whichever is installed) with packing (2).
- **b.** Rework vent valve housing (3) in accordance with paragraph 6-31.
- **c.** Apply heat lamp to rear area of outer race shaft (25). When thoroughly heated, tap unit on aft end of inner race shaft (9) on a block of wood to push shaft (9) from cap (13) and outer race shaft (25).
- **d.** Remove retaining ring (15) from outer race shaft (25).
  - e. Remove packing (26) from outer race shaft (25).
- f. Obtain a sleeve for use as a support to support end of outer race shaft (25) while removing bearing (16), guide ring (17), and clutch (18). The sleeve must be of suitable diameter to support end of shaft with I.D. of sleeve larger than O.D. of bearing and clutch. Apply heat lamp to outer race shaft (25). When shaft is thoroughly warm, hold support sleeve against outer end of shaft and bounce sleeve and shaft on a block of hardwood to remove bearing (16), guide ring (17), and clutch (18).
- g. Remove retaining ring (19) from outer race shaft (25). Apply heat to shaft and bounce end of shaft on a hardwood block to remove bearing (24).
- **h.** Disassemble forward bearing and seal cap (13) as follows:
  - (1) Remove packing (14) from cap (13).
- (2) Remove retaining ring (10) from cap (13) and remove seal (11).
- (3) Apply heat to cap (13) and remove bearing (12). Bearing should slide out with finger pressure.




Figure 6-8. Freewheeling Assembly - Exploded View (Sheet 1 of 3)




Figure 6-8. Freewheeling Assembly - Exploded View (Sheet 2)

- 1. Retaining Ring
- Packing
- 3. Valve Housing, Vent Assembly
- 4. Packing
- 5. Vent Valve
- 6. Valve Spring, Vent Assembly
- 7. Washer, Vent Assembly
- 8. Retaining Ring
- 9. Gearshaft
- 10. Retaining Ring
- 11. Seal
- 12. Bearing, Roller
- 13. Cap
- 14. Packing
- 15. Retaining Ring
- 16. Bearing, Roller
- 17. Guide Ring
- 18. Clutch Assembly, One Way
- 19. Retaining Ring
- 📐 20. Drain Plug and Packing
- 21. Lubrication Fitting
- 22. Bolt and Packing
- 23. Union and Packing
- 24. Bearing, Ball
- 25. Gaershaft

- 26. Packing
- 27. Housing Bushing
- 28. Housing, Freewheeling (206-040-236-5)
- Housing, Freewheeling (206-040-236-9)
- 30. Gasket
- 31. Shim
- 32. Retaining Ring
- Bearing 33.
- 34. Packing
- 35. Bearing Housing
- Reducer and Packing 36.
- 37. Seal
- 38. Tail Rotor Drive Gear
- 39. Washer
- 40. Nut
- **∕2**\41. Plua
  - Nut, Clinch 42.
  - 43. Washer, Flat
  - 44. Nut, Self-locking
  - 45. Bearing Liner
  - 46. Pin
  - 47. Cotter Pin
  - 48. Identification Plate

# NOTES:

/I\ Used on Housing, Freewheeling, P/N 206-040-236-9.

Plug, item 41, replaces item 3 through 8 in lieu of repair.

206040-480-3

Freewheeling Assembly - Exploded View (Sheet 3) Figure 6-8.

- i. Disassemble aft bearing housing (35) as follows:
- Remove packing (34) from aft bearing (1) housing.
  - (2) Remove retaining ring (32) from housing.
- (3) Apply heat lamp to housing and press tail rotor drive gear (38) with bearing (33) from housing.

If bearing inner race is not properly supported during drive gear removal, damage may occur requiring bearing replacement.

(4) Support bearing (33) inner race and press drive gear (38) from bearing.

- (5) Remove seal (37) from housing (35).
- (6) Remove reducer fitting and packing (36).

# 6-29. Inspection — Freewheeling Assembly. (AVIM)

### NOTE

Exercise care to avoid corrosion to bearing surfaces, and avoid getting fingerprints on bearing surfaces. Oil parts immediately after inspection using lubricating oil (C103).

- Visually inspect all parts for wear or damage.
- b. Visually inspect splines of shafts for chipped, broken, or worn teeth.




Figure 6-9. Limit Chart - Freewheeling Assembly (Sheet 1 of 2).

ITEM	NOMENCLATURE		REPLACE
1.	Shaft — Drive Shaft Adapter Shoulder — Pilot Dia	OD	3.4345
2.	shen — Seel end Forwerd Bearing — Inner Race (See Note)	OD	2.0010
3.	Shaft — Clutch Inner Race	OD	1.9569
3. 4. 5.	Shaft — Inner Bearing Set	OD	0.9841
5.	Shaft — Tail Rotor Drive Adapter	OD	0.6325
6.	Shaft — Spline (use 0.1200 diameter pins)	OVER PINS	0.7279
7.	Cap — Bearing Seat — Freewheeling Unit	ID	2.6774
8.	Bearing — Forward Roller (Two Required)	OD	2.6767
9.	Bearing — Forward Ball `	ID	0.9844
10.	Bearing — Forward Ball	OD	2.0467
11.	Shaft — Forward roller Bearing Seat — Outer Bearing	ID	2.6774
12.	Shaft — Clutch Outer Race	ID	2.6145
13.	Shaft — Bail Bearing Seat	ID	2.0473
14.	Shaft — Spline	OVER	1.3446
	99 (use 0.0960 diameter pins)	PINS	
15.	Housing — Bearing and Seal Cap Seat	ID	3.6281
16.	Bearing — Aft	ID	0.7875
17.	Bearing — Aft	OD	1.8500
18.	Housing - Bearing Seat	ID	1.8506
19.	Adapter — Tail Rotor Drive	ID	0.6360
20.	Adapter — Bearing Seat — Tail Rotor Drive	ID	0.7674
21.	Adapter — Spline — Tail Rotor Drive	OVER	1.1070
	(use 0.1200 diameter pins)	PINS	
22.	Adapter — Spline — Tall Rotor	BET-	
	Drive	WEEN	0.3979
	(use 0.1080 diameter pins)	PINS	4.0000
23.	Adapter - Seal Seat — Tail Rotor Drive	QD	1.0580
24.	Cap-Seal Seet-Freewheeling Unit	ID	2.6920
NOTE:	Maximum allowable wear in roller bearing path on the diamete difference in the diameter in the worn and unworn areas.	r is 0.0002 inch, dete	rmined by the

Figure 6-9. Limit Chart — Freewheeling Assembly (Sheet 2)

- **c.** Visually inspect roller bearing inner race area and clutch bearing areas on shafts (9 and 25, figure 6-8) for corrosion, wear, brinelling, or other damage.
- **d.** Visually inspect clutch assembly (18) for wear, brinelling, or other damage.
- **e.** Inspect bearings (24 and 33) for smoothness and freedom of rotation by holding inner race and rotating outer race by hand.
- **f.** Inspect all parts for damage and/or wear in excess of allowable limits. Refer to figure 6-9.
- **g.** Inspect the following parts by magnetic particle (code M) for fluorescent penetrant (code F) method. Refer to TM 55-1500-335-23.

ITEM		
NO.	NOMENCLATURE	CODE
9	Gearshaft, Inner Race	М
13	Cap, Bearing and Seal	F
25	Gearshaft, Outer Race	M
35	Bearing Housing	F
38	Tail Rotor Drive Gear	M

- (1) Inspect gearshaft, inner race (9, figure 6-8) using direct electrical contact with copper braided pads. Magnetize gear drive at 500 amperes, shaft mount at 1200 amperes. Inspect with longitudinal field at 6000 ampere-turns.
- (2) Inspect gearshaft, outer race (25, figure 6-8) with circular field using 3/4 inch central conductor. Make two (2) equally spaced shots (180 degrees apart) at 1200 amperes.
- (3) Inspect tail rotor drive gear (38, figure 6-8) with circular field using 1/2 inch central conductor at 600 amperes.

# All parts must be demagnetized after magnetic particle inspection.

**h.** Visually inspect bearings (balls or rollers and races) for spalling, scoring, brinelling, or corrosion damage. Replace bearings which are rough, spalled, scored, pitted, flaked, or corroded.

#### 6-30. Repair- Freewheeling Assembly. (AVIM)

- a. Replace parts that are cracked, broken, warped, distorted, have malformed threads, or have corrosion damage in critical areas which would affect the function or structural integrity of the part.
- b. Replace all parts that exceed the allowable tolerances in figure 6-9.
- c. Repair minor nicks, scratches, or pits on noncritical surfaces with crocus cloth (C55).
- d. Replace broken, bent damaged, or loose studs. Inspect threaded holes in housing.

# 6-31. Rework - Freewheeling Assembly Vent Assembly. (AVIM)

#### NOTE

When available, plug (41, figure 6-8) should be installed in lieu of reworking vent assembly.

- a. With vent assembly removed, dean threaded hole with drycleaning solvent (C62).
- b. Fill center hole (forward end) with adhesive (6) and allow to cure for 24 hours at room temperature. (See detail C, figure 6-7.)
- c. Drill a 0.600 inch diameter hole through lip around center hole approximately 0.156 inch from valve housing ring. (This hole is to facilitate later vent assembly removal.)

# 6-32. Assembly - Freewheeling Assembly. (AVIM)

#### NOTE

During assembly, Install new packings and lubricate all bearings, races, shafts, packings, seals, and clutch with lubricating oil (C103).

- a. Apply heat lamp to outer race shaft (25, figure 6-8).
- b. Lubricate inner surface of shaft (25) and outer race surface of bearing (24). Using a suitable block on outer race of bearing (24), press bearing into outer shaft (25) and install retaining ring (19).
  - c. Assemble clutch as follows:

- (1) If clutch assembly (X136028) is to be installed, obtain a sheet of soft aluminum sheet stock (approximately 0.300 inch in thickness) to place in shaft (25) in first bearing bore. The stock must be thick enough so that when the strip is coiled one turn in first bearing bore, the I.D. will be slightly smaller than the I.D. of clutch seat (ends must not overlap). Lubricate clutch (18) and position inside coiled aluminum strip with clutch flanges outboard. Work clutch sprags in one at a time. When all sprags are positioned inside coiled aluminum strip, push clutch (18) into shaft (25) as far as it will go. Remove aluminum sheet stock.
- (2) If clutch assembly (18) CL41742 or CL42250-1 is to be installed, set cage on dean work area with arrow etched on cage pointing clockwise and install lower spring. Position all sprags in place over the lower spring. Take top spring in both hands and fit it into the top slots of the sprags. This will push all sprags into position within the cage.

#### NOTE

If one or two sprags come loose, check adjoining sprags for correct position and upper and lower springs for deformation.

- (3) Install CL41742 or C142250-1 clutch assembly (18) with arrow etched on cage pointing clockwise as viewed from open end of gear shaft (25). Push clutch assembly into gear shafts with hand pressure until fully seated with all sprags properly positioned.
- d. Install guide ring (17) with chamfered outer edge inboard, next to clutch assembly (18).
- e. Using a suitable block on outer race of bearing (16), press lubricated bearing into place in outer end of gear shaft (25) and install retaining ring (15).
- f. Assemble forward bearing and cap (13) as follows:
- (1) Apply heat lamp to cap (13) and using a suitable block on the outer race, press bearing (12) through the forward side of the cap as far as it will go.
- (2) Press seal (11) in forward side of cap and install retaining ring (10).

- (3) Position new packing (14) in groove in aft side of cap (13).
- **g.** Lubricate and position new packing (2) on reworked vent valve housing (3) or plug (41) and install in forward end of inner race shaft (9). Install retaining ring (1).
- **h.** Lubricate lip of seal (11) with lubricating oil (C103) and position assembled bearing and seal cap (13) on inner race shaft (9), next to adapter piate on forward end of shaft.
- i. Lubricate clutch assembly (18) with lubricating oil (Cl 03) and press assembled outer gearshaft (25) onto inner gearshaft (9).
- **j.** Install new packing (26) in groove on aft end of gearshaft (25).
  - k. Assemble bearing housing (35) as follows:
    - (1) Apply heat lamp to bearing housing (35).
- (2) Press bearing (33) in the inboard side of housing (35).
  - (3) Install retaining ring (32).
  - (4) Press seai (37) in outboard side of housing (35).
  - (5) Install reducer (36) with new packing in housing.
  - (6) install new packing (34) in groove on housing.
- (7) Support inboard side of inner race of bearing (33) and press adapter (38) into bearing (33) through seal (37).
- 6-33. Installation Freewheeling Assembly.

Remove Preservative from new or overhauled freewheeling assembly prior to installation in engine accessory gearbox. If engine is being replaced, install freewheeling unit on engine before installing engine in airframe.

- a. Ensure that the four oil passage holes in the inner race shaft (9, figure 6-8), approximately 4 inches from the aft end, are open and free of obstructions and that new packing (26) is installed in the groove on the aft end of the outer race shaft (25) forward of the splines.
- b. Apply a light coat of lubricating oil (C103) on packing (26).

#### **NOTE**

Inspect inside sump of freewheeling housing for corrosion and pitting. Refer to paragraph 6-47.

Before final installation of freewheeling assembly, stand assembly on workbench and fill area between inner and outer shaft with lubricating oil (C103).

- C. Position freewheeling shaft assembly (25, figure 6-7) in housing (13) and let splined end of inner shaft protrude through aft side of engine accessory gearbox. Rotate adapter flange back and forth to line up spline teeth between freewheeling outer bearing shaft and drive gear in accessory gearcase. Push outer bearing firmly in place into freewheeling housing (13) and install washer (12), aluminum first, then the steel, and nuts (11) on mounting studs.
- **d.** Install tail rotor drive gear (8) and aft bearing housing (7) as a unit on aft end of freewheeling shaft without packing (9) installed. Position oil inlet fitting so as to prevent binding or excessive twisting of oil line.

#### **NOTE**

The following shimming procedure must be accomplished if a different freewheeling assembly or engine is being installed or if old original shims do not provide correct clearance. (Refer to figure 6-7). Accomplish steps f. through k.

**e.** Install washer and nut (3 and 4, figure 6-7) on shaft. Attach holding tool (T32) to adapter flange on forward end of freewheeling assembly.

6-38

Tighten nut only enough to firmly seat bearing and splined adapter on shaft. No shims should be added at this time.

- **f.** install nuts (5) temporarily to ensure seating of components. Back nut (5) off.
- g. Tap adopter flange on forward end of freewheeling assembly. This will move shaft and aft bearing housing to the rear. Hold adapter flange in this position while measuring. Using two feeler gages, measure, at diametrically opposite positions, the gap between face of accessory gearcase and aft bearing housing (7).
- h. Peel shim (10) to provide shim 0.015 to 0.020 less than measured clearance between faces to provide proper positioning of the freewheeling outer bearing shaft.
- i. Remove aft bearing housing (7) and tail rotor drive gear (8).
- **j.** Position peel shim (10) over aft bearing housing (7). Coat studs, shim, and mating surfaces with zinc chromate primer (C118).

#### NOTE

Do not place shim (10) over studs on engine case as damage to packing (9) will occur when installing housing (7).

- **k.** install tail rotor drive gear, aft bearing support, and new packing (9). install washers (6), aluminum first then the steel and attaching nuts (5) to the three studs that protrude through raised bosses on aft housing.
- i. Apply a ring of sealing compound (C131) to both surfaces of washer (4) and threads of nut (3). Install washer (4) and nut (3) on shaft. Using holding tool (T32) on foward adapter flange, hold freewheeling assembly while torquing nut **450 TO 500 INCH-POUNDS.** Grasp splined adapter (8) with hand and check freedom of motion of freewheeling assembly.
- **m.** Install cotter pin (2) with eye and tangs below outside surface of nut, as shown in figure 6-7. install input oil line to reducer (27) on side of housing (7).
  - **n.** Service transmission (paragraph 1-10).

# 6-34. FREEWHEELING HOUSING.

Refer to paragraph 6-41 for maintenance of the housing assembly.

# 6-35. SHAFT ASSEMBLY FREEWHEELING.

- 6-36. Description Shaft Assembly Freewheelling. The freewheeling shaft assembly (25, figure 6-7) is an assembly of components comprised of freewheeling inner race shaft with plug in forward end, forward bearing and seal cap assembly and freewheelling outer race shaft with bearings and clutch assembly. This assembly is removed from freewheeling housing and engine accessory gearbox as a unit.
- **6-37.** Inspection Shaft Assembly Freewheeling. Visually inspect splines for wear, cracks, and damage. Refer to paragraph 6-29 and figure 6-9 for wear imitations.
- 6-38. Removal Shaft Assembly Freewheeling. Refer to paragraph 6-28.
- **6-39.** Repair/Replacement Shaft Assembly Freewheeling. Refer to paragraph 6-30 for repairs permitted. Refer to paragraph 6-31 for rework of freewheeling vent assembly when plug (41, figure 6-8) is not available.
- **6-40.** Installation Shaft Assembly Freewheeling. Refer to paragraph 6-33.

# 6-41. HOUSING ASSEMBLY.

**6-42. Description - Housing Assembly.** The freewheeling housing (28 or 29, figure 6-8) a component of the freewheeling assembly, is mounted on the forward end of the engine accessory gearcase. It provides coupling adaptation of the transmission driveshaft to tail rotor driveshaft. A lubrication fitting (14, figure 6-7) and oil lines provide freewheeling assembly lubrication from the transmission oil system. A drain plug is provided for draining oil from the freewheeling assembly.

## **NOTE**

Removal of the freewheeling housing is not recommended unless it is necessary for engine gearbox seal replacement, change of engine or inspection, repair or replacement of the housing.

# 6-43. Inspection — Housing Assembly.

- **a.** Inspect lubrication fitting, seals and hoses for leakage and security.
- **b.** Inspect housing for cracks, wear, damage, and security of attachment.

# 6-44. Removal — Housing Assembly.

- **a.** Remove freewheeling assembly. (Refer to paragraph 6-25.)
- **b.** Remove oil return line from housing. This line returns oil from fitting (14, figure 6-7) or union (29) on forward end of housing (13) or housing (31).
- **c.** Remove six self-locking nuts (15) located inside housing.
- **d.** Remove housing (13 or 31), including housing bushing (27, figure 6-8), and gasket (16, figure 6-7) from six mounting studs on forward end of engine accessory gear case.

# 6-45. Disassembly — Housing Assembly.

- **a.** Remove union (23, figure 6-8) and packing from fitting (21).
- **b.** Remove drain plug assembly (20) and packing from fitting (21).
- **c.** Remove bolt (22) with packing and remove fitting (21) with packing from housing.
  - **d.** Remove housing bushing (27) from housing (28).
- **6-46. Cleaning Housing Assembly.** Clean all parts with drycleaning solvent (C62). Dry with clean, dry air.

#### 6-47. Inspection — Housing Assembly.

- **a.** Visually inspect studs in housing (28, figure 6-8) for security and condition of threads.
- **b.** Visually inspect housing for corrosion damage and/ or loose bearings liners.
- **c.** Inspect the housing (28) and bolt (22) for cracks by fluorescent penetrant method. Refer to TM 55-1500-335-23.

- **6-48. Repair Housing Assembly. (AVIM)** Refer to TM 1-1500-204-23 for repairs.
- 6-49. Assembly Housing Assembly.

#### NOTE

The following step is not required for newer freewheeling housing with drain hole in bottom. Lubrication fitting (21) and bolt with packing (22) are not required for newer type housing assembly with drain on bottom. Return to stock.

- **a.** Install new packing onto bolt (22, figure 6-8) and insert bolt through lubrication fitting (21). Install new identical packing over end of bolt (aft side of fitting) and secure fitting to housing (28) with bolt (22).
- **b.** Install drain plug assembly (20) with new packing into large hole on side of fitting (21). Torque drain plug assembly (20) **120 TO 150 INCH-POUNDS.** LockWire (C96) from drain plug to housing.
- **c.** Install union (23) with new packing in bottom of fitting (21) or in lower forward corner of housing assembly of new type housing with drain on bottom.
- **d.** Position housing bushing (27) inside housing (28) and push in place. Align holes of bushing with mating holes in housing.

# 6-50. Installation — Freewheeling housing.

- **a.** Position gasket (16, figure 6-7) over studs on forward face of engine accessory gearbox.
- **b.** insert housing bushing (27, figure 6-8) into housing (13, figure 6-7) and align the six mounting holes in housing.

# **CAUTION**

Nuts (15, figure 6-7) must not be reused if friction torque is iess than 8 INCH-POUNDS.

**c.** Position housing (13) on mounting studs and install the six self-locking nuts (15).

- **d.** Install oil return line to union (29) on fitting (14) or a lower corner of housing assembly for new type housings.
- **e.** Install freewheeling assembly. Refer to paragraph 6-33.
- 6-51. CLUTCH ASSEMBLY FREEWHEELING ASSEMBLY.
- **6-52. Description Clutch Assembly Freewheeling Assembly.** The sprag clutch (18, figure 6-8), a component of the freewheeling assembly, provides a disconnect through the outer rata of the freewheeling shaft to the engine during a autorotation.
- **6-53.** Inspection Clutch Assembly Freewheeling Assembly. Refer to paragraph 6-29 and figure 6-9.
- **6-54.** Removal Clutch Assembly Freewheeling Assembly. Refer to paragraph 6-28 and figure 6-8.
- **6-55.** Repair Clutch Assembly Freewheeling Assembly. Refer to paragraph 6-30 and figure 6-9.
- 6-56. Installation Clutch Assembly Freewheeling Assembly. Refer to paragraph 6-32.
- 6-57. BEARINGS FREEWHEELING ASSEMBLY.
- **6-58.** Description Bearings Freewheeling Assembly. The bearings (12, 16, 24, and 33) figure

- 6-8) are components of the freewheeling shaft assembly (25, figure 6-7).
- **6-59.** Inspection Bearings Freewheeling Assembly. Inspect bearings for wear and roughness. Refer to paragraphs 6-28 and 6-29.
- **6-60.** Removal Bearings Freewheeling Assembly. Refer to paragraph 6-28.
- **6-61.** Repair Bearings Freewheeling Assembly. Refer to paragraph 6-30.
- **6-62.** Installation Bearings Freewheeling Assembly. Refer to paragraph 6-32.
- **6-63. Description Seals Freewheeling Housing.** Preformed seals and packings serve as lubricating oil retention components of the freewheeling housing and shaft assembly. Refer to figure 6-8 for seals and packings location.
- **6-64.** Inspection Seals Freewheeling Housing. Inspect seals and packing for leaks, cuts and general deterioration.
- 6-65. Removal Seals Freewheeling Housing. Refer to paragraph 6-28.
- **6-66.** Repair/Replacement Seals Freewheeling Housing. Repair is limited to removal and replacement of seals and packings with like serviceable items per TM 55-1520-228-23P.
- **6-67.** Installation Seals Freewheeling Housing. Refer to paragraph 6-32 and 6-33.

#### SECTION III. MAIN TRANSMISSION

# 6-68. MAIN TRANSMISSION.

**6-69. Description** — **Main Transmission.** The OH-58A may have a P/N 206-040-003-5 (three-planetary) transmission installed. The OH-58C will have a P/N 206-040-003-23 (four-planetary) transmission installed. Both transmissions provide a two-stage reduction of 17.44 to 1.0 (6180 to 354). The first stage is a bevel gear arrangement with 3.74 to 1.0 reduction; the second stage reduction is obtained with a planetary gear train providing 4.67 to

1.0 reduction. An accessory drive pad is provided on the lubrication pump on the forward side of the transmission for mounting the rotor tachometer and flight control hydraulic pump. This drive pad has a 1.42 to 1.0 reduction from the engine. The transmission is mounted on the cabin roof deck, forward of the power plant. The main rotor mast is secured in the top of the transmission by the main rotor bearing, bearing liner, and bearing seal plate. Transmission is flexibly supported on the airframe by a system composed of two pylon support links, one on

each side, and a drag link secured to bottom of transmission and connected by bolt to the rubber isolation support mount on the airframe. Refer to paragraph 2-289. A cylindrical boss extends downward from forward end of drag link and fits loosely in a hole in the pylon stop mounted on airframe, providing a positive limit of travel of the pylon. Refer to Section VII, this chapter, for transmission oil system information.

# 6-70. Inspection — Main Transmission.

- **a.** Inspect main transmission case for obvious damage (nicks, scratches, gouges, etc.).
- **b.** Inspect main transmission oil for evidence of water. When water is present, the oil has a dirty milky appearance. If this condition is present or suspected, drain and flush until water contamination is removed, then reservice transmission. In the event contamination cannot be cleared, replace transmission. Refer to paragraph 1-10 for servicing.

#### 6-71 Removal — Main Transmission.

# Premaintenance Requirements for Main Transmission

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	(T11)
Test Equipment	None
Support Equipment	(S12)
Minimum Personnel Required	Two
Consumable Materials	(C77) (C103) (C118) (C97) (C103.1)
Special Environment Conditions	None

# **NOTE**

The transmission may be removed with the main rotor mast installed.

- **a.** When transmission is to be replaced, accomplish preservation before removal unless conditions prevent operation. Refer to TB 55-9150-200-24. Drain transmission after preservation.
  - **b.** Open transmission fairing.
  - c. Disconnect battery and any external power source.
  - d. Remove cyclic and collective control rods.
  - e. Remove main rotor hub and blade assembly.
  - f. Remove swashplate and support assembly.
  - g. Remove main driveshaft (1, figure 6-10)
- **h.** Remove tachometer generator and hydraulic pump as a unit from transmission by removing nut (9) and washers (8).
- i. Disconnect transmission oil pressure transmitter.
- **j.** Remove hydraulic reservoir from transmission. Refer to paragraph 7-57.
- **k.** Disconnect pressure oil line and return line from freewheeling assembly. Cap or plug lines and openings.
- I. Loosen clamp (14) and disconnect hose assembly (13).
- **m.** Install mast nut on top of rotor mast. Attach clevis with bolt to eye of mast nut and attach hoist. Refer to table 1-4 (S16).

#### NOTE

If mast assembly has been removed while transmission is mounted on helicopter attach lifting plate to top of transmission and attach hoist.

**n.** Take up slack in hoist cable and apply only sufficient tension to support transmission when pylon supports and drag pin are disconnected.




Figure 6-10. Main Transmission (Sheet 1 of 2)

- 1. Main Drive Shaft (Ref)
- 2. Spindle
- 3. Washer
- 4. Oil Filter Assembly
- 5. Packing
- 6. Transmission Oil Pump
- 7. Tachometer Generator (Ref)
- 8. Washer (Ref)
- 9. Nut (Ref)
- 10. Bellcrank, Collective Control (Ref)

- 11. Bellcrank Support (Ref)
- 12. Transmission
- 13. Hose Assembly
- 14. Clamp
- 15. Oil Cooler
- 16. Nut
- 17. Hydraulic Pump (Ref)
- 18. Filler Cap Assembly
- 19. Packing
- 20. Gasket

206040-482-2

# Figure 6-10. Main Transmission (Sheet 2)

- **o.** Remove main transmission and pylon support links as follows:
- (1) Disconnect drag pin (17, figure 2-55) from isolation mount (4) by removing transmission mount support bolt (13), washers (14), and nut (15).
- (2) Remove nuts (21), washers (19), and bolts (18) from pylon support links (11) at support link fittings 6 and 12).

# CAUTION

Do not remove shims (24) under pylon support fitting (6 and 12) or isolation mount (4). If pylon support fitting or isolation mounts are removed from deck, ensure shims are bonded in place. If shims are not bonded, identify for reinstallation in same location. Loss or mixing of shims will require depot maintenance for transmission alignment.

#### **NOTE**

Ensure all flight controls, oil lines, electrical wiring, and other attachments are disconnected from transmission.

- **p.** Actuate hoist and lift transmission carefully from airframe while guiding transmission to clear components installed on upper part of airframe.
- **q.** Remove pylon support links from transmission by removing cotter pins and nuts (8) and washers (9),

- 6-72. Repair Main Transmission
- a. Repair of the main transmission is limited to removal and replacement of authorized components, polishing out nicks, scratches, and gouges, and spot painting bare surfaces on the transmission case. Nicks, scratches, and gouges may be removed as described in TM 55-1500-204-25/1, General Maintenance Manual. Top of transmission case is made of aluminum; bottom of transmission case is made of magnesium as is the main drive shaft housing,
- **b.** Only bent, cracked, or thread damaged studs may be replaced at AVIM.

# CAUTION

Never use more than the recommended torque in an effort to force a stud into the housing, If driving torque is not within the limits specified, replace the stud with the proper overall size. Occasionally, it will be necessary to try two or more studs of the same size to find one which falls within limits. No drilling or tapping is permitted. Thread clean up is permissible.

c. Except as specified herein, studs are replaced in accordance with instructions contained in TM 55-1500-204-25/1. Whenever a stud is replaced, clean out small vent hole in bottom of threaded hole or adjacent to bottom of threaded hole. Vent holes for the two forward adapter mount studs are drilled from bottom of threaded holes through case assembly. Vent holes for the two aft adapter mount studs run at approximately a 60-degree angle to bottom of stud

holes. Vent holes for upper four spindle studs are drilled from upper case to bottom of threaded holes, approximately 0.800 inch from edge of spindle boss. Replacement of lower spindle studs, due to location of vent holes, is not authorized. Failure to clean vent holes can result in a false torque, or cause the case to crack during stud installation. Install replacement studs to height shown below:

LOCATION	STUD SIZE I	STUD HEIGHT	INCH- POUNDS
Transmission case lower side at drag pin (4 studs)	1/4 inch	0.680 inch	50-95
Top case at pylon support spindles (top 4 special studs only)	3/8 inch	0.790 inch	175-375

#### **NOTE**

Apply zinc chromate primer (C118) to threads of stud and install while wet Dye penetrant inspect area adjacent to drag pin assembly, prior to installation of new Studs.

#### 6-73. Installation — Main Transmission.

Premaintenance Requirements for Main Transmission.

Condition	Requirements
Model	OH-58A/C
Part No. Serial No.	All
Special Tools	None
Test Equipment	Torque wrench
Support Equipment	(S12) (S16)
Minimum Personnel Required	Two
Consumable Materials	(C40) (C103) (C107) (C118) (C97) (C103.1)
Special Environmental Conditions	None

# **CAUTION**

Prior to Installation of the main transmission, inspect the pylon support links, support fittings and isolation mount in accordance with paragraph 2-284 and 2-291/2-292.

- **a.** Install main rotor mast in transmission, if previously removed. If roller bearings in the lower mast bearing prevented insertion of the mast, use a clean length of aluminum tubing to push the rollers to the outboard limit of the bearing cage.
- **b.** Attach maintenance hoist (S12) to lifting eye and lift assembly, guiding transmission carefully to avoid damage.
- **c.** Install pylon support links (11, figure 2-55), by placing one washer (2) on each support spindle (1) with chamfered face of the center hole inboard.
- **d.** Position pylon support link (11) on support spindle. Install washers (9) and nuts (8) on spindle. Tighten nut finger tight.
- **e.** Lower transmission to position pylon stop (3) located on lower side of pylon drag pin (17) into hole in pylon stop. Guide pylon drag pin (17) to connecting position with isolation mount (4).
- **f.** Position legs of pylon support link (11) in mounting position with forward pylon support fitting (12) and aft pylon support fitting (6). Install bolts (18), washers (19), recessed washers (20), and nuts (21). Torque nuts (21) **460 TO 510 INCH-POUNDS.**
- **g.** Install bolt (13) and washer (14) through right side of transmission pylon drag pin and isolation mount (4). install washer (14) and nut (15). Torque nut (15) **480 TO 690 INCH-POUNDS** and secure with cotter pin.
- **h.** Torque spindle nuts (8) to **50 INCH-POUNDS**, plus one castellation to align cotter pinholes, and install cotter pin (7).
- i. Connect oil lines, electrical wiring and air hose assembly (13, figure 6-10).
- **j.** Install collective control bellcrank (10, figure 6-10) and support (11) on forward side of transmission if removed.

#### TM 55-1520-228-23

- **k.** Install swashplate and support assembly, main rotor hub and blade assembly, cyclic and collective control rods, hydraulic pump, rotor tachometer generator, and hydraulic reservoir. Connect hydraulic drain line if removed. Refer to paragraphs 5-10,5-121, steps q. and h., 7-19, 7-45, and 8-52.
- I. Install main driveshaft. Refer to paragraph 6-15.
  - m. Check for security of all items.
  - n. Install and close cowling.
  - o. Connect battery.
- 6-74. Preparation for Shipment or Storage Main Transmission.

# CAUTION

Extreme care must be taken while cleaning, preserving, and packaging the transmission to prevent damage to the chip detector.

**a.** With the mast assembly removed, spray the interior of the transmission through the top opening with approximately one pint of lubricating oil (C103 or C103.1). While spraying, manually rotate the internal gears and bearings with the input drive quill; then drain lubricating oil.

#### **NOTE**

Immediately install hoisting adapter after the mast has been removed from the transmission assembly and the interior preservation has been completed. Keep rubber portions of the transmission pylon mounts free of all oil, grease, or solvents to prevent deterioration or weakening of bonds between rubber and metal.

**b.** Clean the exterior of the transmission, including splines and the threaded areas, with drycleaning solvent (C62). Air dry or wipe with a clean, lint-free cloth.

c. Cap or plug all lines, as applicable, in accordance with TM 1-1500-204-23. Cover breather holes and all other openings with barrier material (C27) and secure with tape (C136). Secure all loose wire and lines with the same tape to prevent damage during shipment.

# **CAUTION**

Do not allow corrosion preventive compound to contact rubber parts.

- **d.** Apply corrosion preventive compound to all exterior bare metal surfaces, including splines, studs, and thread areas.
- **e.** Attach a tag to the transmission stating: TRANSMISSION PRESERVED WITH LUBRICAT-ING OIL, MIL-L-23699, or transmission preserved with lubricating oil, DOD-L-85734.
- **f.** Attach a properly filled out DD Form 1577-2 (Unserviceable/Reparable Tag) to the transmission and a DD Form Label 1577-3 to exterior of the container. Refer to TB 750-126.
- **g.** Initiate DA Form 2410 (Component Removal and Repair/Overhaul Record) in accordance with DA-PAM 738-751.

### **NOTE**

Be sure to place copies of DA Form 2410 in a grease-proof envelope and stow in top of container.

- **h.** Cover input drive spline and generator drive spline areas with barrier material (C27) and secure with tape (C136).
- i. If a transmission metal storage and shipping container (NSN 8145-00-198-8559, P/N 206-040-003 MUSC-1) is available, the preferred method of shipment is in this container. Carefully lower the transmission into the container and onto bottom molded pad. Install upper pad over top of transmission. Install 24 units of desiccant in top of container, install records in top of container, and secure lid of container in place.

**j.** As a field expedient only, prepare the transmission as stated below:

#### NOTE

The procedure is based on the assumption that the provisions of step i. cannot be complied with, that the work will be done under less than ideal conditions with limited equipment, and on some occasions by personnel who are not experts in the field of preservation. This procedure will be used only at locations where facilities for the application of normal preservation procedures do not exist.

- (1) Comply with preceding steps a. through h. to the extent possible with available materials and equipment.
- (2) If caps or plugs specified are not available, openings may be closed with barrier material (C27) and secured with any type of tape that is available.
- (3) Coat the entire exterior metal surface of the transmission with a light coat of aircraft grease (C79). Cover the transmission with barrier material (C27) and secure with adhesive tape (C136) that is available.
- (4) Mount the transmission in the best available container (constructed if necessary) of wood or metal. Cushion, Mock, and brace as necessary.

# NOTE

If the field expedient procedure is used, mark the outside of the container as follows: THIS TRANSMISSION IS NOT PRESERVED FOR STORAGE. STORE INDOORS AND PROCESS AS SOON AS PRACTICABLE.

**k.** Obliterate old markings from container that do not coincide with the item to be returned. Mark container in accordance with MIL-STD-129.

### 6-75. DRAG PIN.

**6-76. Description** — **Drag Pin.** The main transmission is supported and attached at its lower rear section by an isolation mount which dampens pylon to fuselage vibrations and limits pylon rock.

Movement of the transmission and isolation mount is limited by a drag pin which extends down into a plate on the deck. Contact between the drag pin and its static stop produces a noise known as spike knock.

# 6-77. Inspection — Drag Pin.

- **a.** Verify drag pin bolt is properly installed and in the right direction.
- **b.** Inspect drag pin for condition and security. Look for an obviously bent or broken pin. Typically the four drag pin mounting studs will fail before the drag pin. Consequently, nicks and dents are not critical.

#### NOTE

If swashplate to cowling or main drive shaft to isolation mount contact has occurred during a touch-down autorotation, or as a result of a hard landing as defined in Chapter 1 of this manual, the drag pin assembly must be removed for a more detailed inspection, and the four drag pin mounting studs must be removed and replaced. Refer to AVIM.

**c.** Inspect the transmission mount support stop. Refer to paragraph 2-291.

# 6-78. Cleaning – Drag Pin.

- **a.** Clean all sealant residue from drag pin and mounting area on bottom of case.
- **b.** Clean drag pin (4, figure 6-11) in solvent (C62). Dry with clean dry air.
- **6-79.** Removal Drag Pin. Refer to paragraph 6-71.
- **a.** Remove four cotter pins (1, figure 6-11), four stud nuts (2), and washers (3) attaching drag pin (4) to bottom of transmission case.

# NOTE

The drag pin assembly boss mounts into case with a tight fit. Sealant is applied between case and drag pin. Drag pin may be difficult to remove from case.

b. Apply heat lamp to case in area of drag pin.




Figure 6-11. Drag Pin Installation

## **CAUTION**

Exercise care in drag pin removal to avoid damage to main case. Do not use screwdriver as a wedge between drag pin and case.

- **c.** When case is thoroughly heated, tap drag pin assembly gently with a plastic mallet. If drag pin will not slip from case, use a flat, thin, nonmetallic aid approximately one inch wide as a wedge.
- **d.** When drag pin assembly is loosened, use hands and gentle taps with plastic mallet to work assembly down and to remove from case studs.

## 6-80. Inspection — Drag Pin.

- **a.** Visually inspect drag pin (4, figure 6-11) for physical damage.
- **b.** inspect spherical bearing for wear, security, and freedom of movement. If bearing wear exceeds **0.010** inch axial or **0.008** radial, replace bearing.

Inspect drag pin (4, figure 6-11) using dye or fluorescent penetrant method. Refer toTM43-0103.

**d.** For replacement of four drag pin mounting studs, refer to paragraph 6-72.

## 6-81. Repair — Drag Pin (AVIM).

## Premaintenance Requirements for Drag Pin

Condition	Requirements
Model	OH-58A/C
Part No. Serial No.	All
Special Tools	(T30) (T32)
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	One
Consumable Materials	(C22) (C115) (C118) (C120) (C126) (C131)
Special Environmental Conditions	None

- **a.** Replace drag pin assembly if found defective by dye penetrant inspection.
- **b.** Dress out minor nicks and scratches. Touch up bare spots with zinc chromate primer (C118).
- **c.** If spherical bearing failed inspection, replace as follows: (AVIM)
- (1) Using mandrel end of staking tool (T30), press old bearing and bushing into receptacle portion of tool.
- (2) Clean any sealant residue from bore of housing using sandpaper (C126). Wipe with a clean cloth dampened with naphtha (C22).
- (3) Apply primer adhesive (C115) to the bushing, bearing outer race, and bore of drag pin assembly housing. Wipe dry with clean cloth and allow to dry for five minutes.
- **(4)** Apply retaining compound (C120) to the bushing, bearing outer race, and bore of drag pin assembly housing. Wipe dry with a clean cloth.
- (5) Apply a second coat of retaining compound (C120) to surfaces described in step (4). Exercise care so as not to contaminate the bearing element.

#### NOTE

Staking procedure must be completed within 30 minutes of Sealing compound application.

- **(6)** Install bearing and bushing in housing. Using the staking side of tool and the support portion of tool, stake the bushing on each side alternately to a depth of **0.012** to **0.016** inch.
- (7) Cure applied retaining compound (C120) by heating with heat lamp to 170°F (77.3°C) for one hour after staking.

## **NOTE**

Ensure that the bearing has been properly staked.

#### 6-82. Installation — Drag Pin.

- **a.** Make sure that mounting boss of drag pin and mounting area on transmission case are clean.
- **b.** Apply sealing compound (C131). Mix sealant according to directions on package, and apply a thin coat of sealant to mounting area on drag pin.
- **c.** Using a heat lamp, heat lower transmission case in area of drag pin mounting to facilitate installation of drag pin.
- **d.** Position drag pin assembly (4, figure 6-11) over four mounting studs.
- e. Install four washers (3) and nuts (2). Torque nuts50 TO 70 INCH-POUNDS and secure with cotter pins.
- **f.** Apply sealing compound (C131) to outer edge of drag pin (4) and mounting area of case.
- **g.** After sealant dries, trim with sharpened plastic scraper. Do not use metal scraper.

# 6-83. INPUT PINION HOUSING ADAPTER AND SEALS.

- **6-84.** Description Input Pinion Housing Adapter and Seals. An input pinion housing is located on aft side of transmission main case. Engine torque is transmitted through the main driveshaft into the adapter.
- **6-85.** Inspection Input Pinion Housing Adapter and Seals. Inspect area around input pinion housing for leakage, security of attachment, and any apparent damage.

#### NOTE

Total static or dynamic leakage will not exceed 5 DROPS PER MINUTE.


6-86. Removal — Input Pinion Housing Adapter and Seals. (AVIM)

- **a.** Drain transmission oil into suitable container (paragraph 1-10), and remove main driveshaft (paragraph 6-10).
- **b.** Remove retaining ring (9, figure 6-12) and disc (8) from input pinion nut (10).
- **c.** Position holding tool (T32) on face of input adapter (11) with holding pins of tool positioned in two holes in face of adapter (11).
- **d.** Insert a 3/4 inch square drive wrench in hole in the pinion nut (10) and remove nut.
  - e. Remove input adapter (11) from end of pinion.

## **CAUTION**

Do not use screwdriver to remove housing from case. Do not disturb shim (1).

- f. Deleted.
- **g.** Remove nuts (7) and washers (5 and 6) attaching seal housing (4). Carefully cut sealant between seal housing (4) and main case with a sharp plastic scraper. Use plastic mallet with plastic wedge to loosen seal housing (4).
  - h. Remove seal housing (4).
- i. Remove packing (2) from input face of transmission case.
- **j.** Remove packing (14) from end of pinion. Discard packing.
  - k. Remove seal (3) from housing (4). Discard seal.
- 6-87. Inspection Input Pinion Housing Adapter and Seals. (AVIM)
- **a.** Visually inspect all visible parts of the main input pinion gear for damage.






Figure 6-12. Input Pinion Housing Adapter and Seals.

#### TM 55-1520-228-23

- **b.** Inspect adapter (11, figure 6-12) for wear in area of contact with seal (3). Maximum allowable wear in this area is **0.002** inch, provided no nicks, dents, or scratches are present.
- **c.** Inspect input pinion housing for corrosion pitting in sealing areas. No corrosion or repair allowed in sealing areas.
- **d.** Inspect machined mating surface of input pinion housing and transmission for corrosion. Clean up pitting in accordance with TM 43-0105, do not use mechanical means to cleanup pitting. Maximum allowable depth of pitting is **0.030**. Pitting beyond **0.030** is not repairable, return transmission to depot.

## 6-88. Repair — Input Pinion Housing Adapter and Seals. (AVIM)

- **a.** Replace packing (2, figure 6-12) on installation.
- **b.** Replace adapter (11) if worn beyond limits in seal contact area.
- **c.** Replace housing (4), nut (10), disc (8), and retaining ring (9) if damaged.
- **d.** Replace packings (12). Replace tube (13) if damaged.

# 6-89. Installation - Input Pinion Housing Adapter and Seals. (AVIM)

Premaintenance Requirements for Installation of Input Pinion Adapter and Seals

Condition	Requirements
Model	OH-58A/C
Part No. Serial No.	All
Special Tools	(T18) (T32)
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	Two
Consumable Materials	(C57) (C103) (C129) (C131)
Special Environmental Conditions	None

0-a. If shim (1, figure 6-12) is removed, lost or damaged, proceed as follows:

- (1) Position housing (4) against bearings, do not install washers and nuts.
- (2) Using two feeler gauges, measure at diametrically opposite positions the gap between the face of the transmission case and the face of the housing (4).
- (3) Shim as required to obtain 0.001 to 0.004 inch less than measured clearance between the faces to provide proper preload on the input quill bearing.

#### **NOTE**

Install seal (3) P/N 451509H19 in housing (4) for the P/N 206-040-003-5 transmission according to step a., and skip step b. Install seal (3) P/N 206-040-156-1 in housing (4) for the P/N 206-040-003-23 transmission according to step b., and skip step a.

- **a.** Press new seal (3) P/N 451509H19 into bearing and seal housing (4) with bearing tool (T18), using sealant (C129) around O.D. of seal (3).
- **b.** Install seal (3) P/N 206-040-156-1 in housing (4) as follows:

#### **NOTE**

Seal (3) P/N 206-040-156-1 is a magnetic type seal consisting of four parts. The parts are a magnet ring, a seal case, and two packings. If seal is being reused install new packings (15 and 16). Seal should remain in packaging until ready for installation. Seal cavity in housing (4) must be free of foreign material and all packing seating areas and chamfers must be free of burrs.

(1) When removing seal (3) from packaging, the seal case must be separated from the magnet ring. Pull seal case straight away from magnet ring. Discard paper separator.

## **NOTE**

Package contains a small tube of dampening fluid (C57).

## **CAUTION**

Do not slide seal case across magnet ring. Avoid placing magnet ring portion of seal in area where small metal chips could be attached by the magnet.

- (2) Heat housing (4) with heat lamp to ease installation of magnet ring portion of seal.
- (3) Lightly lubricate both packings (15 and 16) of seal and bore of housing (4) with dampening fluid (C57).
- (4) Install larger packing (15) into groove of magnet ring.
- (5) Cover polished surface of magnet ring with a clean, lint-free cloth. Using care not to damage packing, push magnet ring into bore of housing (4) with polished side up until the back side of magnet ring is squarely seated against shoulder in bottom of bore. Rotate magnet ring in bore of housing if necessary. Ensure face of magnet ring is free of lubricant. (See detail A, figure 6-13.)
- **(6)** Place housing and magnet ring assembly over adapter (11, figure 6-12) so that bottom of housing is in contact with adapter.
- (7) Install smaller packing (16) of seal into groove of seal case.
- (8) Using care not to damage packing, hand press seal case over adapter (11, figure 6-12) until lapped carbon sealing surface comes into contact with lapped surface of magnet ring. (See detail C, figure 6-13).

#### CAUTION

Use care not to separate or disturb position of housing, adapter, and seal assembly until adapter is secured in place.

**c.** Install new packings (12) on oil drain tube (13). Apply thin coating of lubricant (C103) to packings and insert one end of tube into hole in input mounting face of transmission case.

- **d.** Install new packing (2) in groove on outer edge of bearing liner and lubricate with lubricant (C103).
- **e.** Lubricate new packing (14) with lubricant (C103) and install just inboard of splines on pinion.

#### NOTE

install housing (4), seal (3) P/N 451509H19, adapter (11), and nut (10) on the P/N 206 040-003-5 transmission according to step f., and skip step g. install housing (4), seal (3) P/N 205440-158-1, adapter (11), and nut (10) on the P/N 206-040-003-23 transmission according to step g. and skip step f.

- **f.** Install housing (4) with elastomeric type seal as follows:
- (1) Position bearing and seal housing (4) containing seal (3) P/N 451509H19, on mounting studs on input face of case. Guide outboard end of oil drain tube (13) into mating hole in bearing and seal housing (4).
- (2) Install aluminum washers (5) next to bearing and seal housing (4) followed by other washers (6) and stud nuts (7). Torque nuts 50 TO 70 INCH-POUNDS.
- (3) Lubricate seal (3) with lubricant (C103) and position splined adapter (11) on end of input pinion shaft, and through seal (3) in bearing and seal housing (4).
  - (4) Install input pinion nut (10) in end of shaft.
- (5) Position holding tool (T32), on face of input adapter (11) with holding pins of tool engaged in two holes in flange of adapter (11). Position a 3/4 inch square drive into end of nut (10), hold input adapter (11) with holding tool and torque nut (10) 150 TO 166 FOOT-POUNDS, to align holes for lock spring (9).
- **(6)** Remove square drive from nut (10) and remove holding tool from input adapter (11).
- **g.** Install housing (4) with magnetic type seal as follows:
- (1) Using care not to disturb position of assembled housing (4), adapter (11), and seal




Figure 6-13. Main Input Quill, Seal Installation

- assembly (3), guide assembly over end of pinion. Guide outboard end of oil drain tube (13) into mating hole in housing (4). Slide housing inboard and install nut (10). (See detail D), figure 6-13.)
- (2) Position holding tool (T32), on fats of input adapter (11, figure 6-12) with holding pins of tool engaged in two holes in flange of adapter (11). Position a 3/4 inch square drive into end of nut (10), hold input adapter(11) with holding tool and torque nut (10) 150 TO **166 FOOT-POUNDS**, to align hole for lock spring (9).
- (3) Remove square drive from nut (10) and remove holding tool from input adapter (11).
- (4) Install aluminum washers next to bearing and seal housing (4) followed by other washers and stud nuts. Torque nuts 50 TO 70 INCN-POUNDS.
- h. Apply a bead of sealant (C129) around the transmission case and housing (4, figure 6-12). Install packing (20) and plug (21). Torque 40 TO 50 INCH-POUNDS and lockwire.
- i. install cover (8) in end of input shaft nut (10). Install locking spring (9) in nut with locking end of spring through hole in nut and hole in shaft.
  - j. Reinstall main input driveshaft.
- **k.** Service transmission with oil (paragraph 1-10).

## 6-89.1. Repair — Input Pinion Cork Seal. (AVIM)

#### NOTE

# Soak new cork in shellac (C163) for 12 hours prior to installation (step f.)

Drain transmission oil into suitable container (paragrph 1-10), and remove main driveshaft (paragraph 6-10).

Remove retaining ring (9, figure 6-12) and disc (8) from input pinion nut (10).

- **c.** Position holding tool (T32) on face of input adapter (11) with holding pins of tool positioned in two holes in flange or adapter (11).
- **d.** Insert a 3/4 inch square drive wrench in hole in the pinion nut (10) and remove nut.

Clean pinion internal surface with naphtha (C22).

#### **NOTE**

The original cork plug is not to be disturbed or removed.

Do not push the new plug further Inboard than the 1/4 inch dimension In the following step to prevent the possibility of forcing out the old plug.

**f.** Insert new cork plug, number 19, type 1, grade A, class 1, short, 1/4 inch inboard of the pinion internal threads. Remove any excess shellac.

After shellac dries, apply a bead of sealant (C131) to the mating surfaces of the new cork and pinion.

Clean pinion internal threads with naphtha (C22).

- i. Position holding tool (T32) on face of input adapter (11) with holding pins of tool positioned in two holes in flange of adapter (11).
- j. Insert a 3/4 inch square drive wrench into end of nut (10), hold input adapter (11) with holding tool and torque nut (10) **150 TO 166 FOOT-POUNDS**, to align hole for lock spring (9).
- **k.** Remove square drive from nut (10) and remove holding tool from input adapter (11).
- I. Install cover (8) in the end of the input shaft nut (10) Install locking spring (9) in nut with locking end of spring through hole in nut and hole in shaft.
  - m. Reinstall main driveshaft (paragraph 6-15).

Service transmission with oil (paragraph 1-10).

#### 6-90. MAST ASSEMBLY.

**6-91. Description -- Mast Assembly.** The mast assembly is a tubular steel shaft fitting with a bearing and seal assembly which secures the mast in top of transmission and supports mast in the vertical position. Mast driving splines engages with transmission planetary gear assembly. Splines on the upper portion of mast provide mounting for main rotor.

#### 6-92 Inspection — Mast Assembly.

- **a.** Visually inspect mast exterior for scratches, nicks, and corrosion.
- (1) From 0 to 7 inches below top of mast: nicks and scratches are not to exceed 0.005 inch depth on the full circumference, **0.0075** inch for half circumference, or **0.010** inch for quarter circumference.

- (2) From 7 to 37 inches below top of mast nicks and scratches are not to exceed 0.010 inch depth for full circumferece, 0.015 inch depth for half circumference or 0.020 inch for quarter circumference.
- (3) All external repairs shall have a minimum radius of **0.500** inch after repair.
- (4) Pits resulting from corrosion after cleanup shall not exceed limits of substeps (1) and (2).
- **(5)** Ensure reworked mast is identified as per fig ure 6-16 notes.
- **(6)** All areas not subject to rework shall be coated with epoxy polyamide primer (C116) and silver spray painted. This procedure will retard corrosion.
- **b.** Inspect retainer plate for corrosion or leakage in seal area.

#### NOTE

Leakage that does not allow oil level to fall below sight gage level, or run down the transmission upper housing onto the transmission case on a flight of maximum endurance possible for an OH-58, is not excessive.

c. Inspect mast interior for corrosion.

#### NOTE

To adequately inspect mast interior, remove mast to hub retaining nut and with appropriate light, inspect for corrosion.

- (1) Corrosion or suspected corrosion on mast interior is not acceptable, remove and evacuate mast to AVIM for repair.
  - (2) Inspect mast plastic plug for serviceability.

## 6-93. Removal — Mast Assembly.

## Premaintenance Requirements for Removal of Mast Assembly

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	(T36) (T17) (T16)
Test Equipment	None
Support Equipment	(S12) (S8)
Minimum Personnel Required	Two
Consumable Materials	(C27) (C52) (C76) (C116) (C124) (C125) (C84) (C62) (C51) (C131) (C103) (C107) (C126) (C118) (C129)
Special Environmental Conditions	None

## **NOTE**

Main rotor mast may be removed from transmission while transmission is installed in helicopter or may be removed with transmission for removal from transmission at a later time.

- **a.** Remove cyclic and collective control rods. Refer to paragraph 5-114 and figure 5-30.
- **b.** Remove main rotor hub and blade assembly. Refer to paragraph 5-8.
- **c.** Remove idler link assembly, boot assembly and swashplate and support assembly from mast.
- **d.** Remove nuts (6, figure 6-14) and washers (7) from studs attaching mast upper bearing liner (14), and bearing and seal plate (10) to top of transmission.
- **e.** Reinstall mast nut. Attach hoist (S12) to nut and take up cable slack.

#### NOTE

To prevent corrosion, do not handle mast assembly with bare hands below upper mast liner. Use white cotton gloves (C76). Use corrosive preventive compound (C52) to remove any existing fingerprints.

- **f.** Using white cotton gloves (C76) carefully lift and guide mast out of transmission. Immediately install a cover (S8) on top of transmission case and wrap mast with barrier material (C27).
- **g.** Place mast assembly on a suitable cushioning material, such as a mattress.

## 6-94. Disassembly - Mast Assembly. (AVIM)

- **a.** Remove screws (2, figure 6-14) securing locking plate (3) to upper mast bearing nut (4), and remove plate.
- **b.** Position mast holding fixture (T17) on lower splines to hold rotor mast (1).
- **c.** Using wrench (T36) and holding fixture (T17), remove mast nut (4).
- **d.** Remove screws (9) securing retaining plate (10) to upper mast bearing liner (14). Remove retaining plate (10), seal (5), shim (11), and packing (13) from assembly.
  - e. Press bearing (12) from mast (1).
  - f. Remove bearing liner (14) from bearing (12).
- **g.** Remove sealant and cap-plug (16) from main rotor mast assembly (1).

## 6-95. Cleaning - Mast Assembly. (AVIM)



Ensure bearings are handled only with clean white cotton gloves. Do not allow bearings to spin when drying with compressed air.

**a.** Clean all parts of mast assembly with drycleaning solvent (C62).




Figure 6-14. Main Rotor Mast - Disassembly

**b.** Dry with clean dry, filtered air and coat bearings with oil (C103).

#### 6-96. Inspection — Mast Assembly. (AVIM)

- **a.** Visually inspect for damage to the area which would be contacted by the main rotor static stops. No yielding or deformation is allowed.
- **b.** Remove bearings, and check mast runout. Refer to figure 6-16.
- (1) Runout at the lower bearing journal not to exceed **0.002** inch.
- (2) Runout at the upper bearing journal not to exceed **0.003** inch.
- (3) Runout at the groove in the upper set of splines (the split cone seat) not to exceed **0.003** inch.
- (4) Runout on the O.D. of the mast at a point approximately **20.00** inches from the upper end not to exceed **0.015** inch.

## **CAUTION**

The greatest single source of unnecessary bearing damage occurs during bearing removal (see paragraph 6-94). Always keep the components of a separable bearing together. Never mix bearing components. Bearings will be placed in unsealed polyethylene bags during processing of mast.

#### NOTE

Damage in excess of the above limits is cause for rejection of the entire mast. If mast meets these requirements, proceed with normal inspection, including magnetic particle and fluorescent penetrant inspections as applicable.

c. Visually inspect split inner races outer race, bearing balls, and cage for condition. Look for brinelling and burnishing of inner and outer races. Look for fractured cage, pitting, nicks, and scoring of ball bearings. No brinelling, burnishing, pitting, or scoring is permitted on active surfaces of bearing races or ball bearings. Tarnish on retainer is not detrimental. Bearings which have been subjected to high impact forces (e.g., crash landing, sudden stoppage, etc.) must be replaced.

#### NOTE

Axial and radial play of the mast bearing is normal; measurements are not required. Transmission oil sampling, chip detector, and visual inspections are the only methods used to determine the condition of the mast bearing.

- **d.** Visually inspect mast splines for burrs, nicks and scratches. Damage **0.002** inch or less in depth is acceptable. Inspect the milled groove in serrations where collar set attaches. Milled groove must cross five serrations only. Look for heavy scoring or missing metal in milled groove, or in one of the adjacent serrations.
  - e. Inspect mast for corrosion and pitting.

#### NOTE

Masts, P/N 206-010-332-5, -9, and -11, were treated internally with hot linseed oil at time of manufacture. Later masts were internally treated with epoxy primer. The change from oil to epoxy primer was made to provide better corrosion protection.

- **f.** Inspect seal and bearing plate for corrosion or pitting in area of seal seat.
- **g.** Inspect the following parts (figure 6-14) by magnetic particle method (code M) or fluorescent penetrant method (code F) as outlined in TM 55-1500-335-23. Refer to figures 6-15 and 6-16 for mast and subassemblies repair areas and limits.

ITEM	NOMENCLATURE	CODE
1	Mast	M
3	Locking Plate	F
4	Mast Bearing Nut	M
10	Plate, Mast and Seal	M
14	Bearing Liner	M

- (1) Inspect mast (1, figure 6-14) using direct electrical contact using copper braided pads, magnetize at 1200 amperes. Inspect with longitudinal field with three (3) overlapping shots spaced 12 inches apart, magnetize at 6000 ampere-turns.
- (2) Inspect mast bearing nut (4, figure 6-14) with circular field using 1 inch central conductor, magnetize at 1200 amperes.
- (3) Inspect plate, mast and seal (10, figure 6-1 4) with circular field using 1 1/2 inch central conductor. Make three (3) equally spaced shots (120 degrees apart) magnetize at 1200 amperes.
- (4) Inspect bearing liner (14, figure 6-14) with circular field using 1 1/2 inch central conductor. Make three (3) equally spaced shots (120 degrees apart) magnetize at 1200 amperes.

## **LOCKING PLATE**



- A. Damage limits for exterior not established.
- B. I.D. serrated area may have maximum of 20% damage.

#### NUT




- A. Seal contact area of nut must be smooth.
- B. Damage to threaded area not permitted.
- C. NOTE 1
- D. NOTE 4
- E. NOTE 5

## **PLATE**



- A . I.D. MAX 3.503
- B. NOTE 1 C. NOTE 2 D. NOTE 3
- D. NOTE 3
  E. NOTE 4
  F. NOTE 5

## BEARING



- A. O.D. MIN 4.3303 NOTE 7 and NOTE 8.
- B . I.D. MAX 2.3623 NOTE 6.
- C. Corrosion is not permitted.

## LINER



- A. O.D. MIN 4.529 NOTE 7.
- B. I.D. MAX 4.331 NOTE 7 and NOTE 8.
- C. NOTE 1
  D. NOTE 2
  E. NOTE 3
  F. NOTE 4
- G. NOTE 5

206040-487-1

Figure 6-15. Main Rotor Mast Subassemblies (Sheet 1 of 2)

#### NOTES

- Surface corrosion which can be removed with scotch brite, crocus cloth, or steel wool (steel parts only) without perceptible removal of base material is negligible.
- 2. Scratches, nicks, gouges, and pits, less than 0.002 inch depth, are negligible.
- 3. Only negligible damage is permitted on this item, except on flange areas.
- 4. Individual pits or other damage not more than 0.010 inch depth by 0.100 inch diameter is permitted, provided the defect is at least 0.050 inch from any bolt hole, sealing surface, bearing seat area, or adjacent damage. This is provided such defects affect no more than 5 percent of any surface.
- 5. Chamfer or corner damage may be cleaned up to a maximum of 0.060 inch X 45 degrees resultant chamfer.
- 6. Some wear can be expected in these areas. Must provide slight interference (press fit) with parts at same temperature. Measure if necessary.
- 7. Measurement of this dimension is not normally required.
- 8. Discretion must be used in taking four place measurements.

206040-487-2

Figure 6-15. Main Rotor Mast Subassemblies (Sheet 2)


## 6-97. Repair — Mast Assembly. (AVIM)

## **NOTE**

To prevent corrosion, do not handle the bearing or the mast assembly with bare hands below upper mast bearing liner — use white cotton gloves (C76). Use corrosion preventive compound (C52) to remove any existing fingerprints.

- a. Blend out sharp edges of scratches, nicks, and gouges in area A and area B splines, with fine India stone (C84). Depth of damage after repair must not exceed 0,030 inch at tip of spline, 0.020 inch on sides of spline, nor 0.005 inch at root of spline, Spline damage must not exceed 0.100 square inch per serration.
- **b.** Polish out nicks, dents, scratches, or corrosion pits not exceeding limits given in figure 6-16 with fine India stone (C84), blending repair area with surrounding area.
- **c.** Replace mast if damage after cleanup exceeds limits given in figure 6-16.
- **d.** Remove superficial corrosion, using a wire brush or steel wool in area E of figure 6-16.

- e. If honing equipment is not available, surface corrosion may be removed from inside diameter of mast with sandpaper (C126). Abrasive cloth, etc., can be attached to **1.400 to 1.500** inch diameter ramrod or rotary drill with extension. Surface may be wet polished, using drycleaning solvent (C62). Do not overheat mast assembly during polishing operation.
- (1) After removal of corrosion products, surface stains excluded, thoroughly clean inside diameter with MEK (C107).
- (2) Treat inside diameter with oil (C103). To ensure adequate coverage, a double pour through is recommended.
- **f.** Replace upper mast bearing if unserviceable. Replace mast if TIR exceeds allowable specified limits in figure 6-16 and paragraph 6-96.
- g. Remove corrosion products from seal and bearing plate with sandpaper items (C124, C125, or C126) then clean surface with drycleaning solvent (C62). Pitting not to exceed **0.010** inch after cleanup will be permitted, provided pitting is not adjacent on both inner and outer diameters, and provided it does not effect critical sealing surfaces.
  - h. Replace all unserviceable parts






Figure 6-16. Mast Repair Areas and Limits (Sheet 1 of 3)

#### **ALLOWABLE**

Area E. Only surface rust which can be removed with a wire brush or steel wool.

Ares F. 0.015 Inch depth with 0.500 inch minimum radius.

Area G.This surface is a roller bearing inner race, perceptible wear necessitates measssurement. Wear allowed is 0.0002 inch by comparing worn to unworn area of bearing surface. O.D. MINIMUM is 2.0666 inch.

AraeH. 0.005 Inch depth or to a maximum I.D. of 1.620 inches provided cleanup is accomplished by honing or similar mathod so that material removed is uniform around diameter.

Area J. Rust shall be removed by raworking the mast to dimensions shown in DETAIL 1. Rework need not ba brought to tha minimum 2.252 inches O.D. provided all traces of corrosion and pitting are removed. Radius shall not be less than 0.250 Inch.


Ares K. The upper bearing journal surface may be reduced in width to allow repair in area J. Minimum acceptable width Is 0.740 Inch. See DETAIL 1. scattered nicks, scratches and pits to a depth of 0.002 inch after cleanup and not exceeding five percent of circumference are acceptable.

Area L. 0.005 inch depth with 0.050 Inch minimum radius.

#### NOTES:

- 1. External repairs must have a minimum radius of 0.500 inch unless, otherwise stated.
- 2. Internal repairs should consist of removing metal uniformly around the diameter.
- 3. Any maat whkh is reworked must be identified as REWORKED as follows:
  - a. Cost reworked areas A, B, and J with epoxy polyamide primer (C116)exclude mast splines, split cons, and thread separation.
  - b. EXAMPLE- When area F is reworked, lightly stamp the letters RF on the center of the mast date pkte between ths pert number and serial number.
  - Repairs to the mast I.D. in areas D and H will also Include I.D. measurements when stamping eras on date plats.
  - d. The uppar 2500 inches of the maat I.D., measured from the top down, maybe honed not to exceed 0.010 inches in depth (0.020 inch diameter). The first inch from the top must not exceed 1.705 inches inside diameter overall. Clean affected ares with MEK (C107) and cost with zinc chromate primer (C110).
- Previously reworked meets shall be carefully measured to ensure dimensions are not exceeded.
- 5. Internal repairs shall be costed with oil (C103).
- 6. All dimensions are in inches.
- 7. TIR total (dial) indicator reading.
- Only surfcecorrosion which can be removed with steel wool is reparable on the threads in area A; no other change is allowable.

Figure 6-16. Mast Repair Areas and Limits (Sheet 2)




# PREFERRED RUNOUT METHOD NOTE

Mount mast between live centers.

#### **ALLOWABLES**

- 1. Runout at area A (split cone seat) not to exceed 0.003 inch TIR.
- Runout at area B on OD of mast at a point 20.000 inches from top end not to exceed 0.015 inch TIR.
- 3. Runout at area C (upper bearing journal) not to exceed 0.003 inch TIR.
- 4. Runout at area D (lower bearing journal) not to exceed 0.002 inch TIR.



## **ALTERNATE RUNOUT METHOD**

## NOTE

Mount mast on two v-blocks, one v-block on area A (split cone seat), the other v-block on area B (upper bearing journal).

#### **ALLOWABLES**

- 1. Runout at area C (lower bearing journal), not to exceed 0.005 inch TIR.
- Any mast that exceed 0.005 inch TIR, shall be rechecked in accordance with preferred method runout before mast rejection.

Figure 6-16. Mast Repair Areas and Limits (Sheet 3)

206040-498-3

### WARNING

Refer to figure 6-16 mast repair areas and limits for any rework of mast assembly.

#### NOTE

Lubricate bearings and surfaces of mating parts on reassembly with oil (C103).

## 6-98. Assembly - Mast Assembly. (AVIM)

#### NOTE

To prevent corrosion, do not handle the bearing or the mast assembly with bare hand below upper mast bearing liner -- use white cotton gloves (C76). Use corrosion preventive compound (C52) to remove any existing fingerprints.

- **a.** If O.D. of bearing (12, figure 6-14) has a chamfer on one corner, install bearing with chamfer up. Apply a thin coating of corrosion preventive compound (C51) to the mast in the bearing mounting area and the lower half of the threaded area, filling the groove at the bottom of threads.
- **b.** Press bearing (12, figure 6-14) onto mast. After bearing is installed, fill the thread relief area located between the bearing and threads with corrosion preventive compound (C51).
- **c.** Preheat bearing liner (14) with heat lamp to 140°F (60°C) temperature and press liner onto bearing (12), using bearing puller (T16).
  - **d**. Position shim (11) on bearing (12).
- **e**. Position plate (10) on shim (11) and bearing liner (14). Remove or add shims to provide 0.001 to 0.004 gap between plate and liner. Refer to figure 6-17.
- **f**. Install packing (13, figure 6-14) in groove in bearing liner (14).
- **g.** Install seal (5) in plate (10). Apply film of sealing compound (C131.1) between seal O.D. and plate mating bore. Trim excess sealant. Lubricate seal lip with oil (C103).

- **h.** Insert mast bearing nut (4) into seal (5) installed in plate (10) before installing on mast
- i. Position seal (5) and nut (4) on shim (11) and bearing line (14).
- **j** Install screws (9) to secure plate (10) to bearing liner (14).
- **k**. Hold mast with holding fixture (T17) and torque nut (4) with wrench (T36). Torque nut to **500 TO 550 FOOT-POUNDS.** Refer to figure 6-17.

#### NOTE

Ensure that end of lockwire is bent In-board toward mast.

I. Apply small bead of sealing compound (Cl31) between mast nut and mast serrations. Install locking plate (3) and nut (4). Install two screws and lockwire.

#### NOTE

Apply thin coating of corrosion preventive compound (C51) to mast prior to bearing installation and above bearing to Include treated area. Remove excess compound after bearing Installation.

### **CAUTION**

If sealant Is applied after controls are Installed, do not cover drain holes at bottom of controls support. When sealant Is dry, trim excess material with sharpened plastic scraper. Do not use metal scraper. Refer to figure 6-17.

- **m** Apply sealant (C129) to a new cap-plug (16) and install cap-plug in main rotor mast (1, figure 6-14).
- 6-99. Installation Mast Assembly.

#### **NOTE**

To prevent corrosion, do not handle the bearing or the mast assembly, with bare hands below upper mast bearing liner, --- use white cotton gloves (C76). Use corrosion preventive compound (C52) to remove any existing fingerprints.




Figure 6-17. Main Rotor Mast Build-up

#### NOTE

Lubricate transmission spider splines and mast alignment bearing with oil.

**a.** Place packing (15, figure 6-14) in recess (not in oil groove) in top of transmission top case.

### **CAUTION**

Ensure mast bearing lubrication holes are free of obstructions. Blockage of lubrication holes can cause premature failure of the mast bearing.

**a.1.** Inspect mast assembly lubrication holes for blockage. if sealer or other foreign material is found, the mast assembly should be disassembled, cleaned, and reassemble.

#### **CAUTION**

To prevent entry of contaminants into mast assembly and transmission, ensure mast cap-plug (16) is installed.

- **b.** Install assembled main rotor mast through opening in top of transmission.
- **c.** Line up lower mast spline teeth with spline teeth in planetary spider.

- **d.** Guide end of mast into lower mast bearing and position upper mast bearing liner over mounting studs in top case.
- **e.** Install swashplate assembly. Refer to paragraph 5-121.
- **f.** Install main rotor assembly. Refer to paragraph 5-10.
- **g.** Install cyclic and collective rods. Refer to paragraph 5-114.
  - h. Install cowling. Refer to paragraph 2-46.

6-100. SIGHT GAGE, OIL LEVEL ASSEMBLY.

**6-101. Description** — **Sight Gage, Oil Level Assembly.** A sight glass located on the transmission housing is used to check the oil level in the transmission. The oil level must be visible in sight glass. If oil is visible, additional oil is not required. If oil is not visible in sight glass, add oil to the center dot only. The normal capacity is 4.0 U.S. quarts.

#### **NOTE**

Refer to paragraph 1-10 for additional information and servicing of transmission oil system.

6-102. Inspection — Sight Gage, Oil Level Assembly. Inspect sight gage for leaks, cracks, and discoloration of glass.

#### **NOTE**

Condensation on the inside of the sight glass is acceptable, providing that the oil does not have a dirty, milky appearance.

# 6-103. Removal — Sight Gage, Oil Level Assembly.

- a. Drain oil below sight gage.
- **b.** Remove retaining ring, sight glass and packing.

## 6-104. Repair — Sight Gage, Oil Level Assembly.

- **a.** Replace sight glass if badly discolored, cracked or excessively crazed.
  - b. Replace packing.

# 6-105. Installation — Sight Gage, Oil Level Assembly.

- **a.** Install new packing, sight glass and retaining ring.
- **b.** Service transmission oil system and check for leaks

## 6-106. SPINDLE (TRANSMISSION).

- **6-107. Description Spindle (Transmission).** Two spindles (2, figure 6-10) are installed, one on each side of the transmission case, and support the transmission to the pylon support links (11, figure 2-55).
- **6-108.** Inspection Spindle (Transmission). Inspect spindles (2) for cracks, nicks, and damage to threads of studs.

### 6-109. Removal — Spindle (Transmission).

- a. Remove nuts (16, figure 6-10), and washer (3).
- b. Remove spindle.
- **6-110.** Repair/Replacement Spindle (Transmission). Repair is limited to removal and replacement with authorized serviceable items Refer to TM 55-1520-228-23P.

## 6-111. Installation — Spindle (Transmission).

- **a.** Clean mounting areas of spindle (2) and transmission and apply sealing compound (C131).
- **b.** Install spindle (2), washers (3), and nuts (16). Torque nuts (16) **160 TO 190 INCH-POUNDS**
- **c.** Apply sealing compound (C131) to faying surfaces of spindle.

#### SECTION IV. TAIL ROTOR DRIVESHAFT

## 6-112. TAIL ROTOR DRIVESHAFT. (Prior to MWO 55-1 520-228 -50-25,)


## **NOTE**

Tail rotor driveshaft after compliance with MWO 55-1520-228-50-25, refer to paragraph 6-158.

**6-113. Description** — **Tail Rotor Driveshaft.** The tail rotor driveshaft is made up of the following four sections; the forward short shaft (3, figure 6-18), the oil cooler fan shaft (4), the aft short shaft (6), and the long shaft (10, figures 6-20 and 6-21). Flexible laminated steel disc couplings are used to connect

the shaft sections, freewheeling assembly, and the tail rotor gearbox.

- a. Original bearing hangers are split, with clamping bolt and shim to adjust fit with the bearing. This permits the bearing to be aligned within the hanger regardless of the angle of the hanger support on the tailboom.
- **b.** Improved bearing hangers incorporate a clinch bolt, clamping nut, spacer, and spring
- **6-114.** Lubrication Tail Rotor Driveshaft. Lubricate the tail rotor driveshaft in accordance with figure 1-5. Disassemble as required to gain access to adapters.



- 1. Shaft, Freewheeling
- Shaft Assembly , Short
   Shaft Assembly , Short
   Shaft
   Housing Assembly
   Shaft
   Shaft Assembly Drive

- 8. Adapter

- 9. Adapter 10. Washer, Beveled 11. Bolt, An174–7A 12. Washer, Flat 13. Adapter 14. Disc Assembly

- 15. Nut
- 16. Bolt, AN174-6A

Figure 6-18. Driveshafts - Tail Rotor (Forward Short Shft Typical (Sheet 1 of 2).




Figure 6-18. Driveshafts - Tail Rotor (Forward Short Shaft Typical) (Sheet 2)

#### 6-115. Inspection - Tail Rotor DriveShaft,

- **a.** Inspect shafts for scratches and damage. Surface of shafts (steel and aluminum) are to be smooth and unmarred.
- **b.** Inspect long driveshaft for wear adjacent to rubber bearing collar. This wear will be characterized by a bright polished ring usually no larger than **0.040** inch in width and running next to or from under the collar. When this wear is found, bearing should be replaced and shaft checked dimensionally. Maximum wear on diameter beneath bearing collar is **0.006** inch, determined by measuring the difference in diameter between the worn and unworn area. When wear is more than **0.006** inch, replace driveshaft and bearing collar and inspect bearing.
- **c.** Check tail rotor shafts for security of bonding of coupling adapters to ends of shafts, and security of bonding of splined adapter on forward end of long shaft. To teat bond, attempt to twist adapter on end of shaft and place end of thumb on head of pin and rotate pin in its hole. if pin is tight in hole and will not turn with thumb pressure, remove pin and check for failure of bond between adapter and end of shaft. Replace shaft if bond has failed
- (1) Check that splined adapter on short shaft is not seized by grasping and moving short shaft fore and aft.
- (2) Check that remaining splined adapters are not seized by flexing disc assembly and adapter with fingers and thumb. Inspect for fore and aft movement at coupling disc.

#### **NOTE**

## Do not attempt to move long shaft forward or aft.

- **d.** Inspect visible area of splines for nicks, dents, scratches, and corrosion. One third of the spline teeth may be corroded or damaged (dented, nicked, or scratched) if damage does not reduce the driving (profile) area by more than **5%** and:
- (1) No scratches or other damage deeper than 0.004 inch or longer than 0.250 inch exist.
  - (2) No three consecutive teeth are damaged.
  - (3) Raised material is smoothed off.

- (4) Measuring splines across two 0.120 inch diameter pins in minimum O.D., of 1.1070 is obtained.
- (5) Damage in other areas is not deeper than 0.006 inch or covering not more than 10% of area.
- **e.** Inspect the coupling discs for cracks, wear, or damage. Refer to paragraph 6-124.
- **f.** Inspect bearing collars (12, figures 6-20 and 6-21) as follows:
- (1) Ensure that sealing compound on both shaft and the bearing collar has not separated from bonding surfaces.
- (2) Replace collar or collars P/N 206-040-319-7 and/or P/N 206-040-319-9 when material is hard and/or cracked completely through to the surface of the driveshaft except as noted in step (3).

#### **NOTE**

If P/N 206-040-315-1 needs replacing use P/N 206-040-319-7 or P/N 206-040-319-9.

(3) Cracks at either end of collar that do not extend more than **0.300** from EOP maybe trimmed to eliminate crack.

#### **NOTE**

Collars P/N 206-040-316-1 are not to be trimmed or sealed.

g. Inspect hanger bearings as follows:

#### NOTE

Lubrication expelled from the bearing is not cause for rejection of the bearing. The expalled lubrication usually, is the result of over lubrication. Do not wash, clean, or spray the bearing or hanger assembly with any type of solution during inspection. Use only clean cloths or shop towels to clean the assembly.

(1) Inspection for bearing roughness is similar to other single row ball bearings of this type except seal drag is more noticeable in this bearing.

- (2) Inspect bearings for smoothness.
  - (a) Disconnect each end of shaft.
- **(b)** Rotate the shaft by hand and apply a slight radial load on each bearing.
- **(c)** When any roughness/drag is detected, replace the bearing.
- (d) Reconnect shaft using new self-locking nut.

#### **NOTE**

Bearing wobble is generally due to the misalignment of the inner race of the bearing on the collar and the corresponding misalignment of the bearing race and driveshaft through center line. Repositioning of the bearing collar on the shaft and bearing realignment is required to correct this deficiency. Bearing slippage is a positive indication of impending bearing failure. After bearing installation and alignment, slippage index marks should be painted from shaft to collar, collar to inner race, and outer race to hanger. Slippage marks should be check for evidence of movement after first flight following MOC and thereafter on a daily basis. If slippage has occurred during flight, the assembly must be reshimmed and/or realigned. If slippage is noted on hard type hangers during the daily inspection, bearing failure is imminent and bearing shall be replaced.

Bearings may move in the spring type hangers in certain normal conditions, when outer race slippage marks show evidence of motion, ascertain that the bearing has not failed and spun in the hanger. Evidence of motion between the bearing inner race and collar or between collar and shaft or a defective bearing is not acceptable and requires corrective action.

(3) Inspect bearing seal for deterioration. Replace bearing if seal is deteriorated.

#### NOTE

Small holes in rubber seals are acceptable on transfer inspection aircraft. These

holes are caused by field personnel lubricating the bearing with a hypodermic needle.

**h.** Inspect hanger for cracks, missing or improperly installed hardware.

#### NOTE

There is no established criteria for wear of the bearing hangers and associated hardware. Replacement of worn parts is required only to correct unacceptable high frequency vibrations.

#### 6-116. Removal — Tail Rotor Driveshaft

## Premaintenance Requirements for Driveshaft

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	None
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	Two
Consumable Materials	(C38) (C55) (C91) (C116) (C118) (C126)
Special Environmental Conditions	None

#### NOTE

Any section of driveshaft, except the fan shaft, may be removed without removing the other sections.

**a.** Remove forward short shaft. Refer to paragraph 6-132.

- **b.** Remove oil cooler fan shaft. Refer to paragraph 6-139.
- **c.** Remove aft short shaft. Refer to paragraph 6-148.
  - d. Remove long shaft. Refer to paragraph 6-155.

## 6-117. Repair — Tail Rotor Driveshaft.

- a. Aluminum driveshaft:
- (1) Area under and immediately adjacent to rubber collars with scratches up to 0.006 inch deep, axial or circumferential, but no longer than 1/4 of circumference will be blended out with crocus cloth (C55). Scratches and wear about the entire circumference must not exceed 0.002 inch. Difference between unworn diameter and worn diameter after cleanup must not exceed 0.006 inch. Treat blended areas with chemical conversion coating (38), then spray the bearing collar areas with zinc chromate primer (C118), and allow to dry prior to installation of the collars.
- (2) Other driveshaft areas. Scratches up to 0.005 inch deep, axial or circumferential, but not longer than 1/4 of circumference will be blended out with crocus cloth (C55) not to exceed 0.006 inch after cleanup. Scratches up to 0.002 inch deep about entire circumference will be blended out with maximum stock removal (including depth of scratch) not to exceed 0.003 inch. Treat blended areas with chemical conversion coating (C38), then paint the area with lacquer (C91).

#### **b.** Steel driveshaft:

- (1) Scratches up to **0.010** inch depth, axial or circumferential, but no longer than **1/4** of circumference will be blended out with sandpaper (C126). Lightly sand entire driveshaft, except for flat surfaces of couplings, to ensure good paint adhesion. Paint entire driveshaft, except for flat surfaces of couplings, with epoxy polyamide primer (C116).
- (2) Scratches up to 0.005 inch depth around the entire circumference will be blended out with sandpaper (C126). Difference between unworn diameter and blended diameter, after cleaning must not exceed 0.010 inch. Lightly sand entire driveshaft, except for flat surfaces of couplings, to ensure good paint adhesion. Paint entire driveshaft, except for flat

surfaces of couplings with epoxy polyamide primer (C116).

(3) Driveshafts having deteriorated cadmium plating will be lightly sanded, except for flat surfaces of couplings, to remove surface corrosion and ensure good paint adhesion. Paint entire driveshaft, except for flat surfaces of couplings, with epoxy polyamide primer (C116).

#### 6-118. Installation — Tail Rotor Driveshaft.

- **a.** Install forward short shaft. Refer to paragraph 6-134.
- **b.** Install oil cooler fan shaft. Refer to paragraph 6-143.
- **c.** Install aft short shaft. Refer to paragraph 6-150.
  - d. install long shaft. Refer to paragraph 6-157.

#### 6-119. DISC ASSEMBLY.


- **6-120. Description Disc Assembly.** Flexible laminated steel disc couplings, (4, figure 6-19) are used to connect the shaft section, freewheeling assembly, and the tail rotor gearbox.
- **6-121. Inspection** Disc Assembly. See paragraph 6-115 for inspection while installed on tail rotor driveshaft.

## 6-122. Removal - Disc Assembly.



After a disc assembly has been run on a helicopter, disc will not be changed from original stack up, Changing of sequence or reversing of indexing flats will render disc assembly unserviceable, and the disc assembly must be replaced with a new, properly stacked disc assembly.

Remove four bolts (2 and 7, figure 6-19), beveled washers (3), flat washers (5), and nuts (6). Support driveshaft (1) and carefully remove disc assembly (4) from adapters (8).



- 1. Shaft Assembly
- 2. Bolt, AN174-7A
- 3. Washer-Beveled
- 4. Disc Assembly
- 5. Washer, Flat
- 6. Nut
- 7. Bolt, AN174-H7A (See Note) Bolt, AN174-H6A (See Note)
- 8. Adapter (Splined)

#### NOTE

AN174-H6A bolts are used two places on each forward short shaft disc assembly. AN174-H7A bolts are used four places on each short shaft disc assembly. AN174-H7A bolts are used four places on each long shaft disc assembly. This figure reflects a typical stackup for the couplings on the aft end of three shaft assemblies (forward short shaft, aft short shaft, and long shaft). No threads are permitted to bear in adapters (item 1 and item 8) or the disc assembly (item 4). One size longer bolt, with a minimum of one thin washer and a maximum of one thick and one thin washer may be used under bolt head or nut next to driveshaft or adapter to correct for this condition. Opposing bolt lengths and washers must be equal. Under no condition will the beveled washer stackup be altered.

Figure 6-19. Aft Disc Assemblies

**6-123. Cleaning** — **Disc Assembly.** Clean disc assembly and adapter with drycleaning solvent (C62) and wipe clean with lint-free cloth.

6-124. Inspection — Disc Assembly.

#### **CAUTION**

Do not mix old and new discs. Do not change sequence of reverse indexing flats.

**a.** Inspect discs for cracking, wear, and damage. No damage of any type permitted. Disc assemblies vary between **9 to 12** plates, each plate of **0.010** to **0.014** inch thickness. Stacked discs in an assembly will vary between **0.115 to 0.127** inch. Any gap between two of the assembled discs must not exceed **0.005** inch at any point.

**b.** Inspect bolts, washers, and nuts for obvious damage and wear.

## 6-125. Repair — Disc Assembly.

- **a.** No repair is authorized for the disc.
- **b.** Replace defective bolts, washers, and nuts.

## **CAUTION**

Grain of each disc runs parallel to the indexing flat edges. When assembling new disc assembly it is necessary to alternate indexing flats to obtain alternate grain direction. DO NOT ALTER DISC STACK-UP SEQUENCE. Install beveled side of washers toward disc assembly. If beveled washers are installed with flat side of washer next to disc, premature failure is apt to occur.

#### NOTE

On each of the five disc assemblies torque the nuts in an alternate pattern. Tighten one nut to 20 INCH-POUNDS, then afternate 180 degrees and tighten the opposite nut the same amount. Repeat this procedure on all nuts increasing the torque 15 TO 20 INCH-POUNDS increments until the final torque value is reached.

a. Position disc assembly (4, figure 6-19) between shaft assembly (1) and adapter (8) and secure using




Figure 6-20. Long Driveshaft Installation — Tail Rotor (Hard Type)




Figure 6-21. Long Driveshaft Installation — Tail Rotor (Spring Type)

four bolts (2 and 7), beveled washers (3, beveled washers with rounded edge next to disc assembly and beveled washers with rounded edge next to adapter), flat washers (5), and nuts (6).

- b. Torque four nuts (6) 50 TO 70 INCH-POUNDS.
- **c.** After disc assembly is installed, inspect for distortion resulting in gaps between the individual discs. If any gaps are detected by visual examination, measure gaps with a feeler gage. Maximum allowable gap is **0.005** inch. If any gaps are found which exceed this limit, loosen bolts, rotate disc back and forth, and uniformly tighten bolts to required torque. Re-inspect for gaps, if gaps exceed limits replace disc assembly.

## 6-127. Adjustment and Alignment — Tail Rotor Driveshaft.

a. Original (Hard Type) Bearing Hangers.



All maintenance functions to be performed on the tail rotor driveshaft assembly during runup will be accomplished from the right side of the helicopter. Extreme care must be taken to prevent hands, clothing or tools from becoming entangled with operational components. Stay clear of the tail rotor.

- (1) For initial helicopter runup, torque bearing hanger clamp bolts 15 INCH-POUNDS to allow bearing to align.
- (2) Runup at least 15 minutes before checking for wobble.
- (3) Hangers must not wobble in free state more than 0.004 inch measured at hanger clamp ring during shaft rotation and must be centered in the bearing support bracket within 0.060 inch.

### NOTE

There is no established criteria for wear of the bearing hangers and associated hardware. Replacement of worn parts is required to correct unacceptable high frequency vibration.


- (4) After runup, torque bolts 50 TO 70 INCH-POUNDS. Lockwire (C96) after shutdown. Using acrylic lacquer (C92), paint slippage mark from driveshaft assembly to rubber collar, to inner race of bearing and from outer race of bearing to bearing hanger.
- (5) Maintenance operational check is required. Refer to TM 55-1500-328-25.
- (6) After maintenance operational check, inspect slippage mark. Any evidence of slippage requires replacement of shim (17, figure 6-20) with a shim 0.002 inch smaller.
  - b. Improved (Spring Type) Bearing Hangers.
- (1) Disconnect disc coupling at forward end of long driveshaft and remove aft short aluminum shaft,
- (2) Back off nut (1, figure 6-22) to end of clinch bolts. Do not remove nut.
- (3) Insert wedge in slot on the bearing hanger and open slightly taking care not to damage the hanger.
- (4) Rotate shaft by turning the tail rotor blade and hub assembly.
  - (5) Visually inspect the bearing for wobble.
- (6) If no wobble exists, remove wedge and torque 50 TO 70 INCH-POUNDS.
- (7) Repeat steps (2) through (6) for each bearing.
  - (8) Install aft short shaft removed in step (1).



Do not grasp tail rotor driveshaft while operating. Secure articles of clothing, rags, etc, to prevent wrapping about shaft.

Last two hangers will be adjusted from right (pilot) side of tailboom only. Stay clear of tail rotor blade when walking from one side of tailboom to the other.

(9) Ground run helicopter. During runup, insert a flat non-sharp tool in the parting line of bearing



206040-494

Figure 6-22. Improved (Spring Type) Bearing Hangers

hangers. Pry up to relieve tension from spring, thus allowing bearing to self align.

- (10) Remove tool and allow hanger to return to spring-loaded condition.
- (11) Repeat steps (9) and (10) for each bearing and hanger.
- (12) Continue ground run for 15 minutes, then shut down. During coastdown, check bearing wobble. This is indicated by noting wobble of bearing hanger when felt by hand. Eliminate wobble by repeating steps (9, 10, and 12).
- (13) After shutdown, disconnect disc coupling at forward end of long driveshaft and remove aft short shaft.
- (14) Slowly rotate shaft by turning the tail rotor blades and hub assembly by hand.
- (15) Visually inspect bearing and hangers for wobble. Bearing hangers must be centered within 0.060 inch of midpoint of bearing supports.

#### NOTE

A dial indicator, if locally available, may be used for this purpose. If the bearing inner race and collar are positioned square to the tail rotor shaft within 0.004 inch indicated runout, the bearing inner race and collar position is satisfactory.

- (16) If no wobble exists, reinstall aft short shaft. If wobble does exist, repeat steps (9) through (16) to remove wobble.
- (17) Paint slippage marks using acrylic lacquer (C92) from shaft to collar, collar to inner race and from bearing outer race to hanger.
- (18) To prevent corrosion damage to the tail rotor driveshaft, mask bearings and collars with tape (C143), then spray paint with acrylic lacquer (C91).
- (19) Maintenance Operational Check is required. Refer to TM 55-1500-328-25.
- (20) After Maintenance Operational Check, inspect slippage marks. Any evidence of slippage requires inspection in accordance with paragraphs 6-115 and 6-127, step b.

- 6-128. FORWARD SHORT SHAFT.
- **6-129. Description Forward Short** Shaft. The forward short shaft (3, figure 6-18), is a component section of the tail rotor driveshaft. Flexible adapter complete coupling of short shaft to main driveshaft and oil cooler fan driveshaft.
- **6-130.** Lubrication Forward Short Shaft. Refer to figure 1-5.
- **6-131. Inspection Forward Short Shaft.** Refer to paragraph 6-115 for required inspection.
- **6-132.** Removal Forward Short Shaft. Refer to figure 6-18. Remove two opposed bolts (16), washers (10 and 12), and nut (15) from splined couplings at each end of forward short shaft (3). Leave laminated disc assemblies assembled on forward short shaft. Remove forward short shaft (3) from helicopter.
- 6-133. Repair Forward Short Shaft. Refer to paragraph 6-117 for repairs.
- 6-134. Installation Forward Short Shaft.

#### **NOTE**

Prior to installation lubricate shaft and adapter splines identified in figure 1-5.

**a.** Position forward short shaft between freewheeling shaft (1, figure 6-1 8) and oil cooler shaft (22, figure 6-23).

# CAUTION

Install beveled side of washers toward disc assembly. If beveled washers are installed with flat side of washer next to disc this will result in premature disc failure.

## **NOTE**

On each of the five disc assemblies torque the nuts in an alternate pattern. Tighten one nut to 20 INCH-POUNDS, then alternate 180 degrees and tighten the opposite nut the same amount. Repeat this procedure on all nuts increasing the torque 15 TO 20 INCH-POUNDS increments until the final torque value is reached.




Figure 6-23. Oil Cooling Blower and Shaft Assembly (Sheet 1 of 3)




Figure 6-23. oil Cooling Blower and Shaft Assembly (Sheet 2)

Flat Steel Washer 26. Forward Short Shaft 27. Bolt 2. Screw 28. Housing Assembly 3. Retaining Screw 29. Nut 4. Gasket Flat Steel Washer 5. Aft Firewall 30. Aft Short Shaft 31. 6. Gasket 7. Doubler 32. Nut 8. Dissimilar Metals Tape (C138) 33. Kev Washer 9. Hanger Bearing 34. Bearing Flat Aluminum Washer 35. 10. Nut Flat Steel Washer 11. Key Washer 36. 12. Bearing Bolt 37. Bolt 13. Aluminum Washer 38. 14. Nut 39. Flat Steel Washer 40. Flat Aluminum Washer 15. Spacer Hanger Assembly 16. Bolt 41. 17. Bolt 42. Spacer 18. Flat Steel Washer 43. Shim 19. Aluminum Washer 44. Bolt 45. Flat Steal Washer 20. Flat Aluminum Washer

21. Flat Steel Washer

22. Shaft 23. Screw 24. Inlet Plate 25. Rotor Assembly

Clinch Nut 205040-495-3

Flat Aluminum Washer

Figure 6-23. Oil Cooling Blower and Shaft Assembly (Sheet 3)

46.

47.

48.

49

Shim Shim

#### NOTE

Bolts (11, figure 6-18) may be installed in either direction, for ease of maintenance. Diametrically opposed bolts must be in same direction.

install bolts (11) washers (10) and (16), and nuts (17). Refer to figure 6-18.

Torque four nuts (15) 50 TO 70 INCH-POUNDS.

## 6-135. OIL COOLING BLOWER AND SHAFT ASSEMBLY.

6-136. Description — Oil Cooling Blower and Shaft Assembly. The cooler blower is mounted on the structure, aft of the firewall and is driven by the tail rotor driveshaft. The squirrel cage type impeller is mounted on a flanged shaft which is mounted in bearing hangers. The blower shaft connects the forward and aft short tail rotor driveshafts and is part of the tail rotor driveshaft system. The oil cooler blower provides cooling air for the engine oil system and transmission oil system. The engine oil cooler mounts above the cooling blower while a flexible duct conveys cooling air forward to the transmission oil cooler.

## 6-137. Cleaning — Oil Cooling Blower and Shaft Assembly.

- Prepare two to four quarts of cleaning solution corsisting of one part cleaning compound (C43) (water soluble cleaner) to four parts of clean water.
- Remove aft fairing (5, figure 2-10) by loosening turn lock fasteners.
- Disconnect hose assembly at the engine oil cooler blower housing by removing clamps. Refer to paragraph 4-76.
- Temporarily reposition the hose assembly by pushing down on the hose assembly and pulling outward from the oil cooler blower housing.

## NOTE

Position hose assembly to ensure that the cleaning solution does not enter the hose assembly opening during flushing procedures.

- **e.** Operate engine at idle speed **62% to 63%** N1 during cleaning procedure.
- **f.** Spray the cleaning solution into the center of the oil cooler housing shaft ring assembly.



Do not spray the cleaning solution directly onto the blower assembly blades, balance could be affected.

- **g.** Spray the cleaning solution into the center of the oil cooler blower assembly at the rate of one quart to **9 to 11** seconds until 2 to 4 quarts have been utilized.
- h. After shutdown, visually inspect oil cooler blower assembly end oil cooler assembly for cleanliness and evidence of surface corrosion.
- i. Repeat above procedures as necessary until the oil cooler and oil cooler blower assembly are clean.
- **j.** install hose assembly on the oil cooler blower assembly and secure with clamp.
- **k.** Install aft fairing assembly and secure turnlock fasteners.

# 6-138. Inspection — Oil Cooling Blower and Shaft Assembly. (Figure 6-23.)

- **a.** inspect hangers and shaft for cracks and other mechanical damage.
- **b.** inspect rotor (25) for cracks, particularity at mounting flange and at individual blades. No cracks are allowed.
- **c.** if rotor requires refinishing, clean thoroughly and apply a very thin uniform coat of zinc chromate primer (C118).
- **d.** inspect housing (28) for cracks and other mechanial damage. Check for presence of drain hole in bottom of housing (28). if there is no drain hole, drill a **0.188 to 0.194** inch hole (No. 13 drill) in the bottom center of the housing approximately **0.0260** inch forward of the aft edge.

**e.** If there is any reason to suspect that an overspeed of the drive system has occurred, perform inspection of the hanger bearings outlined in paragraph 6-115, step g, and of blower rotor.

#### NOTE

Oil cooler blowers other than the two listed in Chapter 1, Section V are condition items.

# 6-139. Removal – Oil Cooling Blower and Shaft Assembly. (Figure 6-23.)

- **a.** Remove aft fairing to gain access to cooling blower.
- **b.** Remove forward and aft short tail rotor driveshafts attached to each end of gearshaft (22). Refer to paragraph 6-132 and paragraph 6-148.
- **c.** Drain oil tank and remove engine oil cooler, oil fittings and lines, flexible air duct, and other components as required to provide clearance for removal of blower assembly from structure. Refer to paragraph 4-75 for oil cooler removal.
  - d. Remove four screws (2, figure 6-23).

# CAUTION

if shims are lost or damaged and the exact thickness is not known, depot level maintenance is required. if shims are not bonded to structure, take adequate precautions to ensure that shims are reinstalled in same location.

**a.** Remove four bolts (44), four bolts (38), and two bolts (17). Remove fan and shaft assembly from helicopter, identify shims (43) for reinstallation in same location. Check that shims under bearing hangars (9 and 41) are bonded to helicoixer structure.

# 6-140. Disasaembly - Oil Cooling Blower and Shaft Assembly.

**a.** Straighten tang of key washers (11 and 33, figure 6-23), and remove nuts (10 and 32). Hold gearshaft with spline wrench (119), and remove nuts with spanner wrench.

- **b.** Remove hangers (9 and 41 ) as follows:
- (1) On original style (hard type) shown in figure 6-23, loosen bolts (16 and 37). Pivot hangers around toward the 90 degree position to bearings (12 and 34). Apply slight pressure to separate hanger from bearing (a wedge may be inserted in the slot on the hanger to open it slightly, taking care not to damage the hanger).
- (2) On improved (spring type) hanger shown in figure 6-22, loosen nuts (1) and remove hangers as outlined in step a. above.
- (3) Press bearings (12 and 34, figure 6-23) off gearshaft (22). Discard bearings as pressure applied to the outer race during removal damages the bearing.
- (4) Remove screws (23, figure 6-23) and plate (24). Remove gearshaft and rotor from housing (28).
- **(5)** Remove bolts (27) and remove rotor (25) from gearshaft (22).

## 6-141. Repair — Oil Cooling Blower and Shaft Assembly.

- a. Rotor assembly No repair is authorized except for rebalance. Refer to paragraph 6-142, step
- **b.** Gearshaft assembly Refer to repair procedures for steel driveshaft, paragraph 6-117, step b., except that bearing sleeves, threaded areas, and splines will not be painted.
  - **c.** Splines Refer to paragraph 6-115.
- **d.** Housing assembly Refer to TM 1-1500-204-23 for standard sheet metal repair procedures.

#### NOTE

If not previously accomplished, drill a 0.188 to 0.194 inch hole in the bottom center of the housing approximately 0.250 inch forward of the aft edge of housing assembly.

- (1) Repaint housing with epoxy polyamide primer (C116) or zinc chromate primer (C118).
- (2) If housing assembly (28) is generally deteriorated and damaged, replace housing assembly in lieu of repair.

**e.** Hanger assemblies — No repair other than dressing out minor scratches, nicks, and dents is authorized. Scratches, nicks, and dents up to **0.010** inch, except for bearing bolt, and interface areas, will be blended out with sandpaper (C126), polished with crocus cloth (C55) and touched up with epoxy polyamide primer (C116).

# 6-142. Reassembly — Oil Cooling Blower and Shaft Assembly.

#### NOTE

Balance gearshaft and rotor only when a known out-of-balance condition exists. Balancer to be fabricated locally, by use of two sections of aluminum alloy angle six inches in length, set a sufficient height to allow free movement of rotor.

Rotor and gearshaft is statically balanced. The heavy side will rotate to the lowest position on the balancer. Add washers (as required) to obtain a balanced assembly.

- **a.** Position rotor (25, figure 6-23) on gearshaft (22) from forward end as illustrated and install bolts (27), washers (26 and 30), and nuts (29). Tighten nuts (29) to align rotor with shaft but do not torque at this time. Place the gearshaft on knife edge balancer with the balancer blades positioned inboard of the keyway slots on the bearing journal surfaces. Add additional thin steel washers (30), to balance assembly as nearly as possible within the limits obtainable with one final AN960-416L washers may be used on one bolt (27), and a maximum of two AN4-6A bolts may be substituted for AN4-5A bolts (27) to obtain balance. When assembly is in balance, torque nuts (29), **TO 50 TO 70 INCH-POUNDS.**
- **b.** On original style (hard-type) bearing hangers shown on figure 6-23, fit new bearings to hangers as follows:
- (1) If not previously accomplished, install spacers (15 and 42), thin aluminum washers (20 and 35), thin steel washer (21 and 36), and bolts (16 and 37) on bearing hangers. Apply a thin coat of corrosion preventive compound (C51) to grips to bolts (16 and 37), prior to installation.
- (2) Hold bearing (12 and 34) 90 degrees, to notches in hangers, insert bearings one half way through hangers then rotate bearings into same plane as hangers.

(3) Check fit of bearings in hangers by same procedures as outlined for long tail rotor driveshaft. Refer to pararaph 6-157.

#### NOTE

If bearings P/N 206-040-339-7 or -9 are being installed, corrosion preventive compound is not required.

Bearing assemblies P/N 206-040-339-3 and -5 are no longer authorized for new installations. Bearing assemblies P/N 206-040-339-7 and -9 may be used interchangeably.

- (4) After bearings (12 and 34) are properly fitted to hangers remove bearings from hangers and apply a thin coating of corrosion preventive compound (C61) to mating surfaces of bearings and hangers. Thin the corrosion preventive compound with drycleaning solvent (C62), if necessary, but mix solvent and compound thoroughly. Do not allow compound to contact bearing grease seals. Reinstall bearings in hangers and torque bolts (16 and 37) 50 TO 70 INCH-POUNDS.
- **c.** On improved (spring-type) bearing hangers shown on figure 6-22, install new bearings as follows:

# CAUTION

Do not allow compound to contact bearing grease seals.

#### NOTE

The bearing-to-hanger fit check is not required on the (spring-type) bearing hanger. If bearings P/N 206-040-339-7 or -9 are being installed, corrosion preventive compound is not required.

Bearing assemblies P/N 206-040-339-3 and -6 are no longer authorized for new installations. Bearing assemblies P/N 206-040-339-7 and -9 maybe used interchangeably.

- (1) Apply a thin coating of corrosion preventive compound (C51) to mating surface of bearings and hangers. If necessary, thin the corrosion preventive compound with drycleaning solvent (C62).
- (2) Inspect spacers (2 and 5. figure 6-22) to ensure that they are the correct length spacers. Similar, but shorter, specers (8) could be intermixed with spacers (2 and 6). Install springs (3) on spacers (2 and 5) and insert spacers into bearing hangers (4 and 6). Install nuts (1) and torque 50 TO 70 INCH-POUNDS.

#### NOTE

Beveled aide of nut (32) should be installed toward the bowing.

**d.** Position inlet plate (24, figure 6-23) on shaft (22) aft of rotor (25). Pressbearing (34) and assembled hanger (41) on aft end of shaft with the side of the hanger with the longest height dimension toward the forward end of the shaft. Install key washer (33) and nut (32). Do not torque nut at this time.

### NOTE

Beveled side of nut (10) should b. installed toward the bearing.

- **e.** Position shaft (22) and rotor into housing (28). Press bearing (12) and assembled hanger (9) on forward end of shaft. Install key washer (11) and nut (10).
- **f.** Install injet plate (24) on housing (28) with screws (23).
- g. Hold shaft (22) with spline wrench (T19), and torque nuts (10 and 32) 200 TO 300 INCH-POUNDS with a spanner wrench. Lock nuts (10 and 32) by bending a tab of key washers into lugs of nuts.

## 6-143. Installation — Oil Cooling Blower and Gearshaft Assembly. (Figure 6-23.)

## Premaintenance Requirements for Installation of Oil Cooler Blower and Shaft

Condition	Requirements
Model	OH-58AIC
Part No. or Serial No.	All
Special Tools	None
Test Equipment	Torque wrench
Support Equipment	None
Minimum Personnel Required	Two
Consumable Materials	(C19) (C51) (C92) (C96) (C131) (C138) (C150)
Special Environmental Conditions	None

### CAUTION

Ensure that shims at mounting points for bearing hangers (9 and 41) are in proper place on helicopter structure. If any of these shims are missing or intermixed and proper thickness is not known, depot maintenance is required to determine proper shim thickness.

**a.** Ensure that shims are securely positioned at the bearing hanger mount bolt holes on the deck surface. Missing or excessively damaged shims must be replaced with shims of like thickness. Loose replacement shims must be secured in position on the deck. Apply adhesive (C19) around the outer edge of the shim.

## **NOTE**

Use dissimilar metals tape (C138) or sealing compound (C131) between doubler and bearing hanger as a corrosion preventive measure.

- **b.** Position oil cooling blower and shaft assembly on helicopter. Place gasket (4) and retaining plate (3) on forward side of firewall and install screws (2). Place two gaskets (6), doubler (7), and dissimilar metals tape (C138) (8) between firewall and hanger (9). Install washers (13) and nuts (14). Do not tighten nuts (14) at this time
- c. Check that original shims (43) are bonded in place under housing (28). If found unbended, clean affected bonding area with ethyl alcohol or toluene (C150), and apply a layer approximately 1/64 to 1/32 thick of adhesive (C19) to bonding area. Install bolts (44) with thin steel washer (45) under bolt heads and aluminum washers (46) next to housing. Bolt (44) at right hand, aft location is an AN3-5A bolt. The other three bolts (44) are AN3-4A. Install a right angle bracket (not illustrated) with the AN3-5A bolt.
- **d.** Install oil cooler on housing (28). Install aft fairing temporarily and check that oil cooler and aft fairing fit properly. If required, adjust shims (43) to obtain proper fit. Remove aft fairing after proper fit is obtained.
- **e.** Position hanger (41) and install four bolts (38) with thin steel washers (39) next to bolt heads and aluminum washers (40) next to hanger. Do not torque bolts at this time.
- **f.** Install two bolts (17) with thin steel washers (18) next to bolt heads and aluminum washers (19) next to hangers. Do not torque bolts at this time.
- **g.** Check fit of hanger (9) to firewall (5). If firewall is deflected in excess of 3/32 inch, move one gasket (6) to forward side of firewall. Ensure that dissimilar metals tape (C138) is in place next to hanger and install nuts (14) and tighten snugly.
- **h.** Rotate shaft (22) and check rotor (25) to ensure that rotor has adequate clearance with housing (28).
- i. Torque bolts (17) **50 TO 70 INCH-POUNDS** and lockwire (C96) bolts to hanger.
  - j. Torque bolts (44) 20 TO 25 INCH-POUNDS.
- **k.** Torque bolts (38) 50 to 70 INCH-POUNDS and lockwire bolts in place using lockwire (C96).
- **I.** Install forward short shaft (1) and aft short shaft (31). Refer to paragraphs 6-134 and 6-150.

- **m.** Instail oil lines, flexible air duct, and other components removed in paragraph 6-139, step c.
  - n. Fill engine oil tank. Refer to paragraph 1-8.
- **o.** On original style (hard-type) bearing hangers shown gure 6-23, align bearing (12 and 34) as follows:
  - (1) Torque bolts (16 and 37) to 5 INCH-POUNDS.

During accomplishment of following step do not allow bearing outer races to rotate excessively.

- (2) Ground runup is required. During runup remove all torque on bolts (16 and 37), if necessary, to allow bearing outer races to move and align in hangers.
- (3) After bearings (12 and 34) are aligned, torque bolts (16 and 37) 60 TO 70 INCH-POUNDS and lockwire. Using acrylic lacquer (C92), paint slippage mark from driveshaft to inner race of bearing and from outer race of bearing to hanger. Torque nuts (14) 50 TO 70 INCH-POUNDS.
- (4) Apply corrosion preventive compound (C51) to outer races of bearings (12 and 34) and to adjacent area on bearing hanger. Do not allow corrosion preventive compound to contact bearing seals.
- (5) Perform maintenance operational check. After MOC, check slippage marks on bearings (12 and 34). If either bearing outer race has moved in its hanger, replace the associated spacer (15 or 42) with a spacer 0.002 inch thinner and repeat steps (1) through (5).
- **p.** On improved (spring-type) bearing hangers shown on figure 6-22, align bearings in hanger (4 and 6) as follows:
- **(1)** Remove forward short shaft (1) if required. Refer to paragraph 6-132.
- (2) Back off the bearing hanger clamp nuts, (1, figure 6-22) to end of clinch bolt. Do not remove nut.

#### **NOTE**

Construct a wedge from nonmetallic stock with thickness of 0.25 inches. Form edge by filing an end to insert into opening of hanger when performing bearing wobble inspection.

- (3) Insert wedge in slot on the bearing hanger and open slightly taking care not to damage the hanger.
- (4) Rotate shaft by turning the tail rotor blade and hub assembly.
  - (5) Visually inspect the bearing wobble.
- (6) If no wobble exists, remove wedge and torque 50 TO 70 INCH-POUNDS.
- (7) To remove wobble, reposition bearing outer race in hanger.
- (8) Remove steps (2) through (7) for both bearings.
- **(9)** Install forward short shaft if removed in step (1) above.
- **q.** Ground run helicopter for **15** minutes. During coastdown, check bearing wobble. This is indicated by noted vibrations of bearing hanger when felt by hand. Eliminate wobble by repeating above steps (2) through (7).

#### NOTE

An additional maintenance operational check will be required if corrective action was required in the above step q.

### 6-144. AFT SHORT SHAFT.

- **6-145. Description Aft Short Shaft.** The aft short shaft, a section of the tail rotor driveshaft, is located between the oil cooler fan shaft and the long tail rotor driveshaft. Flexible laminated steel disc assemblies and splined adapters connect the shaft sections.
- **6-146. Lubrication Aft Short Shaft.** Refer to Chapter 1, figure 1-5 for lubrication requirements.
- **6-147. Inspection Aft Short Shaft.** Refer to paragraph 6-115.
- **6-148.** Removal Aft Short Shaft. Remove two opposed bolts (11, figure 6-18), washers (10 and 16) and nut (17) from adapters at each end of short shaft (6). Leave laminated disc assemblies (14) assembled on aft short shaft (6). Remove aft short shaft (6) from helicopter.



6-149. Repair – Aft Short Shaft. Refer to paragraph 6-117.

6-150. Installation - Aft Short Shaft.

## CAUTION

Install beveled side of washers toward disc assembly. If beveled washers are installed with flat side of washer next to disc this will result in prematura disc failure.

#### NOTE

Prior to installation, lubricate shaft and adapter splines identified in figure 1-5.

**a.** Position aft short shaft (6) on helicopter. Install bolts (11) with washers (10 and 16) and nuts (17). Refer to figure 6-18 for beveled washers (10) installation.

### NOTE

On each of the five disc assemblies torque the nuts in an alternate pattarn. Tighten one nut 20 INCH-POUNDS, then alternate 180 degrees and tighten the opposite nut the same amount. Repeat this procedure on all nuts increasing the torque 16 TO 20 INCH-POUNDS increments until the final torque value is reached.

b. Torque nuts (17) 60 TO 70 INCH-POUNDS.

### 6-151. LONG SHAFT,

**6-152. Description** — **Long Shaft.** The long shaft, a section of the tail rotor driveshaft, couples the aft short shaft to the tail rotor gearbox. Flexible laminated steel disc couplings, splined adapters, and bearing hangers support and connect the long driveshaft to the tail rotor gearbox. Refer to figure 6-20.

**6-153. Lubrication** — **Long Shaft.** Refer to Chapter 1, figure 1-5 for lubrication requirements.

**6-154. Inspection** – **Long Shaft.** Refer to paragraph 6-115 for inspection of long driveshaft.

6-155. Removal — Long Shaft, Refer to figures 6-20 and 6-21.

## Premaintenance Requirements for Removal of Long Driveshaft

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	None
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	Two
Consumable Materials	(C106) (C107)
Special Environmental Conditions	None

- **a.** Remove two opposed bolts (2), washers (6 and 3), and nuts (7) from coupling at each end of shaft. Leave laminated discs assembled on splined adapter on tail rotor gearbox and on aft end of aft short tail rotor driveshaft (1).
- **b.** Remove two hanger screws (23), washers (21), cotter pin (27), and nuts (20) attaching each of six bearing hangers (13) to support brackets (22) mounted along top center of tailboom. Remove tail rotor shaft (10) and bearing hangers (13) from tailboom.
- **c.** Remove safety pin (9), washers (26), cotter pin (27), and adapter (5) from forward end of long driveshaft (10).
- **d.** Clean shaft of all accumulated dirt or grease. Surgical lubricant (C106) applied to the shaft will serve as an aid in removal and installation of bearing assemblies. Remove lacquer with MEK (C107) as required for collar removal.

Do not remove bearing hanger (13) from bearing (11) while still on shaft.

- **e.** Remove bearing (11), hanger (13), and collar (12), by sliding forward and off end of long driveshaft (10).
- f. Remove bearing (11) from hanger (13) as follows:
- (1) On original style (hard-type) hanger, remove bolt (15), washers (14 and 21), and shim (17). While holding hanger (13), twist bearing (11) one-quarter turn on its vertical axis and remove through slot.
- (2) On improved (spring-type) hanger, remove nut (1, figure 6-22), spacers (8), and spring (3). While holding hanger (7), twist bearing one-quarter turn on its vertical axis and remove through slot.
- **g.** Remove bearing collar (12, figure 6-20) from bearing (11).
- **6-156. Repair Long Shaft.** Refer to paragraph 6-117.
- 6-157. Installation Long Shaft.

## Premaintenance Requirements for Installation of Long Driveshaft

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	None
Test Equipment	Torque wrench
Support Equipment	None
Minimum Personnel Required	Two
Consumable Materials	(C51)(C106) (C107)(C131) Shims (Refer to table 6-3)
Special Environmental Conditions	None

#### **NOTE**

Either the original style (hard-type) or improved (spring-type) bearing hangers may be installed and are interchangeable.

**a.** Install bearings (11, figure 6-20) in original style (hard type) hanger (13) as follows:

#### **NOTE**

The original style (hard-type) bearing hangers can be installed with the lock-up hardware either to the left or right side of the driveshaft. For safety, the hardware should be installed to the right in the tail rotor area.

If bearings P/N 206-040-339-7 or -9 are being installed, corrosion preventive compound is not required.

Bearing assemblies P/N 206-040-339-3 and -5 are no longer authorized for new installations. Bearing assemblies P/N 206-040-339-7 and -9 may be used interchangeably.

- (1) Install assembled bearings and hangers on their respective collars. (Refer to figure 6-24.)
- (2) Position each hanger to correspond to hanger supports (22, figure 6-20).
- (3) Install bolt (15), washers (14 and 21), and shim (17) in hanger (13), torque bolt 50 T0 70 INCH-POUNDS. Bearing should not pivot axially or rotate radially under hand pressure.

## NOTE

Shims (17) are available in 0.002 inch thickness difference as listed in table 6-3. Use proper thickness shim to obtain correct fit.

Table 6-3. Shim Thickness

206-040-347-1	0.060 inch
206-040-347-3	0.058 inch
206-040-347-5	0.056 inch
206-040-347-7	0.054 inch
206-040-347-9	0.062 inch
Use proper thickness shim to ob	tain correct fit.

NOTE: All dimensions are in inches.




Figure 6-24. Typical Bearing Locations and Numbering

- (4) Loosen bolt and install **0.002** inch shim with shim (17); torque bolt to **50 TO 70 INCH-POUNDS.** Using hand pressure, bearing should pivot axially, but not radially.
- (5) Loosen bolt and remove extra shim. Refer to paragraph 6-127 for initial helicopter runup torque and final torque.

## NOTE

As an alternate check to prevent excessively tight or loose bearing fit, perform the following:

- (a) Torque bolt (15) 50 TO 70 INCH-POUNDS. At 65° to 85°F, the torque required to pivot the bearing in any direction from dead center in the hanger must be within 115 TO 155 INCH-POUNDS. If the torque is high or low change shim (17) to obtain an acceptable fit.
- **(b)** An acceptable way to accomplish this alternate check is to insert a 10 inch socket wrench extension into the bearing, attach a spring scale to the end of the extension and pull perpendicular to the extension with the spring scale. Bearing should pivot between **11.5 TO 15.5** pounds.

#### NOTE

If bearings P/N 206-040 -339-7 or -9 are being installed, corrosion preventive compound is not required.

Bearing assemblies P/N 206-040-339-3 and -5 are no longer authorized for new installations. Bearing assemblies P/N 206-040 -339-7 and -9 may be used interchangeably.

- **(6)** Apply a thin coating of corrosion preventive compound (C51) to inner diameter of hangers and outer diameter of bearings.
- (7) Apply a thin coating of corrosion preventive compound (C51) to edge of bearing and hanger. Do not allow compound to contact bearing grease seal.

### NOTE

To complete driveshaft installation, use procedures outlined in steps b.(7) through b.(16).

**b.** Install bearings in improved (spring-type) hangers (7, figure 6-22) as follows:

#### NOTE

Bearing to hanger fit check is not required on improved (spring-type) bearing hangar.

Replace driveshaft if painted with epoxy paint. Epoxy paint cannot be removed and will prevent proper installation of the new collars.

The procedure for installation of new collars (P/N 206-040-319-7 and -9) requires that a single collar will first be installed on the shaft then its associated bearing and hanger.

Collars will not be reused. Replace collar whenever a bearing is removed for any reason.

Preformed packings (16, figure 6-21) will be installed at bearing location No. 7.

(1) Clean shaft thoroughly with MEK (C107).

#### WARNING

Surgical lubricant (C106) is the only authorized lubricant for installation of the new collars.

- (2) Apply a thin coat of surgical lubricant (C106) to shaft and inner diameter of collar (12) and install collar. Refer to figure 6-24 for locations.
  - (3) install baering in hanger.

### **CAUTION**

Inspect spacer (8, figure 5-22) to ensure that it is the correct length.

- (4) Install nut (1), spacer (8), and spring (3) on bolt installed in hanger (7), and torque 50 TO 70 INCH-POUNDS.
- (5) Install assembled bearing and hanger on its respective collar. (Refer to figure 6-24.)

#### NOTE

Bearing shall be positioned on the straight part of the new Improved collar, within 0.260 inch of center.

- (6) After all collars, bearings, and hangers have been installed in the above manner, position each hanger to correspond with bearing support (22, figure 6-20).
- (7) After collars, bearings, and hanger assemblies have been properly positioned, clean affected areas adjacent to each collar using MEK (C107).
- (8) Using a spatula, apply sealing compound (C131) around the ends of each collar to create a fillet approximately 0.030 inch by 0.250 inch on the shaft at the I.D. edge of the collar.

#### **CAUTION**

Ensure that safety pin, washer, and cotter pin are properly installed.

(9) Insert pin (9, figure 6-20 or 6-21) through shaft (10) and adapter (8). Secure with washer (26) and cotter pin (27).

#### NOTE

Prior to installation, lubrfcate shaft and adapter splines identified in figure 1-5 with grease (C77).

(10) Install splined adapter (5, figure 6-20 or 6-21) on forward end of shaft. install splined adapter (4, figure 6-28) on input pinion shaft (5).

Install beveled side of washers toward disc assembly. If beveled washers are installed with flat side of washer next to disc, premature disc failure will result.

(11) Position long tail rotor driveshaft assembly along top of tailboom. Connect disc assemblies at ends of tail rotor driveshaft. Refer to paragraph 6-126 for installation of disc assembly.

#### **NOTE**

Install packings (16, figure 6-20 or 6-21) as spacers on the bushings of the seventh hanger.

Install additional washers as required if screw grip is too long for cotter pin installation.

- (12) Insert two screws (23, figure 6-20 or 6-21) through support (22), bushing (19), and hanger (13). Ensure bushings (19) are in place,
- (13) Install washer (21) and nut (20) on each screw (23) and torque 35 TO 45 INCH-POUNDS. Install cotter pin (27).

#### NOTE

In operation, the driveshaft is free to float within the limits of the packings on the seventh hanger.

- (14) Reposition shaft to give 0.110 to 0.170 inch clearance between aft end of adapter (4, figure 6-28) and gearbox (8). See detail in figure 6-28.
- (15) Center bearing hangers within 0.060 inch of midpoint of bearing supports (22, figure 6-21) while maintaining the 0.110 to 0.170 inch clearance between adapter (4, figure 6-28) and gearbox (8).
- (16) Perform adjustment and alignment of tail rotor driveshaft. Refer to paragraph 6-127.
- **6-158. TAIL ROTOR DRIVESHAFT.** (After compliance with MWO 55-1520-228-50-25.)
- **6-159. Description Tail Rotor Driveshafts,** The driveshafts consist of separate segments that are

connected by flexible, laminated steel disc assemblies and supported by bearing hangers. Five of the driveshaft segments installed between the forward and aft tailboom bearing hangers are identical and interchangeable. The shaft forward of the blower is constructed of steel and the remaining shafts are constructed of aluminum alloy. (Figures 6-25 and 6-27.)

## Premaintenance Requirements for Tail Rotor Driveshaft

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	None
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	Two
Consumable Materials	(C45) (C77) (C22) (C50) (C38) (C126) (C62) (C127) (C143) (C147) (C155) (C84) (C154) (C90)
Special Environmental Conditions	None

## 6-160. Inspection and Repair — Tail Rotor Driveshaft.

- **a.** Inspect surfaces of driveshafts (1 through 6, figure 6-25) for scratches, corrosion, or other damage. Surface of driveshafts to be smooth and unmarred. Replace driveshafts which exceed the following limits:
- (1) Scratches up to **0.002** inch deep around entire circumference shall be blended out using **400** to 600 grit sandpaper (C126 or C127) or abrasive cloth (C45). Maximum stock removal is **0.003** inch.
- (2) Scratches up to 0.005 inch deep, axial or circumferential, but not longer than 25 percent of the






Figure 6-25. Segmented Tail Rotor Driveshaft (Sheet 1 of 3). (After Incorporation of MWO 55-1520-228-50-25)








Figure 6-25. Segmented Tall Rotor Driveshaft (Sheet 2). (After Incorporation of MWO 55-1520-228-50-25)

Driveshaft Driveshaft 3. Driveshaft Driveshaft Driveshaft Driveshaft Slip Adapter Tail Rotor Gearbox 8. Splined Adapter Nut 10. Steel Washer 11. **Beveled Washer** Disc Assembly 13. **Beveled Washer** Bolt Bracket Nut Cotter Pin 18. Aluminum Washer Screw 19. 20. Bushing Splined Adapter 21. 22. Hanger 23. Driveshaft **Spring** 

Spacer

Packing

Nut

#### NOTES

Torque nuts 50 to 70 Inch-pounds.



Torque nuts 30 to 40 Inch-pounds.



Four packings, two each side, forward and aft end at fifth hanger only



All dimensions are in inches.

Bott lengths shall be changed as require to prevent nuts from bottoming on bolt threads.





A minimum of two threads shall protrude beyond the nut. Bolt length and number of washers shall be equal at any pair of bolts located diametrically oppo-site each other.



Disc assembly stack-up must not be disturbed. Disc indexing flats must be alternated in disc assembly. No gaps exceeding 0.005 inch are permitted between the discs (see detail C). Inspect disk for damage. No repair is authorized on disk.



Install washers with rounded edge side adjacent to disc assembly. When two washers are specified in contact with each other, the flat side of washers shall be installed back to back.



Any equivalent size packing may be substi-



Afterinstallation, the hanger assemblies are to be centered in the brackets within 0.030 of the mid-position of the available gap.



△10 One 206-040-329-3 washer may be removed at bearing hangers to obtain hanger to bracket centering per note/9 and 0.290-0.350 dimension at the tail rotor gearbox



One 206-040-329-3 washer may be added at bearing hangers to obtain hanger to bracket center per note

🛕 and 0.290-350 dimension at tall rotor gearbox.



Additional aluminum washers may be added if screw grip is too long for cotter pin installation.



Minimum clearance between bolt heads or threaded ends and the hanger brackets shall be .06 (1/16) inches. Check with drive shaft at fwd and aft limits of motion. Clearance is required between all rotating parts and structures.



Inspect the beveled washer, P/N 206-040-329-3, prior to installation to assure it is in fact beveled or rounded on one side.



215 Bolts may be installed in either direction. The bolts are illustrated with nuts facing away from hangers for mot convenient torque application.



Boit length shall be selected so that there are no threads bearing in the shaft, shaft adapter, or disc assembly.



Diametrically opposed bolt installation shall be identical bolt length, bolt direction, and washer arrangement.

Figure 6-25. Segmented Tall Rotor Driveshaft (Sheet 3) (Aft Incorporation of MWO 55-1520-228-50-25)

#### TM 55-1520-228-23

circumference, shall be blended out using 400 to 600 grit sandpaper (C126 or C127) or abrasive cloth (C45). Maximum material removal is **0.006** inch.

- (3) Nicks shall be removed from corners using 400 to 600 grit sandpaper (C126 or C1 27) or abrasive cloth (C45) using a chamfer of **0.030** inch by **40 to 50** degrees, whose total length, when blended to existing surface shall not exceed **0.050** inch. Maximum of two repairs are permitted in the same quadrant of the driveshaft.
- (4) Corrosion pitting shall be blended out using 400 to 600 grit sandpaper (C126 or C127) or abrasive cloth (C45). Maximum stock removal is **0.006** inch.
- **b.** Inspect surfaces of splined adapters (9) for scratches, corrosion, or other damage. Surface of adapters to be smooth and unmarred. Replace adapters which exceed the following limits:
- (1) Scratches up to **0.005** inch deep around the entire circumference shall be blended out using 400 to 600 grit sandpaper (C126 or C127) or abrasive cloth (C45). Maximum material removal is **0.007** inch.
- (2) Scratches up to **0.010** inch deep, axial or circumferential, not longer than **25** percent of circumference shall be blended out using 400 to 600 grit sandpaper (C126 or C127) or abrasive cloth (C45). Maximum material removal is **0.012** inch.
- (3) Nicks shall be removed from corners using 400 to 600 grit sandpaper (C126 or C127) or abrasive cloth (C45) using a chamfer of **0.030** inch by 40 to 50 degrees, whose total length, when blended to the existing surface is **0.500** inch. Maximum of two repairs are permitted in same quadrant of the adapter.
- (4) Corrosion pitting shall be polished out using 400 to 600 grit sandpaper (C126 or C127) or abrasive cloth (C45). Maximum material removal is 0.010 inch.
- **c.** Inspect surfaces of hangers (23) for scratches, corrosion, or other damage. Replace hangers which exceed the following limits:

#### NOTE

It is preferred that all hanger bearing clamp hardware will be on the left after compliance with MWO 55-1520-228-50/25.

- (1) Scratches, nicks, and corrosion on exterior surfaces shall be blended out using 400 to 600 grit sandpaper (C126 or C127) or abrasive cloth (C45).
  - (2) Maximum material removal is **0.010** inch.
- **d.** Any damage or repairs to an anodized finished surface requires repair with chemical conversion coating (C38).
- **e.** Touch up clear protective coating on tail rotor driveshaft segments (1, 2, 3, 4, 5, and 6) as required (paragraph 6-172).
- f. Inspect sealed tail rotor hanger bearings for smoothness, evidence of overheating and turning inside the hanger. Do not wipe bearing seal lip. If bearing is running hot, inspect at frequent intervals until 20 hours of operation have elapsed. If bearing temperature has not stabilized after this time, replace bearings.

## WARNING

If there is any question of bearing serviceability, replace bearing.

## **CAUTION**

After a disc assembly has been run on a helicopter, discs should not be changed from original pack except as noted in step g. The grain of each disc runs parallel to the indexing flat edges. When assembling disc pack assembly, it is necessary to alternate indexing flats to obtain alternate grain direction. See detail C.

## **NOTE**

The inspection for rough bearings should be accomplished after a flight while the bearings are still warm. New bearings will normally run warm for the first 20 hours of operation. If a rough bearing is found, but there is no indication of overheating, fly helicopter for another 5 to 20 hours and check bearing again for roughness. Also check proper alignment of the bearing to the shaft by rotating the shaft and checking for wobble of the hanger at the attaching bracket, with screws removed.

It is not necessary to disconnect segmented driveshaft. Turn main rotor system to check for rough, misaligned, or binding bearings.

- g. inspect disc assemblies (13) for distortion resulting in gaps between the disc. Do not mix old and new discs. Do not change sequence or reverse indexing. No gaps exceeding 0.005 inch are permitted between the discs. If any gaps are found loosen bolts, rotate discs back and forth, and then uniformly tighten bolts to required torque. Recheck gaps. If gaps still exist replace disc assembly (13). When discs are in an assembly, the thickness is 0.115 to 0.127 inch. The disc assemblies vary between 9 to 12 plates. Thickness of each plate varies between 0.010 to 0.014.
- **6-161.** Cleaning Tail Rotor Driveshafts. Clean segments of the tail rotor driveshafts with drycleaning solvent (C62) and dry with filtered compressed air. Do not allow solvent to contact sealed bearing and do not wipe grease from bearing seals. Wiping grease from seal may push foreign material into bearing.

## 6-162. Removal - Tail Rotor Drivashaft Segment - Typical.

**a.** Open or remove tail rotor driveshaft covers. (Refer to Chapter 2.)

#### **CAUTION**

After a disc assembly has bean run on a helicopter, discs should not be changed from original pack except as noted in paragraph 6-160, step g.

### NOTE

Remove tail rotor driveshaft segments (1,2,3,4,5, and/or 6, figure 6-25) individually, or as required to accomplish maintenance requirement.

- **b.** Remove tail rotor driveshaft segment (typical, detail A) by removal of two diametrically opposed bolts (15), beveled washers (12 and 14), thin steel washers (11), and nuts (10) from aft discassembly (13). This will leave the disc assembly (13) attached to aft end of driveshaft.
- **c.** Remove two diametrically opposed bolts (15), beveled washers (12 and 14), thin steel washers (11), and nuts (10) from forward splined adapter (22).
- **d.** Remove cotter pins (18), nuts (17), aluminum washers (19), screws (20), from hanger (23). Lift complete tail rotor driveshaft segment (1) from hanger bracket on top of tailboom.

- **e.** When removing the fifth hanger (23), remove packings (28) on forward and aft end of hanger. (See detail B.)
- **f.** Remove slip adapter (7) from input shaft on tail rotor gearbox (8).
- **g.** If required, remove disc assembly (13) from drivshaft segment (24) by removing two bolts (15), beveled washers (12 and 14), washers (11), and nuts (10).


## 6-163. Disassemble Driveshaft Segment (After MWO 55-1520-226-50-25).

Remove driveshaft segment with hanger attached from tailboom. Refer to paragraph 6-162.

- **b.** Remove adapter (6, figure 6-26) from driveshaft (2) as follows:
  - (1) Remove nut (4), washer (5), and plate (3).
  - (2) Remove adapter (6).

Remove hanger (7) from driveshaft. Refer to paragraph 6-155.

**d.** Press bearing (1) off driveshaft (2). Discard bearing.



206040-498

Adapter
 Hanger

Figure 6-26. Tail Rotor Driveshaft Segment Disassembly (After incorporation of MWO 55-1520-228-50-25)




Figure 6-27. Forward and Aft Short Tail Rotor Driveshaft




Figure 6-28. Tail Rotor Gearbox Installation

# 6-164. Assemble Driveshaft Segment (After MWO 55-1520-228-50-26).

- **a.** Press bearing (1) against shoulder on driveshaft (2).
- **b.** Install hanger (7) onto bearing (1). Refer to paragraph 6-157.b.
  - c. Install adapter (6) as follows:

#### **NOTE**

Prior to installation, lubricate driveshaft (2, figure 6-26) and adapter (6) splines with grease (C77).

- (1) Insert adapter (6) onto splined end of driveshaft (2).
  - (2) Install plate (3), washer (5), and nut (4).
  - (3) Torque nut (4) 30 TO 50 INCH-POUNDS.

# 6-165. Installation — Tail Rotor Driveshaft Segment - Typical.

**a.** Apply a light coating of grease (C77) to splines on input pinion shaft of tail rotor gearbox (8, figure 6-25) and slip adapter (7). (See detail D.) Position slip adapter (7) onto input pinion shaft of tail rotor gearbox (8).

After a disc assembly has been run on a helicopter, discs should not be changed from original pack except as noted in paragraph 6-160, step g.

The grain of each disc runs parallel to the indexing fiat edges. When assembling disc pack assembly, it is necessary it alternate grain direction. See detail C.

**b.** Install disc assemblies (13) to aft splined adapters (9) on each tail rotor driveshaft as follows:

## **CAUTION**

Beveled washers must be installed with rounded edge side contacting disc assemblies and quantities must be equal at 180 degree positions.

Only the grip portion (unthreaded) of bolts are permitted to contact disc assemblies and boit lengths must be equal at 180 degree positions.

- (1) Install two diametrically opposed bolts (15), beveled washers (12 and 14), thin steel washers (11), and nuts (10). install beveled washers with rounded edge side in contact with disc assembly (13). Torque nuts uniformly in 20 inch-pound increments 50 TO 70 INCH-POUNDS.
- (2) Inspect all disc assemblies (13) for distortion resulting in gaps between the individual discs. No gaps exceeding 0.005 inch are permitted between discs. If any gaps are found, loosen bolts, rotate disc back and forth, and tighten bolts. Torque nuts uniformly in 20 inch-pound increment to 50 TO 70 INCH-POUNDS. If gaps still exist, replace assembly (13).
- **c.** install two bushings (21) into hanger (23) and insert tail rotor driveshaft segment (detail A) in hanger bracket (16) on top of tailboom. Use suitable support to hold aft section of tail rotor driveshaft segment at approximate alignment.

#### NOTE

It is preferred that all hanger bearing clamp hardware will be on the ieft after compliance with MWO 55-1520-228-50/25.

**d.** At fifth hanger (23), install four packings (28), two each side, on forward and aft end of bushing (21).

e. Install two screws (20) with heads forward, through hanger bracket and hanger (23). Install aluminum washers (19) and nuts (17). Torque nuts (17) 30 TO 40 INCH-POUNDS and secure with cotter pins (18).

## **CAUTION**

Beveled washers must be installed with rounded edge side contacting disc assemblies and quantities must be equal to 180 degree positions.

Only the grip portion (unthreaded) of bolts are permitted to contact disc assemblies and bolts lengths must be equal to 180 degree positions.

### **NOTE**

Additional aluminum washers (19) may be used to ensure correct nut and cotter pin engagements. See detail E.

- **f.** Connect tail rotor driveshafts (1,2,3,4,5, and 6) together, and to aft short shaft and slip adapter (7) as follows:
- (1) At each hanger location install two diametrically opposed bolts (15), beveled washers (12a and 14), thin steel washers (11), and nuts (10). Install beveled washers with rounded edge side in contact with disc assembly (13). Torque nuts uniformly in 20 inch-pound increments to 50 TO 70 INCH-POUNDS.
- (2) Inspect all disc assemblies (3) for distortion resulting in gaps between the individual discs. No gaps exceeding **0.005** inch are permitted between discs. If gaps are found, loosen bolts, rotate disc back and forth, and uniformly tighten bolts. Torque nuts uniformity in **20 INCH-POUND** increments to **50 TO 70 INCH-POUNDS**. Recheck gaps. if gaps still exist, replace assembly (13).
- **g.** Check tail rotor driveshaft segments (1,2,3, 4,5, and 6) at hangers (23) to insure they are centered in the brackets within **0.030** inch of the mid-position of the available gap. (See detail E.) if required clearance is not available, add or remove washers from adjoining disc assembly (13) as follows:
- (1) One additional beveled washer (12) and or flat washer (11) may be added with beveled washer at each disc assembly (13) to obtain clearance. Position beveled washers with flat sides back-to-back, install, and torque nuts (10) uniformly in 20 inch-pound increments to **50 TO 70 INCH-POUNDS.** Recheck hanger for required clearances and ensure the preceding caution statements have been observed.

- (2) One beveled washer (12) and/or flat washer (11) may be removed at each disc assembly (13) to obtain clearance. Position beveled washers with rounded edge side contacting disc assembly and torque nuts (10) 50 TO 70 INCH-POUNDS. Recheck hanger for required clearance and ensure the preceding cautions have been observed.
- h. Check slip adapter (7) on input pinion shaft of tail rotor gearbox (8) for a clearance dimension of **0.290 to 0.350** inch. (See detail D.) Dimension is measured from aft end of slip adapter to shoulder on input pinion shaft of tail rotor gearbox. If required clearance is not available. add or remove beveled washer from adjoining disc assembly (13) by the same procedure as described in step g. (1) and g. (2).

Ensure that only spacers (26) measuring 0.545 to 0.550 inch in length from flanged end are used in the six bearing hangers (23). Refer to figure 6-25.

i. Prepare helicopter for ground runup and accomplish hanger bearing centering as follows:

#### WARNING

Insure tail rotor driveshaft covers are closed during ground run operations.

(1) Loosen hanger clamping nuts (27, figure 6-25) until all preload is removed from springs (25) and springs can be turned by hand, then using nonsharp tool in split line of hanger, pry open slightly and move bearing slightly by hand to ensure freedom. Remove tool from hanger.

#### WARNING

Do not grasp tail rotor driveshafts during ground run or rotor coast down.

## **CAUTION**

Do not exceed one minute ground run or bearings may spin excessively in hangers.

- (2) Ground run helicopter at 60 to 62 percent rotor rpm for 45 seconds to 1 minute. Shut down and torque nuts (27) 50 TO 70 INCH-POUNDS. Wipe off any grease from outside of bearings.
- (3) Ground run helicopter for 15 minutes. Shutdown and check, hanger bearings in tail rotor driveshaft segments (1, 2, 3, 4, 5, and 6) for signs of overheating, roughness and turning inside the hanger. If bearings appear rough or are running hot, inspect at frequent intervals until 20 hours of operation have elapsed. If bearing operating temperature has not stabilized after this time, replace bearing.
- **j.** Apply coating to tail rotor driveshaft segments. (Refer to paragraph 6-172.)
- **k.** Apply a coating of corrosion preventive compound (C50) to the following surfaces:
- (1) Seam between outer race of hanger bearing and exposed inside diameter surface of hangers (23).
- (2) Exposed shank of clinch bolt, spring (25), spacer (26), and nut (27) on each hanger (23).

# 6-166. FORWARD AND AFT SHORT SHAFTS.

**6-167. Description** — **Forward and Aft Short Shafts.** The forward short shaft and aft short shaft are located on either side of the oil cooler blower assembly. The forward short shaft is constructed of steel and is connected to the aft end of the freewheeling assembly and forward end of the fan shaft by splined adapters. The aft short shaft is constructed of aluminum alloy and is connected to the aft end of the fan shaft and the first tail rotor driveshaft by a splined adapter.

## 6-168. Inspection and Repair — Forward and Aft Short Shafts.

- **a.** Inspect forward and aft short shafts (3 and 6, figure 6-27) for scratches and damage. Surface of shafts (steel or aluminum) to be smooth and unmarred. Replace shafts which exceed the following limits:
- (1) Scratches up to **0.002** inch deep around entire circumference may be blended out using 400 to 600 grit sandpaper (C126 or C127) or abrasive cloth (C45) or India stone (C84). Maximum stock removal not to exceed **0.003** inch.

- (2) Scratches up to **0.005** inch deep, axial or circumferential, but not longer than **25** percent of circumference may be blended out using 400 to 600 grit sandpaper (C126 or C127) or abrasive cloth (C45) or India stone (C84). Maximum material removal not to exceed **0.006** inch.
- (3) Corrosion pitting must be polished out using 400 to 600 grit sandpaper (C126 or C127) or abrasive cloth (C45). Maximum depth of material removal after cleanup shall not exceed **0.006** inch.
- (4) Any damage or repair to anodized finished surfaces requires repair with chemical conversion coating (C36).
  - **(5)** Touch up coating. (Refer to paragraph 6-172.)
- **b.** Inspect splined adapters (2, 8, and 9) for chips, cracks, and wear. Replace splined adapters which have damaged splines, chips, or cracks.
- **c.** Inspect the coupling disc assemblies (17) for cracks, wear, or damage. Refer to paragraph 6-160. Gaps of more than **0.005** inch are not acceptable. If gaps are found, loosen bolts, rotate discs back and forth, and tighten bolts. Torque nuts uniformly in 20 inch-pound increments to **50 TO 70 INCH-POUNDS.** Recheck gaps. If gaps still exist, replace disc assembly (17).
- **d.** Inspect coupling discs for corrosion. Surface corrosion may be removed with abrasive pad (C154) or steel wool (C155). Corrosion on single disc sections that cannot be removed by this method must be replaced with serviceable disc sections.

The grain of each disc runs parallel to the indexing flat edges. When assembling disc pack assembly, it is necessary to alternate indexing flats to obtain alternate grain direction. Discs should not be changed from original pack except as noted in paragraph 6-160, step g.

**e.** For inspection and repair of blower shaft (4), blower assembly (5), and the bearing hangers refer to paragraph 6-135.

## **WARNING**

Cleaning solvents are flammable and toxic. Use only in well-ventilated ares. Avoid skin contact and inhalation of vapors. Protect eyes with safety glasses.

**6-169.** Cleaning — Forward and Aft Short Shafts. Clean forward and aft short shafts (3 and 6, figure 6-27) with drycleaning solvent (C62) and dry with filtered compressed air. Do not allow solvent to enter hanger bearings.

6-170. Removal — Forward and Aft Short Shafts.

## **CAUTION**

After a disc assembly has bean run on a helicopter, discs should not be changed from original pack except as noted in paragraph 6-160, step g.

- **a.** Remove forward short shaft (3, figure 6-27) or aft short shaft (6) by removing two diametrically opposed bolts (15), beveled washers (16 and 18), washers (19), and nuts (20).
- **b.** Recommend disc assembly (17) be left installed on shafts and removed hardware be loosely reinstalled in disc assembly (17) for reinstallation and to maintain disc stackup, if disc must be removed.

## 6-171. Installation — Forward and Aft Short Shafts.

- **a.** Apply a thin film of grease (C77) to splines on ends of blower shaft (4, figure 6-27) and to internal splines or splined adapters (2, 8, and 9).
- **b.** Position splined adapters (2) on aft end of free-wheeling assembly (1) and splined adapters (8 and 9) on ends of blower shaft (4).

After a disc assembly has been run on a helicopter, discs should not be changed from original pack except as notad in paragraph 6-160, step g.

The grain of each disc runs parallel to the indexing flat edges. When assembling disc pack assembly, it is necessary to obtain alternate grain direction. Discs should not be changed from original pack except as noted in paragraph 6-160, step g.

Beveled washers must be installed with round edge side contacting disc assemblies and quantities must be equal at 180 degree positions.

Only the grip portion (unthreaded) of bolts are permitted to contact disc assemblies and bolt lengths must be equal at 180 degree positions.

- **c.** If removed, install disc assemblies (17) to both ends of forward short shaft (3) and to aft short shaft (6) as follows:
- (1) Ensure all disc assemblies (17) are assembled as shown in detail A, and preceding caution statements.

#### **NOTE**

Bolts (10) may be installed in either direction, for ease of maintenance. Diametrically opposed bolts must be in same direction.

- (2) Position disc assemblies (17) to flanged end of shafts and install two diametrically opposed bolts (10, beveled washers (11 and 12), thin steel washers (13), and nuts (14). Observe preceding caution statements and install the two beveled washers (12) with flat sides back-to-back. Torque nuts (14) uniformly in 20 inch-pound increments to 50 TO 70 INCH-POUNDS.
- d. Carefully position forward short shaft (3) between splined adapters (2 and 9) and aft short shaft (6) between splined adapter (8) and splined adapter on forward end of tail rotor driveshaft segment (7). Connect shafts to adapters as follows:

- (1) Align open bolt holes in disc assemblies (17) to bolt holes in mating splined adapters (2, 8, and 9) and splined adapter on tail rotor driveshaft segment (7).
- (2) Install two diametrically opposed bolts (15), beveled washers (16 and 18), thin steel washers (19), and nuts (20). Observe preceding caution statements and install beveled washers (18) with flat sides back-to-back. Torque nuts (20) uniformly in 20 inch-pound increments to 50 TO 70 INCH-POUNDS.
- (3) Inspect all disc assemblies for distortion resulting in gaps between the individual discs. No gaps exceeding 0.005 inch are permitted between discs. If any gaps are found, loosen bolts, rotate disc back and forth, and tighten bolts. Torque nuts uniformly in 20 inch-pound increments to 50 TO 70 INCH-POUNDS. Recheck gaps. If gaps still exist, replace disc assembly.
- **e.** Apply coating to aft short shaft (6). (Refer to paragraph 6-172.)

6-172. Application of Coating for Corrosion Protection — Tail Rotor Driveshafts.

## **WARNING**

Cleaning solvents are flammable and toxic. Use only in well-ventilated area. Avoid skin contact and inhalation of vapors. Protect eyes with safety glasses.

### **NOTE**

Coating is to be applied to the aft short shaft and to tail rotor driveshaft segment assemblies after installation on helicopters.

- **a.** Thoroughly clean driveshafts to receive coating with a cloth saturated with naphtha (C22). Wipe surface dry with a clean cloth before solvent evaporates.
- **b.** Apply a brush chemical conversion coating alodine (C38) to exposed areas of the driveshaft. Mask all bearings and disc assemblies with masking tape (C143).
- **c.** Mix 1 part of clear acrylic lacquer (C90) to 1.5 to 2 parts acrylic lacquer thinner (C147) and apply in accordance with substep (1) and (2).

- (1) Apply a wet spray coat, holding spray gun close to the surface (approximately 6 to 8 inches). After 15 to 30 minutes drying time, apply a second coat in the same manner as the first coat.
- (2) Apply the lacquer coating quickly over the surface, overlapping the previous strokes, but not reworking the entire coated area. After 30 minutes drying time, apply a second coat in the same manner as the first coat.
- **d.** Curing of the second coat may be accomplished in accordance with substep (1) or (2).
- (1) After second coat is applied full cure can be obtained in maximum drying time of 48 hours at ambient room temperature.
- (2) After second coat is applied, accelerated curing can be accomplished by air drying for 30 minutes, then heat lamp bake at 150°F (66°C) for 2 hours.
  - (3) Remove masking tape.
- **e.** After curing, the coating shall be smooth and uniform over entire surface with no area of shafting uncoated. Coating shall have a dry film thickness of **0.001** to **0.002** inch **(1.000 mil to 2.000 mils)**. Areas found to be uncoated maybe repaired in accordance with step f.

## **WARNING**

Cleaning solvents are flammable and toxic. Use only in well-ventilated area. Avoid skin contact and inhalation of vapors. Protect eyes with safety glasses.

- **f.** Isolated areas of non-adhesion shall be refinished by feathering the isolated areas with 400 to 600 grit sandpaper (C126 or C127) or abrasive cloth (C45). Wipe areas with naphtha (C22) and refinish in accordance with step c.
- **g.** Apply corrosion preventive compound (C50) to seam where hanger bearing outer race contacts hanger. Do not allow corrosion preventive compound to contact bearing seals.

### 6-173. DISC ASSEMBLY.

- **6-174. Description Disc Assembly.** Refer to paragraph 6-120.
- **6-175. Inspection Disc Assembly.** Inspect disc assemblies while installed on tail rotor driveshafts and forward and aft short shafts. Refer to paragraph 6-160.
- **6-176. Cleaning Disc Assemblies.** Refer to paragraph 6-161.
- **6-177. Removal Disc Assemblies.** Refer to paragraphs 6-162 and 6-170.
- **6-178. Installation Disc Assemblies.** Install disc assemblies on tail rotor driveshafts and forward and aft short shafts. Refer to paragraphs 6-165 and 6-171.
- **6-179. Repair Disc Assembly.** No repair is authorized.
- **6-180.** Adjustment and Alignment Tail Rotor Driveshaft. Refer to paragraphs 6-165, tail rotor driveshafts, and 6-171, for forward and aft short shafts.

## SECTION V. INTERMEDIATE GEARBOX

(Not Applicable)

## SECTION VI. TAIL ROTOR GEARBOX

6-181. TAIL ROTOR GEARBOX. (Prior to MWO 55-1520-228-50-25.)

### **NOTE**

Tail rotor gearbox after compliance of MWO 55-1520-228-50-25, refer to paragraph 6-199.

**6-182. Description** — **Tail Rotor Gearbox.** The tail rotor gearbox contains 90 degree spiral bevel gears providing a speed reduction of **2.350 to 1.000.** The bevel gears and mountings are designed to controlled dimensions to provide interchangeable replacement of parts without adjustment. The housing is a magnesium casting attached to the fuselage structure with four studs. A breather type filler cap, electrical chip detector drain plug and oil level sight gage are accessible from ground level. Refer to figure 6-28.

## 6-183. Inspection — Tail Rotor Gearbox.

**a.** Inspect tail rotor gearbox for leaking seals, cracks, security, and metal contamination.

### NOTE

Total static or dynamic leakage for input or output seal must not exceed two drops per minute. Total gearbox leakage at all sources must not exceed six drops per minute.

- **b.** Inspect filler plug (7) for proper locking and security.
  - c. Inspect for defective packing.
- **d.** Inspect tail rotor gearbox oil for evidence of water. When water is present the oil has a dirty milky appearance. If this condition is present or suspected, drain and flush until water contamination is removed, then service gearbox. Refer to paragraph 1-11 for servicing. Condensation on the inside of the sight glass is acceptable, providing that the oil does not have a dirty milky appearance.
- **e.** Inspect sight glass for security, cracks, crazing, or discoloration. If any of these conditions are found, the sight glass will be replaced.

- **f.** Inspect the tail rotor gearbox shaft for excessive movement as follows:
- (1) Total radial piay shall not exceed **0.003** inches on output shaft. Measure by installing a dial indicator one inch outboard of gearbox output seal. Total radial movement of the shaft when moved up and down shall not exceed **0.003** inches at this point. The movement should be performed by applying thumb and index finger to the outboard end of shaft and enough up and down pressure to check the actual looseness. Movement in excess of **0.003** warrants replacement of the tail rotor gearbox.
- (2) Axial movement of the tail rotor gearbox output shaft is not permitted. Replace the gearbox if there is any axial movement of the output shaft.
- (3) Total allowable wobble of the gearbox output shaft is 0.009 inches. Measured by installing a dial indicator 6-1/2 inches outboard of gearbox output seal (just inboard of tail rotor mounting splines).
- (4) Inspect visible area of splines for nicks, dents, scratches, and corrosion. One third of the spline teeth may be corroded or damaged (dented, nicked, or scratched) if damage does not reduce the driving (profile) area by more than 5% and:
- (a) No scratches or other damage deeper than 0.004 inch or longer than 0.250 inch exist.
- **(b)** No three consecutive teeth are damaged.
  - (c) Raised material is smoothed off.
- (d) Use two **0.060** diameter pins to check spline wear, minimum O.D. is to be **1.0873** inch.
- (e) Damage in other areas is not deeper than **0.006** inch or covering not more than **10%** of area.
- **g.** Inspect input pinion (5) refer to paragraph 6-191.

**6-184. Cleaning** — Tail Rotor Gearbox. Clean exterior of the tail rotor gearbox with drycleaning solvent (C62) and wipe with dry clean cloth.

6-185. Removal — Tail Rotor Gearbox.

### NOTE

If tail rotor gearbox is being removed for return to overhaul, preserve the gearbox. Coat splines with corrosion preventive compound (C51) prior to packaging. Refer to TM 38-230.

- **a.** Remove vertical fin. Refer to paragraph 2-267 for removal procedures.
  - **b.** Disconnect electrical lead from chip detector.
- **c.** Remove tail rotor hub and blade assembly (9, figure 6-28). Refer to paragraph 5-183.
- **d.** Remove two opposed bolts to disconnect disc assembly (2) on aft end of long tail rotor driveshaft from splined adapter (4) on gearbox input shaft.
- **e.** Remove tailboom fairing for access to gearbox mounting studs.
- **f.** Remove lower bolt connecting pitch change lever assembly to rod assembly.
- **g.** Remove nuts (10) from gearbox mounting studs at each corner of gearbox.
- **h.** Remove gearbox from tailboom with pitch change mechanism attached.
- i. Check two spacer washers and aluminum angle on tailboom at gearbox mounting point for secure bonding to tailboom. If a washer or washers are loose, retain washer and refer to Chapter 2 for bonding instructions. Inspect the two forward gearbox mounting holes to ensure that a radius block is bonded below each hole.
- **j.** Remove and retain pitch change mechanism for use on new gearbox installation. Disassemble, clean and inspect pitch change mechanism in accordance with paragraph 5-204 prior to installation on new gearbox.

**6-186.** Repair — Tail Rotor Gearbox. Refer to paragraphs 6-188 through 6-198.

#### 6-187. Installation — Tail Rotor Gearbox.

- **a.** Check tail rotor gearbox mounting area on tail-boom to ensure:
- **(1)** Two washers (P/N 206-040-426-1) are bonded in place at rear tail rotor gearbox stud holes.
- (2) Two washers (P/N 140-009-G17H48) are bonded in place at the top forward stud holes on tail-boom serial numbers BCLN-0827 and subsequent. (Washers are not required at top forward stud holes on prior serial numbered tailbooms.)

#### NOTE

It is possible to determine washer location by measuring washer thickness (refer to figure D-48). If washers are not within 0.005 of original thickness, replace them.

Refer to paragraph 2-249, step c. When locally manufacturing washers, use only 5052 aluminum alloy.

(3) Two radius blocks are bonded in place inside tailboom and under forward tail rotor gearbox stud holes.

## **CAUTION**

If the required upper washers or the required radius blocks inside the tail-boom are missing, refer to tailboom repair, paragraph 2-249, step c.

- (4) Before installing a new or overhauled tail rotor gearbox inspect the inside surfaces of the input pinion shaft (5, figure 6-28) for corrosion. Clean and treat corroded areas in accordance with paragraph 6-191. If no corrosion is present, protect the inside surfaces of the pinion gear from corrosion in accordance with paragraph 6-191, step c.
- **b.** Position gearbox on tailboom and check to ensure that gearbox rests evenly on all four points.

#### NOTE

If gearbox dose not rest evenly on all four mounting points of tallboom, refer to paragraph 2-245 for Impaction of teilboom and paragraph 2-249 for repairs it is satisfactory if the mounting points for the tail rotor gearbox are within 0.002 inch of a plane surface. Also, shimming maybe used if required to make gearbox set solid.

- **c.** Apply a thin film of grease (C77) to the mating splines of adapter (4, figure 6-28) and input pinion shaft (5). Install adapter.
- **d.** Install dissimilar metal tape (C138) to surface of bonded washers.
- **e.** Position gearbox on tailboom and connect pitch rod assembly. Secure gearbox with aluminum washer (12), steel washer (11), and nut (10) in that sequence. Torque nut **50 To 70 INCH-POUNDS** plus drag torque. Using lacquer (C92) install slippage mark
  - f. Connect electrical lead to chip detector plug.
- **g.** Install pitch change mechanism. Refer to paragraph 5-214.
- **h.** Install tail rotor assembly. Refer to paragraph 5-188 or 5-189 as applicable.
- i. connect long tail rotor driveshaft to gearbox splined adapter. Refer to paragraph 6-157.
  - j. Install vertical fin. Refer to paragraph 2-269.
- **k.** Install tailboom fairing. Refer to paragraph 2-281.
- I. Drain, flush, and service gearbox. Refer to paragraph 6-183, step d.

6-188. Replacement - Output Seal, Tall Rotor Gearbox.

#### **NOTE**

See paragraph 5-183 for removal of tail rotor hub and blade assembly.

- a. Remove nuts (11, figure 6-31), washers (12 and 13). Remove cap (14) from case and shaft.
  - **b.** Press seal (10) out of cap.
  - c. Press new seal in cap.
- **d.** Replace packing (15) and reinstall cap (14) and secure with nuts (11), and washers (12 and 13).
- **e.** Reinstall hub and blade assembly. Refer to paragraphs 5-188 or 5-190 as applicable.
- 6-189. Replacement Input Seal, Tail Rotor Gearbox.

#### **NOTE**

Input seal may be replaced with gearbox mounted on the tailboom.

**a.** To replace seal with gearbox installed, remove tail rotor driveshaft and fabricate work aid by attaching a metal handle (figure 6-29) to splined adapter (4, figure 6-28) to use instead of clamping splined adapter in vise as directed in step c. and step i. below. Drain tail rotor gearbox oil into suitable container (paragraph 1-11).

### NOTE

Refer to paragraph 6-185 for removal of tall rotor gearbox assembly.




Figure 6-29. Work Aid

- **b.** Use two offset screwdrivers and lift two opposite locking tangs of keywasher (20, figure 6-31) and force washer outboard to free it from nut (21). After washer is freed from nut, slide washer outboard and free from serrations on shaft threads. Replace keywasher (20) with new washer on reassembly.
  - c. Remove input shaft inner nut (21) as follows:
- (1) Clamp splined adapter (4, figure 6-28) in vise and position splined end of input pinion (23) in adapter.
  - (2) Remove nut (21) with spanner wrench.
  - d. Remove seal (22) from input nut (24) as follows:

Do not disturb the torque of input nut (24).

- (1) The primary method for removal of the seal (22) is as follows:
- (a) Install two small self-tapping metal screws in metal housing of seal, 180 degrees apart.
- **(b)** Use two offset screwdrivers under the heads of the screws and lift seal (22) out of the input nut (24).
- (2) The alternate method for removal of the seal (22) is as follows:
  - (a) Fabricate a work aid (figure 6-30).
- **(b)** Install work aid with three self-tapping metal screws in metal housing of seal, approximately 120 degrees apart.
- **(c)** Using puller, battery terminal, (T44), remove seal.
- **e.** Remove and inspect spacer (26), for damage or excessive wear to oil seal surface, replace if required, (maximum allowable depth of wear on oil seal contact surface is **0.002** inch, or to a maximum diameter of **1.496** inch).

- **f.** Replace packing (27) and install serviceable spacer (26). Pre-lubricate packing and spacer with lubricating oil (C103 or C103.1).
- **g.** Before installing seal (22), visually check shaft and nut housing bore finishes for tooling marks, nicks, and scratches. Check entering edge of shaft for proper chamfer and deburring, so as not to cut or bend back lip of seal. Pre-lubricate seal by wiping shaft and lip of seal with lubricating oil (C103 or C103.1).
  - h. Press new seal (22) in place.
- i. Lubricate threads on input pinion gear (23) and install nut (21) on gear with flat side toward seal (22) and the beveled side toward keywasher (20). Clamp splined adapter (4, figure 6-28) in vise and position splined end of input shaft in adapter. Use spanner wrench with torque wrench and torque inner nut (21) to 310 TO 350 INCH-POUNDS.

## CAUTION

## Ensure that serrated keywasher (20) tangs are locked behind nut (21).

- **j.** Position a new serrated keywasher (20) on shaft, then use plastic mallet to force locking tangs of washer over nut (21) with two locking tangs locked behind nut.
- **k.** Service tail rotor gearbox with oil (paragraph 1-11).


## 6-190.Tail Rotor Gearbox Stud Replacement. (AVIM)

- a. Remove tail rotor gearbox. Refer to paragraph 6-185.
- **b.** Remove broken, bent, damaged, or loose studs. Inspect threaded holes n case.

### NOTE

## If stud hole threads are unserviceable, return gearbox for overhaul.

**c.** Clean out small vent hole to bottom of threaded hole. Apply unreduced zinc chromate primer (C118) to threads of replacement studs and install in accordance with table 6-4.



## NOTE

- 1. All dimensions are in inches.
- 2. May be fabricated from aluminum or steel alloy.

206040-502

Figure 6-30. Work Aid




Figure 6-31. Tail Rotor Gearbox Repair

Table 6-4. Stud Replacement Limits

LOCATION	STUD SIZE	STUD HEIGHT	INCH- POUNDS
Mounting Base (4 Studs)	1/4	0.75	50-95
output Port	1/4	0.75	50-95
Pitch Change port (3 Studs)	1/4	0.88	60-95

#### **NOTE**

Stud retaining holes must be tapped to a sufficient depth so that no imperfect threads are engaged. Instaill replacement studs to height shown in table. Stud driving torque must be within limits shown. If driving torque is below the low limit, replace the stud with proper oversize stud so that torque will be within range (see TM 55-1520-228-23P). Undersize and oversize identification is stamped on end of stud. Apply zinc chromate primer to thread studs which will be in contact with ease and install while primer is wet.

## 6-191. Corrsion Treatment for Inside Surfaces of the Input Pinion Gear. (AVIM)

**a.** Remove tail rotor gearbox. Refer to paragraph 6-185.

- **b.** Remove pitting and corrosion inside input pinion gear (23, figure 6-31) by honing or using a wire brush. A maximum of **0.010** inch may be removed from the inside walls for corrosion in concentrated form. Remove an equal amount of material from the opposite wall to eliminate a possible out of balance condition. Feather out all repairs. Replace the gearbox if corrosion removal exceeds limits in figure 6-32.
- **c.** After cleaning, protect the inside surfaces against further corrosion by masking the threaded area and applying epoxy polyamide primer (C116) to all other internal surfaces.

# 6-192. CHIP DETECTORS - TAIL ROTOR GEARBOX.

**6-193. Description** – **Chip Detectors.** The chip detector is the removable center portion of the chip detector and drain plug assembly. It consists of a self-lock bayonet probe with a permanent magnet at the end. When the magnet attracts sufficient metal to complete the circuit between pole and the ground, the T/R CHIP DET segment will illuminate on the caution panel. On installation, torque drain plug **75 to 125 INCH-POUNDS.** 

## 6-194. Removal - Chip Detectors.

**a.** Disconnect the electrical lead from chip detector stud.

206040-504




Figure 6-32. Maximum Internal Corrosion Removal Limits For Tail Rotor Gearbox Input Pinion Gear

Improper and/or rough handling of chip detectors and the electrical connection is the major cause of failure. Use care in removal, installation, and connection of the terminals to avoid false indications in the caution light system.

**b.** Press detector in, turn counterclockwise, and remove from plug.

## 6-195. Inspection - Chip Detectors.

- **a.** Inspect chip detector for stripped or damaged bayonet pins.
- **b.** Check for accumulation of metal particles on magnet. Presence of metal may indicate need for further investigation and corrective action. Compare particles found with metal particle identification list. Refer to paragraph 6-4 and table 6-2.
- **c.** Inspect chip detector electrical connector mounting stud for security.

#### 6-196. Installation - Chip Detectors.

- a. Replace packings on chip detector insert if needed,
- **b.** Position insert in plug, push insert in as far as possible and turn clockwise to lock in place.
  - c. Connect electrical wire to stud.

#### 6-197. Sight Glass Replacement.

- **a.** Remove retainer ring (1, figure 6-31), packing (2), and sight glass (3).
- **b.** Install oil sight gage indicator (25) (oil level line horizontal with notch on bottom securely into notch in gearbox). New packing (2), sight glass (3), and retaining ring (1).

## 6-198. Filler Plug Packing Replacement.

- **a.** Remove cap (6) and oil filter plug (9) as an assembly.
- **b.** Remove packing (8) from plug (9) and install new packing.

# 6-199. TAIL ROTOR GEARBOX. (After compliance with MWO 55-1520-228-50-25.)

**6-200. Description - Tail Rotor Gearbox.** The tail rotor gearbox contains two spiral bevel gears positioned 90 degrees to each other. The direction of drive is changed 90 degrees and there is a speed reduction of 2.350 to 1.000 at the gearbox. The gearbox housing is magnesium and is attached to the tailboom with four studs, nuts, washers, and two dowel pins for alignment. The gearbox assembly includes a breather-type filler cap, oil level sight gage, and a combination electrical chip detector and self-closing valve. The self-closing valve makes it possible to check the electric chip detector for metal particles without draining oil from the gearbox. The self-closing valve also serves as a drain plug for gearbox oil.

## Premaintenance Requirements for Tail Rotor Gearbox

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	(T19) (T37)
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	One
Consumable Materials	(C96) (C143) (C126) (C77) (C127) (C51) (C10) (C19) (C23) (C17) (C39) (C43) (C45) (C62) (C80) (C88) (C103) (C103.1) (C107) (C116) (C118) (C129) (C32) (C154)
Special Environmental Conditions	None

## 6-201. Inspection - Tail Rotor Gearbox.

**a.** Inspect tail rotor gearbox (1, figure 6-33) for leaking seals, cracks, security, and damage.




Figure 6-33. Tail Rotor Gearbox External Components

#### NOTE

Total static or dynamic leakage for input or output seal must not exceed two drops per minute. Total gearbox leakage at all sources must not exceed six drops per minute.

**b.** Inspect electric chip detector (15) for metal particles and self-closing valve (13) for leakage. (Refer to paragraph 6-220.)

#### NOTE

Placing a small amount of sealant, NSN 8040-01-252-8567, over the lock ring on top of the tail rotor gearbox cap assy will help prevent water contamination of the gearbox and does not affect the venting ability of the cap.

- **c.** Inspect tail rotor gearbox oil for evidence of water. When water is present, the oil will have a dirty, milky appearance. If this condition is present or suspected, drain, flush, and service tail rotor gearbox (1). (Refer to paragraph 1-11.)
- **d.** Inspect cap assembly (21, detail A) for positive locking and cleanliness.
- **e.** Inspect sight glass (18) and oil level indicator(19) for leakage, cracks, and crazing. Sight glass (18) and oil level indicator (19) are considered serviceable if oil level and oil condition can be verified.
- f. Inspect exterior of output cap assembly (6, figure 6-34) and gearbox case (1) for mechanical and corrosion damage. Damage which does not exceed **0.015** inch may be blended out using sandpaper (C126 or C127) or abrasive cloth (C45). Touch up repaired areas with two coats of epoxy polyamide primer (C116). For damage that exceeds **0.015** inch refer to higher level of maintenance.
- **g.** When tail rotor gearbox is removed, inspect mounting area on tailboom to ensure that the four laminated shims are bonded in place where tail rotor gearbox lugs rest on surface of support. (See figure 6-35.)
- (1) Position tail rotor gearbox on tailboom and check that gearbox rests evenly on all four shims (figure 6-35).
- (2) Inspect dowel pin holes on tailboom for elongation and dowel pins on-tail rotor gearbox for condition.

Wear shall not exceed 0.005" for the tail rotor gearbox mounting holes and 0.001" for the dowel pin holes.

- **h.** Inspect output shaft (2, figure 6-34) for out-of-round condition by installing a dial indicator just out-board of splines. If maximum total indicator reading (TIR) is **0.005** inch, overhaul gearbox.
- i. Inspect output shaft (2) for excessive play. The maximum radial play allowable is 0.003 inch measured 1.000 inch outboard of seal (8). No axial movement is permitted. If axial play is noted or radical play exceeds 0.003 inch, overhaul gearbox. Refer to paragraph 6-183.
- **j.** Inspect visible surfaces of output shaft (2) and pinion gear (12) for corrosion and pitting.

6-202. Cleaning — Tail Rotor Gearbox.

## **WARNING**

Cleaning solvents are flammable and toxic. Use only in well-ventilated area. Avoid skin contact and inhalation of vapors. Protect eyea with safety glasses.


- **a.** Clean exterior of tail rotor gearbox with drycleaning solvent (C62). Dry with filtered compressed air. Do not allow solvent to contact seals or rod end bearings.
- **b.** Remove filler cap (21, figure 6-33) and rinse in drycleaning solvent (C62). Dry with filtered compressed air.

6-203. Removal — Tail Rotor Gearbox.

#### NOTE

If tail rotor gearbox is being removed for return to overhaul, preserve the gearbox. Coat splines with corrosion preventive compound (C51) prior to packing. Refer to TB 55-9150-200-24.

- a. Remove vertical fin (paragraph 2-269).
- **b.** Disconnect electrical lead from chip detector(15, figure 6-33).
- **c.** Remove tail rotor hub and blade assembly (9, figure 6-36). (Refer to paragraph 5-229.)



- 1. Gearbox Case
- 2. Output Shaft
- 3. Retaining Ring
- 4. Bearing
- 5. Packing
- 6. Cap Assembly
- 7. Sleeve
- 8. Seal
- 9. Nut
- 10. Thin Steel Washer

- 11. Aluminum Washer
- 12. Input Pinion Shaft
- 13. Packing
- 14. Input Shaft Nut
- 15. Seal
- 16. Locknut
- 17. Lockwasher
- 18. Slip Adapter
- 19. Spacer


## NOTE



Parts shown disassembled for clarity only. These parts are removed at depot level only.

206040-506

Figure 6-34. Tail Rotor Gearbox Seal Replacement



NOTE: Four laminated shim washers to be in same plane within 0.002 inch and parallel within 0.001 Inch across their diameters.

206040-507\*

Figure 6-35. Tail Rotor Gearbox Mounting (After Incorporation of MWO 55-1520-228-50-25)

## CAUTION

After a disc assembly has been run on a helicopter, discs should not be changed from original pack except as noted in paragraph 6-160, step g.

- **d.** Remove two diametrically opposed bolts (19), beveied washers (18 and 16), thin steei washers (15), and nut (14). Leave disc assembly (17) attached to tail rotor driveshaft segment (20).
- **e.** Disconnect pitch change control rod (22) (see detail A), from antitorque control system. (Refer to paragraph 5-208.)
- f. Drain tail rotor gearbox (8). Remove chip detector (15, figure 6-33) and self-closing valve (13). Remove and discard packings (12 and 14).
- **g.** Remove nuts (10, figure 6-36) and steel washers (11 and 12) from four studs.


### **NOTE**

Laminated shims are not used on tailboom P/N 206-032-004-105 and are not recorded on data plate. The tail rotor gearbox is installed using only the tape between gearbox and tailboom mount. All other procedures are the same.

- h. Remove tail rotor gearbox (8) from tailboom. Check security of four laminated shims (2, figure 6-35) on tailboom which form the mounting surface for tail rotor gearbox. If a laminated shim is missing, obtain correct shim thickness from tailboom data piate. Prepare a new shim to the required thickness and bond in place with adhesive (C19). Ensure shim surfaces meet requirements of figure 6-35.
- i. Remove and store filler cap (8, figure 6-33). install dehydrator (T37).

## **NOTE**

An appropriate entry shall be made upon installation of dehydrator (T37).



NOTE: All dimensions are in inches.

206040-508

Figure 6-36. Tail Rotor Gearbox (After Incorporation of MWO 55-1520-228-50-25)

- **j.** Remove and retain pitch change mechanism for new gearbox installation. Disassemble, clean and inspect pitch change mechanism in accordance with paragraph 5-204 prior to installation on new gearbox.
- **6-204. Repair Tail Rotor Gearbox.** (Refer to paragraphs 6-207 through 6-224.)
- 6-205. Installation Tail Rotor Gearbox.

### NOTE

Laminated shims are not used on tailboom P/N 206-032-004-105 and are not recorded on data plate. The tail rotor gearbox is installed using only the tape between gearbox and tailboom mount. All other procedures are the same.

- **a.** Check that four laminated shims are bonded in place where tail rotor gearbox mounts on tailboom. (Figure 6-35 and paragraph 6-203, step h.)
- **b.** Clean surfaces of bonded shims on tailboom with drycleaning solvent (C62). Install vinyl tape (3, figure 6-35) to upper surface of the four laminated shims. Touch up bare metal surfaces with epoxy polyamide primer (C116).
- (1) Before installing a new or overhauled tail rotor gearbox inspect the inside surfaces of the input pinion shaft (13) for corrosion.
- (2) Clean and treat corroded areas in accordance with paragraph 6-191.c.

## **CAUTION**

On certain tailbooms there maybe manufacturing variances which will not allow the required two threads showing after nut (10 and steel washers (11 and 12) have been installed. Two threads must be showing, if not attainable, reduce the steel washer to one AN960-416 or a minimum to one AN960-416L.

**c.** Position tail rotor gearbox (8, figure 6-36) on tailboom aligning dowel pins with holes in tailboom. Install steel washers (1 and 12) and new nuts (10) on

- each stud. Torque nuts (10) 50 to 70 inch-pounds plus drag torque. Use paint (C92), install slippage mark.
- **d.** Apply a coating of grease (C77) to splines of input pinion shaft (13), and to splines of slip adapter (6). Position slip adapter (6) on input pinion shaft (13).
- **e.** Install pitch change levers (7), idler assembly (21), and pitch change control rod (22), if removed. (Refer to paragraph 5-214.)
- **f.** Apply a bead of sealant (C17) to exposed mating edge surfaces of tail rotor gearbox (8) and tailboom.
- **g.** Connect pitch change control rod (22), see detail A, to antitorque control system. (Refer to paragraph 5-214.)
- **h.** Connect sixth tail rotor driveshaft segment (20) and slip adapter (6). (Refer to paragraph 6-165.)
- i. Install tail rotor hub and blade assembly (9). (refer to paragraph 5-226.)
- **j.** Remove dehydrator (T37). Attach cap (8, figure 6-33) to tail rotor gearbox with pin (9), safety chain (10), and pin (11).
- k. Install self-closing valve (13) and chip detector (15). (Refer to paragraph 6-221.)
- **I.** Rig antitorque control system. (Refer to paragraph 11-101.)
- m. Service tail rotor gearbox (8) to correct level. (Refer to paragraph 1-11.)
  - n. Install vertical fin. (Refer to paragraph 2-269.)
- **o.** If a new or overhauled tail rotor gearbox (8) has been installed, perform run-in checks and inspection in accordance with paragraph 6-206.
- 6-206. Operational Check Tail Rotor Gearbox.

#### NOTE

Perform this operational check after each tail rotor gearbox installation.

a. Perform ground run-in cycle for 20 minutes.

- **b.** After shutdown accomplish the following requirements:
- (1) Remove and inspect electric chip detector for metal particles. if metal particles are found investigate to determine cause. (Refer to table 6-1.)
- (2) Visually inspect oil at sight gate for discoloration and contamination.
  - (2) Inspect tail rotor gearbox for oil leaks.

## 6-207. Replacement - Tail Rotor Gearbox output seal.

- 6-208. Removal Tail Rotor Gearbox Output Seal.
- **a.** Remove rail rotor hub and blade assembly. (Refer to paragraph 5-229.)
- **b.** Drain lubricating oil from tail rotor gearbox. (Refer to paragraph 1-11.)

- **c.** Remove nuts (9, figure 6-34) and thin steel washers (10) and aluminum washers (11) from studs on gearbox case (1). Remove cap assembly (6) from gearbox case (1) and output shaft (2).
- **d.** Remove and discard packing (5) and press seal (8) from cap assembly (6). It is not necessary to remove retaining ring (3) and bearing (4) unless interference may result when pressing out seal (8). If bearing (4) must be removed, replace cap assembly (6).

## 6-209. Inspection and Repair - Tail Rotor Gearbox Output Seal.

- **a.** Inspect all visible parts of output shaft (2, figure 6-34) and attaching gear for damage.
- **b.** Inspect sleeve (7) on output shaft (2) for wear in area contacted by seal (8). If sleeve has groove greater than **0.002** inch tail gearbox (8, figure 6-36) must be replaced. Also, if nicks, dents, or scratches are present, or evidence of oil leakage is noted, tail rotor gearbox (8) must be replaced.
- **c.** Inspect gearbox case (1, figure 6-34) and cap assembly (6) for wear, damage, and corrosion. If studs are loose or damaged, replace studs in accordance with paragraph 6-215.
- **d.** Inspect bearing (4, figure 6-34) for freedom of movement and flat spots. If bearing is binding or has flat spots replace cap assembly.

## 6-210. Installation - Tail Rotor Gearbox Output Seal.

- **a.** Apply a film of sealant (C129) to outside diameter of new seal (8, figure 6-34) and mating surface of cap assembly (6). Press seal into cap assembly (6) with lip of seal outboard. (See view A.) Seat seal flush in cap assembly (6). Trim excess sealing compound from seal (8) and cap assembly (6) with a plastic scraper.
- **b.** Install new packing (5) in groove on inboard side of cap assembly (6). Lubricate packing (5) with lubricating oil (C103). Fill cavity between lips of seal (8) with grease (C80).
- **c.** Position cap assembly (6) with seal (8), bearing (4), and retainer ring (3) on output shaft (2). Seat cap assembly (6) to gearbox case (1) using extreme caution not to damage new seal. Secure cap assembly to gear-

box case with aluminum washers (11), thin steel washers (10), and nuts (9). Torque must (9) **50 TO 70 INCH-POUNDS.** 

- **d.** Apply a bead of adhesive (C10) to outer diameter of mating surface area of gearbox case (1) and cap assembly (6).
  - e. Service tail rotor gearbox with lubricating oil (C103).
- **f.** Install tail rotor hub and blade assembly. (Refer to paragraph 5-236.)
- **g.** Inspect for oil leaks on first ground runup. (Refer to paragraph 6-201.)
- 6-211 Replacement Tail Rotor Gearbox Input Seal.
- 6-212. Removal Tail Rotor Gearbox Input Seal.
  - a. Drain lubricating oil from tail rotor gearbox.
- **b.** Remove sixth tail rotor driveshaft segment and slip adapter (18, figure 6-34) from tail rotor gearbox. (Refer to paragraph 6-162.)
- **c.** Use two offset screwdrivers and lift two opposite locking tangs of lockwasher (17) and force lockwasher outboard to free it from locknut (16). After lockwasher is freed from nut, slide lockwasher outboard and free from serrations on threads of pinion gear (12). Discard lockwasher.
- **d.** Position spline wrench (T19) on splines of pinion gear (12), insert a 1/2 inch square drive breaker bar into opening in spline wrench to hole pinion gear while removing locknut (16) with a spanner wrench. If tail rotor gearbox is removed clamp splined wrench in a vise for security when removing locknut (16).

## **CAUTION**

Do not disturb the torque of input shaft nut (14).

**e.** Drill two small holes in face of seal (15) 180 degrees part and install two self-tapping screws. Using two offset screwdrivers pry seal out of input shaft nut (14) and discard.

# 6-213. Inspection - Tail Rotor Gearbox Input Seal.

- **a.** Inspect all visible parts of pinion gear (12, figure 6-34).
- **b.** Inspect spacer (19) for wear in area of contact with seal (15). If wear is evident through cadmium plating or nicks and scratches are present replace spacer.
- **c.** Inspect spline teeth and threads on pinion gear for damage. Dress spline teeth and threads with fine India stone.

# 6-214. Installation - Tail Rotor Gearbox Input Seal.

- **a.** Fill cavity between lips of new seal (15, figure 6-34) and apply a film to outside diameter of spacer (19) with grease (C80).
- **b.** Apply a film of sealant (C129) to outside diameter of new seal (15) and mating surface of input shaft nut (14). Press seal (15) into input shaft nut (14) with lip of seal outboard. (See view A.) Seat seal flush in input shaft nut using extreme caution not to damage seal. Trim excess sealing compound from edge of seal and nut with a plastic scraper.
- c. Thread locknut (16) onto pinion gear (12) with tangs outboard. Position spline wrench (T19) on splines of pinion gear (12) with a 1/2-inch square drive breaker bar installed. Hold pinion gear (12) secure with tools and torque locknut (16) 360 TO 400 INCH-POUNDS.
- **d.** Position a new lockwasher (17) on pinion gear (12) and using a plastic mallet force locking tangs over locknut (16) with two locking tangs locked behind locknut (16).
- **e.** Service tail rotor gearbox with lubricating oil (C103).
- **f.** Install sixth tail rotor driveshaft segment and slip adapter (18). (Refer to paragraph 6-165.)
- **g.** Inspect for oil leaks on first ground runup. (Refer to paragraph 6-201,)

# 6-215. Stud Replacement - Tail Rotor Gearbox. (AVIM)

- **a.** Remove tail rotor gearbox, (Refer to paragraph 6-203.)
- **b.** Remove damaged or loose studs (1 and 2, figure 6-37) and dowel pin (3) in case assembly (4) as follows:

#### NOTE

# If stud hole threads are unserviceable, return gearbox for overhaul,


**c.** Clean out small vent hole in bottom of stud or dowel pin holes, as required. Apply unreduced zinc chromate primer (C118) to threads of replacement studs or shank of dowel pin and install to the depth as shown in figure 6-37. Torque studs (1 and 2) in accordance with table 6-5.

Table 6-5. Stud Replacement Limits

LOCATION	STUD SIZE	STUD HEIGHT	INCH- POUNDS
Mounting Base (4 Studs)	1/4	0.75	50-95
Output Port	1/4	0.75	50-95
Pitch Change Port (3 Studs)	1/4	0.88	50-95

#### **NOTE**

Stud retaining holes must be tapped to a sufficient depth so that no imperfect threads are engaged. Install replacement studs to height shown in table 6-5. Stud driving torque must be within limits shown. If torque is below the low limit torque, replace the stud with proper oversize stud so that torque will be within range (TM 55-1520-228-23P). Undersize and oversize identification is stamped on end of stud. Apply zinc chromate primer (C118) to stud threads which will be in contact with case and install while primer is wet.



- 1. Stud AN125999 thru AN126002 oversize AN126003 thru AN126004
- 2. Stud AN126011 thru AN126014 oversize AN126015 thru AN126016
- 3. Pin Dowel NAS607-4-7P oversize NAS607-5-7P
- 4. Case Assembly

NOTES: 1 Set studs and pin with unreduced primer (C118).

Use of oversize dowel pin will require that exposed portion be machined to a diameter of 0.250 inch to match tailboom assembly.

3 All dimensions are in inches.

206040-509

Figure 6-37. Tail Rotor Gearbox Stud Replacement

- d. In the event an oversized dowel pin is required for replacement, use NAS607-5-7P dowel pin and machine the length to be exposed (0.360 to 0.390 inch) to a diameter of 0.025 inch. Rework case assembly dowel pin holes to a diameter of 0.311 to 0.312 inch and a depth of 0.500 to 0.530 inch. Remove drill filings and clean vent holes to ensure they are clear. Clean lower part of case assembly (4) and apply magnesium touchup to reworked areas, (Refer to paragraph 6-21 6.)
- **e.** Install new machined dowel pin (3). Refer to step c.

# 6-216. Corrosion Removal and Repair - Tail Rotor Gearbox. (AVIM)

#### NOTE

Removal of corrosion products is mandatory prior to subsequent repair of corrosion protective treatment.

**a.** The use of the magnesium touchup treatment is restricted to parts and assemblies that have small areas of the bichromate coating removed by scratches, abrasions, or minor rework, Parts or assemblies that require touchup shall be treated as follows:

# WARNING

Cleaning solvents are flammable and toxic. Use only in well-ventilated area. Avoid skin contact and inhalation of vapors. Protect eyes with safety glasses.

- (1) Remove oil and grease with drycleaning solvent (C62) or MEK (C107).
- **(2)** Masking tape (C143) should be used, as required, to prevent touchup solution from running into areas where it is not needed.
- (3) Scrub the area to be treated with fine abrasive pads (C154), or fine aluminum wool (C23), Abrade to clean bare metal. Fresh machined surfaces may be treated without abrading.
- (4) Flush areas with cleaning compound (C43) mix 4 ounces per galion of water, as required, to ensure a waterbreak free surface.
- **(5)** Rinse with clean water and repeat steps (3) and (4) as required, to provide a clean surface,

**b.** Prepare magnesium touchup treatment solution by mixing 1.3 ounce chromic acid (C39), and 1 ounce calcium sulfate (C32) per gallon of water.

#### NOTE

The calcium sulfate will not go into solution.

- (1) Apply touchup solution with a brush or swab to repaired areas. Allow solution to react for at least 1 minute, reapply solution, as required, to keep the area wet. Excess solution should be clearly marked, dated, and stored at room temperature in a glass jar. Do not store touchup solution where temperatures may vary to extremes, or in contact with direct sunlight. Do not use a touchup solution older than 3 months from date of mixing.
- (2) Rinse thoroughly with clean water to remove excess solution. The treatment should produce a brassy colored film; if required, repeat application of touchup solution until a brassy colored film is obtained. Rinse, demask and rinse again to ensure solution removal. All rinsing shall be accomplished using room temperature water.
- (3) Dry with filtered compressed air and dry cloths.
- (4) Parts that require painting as the next operation shall be painted as soon as practicable, after drying, preferably within 24 hours. Apply one coat of epoxy polyamide primer (C116) to bare areas and top finish with acrylic lacquer (C88).

# 6-217. CHIP DETECTORS - TAIL ROTOR GEARBOX.

**6-218.** Description — Chip Detector Assembly. One electric chip detector assembly is installed in the tail rotor gearbox. The electric chip detector assembly is made up of one self-closing valve and an electric chip detector.

The electric chip detector consists of a self-locking bayonet probe with a permanent magnet at the end. Free ferrous metal particles in the oil will be attracted to the magnet and when sufficient metal is attracted to complete the circuit between pole and around, the T/R CHIP DET segment on the caution-panel will illuminate.

The self-closing valve automatically closes and prevents loss of oil when the electric chip detector is removed for inspection. The self-closing valve also serves as a drain plug.

### 6-219. Removal - Chip Detector Assembly.

**a.** Disconnect electrical lead from electric chip detector (15, figure 6-33).

# CAUTION

Rough handling of chip detectors and the electrical connector is the major cause of failure and of false indications in the caution light system.

- **b.** Press chip detector (15) in toward tail rotor gearbox (1), turn counterclockwise and remove from self-closing valve (13). Inspect chip detector (15) immediately for metal particles. If any particles are found, place in a clean container and retain until inspection is completed.
- c. Inspect self-closing valve (13) for leakage while still installed in tail rotor gearbox (1) but after electric chip detector (15) is removed. If leakage is found, remove self-closing valve (paragraph 6-203).
- **d.** When it is necessary to drain oil from the gearbox for any reason, refer to paragraph 6-203, step f.

#### 6-220. Inspection - Chip Detector Assembly.

- **a.** Inspect chip detector (15, figure 6-33) immediately on removal from tail rotor gearbox (1). If any particles are found, make further investigation as outlined in paragraph 6-4 and table 6-2.
  - b. Remove and discard packings (14).
- **c.** Clean chip detector (15) and self-closing valve (13) (if removed) with drycleaning solvent (C62).
- **d.** Inspect chip detector (15) for stripped or damaged bayonet pins. Inspect self-closing valve (13) for damaged threads.

- **e.** Functional check T/R CHIP DET segment electrical circuit as follows:
- (1) Turn BAT switch to BAT. Position CAUTION/RESET/TEST switch to TEST and release. All caution segments should illuminate.
- (2) Short across probe on electrical chip detector (15) to tail rotor gearbox case. Observe that T/R CHIP DET segment illuminates.

### 6-221. Installation - Chip Detector Assembly.

- **a.** Lubricate new packings (12 and 14, figure 6-33) with lubricating oil (C103).
- **b.** Position new packing (12) on self-closing valve (13) and install in tail rotor gearbox (1). Torque self-closing valve **75 TO 126 INCH-POUNDS.** Secure self-closing valve to case of tail rotor gearbox with **0.032** inch lockwire (C96).
- **c.** Position new packing (14) on chip detector (15) and insert into self-closing valve (13). Turn clockwise to lock in place. Attach electrical leads terminal to chip detector (15).
- **d.** Fill the tail rotor gearbox (1) to proper level with lubricating oil (C103). Check for oil leaks on first ground run.

# 6-222. Sight Glass Replacement - Tail Rotor Gearbox.

- **a.** Remove retainer ring (16, figure 6-33), packing (17), and sight glass (18).
- **b.** Install new packing (17), sight glass (18), and retainer ring (16).

# 6-223. CAP ASSEMBLY - TAIL ROTOR GEARBOX.

# 6-224. Replacement of Aluminum Wool - Tail Rotor Gearbox Cap Assembly.

- **a.** Remove cap assembly (21, figure 6-33, detail A) from tail rotor gearbox (1) by unlocking pin (11) from gearbox and safety chain (10).
- **b.** Remove retaining ring (2), washer (3), and old aluminum wool (20), from inside plug (4).

- c. Clean cap with drycleaning solvent (C62) and inspect all parts for damage which would affect function, Replace faulty parts or entire cap assembly,
- **d.** Install new aluminum wool (20) (C23) in plug (4), The correct amount of aluminum wool is in place

when washer (3) can be pressed down toward the wool **0.060** inch from its normal installed position and will spring back to the original position, When correct amount of aluminum wool is in place, install retaining ring (2) to hold washer (3) in place,

#### SECTION VII. OIL SYSTEM

### 6-225. TRANSMISSION OIL SYSTEM.

6-226. Description - Transmission Oil System. The transmission lubrication system, (figure 6-38) includes a pump, relief valve, filter, spray jets, and an oil cooler. The pump is a constant volume type driven by the accessory gear. An oil level sight gage is located on the right side of the transmission case, A breather type filler cap and two electrical magnetic chip detectors and drain plugs are incorporated, The transmission also furnishes lubrication for the freewheeling assembly mounted in the engine accessory gear case. A pressure line and a return oil line pass through the forward bulkhead to connect the transmission and freewheeling assembly. A law pressure switch is connected to a warning light on the instrument panel.

# 6-226.1. TRANSMISSION OIL LEVEL INDICATOR. Refer to Figure 6-40.

**6-226.2. Description - Transmission Oil Level Indicator.** The transmission oil level indicator is located an the Right side of the transmission case. The oil level indicator consists of a round metal disc with a white epoxy coating an one side of the disc. Holes are drilled around the disc to allow oil to pass through the indicator and thus indicate the level of fluid in the transmission.

The Sight Glass itself is fabricated from an acrylic material. Through time it is possible for the sight glass to become crazed, scratched, or discolored and give an erroneous reading.

# 6-226.3. Inspection - Transmission Oil Level Indicator.

**a.** Inspect sight glass for condition; replace sight glass if discolored or if it prevents a clear indication of correct oil level.

- **b.** Inspect oil level indicator to assure the epoxy facing material is securely bonded to the disc. Replace the indicator if the facing material is unhanded, or if the facing is discolored.
- **c.** Inspect oil level indicator to assure all the holes in the indicator are free to allow the transmission fluid to pass through the disc.

# CAUTION

It is possible for a (unauthorized) rework oil level indicator to trap fluid inside the sight glass and provide a false reading.

**d.** Whenever servicing the transmission fluid, to include transmission fluid change, verify the transmission oil level indicator is operative (fluid can pass freely through the indicator, both into and out of the assembly).

#### 6-227. TRANSMISSION OIL PUMP.

**6-228. Description - Transmission Oil Pump.** A constant delivery pressure transmission oil pump (61, figure 6-40) is flush mounted on the forward side of the transmission main case and is driven by the accessory bevel gear. The outboard end of the oil pump has an accessory drive pad for mounting the rotor rpm tachometer and, through it, the flight control hydraulic pump.

**6-229.** Inspection - Transmission Oil Pump. Inspect ail pump mounting area for oil leaks and hold down nuts for security.

### 6-230. Removal - Transmission Oil Pump.

- **a.** Remove hydraulic pump and tachometer generator as a unit from transmission oil pump flange.
  - b. Apply heat, using lamp, to transmission case.
- **c.** Pull transmission oil pump (61, figure 6-40) from transmission using flange puller as shown in figure 6-39.
- **d.** Remove packing (62, figure 6-40) from oil pump.

### 6-231. Installation - Transmission Oil Pump,

- **a.** Install new packing (62, figure 6-40) on oil pump (61).
- **b.** Lubricate packing and spline teeth of pump driveshaft with oil (C103).
  - c. Apply heat lamp to transmission case.

- d. Install oil pump (61).
- **e.** Reinstall hydraulic pump and tachometer generator on transmission oil pump flange.
- f. Apply sealing compound (C131) between outer edge of pump flange and mating area on transmission. When sealant is dry, trim excess material with sharpened plastic scraper.

### 6-232. OIL FILTER HEAD ASSEMBLY.

**6-233. Description - Oil** Filter Head Assembly. The transmission is provided with an oil filter head assembly (49, figure 6-40) mounted on the left side of the transmission with an inlet to the assembly through an internal passage sealed with a gasket (56). Provisions are made for incorporation of a filter bypass valve (50), a temperature switch (54), and an oil filter assembly (47).





Figure 6-38. Transmission Oil System Schematic



- Puller
   Nut
- 3. Puller, Slide Hammer

206040-511

Figure 6-39. Flange Puller




Figure 6-40. Transmission External Components (Sheet 1 of 3)




Figure 6-40. Transmission Components (Sheet 2)

- 31. Packing 52. Packing 32. Packing 53. Bolt Valve Retainer 33. Packing 54. Switch 34. Packing 55. Packing 35. Nozzle Oii Transmission (No. 2) 56. Gasket Filter Head 36. Packing 57. Washer Flat 37. Screw Machine 58. Waaher Fiat 38. Screw Machine 59. Nut Self-locking Extended 39. Screw Machine 60. Spacer Sleeve 40. Packing 61. Pump Assembly Lubricating 41. Nozzle Oil Transmission (No. 1) 62. Packing 42. Packing 63. Plua 43. Packing 64. Packing 44. Packing 65. Retainer 45. Packing 66. Glass 46. Screw Machine 67. Packing 47. Filter Assembly 68. Indicator 46. Clamp Assembly 69. Packing 49. Head 70. Chip detector 50. Valve Bypass

Figure 6-40. Transmission External Components (Sheet 3)

6-234. Removal — Oil Filter Head Assembly. Remove oil line to the oil cooler and disconnect electrical

51. Spring Bypass Valve

wiring. Remove three nuts (59) and washers (57 and 58) attaching assembly to transmission case. Remove oil filter head assembly (49).

### 6-235. Inspection — Oil Filter Head Assembly.

Inspect for cracks, damage, and oil leakage after installation.

**6-236.** Installation — Oil Filter Head Assembly. Install new gasket (56) on studs and position oil filter head assembly (49) in place. Secure with nuts (59) and washers (57 and 58) and connect electrical wiring and cooler oil line.

#### 6-237. FILTER BYPASS VALVE.

**6-238. Description** — **Filter Bypass Valve.** The filter bypass valve (50, figure 6-40) is mounted in the filter head assembly and bypasses the filter during high oil pressure operation.

**6-239.** Removal — Filter Bypass Valve. Loosen valve retainer bolt (53, figure 6-40) and remove boit (53), packing (52), valve spring (51), and valve (50) from filter head assembly (49).

**6-240. Inspection** — **Filter Bypass Valve.** Visually inspect valve (50, figure 6-40) for evidence of wear and

damage. Inspect spring (51) for free length of 2.780 inches.

206040-512-3

**6-241.** Installation — Filter Bypass Valve. Position packing (52, figure 6-40) on retainer bolt (53). Insert vaive (50) and spring (51) in filter head assembly (49). Install retainer bolt (53).

# 6-242. TRANSMISSION OIL PRESSURE TRANSMITTER. C Refer to paragraph 8-275.

# 6-243. TRANSMISSION OIL TEMPERATURE SWITCH.

**6-244. Description** — **Transmission Oii Temperature** Switch. The transmission oil temperature switch (54, figure 6-40) is mounted on the filter head assembly (49) and senses a high temperature of filter inlet oil. This gives an indication in cockpit by lighting a warning light (XMSN OIL HOT) on instrument panel.

**6-245. Removal** — **Transmission Oil Temperature** Switch. Unscrew and remove the transmission oil temperature switch (54) and packing (55) from filter head assembly (49).

**6-246.** Inspection — Transmission Oil Temperature Switch. Inspect for broken or loose terminal, evidence of leakage and visible damage

#### **CAUTION**

Do not apply more than 6 INCH-POUNDS torque to terminal stud, nor more than 25 INCH-POUNDS torque to hex head of temperature switch.

When performing next step, position thumb-screw of clamp (48) in the vertical position to prevent damage to the transmission deck.

**6-247.** Installation Transmission Oil Temperature **Switch.** Install packing (55, figure 6-40) on temperature switch (54), insert switch in filter head assembly and tighten.

6-248. FILTER.

- **6-249. Description Filter**. The filter assembly (47, figure 6-40) is installed on the oil filter head assembly (49) by screwing on and clamping in place.
  - **6-250.** Removal Filter. Remove clamp (48, figure 6-40) around filter seat and turn filter cartridge from filter head assembly.
  - **6-251. Inspection Filter**. No inspection required. Inspect clamp for serviceability and obvious damage.
  - **6-252. Installation Filter.** Wipe light film of oil (C103) on seal of new filter, screw filter (47, figure 6-40) into place, hand tight, and safety with clamp (48). Tighten clamp by thumbscrew until clamp will not rotate. Safety wire on thumbscrew is not essential.
  - 6-252.1. 3-MICRON OIL FILTER (After Compliance with MWO 1-1520-228-50-51).
  - **6-252.2. Description 3-Micron Transmission External Oil Filter** (After compliance with MWO 11520-228-50-51, reference figure 6-40.1 and 6-40.2). The external oil filter is installed on the left side of the flight control servos mounted on the roof. The in-line oil filter consists of a 3-micron filter element, oil bypass indicator and bypass valve. When the filter element becomes clogged, it will give a warning by extending the oil bypass (red) indicator. The indicator extends when a set differential pressure across the filter is exceeded. When in the reset position, the indicator will be hidden from view.

Premaintenance Requirements for 3-Micron Transmission External Oil Filter

Condition	Requirements	
Model	OH-58A/C	
Part No. or Serial No.	All	
Special Tools	None	
Test Equipment	None	
Support Equipment	None	
Minimum Personnel Required	One	
Consumable Materials	(62) (C96) (C103) (C119.1)	
Special Environmental	Clean, Dust Free Area	

#### 6-252.3. Inspection - 3-Micron Filter.

- a. Check for extended oil bypass (red) indicator. If indicator is extended, it can be reset by pressing in.
- *b.* If filter bypass indicator (red button) is showing, reset indicator, ground run transmission and reinspect.

If indicator is not showing after ground run, the aircraft may be released for operation. If indicator is showing after ground run, change transmission oil and replace filter element.

c. If filter bypass indicator is showing on any two consecutive preflight inspections, change transmission oil and replace filter elements.

### **CAUTION**

Protective covers shall be used to cover all open ports and lines to prevent contamination by entry of foreign material.

### 6-252.4. Removal - 3-Micron Oil Filter Element.

a. Remove the transmission cowling. Place suitable container under the filter element bowl, cut lockwire, and remove filter bowl (1) from filter head (2) (figure 6-40.3).

- b. Remove filter element (3) from filter head (2). Discard filter element (3).
- c. Remove packing (4) from filter bowl (1). Discard packing (4).

#### WARNING

Dry-cleaning solvent (C62) is flammable any toxic. It can irritate skin and cause bums. Use only in well ventilated area, away from heat and open flame. Wear rubber I gloves and goggles. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

- d. Clean inside of filter bowl (1) using dry-cleaning solvent (C62) and wiping rags (C 119.1).
- 6-252.5. Replace and Install 3-Micron External Oil Filter.

#### NOTE

# All packings shall be lubricated with lubricating oil (C103).

- a. Lubricate packing (5) in new filter element (3) with lubricating oil (C103).
  - b. Install filter element (3) in filter bowl (1).
- c. Lubricate packing (4) with lubricating oil (C103) and install in filter bowl (1).
- d. Install filter bowl (1) hand tight into filter head (2). Secure with lockwire.
  - e. Service transmission to correct oil level.
  - f. Perform MOC and leak check of filter assembly.
  - g. Reinstall transmission cowling.

# 6-252.6. REMOVE - 3-MICRON OIL FILTER ASSEMBLY (figure 6-40.1).

#### **CAUTION**

Protective covers shall be used to cover all open ports and lines to prevent contamination by entry of foreign materials.

- a. Remove the transmission cowling. Place suitable container under oil filter housing.
- b. Remove hose (1) from inlet side of filter assembly (2) (figure 6-40.1).
- c. Remove hose (3) from outlet side of filter assembly (2).
- d. Remove reducer (4) and packing (5) from outlet side of filter assembly (2). Discard packing (5).
- e. Remove reducer (6) and packing (7) from inlet side of filter assembly (2). Discard packing (7).
- f. Remove filter assembly (2) by removing three bolts (8), three washers (9), and three spacers (10).

6-252.7. INSTALL - 3-MICRON OIL FILTER ASSEMBLY (figure 6-40.1).

#### NOTE

All packings shall be lubricated with lubricating oil (C103).




Figure 6-40.1. 3-Micron Oil Filter Assembly

- a. Install filter assembly (2) with three bolts (8), three washer (9), and three spacers (10).
- b. Install reducer (6) with new packing (7) lubricated with lubricating oil (C103) on inlet side of filter assembly (2).

- c. Install reducer (4) with new packing (5) lubricated with lubricating oil (C103) on outlet side of filter assembly (2).
- d. Install hose (3) on outlet side of filter assembly (2).
- e. Install hose (1) on inlet side of filter assembly (2).
  - f. Service transmission to correct oil level.
  - g. Perform MOC and leak check of filter assembly.
  - h. Reinstall transmission cowling.




Figure 6-40.2. 3-Micron Oil Filter Element

#### 6-253. OIL COOLER.

- **6-254. Description Oil Cooler**. The oil cooler (3, figure 6-40) mounts on the transmission top above the input drive quill and has a thermo-bypass valve incorporated to bypass cool oil. Oil is cooled as it flows through the cooler by air which is supplied by a fan and duct arrangement.
- **6-255.** Removal Oil Cooler. Disconnect oil inlet I line. Remove clamp (2, figure 6-40) and air hose (1) from air duct. Remove oil outlet transfer bolt (7) in transfer tube (4). Remove bolts holding cooler to mount brackets.

- **6-256. Inspection Oil Cooler**. Inspect oil cooler (3, figure 6-40) for oil leakage in core, cracks, and security.
- **6-257. Installation Oil Cooler**. Position oil cooler (3, figure 6-40) on mount brackets and install bolts securing cooler to brackets. Connect oil inlet line and outlet transfer bolt (7).

#### 6-258. AIR DUCT HOSE ASSEMBLY.

### 6-259. Description Air Duct Hose Assembly.

The air duct hose assembly (reference figure 6-40) conveys cooling air forward to the transmission oil cooler (3) from the cooling fan mounted on the upper structure, aft of the aft firewall and driven by the tail rotor driveshaft.

### 6-260. Inspection - Air Duct Hose Assembly.

Inspect duct assembly for tears, cuts, fraying, collapse, and security of mounting.

- **6-261.** Removal Air Duct Hose Assembly. Refer to paragraph 6-255.
- **6-262. Repair Air Duct Hose Assembly**. Repair is limited to removal and replacement of authorized parts as outlined in TM 55-1520-228-23P.
- 6-263. Installation Air Duct Hose Assembly.
- a. Connect air hose (1, figure 6-40) and clamps(2 and 19) on air inlet duct and aft cabin roof duct (22).
- b. On upper end of air hose (1) below air inlet duct, install clamp (23) with attaching hardware to existing bracket (29) on main rotor transmission.
  - c. Attach supporting clamps (23 and 28) as follows:
- (1) At approximately nine inches from upper end of air hose (1) position one clamp (23).
- (2) On right leg of pylon support link (11, figure 2-55) position one clamp (28, figure 6-40).
- (3) Secure clamps (23 and 28) together with attaching hardware.

### NOTE

Before tightening,- position clamps to prevent chafing of air hose on bulkhead support of transmission cowling.

- **d.** Gain access to aft electrical shelf area and connect hose assembly (21) to aft cabin roof duct (22) with clamp (19).
- **e.** Position two clamps (23) on air hose (21) and secure to frame assembly with attaching hardware.
  - f. Install filler (20) in oil cooler deck.
- **g.** Insert air hose (21) up through cooler deck and attach to oil cooler Mower with hose clamp (2).
- **h.** Install clamp (23) on air hose (21) at oil cooler deck with attaching hardware.
- i. Apply sealing compound (C130) to air hose (21) at oil cooler deck.

### 6-264. OIL TRANSFER TUBE.

- **6-265. Description Oil Transfer Tube.** The transfer tube (4, figure 6-40) carries oil from the oil cooler to the transmission top case.
- **6-266.** Removal Oil Transfer Tube. Remove bolts (7, figure 6-40), packing (6), gasket (12), and oil transfer tube (4).
- **6-267.** Cleaning Oil Transfer Tube. Clean all parts with drycleaning solvent (C62). Dry with clean dry filtered air. Ensure openings are clear.

### 6-268. Inspection - Oil Transfer Tube.

- **a.** Inspect for cracks and holes in walls of tube. None are permitted.
- **b.** Inspect for scratches and pitting on sealing surfaces. None are permitted.
  - c. Inspect tube for restrictions.
- **6-269. Repair Oil Transfer Tube.** No repair authorized, except for treatment of magnesium surface in accordance with procedures outlined in TM 55-1500-204-25/1, and painting with epoxy polyamide primer (C116).

#### 6-270. Installation - Oil Trensfer Tube.

- e. Install new packing (6, figure 6-40) on bolt (7).
  - **b.** Insert bolt (7) through oil transfer tube (4).

- c. Install new packing (11) on bolt (7).
- d. Install new gasket (12) on bolt (7)
- **e.** Position tube and install bolts (7). Torque bolts **100 TO 200 INCH-POUNDS** and lockwire (C96).

# 6-271. PRESSURE REGULATOR VALVE.

**6-272. Description - Pressure Regulator Valve.** The oil pressure regulator valve (9, figure 6-40) is mounted on the left, aft side, of the transmission case and limits the system oil pressure by relieving excess oil back into the transmission case. The oil pressure regulator is located below the oil cooler.

#### NOTE

Do not loosen jamnut or turn external pressure adjusting screw.


### 6-273. Adjustment - Pressure Regulator Valve.

Remove plug (3, figure 6-41) A or transducer (5) and connect pressure gage (T6), 0-100 psi range using 0,250 inch flexible hose to cross boss fitting.

# CAUTION

Do not use helicopter transmission oil pressure gage to check pressure regulator. An inaccurate pressure adjustment will result at reading between 40 to 60 psi on the transmission oil prassure gage.

- **b.** Run up helicopter to warm lubricating oil. Do not attempt adjustment of valve until oil is hot or unless pressure is below **30** psi when at full rpm.
- c. Check pressure to range of 40 to 60 psi when at 103% rpm A or 100% rpm C with with hot oil. If not within this range, adjust to 45 to 55 psi. Back off adjusting screw jamnut; increase pressure by clockwise rotation of the adjusting screw. Tighten jamnut, check pressure range and shutdown engine.



- 1. Low Pressure Sensing Switch
- 2. Oil Flex Hose
- 3. Plug A
- 4. Oil Tubing
- 5. Tranducer C

206040-513

Figure 6-41. Pressure Sensing Switch Installation

- **d.** Remove test gage, install plug (3) q or transducer (5) q and safety with lockwire, Torque plug to **40 TO 65 INCH-POUNDS.**
- **6-274.** Removal Pressure Regulator Valve. Remove lockwire. Use wrench on hexagonal shoulder of valve body to loosen and remove valve assembly with packings.
- **6-275.** Inspection Pressure Regulator Valve. Inspect valve for scored areas, and damaged threads, Using a nonmetallic blunt rod, check piston for freedom of movement by pushing it into the body several times.

- 6-276. Installation Pressure Regulator Valve.
- **a.** Lubricate threads and packing with oil, and place new packing on valve.
  - b. Install body in case.
- **c.** Check oil pressure in operation. If a new valve assembly is being installed or incorrect adjustment of the valve is suspected, check pressure setting. Refer to paragraph 6-273.

# 6-277. LOW PRESSURE SENSING SWITCH.

**6-278. Description - Low pressure Sensing Switch.** The transmission oil low pressure sensing switch (1, figure 6-41) is mounted on the cabin roof and completes the electrical circuit to light the XMSN OIL PRESS warning light when transmission oil pressure drops below 30 psi.

**6-279.** Removal - Low Pressure Sensing Switch. Disconnect electrical lead, remove screw, clamp, spacer, and washer that attaches switch (1) to cabin roof and turn switch from cross fitting. Discard packing.

**6-280.** Installation - Low Pressure Sensing Switch. Install new packing on switch (1) and install switch in cross fitting. Torque switch **40 TO 65 INCH-POUNDS** and lockwire (C96). Place clamp on switch and attach to cabin roof with a washer, spacer, and screw. Connect electrical lead to switch.

### 6-281. OIL NOZZLES (JETS).

**6-282. Description** — **Oil Nozzles (Jets.** Two oil jet assemblies are installed on the left side of the transmission main case and top case. These jets carry oil under pressure from internal oil supply passages, to deliver aimed sprays of oil on gears and bearing. Spacing of retaining screw holes prevents installation in wrong hole. Attaching screw hole indexes the jet nozzle spray direction. Refer to figure 6-40.

### 6-283. Removal - Oil Nozzles (Jets).

- **a.** Cut lockwire between two screw heads on jet. Remove only the one screw which secures mounting plate of jet to case.
- **b.** Pull jet tube, with packings, from case. Cover open port to prevent contamination.
- **6-284.** Cleaning Oil Nozzles (Jets). Wash in drycieaning solvent (C62) with a suitable brush. Dry with clean dry filtered air, ensuring nozzle openings are clear.

#### 6-285. Installation - Oil Nozzles (Jets).

**a.** Uncover openings, apply light coat of oil (C103) to new packings,

**b.** Insert jet, align mounting plate and secure to case with screw. Lockwire (C96) screws together.

# 6-286. CHIP DETECTORS - TRANSMISSION.

6-287. Description - Chip Detectors -Transmission. The chip detectors (two) are installed in the transmission case. One is adjacent to the oil pump inlet screen on the forward right side of the transmission, this also is the drain for the transmission. The other is a few inches aft. The chip detector is the removable center portion of the chip detector end drain plug assembly. It consists of a self lock bayonet probe with a permanent magnet at the end. When the magnet attracts sufficient metal to complete the circuit between pole and the ground, the XMSN CHIP DET segment will illuminate on the caution panel. If the drain plug is removed, on installation torque the forward plug 100 TO 176 INCH-POUNDS and the aft plug 150 TO 250 INCH-POUNDS. Refer to figure 6-40.

# 6-288. Removal - Chip Detectors - Transmission.

**a.** Disconnect the electrical lead from chip detector stud.

# CAUTION

Improper and/or rough handling of chip detectors and the electrical connection is the major cause of failure. Use care in removal, installation and connection of the terminals to avoid false indications in the caution light system.

**b.** Press detector in, turn counterclockwise, and remove, from plug.

# 6-289. Inspection - Chip Detectors - Transmission.

- **a,** Inspect chip detector for stripped or damaged bayonet pins.
- **b.** Check for accumulation of metal particles on magnet. Presence of metal may indicate need for further investigation and corrective action. Compare particles found with metal particle identification list. Refer to paragraph 6-4 and table 6-2.

#### TM 55-1520-228-23

# 6-290. Installation — Chip Detectors —Transmission.

- **a.** Replace packings on chip detector insert.
- **b.** Position insert in plug, push insert in as far as possible, and turn clockwise to lock in place.

#### 6-291. HOSES AND LINES.

Hoses and lines are used to carry oil to and from freewheeling unit. Check lines and hoses for leaks, chafing, and deterioration. Inspect and replace in accordance with TM 1-1500-204-23.

### 6-292. STRAINER PUMP ASSEMBLY REMOVAL.

- **a.** Remove retaining ring (15) figure 6-40 from housing.
  - **b.** Remove strainer assembly (17).

c. Remove and discard packing (16).

# 6-293. CLEAN AND INSPECT STRAINER PUMP ASSEMBLY.

- **a.** Inspect screen for accumulation of metal particles on magnet. Presence of metal may indicate need for further investigation and corrective action. Compare particles found with metal particles identification list. Refer to paragraph 6-4 and Table 6-2.
- **b.** Inspect general condition of screen. Replace if damaged.
  - c. Flush screen with cleaning solvent (C44).

#### 6-294. INSTALL STRAINER PUMP ASSEMBLY.

- a. Install packing (16) on strainer assembly (17).
- **b.** Install strainer assembly (17) into housing.
- **c.** Install retainer ring (15).

# CHAPTER 7 HYDRAULIC SYSTEM

### 7-1. HYDRAULIC SYSTEM.

**7-2. General - Hydraulic System.** This chapter provides information and instructions for maintenance personnel to accomplish maintenance on the hydraulic system. This system includes hydraulic pump, hoses and lines, quick-disconnects, filters, reservoir, actuators and support, check valve, solenoid valve, pressure switch, and relief valve.




Prolonged contact with hydraulic fluid (C73), liquid or mist, can irritate eyes and skin. After any prolonged contact with skin, immediately wash contacted area with soap and water. If liquid contacts eyes, flush immediately with clear water. If liquid is swallowed, do not induce vomiting; get immediate medical attention. Wear rubber gloves when handling liquid. If prolonged contact with mist is likely, wear an appropriate respirator. When fluid is decomposed by heating, toxic gases are released.

### SECTION I. FLIGHT CONTROL

#### 7-3. FLIGHT CONTROL.

7-4. Description - Flight Control. The flight control hydraulic system (figures 7-1 and 7-2) provides power to operate cyclic and collective power control cylinders. The system includes a variable delivery pump, reservoir, two filters, a relief valve, solenoid valve, pressure switch, directional flow check valve, servo power cylinders, connecting lines. and couplings for a ground test stand. The pump is located on the forward side of the transmission and is driven by the transmission oil pump through the rotor tachometer generator. The reservoir is located on the transmission above the pump. The filler opening is in the top of the reservoir. A scupper and drain line are provided to drain excess fluid overboard. Hydraulic fluid level may be observed through a sight gage in the right side of the reservoir. Pressure and return filters are located on the right side of the system. Both filters have indicator buttons which pop out to indicate an impending filter blockage. Filters and fluid level can be checked through the inspection door on the right side of the forward transmission fairing. A solenoid valve, for turning the system on and off, a pressure switch, and a relief valve are located on the work deck forward of the transmission. A boost ON-OFF switch may be mounted on the instrument panel for pilot control of the solenoid valve. Access to the hydraulic system is gained by removal of the forward transmission fairing.

7-5. Operation - Flight Control. System pressure of 575 to 626 psig is produced by the transmission driven pump. Fluid is drawn from the reservoir by the pump. The pump forces fluid through the filter and a normally open solenoid operated system shutoff valve. When the HYD BOOST switch is on, this valve is open and system pressure is supplied to the two cyclic and one collective flight control power cylinders. Each power cylinder assembly includes a servo valve which is mechanically controlled by the flight control linkages. When the linkage moves any servo valve control lever the cylinder moves in the same direction. When the lever is centered, system pressure is applied equally to both sides of the cylinder piston but the system return port is shut off and the cylinder does not move in either direction. Irreversible valves in each power cylinder prevent rotor feedback in the event of hydraulic failure. Each irreversible valve incorporates a check valve to isolate surge pressures produced by rotor feedback in power cylinders from the system pressure lines. A differential relief valve in the servo opens automatically to relieve pressure in excess of



Hydraulic System (Sheet 1 of 2)

1. Quick-disconnect (Pressure) 2. Quick-disconnect (Return)

3. Filter (Return) 4. Filter (Pressure) 5. Vent Line




Figure 7-1. Hydraulic System (Sheet 2)




Figure 7-2. Hydraulic System Schematic

- 1. Reservoir
- 2. Baffle
- 3. Scupper Drain
- 4. Quick-disconnects
- 5. Pump
- 6. Check Valve
- 7. Filter

- 8. Filter Bypass Valve
- 9. Relief Valve
- 10. Solenoid Valve
- 11. Pressure Switch
- 12. Servoactuator, Cyclic
- 13. Servoactuator, Collective

206076-81

**670 to 770** psi. When no system pressure is available and the power cylinders are operated manually, fluid flows from one side of the piston directly through the servo valve and check valve to the other side of the piston. The hydraulic pump is driven by the transmission, therefore, hydraulic boost is provided during autorotation.

**7-6.** Troubleshooting — Hydraulic System. Indications, probable cause, and corrective action for

trouble in the hydraulic systems are contained in table 7-1.

#### **NOTE**

Before using table 7-1, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 7-1, notify the next higher level of maintenance.

Table 7-1. Troubleshooting — Hydraulic System

#### CONDITION

**TEST OR INSPECTION** 

#### CORRECTIVE ACTION

- 1. HYD PRESS caution segment reported being illuminated during normal operation.
  - STEP 1. Loss of fluid and pressure by leakage.

Locate and repair leaks; replace faulty lines, hoses, seals, or other parts. Refer to paragraph 7-67. Service system as required. Refer to paragraph 1-12.

STEP 2. Other malfunction in system.

Perform operational check with (S3) hydraulic test stand. Refer to paragraph 7-7.

STEP 3. If HYD PRESS caution segment does not illuminate and system operates normally with hydraulic test stand, trouble may be in pump circuit or defective pump.

Replace pump. Refer to paragraph 7-9.

STEP 4. Pump pressure line restricted.

Replace or correct installation of parts. Refer to paragraph 7-9.

STEP 5. System actuators operate normally on (S3) hydraulic test stand, but caution segment is illuminated. Warning circuit or pressure switch may be faulty.

Replace pressure switch. Refer to paragraph 7-48.

STEP 6. Electric circuit malfunction.

Check and repair electrical circuit.

STEP 7. System solenoid valve staying at OFF position or faulty HYD BOOST switch.

Replace solenoid valve, repair electrical circuit, or replace switch. Refer to paragraph 7-20.

### Table 7-1. Troubleshooting — Hydraulic System (Cont)

### CONDITION

TEST OR INSPECTION

#### **CORRECTIVE ACTION**

STEP 8. System relief valve staying open or relieving at too low pressure.

Replace relief valve. Refer to paragraph 7-79.

STEP 9. Internal leakage through a unit.

Isolate and replace defective unit.

- 2. HYD PRESS segment in caution panel fails to illuminate.
  - STEP 1. Caution panel lamp or panel segment failed.

Replace lamp or panel.

STEP 2. Pressure switch or wiring faulty.

Replace pressure switch or repair electrical circuit. Refer to paragraph 7-48,

STEP 3. System solenoid or electrical circuit faulty.

Replace solenoid valve or repair electrical circuit. Refer to paragraph 7-20.

STEP 4. Faulty HYD BOOST switch.

Replace switch.

- 3. Servo cylinders chatter when controls are moved.
  - STEP 1. Air in system.

Cycle controls at least 10 full strokes at normal operating pressure to work out air. Refer to paragraph 7-7.

- 4. Controls do not operate smoothly.
  - STEP 1. Incorrect bolts inserted.

Check valve linkage bolts. Insert correct bolts.

- 5. Excessive feedback in operation of controls,
  - STEP 1. Air in servo cylinders.

Cycle controls at least 10 times to work out air. Refer to paragraph 7-7.

# 7-7. Testing Hydraulic System with Hydraulic Test Stand (S3).

# Premaintenance Requirements for Cleaning and Flushing of Hydraulic System

Condition	Requirements	
Model	OH-58A/C	
Part No. or Serial No.	AII	
Special Tools	None	
Test Equipment	None	
Minimum Personnel Required	Two	
Consumable Materials	(C62), (C73), (C96), (C104)	
Special Environmental Conditions	Dust free, well ventilated area	

A portable hydraulic test stand can be used to provide pressure to test or bleed the hydraulic system without operation of the helicopter engine. Prior to use, the test stand shall be thoroughly cleaned and serviced with hydraulic fluid (C73). The stand shall be equipped with a 10-micron filter and a calibrated pressure gage with a capacity of 1000 psig. The stand shall be capable of producing pressure to 1000 psig and shall have a minimum flow rate of two gallons per minute at 1000 psig. Refer to TB 55-1500-334-25.

a. Prepare for test as follows:

### NOTE

A complete visual inspection of the hydraulic system shall be accomplished before the functional test is performed to ensure that all components and lines are attached, secure, and appear capable of satisfactory operation.

(1) Position ground test stand on right side of helicopter by engine compartment.

- (2) Remove forward transmission fairing. (Refer to paragraph 2-39 A or 2-40C.) Remove bases at quick-disconnects (1 and 2, figure 7-1).
- (3) Cap ends of removed hoses to prevent entrance of foreign matter.
  - (4) Connect test stand hoses.
  - (5) Apply electrical power to helicopter.
  - (6) Position HYD BOOST switch on.
  - b. Clean and flush hydraulic system as follows:

#### **NOTE**

For pump failure, the pressure line filter will trap all particles. When replacing failed pump flush pressure line to filter and replace filter element.

- (1) Drain hydraulic reservoir,
- (2) Inspect interior of hydraulic reservoir. If reservoir is pitted, or contaminated with sediment, dirt or other foreign matter, clean the following components (figure 7-1) with drycleaning solvent (C62):
  - (a) Reservoir (6)
  - (b) Pump inlet hose (25)
  - (c) Pump pressure hose (24)
  - (d) Return hose from filter (23) to reservoir (6)
  - (e) Pump case drain hose (10).
- (3) If interior of hydraulic reservoir is not visually contaminated, except for traces of water, the hydrauic reservoir and pump inlet hose may be flushed on the helicopter. Proceed as follows:
- (a) Remove traces of water with clean, lint-free cloth,
  - (b) Disconnect pump inlet hose (25) at pump.
- **(c)** Position end of pump inlet hose in container.

- **(d)** Pour approximately one quart of clean hydraulic fluid (C73) into reservoir and pump inlet hose.
  - (e) Attach pump inlet hose at pump.
- **(f)** Uncouple quick-disconnect couplings (1 and 2). Disconnect hose (23) at reservoir (6) and hose (24) at pump (9).
- **(g)** Remove hydraulic reservoir return line coupling and clean baffle with drycleaning solvent (C62).
- **(h)** Remove pump case drain hose (10) and clean with drycleaning solvent (C62).
- (4) Install pump case drain hose (10). Ensure check valve (8) is installed with arrow in direction illustrated in figure 7-1.
- (5) Remove filter elements, clean filter bowls with drycleaning solvent (C62), and reinstall filter bowls without filter elements.
- **(6)** Disconnect hoses (13 and 15) from the right hand servoactuator and connect together, using an AN919-3 reducer.
- (7) Disconnect hose (14) from the left hand servoactuator, and hose (17) from the center servoactuator; then connect together using an AN919-3 reducer.
- (8) Disconnect hoses (14 and 16) from the center servoactuator and connect together, using an AN815-4 union.
- (9) Disconnect hoses (12 and 13) from the left servoactuator and connect together, using an AN818-5 union.
- (10) Connect hydraulic test stand (S3) pressure line to quick-disconnect at pressure filter (4).
- (11) Connect a hose of sufficient length to the return filter (3) to reach a container overboard for contaminated fluid.
- (12) Start test stand and adjust to 100  $(\pm 50)$  psi.
- (13) Circulate hydraulic fluid for approximately one minute, or until fluid runs clean.

- (14) Shut down test stand.
- (15) Remove hose at return filter (3) and attach test stand return line to quick-disconnect at filter (3).

# CAUTION

Do not exceed 625 psi. Excessive pressure may damage system seals.

- (16) Start test stand and adjust to 600  $(\pm 25)$  psi.
- (17) Circulate hydraulic fluid for approximately 5 minutes.
  - (18) Shut down test stand.

#### NOTE

Refer to TM 55-1 500-204-25/1 for torque requirements.

- (19) Remove reducers and unions then attach hoses (12, 13, 14, 15, 16, and 17) to servoactuators as illustrated in figure 7-1.
- (20) Disconnect test stand return line at quick-disconnect at return filter (3).
- (21) Connect a hose of sufficient length to the return filter (3) to reach a container overboard for contaminated fluid.

# CAUTION

Do not exceed 625 psi. Excessive pressure may damage system and servoactuator seals.

- (22) Start test stand and adjust to 600 (±25) psi.
- (23) Cycle the collective stick full up to full down 10 times. With collective full down, move the cyclic in a circle 10 times. With collective full up, move the cyclic in a circle 10 times.
  - (24) Shut down test stand

- (25) Remove test stand connections and install clean hydraulic reservoir if removed, clean filter elements, clean lines, fitting, and baffle. Refer to TM 55-1500-204-25/1 for torque requirements, and figure 7-1 for proper location of components.
- (26) Connect hose (23) at quick-disconnect coupling (2) and reservoir (6).
- (27) Connect hose (24) at quick-disconnect coupling (1) and pump (9).
- (28) Fill reservoir with clean hydraulic fluid (C73).
- **c.** Bleeding hydraulic system using transmission-driven pump.
- (1) Remove transmission fairing. Refer to paragraphs 2-39 A or 2-40 C.
  - (2) Ensure hydraulic reservoir is full.
  - (3) Start and ground run the helicopter.
- (4) With main rotor turning at idle speed, cycle the cyclic and collective controls a minimum of 10 times to bleed air from system.
  - (6) Shut down the engine.
- **(6)** Fill reservoir with hydraulic fluid (C73) and repeat steps (3), (4), and (5) as necessary until all air is out of system.
- **d.** Perform functional test of hydraulic system as follows:
- (1) If test stand is not available remove plug at test port of one servoactuator and connect calibrated pressure gage (T5) to hydraulic system. Ground-run aircraft, with engine running at 82 to 85% of N2; hydraulic pressure should be 600 (±25) psig without movement of controls.
- (2) If test stand is available, connect test stand (S3) at quick-disconnect couplings (1 and 2, figure 7-1) located on right side of helicopter and set test stand (if used) pumps to provide a minimum flow of 1.9 G PM with pressure compensator adjusted to 600 (±25) psig.

- (3) Sequence valve test is not required for servoactuator P/N 206-076-031-15 and subsequent.
- (a) Actuate the controls and turn the hydraulic system on and off several times in accordance with TM 55-1520-228-10.
- **(b)** After **15** minutes turn test stand pump off. Disconnect return line hose assembly from the return port of all three cylinder assemblies (figure 7-1). Cap hose assemblies to prevent loss of hydraulic fluid.
- **(c)** Place shop towels or containers as necessary to catch any hydraulic fluid that may drain from the cylinder assembly return ports.
- **(d)** Place cyclic stick in center of travel and apply friction to hold in position.
- **(e)** Actuate the collective control stick through its full travel. While moving the control, check for hydraulic fluid leakage out of return line port of each cylirider.
- (f) Continue to test for leakage for 5 minutes. Remove and replace any cylinder assembly which leaks a steady stream of fluid sufficient to rapidly drain the servo head assembly, or which leaks in excess of 6 drops per minute during the last 2 minutes of the test.
- **(g)** Connect the return line hydraulic hose assemblies to their respective cylinder assembly return ports.
  - (h) Turn test stand pump on.
- (4) Clearance: Slowly cycle the cyclic and collective controls to the limit of stroke and observe movement of hydraulic servoactuators. Clearance between all moving parts shall be sufficient to prevent fouling of adjacent parts. Particular attention shall be given to flexible connections to ensure that pinching does not occur and cycling does not loosen attaching fittings.
- (5) Check operation of HYD PRESS warning light as follows:
- (a) Slowly decrease pressure. Light should illuminate at 300 psig.

**(b)** Slowly increase test stand pressure to hydraulic system. Light should extinguish at 400 psig.

#### **NOTE**

# The following check can only be accomplished using a hydraulic test stand.

- (6) Check operation of pressure relief valve in hydraulic system. Place the HYD BOOST switch to the OFF position. While operating pressure is slowly increased, place hand on relief valve to determine when it opens. Valve should open between 670 and 770 psig. Valve should reseat at 670 psig. Decrease pressure to 600 (±25) psig. Place HYD BOOST switch to the ON position.
- (7) With system pressure at 600 (±25) psig to test operation of solenoid valve, place HYD BOOST switch to OFF. HYD PRESS warning light should illuminate. Cycle the cyclic and collective controls. They should require more force to operate if valve closed properly. Position HYD BOOST switch to ON position. The HYD PRESS warning light should extinguish.
  - (8) Check operation of servoactuators as follows:
- (a) Set hydraulic test stand pressure to ZERO psig.
- **(b)** Slowly increase hydraulic pressure until it can be determined that the control system is functioning with hydraulic power. Change over from mechanical to hydraulic operation should occur between **100 to 188** psig. Actuate both cyclic and collective controls to determine if this requirement is met on all cylinders.
  - (c) Reduce pressure to ZERO psig.
- **(d)** Check each servoactuator for irreversibility by grasping rod end of power cylinders, and pushing or pulling with approximately **50** pounds of force. Piston rod should not move.
- **(9)** When test is complete, refill and bleed system as necessary. Disconnect hydraulic test stand and connect helicopter hydraulic hose couplings.
- **7-8. Testing hydraulic System With Transmission- Driven Pump.** When a ground test stand is not available, the transmission driven hydraulic pump can be used to perform operational checks and to bleed the hydraulic system. Operation of the engine shall be per-

formed in accordance with instructions contained in TM 55-1520-228-10. The following check will be accomplished as a MOC anytime maintenance is performed on the hydraulic system.

**a.** Perform operational check of hydraulic system as follows:

#### NOTE

# Ensure that the hydraulic system has been bled and filled.

- (1) Start and ground-run the helicopter.
- (2) Increase engine rpm until idle speed is reached. Maintain idle speed for at least 15 minutes.
- (3) While speed is maintained, place HYD BOOST switch on and make the following checks.
- (a) Observe all hydraulic fittings and components for evidence of external leakage.
- **(b)** Repair or replace components and fittings as necessary to correct leakage.
- **(c)** Slowly cycle the controls to allowable limits for idle speed and observe movement of hydraulic servo cylinders. No fouling should occur.
- **(d)** Check flexible hoses and connections to ensure that pinching of hoses does not occur.
- **(e)** Position HYD BOOST switch to OFF. Solenoid valve should energize and close. HYD PRESS caution light should illuminate and more force should be required to move the controls.

#### NOTE

The following paragraph is not required for removal and replacement of hydraulic lines.

- **b.** Pressure test hydraulic system as follows:
- (1) Remove plug at test port of one servo-actuator and connect a calibrated pressure gage (T5) to hydraulic system. With engine running at 82 to 85% of N2, hydraulic pressure should be 600 (±25) psig without movement of controls.

- (2) If pressure is out of limits replace pump and repeat step a.
- (3) Shut down helicopter, remove gage, and replace plug.

## SECTION II. HYDRAULIC PUMP

#### 7-9. HYDRAULIC PUMP.

#### NOTE

Hydraulic Pump 421210 has two additional ports which are located 90 degrees from the case drain and seal drain ports. As installed, these extra ports are located horizontally on the left and right sides of the pump (9 o'clock and 3 o'clock positions). Field units should install metal plugs AN814-4D with packings MS28778-4 in the extra ports. Lockwire is not required. All other installation, hookup, inspection and test requirements are as stated in existing manuals.

- **7-10. Description Hydraulic Pump.** The variable-delivery hydraulic pump (9, figure 7-1) is mounted on the rotor tachometer generator, on the forward side of the transmission. It is driven by the transmission through the tachometer generator and has three connections; inlet, pressure outlet, and case drain port. The pump is self-lubricating and has a seepage drain port to allow fluid that may leak past the drive seals to escape.
- **7-11 Cleaning Hydraulic Pump.** Clean with drycleaning solvent (C62). Dry with moisture-free, compressed air at approximately 20 psi pressure.

### 7-12. Inspection - Hydraulic Pump (Installed).

#### **CAUTION**

Check valve, in case drain line, must be insalled with arrow pointing away from pump. (Refer to 8, figure 7-1 and 6, figure 7-2). Improper installation (backward) will cause the pump to overheat, and can result in precautionary or forced landings.

- **a.** Inspect hydraulic pump for leakage. Refer to table 7-2.
  - **b.** inspect hydraulic pump for security of installation.
  - c. inspect hydraulic pump for cracked housing.

- **d.** Ensure plugs and screws are properly lockwired.
- **e.** Inspect connecting lines and hose for security and leakage.

### 7-13. Removal - Hydraulic Pump.

- **a.** Remove forward transmission fairing. Provide suitable container to catch hydraulic fluid.
  - b. Drain reservoir.
- **c.** Disconnect three hoses from the pump. Cap or cover ends of hoses and pump fittings.
- **d.** Remove four nuts which secure pump mounting flange to tachometer pull pump free of drive pad and remove from helicopter.

### 7-14. Inspection - Hydraulic Pump (Removed).

- **a.** Inspect for broken shaft and worn spline.
- **b.** Inspect ports and passageways for cleanliness.
- **c.** Inspect ports for cross threading and mutilation.
- **d.** Inspect external driveshaft for cracked or broken teeth.
  - e. Inspect data plate for legibility.
- **f.** Rotate pump driveshaft by hand. The shaft must not bind or require more than 16 inch-pounds of torque to rotate.

### CAUTION

Contamination is a major cause of wear and pump failure.

**g.** Install an AN806D6 plug in the inlet and an AN806D8 plug in the discharge port. Using hydraulic test stand (S3) or equivalent, apply fluid to the case drain port at 160 psig for 10 minutes. Not more than 1 drop leakage will be permitted for any joint or seal.

Table 7-2. Maximum Allowable Leakage for in-Service Components

COMPONENT	FUNCTION	TYPE	LEAKAGE RATE
Servo- Actuators	Rod Seal	D	1 drop/flight hour or 1 drop/20 full stroke
	Rod Seal	S-D	cycles 1 drop/15 minutes
	End Cap	S	2 drops/day
	Valve Input	D	1 drop/5 cycles
	Valve Input	S-D	1 drop/5 minutes
	Valve Body	S-D	None
	(Weep Holes)	S-D	1 drop/5 minutes
Pump	Output Shaft	D	1 drop/minute
	Output Shaft	S-D	1 drop/minute
	Housing (mating surfaces)	S	2 drops/day
Fittings	Flared or Flareless	S	None
•	Compression Seals	S	1 drop/30 minutes

#### NOTE:

D — Dynamic

S — Static

S-D — Static leakage through dynamic seal

See Figure 7-3 for location of functions.

### 7-15. Disassembly - Hydraulic Pump. (AVIM)

- a. Remove driveshaft and seal as follows:
- (1) Hold external driveshaft (1, figure 7-4) and lightly tap housing (25) with a small mallet to remove shaft (1). Discard ring (2) and remove spring (3).
- (2) Remove four screws (12), retainer (4), mating face (7), and packings (5 and 6).
- (3) Remove nose seal (8), packing (9), flat washer (10), and spring washer (11) from internal driveshaft (not illustrated).
- **b.** Remove rate piston port cap seal by removing plug (13) and packing (14).



# Do not remove spring (16) and rate piston (17).

**c.** Remove stroking piston port seal by removing plug (20) and packing (19).



## Do not remove stroking piston (18).

d. Remove trunnion seal by removing eight screws (23) and eight washers (22). Remove two




Figure 7-3. Hydraulic System Functions

- 1. External Drive Shaft
- 2. Ring
- 3. Spring
- 4. Retainer
- 5. Packing
- 6. Packing
- 7. Mating Face
- 8. Nose Seal
- 9. Packing
- 10. Flat Washer
- 11. Spring Washer
- 12. Screws
- 13. Plug
- 14. Packing
- 15. Spring
- 16. Spacer
- 17. Rate Piston
- 18. Stroking Piston
- 19. Packing
- 20. Plug
- 21. Trunnion Cover
- 22. Washer
- 23. Screw
- 24. Packing
- 25. Housing
- 26. Cover




Figure 7-4. Hydraulic Pump

trunnion covers (21) and discard two packings (24). (identical trunnion cover, etc., on opposite side of pump is not illustrated.)

- **7-16.** Cleaning After Disassembly Hydraulic Pump. (AVIM) Clean all parts removed with drycleaning solvent (C62) except seals, which must be discarded.
- 7-17. Repair or Replacement Hydraulic Pump.

# CAUTION

Do not adjust hydraulic pump pressure. Pressure is preset by manufacturer. If compensator seal is broken, replace hydraulic pump.

Repair is limited to items covered in reassembly. If pump cannot be repaired by replacement of specified items, pump must be replaced.

### 7-18. Assembly - Hydraulic Pump. (AVIM)

- e. Assemble driveshaft and seal as follows:
- **(1)** Lubricate parts with hydraulic fluid (C73) prior to reassembly.
- (2) Slide spring washer (11, figure 7-4), flat washer (10), packing (9), and nose seal (8) onto shaft (not illustrated).
- (3) Install packing (6) on mating face (7), install packing (5) on retainer (4), and insert parts into housing (25) making sure seal drain hole in retainer is aligned with hole in housing. Secure retainer (4) with screws (12). Torque screws 14 TO 16 INCH-POUNDS.
- (4) Install new ring (2) and external driveshaft (1), then insert spring (3) in shaft (1). Compress ring (2) and slide shaft (1) into internal driveshaft (not illustrated) allowing ring (2) to expand, securing shaft (1).
- (5) Rotate pump driveshaft by hand. Check for binding and excessive torque required for rotation.
  - b. Assemble rate piston port seal as follows:
- (1) Install new packing (14) and reinstall plug (13).

- **(2)** Torque plug **100 TO 110 INCH-POUNDS.** Install lockwire (C96) as necessary.
- **c.** Assemble stroking piston port cap seal as follows:
- (1) Install new packing (19) and reinstall plug (20).
- (2) Torque plug 70 TO 80 INCH-POUNDS. Lockwire (C96) as necessary.
  - d. Assemble trunnion and seal as follows:
- (1) Clean trunnion cover adjacent area of pump with drycleaning solvent (C62).
- (2) Install two new packings (24), two trunnion covers (21), eight washers (22), and eight screws. Torque screws (23) 14 TO 16 INCH-POUNDS and install lockwire (C96).
- (3) Check for leaks in pump as described in inspection procedure. Refer to paragraph 7-12.

### 7-19. Installation - Hydraulic Pump.

#### NOTE

Ensure that all tubing and fittings are clean and that connecting hoses are not frayed or cracked.

a. If new pump is being installed, remove four shipping plugs from pump and drain shipping fluid. Install hose fittings and packings in pump. Apply a thin coat of lubricant (C104) to salines on pump and mating splines on tachometer generator.

# CAUTION

Check valve in case drain line must be installed with arrow pointing away from pump (8, figure 7-1 and 6, figure 7-2). Improper installation (backward) will cause the pump to overheat and can result in precautionary or forced landings.

**b.** Position pump and gasket on tachometer generator mounting pad, engaging pump shaft in splined gearshaft. Check that pressure outlet is at

lower side of pump. Install four nuts with washers on mounting studs.

- c. Connect pressure line to pressure port.
- **d.** Prime hydraulic pump with hydraulic fluid (C73) at suction port. Install suction line to suction port. Connect case drain hose (10, figure 7-1) to hydraulic check valve (8) in case drain port at top of pump.

#### NOTE

Ensure shipping plug has been removed from seepage drain on bottom of pump. No plug is required in seepage drain.

- e. Fill reservoir with hydraulic fluid (C73).
- **f.** Check hydraulic pressure. (Refer to paragraph 7-8 for hydraulic pressure check procedure.) Observe hydraulic system for leakage while making pressure check.

#### SECTION III. SOLENOID VALVE

### 7-20. SOLENOID VALVE,

**7-21. Description - Solenoid Valve.** An electrical solenoid control valve is incorporated in the hydraulic system for turning the system on or off, The solenoid is installed forward of the transmission in the center work deck area.

Premaintenance Requirements for Hydraulic Solenoid Valves

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	None
Test Equipment	None
Support Equipment	(S3)
Minimum Personnel Required	Two
Consumable Materials	(C62) (C73) (C96)
Special Environmental Conditions	None

### 7-22. Inspection - Solenoid Valve.

- **a.** Ensure electrical connector is attached to solenoid.
- **b.** Ensure wires to connector are not broken or loose.
- **c.** Inspect valve and fittings for security of attachment.
- **d.** Perform operational check. Refer to paragraph 7-7.
- **e.** Inspect for leakage between solenoid (1, figure 7-5) and valve body (5).
- **f.** Feel solenoid for clicking while solenoid is being energized.

#### NOTE

Solenoid is defective if nothing can be felt and HYD PRESS light does not go out when valve is energized.

### 7-23. Removal - Solenoid.

**a.** Remove forward transmission fairing if not previously accomplished. Refer to paragraph 2-39 A or 2-40 C.




Figure 7-5. Solenoid Valve

206076-84

**b.** Turn BAT switch OFF and disconnect external power.

4. Spool

- **c.** Disconnect electrical connectors from solenoid valve (11, figure 7-1).
- **d.** Place wiping cloth around solenoid valve (11) to catch hydraulic fluid.
- **e.** Remove lockwire securing solenoid (1, figure 7-5) to body (5).
- **f.** Remove solenoid (1) by unscrewing from body (5).

### **NOTE**

Do not remove internal parts of valve.

### 7-24. Installation - Solenoid Valve.

8. Lockwire

- **a.** Place a new packing (2, figure 7-5) on serviceable solenoid (2).
- **b.** Screw solenoid (1) into body (5) and tighten firmly with hands to compress packing (2).
- **c.** Secure solenoid (1) to body (5) using lockwire (C96).

- d. Attach electrical connector to solenoid
- e. Perform operational check of solenoid valve.
- (1) Inspect solenoid valve (refer to paragraph 7-22). (Turn BAT switch ON when visual inspection of electrical connector and wires is complete, )

#### NOTE

If HYD PRESS light does not illuminate or valve operates intermittently, remove and replace with serviceable solenoid valve. Refer to paragraphs 7-23 and 7-24.

(2) Install forward transmission fairing if inspection is satisfactory. Refer to paragraph 2-43.

#### 7-25. Removal - Solenoid Valve.

- **a.** Remove forward transmission fairing. Refer to paragraph 2-39 **A** or 2-40 **C**
- **b.** Turn BAT switch OFF, and disconnect external power if external power is attached.
- c. Disconnect electrical connector from solenoid (11, figure 7-1) and pressure switch (18),
- **d.** Place wiping cloth around solenoid valve (11) to catch hydraulic fluid.
- e. Disconnect hydraulic lines and fittings from solenoid valve body. Cap and plug all open lines,
- **f.** Remove two bolts to release solenoid valve from mounting then remove solenoid valve.
- g. If solenoid valve is to be replaced, remove fittings (22) and retain for installation

#### 7-26. Test - Solenoid Valve.

- **a.** Connect solenoid valve pressure port to hydraulic test stand (S3).
  - b. Cap SYS port.
- **c.** Bleed air from solenoid valve by applying 50 psi to pressure port while electrically actuating the solenoid with 18-volts dc.

#### NOTE

# Fluid will flow from return port if valve is properly functioning.

- d. Shut down test stand and cap solenoid.
- e. Apply 1500 psi to pressure port, then electrically energize solenoid with 18-volts dc. Measure leakage after waiting 1 minute. Leakage from return port must not exceed 10cc/minute.
- **f.** Apply 1500 psi to pressure port with solenoid de-energized. Measure leakage from return port after waiting 1 minute. Leakage from return port must not exceed 10 cc/minute.
- **g.** Shut down test stand and remove solenoid valve from test stand.

### 7-27. Disassembly - Solenoid Valve.

- **a.** Remove lockwire (8, figure 7-5) securing solenoid (1) to body (5).
- **b.** Remove solenoid (1) by unscrewing from body (5).
  - c. Remove packing (2) and discard.
  - d. Remove spacer (3).
  - e. Remove spool (4) and spring (6) from body (5),
- **7-28. Cleaning Solenoid Valve.** Clean hydraulic ports with drycleaning solvent (C62),

### 7-29. Inspection - Solenoid Valve.

- **a.** Inspect body (5) with dye penetrant. Refer to TM 55-1500 204-25/1.
- **b.** Check all machined surfaces for nicks, scratches, corrosion pitting, burrs, and scoring. No damage allowed,

#### 7-30. Repair - Solenoid Valve.

- **a.** Replace all parts which do not meet inspection requirements.
- **b.** Replace solenoid if valve did not actuate properly during test.

### 7-31. Assembly - Solenoid Valve.

- **a.** Coat all internal parts with hydraulic fluid (C73) prior to assembly.
- **b.** Insert spring (6, figure 7-5), spool (4), and spacer (3) into valve body.
- **c.** Screw solenoid (1) into body (5) and tighten firmly with hand to compress packing (2).
  - d. Secure with lockwire (C96) and retest.

#### NOTE

# If solenoid valve will not be used immediately, install clean valve return port.

- **e.** Gradually apply **2250** psi to pressure port, then actuate solenoid twice with pressure applied. Check for external leakage after one minute. No external leakage is permitted.
- **f.** Shut down test stand, then correct system port to test stand flowmeter, and uncap return port.
  - q. Apply 1500 psi and 3.0 GPM to pressure port.
- **h.** Electrically actuate the solenoid 10 times with 18-volts dc, and **1500** psi applied. Solenoid valve must actuate without evidence of hesitation or malfunction, as indicated by alternating external flow and **3.0** GPM from pressure port.
- i. With solenoid de-energized, measure pressure drop from pressure to system ports with **1500** psi at pressure port and **3.0** GPM at system port. Pressure drop must not exceed **75** psi differential.

**j.** Shut down test stand, then cap the system port and remove the cap from the return port.

#### NOTE

Install polyethylene caps over the three ports and electrical connector. Valves which fail retest are not reparable.

#### 7-32. Installation - Solenoid Valve.


- **a.** Install all hydraulic fittings previously removed from solenoid valve using new packing (2, figure 7-5),
- **b.** Lockwire (C96) nut and bolt securing fitting bodies to solenoid valve.
- **c.** Position solenoid valve on mounting and secure with two mounting bolts and washers.
- d. Install cross in left fitting of body with packing and nut.
- **e.** Attach hydraulic lines and hoses. Refer to figure 7-1.
- **f.** Move cyclic and collective controls through full range of travel and ensure that hoses do not bind or chafe.
- $\ensuremath{\mathbf{g}}.$  Connect electrical connectors to solenoid valve and pressure switch.
- **h.** Bleed hydraulic system and perform operational check.

# SECTION IV. SERVOACTUATORS (CYCLIC AND COLLECTIVE)

# 7-33. SERVOACTUATORS (CYCLIC AND COLLECTIVE).

**7-34.** Description - Servoactuators (Cyclic and Collective). The cyclic and collective control servoactuators are installed in a support located on the cabin roof. The collective control servoactuator is mounted in the center position, and the two cyclic servoactuators are mounted in the outboard

positions. The cyclic and collective servoactuators reduce the operational loads of these flight control systems. An irreversible valve is incorporated in each servoactuator. In the event of loss of hydraulic pressure to a servoactuator, the plunger (12, figure 7-6) in the sequence valve (3) is pushed up by the lower spring and poppet valve (10), the upper spring holds the valve seat (11) down. This action closes the hydraulic return port and maintains irreversibility



- 1. Return Port
- 2. Pressure Port
- Sequence Valve with Thermal Relief Provisions, Sequence Valve Cracks at 100 to 188 psi. Full Flow at 250 psi.
- 4. Differential Relief Valve Flow 575 to 645 psi Above System Pressure
- 5. Test Port
- 6. Check Valves

- 7. Slide and Sleeve Assembly
- 8. Actuator
- 9. Input Control
- 10. Poppet Valve
- 11. Valve Seat (Floating)
- 12. Plunger

206076-85

Figure 7-6. Cyclic and Collective Servoactuator Schematic

independent of hydraulic pressure. This provides safe control of the helicopter even though hydraulic power is lost. The sequence valve (3) also serves to relieve thermal pressure buildup should this occur while the system is inactive. The sequence valve (3) would normally be closed when system pressure is below **100 to 180** psig. If internal pressure builds up, the valve seat (11) is pushed up, compressing the upper spring. The poppet valve (10) on the lower spring is prevented from following by an internal obstruction in the valve shown as a line above the poppet valve (10, figure 7-6). The differential pressure relief valve (4) serves to relieve pressure buildup which could occur from excessive rotor loads.

# Premaintenance Requirements for Servoactuators

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	None
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	Two
Consumable Materials (C55) (C62) (C73) (C138)	
Special Environmental Conditions	None

# 7-35. Cleaning — Servoactuators (Cyclic and Collective).

- **a.** Clean exterior of servoactuator with drycleaning solvent (C62) using care to prevent solvent from contacting exposed portion of servo-extension shaft.
- **b.** Clean exposed portion of servo-extension shaft with a clean, lint-free cloth moistened with hydraulic fluid (C73).
  - **c.** Clean fluid pressure and return ports.

# 7-36. Inspection — Servoactuators (Cyclic and Collective).


- **a.** Visually inspect servoactuators for cracks and other signs of obvious damage. Inspect aft end of piston rod, between jamnut on rod and valve housing for cracks.
- **b.** Check dual slippage marks for slippage, broken marks, and deterioration (slippage marks are from clevis link, across locknut to servo drive 180 degrees apart). (Figure 7-7.) No adjustment authorized.

#### NOTE

Slippage marks still required when tab washer is used.

If only one slippage mark for locknut to clevis link and servo valve drive is present another mark may be added.

- **c.** Inspect pressure and return ports for mutilated threads and/or chamfer. Check ports for dirt or other foreign material.
- **d.** Inspect exposed portion of shaft at end of actuator for scoring and evidence of corrosion.
- **e.** Visually inspect rod end assembly on bottom of servovalve housing for permanent deformation and cracking.



ADJUSTMENT OF THE SERVOVALVE DRIVE IS CRITICAL AND ANY ROTATION OF THE LOCKNUT (IN EITHER DIRECTION) IS CAUSE FOR REMOVAL OF THE SERVO-CYLINDER.

Figure 7-7. Hydraulic Servoactuator

f. Visually inspect the control mechanism for obvious damage, such as bent or broken linkage. Look for missing cotter pins.

#### WARNING

The control linkage which extends into the servo-housing on the bottom of the actuator and which is attached to middle bolt on trunnion assembly, must be treated with care. Do not adjust or tighten control linkage jamnut while Installed on the aircraft. Refer to figure 7-7.

# Screws (21, figure 7-8) must be capable of being turned by hand.

- g. Move the control mechanism trunnion up and down with fingers. Trunnion must move freely. Ensure both slotted head screws through pilot input lever (sloppy link) can be rotated with fingers.
- h. Replace servoactuators that do not meet inspection requirements.
  - i. Inspect servo-trunnion spindles for wear.
- (1) Servo, forward trunnion spindle, minimum O.D. **0.748** inch.
- (2) Servo, rear trunnion spindle, minimum O.D. **0.499** inch.
- (3) Forward or rear trunnion spindle to bushing end-play (slop) shall not exceed **0.003** inch.

# 7-37. Removal - Servoactuator (Cyclic and Collective).

- a. Disconnect hydraulic lines from servoactuator to be removed. Cap or plug open line and retain fittings for installation of servoactuator.
- b. Disconnect cylinder extension tube assembly (10, figure 7-8) at servoactuator end of tube assembly. Refer to figure 7-9 for breakdown of cylinder extension tube assembly attaching hardware.
- c. Remove four bolts (16 and 18, figure 7-8) to permit separation of the two bearing plate assemblies (8) or trunnion plates (3) as applicable for servoactuator being removed. Remove servoactuator.

#### NOTE

Do not disturb position of shim plates under plate assemblies or trunnion plates. Retain original positions.

7-38. Repair - Servoactuators (Cyclic and Collective).

#### **CAUTION**

Remove one screw at a time and reinstall first screw prior to removing the second. Do not reuse nut (23, figure 7-8).

- a. Remove cotter pin (22), nut (23), and washer (24) from screw (21).
- b. Screw (21) may be polished with crocus cloth (C55) and reinstalled or replaced as necessary.
- c. Install screw (21), washer (24), and new nut (23). Tighten nut firmly against shoulder of screw, then back off to nearest castellation and install cotter pin (22). Ensure that screws can be rotated by hand.
- 7-39. Installation Servoactuators (Cyclic and Collective).

### NOTE

If new plate assemblies (8) or new bushing are being Installed, ensure cylinder trunnion can be moved freely In either fore or aft direction by pivoting bell cranks with control tubes disconnected. Should the cylinder trunnion fall to move freely, bushings may be line reamed or burnished, but not to exceed 0.501 maximum diameter. Should not be more than 0.002 difference between the O.D. spindle and I.D. of bushing.

Inspect support (19, figure 7-8) and trunnion plates (3) for presence of serviceable dissimilar metal tape on mating surface of these parts. If tape is not serviceable, dean the mating surfaces and apply new dissimilar metal tape (C138) to either the support or to the trunnion plate. Place two trunnion plates (3) on servoactuator (5) with flanged side of bushing inboard toward servoactuator. Install two bolts (18) to secure trunnion plates to support (19) with shims (4) in place between trunnion plates and servoactuator. Measure (clearance) between trunnion plates gaps servoactuators. (See detail A). Total gap for each servoactuator (both sides combined) should be 0.005 TO 0.020 inch. Remove trunnion plates (3) as required, and peel shims (4) to obtain proper gap. Reinstall trunnion plates.




Figure 7-8. Cyclic and Collective Servoactuator Installation

Inspect plates assemblies (8) and if necessary, apply dissimilar metal tape (C138) as described in step a. Place two plate assemblies (8) on servoactuator with flanged bushings inboard toward servoactuator. Install two bolts (16) to secure plate assemblies (8) and shims (9) to support assemblies (19). Measure gaps (between) plate assemblies and servoactuators at trunnion. (See detail b). Add or remove shims (9) to obtain proper gap. Gap must be 0.030 inch minimum on each side of trunnion and total gap must not exceed 0.070 inch, with trunnion moved laterally in either direction. To check for 0.030 inch minimum gap, laterally move and hold trunnion. Cycle bearing plate back and forth through several inches of travel to allow trunnion to seek its free position, then check gap. Repeat check fro trunnion gap in opposite direction.

#### NOTE

Use one washer (17 and 15) under head of bolt (16 and 18) and two washers (2 and 7) under nut (1 and 6). Omit one washer under nut if needed to allow two thread exposure.

- c. Connect cylinder extension tube (10) at aft end of servoactuator with bolt (14), washers (13), and nut (11). Install cotter pin (12).
- d. Remove caps and plugs and connect hydraulic lines to servoactuator.
- e. Bleed hydraulic system and test servoactuators. Refer to paragraph 7-7.

#### SECTION V. SERVOACTUATOR SUPPORT

#### 7-40. SERVOACTUATOR SUPPORT.

**7-41. Description - Servoactuator Support**. The cydic and collective control servoactuator support is installed on the cabin roof. It serves as a mount for the servoactuators and associated bellcranks.

# 7-42. Inspection - Servoactuator Support (Installed).

- a. Inspect support for cracks and corrosion. No cracks are permitted.
  - b. Inspect support for security of mounting.

#### 7-43. Repair - Servoactuator Support.

a. Remove corrosion using sandpaper (C126).

#### **NOTE**

Depth of repair after removal of corrosion deposits must not exceed 0.002 inch.

b. The repaired area must be treated with corrosion preventive. Refer to TM 1-1500-204-23.

#### 7-44. Removal - Servoactuator Support.

- a. Remove servoactuators if installed. Refer to paragraph 7-37.
- b. Remove screws, washers, nuts, and cotter pins (14, figure 7-9) attaching cyclic control tubes (15) to bell-cranks (20 and 24).
- c. Remove bolt, washers, nut, and cotter pin (17) attaching collective control tube (16) to bellcrank (21). Remove bolts (19), nuts (22), and cotter pins (23) attaching bellcranks (20 and 24) to support assembly (18).
- d. Remove bolt (28), washers (26), nut (25), and cotter pin (23) attaching bellcrank (21) to support assembly (18).
- e. Remove screws attaching cover assembly (27) to cabin roof. Remove cover assembly (27).
- f. Remove four bolts (2), two bolts (6), eight washers (3), two washers (5), four nuts (4), and support assembly (18) from cabin roof (1).
- g. Remove anti-torque control bellcrank from bottom of servoactuator. Refer to paragraph 11-115.
- h. Use heated putty knife to cut sealant between servoactuator support and cabin roof.

#### 7-24 Change 24




Figure 7-9. Servoactuator Support Assembly Installation (Sheet 1 of 2)




Figure 7-9. Servoactuator Support Assembly Installation (Sheet 2)

i. Remove servoactuator support.

# 7-45. Inspection — Servoactuator Support (Removed).

- **a.** Inspect support casting for cracks. No cracks are permitted.
- **b.** Inspect support casting for corrosion pitting. Corrosion pitting must not exceed 0.002 inch after removal or corrosion.
  - c. Inspect mounting holes for elongation,
- **d.** Check bearings for smooth operation and security.
  - e. inspect for unprotected bare surfaces.
- **f.** Check inner two bearings for ring staking on both sides. inner two bearings must be tight in their respective sleeves (0.002 to 0.0012 inch tight at time of installation).
- **g.** Check outer two floating bearings (35) for excessive looseness. Looseness between outer two bearings and their respective sleeves must not exceed 0.0015 inch. Ensure steel sleeves are ring staked in housing assembly.
- **h.** Check bushings for wear, damage, or looseness in housing. Maximum elongation to bushing holes is not to exceed 0.003 inch.
- **7-46. Repair Servoactuator Support.** Refer to paragraphs 7-43 and 11-126.

#### 7-47. Installation — Servoactuator Support.

#### **WARNING**

Excessive sealing compound or other foreign matter concentrated under edge of support assembly can cause support to crack during installation.

- **a.** Remove old sealing compound, oil, and foreian material from edge of support and roof.
- **b.** Apply a bear of sealing compound (C131) to faying surface and around mating edge of support assembly (18) and cabin roof (1).
- **c.** Position support assembly (18) on cabin roof (1) and secure as follows:

#### NOTE

Ensure aluminum washers are installed under bolt heads and nuts. After all bolts and washers are installed, incrementally torque bolts (2), and nuts (4), in sequence, 100 TO 140 INCH-POUNDS plus free running torque.

- (1) Install two aft bolts (2) and aluminum washers (3) through suppart assembly (18) and cabin roof (1) and secure with nuts (4).
- (2) Install two bolts (2) with aluminum washers (3) through support assembly (18) and secure into nut plates in cabin roof (1).
- (3) Install two forward bolts (6) with thin aluminum washers (5) under bolt heads through support assembly (18) and cabin roof (1).
- (4) Install two washers (3) and secure with two nuts (4).
- **(5)** Fair out sealant squeeze-out to fill edge voids. Remove any excess.
- **(6)** install anti-torque control bellcrank on bottom of servoactuator. Refer to paragraph 11-116.
- **d.** Install cover assembly (27) on cabin roof with two screws.
- **e.** Install cover assembly (27) and bellcrank (21) on support assembly (18) with bolt (28), washers (26) and nut (25). Torque nut 30 TO 40 INCH-POUNDS and install cotter pin (23).
- **f.** Ensure that floating bearings (35) are installed in outer legs of support assembly (18), then install bellcranks (20 and 24) on support assembly with bolts (19), nuts (22), and cotter pins (23).
- **g.** Connect collective control tube (16) to bellcrank (21) with bolt, washer, nut, and cotter pin (17).
- **h.** Connect cyclic control tubes (15) to bellcranks (20 and 24) with screws, washers, nuts, and cotter pins (14).
  - i. Install servoactuators. Refer to paragraph 7-39.
- **j.** Perform functional test system. Refer to paragraph 7-7.

#### SECTION VI. PRESSURE SWITCH

### 7-48. PRESSURE SWITCH.

**7-49. Description - Pressure Switch.** The hydraulic switch (18, figure 7-1) is installed on the right side of the solenoid valve. When hydraulic pressure is below **300** psig, the pressure switch causes the HYD PRESS warning light in the pedestal to illuminate.

# 7-50. Inspection - Pressure Switch.

- a. Visually inspect pressure switch for damage.
- **b.** Inspect electrical harness for condition and security.

#### 7-51. Removal - Pressure Switch.

a. Remove forward transmission fairing.

- **b.** Turn BAT switch OFF and disconnect external power. Disconnect electrical connector from pressure switch.
- **c.** Place wiping cloth around pressure switch to catch hydraulic fluid. Screw pressure switch out of fitting body and remove. Cap or plug openings.
- **7-52.** Repair or Replacement Pressure Switch. Replace pressure switch if it does not meet inspection requirements.

#### 7-53. Installation - Pressure Switch.

- **a.** Install packing and screw pressure switch into fitting body.
  - b. Install electrical connector.
- **c.** Bleed hydraulic system and test pressure switch. Refer to paragraph 7-7.

# SECTION VII. HYDRAULIC RESERVOIR

#### 7-54. HYDRAULIC RESERVOIR.

**7-55. Description - Hydraulic Reservoir.** The hydraulic reservoir (6, figure 7-1) is mounted on a bracket on the forward side of the transmission above the hydraulic pump. The reservoir has a cover, a filler screen, an internal baffle, vent screen, overflow scupper, drain plug, a fluid low level sight gage, and connections for suction, return and scupper vent line.

# Premaintenance Requirements for Hydraulic Reservoir

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
Special Tools	None
Test Equipment	None

Condition	Requirements
Support Equipment	None
Minimum Personnel Required	One
Consumable Materials (	C39) (C40) (C62) (C96) (C107) (C116) (C125)

### 7-56. Inspection - Hydraulic Reservoir.

- **a.** Inspect reservoir body, cover, sight gage plug, and all fittings for damage and corrosion.
- **b.** Inspect reservoir strainer (41) and vent screen assembly (36) for rust, corrosion, cleanliness, cuts, and breaks. Clean screens using drycleaning solvent (C62) and brush, then air dry. Refer to figure 7-1,
- c. Inspect reservoir for leaks, check reservoir cover (42) for proper locking and security. If normal

thumb force disengages catch, replace cover or catch as required. Check cover latching tab for cracks. If cracked, replace cover.

- **d.** Inspect drain plug (30) for proper locking and security.
- **e.** Inspect sight gage for cracks and discoloration. If required, replace sight gage as follows:
- (1) Remove lockwire securing sight plug (35) to reservoir housing (43). Remove sight plug (35) and packing (27).
- (2) Install packing (27) on sight plug (35). Install sight plug (35) to reservoir housing (43). Torque sight plug to 95-105 INCH-POUNDS. Secure sight plug to reservoir with lockwire (C96).

### 7-57. Removal — Hydraulic Reservoir.

- **a.** Remove forward transmission fairing. (Refer to paragraph 2-39 **A** or 2-40 **C** .) Provide suitable container to catch hydraulic fluid.
- **b.** Remove plug (30, figure 7-1) and packing (31), drain reservoir.
- **c.** Disconnect suction, return, and scupper drain lines from reservoir fittings. Cap or cover open lines and fittings.
- **d.** Remove three bolts, nuts, and washers securing reservoir to mounting bracket and remove reservoir.

# 7-58. Repair or Replacement — Hydraulic Reservoir.

- **a.** Replace damaged or unserviceable gaskets, seals, lock, hinge pin, etc.
- **b.** Corrosion pitting should be removed with sandpaper (C125) or a hand buffing wheel may be used. If depth of the repaired area exceeds **0.020** inch, replace reservoir.
- **c.** Treat repaired magnesium surfaces with chromic acid (C39) or chrome pickle solution (C40), thoroughly rinse with clean water and dry completely. Refer to TM 1-1500-204-23.
  - d. Clean parts with MEK (C107).
- **e.** Exterior surface may be touched up with epoxy polyamide primer (C116).

# 7-59. Installation — Hydraulic Reservoir.

- **a.** Reinstall plug (30, figure 7-1) with packing (31) hand tight plus an additional 1/4 turn and lockwire (C96). Position reservoir on mounting bracket on forward side of transmission. Install three bolts, nuts, and washers.
- **b.** Connect lines to return, suction, and scupper drain fittings of reservoir.
- **c.** Service reservoir in accordance with paragraph 1-
- **d.** Perform system operational check. Refer to paragraph 7-7.

#### SECTION VIII. HYDRAULIC FILTERS

### 7-60. HYDRAULIC FILTERS.

**7-61. Description** — **Hydraulic Filters.** Two hydraulic filters (3 and 4, figure 7-1) are installed in the hydraulic system. The filters are located on the right side of the transmission work deck. Both filters incorporate pop-

out buttons that pop out to indicate an impending filter stoppage on pressure line and impending bypass on return line filter. Only the filter on the return line incorporates a bypass valve. The filter assembly elements are accessible for removal and installation.

# Premaintenance Requirements for Hydraulic Filters

Condition	Requirements
Model	OH-58A/C
Part No. or Serial No.	All
_	,
Special Tools	None
Test Equipment	None
Support Equipment	None
Minimum Personnel Required	One
Consumable Materials	(C62) (C73) (C96)
Special Environmental Conditions	Clean, Dust Free Area

### 7-62. Cleaning - Hydraulic Filters.

- **a.** Place wiping cloth around hydraulic filter assembly to catch hydraulic fluid.
- **b.** Unscrew filter assembly and filter element. Dispose of old packings.

# CAUTION

# Remove filter element to a safe area for cleaning.

- c. Clean element using one of the following:
  - (1) Hydraulic fluid (C73)
  - (2) Drycleaning solvent (C62)
  - (3) 1/2% common liquid detergent and water.
- **d.** Back flush element during cleaning (inside to outside).

### 7-63. Inspection - Hydraulic Filters.

a. Check threads and ports for damage.

#### **NOTE**

While an extended red pop-out button indicates an impending filter stoppage, operation is also affected by low temperature, pressure surges, and excessive vibration.

- **b.** Check to see if red pop-out button is extended. If red pop-out button is extended, proceed as follows:
  - (1) Reset red pop-out button.
- (2) If red pop-out button is extended after the next engine run, remove, clean, inspect, replace, and/or reinstall filter element.
  - c. Inspect filter element for deterioration.

# 7-64. Removal - Hydraulic Filters.

- a. Remove forward transmission fairing.
- **b.** Disconnect hydraulic quick-disconnect at the quick-disconnect on the front of the filter.
- **c.** Disconnect hydraulic line aft of filter housing, and cap lines.
- **d.** Remove two bolts, nuts, and washers securing filter to mounting bracket and remove filter from bracket.
- **e.** Remove lockwire and screw filter assembly from body. Remove filter element.

# **7-65.** Repair or Replacement - Hydraulic Filters. Replace filter assembly, packings, element, or body if inspection requirements are not met. Reset the red pop-out button by pressing down.

# 7-66. Installation - Hydraulic Filters.

- a. Position filter element into filter assembly with new packing in place. Screw assembly into body, torque **20 TO 60 INCH-POUNDS** and secure with lockwire (C96).
- **b.** Position filter on mounting bracket and install two mounting bolts, nuts, and washers.
- **c.** Remove caps from lines and install aft hydraulic lines.
- **d.** Connect hydraulic quick-disconnect at the quick-disconnect on the front of the filter. Bleed hydraulic system. Refer to paragraph 7-7.

### SECTION IX. HYDRAULIC HOSES, LINES, AND QUICK-DISCONNECTS

# 7-67. HYDRAULIC HOSES, LINES, AND QUICK-DISCONNECTS.

**7-68. Description - Hydraulic Hoses, Lines, and Quick-Disconnects.** Hydraulic hoses and lines are utilized to connect the various components of the hydraulic system. The quick-disconnect hoses (1 and 2, figure 7-1) are attached to the two hydraulic filter assemblies (3 and 4) to provide a means of connecting a ground test unit to the hydraulic system.

# 7-69. Inspection - Hydraulic Hoses, Lines, and Quick-Disconnects.

- **a.** Inspect hoses and lines for damage and serviceability.
- **b.** Inspect quick-disconnects for proper locking, cracks, and distortion.

# 7-70. Removal - Hydraulic Hoses, Lines, and Quick-Disconnects.

- **a.** Disconnect each end of hoses and lines from attaching points.
- **b.** Disconnect hose coupling half from coupling half installed in hydraulic filter assembly.
  - c. Remove coupling half from hose.

- **d.** Remove coupling half and packing from filter assembly.
- 7-71. Repair or Replacement Hydraulic Hoses, Lines, and Quick-Disconnects. Replace hoses, lines, and quick-disconnects that fail to meet inspection requirements.

# 7-72. Installation - Hydraulic Hoses, Lines, and Quick-Disconnects.

- a. Remove caps from end fittings of hose or line.
- **b.** Inspect hose or line being installed for thorough cleanliness.
- **c.** Secure each end of hose or line to components from which defective hose or line was previously removed.
  - d. Install hose coupling half on hose fitting.
- **e.** Install new packing and quick-disconnect half in filter assembly.
- **f.** Bleed hydraulic system and fill reservoir as outlined in paragraphs 7-7 and 1-12.
- **g.** Ensure the pins on quick-disconnect are fully engaged.

# SECTION X. HYDRAULIC CHECK VALVE

### 7-73. HYDRAULIC CHECK VALVE.

**7-74. Description - Hydraulic Check Velve.** A check valve (8, figure 7-1) is installed in the hydraulic pump adjacent to the mounting flange. The check valve prevents hydraulic fluid from entering the hydraulic pump through the case drain port.

#### 7-75. Inspection - Hydraulic Check Valve.

**a.** Visually inspect check valve for damage, corrosion or pitting.

b. Check threads for distortion and damage.

### 7-76. Removal - Hydraulic Check Valve.

- **a.** Remove case drain hose (10, figure 7-1) from check valve.
- **b.** Remove check valve (8) and packing from hydraulic pump case drain port. Cap or plug openings.
- **7-77.** Repair or Replacement Hydraulic Check Valve. Replace check valve if inspection requirements are not met.

# 7-78. Installation - Hydraulic Check Valve.

# CAUTION

Check valve (8) can be installed backward. Ensure that arrow on the check valve is pointing away from the hydraulic pump.

- **a.** Install check valve (8, figure 7-1) and new packing in hydraulic pump case drain port adjacent to pump flange, Ensure arrow on check valve is pointing away from pump. Refer to paragraph 7-19.
  - **b.** Connect case drain hose (10) to check valve (8).

### SECTION XI. HYDRAULIC RELIEF VALVE

#### 7-79. HYDRAULIC RELIEF VALVE.

**7-80. Description** — Hydraulic Relief Valve. The hydraulic relief valve (19, figure 7-1) is provided to automatically bypass inlet pressure to return line if inlet line pressure exceeds 670 to 770 psig.

### 7-81. Inspection - Hydraulic Relief Valve.

- a. Inspect relief valve for cracks.
- **b.** Check relief valve (19, figure 7-1) for proper installation.

### 7-82. Test - Hydraulic Relief Valve.

- **a.** Connect hydraulic test stand at quick-disconnect couplings (1 and 2, figure 7-1) located on right hand side of helicopter.
- **b.** Adjust test stand to provide a minimum flow of 1.90 GPM with pressure compensator adjusted to 600 psig.
- **c.** Place hand on relief valve (to detect change in valve) while slowly increasing pressure. Valve must open between 670 to 770 psig.

- **d.** Slowly decrease pressure. Valve must reset at 670 psig.
  - e. Reduce pressure to zero
- **f.** Disconnect hydraulic test stand and reconnect helicopter quick-disconnect couplings.

### 7-83. Removal - Hydraulic Relief Valve.

- **a.** Disconnect hydraulic lines and fittings from relief valve (19, figure 7-1) and discard packing,
- **b.** Unscrew relief valve from fitting and discard packing.
- **7-84.** Repair or Replacement Hydraulic Relief Valve. Replace hydraulic relief valve if inspection requirements are not met,

### 7-85. Installation - Hydraulic Relief Valve.

- a. Screw relief valve (19, figure 7-1) and new packing into fitting.
  - **b.** Connect hydraulic lines.
- **c.** Functionally test hydraulic relief valve. Refer to paragraph 7-82.

#### CHAPTER 8

#### INSTRUMENT SYSTEMS

### 8-1. INSTRUMENT MAINTENANCE.

**8-2. General.** This chapter provides the instructions and information required by maintenance personnel to perform maintenance on OH-58 series helicopter instruments. All flight, navigation, engine, and miscellaneous instruments are mounted in instrument panel attached to console. Power loading charts and detailed system wiring diagrams are contained in Appendix F. Maintenance acivities shall request assistance for electrical system repair in accordance with maintenance allocation chart Appendix B.

# WARNING

Self-luminous dials may contain radioactive materials. If such an instrument is broken or becomes unsealed, avoid personal contact. Use forceps or gloves made of rubber or polyethylene to pick up contaminated material. Place material and gloves in a plastic bag. Seal bag and dispose of it as radioctive waste in accordance with AR755-15 and TM3-261 (Refer to TB55-1500-314-25). Repair procedures shall conform to requirements in AR700-52.

# NOTE

For instrument piping installation refer to figure 8-1; additional illustrations, pertaining to instrument location and marking, circuit breaker location, and control infromation are contained in TM 55-1520-228-10 and TM 55-6600-200-20 for marking instruments and interpretation of markings. For instrument configurations, refer to figure 8-3.

#### NOTE

Throughout this chapter, when performing operational checks, use auxiliary power unit sat to 28 Vdc (±0.5) volt unless otherwise specified.

The following steps list general procedures to follow in removing. inspecting, cleaning, and installing instruments mounted on the pilot and copilot instrument panel.

8-3. Cleaning. Clean panel and instrument cover glasses with a suitable soft, lint-free cloth.

### 8-4. Inspection.

- **a.** Inspect for loose, cracked, or broken cover glasses.
  - **b.** Inspect for proper and secure mounting.

Inspect range markings and decals for completeness and legibility. Refer to TM 55-1520-228-10.

**8-5. Removal - Instruments.** Remove any instrument from panel by following general procedure.



Before removing any instrument from the instrument panel, ensure that BAT switch is OFF, and that external power is disconnected from the helicopter.

- **a.** Remove mounting screws. Remove instrument.
- **b.** Disconnect electrical leads or instrument piping from back of instrument. Necessary access may be through side panels and console.

**c.** Protect ends of electrical leads with electrical tape (C137) and cap open piping and openings on instrument.

# **CAUTION**

To prevent static charges from damaging the turbine outlet temperature indicator, install a piece of copper wire across the instrument terminals. Remove the wire before reinstallation into the panel.

**8-6.** Repair or Replacement — Instruments. Replace any missing or damaged limits or index markings on cover glasses of instruments. Also replace any required decals which are not clearly legible. Replace any instrument if cover glass is loose or broken, or when found to be unserviceable. Replace instruments if range markings are not legible.

#### NOTE

When range markings are illegible and replacement instruments are not readily available, range markings may be applied in accordance with TM 55-1520-228-10 using tape (C142) and protected with a clear cost of lacquer (C90). Taps shall not be used to change calibration or range of instruments.

**8-7. Installation** — **instruments.** Install any instrument in panel by the following general procedures:

# **WARNING**

Before installing any instrument on the instrument panel, ensure that BAT switch if OFF, and that external power is disconnected from the helicopter.

- **a.** Check instrument for correct markings on cover glass.
- **b.** Remove protective caps or covers as necessary. Connect electrical leads and instrument piping.
- **c.** Use silicone lubricant (C104) on threads of nylon fittings.

d. Torque coupling nuts finger tight.

# CAUTION

If a copper wire was installed between terminals during removal of TOT indicator, remove the wire at this time.

Do not tighten mounting screws more than necessary to hold instrument as excessive tension may deform instrument case.

**e.** Position instrument in panel. Install mounting screws.

#### NOTE

When any instrument is replaced or reinstalled in the pitot-static system, a functional check will be performed in accordance with paragraph 8-155.

- **f.** Perform functional test after installation of instruments.
- 8-8. System Bleeding Engine Oil Pressure Indicator and Torque-Meter Indicator.
- **a.** Start and operate the engine. Refer to TM 55-1520-228-10.
- **b.** Wrap cloth around fitting at back of the indicator.
- **c.** Loosen, but do not remove the tube connector from the back of indicator.
- **d.** Allow engine oil to drip into cloth until a steady flow is observed.
- **e.** Tighten the connector at back of indicator and wipe up any spilled oil.
  - **f.** Shut down engine.

Check the engine oil level and replenish if necessary (refer to Chapter 1).

**8-9. Testing** — **Instruments.** Perform operational check of the repaired or replaced instrument. Refer to TM 55-1520-228-10.

**8-10. Description** - **Instrument Panel.** The instrument panel is mounted on the respective console and contains all instruments for the pilot and copilot The instrument panel is mounted by

mounting screws located around edge of panel. The instrument panel is rigidly mounted and no adjustments are required.

# SECTION I. ENGINE, ROTOR, AND TRANSMISSION INSTRUMENTS

# 8-11. ENGINE OIL PRESSURE INDICATOR.

- 8-12. Description Engine Oil Pressure Indicator. A The engine oil pressure indicator precalibrated in psi against a standard, is located in instrument cluster on instrument panel, and is included in piping circuit from engine oil pressure disconnects. No installation calibration is required.
- 8-13. Description Engine Oil Pressure Indicator. The indicator is part of a dual purpose indicator. The right side is for engine oil pressure and the left side is for engine oil temperature. The indicator is located on the instrument panel, precalibrated in psi against a standard, and is included in piping circuit from engine oil pressure disconnects. No installation calibration is required.
- **8-14.** Clearaing Engine Oil Pressure Indicator. Clean the indicator in accordance with paragraph 8-3.
- **8-15.** Inspection Engine Oil pressure Indicator. inspect the indicator in accordance with paragraph 8-4.

### 8-16. Testing - Engine Oil Pressure Indicator.

- **a.** Disconnect pressure gage line from engine port.
- **b.** Connect a variable pressure (0 to 150 psi) gage (MP-1 or equivalent) (T6) to the pressure gage line.
- **c.** Gradually apply pressure until applied pressure is 130 psi.
- **d.** The engine oil pressure indicator shall indicate 130 (red line) ±4.5 psi.
- **e.** Replace any indicator that does not meet the above reading.

- **f.** Disconnect pressure gage line from tester and reconnect line to engine port.
- **8-17.** Troubleshooting Engine Oil Pressure Indicator. Troubleshoot the indicator in accordance with table 8-1

#### **NOTE**

Before using table 8-1, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 8-1, notify the next higher level of maintenance.

- **8-18.** Removal Engine Oil Pressure Indicator. Remove the indicator from the instrument panel in accordance with paragraph 8-5.
- **8-19.** Repair or Replacement Engine Oil Pressure Indicator. Repair or replace the indicator in accordance with paragraph 8-6.
- **8-20.** Installation Engine Oil Pressure Indicator. Install the indicator into the instrument panel in accordance with paragraph 8-7.

#### 8-21. TORQUEMETER INDICATOR.

- **8-22.** Description Torquemeter Indicator. The engine torquemeter located in instrument panel, is precalibrated in psi against a standard. This instrument is included in piping circuit to lower firewall disconnect which continues to engine accessory drive gearbox (forward side of engine). No calibration of the torquemeter is required when installed.
- **8-23.** Cleaning Torquemeter Indicator. Clean the indicator in accordance with paragraph 8-3.

# Table 8-1. Troubleshooting — Engine Oil Pressure Indicator and Torquemeter Indicator

#### CONDITION

### **TEST OR INSPECTION**

#### CORRECTIVE ACTION

- 1. Low reading on pressure indicator.
  - STEP 1. Obstructed line and/or fitting. Refer to paragraph 8-4.

# Replace or clean line and/or fitting. Refer to paragraph 8-8.

2. Inaccurate or sticking pressure indicator.

STEP 1. Defective indicator.

### Replace indicator. Refer to paragraph 8-7.

3. Sluggish or fluctuating reading.

STEP 1. Sludge in pressure line or a twist or sharp bend in the line.

Bleed line or replace hose. Refer to paragraph 8-8.

- **8-24.** Inspection Torquemeter Indicator. Inspect the indicator in accordance with paragraph 8-4.
- 8-25. Testing Torquemeter Indicator.
- **a.** Disconnect pressure gage line from engine inlet.
- **b.** Connect pressure hand gun to the pressure gage line.
- c. Using hand gun appiy pressure and make several random checks through the full range of the gage. Particular attention should be directed to the red line areas. All readings should be with ±2 psi for the A, ±1% for the

	Tester Pressure (psi)	Indicator P/N	Reading
Α	100	206-070-268-5	<b>100 (±2)</b> psi
С	74	206-075-711-1	100 (±1)% (Red Sawtooth)

- **d.** Replace any indicator that does not meet the above reading.
- **e.** Disconnect pressure gage line from hand gun and reconnect iine to engine inlet.
- **8-26.** Troubleshooting Torquemeter Indicator. Troubleshooting procedures for the torquemeter indicator are the same as for the engine oil pressure indicator. Refer to table 8-1.
- **8-27.** Removal Torquemeter Indicator. Remove the indicator from the instrument panei in accordance with paragraph 8-5.
- **8-28.** Repair or Replacement Torquemeter indicator. Repair or replace indicator in accordance with paragraph 8-6.
- **8-29. Installation Toquemeter Indicator.** Install the indicator in the instrument panel in accordance with paragraph 8-7.

#### 8-30. TACHOMETER INDICATING SYSTEM.

#### 8-31. **Description - Tachometer Indicating System.**

The rotary self generating tachometer indicating system includes gas producer tachometer generator (G4), gas producer tachometer indicator (M3), and interconnecting wiring; power turbine tachometer generator (G3), power turbine tachometer indicator (part of M1) interconnecting wiring; rotor tachometer generator (G2); and rotor tachometer indicator (part of M1) and interconnecting wire. Refer to figure F-5.

**Description Dual Tachometer Indicating System** C . The tachometer indicating system is protected by the DUAL TACH and GAS PROD TACH circuit breakers and powered by 28Vdc. The system includes gas producer tachometer generator (G4), gas producer tachometer indicator (M3), GAS PROD TACH circuit breaker (CB18), and interconnecting wiring; power turbine tachometer generator (G3), ENGINE-ROTOR tachometer indicator (MI), rotor tachometer generator (G2), DUAL TACH circuit breaker (CB17), and interconnecting wiring, (refer to figure F-25).

#### Testing Dual Tachometer Indicating System. 8-33.

#### Premaintenance Requirements for **Testing Tachometer Indicating System**

Condition	Requirements
Model	OH-58A/OH-58C
Part No. or Serial No	All
Special Tools None	
Test Equipment	TTU-27E
Support Equipment	None
Minimum Personnel Required	Two
Consumable Materials	(C31) (C118) (C62) (C77) (C96) (C103) (C137)
Special Environmental Conditions	None

- Dual Tachometer Indicator (Rotor and N2 Power Turbine Tach Generator). Both rotor and free turbine tachometer sections of the dual tachometer shall be checked in accordance with the following procedure.
- (1) Remove plug (P6) from rotor tachometer generator and connect to matching receptacle on the test stand.
  - (2) Close the DUAL TACH circuit breaker C .



- (3) Energize tach generator in test stand. Check that rotor tach pointer, R, on the rotor and turbine indica tor reads upscale at the approximate ± 1 percent rpm that the test stand tach generator is turning.
- (4) Remove plug (P6) from test stand and reconnect to the rotor tach generator on the transmission. Check that connector is properly mated, tight, and secure.
- (5) Remove plug (P7) from N2 power turbine tach generator and connect to matching receptacle on the test stand. Energize tach generator in the test stand. Check that the turbine tach pointer, T, on the rotor and turbine rpm indicator reads upscale and reads the approximate ± 1 percent rpm at which the test stand tach generator is turning.
- (6) Remove plug (P7) from the test stand and reconnect to the matching receptacle on the N2 Power Turbine Tach Generator. Check that connector is properly mated, tight, and secure.

#### NOTE

The anodize coating was not completely removed from end cop and housing of a number of tachometer generators before rolling lip over end cap. This may cause Intermittent grounding of C phase that results In an erratic Indication.

This condition can be corrected in the field, without removing tachometer generator from engine, by using an automatic center punch to stake lip to end cap In at least three equally spaced points and then protecting Impact points with primer.

**8-34.** Troubleshooting - Dual Tachometer Indicating System. Refer to table 8-2 for probable causes and corrective action in troubleshooting the dual tachometer indicating system.

### **NOTE**

Before using table 8-2, ensure all normal operational checks have been

performed. If a malfunction exists which is not listed in table 8-2, notify the next higher level of maintenance.

#### NOTE

For testing refer to paragraphs 8-33 and 8-48.

# Table 8-2. Troubleshooting - Dual Tachometer Indicating System

#### CONDITION

**TEST OR INSPECTION** 

#### **CORRECTIVE ACTION**

1. Excessive scale error.

STEP 1. Weak magnet in tachometer-generator.

# Replace tachometer-generator.

2. Pointer moves backward.

STEP 1. Leads reversed at generator.

### Properly connect leads at generator.

3. No reading on indicator.

STEP 1. Open or short circuit.

# Repair or replace faulty wiring.

4. High or low reading on indicator, either constant or intermittent.

STEP 1. Poor connections at indicator or generator.

#### Clean and tighten connections.

STEP 2. Intermittent ground at generator housing

Ensure electrical continuity exists between end cap and housing.

- 8-35. DUAL TACHOMETER INDICATOR.
- **8-36. Description Tachometer Indicator**. The tachometer indicator is located on the center section of the instrument panel and is a component of the dual tachometer indicating system. The instrument indicator dual inputs from the system generators located on the engine and transmission.
- **8-37.** Cleaning Tachometer Indicator. Clean the indicator in accordance with paragraph 8-3.
- **8-38. Inspection Tachometer Indicator**. Inspect the indicator in accordance with paragraph 8-4.
- **8-39. Testing Tachometer Indicator**. Test the indicator using tachometer tester or equivalent in accordance with paragraph 8-33.
- **8-40.** Troubleshooting Tachometer Indicator. If the indicator does not meet test performance standards, replace the indicator.
- **8-41.** Removal Tachometer Indicator. Refer to paragraph 8-5.
- **8-42.** Repair or Replacement Tachometer Indicator. Refer to paragraph 8-6.

#### **CAUTION**

When installing dual tachometer assure electrical cable terminals are properly Installed to either engine or rotor terminals on Instrument. Terminals are Identical and may be easily reversed.

**8-43. Installation Tachometer Indicator**. Refer to paragraph 8-7.

### NOTE

Terminals without self-locking cannon plugs require lockwire. Refer to TM 55-1500-323-24.

- 8-44. ROTOR TACHOMETER GENERATOR.
- **8-45. Description Rotor Tachometer Generator.** The rotor tachometer generator which transmits rotor rpm is located on the forward left side of the transmission and is connected to the dual tachometer indicator on the instrument panel. The rotor tachometer generator is a component of the dual tachometer indicating system.
- 8-46. Cleaning Rotor Tachometer Generator.

a. Remove moisture and loose dirt with a dean, soft cloth.

### WARNING

Drycleaning solvent is flammable and its fumes are toxic. Provide adequate ventilation. Do not use near flame.

- b. Remove grease, fungus, and ground-in dirt with a clean, lint-free cloth dampened with drycleaning solvent (C62).
- c. Remove dirt from electrical connectors with a bristle brush (C31).

#### 8-47. Inspection Rotor Tachometer Generator.

- a. Inspect tachometer generator case for cracks, excessive wear, or any visible damage.
- b. Check connector for damaged or bent pins and cracked inserts.
- c. Check that rotor turns freely and there is no visible indication of excessive wear to bearings.

# 8-48. Testing Rotor Tachometer Generator A

- a. Check interconnecting wiring between the Rotor Tachometer Generator and the Tachometer indicator. Refer to figure F-5 and proceed as follows:
- (1) Check continuity of wiring between rotor tachometer generator connector plug (P6) and tachometer indicator connector plug (P2), pin A to A and pin B to B respectively.
- (2) The ohmmeter shall read less than 1 ohm in each of the readings.
  - b. Place ohmmeter leads accordingly:
- (1) Between pins A and B on tachometer generator connector pins.
  - (2) Between pin A and tachometer generator case.
  - (3) Between pin B and tachometer generator case.
- c. There shall be no evidence of discontinuity. The resistance between pins or between a pin and the case shall be less than fifty (50) ohms. The measurements shall be within two (2) ohms of each other.
- d. Rotate the tachometer rotor by hand to determine that rotor rotates freely.

Change 24 8-7

#### TM 55-1520-228-23

- **8-49. Testing Rotor Tachometer Generator C**. Follow the same general procedures given in paragraph 8-48 and proceed as follows:
- a. Refer to figure F-25 and check continuity of wiring between generator connector plug (P6) and indicator connector plug (P55), pin A to pin C and from ground on generator to pin D respectively.
- b. Check winding in generator by placing ohmmeter leads across pin A and ground on generator. Refer to figure F-25.

#### **NOTE**

If generator does not meet performance standards listed in steps b, c, and d, replace tachometer

#### 8-50. Removal Rotor Tachometer Generator.

- a. Disconnect electrical connector and protect end with plastic cap.
- b. Remove hydraulic pump. Refer to paragraph 7-13.
- c. Remove nuts (9) and washers (8) from mounting studs. Remove generator (7) and gasket (20). Refer to figure 6-10.
- **8-51.** Repair or Replacement Rotor Tachometer Generator. Replace tachometer if inspection and test requirements are not met. Refer to paragraphs 8-47, 8-48, and 8-49.

# 8-52. Installation Rotor Tachometer Generator.

a. Thoroughly clean the generator drive and mating transmission oil pump flange. Apply a film of grease (C77) to the drives.

### 8-8 Change 24

- c. Install hydraulic pump. Refer to paragraph 7-19.
- d. Remove plastic cap from electrical plug and connector to generator.

### 8-53. POWER TURBINE TACHOMETER GENERATOR.

- **8-54. Description Power Turbine Tachometer Generator**. The power turbine tachometer generator (39, figure 4-1) which transmits engine output shaft rpm is mounted on the forward left side of the power and accessory gearbox and connected to the dual tachometer indicator on the instrument panel. The power turbine tachometer generator is a component of the dual tachometer indicating system.
- **8-55.** Cleaning Power Turbine Tachometer Generator. Refer to paragraph 8-46.
- **8-56. Inspection Power Turbine Tachometer Generator.** Refer to paragraph 8-47.
- **8-57. Testing Power Turbine Tachometer Generator**A Follow the same general procedures given in paragraph 8-48. Refer to figure F-5 and proceed as follows:
- a. Check continuity of wiring between generator connector plug (P7) and indicator connector plug (P1), pin B to pin A and pin A to pin B respectively.
  - b. Place ohmmeter leads accordingly:
- (1) Between pins A and B on tachometer generator connector pins.
  - (2) Between pin A and tachometer generator case.
  - (3) Between pin B and tachometer generator case.

# 8-59. Removal - Power Turbine Tachometer Generator.

- **a.** Disconnect electrical connector; protect connector with plastic cap.
- **b.** Remove four nuts and washers from mounting studs and remove generator (39, figure 4-1) and gasket from accessory pad.
- **8-60.** Repair or Replecement Power Turbine Techometer Generator. Replace tachometer if inspection and/or test requirements are not met. Refer to paragraphs 8-47 and 8-48.

# 8-61. Installation - Power Turbine Tachometer Generator.

- **e.** Thoroughly clean the generator drive and mating engine drive. Apply a film of grease (C77) to the drives.
- **b.** Position gasket and generator on accessory pad studs and secure with four washers and nuts.
- **c.** Remove plastic cap from electrical plug and connect to generator.

# 8-62. GAS PRODUCER TACHOMETER INDICATOR.

- **8-63. Description Gas Producer Tachometer Indicator.** The indicator is a component of the tachometer indicating system. The indicator is used for indicating inputs from the gas producer tachometer generator mounted on the forward right side of the power and accessory gearbox.
- **8-64.** Cleaning Gas Producer Tachometer Indicator. Clean the indicator in accordance with paragraph 8-3.
- 8-65. Inspection Gas Producer Tachometer Indicator. Refer to paragraph 8-4.
- 8-66. Testing Gas Producer Tachometer Indicator (N1). With engine running, monitor percent rpm indicator of exhaust gas temperature tester (T3) and compare with N 1 tachometer indicator installed in the instrument panel. When the N1 tachometer generator is rotating at 4120 rpm A, 4198 rpm C, both tachometer indicators should indicate 100%. EGT test rpm indicator and N1 indicator should correspond with 3%.

**8-67.** Troubleshooting - Gas Producer Tachometer Indicator. Refer to table 8-3 for probable causes and corrective action in troubleshooting gas producer tachometer.

#### NOTE


Before using table 8-3, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 8-3, notify the next higher level of maintenance.

- 8-68. Removal Gas Producer Tachometer Indicator. Refer to paragraph 8-5.
- 8-69. Repair or Replacement Gas Producer Tachometer Indicator. Refer to paragraph 8-6.

#### **NOTE**

Lockwire is required for the terminal. Refer to TM 66-1500-323-26.

- 8-70. Installation Gas Producer Tachometer Indicator. Refer to paragraph 8-7.
- 8-71. GAS PRODUCER TACHOMETER GENERATOR.
- **8-72. Description Gas Producer Tachometer Generator.** The gas producer tachometer generator is mounted on the forward right side of the power and accessory gearbox (39, figure 4-1). The gas producer tachometer is a component of the tachometer indicating system.
- 8-73. Cleaning Gas Producer Tachometer Generator.
- **a.** Remove moisture and loose dirt with a clean, soft cloth.



Drycleaning solvent is flammable and its fumes are toxic. Provide adequate ventilation. Do not use near a flame.

**b.** Remove grease, fungus and ground-in dirt with a clean, lint-free cloth dampened with drycleaning solvent (C62).

# Table 8-3. Troubleshooting — Gas Producer Tachometer

#### CONDITION

#### TEST OR INSPECTION

#### **CORRECTIVE ACTIVE**

- 1. Gas producer tachometer fails to respond.
  - STEP 1. Determine if tach generator is defective by substitution of known good tach generator. Check tach generator IAW 8-75. b. A Model and 8-76. b. C Model. Test IAW paragraph 8-66.

### Replace tach generator if defective. Refer to paragraphs 8-77 and 8-79.

- STEP 2. Determine if tachometer is defective by substitution of known good tachometer and test IAW paragraph 8-66.
- STEP 3. Determine continuity of wiring between tach generator and indicator. Check continuity of wiring IAW paragraph 8-75a. A model and 8-76a Model.

## Replace tachometer if defective. Refer to paragraph 8-7.

- 2. Gas producer tachometer indicates incorrectly.
  - STEP 1. Determine if tach generator is defective by substitution of known good tach generator. Check tach generator IAW 8-75.b A Modei and 8-76. b C Model. Test IAW paragraph 8-66.

# Replace generator if defective. Refer to paragraphs 8-77 and 8-79.

STEP 2. Determine if tachometer is defective by substitution of known good tachometer and test IAW paragraph 8-66.

# Replace tachometer if defective. Refer to paragraph 8-7.

- STEP 3. Determine continuity of wiring between tach generator and indicator. Check continuity of wiring IAW paragraph 8-75-a Model and 8-76a Model.
- 3. Gas producer tachometer indicates backwards.
  - STEP 1. Check if wires are reversed at pins of tachometer generator plug. Refer to paragraph 8-74.

### Remove piug and reverse wires. Refer to paragraph 8-74.

- **c.** Remove dirt from electrical connectors with a bristle brush (C31).
- 8-74. Inspection Gas Producer Tachometer Generator.
- **a.** Inspect tachometer generator case for cracks, excessive wear, or any visible damage.
- **b.** Check connector for damaged or bent pins and cracked inserts.

- **c.** Check that rotor turns freely and there is not visible indication of excessive wear to bearings.
- **8-75.** Testing Gas Producer Tachometer Generator A Follow the same general procedures given in paragraph 8-48 and proceed as follows:
- **a.** Refer to figure F-5 and check continuity of wiring between this tachometer generator connector piug (P10) and the indicator connector plug (P3), pin A to pin B and pin B to pin A respectively.
- **b.** Check winding in generator by placing ohmmeter leads across pins A and B in the generator.

### 8-10 Change 18

- **8-76.** Testing Gas Producer Tachometer Generator C . Follow the same general procedures given in paragraph 8-48 and proceed as follows:
- **a.** Refer to figure F-25 and check continuity of wiring between generator connector plug (P10) and the gas producer tachometer indicator connector plug (P3), pin A to pin A, and from ground on generator to pin B on indicator connector plug.
- **b.** Check winding in the generator by placing ohmmeter leads across pin A in generator and ground on generator.

# 8-77. Removal — Gas Producer Tachometer Generator.

- **a.** Disconnect electrical connector and protect end with plastic cap.
- **b.** Remove four nuts and washers from mounting studs and remove generator and gasket from accessory pad. Remove ground wire from stud and protect terminal.
- **8-78.** Repair or Replacement Gas Producer Tachometer Generator. Replace tachometer generator if inspection and test requirements are not met.

# 8-79. Installation — Gas Producer Tachometer Generator.

- **a.** Thoroughly clean the generator drive and mating engine drive. Apply a film of grease (C77) to the drives.
- **b.** Position gasket and generator on accessory pad studs and secure with four washers and nuts. Install ground wires on studs.
- **c.** Remove plastic cap from electrical plug and connect to generator.
- **d.** Test gas producer tachometer in accordance with paragraph 8-66.

# 8-80. SENSOR, RPM.

**8-81. Description** — **SENSOR**, **RPM**. The RPM sensors located on equipment shelf right side, just aft of the engine out audio generator, receives and interprets output signals from the N1 and rotor tachometer generators. Should the gas producer (N1) fall below 55% (±3)%, one side of the RPM sensor serves to complete circuits to the engine out audio generator and

engine out warning light simultaneously to alert the pilot of engine failure. (Should the rotor RPM, fall below 335 RPM plus or minus 5 RPM A , 95% plus or minus 1.4% C , the other side of the RPM sensor serves to complete circuits to the rotor rpm warning light and audio generator simultaneously to alert the pilot of low rotor rpm). An engine out warning switch (S70) enables the pilot to prevent audio warning in the headset while helicopter is in a nonflight status by placing collective in down position.

**8-82.** Cleaning — SENSOR, RPM. Clean the sensor case with a suitable lint-free cloth.

# 8-83. Inspection — SENSOR, RPM.

- **a.** Visually inspect sensor case for dents or physical damage that could impair normal efficient operation of the unit.
- **b.** Inspect sensor receptacle for bent or broken contacts, pins, cracked insert, or damage to connector threads.
- **c.** Replace sensor if it fails to meet inspection requirements.
- **8-84. Testing SENSORS**, **RPM**. Refer to figure F-12 and proceed as follows:
- **a.** To test engine out RPM sensor. Disconnect rotor sensor.
  - **b.** Start engine. Refer to TM 55-1520-228-10.
- **c.** Raise collective approximately 1 inch. Check to see that the light and audio go out at 55 (±3)% when rpm is increased and illuminates 55 (±3)% when rpm is decreased.
  - d. Shut down engine.
- **e.** To test rotor RPM sensor: Disconnect engine RPM sensor, reconnect RPM sensor.
  - f. Start engine.
- g. Raise collective 1 inch. Check to see that the light and audio go out at 335 ( $\pm$ 5) rpmA , 95% ( $\pm$ 1.4%) C as rpm is decreased.
  - **h.** Adjust rotor RPM sensor as required.
  - i. Shut down engine.

i. Reconnect engine RPM sensor,

#### 8-85. Removal - SENSOR, RPM.

- a. Check that all electrical power is OFF.
- **b.** Disconnect electrical connector and cover plug and receptacle for protection using cap or with electrical tape (C137).
- **c.** Remove mounting screws and washers and lift sensor from equipment shelf.
- **8-86.** Repair or Replacement SENSOR, RPM. Replace the sensor if it fails to meet inspection or test requirements.

#### 8-87. Installation - SENSOR, RPM.

#### NOTE

Determine that power is disconnected from helicopter.

- **a.** Position sensor on equipment shelf and install mounting screws and washers.
- **b.** Remove covers from sensor plug and receptacle. Engage and secure connectors.
  - c. Apply power to helicopter.
- **d.** If operational check fails to give proper response, perform test procedures in paragraph 8-84.

# 8-88. ENGINE OUT WARNING SWITCH.

**8-89. Description - Engine Out Warning Switch.** The engine out warning switch disconnects audio warning from the pilot headset when the helicopter is in a nonflight status.

#### NOTE

Audio warning input to the headset may be disconnected by placing the collective stick in down position.

### 8-90. Inspection - Engine Out Warning Switch,

#### NOTE

Determine that power is disconnected from helicopter before performing maintenance procedural on switch.

- **a.** Remove copilot seat and seat panel. Refer to paragraphs 2-79 and 2-86.
- **b.** Visually inspect switch for physical damage that could impair normal operation; check switch for security.
- **c.** Check spring action of the switch by repositioning the switch.

### 8-91. Removal - Engine Out Warning Switch.

- **a.** Remove copilot seat and seat panel. Refer to paragraphs 2-86 and 2-79.
- **b.** Remove two screws attaching engine out warning switch to mounting bracket beneath collective jackshaft in void beneath copilot seat.
  - c. Disconnect electrical wires and remove switch.
- **8-92.** Repair or Replacement Engine Out Warning Switch. Replace switch if it fails to meet inspection requirements.

### 8-93. Installation - Engine Out Warning Switch.

- **a.** Attach electrical wires and install switch with two screws to bottom of mounting bracket beneath collective jackshaft in void beneath copilot seat.
- **b.** Loosen clamp and striker arm on jackshaft and position so that when collective is full down, striker arm depresses engine out warning switch.
- c. Check engine OUT warning switch with battery on. Audio should be heard through pilot/copilot headset when collective is raised approximately 1 inch.
- **d.** Install copilot seat pan and seat. Refer to paragraph 2-88.

# 8-94. ENGINE OIL TEMPERATURE SYSTEM.

**8-96.** Troubleshooting - Engine Oil Temperature System. Troubleshoot the engine oil temperature system in accordance with table 8-4.

#### **NOTE**

**8-95. Description - Engine Oil Temperature System.** The temperature system includes engine oil temperature indicator, engine oil temperature bulb, and interconnecting wiring.

Before using table 8-4, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 8-4, notify the next higher level of maintenance.

Table 8-4. Troubleshooting — Engine Oil Temperature System

#### CONDITION

**TEST OR INSPECTION** 

#### **CORRECTIVE ACTION**

1. Indicator fails to operate.

STEP 1. Check for open or defective instrument cluster A or engine oil temperature C circuit breaker.

Replace faulty circuit breaker.

STEP 2. Check for faulty or loose connection. Refer to figure F-7 A or figure F-27 C.

Replace faulty wiring and tighten connections. Refer to figure F-7 A or figure F-27 C.

STEP 3. Check for defective temperature bulb. Refer to paragraph 8-109.

Replace bulb. Refer to paragraph 8-113.

STEP 4. Check for defective indicator. Refer to paragraph 8-101.

Replace indicator. Refer to paragraph 8-7.

# 8-97. ENGINE OIL TEMPERATURE INDICATOR.

8-98. Description - Engine Oil Temperature Indicator. A The indicator is located on the instrument panel as a part of the instrument cluster,

**8-99. Description - Engine Oil Temperature Indicator.** The indicator is part of a dual purpose indicator. The right side is for engine oil pressure and the left side is for engine oil temperature. The indicator is located on the instrument panel.

**8-100. Cleaning - Engine Oil Temperature Indicator.** Refer to paragraph 8-3.

**8-101.** Inspection - Engine Oil Temperature Indicator. Refer to paragraph 8-4.

**8-102. Testing - Engine Oil Temperature Indicator.** Check that engine oil temperature indicator reads approximately ambient temperature provided that helicopter has not been previously ground run or moved from a different temperature location (hangar to ramp, etc.)

- **8-103.** Removal Engine Oil Temperature Indicator. Refer to paragraph 8-5.
- **8-104.** Repair or Replacement Engine Oil Temperature Indicator. Refer to paragraph 8-6.
- **8-105.** Installation Engine Oil Temperature Indicator, Refer to paragraph 8-7.

# 8-106. ENGINE OIL TEMPERATURE TRANSMITTER BULB.

**8-107. Description - Engine Oil Temperature Transmitter Bulb.** The engine oil temperature bulb, installed in the outlet fitting of the engine oil tank is a resistance type thermobulb which monitors engine oil temperature and transmits varying voltage signals to engine oil temperature portion of indicator. The resistance element of the bulb is hermetically sealed in a metal well.

# 8-108. Cleaning - Engine Oil Temperature Transmitter Bulb.

**a.** Remove moisture and loose dirt with a clean, soft cloth.

# WARNING

Drycleaning solvent is flammable and the fumes are toxic. Provide adequate ventilation. Do not use near a flame.

- **b.** Remove oil, grease, fungus, and ground-in dirt with a clean, lint-free cloth dampened with drycleaning solvent (C62).
- **c.** Remove dirt from electrical connectors with a bristle brush (C31).

# 8-109. Inspection - Engine Oil Temperature Transmitter Bulb.

- **a.** Inspect temperature bulb for cracks, leaks, security, and proper mounting.
- **b.** Inspect electrical connector for damaged or bent pins and cracked inserts.

# 8-110. Removal - Engine Oil Temperature Transmitter Bulb.

a. Cut lockwire and disconnect electrical connector.

- **b.** Remove lockwire and unscrew temperature bulb from oil manifold.
  - c. Remove gasket.

# 8-111. Repair - Engine Oil Temperature Transmitter Bulb.

- a. Repair damaged electrical connectors.
- **b.** Replace damaged or worn gasket.
- **c.** Replace temperature bulb if cracked or damaged,

# 8-112. Functional Test - Engine Oil Temperature Bulb - Bench (AVIM).

- a. Resistance check.
- (1) Remove oil temperature bulb to be checked and allow sufficient time to adjust to ambient temperature.
- (2) With Wheat stone bridge, measure resistance of temperature bulb between pin A and B. Ambient temperature test points and tolerances are shown in table 8-5.
- **b.** Insulation Leakage Test. With temperature bulb subjected to a 100 volt potential between any electrical pin and bulb housing, the minimum resistance shall be 5 megohms.
  - c. Reinstall temperature bulb.

# 8-113. Installation - Engine Oil Temperature Transmitter Bulb.

Coat threads and gasket with lubricating oil (C103) when installing gasket on temperature bulb.

- **b.** Install temperature bulb and gasket in manifold. Lockwire (C96).
  - c. Install electrical connector.
- **d.** Lockwire (C96) adjacent bolt head on manifold to electrical connector.

Table 8-5. Resistance Bulbs

BULB TYPE — MS28034-3

AMBIENT TEMPERATURE TEST POINT DEGREES	RESISTANCE (OHMS)	RESISTANCE TOLERANCE (OHMS)
-20° Celsius (-4°F)	83.77	±0.4
-10° Celsius(14°F)	87.04	±0.4
0° Celsius (32°F)	90.36	±0.4
+10° Celsius (50°F)	93.60	±0.4
+20° Celsius (68°F)	97.31	±0.4
+30° Celsius (86°F)	100.91	±0.4
+40° Celsius (104°F)	104.60	±0.4

# **8-114.** Troubleshooting - Engine Oil Temperature Transmitter Bulb. Refer to table 8-4 and paragraph 6-112.

# 8-115. TURBINE OUTLET TEMPERATURE SYSTEM A.

**8-116. Description - Turbine Outlet Temperature System.** The turbine outlet temperature system is thermocouple self generating and consists of four bayonet type thermocouples mounted in turbine outlet, one turbine outlet temperature resistor, one turbine outlet temperature indicator, one terminal board and interconnecting wiring. Refer to figure F-7.

# 8-117. Teating - Turbine Outlet Temperature System.

# Premaintenance Requirements for Testing Turbine Outlet Temperature System

Condition	Requirements
Model	OH-58A
Part No. or Serial No.	All
Special Tools	None
Test Equipment	(T3) (T2) (T54) (T55) (T56)
Support Equipment	General Mechanics Tool Box

Condition	Requirements
Minimum Personnel Required	Two
Consumable Materials	(C120) (C31) (C62) (C95)
Special Environmental Conditions	Stabilize TOT for one hour

- **a.** Sequential testing. Accomplish the following sequential steps to isolate and correct the source or cause of defective TOT indicating system.
- (1) Check all electrical connections for security of attachment and absence of corrosion. If no problem is found, proceed,

#### **CAUTION**

When turbine outlet temperature indicator is removed, the instrument terminals shall be short circuited with a piece of copper wire to prevent induced electrical damage. Remove wire before reinstallation.

(2) Remove TOT indicator from panel and check indicator accuracy at 693°C (beginning of yellow arc), 749°C (red line), and 927°C (red dot) using Jet-Cal analyzer (refer to TM 55-4920-244-14 or TM 55-4920401-13&P). Indicator shall read within ±5°C (9°F) at 693°C and 749°C and within ±30°C (54°F) at 927°C. Maximum accuracy is required at the 749°C reading. If minimum error is not obtained at this point, calibrate again to obtain a minimum error reading at 749°C by turning zero adjusting screw located on back of indicator and then rechecking for within tolerance readings at the 693°C and 927°C points. If indicator has helicopter manufacturers functional stamp, check indicator calibration against the following procedures.

- (a) Increase degree scale of analyzer to indicate a test temperature of 1000°C. The temperature variation between the analyzer setting and TOT indicator must be within ±30°C (54°F).
- **(b)** After completion of adjustment, apply a small amount of retaining compound (C120) to adjusting screws.

#### **NOTE**

To ensure best results, instrument should be subjected to a constant room temperature for at least 1 hour. If TOT indicator readings are in excess of allowable tolerances, replace indicator.

- (3) If indicator accuracy is confirmed, check the total airframe/engine circuit resistance as follows:
- (a) Check circuit resistance using the Jet-Cal analyzer. (Refer to TM 55-4920-244-14.) Resistance indicator should be 8(±0.05) ohms.

#### **NOTE**

For best results, both cockpit air temperature and outside air temperature should be the same.

- (b) If the total TOT circuit resistance is not  $8 \pm 0.05$ ) ohms, adjust thermocouple resistor spool to obtain the required resistance. Refer to paragraph 8-130.
- (4) Test turbine outlet temperatures system with T63-A-720 installed as follows:
- (a) Connect indicator to test set and check indicator accuracy at 738°C (beginning of yellow arc), 810°C (red line), and 927°C red dot. The indicator shall read within ±5°C at 738°C and 810°C, and within ±30°C at 927°C. Maximum accuracy is required at the 810°C reading. If minimum error is not obtained at this point, re-calibrate to obtain minimum error reading at

**810°C** by turning the "zero" adjustment screw located on the back of the indicator and then rechecking for within tolerance readings at the **738°** C and **810°** C, and **927°C** points.

- (b) Increase degree scale of analyzer to indicate a test temperature of 1000°C. Temperature variation between the analyzer setting and the indicator must be within ±30°C.
- **(c)** After completion of adjustment, apply a small amount of retaining compound, MIL-S-22473, Grade E, to the adjusting screw.
- **b.** For additional testing information refer to TM 55-2840-231-23.
- **c.** Install turbine out temp indicator (refer to paragraph 8-127).

# 8-118. Troubleshooting - Turbine Outlet Temperature System.

#### **CAUTION**

The TOT system contains alumel and chromel wire and terminals. Repair items must be of the same material. Connections at the engine disconnect (TB3) are silver soldered. All other connections may be crimp or solder type. Refer to TM 55-1500-323-24 for general requirements.

#### NOTE

Before using table 8-6, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 8-6, notify the next higher level of maintenance.

# 8-119. TURBINE OUTLET TEMPERATURE (TOT) INDICATOR A.

**8-120. Description - Turbine Outlet Temperature Indicator.** The turbine outlet temperature indicator receives temperature indications from bayonet-type thermocouples mounted in the turbine outlet. The indicator is graduated in degrees centigrade and electrical power is not required as the system is self-generating. Throughout TOT indicator maintenance procedures, if a Jet-Cal analyzer is specified, refer to TM 55-4920-244-14 for operation and maintenance instructions for the analyzer.

- **8-121.** Cleaning Turbine Outlet Temperature indicaters. Refer to paragraph 8-3.
- **8-122.** Inspection Turbine Outlet Temperature (TOT) indicator. Refer to paragraph 8-4.
- **8-123. Testing Turbine Outlet Temperature (TOT) Indicator.** Refer to paragraph 8-115.
- **8-124.** Troubleshooting Turbine Outlet Temperature (TOT) indcator. Refer to paragraph 8-118 and table 8-8.
- **8-125.** Removal-Turbine Outlet Temperature (TOT) indicator. Refer to paragraph 8-5.

### **CAUTION**

When turbine outlet temperature indicator is removed, the instrument terminals shall be short circuited with a piece of copper wire to prevent induced electrical damage. Remove wire before reinstallation.

8-126. Repair or Replacement - Turbine Outlet Temperature (TOT) indicator. Replace indicator that

### Table 8-6. Troubleshooting - Turbine Outlet Temperature System (TOT)

# CONDITION

**TEST OR INSPECTION** 

#### **CORRECTIVE ACTION**

1. Indicator shows excessive temperature (incorrect reading).

STEP 1. Loose connectors.

### Tighten connectors.

STEP 2. Incorrect circuit resistance. Refer to paragraph 8-117.

Check and set resistance. Refer to paragraph 8-117.

STEP 3. Defective indicator. Refer to paragraphs 8-4 and 8-123.

Replace indicator. Refer to paragraph 8-7.

2. No reading on indicator.

STEP 1. Loose connections on indicator lead spool resistor terminal block. Refer to paragraphs 8-123 and 8-130.

#### Clean and tighten connections.

STEP 2. Open circuit in indicator.

# Replace indicator. Refer to paragraph 8-7.

3. Incorrect reading.

STEP 1. Harness not calibrated to 8 ohms.

#### Calibrate harness to 8 ohms. Refer to paragraph 8-123.

4. Higher than normal temperature.

STEP 1. Check for leaking in the flexible portion of tube assembly (44, figure 4-1).

## Replace defective tube assembly.

STEP 2. Check all bleed air lines, fittings, and connections for leaks.

Replace defective parts or tighten connections.

does not meet inspection and/or test requirements. Prior to installation, calibrate indicator per instructions and test points of paragraph 8-117a.(2) and 8-117a.(2)(a).

**8-127.** Installation - Turbine Outlet Temperature (TOT) Indicator. Refer to paragraph 8-7 and CAUTION of paragraph 8-125.

#### 8-128. THERMOCOUPLE RESISTOR.

**8-129.** Description - Thermocouple Resistor. The thermocouple resistor spool located on the electrical shelf is used in conjunction with the turbine outlet temperature indicator and enables selection of the proper operating resistance of the indicator circuit. The spool is mounted on a board along with a spare spool. The spool is a part of the TOT circuit. Varying the length of the wire on this spool will change the turbine outlet temperature (TOT), circuit resistance.

# 8-130. Adjustment/Replacement - Thermocouple Resistor.

#### NOTE

The loop resistance of the wire on the spool is 7 ohms for each 25 feet or approximately 0.02 ohms per inch of wire.

- a. Access to the spool resistor is gained as follows:
  - (1) Remove safety wire.
  - (2) Unlatch and remove resistor cover.
- **b.** If TOT circuit resistance was in excess of 8.05 ohms, proceed as follows:
- (1) Unsolder one end of the resistor winding from the terminal lug,

#### NOTE

New spool resistors have only one end of the winding soldered to a terminal. The other end is free to permit adjustment upon installation.

(2) Unwind a turn or two of wire at a time and scrape off the insulation. Touch the bare wire to the

terminal and check TOT circuit resistance. When resistance is between 7.95 and 8.05 ohms, solder wire to terminal.

- c. If TOT circuit resistance was less than **7.95** ohms, replace resistor spool as follows:
- (1) If spare resistor spool remains, unsolder old resistor spool connection and solder spare resistor spool into circuit, following above procedure to obtain correct circuit resistance.
- (2) If no spare resistor spool remains, a new spool resistor assembly must be installed.
  - (3) Remove thermocouple leads
- (4) Remove attachment screws, nuts, and washers.
- **(5)** Remove and replace spool resistor assembly.
  - (6) Replace attaching hardware.
  - (7) Replace thermocouple leads.
- **d.** Repeat adjustment/replacement procedures as necessary to obtain the  $8.00~(\pm0.05)$  ohm TOT circuit resistance reading

### 8-131. Installation - Thermocouple Resistor.

- **a.** Position resistor in helicopter and install two attaching screws, nuts, and washers.
- **b.** Connect thermocouple leads to resistor terminals.
  - c. Install resistor cover.
  - d. Lockwire (C95) cover fasteners.

# 8-132. TURBINE OUTLET TEMPERATURE INDICATING SYSTEM

**8-133. Description - Turbine Outlet Temperature Indicating System.** The turbine outlet temperature indicating system is protected by a TURB OUTLET TEMP circuit breaker and powered by 28 Vdc and a self-generating thermocouple system consisting of four bayonet type thermocouples

mounted in turbine outlet, turbine outlet temperature indicator (an electronic bridge circuit is included in the indicator, which eliminates the need for a resistance spool in the thermocouple circuit), and interconnecting wiring. Refer to figure F-27.

#### **NOTE**

The resistance spool is still part of the turb outlet tamp circuit, but the resistance spool does not require any adjustment.

8-134. Testing — Turbine Outlet Temperature Indicating System.

#### **NOTE**

The operating instructions are located on a placard attached to the Jet-Cal analyzer cover.

- **a.** Disconnect plug (P50) from turbine outlet temperature indicator and connect the indicator to the Jet-Cal analyzer.
- **b.** Check the indicator in accordance with TM 55-4920-401-13&P.
- c. Check indicator at 738°C (beginning of yellow arc) and at 810°C (red line), 927°C (maximum). The indicator shall be within ±5°C of the applicable check temperature.
- **d.** Disconnect plug (P12) from receptacle (J12) in thermocouple harness. Connect a Jet-Cal analyzer to pins A and B of (P12). Measure the resistance of the engine thermocouple loop. Resistance shall be **1.3 to 1.9** ohms.
- **e.** Remove Jet-Cal analyzer and reconnect plug (P12). Ensure that connector is properly mated and secure.
- **f.** Connect Jet-Cal analyzer to (P50). Measure resistance of entire thermocouple harness. Total circuit resistance shall be **7 to 100** ohms.
- **g.** Remove Jet-Cal analyzer and reconnect (P50) to the indicator. Ensure that connector is properly mated and secure.

**8-135.** Troubleshooting — Turbine Outlet Temperature Indicating System. Refer to table 8-7.

### **CAUTION**

The TOT system contains alumel and chromel wire and terminals. Repair items must be of the same material. Connecions at the engine disconnect (TB3) are silver soldered. All other connections may be crimp or solder type. Refer to TM 55-1500-323-24 for general requirements.

#### NOTE

Before using table 8-7, ensure all normal operational checks have been performed.

# 8-136. TURBINE OUTLET TEMPERATURE INDICATOR C.

- **8-137. Description Turbine Outlet Temperature Indicator.** The indicator displays turbine outlet temperature in degrees centigrade. Power to energize an internal bridge circuit in the indicator is from the 28Vdc TURB OUTLET TEMP circuit breaker.
- **8-138.Cleaning** Turbine Outlet Temperature Indicators. Refer to paragraph 8-3.
- **8-139.** Inspection Turbine Outlet Temperature Indicator. Refer to paragraph 8-4.
- **8-140. Testing Turbine Outlet Temperature Indicator.** Refer to paragraph 8-134.
- **8-141.** Troubleshooting Turbine Outlet Temperature Indicator. Refer to paragraph 8-135.
- **8-142.** Removal Turbine Outlet Temperature Indicator. Refer to paragraph 8-5.
- **8-143.** Repair or Replacement Turbine Outlet Temperature Indicator. Replace indicator that does not meet inspection and/or test requirements.
- **8-144.** Insulation Turbine Outlet Temperature Indicator. Refer to paragraph 8-7.

# Table 8-7. Troubleshooting — Turbine Outlet Temperature Indicating System C

# CONDITION

**TEST OR INSPECTION** 

### **CORRECTIVE ACTION**

1. No reading on indicator.

STEP 1. Check for defective TURB OUTLET TEMP circuit breaker.

Replace circuit breaker.

STEP 2. Loose connection or broken wires.

Tighten connection or repair wires.

STEP 3. Defective indicator. Refer to paragraph 8-134.

Replace indicator, Refer to paragraphs 8-142 and 8-144.

STEP 4. Defective thermocouple.

Check thermocouple circuit. Refer to paragraph 8-134.

2. Incorrect reading.

STEP 1. Defective indicator. Refer to paragraph 8-134.

Replace indicator. Refer to paragraphs 8-142 and 8-144,

STEP 2. Defective thermocouple.

Check thermocouple circuit. Refer to paragraph 8-134.

# SECTION II. FLIGHT INSTRUMENTS

#### 8-145. PITOT-STATIC SYSTEM.

**8-147.** Troubleshooting — Pitot-Static System. Refer to applicable portions of airspeed indicator altimeter, and vertical speed indicator troubleshooting, procedures.

# 8-148. PITOT-STATIC PIPING AND FITTINGS.

**8-149. Description** — **Pitot-Static Piping and Fittings.** The pitot-static piping and fittings consists of flexible piping lines routed from the pitot tube and static ports to the proximity warning system, airspeed indicators, altimeters, and vertical speed indicator. The piping lines are connected with fittings and contain a pitot drain and static drain. Refer to figure 8-1 for equipment location.

#### NOTE

A functional check of the pitot static system and pitot static instruments will be preformed following any opening and closing of the pitot static system, except for the use of the system drain.

### 8-150. Cleaning — Pitot-Static Piping and Fittings.

- **a.** Remove caps and open pitot drain valve and static drain valve.
- **b.** Disconnect pitot and static lines from proximity warning panel airspeed indicators and static lines from altimeters and vertical velocity indicator. Cap openings in indicators and pressure transducer to prevent entrance of foreign material. To prevent damage to components, use figure 8-1 as a guide.
- **c.** Slowly apply low dry pressure to one of the disconnected static lines in the cockpit and at the same

time, watch all the indications for evidence of any indicator still being connected to the static system.

- **d.** When it is determined all instruments are disconnected, increase the pressure to blow out lines.
  - e. Clean out static port holes.
  - f. Reconnect all lines.
  - **g.** Close pitot and static drain valves and install plugs.

# 8-151. Inspection — Pitot-Static Piping and Fittings.

- **a.** Inspect pitot and static piping and fittings for leaks, chafing, crimping, or other visible damage.
- **b.** Inspect system for improperly installed fittings and clamps.
  - c. Remove drain plugs and check for moisture.
- **d.** Inspect static ports for damage, obstructions and cleanliness.

#### 8-152. Removal — Pitot-Static Piping and Fittings.

- **a.** Disconnect pitot and static lines from indicators. Cap openings in indicators to prevent entrance of foreign material.
  - **b.** Disconnect applicable fittings and clamps.
  - **c.** Remove pitot and static lines.

# 8-153. Repair or Replacement — Pitot-Static Piping and Fittings.

- **a.** Repair any leaks to pitot system found during check procedure. Refer to TM 1-1500-204-23.
- **b.** Replace only defective components such as broken B nuts, deteriorated hoses, bad valves, etc. Check for kinked hoses.
  - **c.** Remove drain plugs and check for moisture.
- **d.** If moisture is found, perform cleaning procedures as outlined in paragraph 8-150.




Figure 8-1. Pitot-Static and Instrument Piping Installation A (After incorporation of MWO 55-1520-228-30/22)

### 8-154. Installation — Pitot-Static Piping and Fittings.

- **a.** Route pitot and static lines through clamps in place. Tighten clamps. Connect pitot and static lines to indicators.
- **b.** Apply silicone lubricant (C104) to threads of fitting couplings.
  - **c.** Connect fittings. Torque coupling nuts fingertight.
- **d.** Conduct functional check. Refer to paragraph 8-155.
- **8-155.** Functional Check Altimeter, Airspeed, and Vertical Speed Indicators Pitot-Static System. (Removing the instruments from the helicopter is not required for performing the functional check.)

#### **CAUTION**

Do not apply suction to pitot lines or pressure to static lines; except as instructed in paragraph 8-155c.

#### **NOTE**

Ensure pitot static tester has a current calibration label (DA Form 80). Use appropriate power supply in accordance with pitot static tester requirements.

- a. Pitot Line Leak check
- (1) Seal pitot tube drain holes air tight with pressure sensitive tape (C136).
- **(2)** Hook up pitot static tester, airspeed outlet, to pitot system in accordance with figure 8-2. Close pitot static tester pressure down valve.

# CAUTION

The valves on test set are sensitive and should be operated slowly and with care to avoid possible damage to instrument. These instruments are easily pegged and damaged by improper manipulation of the valves on the test set.

(3) Slowly apply pressure to pitot line (figure 8-2) until the airspeed indicator reads 100 knots.

- (4) Tap instrument to remove friction effects. When indicator pointer drops more than 10 mph (8.7 knots) in one minute, a leak is indicated. Slowly decrease pressure to return tester airspeed indicator to zero, repair any faults, if necessary, and repeat above steps.
  - b. Airspeed Indicator Functional Check.
- (1) Slowly apply pressure to pitot line to obtain airspeed readings in table 8-9; indicator should be gently tapped prior to reading; check need not exceed 120 knots
- (2) If readings are not within tolerance of table 8-9, slowly relieve pressure on pitot line until airspeed indicator reads zero. Replace indicator with serviceable one and repeat steps b. (1) and (2).
- **(3)** Airspeed indicators that fail check shall be turned in for overhaul.

#### **CAUTION**

Remove static line from aircraft airspeed indicator and cap before proceeding to next step.

- c. Static Line Leak Check.
- (1) Hook up pitot static tester, rate-of-climb and altimeter outlet to pitot and static system in accordance with figure 8-2.

#### CAUTION

Ensure that both helicopter pitot and static lines are connected to airspeed indicator to prevent possible damage to airspeed indicator.

### NOTE

Hooking up the pitot line to the tester vacuum source will only be done during the following check to equalize the pressure in the airspeed indicator case to prevent damage to its diaphragm.

- (2) Tape all unused static parts.
- (3) Adjust test set and aircraft altimeter barometric scales to read 29.92, gently tap altimeters, and check to ensure that aircraft altimeter reads within 70 feet of test set altimeter and




Figure 8-2. Connector for Pitot and Static Leak Check (Typical).

- **g.** Brush Run-In Equipment. The following equipment is required for the brush run-in procedure:
  - (1) The 30-volt dc power source.
- (2) A set of V-blocks, padded with sponge rubber, to support the starter-generator.
- (3) A single-pole, single-throw switch capable of handling 300 amperes.
- (4) A rheostat having a minimum rating of 10 ohms, 15 amperes
- (5) A tachometer of suitable range, or a stroboscopic light for indicating starter-generator speed.
- (6) A resistor in the armature circuit having a rating of 0.100 ohms, 200-500 amperes.

#### **NOTE**

Instead of running the starter-generetor as e motor, brush run-in may be accomplished by using a generator test stand to drive the starter-generator, and operate as a generator with 50-100 amperes load at 28-30 volts, and 8000 to 10,000 rpm. The instant-filming type brushes that are used in this starter-generator do not required prolonged run-in to produce a satisfactory film on commutator.

- h. Brush Run-In Procedure. Refer to figure 9-6.
- (1) Place the starter-generator on the V-blocks for support and connect terminal E of the starter-generator to the negative terminal of the dc power source. Refer to figure 4-5 for identification of terminals on the starter-generator.
- **(2)** Connect terminal C to the positive terminal of the dc supply in series through the resistor and single-pole, single-throw switch.
- (3) Connect terminal A to the switch through the variable rheostat.
- (4) Rotate the rheostat control to the minimum resistance setting and close the switch. The generator should start and run as a motor rotating in a clockwise direction, as viewed from the commutator end





Figure 9-6. Brush Run-in Diagram



206061-103

Figure 9-7. Work and Inspection Gage

- (5) Adjust the rheostat until the generator revolves at approximately 5000 rpm, Allow the generator to operate until the brushes are seated a minimum of 100% in direction of rotation and 90% in the axial direction.
- **(6)** Blow out all carbon dust with clean, dry, compressed air.

#### 9-44. Installation — Starter-Generator.

- a. Install adapter (5, figure 9-4) if removed, and gasket (4) on engine starter-generator pad (3) studs and secure with four washers (9) and four nuts (8).
- **b.** Clean driveshaft splines and engine mating splines thoroughly. Apply a film of grease (C77) to the splines.
- **c.** Slide driveshaft splines into mating splines and firmly support unit against adapters (5) pad.

#### NOTE

Prior to installation of starter-generator, rotate splined. shaft to check for fan rub and clearance between fan and screen.

- **d.** With bolt unlatched, place the clamp (6) on the starter-generator (7) and adapter (5).
  - e. Latch bolt and tighten nut snugly on clamp
- **f.** Tap clamp in several places with a rubber mallet to align and seat clamp. Repeat tapping with mallet and torque nut to **45 TO 55 INCH-POUNDS.**

- **g.** Remove electrical tape, connect electrical wires, and secure installation hardware (figure 4-5). Restore electrical power to helicopter.
- **h.** Install air duct on starter-generator and tighten clamp.

#### 9-45. GENERATOR SHUNT.

- **9-46. Description Generator Shunt.** The generator shunt (R3) is located on the equipment shelf above the avionics compartment and providesa small voltage drop, proportional to the current, to operate the ammeter.
- **9-47. Inspection Generator Shunt.** Inspect generator shunt for corrosion, scratches, deformation, discoloration, or obvious damage.

### 9-48. Removal — Generator Shunt.

- **a.** Place BAT switch in OFF position and ensure battery is disconnected.
- **b.** Remove upholstered panel, located aft of rear seat, to gain access to generator shunt.
- **c.** Disconnect electrical wiring and cover ends with tape (C137).
- d. Remove mounting screws and washers and remove shunt.

#### 9-49. Installation — Generator Shunt.

a. Position shunt and install mounting hardware




Figure 8-3. Instrument Panel (Typical) (Sheet 1 of 2)




Figure 8-3. Instrument Panel (Typical) (Sheet 2)

## 9-69. NONESSENTIAL BUS RELAY.

- **9-70. Description Nonessential Bus Relay.** The nonessential bus relay (K2) is an electrically operated switch between the main bus and the nonessential bus and is controlled by either the generator fail relay or the nonessential bus switch (S1).
- **9-71.** Inspection Nonessential Bus Relay. Inspect relay for obvious damage, broken pins, discoloration, security of mounting, etc.

## 9-72. Removal - Nonessential Bus Relay.

- **a.** Place BAT switch in OFF position and ensure battery is disconnected.
  - **b.** Remove bus bar from relays (K2,K3,andK12).
- **c.** Disconnect wires from relay and identify and tape ends with electrical tape (C137).
- **d.** Remove mounting bolts and washers and remove relay from shelf.

### 9-73. Installation - Nonessential Bus Relay.

- **a.** Position relay on shelf and install attaching bolts and washers.
- **b.** Remove tape from wires and connect to proper terminals.
  - c. Install bus bar on relays (K2, K3, and K1 2).
- **9-74.** Troubleshooting Nonessential Bus Relay. Refer to figure F-8.

## 9-75. FUEL BOOST PUMP SYSTEM.

**9-76. Description - Fuel Boost Pump System.** The fuel boost pump system consists of one electrically operated fuel boost pump (B1) submerged in the fuel cell and accessible from the bottom of the fuselage. The pump is energized from a circuit breaker in the overhead console or FUEL BOOST switch on instrument panel The boost pump can also be activated through the fuel boost relay (K16) by depressing the starter switch or through actuation of the fuel pressure switch (S12). Refer to figures 9-1 and F-18.

## 9-77. Testing - Fuel Pump System.

- **a.** Close FUEL BOOST PUMP circuit breaker or FUEL BOOST switch. Check that fuel boost pump operates.
- **b.** Open FUEL BOOST PUMP circuit breaker or FUEL BOOST switch. Check that fuel boost pump stops operating.
- **9-78.** Troubleshooting Fuel Pump System. Refer to table 9-3 and figure F-17 for troubleshooting of the fuel boost pump system.

#### NOTE

Before using table 9-3, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-3, notify the next higher level of maintenance.

- **9-79. Inspection Fuel Boost Pump System.** Refer to paragraph 10-19 for inspection of the fuel boost pump.
- **9-80.** Removal Fuel Boost Pump System. Refer to paragraph 10-20 for removal of the fuel boost pump.
- **9-81. Installation Fuel Boost Pump.** Refer to paragraph 10-22 for installation of the fuel boost pump.

# 9-82. GOVERNOR CONTROL SYSTEM.

**9-83. Description - Governor Control System.** The governor control system allows pilot control of the governor setting and consists of GOV CONT 5 ampere circuit breaker, a governor control switch (S5), and a governor control actuator (B3). Refer to figures 9-1 and F-9.

#### 9-84. Testing - Governor Control System.

- **a.** Ensure that GOV CONT circuit breaker is closed. Press GOV RPM switch to INCR. Check that governor control actuator retracts.
- **b.** Press GOV RPM switch to DECR. Check that linear actuator extends.

# Table 9-3. Troubleshooting — Fuel Pump System

CONDITION

TEST OR INSPECTION

#### **CORRECTIVE ACTION**

1. Low pressure flow or no fuel flow to engine.

STEP 1. Check circuit breaker in overhead console for engagement.

Engage or replace circuit breaker if required.

STEP 2. Check continuity of wiring at boost pump connector.

Repair or replace wiring if continuity does not exist.

STEP 3. Check for low or no fuel boost pump output pressure.

Replace defective boost pump.

STEP 4. Check for clogged filter

Clean or replace filter element.

9-85. Troubleshooting — Governor Control System. Refer to table 9-4 and figure F-9.

#### **NOTE**

Before using table 9-4, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-4, notify the next higher level of maintenance.

#### 9-86. GOVERNOR CONTROL SWITCH.

9-87. Description — Governor Control Switch. The governor control switch (S5), located in the pilot collective switch hex, is a double-pole, double-throw, spring-loaded, momentary contact switch that enables the pilot to increase or decrease the governor rpm actuator setting. With the switch in INCR position, the circuit to the actuator motor is completed and allows motor to move arm in one given direction. With the switch in DECR position the polarily to the actuator motor is reversed, allowing the actuator arm to move in the opposite direction. When the switch is in rest position, circuit is de-energized. Refer to figure F-9.

**9-88.** Inspection — Governor Control Switch. Refer to paragraph 9-128.

9-89. Removal — Governor Control Switch. Refer to paragraph 9-117.

9-30 Change 5

**9-90.** Installation — Governor Control Switch. Refer to paragraph 9-130.

9-91. GOVERNOR CONTROL LINEAR ACTUATOR.

# CAUTION

The instructions contained in par. 9-91 through 9-105 are applicable to P/N 206-062-721-1 (vendor P/N 65A120) only. No repairs are authorized on P/N 206-062-721-11 (vendor P/N 7185-1).

9-92. Description — Governor Control Linear Actuator. The governor control linear actuator (B3, figure 9-1 and 9-8) is located on the forward side of the engine and is a motor-actuated device operated by the governor switch (S5) on the pilot collective stick to allow engine output speed to be varied over a normal range.

#### **NOTE**

Refer to paragraphs 4-113, 4-114, and 4-115 for inspection, removal, and installation procedures for the governor control linear actuator.

Table 8-11. Altimeter Scale Error

ALTITUDE (Feet)	TOLERANCE (Feet)
0	±70
500	±70
1,000	±70
2,000	±70
3,000	±70
5,000	±100
10,000	±130
15,000	±140

- **8-181.** Removal Altimeters. Refer to paragraph 8-5.
- **8-182.** Repair Altimeters. Refer to paragraph 8-6.
- **8-183.** Installation Altimeters. Refer to paragraph 8-7
- 8-183.1. Radar Altimeter with Voice Warning (After compliance with MWO 1- 1520-228-50-52).
- **8-183.2. Description**. After radar altimeter set AN/ APR-209(V) with voice warning is installed, the pilot is provided with an instrument panel mounted indicator of absolute clearance above the ground. Refer to TM 11-1520-228-20-1 for description, installation and maintenance of the system components.

#### 8-184. VERTICAL SPEED INDICATOR.

- **8-185.** Description Vertical Speed Indicator (VSI). The VSI instrument is connected to the pitot static air system and incorporates a mechanism that provides instantaneous indications. It is actuated by the rate of atmospheric pressure change and provides an anticipated indication of speed of ascent or descent in feet per minute. Refer to figure 8-1 for location.
- **8-186. Cleaning Vertical Speed Indicator**. Refer to paragraph 8-3.
- **8-187. Inspection Vertical Speed Indicator.** Refer to paragraph 8-4.
- **8-188.** Functional Check Vertical Speed Indicator. Check the vertical speed indicator using pitot-static system tester. Refer to paragraph 8-155.

**8-189.** Troubleshooting - Vertical Speed Indicator. Use table 8-12 and perform necessary checks to isolate trouble.

#### NOTE

Before using table 8-12, be sure to perform all normal operational checks. If a malfunction exists which is not listed in table 8-12, notify the next higher level of maintenance.

- **8-190.** Removal Vertical Speed Indicator. Refer to paragraph 8-5.
- **8-191. Repair Vertical Speed Indicator**. Refer to paragraph 8-6.
- **8-192. Installation Vertical Speed Indicator**. Refer to paragraph 8-7.
- 8-193. TURN AND SLIP INDICATOR A.
- **8-194. Description Turn and Slip Indicator**. The turn and slip indicator is controlled by an electrically actuated gyro. This instrument has a needle (turn indicator and a ball (slip indicator). Although needle and ball are combined in one instrument and are normally read and interpreted together each has its own specific function and operates independently of the other. The ball indicates when helicopter is in directional balance, either in a turn or in straight and level flight. If helicopter is yawing or slipping, ball will be off center. The needle indicates in which direction and at what rate helicopter is turning. Refer to figure F-4 for wiring diagram.
- **8-195. Cleaning Turn and Slip Indicator**. Refer to paragraph 8-3.
- **8-196. Inspection Turn and Slip Indicator**. Refer to paragraph 8-4.
- **8-197.** Troubleshooting Turn and Slip Indicator. Use table 8-14 and perform necessary checks to isolate trouble.

#### NOTE

Before using table 8-14, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 814, notify the next higher level of maintenance.

### CONDITION

#### **TEST OR INSPECTION**

### **CORRECTIVE ACTION**

- 1. Pointer fails to respond.
  - STEP 1. Check for obstruction in line. Refer to paragraph 8-151.

Drain moisture and/or clean obstruction from static line. Refer to paragraph 8-150.

STEP 2. Check for defective indicator. Refer to paragraphs 8-4 and 8-155.

Replace indicator. Refer to paragraph 8-7.

- 2. Pointer indicates incorrectly.
  - STEP 1. Check for leak in static line. Refer to paragraph 8-151.

Repair or replace line. Refer to paragraph 8-153.

- STEP 2. Tap face of indicator lightly while adjusting and return pointer to zero by turning adjustment knob.
- STEP 3. Check for plugged static vent.

Clean static vent. Refer to paragraph 8-165.

STEP 3. Check for defective instrument.

### Replace instrument.

Table 8-13. Vertical Speed Indicator Tolerance

Scale Accuracy				
Standard Altitude Check Interval (Feet)	Check Rate Ascent or Descent (FPM)	Tolerance Scale Error (FPM)		
2000 To 2500	500	±100		
2000 To 3000	1000	±200		
2000 To 4000	2000	±300		
2000 To 5000	3000	t300		
15,000 To 17,000	2000	±300		

## Table 8-14. Troubleshooting — Turn end Slip Indicator A

#### CONDITION

**TEST OR INSPECTION** 

### **CORRECTIVE ACTION**

- 1. Pointer remains centered, either constantly or intermittently.
  - STEP 1. Check for sticky gyro.

Replace indicator. Refer to paragraph 8-7.

STEP 2. Check for electrical power to indicator. Refer to paragraph 8-198.

Ensure proper circuitry connections and replace faulty wiring. Refer to figure F-4.

- 2. Ball too sensitive.
  - STEP 1. Check if dampening fluid has leaked out.

Replace indicator. Refer to paragraph 8-7.

### 8-198. Testing - Turn and Slip Indicator.

- **a.** Determine that power is connected to helicopter.
- **b.** Determine that TURN & BANK IND circuit breaker is depressed (closed).
  - c. Check that the indicator gyro is running.
- **8-199. Removal Turn and Slip Indicator.** Refer to paragraph 8-5.
- **8-200.** Repair or Replacement Turn and Slip Indicator. Refer to paragraph 8-6.
- **8-201.** Installation Turn and Slip Indicator. Refer to paragraph 8-7.

# 8-202. ATTITUDE INDICATOR A.

**8-203. Description - Attitude Indicator.** The attitude indicator displays rate of turn of the helicopter relative to the earth. The indicator is self-contained and requires connection through a 1/2 ampere circuit breaker (GYRO HORIZ) 115 Vac bus. Refer to figure F-4.

- **8-204.** Cleaning Attitude Indicator. Refer to paragraph 8-3.
- **8-205. Inspection Attitude Indicator.** Refer to paragraph 8-4.
- 8-206. Testing Attitude Indicator.
- **a.** Determine that power is connected to helicopter.
  - b. Position helicopter circuit controls as follows:
    - (1) Position inverter switch to INV.
- (2) Depress (close) the GYRO HORIZ circuit breaker.
- **c.** Observe that within 3 minutes, the indicator OFF flag disappears.
- **d.** Cage the gyro by pulling out, then releasing PULL TO ERECT knob. Check that the display erects properly and remains stable in both pitch and roll.

#### **NOTE**

When caging the gyro, PULL TO ERECT knob must be pulled sraight out without turning. If turned, knob may lock in the out position. Gyro will not cage until knob has been released and returned to its normal position.

- **e.** Rotate pitch trim knob (at lower center of indicator). Check that trim indicator moves up; and then down, or moves down and then UP.
- **f.** Return trim knob to zero trim. Check that display remains stable in both pitch and roll.

- **g.** Open GYRO HORIZ circuit breaker. Check that the OFF flag appears and that gyro decreases in speed and stops after several minutes.
  - h. Return inverter switch to the OFF position.

**8-207. Troubleshooting - Attitude Indicator.** Use table 8-15 and perform necessary checks to isolate trouble

#### NOTE

Before using table 8-15, ensure all normal operational checks have been performed. If a malfunction exists which is not listed on table 8-15, notify the next higher level of maintenance.

### Table 8-15. Troubleshooting - Attitude Indicator

#### CONDITION

**TEST OR INSPECTION** 

#### **CORRECTIVE ACTION**

1. Indicator does not operate.

STEP 1. Check for AC power failure (INST INVERTER light illuminated).

Check wiring, plug, circuit breakers, and inverter switch. Repair or replace faulty component or wiring as necessary.

2. Indicator does not indicate within ±1 degree.

STEP 1. Check for defective indicator. Refer to paragraphs 8-4 and 8-206.

Replace indicator. Refer to paragraph 8-7.

STEP 2. Check for loose plug at indicator

Make proper plug installation at indicator.

STEP 3. Check for faulty wiring.

Check system circuit and wiring. Repair or replace faulty component or wiring as necessary.

- **8-208 Removal Attitude Indicator.** Remove attitude indicator from instrument panel in accordance with paragraph 8-5.
- **8-209.** Repair or Replacement Attitude Indicator. Repair the indicator in accordance with paragraph 8-6.
- **8-210.** Installation— Attitude Indicator. Install the indicator in the instrument panel in accordance with paragraph 8-7.

# 8-211. ATTITUDE/TURN AND SLIP INDICATOR C.

- 8-212. Description Attitude/Turn and Slip Indicator. The attitude/turn and slip indicator has a self-contained vertical gyro and displays flight attitude of the helicopter in relation to the horizon. The display can be adjusted for trim in level flight by means of pitch trim and roll trim knobs on the front of the indicator. The indicator rate-of-turn pointer indicates the direction and rate of turn that the helicopter is turning. It is controlled by electrical signals derived from a directional gyro (part of compass system). The ball indicates when the helicopter is in directional balance, either in a turn or in straight and level flight. If the helicopter is yawing or slipping, bail will be off center. Refer to figure F-24 for wiring diagram and figure 8-3 for indicator location. The indicator receives 28 Vdc power when the ATTD TURN and ATTD HRZN circuit breakers are depressed. the indicator receives 115 Vac reference power when the GYRO CMPS circuit breaker is depressed.
- **8-213. Cleaning** Attitude/Turn and Slip Indicator. Refer to paragraph 8-3.
- **8-214.** Inspection Attitude/Turn and Slip Indicator. Refer to paragraph 8-4.
- 8-215. Testing Attitude/Turn and Slip Indicator.

- **a.** Energize inverter, close ATTD TURN, ATTD HRZN and GYRO CMPS circuit breakers. Indicator ATT flag will disappear within **3-1/2** minutes.
- **b.** Attitude display will erect properly (within one degree) and remain stable in both pitch and roll. Rate-of-turn pointer will be approximately centered. Ball will be centered if helicopter is level.
- **c.** Rotate pitch trim knob in lower left corner of indicator to full clockwise position. Miniature airplane will move upward to indicate a **10** degree climb.
- **d.** Rotate pitch trim knob to full counterclockwise position. Miniature airplane will move downward to indicate a **10** degree dive.
- **e.** Return trim knob to **zero** trim. Display will remain stable in both pitch and roll.
- **f.** Momentarily depress the fast erect knob in lower right corner of indicator. The fast erect mode of operation is automatically maintained, **1.000** ( $\pm$ **0.250**) minute. The ATT flag will appear while system is in fast erect mode and disappear when automatic time cycle has elapsed, **1.000** ( $\pm$ **0.250**) minute.
- **g.** Open ATTD TURN, ATTD HRZN and GYRO CMPS circuit breakers. ATT flag will appear, gyros speed will decrease and stop after several minutes. Rate-of-turn pointer will be biased out of view.
- **8-216.** Troubleshooting Attitude/Turn and Slip Indicator. Use table 8-16 and perform necessary checks to isolate trouble.

#### NOTE

Before using table 8-16, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 8-16, notify the next higher level of maintenance.

## Table 8-16. Troubleshooting - Attitude/Turn and Slip Indicator

CONDITION

**TEST OR INSPECTION** 

#### **CORRECTIVE ACTION**

1. Attitude indicator inoperative. Turn end slip function properly.

STEP 1. Open or defective ATTD-TURN HRZN circuit breaker.

Close or replace circuit breaker.

STEP 2. Check for faulty wiring.

Check system circuit and wiring. Repair or replace faulty wiring as necessary,

STEP 3. Check for defective indicator.

Replace indicator. Refer to paragraphs 8-217 and 8-219.

2. Ball is too sensitive

STEP 1. Determine if dampening fluid has leaked out of indicator.

Replace indicator. Refer to paragraphs 8-217 and 8-219.

**8-217.** Removal - Attitude/Turn and Slip Indicator. Refer to paragraph 8-5.

**8-219.** Installation - Attitude/Turn and Slip Indicator. Refer to paragraph 8-7.

8-218. Repair or Replacement - Attitude/Turn and Slip Indicator. Refer to paragraph 8-6.

## SECTION III. NAVIGATION INSTRUMENTS

8-220. MAGNETIC COMPASS (STANDBY).

**8-221. Description - Magnetic Compass** (Standby). The magnetic compass is a standard, nonstabilized, magnetic type instrument mounted on a support which is attached to the forward cabin, right side. The compass is used in conjunction with a compass correction card that is located adjacent to the compass.

**8-222.** Cleaning - Magnetic Compass (Standby). Refer to paragraph 8-3.

**8-223.** Inspection - Magnetic Compass (Standby) Refer to paragraph 8-4.

**8-224.** Compensation (Swinging) - Magnetic Compass (Standby). Refer to TM 55-1500-204-25/1

**8-225.** Repair - Magnetic Compass (Standby). Replace compass if found to be defective.

**8-226.** Installation - Magnetic Compass (Standby). Refer to paragraph 8-7.

**8-227.** Troubleshooting - Magnetic Compass (Standby). Refer to TM 55-1 500-204-25/1.

8-228. Global Positioning System (GPS) (After compliance with MWO 1-1520-228-50-53).

**8-228.1. Description - Global Positioning System (GPS).** After GPS is installed, the pilot is provided a six-channel dual-frequency receiver module with a Precise Positioning Service (PPS) capability. Refer to TM 11-1520-228-20,-1 for description, installation and maintenance of the system components.

#### SECTION IV. MISCELLANEOUS INSTRUMENTS

**8-229. Description-Miscellaneous Instruments.** The miscellaneous instruments included fuel quantity indicating system, free air temperature gage, clock, and dc ammeter.

#### **NOTE**

A transmission oil pressure indicating system Is installed on OH-58C helicopters.

8-230. Fuel Quantity Indicating System.

8-231. Description-Fuel Quantity Indicating System. This fuel gaging system is designed specifically to measure mass or weight of fuel in the helicopter fuel cell. The operation of the system is based on the principle that the capacitance of a capacitor in an electrical circuit is determined by the dielectric constant of the insulating medium between capacitor plates. When the fuel cell is empty, air is the insulating medium and when there is fuel in the cell, fuel is the insulating medium. The tank unit assembly (Z5) acts as a variable capacitor in the circuit. The capacitance of the tank unit will vary in direct proportion to the mass of fuel in the tank. The tank unit is a flange mounted unit with system electronics housed in the flanged head. The indicator (part of instrument cluster) is milliamp meter which receives a rectified dc signal in proportion to the level sensed by the tank unit. The signal is generated by a small transistorized oscillator which applies the unbalance signal in the bridge and applies a signal to a bridge circuit. A sensitive amplifier amplifies it to a stage of rectification to allow adaptation to a calibrated milliamp meter. Refer to Figure F-6 or Figure F-26

8-232. Test and Adjustment Fuel Quantity Indicating System.

Premaintenance Requirements for Testing Fuel Quantity System

Condition	Requirements
Model	OH-58A/OH-58C
Part No. or Serial No.	All
Special Tools None	
Test Equipment	None
Support Equipment	None
Minimum Personnel	Three
Required	
Consumable Material	(C95) (C1 119)
Special Environmental	None
Conditions	

a. Adjustment (on helicopter)

# WARNING

Refer to TM 1-1500-204-23-3 for safety precautions when servicing fuel system.

### **CAUTION**

Calibration must be accomplished with an external power supply. If an expedited calibration must be accomplished with battery power, calibration must be repeated within 30 days using external power. Aircraft remains on a Red (dash) status until this procedure is completed using external power.

#### NOTE

The most accurate method of adjustment, after system is installed on the helicopter, is with a known quantity of fuel In the cell. The minimum readjustment requirement after replacement of fuel quantity Indicator or lower transmitter Is resetting the empty adjustment. A complete adjustment must be accomplished after replacement of upper tank transmitter (signal conditioner).

- (1) Completely drain fuel tank. Refer to para 1-7.
- (1a) Level helicopter, refer to para 1-45.
- (2) Apply external power, refer to paragraph 1-46. Verify system voltage is 28  $^{\ast}$  0.5 volts.
- (3) Ensure that OH-58A instrument cluster or OH-58C fuel quantity circuit breaker is in (ON) position.
- (4) Observe that the "20 MIN FUEL" caution light is on. DO NOT fly helicopter if low fuel "20 MIN FUEL" caution system is not working.

#### NOTE

In the following steps, fuel must be added in accurately measured quantities from a calibrated container. DO NOT rely on the fuel truck meter.

- (5) If tank is completely dry (new tank, sump removed, or similar condition), add a measured quantity of 0.2 gallons of fuel to tank. NOTE: This fuel is the undrainable fuel allowance. If tank was drained using a sump pump, DO NOT add this fuel.
- (6) Add a measured quantity of 1.2 gallons of fuel to tank. NOTE: : This fuel with undrainable fuel is the unusable fuel allowance (total of 1.4 gallons unusable).
- (7) Turn "E" adjustment screw on upper fuel transmitter clockwise until cockpit gage reads above zero, turn

Change 23 8-37

adjustment screw counterclockwise until pointer goes downscale to zero. Lightly tap cockpit gage during adjustment.

- (8) Begin fueling helicopter and observe that "20 MIN FUEL" caution light goes out when a measured total (including amount added in paragraph 6) of  $12.5 \pm 2.5$  gallons have been loaded. NOTE: Remaining fuel may be added using standard gravity fueling method. Refer to paragraph 1-5c.
- (9) Continue fueling helicopter to spillover. Observe total quantity of fuel added is 71.5 gallons. If measured quantity is not within ± 2.5 gallons, check for errors in measurement system or defects such as swelling (activation) of fuel cell. If necessary repeat entire procedures using calibrated containers to measure fuel added.
- (10) Turn "F" adjustment screw on upper fuel transmitter until cockpit gage reads 450 pounds. lightly tap cockpit gage during adjustment.
  - (11) Disconnect external power.
- (12) The following is an acceptable method of setting the high level on the fuel gage when 450 pounds is not acceptable; such as when JP-5/JP-8 is used.
- (a) Complete entire process as stated previously. If system cannot be adjusted to read 450 pounds there is a problem, most likely a defective upper transmitter.
  - (b) Determine actual fuel density with a hydrometer.
- (c) Calculate the weight of a full tank by multiplying density times 70.3 (70.3 gallons is usable fuel).


#### **NOTE**

Fuel gage marks are in 50 pound intervals. It is not possible to establish precedures readings at smaller Increments, however It Is acceptable to estimate to the nearest 12.5.

- (d) Set fuel gage to calculated value using "F" adjustment screw. Lightly tap cockpit gage during adjustment.
  - b. Deleted.
- 8-233. Fuel Quantity Indicator.
- 8-234. Discretion Fuel Quantity Indicator. The fuel quantity indicator receives inputs from fuel transmitted and indicates fuel quantity in total pounds.
- 8-235. Cleaning Fuel Quantity Indicator. Refer to paragraph 8-3.
- 8-236. Inspection Fuel Quantity Indicator. Refer to paragraph 8-4
- 8-237. Troubleshooting Fuel Quantity Indicator. Use table 8-17 and perform necessary checks to isolate trouble.

#### NOTE

Before using table 8-17 ensure all normal operational checks have been performed. If a malfunction exists which is not listed In table 8-17, notify next higher level of maintenance.



**TEMPERATURE °F AND °C** 

TM 55-1520-228-23

# Table 8-17. Troubleshooting - Fuel Quantity Indicator.

#### CONDITION

#### **TEST OR INSPECT**

#### CORRECTIVE ACTION

1. Indicator reads low.

STEP 1. System out of adjustment. Refer to paragraph 8-232.

Perform adjustment procedures. Refer to paragraph 8-232.

Step 2. Tank unit has low capacitance.

Change tank unit. Refer to paragraph 8-232.

Step 3. Indicator movement defective. Refer to paragraphs 8-4 and 8-232.

Replace Indicator. Refer to paragraph 8-7.

STEP 4. Signal conditioner defective. Refer to paragraph 8-232.

Replace tank unit. Refer to paragraph 8-241 and Chapter 10 as applicable.

2. Indicator reads high.

STEP 1. Systen out of adjustment.

Perform adjustment procedures. Refer to paragraph 8-232.

STEP 2. Tank unit has high capacitance.

Change tank unit. Refer to paragraph 8-241 and Chapter 10 as applicable.

STEP 3. Indicator movement defective.

Replace indicator, Refer to paragraph 8-7.

STEP 4. Signal conditioner defective. Refer to paragraph 8-232.

Replace tank unit. Refer to paragraph 8-241 and Chapter 10 as applicable.

Step 5. Tank unit shorted.

Replace tank unit. Refer to paragraph 8-241 and Chapter 10 as applicable.

# **Table 8-17. Troubleshooting - Fuel Quantity Indicator (Continued)**

## **CONDITION**

## **TEST OR INSPECT**

## **CORRECTIVE ACTIONS**

3. Indicator remains at one point on scale.

STEP 1. No power.

Check Input and output of power supply.

STEP 2. Defective indicator. Refer to paragraphs 8-4 and 8-232.

Replace Indicator. Refer to paragraph 8-7.

STEP 3. Coaxial lead grounded.

Check wiring and repair of replace as necessary.

4. Indicator remains at zero or below.

Open wiring.

Check wiring.

- **8-238.** Removal Fuel quantity Indicator. Refer to paragraph 8-5.
- **8-239. Repair Fuel Quantity Indicator.** Refer to paragraph 8-6.
- **8-240.** Installation Fuel Quantity Indicator. Refer to paragraph 8-7.
- 8-241. FUEL QUANTITY TRANSMITTER.
- **8-242. Description Fuel Quantity Transmitter.** Two fuel transmitters, upper (60, figure 10-1) and lower (20) are installed in fuel cell. These measure fuel quantity and are electrically interconnected by jumper wires inside the fuel cell.
- **8-243. Testing Fuel Quantity Transmitters.** The transmitters are tested in the overall system. Refer to paragraph 8-232.
- **8-244.** Troubleshooting Fuel Quantity Transmitters. Refer to table 8-17.



Fuel tank must be defueled, Refer to paragraph 1-7.

#### 8-245. Removal - Fuel Quantity Transmitters.

- a. Remove upper transmitter as follows:
  - (1) Disconnect electrical connector,
- (2) Remove five screws (66, figure 10-1) and washers (65),
  - (3) Remove retainer (64) and seal (63).
- (4) Lift transmitter (60), remove clamp, bolt, and washer (68) and disconnect electrical wiring interconnecting upper and lower transmitters.
  - (5) Remove transmitter (60) and gasket (62)
  - **b.** Remove lower transmitter as follows:
    - (1) Remove six bolts (22) and washers (21),

- (2) Lower transmitter (20), and disconnect electrical wiring interconnecting upper and lower transmitters.
- (3) Remove lower transmitter (20) and gasket (19).
- **8-246.** Repair or Replacement Fuel Quantity Transmitters. Replace transmitters not meeting testing/adjustment requirements of paragraph 8-232.

#### 8-247. Installation - Fuel Quantity Transmitters.

- a. Install upper transmitter as follows:
- (1) Place gasket (62, figure 10-1) on transmitter (60), install clamp (68) and connect electrical wiring interconnecting upper and lower transmitters.
- (2) Position transmitter (60) through seat back shelf into fuel cell with connector facing aft.
- (3) Place seal (63) and retainer (64) on transmitter and install five screws (66) and washers (65). Torque screws 30 TO 40 INCH-POUNDS,
  - (4) Connect electrical connector.
  - b. Install lower transmitter as follows:
- (1) Place gasket (19) on transmitter (20) and connect electrical wiring interconnecting upper and lower transmitters.
- (2) Place transmitter (20) through sump plate and install with six bolts (22) and washers (21).

#### 8-248. PRESSURE SWITCH.

**8-249.** Description - Pressure Switch. Pressure switch (67, figure 10-1) is installed in fuel tine fitting (8) at top of tank, This switch lights the FUEL BOOST light in the cockpit when the boost pump malfunctions or any loss of pressure is evident.

### 8-250. Inspection - Pressure Switch.

**a.** Inspect electrical terminal for damage and leakage.

**b.** Inspect switch for evidence of leakage and thread condition.

#### 8-251. Removal - Pressure Switch.

- **a.** Remove access plate (12, figure 2-1) on outside skin above filler cap (11). Working through access opening, disconnect electrical wire from pressure switch (67, figure 10-1).
  - **b.** Cut lockwire and remove switch (67).
- **8-252.** Repair or Replacement Pressure **Switch.** Replace switch not meeting inspection requirements.

#### 8-253. Installation - Pressure Switch.

- **a.** Install new packing on switch (67) and screw into adapter.
- **b.** Operational check fuel boost pump and pressure switch. Refer to paragraph 9-149.b.
  - c. Connect electrical lead.
- **d.** LockWire (C95) switch and apply sealant (C129) to access plate (12, figure 2-1) and install access plate.

# 8-254. FREE AIR TEMPERATURE INDICATOR (THERMOMETER).

- **8-255. Description Free Air Temperature Indicator** (Thermometer). The thermometer is mounted in the upper center of the cabin bubble. The thermometer provides the means for measuring the outside free air temperature.
- **8-256. Cleaning Free Air Temperature Indicator** (Thermometer). Refer to paragraph 8-3.
- **8-257.** Inspection Free Air Temperature Indicator (Thermometer). Refer to paragraph 8-4.
- **8-258. Testing Free Air Temperature Indicator (Thermometer).** To test the thermometer, refer to TM 1-1500-204-23.

# 8-259. Removal - Free Air Temperature Indicator (Thermometer).

**a.** Unscrew and remove sunshield, dished washer, and one case washer from outer end of thermometer.

- **b.** Remove thermometer and other case washer from inside of windshield.
- **8-260.** Repair or Replacement Free Air Temperature Indicator (Thermometer). Replace the thermometer if it does not meet performance requirements

# 8-261. Installation - Free Air Temperature Indicator (Thermometer).

- **a.** Place a rubber case washer over probe of thermometer with flat side of washer next to case. Insert probe through mounting hole from inside windshield.
- **b.** Place another rubber case washer, flat side out, on thermometer probe outside windshield. Seal washer shoulders in mounting hole. Install dished washer, with outside edge curving toward windshield. Position thermometer scale correctly before tightening.
- **c.** Place sunshield over thermometer probe and tighten securely.

#### 8-262. CLOCK.

- **8-263. Description -** Clock. The clock, in instrument panel, has a sweep-second pointer and a minute totalizer hand to indicate elapsed time. The control knob on case stops pointers when pressed and returns pointers when pressed again.
- 8-264. Cleaning Clock. Refer to paragraph 8-3
- **8-265. Inspection -** Clock. Refer to paragraph **8-4**.
- 8-266. Removal Clock. Refer to paragraph 8-5
- **8-267. Installation -** Clock. Refer to paragraph **8-7.**
- 8-268. DC AMMETER.
- **8-269. Description -** DC Ammeter. The DC ammeter mounted in the instrument cluster, measures and indicates the output of the generator in amperes
- **8-270. Cleaning DC Ammeter.** Refer to para graph 8-3.

**8-271. Inspection - DC Ammeter.** Refer to paragraph 8-4.

**8-272.** Troubleshooting - DC Ammeter. Use table 8-18 and perform necessary checks to isolate trouble.

#### NOTE

Before using table 8-18, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 8-18, notify the next higher level of maintenance,

### Table 8-18. Troubleshooting — DC Ammeter

#### CONDITION

**TEST OR INSPECTION** 

#### CORRECTIVE ACTION

1. No reading or erratic reading.

STEP 1. Defective generator. Refer to paragraph 9-22,

Replace genarator. Refer to paragraph 9-42.

STEP 2. Open or short circuit in ammeter,

Replace ammeter. Refer to paragraph 8-7.

STEP 3. Dirty or worn mechanism in ammeter.

Replace ammeter, Refer to paragraph 8-7.

STEP 4. Voltage regulator faulty. Refer to paragraph 9-52.

Replace voltage regulator. Refer to paragraph 9-57,

STEP 5. Open or defective circuit breakers (located in aft electrical compartment).

Check and replace circuit breakers as required.

**8-273.** Removal - DC Ammeter. Refer to paragraph 8-5.

**8-274.** Repair or Replacement - DC Ammeter. Refer to paragraph 8-6.

**8-275. Installation - DC Ammeter.** Refer to paragraph 8-7.

8-276. FUEL FILTER PRESSURE SWITCH.

Refer to paragraph 9-164.

8-277. TRANSMISSION OIL PRESSURE SWITCH.

Refer to paragraphs 9-169 and 6-277.

# 8-278. TRANSMISSION OIL PRESSURE INDICATING SYSTEM C.

**8-279. Description** — **Transmission Oil Pressure Indicating System.** The transmission oil pressure indicating system consists of the transmission oil pressure indicator, the transmission oil pressure transmitter, and interconnecting wiring. Refer to figure F-33.

# 8-280. Testing — Transmission Oil Pressure Indicating System.

- **a.** Disconnect fluid pressure line from transmission oil pressure port.
- **b.** Disconnect freewheeling oil pressure line from cross fitting at oil pressure transmitter. Cap or plug openings.
- **c.** Connect a pressure gage **(0 100** psi) MPI or equivalent (T6) to the input line on the transmission oil pressure transmitter.

- d. Close XMSN OIL PRESS circuit breaker.
- **e.** Apply pressure gradually until applied pressure is 70 psi.
- **f.** Transmission oil pressure indicator shall indicate 70 (red line) (±5) psi.

**8-281.** Troubleshooting — Transmission Oil Pressure Indicating System. Troubleshoot the system in accordance with table 8-19.

#### **NOTE**

Before using table 8-19, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 8-19, notify the next higher level of maintenance.

# Table 8-19. Troubleshooting — Transmission Oil Pressure Indicating System C

CONDITION

TEST OR INSPECTION

### **CORRECTIVE ACTION**

- 1. Pressure indicator is reading low.
  - STEP 1. Check for kinked or obstructed pressure line.

Replace or clean obstructed line. Refer to paragraph 8-4.

- 2. Pressure indicator is inaccurate or sticking.
  - STEP 1. Determine if indicator is defective.

Replace indicator if defective. Refer to paragraphs 8-288 and 8-290.

- 3. Pressure indicator has sluggish action.
  - STEP 1. Check for sludge in pressure line.

Bleed pressure line. Refer to paragraph 8-4.

## Table 8-19. Troubleshooting - Transmission Oil Pressure Indicating System C (Cont)

CONDITION

**TEST OR INSPECTION** 

#### **CORRECTIVE ACTION**

4. Pressure indicator is inoperative.

STEP 1. Perform continuity check of circuits.

Repair or replace electrical wires.

STEP 2. Determine if indicator is defective.

Replace indicator if defective. Refer to paragraphs 8-288 and 8-290.

STEP 3. Determine if transmitter is defective.

Replace transmitter if defective. Refer to paragraphs 8-297 and 8-299.

- 5. Pressure indicator shows fluctuating pressure.
  - STEP 1. Check for loose electrical connections and determine if indicator is clamped too tight.

Tighten electrical connections or readjust clamp.

STEP 2. Determine if incorrect restictor is installed in system.

Install correct restrictor.

# 8-282. TRANSMISSION OIL PRESSURE INDICATOR C.

**8-283. Description - Transmission Oil Pressure Indicator.** The transmission oil pressure indicator, located on the instrument panel, indicates transmission oil pressure in psi. The indicator receives electrical signals from the transmitter equal to the oil pressure.

**8-284.** Cleaning - Transmission Oil Pressure Indicator. Refer to paragraph 8-3.

**8-285.** Inspection - Transmission Oil Pressure Indicator. Refer to paragraph 8-4.

**8-286.** Testing - Transmission Oil Pressure Indicator. Refer to paragraph 8-280.

**8-287.** Troubleshooting - Transmission Oil **Pressure Indicator.** Refer to paragraph 8-281.

**8-288.** Removal - Transmission Oil Pressure Indicator. Refer to paragraph 8-5.

**8-289.** Repair or Replacement - Transmission Oil Pressure Indicator. Refer to paragraph 8-6.

**8-290.** Installation - Transmission Oil Pressure Indicator. Refer to paragraph 8-7.


8-291. TRANSMISSION OIL PRESSURE TRANSMITTER C.

**8-292.** Description - Transmission Oil Pressure Transmitter. The transmission oil pressure transmitter, located on the cabin roof deck, is

attached to the cross containing the low pressure oil switch.

# 8-293. Cleaning - Transmission Oil Pressure Transmitter.

a. Remove moisture and loose dirt with a clean, soft cloth.



Drycleaning solvent is flammable and fumes are toxic. Provide adequate ventilation. Do not use near a flame.

- **b.** Remove oil, grease, fungus, and ground-in dirt with a clean, lint-free cloth dampened with drycleaning solvent (C62).
- **c.** Remove dirt from electrical connector with a bristle brush (C31).

# 8-294. Inspection - Transmission Oil Pressure Transmitter.

- **a.** Inspect transmitter for cracks, secure and proper mounting, and proper operation.
- **b.** Inspect oil line and fitting connection for leaks and proper installation.
- **c.** Inspect electrical connector for damaged or bent pins and cracked inserts.

# **8-295.** Testing - Transmission Oil Pressure Transmitter. Refer to paragraph 8-280.

# **8-296.** Troubleshooting - Transmission Oil Pressure Transmitter. Refer to paragraph 8-281.

# 8-297. Removal - Transmission Oil Pressure Transmitter.

- **a.** Disconnect electrical connector and place protective covers over connectors.
- **b.** Disconnect transmission oil pressure line and place protective cover over oil line.
- **c.** Remove lockwire and mounting screws securing oil pressure transmitter in mounting bracket.
  - d. Lift transmitter from mounting bracket.

# 8-298. Repair or Replacement - Transmission Oil Pressure Transmitter.

- a. Repair damaged electrical connector.
- **b.** Tighten loose oil line or fitting connection.
- c. Replace defective or damaged oil line or fitting.
- d. Replace transmitter if cracked or damaged.
- **e.** Reinstall improperly mounted pressure transmitter.

# 8-299. Installation - Transmission Oil Pressure Transmitter.

- **a.** Remove protective cover from oil pressure line.
- **b.** Place new preformed packing on transmission oil pressure line. Torque transmitter **40 T0 65 INCH-POUNDS.**
- **c.** Secure transmitter to cabin roof with bracket mounting screw and lockwire.
- **d.** Remove protective cover from electrical plug and connect to transmitter.

### **CHAPTER 9**

# **ELECTRICAL SYSTEM**

## 9-1. ELECTRICAL SYSTEM.

#### 9-2. General.

- **a.** Power loading charts and detailed system wiring diagrams are contained in Appendix F. Maintenance activities shall request assistance for electrical system repairs in accordance with the maintenance allocation chart, Appendix B.
- **b.** Refer to figure 9-1 for electrical equipment locations, figures F-4 through F-39 for systems diagrams, table F-1 for equipment listing and table F-2 for connector replacement chart.

#### NOTE

Illustrations pertaining to circuit breakers, control panel arrangement and face

identification are contained in TM 55-1520-228-10.

When performing operational checks, external power set to 28Vdc (±0.5) volt will be utilized whenever possible. The battery is an emergency power source only. Perform operational checks to make certain that circuits are free of possible potential malfunction when equipment is replaced or airframe wiring is repaired or replaced. Words, cycles or hertz, are used to designate frequency. Either word has the same meaning. The abbreviation cps carries the same meaning as Hz.

Electrical connectors are to be lockwired in accordance with TM 55-1500-323-24.

## SECTION I. DIRECT CURRENT POWER DISTRIBUTION SYSTEM

# 9-3. DIRECT CURRENT POWER DISTRIBUTION SYSTEM.

# NOTE

For maintenance of the direct current distribution system refer to applicable instructions for each component.

# 9-4. General — Direct Current Power Distribution 9-5. EXTERNAL POWER SYSTEM.

**System.** The OH-58 series helicopter is equipped with a 28-volt direct current dual-bus (essential and nonessential) system supplied by a starter-generator and battery. Major components of the dc power system include battery, starter-generator, voltage regulator, relays, switches, and circuit breakers. All circuits in the electrical system are single wire with common ground return. The negative terminals of the starter-generator and the battery are grounded to the helicopter structure. In the event of generator failure, the battery will furnish power to the essential bus. Power to the nonessential bus will be automatically disconnected. The nonessential bus relay may be manually reactivated.

9-6. Description — External Power System. During ground operations, external power may be connected to the systems through an external power receptacle (J16) located on helicopter fuselage, lower right side of avionics compartment. No special action or switching is necessary to connect external power. If the external power connections are of correct polarity, the external power relay (k1), mounted on the forward bulkhead of the avionics compartment closes automatically and connects the ground unit to the main power cables serving the direct current bus in the avionics compartment. Refer to figures 9-1 and F-8.




Figure 9-1. Equipment Location (Sheet 1 of 10)




Figure 9-1. Equipment Location (Sheet 2) A

A1	Caution Panel	K10	Relay, Inverter Fail
A2	Impedance Pad	K11	Relay, Generator Fail
B1	Fuel Pump	K12	Relay, Line Control
В3	Governor Control Actuator	K15	Relay, Heater
B4	Engine De-ice Control	K16	Relay, Fuel Boost
B7	Defog Blower (Right)	K45	Relay Engine Relight
B8	Defog Blower (Left)	L1	Hydraulic Bypass Solenoid
BT1	Battery	L2	Solenoid, Heater
CB7	5 Ampere Circuit Breaker (2 Required)	L4	Force Trim — Fore and Aft
CR7	Diode, External Power Relay	L5	Force Trim - Lateral
CR8		P38	RPM Sensor
CR9		PS1	Inverter
	2 Diode	QÍ	Transistor, Dimming Element
DS1	Anticollision Light, Upper	R1	Resistor, Turbine Outlet Temperature
DS2	Position Light, Left	R3	Resistor, Shunt
DS3	Position Light, Right	R33	Resistor, Position Lights
DS4	Position Light, Tail	S3	Switch, Transmission Oil Temperature
DS5	Anticollision Light, Lower	S4	Switch, Oil Pressure
DS6	Cockpit Light	S12	Switch, Fuel Pressure
DS7	Landing Light	S18	Sensor, RPM
DS8	Landing Light		Switch, Heater Overheat
DS17	Audio Warning, Engine Out	TB1	Terminal Board, Instrument Panel
E3	Chip Detector, Engine, Upper	TB3	Terminal Board, Turbine Outlet
E4	Chip Detector, Tail Rotor	TB4	Terminal Board, Console
E5	Chip Detector, Transmission	TB5	Terminal Board, Utility Light
E6	Chip Detector, Engine, Lower	TB6	Terminal Board, Lighting
E7	Chip Detector, Transmission	TB7	
G1	Starter-Generator		Terminal Board, Oil Level
G2	Rotor Tach Generator		Terminal Board, Instrument Lighting
G3	Power Turbine Tach Generator		Terminal Board, Ground
G4	Gas Producer Tach Generator		Terminal Board, Landing Lights
HR1	Pitot Tube Heater		Terminal Board, Master Caution Panel
J16	Receptacle, External Power		Terminal Board, Diode Instrument
K1	Relay, External Power	ТВ30	Terminal Board, Diode Instrument
K2	Relay, Nonessential Bus	VR1	Voltage Regulator
K3	Relay, Starter	Z1	Ignition Exciter
K4	Relay, Engine Oil Bypass	<b>Z2</b>	Engine Oil Temperature Bulb
K6	Relay, Battery	<b>Z</b> 5	Upper Fuel Tank Unit
K8	Relay, Landing Light — Forward	Z6	Lower Fuel Tank Unit
K9	Relay, Landing Light — Aft	Z10	Anticollision Flasher

206075-275-3

Figure 9-1. Equipment Location (Sheet 3)




Figure 9-1. Equipment Location (Sheet 4) (Prior to compliance with MWO 55-1520-228-50-32)





Figure 9-1. Equipment Location (Sheet 5) (Prior to compliance with MWO 55-1520-228-50-32)

A1	Caution Panel	K18	Relay, Night Vision Goggles
A2	Impedance Pad	K19	Relay, Caution Light
B1	Fuel Pump	K45	Relay, Engine Relight
B3	Governor Control Actuator	L1	Solenoid, Hydraulic Bypass
B4	Engine De-ice Control	L2	Solenoid, Heater
B7	Defog Blower (Right)	<u>14</u>	Force Trim — Fore and Aft
B8	Defog Blower (Left)	L5	Force Trim — Lateral
BT1	Battery	P513	Plug, Time Delay Relay
CR7	Diode, External Power Relay	PS1	Inverter
CR8	Diode, Force Trim — Fore and Aft	PS1	Power Supply
CR9	Diode, Trim Lateral Force	PS2	Power Supply
	Diode, Tilli Lateral Toroc	Q1	Transistor, Dimming Element
DS1	Anticollision Light, Upper	R1	Resistor, Turbine Outlet Temperature
DS2	Position Light, Left	R3	Resistor, Shunt
DS3	Position Light, Right	R33	Resistor, Position Lights
DS4	Position Light, Tail	<b>S3</b>	Switch, Transmission Oil Temperature
DS5	Anticollision Light, Lower	<b>S4</b>	Switch, Transmission Oil Pressure
DS6	Cockpit Light	<b>S12</b>	Switch, Fuel Pressure
	Audio Warning, Engine Out	S18	Sensor, RPM
E3	Chip Detector, Engine, Upper	<b>S90</b>	Switch, Heater Overheat
E4	Chip Detector, Tail Rotor	<b>S90</b>	Switch, Night Vision Goggles
E5	Chip Detector, Transmission	TB1	Terminal Board, Instrument Panel
E6	Chip Detector, Engine, Lower	TB3	Terminal Board, Turbine Outlet
E7	Chip Detector, Transmission	TB4	Terminal Board, Console
G1	Starter-Generator	TB5	Terminal Board, Cockpit Light
G2	Rotor Tach Generator	TB6	Terminal Board, Lighting
G3	Power Turbine Tach Generator	TB7	Terminal Board, Position Lights
G4	Gas Producer Tach Generator		Terminal Board, Oil Level
HR1	Pitot Tube Heater		Terminal Board, Instrument Lighting
J16	Receptacle, External Power		Terminal Board, Ground
J517	Receptacle, Control Relay		Terminal Board, Landing Lights Terminal Board, Master Caution Panel
K1	Relay, External Power		Terminal Board, Master Caution Panel Terminal Board, Diode Instrument
K2	Relay, Nonessential Bus		Terminal Board, Diode Instrument
КЗ	Relay, Starter	TB30	
K4	Relay, Engine Oil Bypass		Terminal Board, Interior Lights
K6	Relay, Battery	VR1	Voltage Regulator
K8	Relay, Landing Light — Forward	VR2	Voltage Regulator
K9	Relay, Landing Light - Aft	Z1	laniter
K10	Relay, Inverter Fail	Z2	Engine Oil Temperature Bulb
K11	Relay, Generator Fail	<b>Z</b> 5	Upper Fuel Tank Unit
K12	Relay, Line Control	Z6	Lower Fuel Tank Unit
K15	Relay, Heater	Z10	Anticollision Flasher
K16	Relay, Fuel Boost	2.0	······································
	,,		AAAAT 275 C

206075-275-6

Figure 9-1. Equipment Location (Sheet 6) (Prior to compliance with MWO 55-1520-228-50-32)







Figure 9-1. Equipment Location (Sheet 8) C (After compliance with MWO 55-1520-228-50-32)


		К18	Relay, Night Vision Goggles
A1	Caution Panel	К19	Relay, Caution Light
A2	Impendance Pad	K45	Relay, Engine Relight
B1	Fuel Pump	L1	Solenoid, Hydraulic Bypass
В3	Governer Control Actuator	L2	Solenoid, Heater
B4	Engine De-ice Control	L4	Force Trim — Fore and Aft
B7	Defog Blower (Right)	L5	Force Trim — Lateral
B8	Defog Blower (Left)	P513	Plug, Time Delay Relay
BT1	Battery	PS1	Inverter
CR7	Diode, External Power Relay	PS1	Power Supply
CR8	Diode, Force Trim — Fore and Aft	PS2	Power Supply
CR9	Diode, Trim Lateral Force	Q1	Transistor, Dimming Element
CR12	Diode	R1	Resistor, Turbine Outlet Temperature
DS1	Anticollision Light, Upper	R3	Resistor, Shunt
DS2	Position Light, Left	R33	Resistor, Position Lights
DS3	Position Light, Right	<b>S3</b>	Switch, Transmission Oil Temperature
DS4	Position Light, Tail	<b>S4</b>	Switch, Transmission Oil Pressure
DS5	Anticollision Light, Lower	S12	Switch, Fuel Pressure
DS6	Cockpit Light	S131	Switch, NVG Position Lights
DS17	Audio Warning, Engine Out	\$18	Sensor, RPM
DS61	NVG Position Light	S90	Switch, Heater Overheat
DS63	NVG Position Light	S90	Search/Landing (Dual) Light
DS64	NVG Position Light	TB1	Terminal Board, Instrument Panel
E3	Chip Detector, Engine, Upper	TB3	Terminal Board, Turbine Outlet
E4	Chip Detector, Tail Rotor	TB4	Terminal Board, Console
E5	Chip Detector, Transmission	TB5	Terminal Board, Cockpit Light
E6	Chip Detector, Engine, Lower	TB6	Terminal Board, Lighting
E7	Chip Detector, Transmission	TB7	Terminal Board, Position Lights
G1	Starter-Generator	TB14	Terminal Board, Oil Level
G2	Rotor Tach Generator	TB25	Terminal Board, Instrument Lighting
G3	Power Turbine Tach Generator	TB26	Terminal Board, Ground
G4	Gas Producer Tach Generator	TB27	Terminal Board, Landing Lights
HR1	Pitot Tube Heater	TB28	Terminal Board, Master Caution Panel
J16	Receptacle, External Power	TB29	Terminal Board, Diode Instrument
J517	Receptable, Control Relay	TB30	Terminal Board, Diode Instrument
K1	Relay, External Power	TB31	Terminal Board, Interior Lights
K2	Relay, Nonessential Bus	TB32	Terminal Board, Interior Lights
K3	Relay, Starter	TB33	Terminal Board, NVG Floodlights
K4	Relay, Engine Oil Bypass	TB35	Terminal Board, NVG Pos Lts
K6	Relay, Battery	TB36	Terminal Board, NVG Pos Lts
K8	Not Used	VR1	Voltage Regulator
K9	Not Used	VR2 Z1	Voltage Regulator
K10	Relay, Inverter Fail		Ingiter
K11 K12	Relay, Generator Fail Relay, Line Control	Z2 Z5	Engine Oil Temperature Bulb Upper Fuel Tank Unit
K12 K15	•	25 26	Lower Fuel Tank Unit
K15 K16	Relay, Heater	Z10	Anticollision Flasher
KIU	Relay, Fuel Boost	210	AUTOMISION LIGSTICE

206075-275-9

Figure 9-1. Equipment Location (Sheet 9) C (After compliance with MWO 55-1520-228-50-32)



DETAIL A



206075-275-10

Figure 9-1. Equipment Location (Sheet 10)



Battery switch will be in OFF position prior to connecting external power source.

**9-7. Testing - External Power System.** Before connecting external power for the first time, check wiring for correct polarity and terminations at external power receptacle (J16).

#### NOTE

### Ensure GEN and BUS reset circuit breaker is open.

- **a.** Apply 28 Vdc reverse polarity between the small pin on external power receptacle (J16) and ground. Check that external power relay (K1) does not close. Remove 28 Vdc reverse polarity.
- **b.** Connect an external 28 Vdc power source to external power receptacle. Energize the power source. Measure voltage on main dc bus in the overhead console. Check that bus voltage is within one volt of the external power source voltage.
- **c.** Place NON-ESS BUS switch (S81) to MAN. Check that no voltage is present on the nonessential dc bus (located in the overhead console).
- **d.** Ensure that GEN & BUS RESET circuit breaker is closed. Check that voltage on the nonessential dc bus is within one volt of external power source voltage.
- **e.** Place NON-ESS BUS switch to NORM. Check that voltage on nonessential dc bus is within one volt of external power source voltage.
- **f.** De-energize external power source. Check that there is no voltage on the essential dc bus.
- **9-8. Troubleshooting External Power System.** Refer to table 9-1 and figure F-8.

### NOTE

Before using table 9-1, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-1, notify the next higher level of maintenance.

### 9-9. EXTERNAL POWER RECEPTACLE.

- **9-10. Description External Power Receptacle.** The external power receptacle (J16) is a polarized receptacle used as contact point for external power plug-in.
- **9-11.** Inspection External Power Receptacle. Inspect the external power receptacle for the following:
  - a. Contact corrosion
  - b. Faulty insulation
  - c. Broken wires
  - d. Faulty contacts.

### 9-12. Removal - External Power Receptacle.

- **a.** Place the BAT switch to OFF and ensure battery is disconnected.
- **b.** Remove attachment screws and extract receptacle enough to gain access to power cables.
- **c.** Disconnect power cables and wrap terminals with electrical tape (C137).

### 9-13. Installation - External Power Receptacle.

- **a.** Remove tape from wire ends and connect cables to receptacle.
- **b.** Position receptacle in helicopter and install attachment screws.

### 9-14. EXTERNAL POWER RELAY.

- **9-15. Description External Power Relay.** The external power relay (K1) is an electrically operated switch between the external power receptacle and essential bus. It is controlled through the small positive pin from the external power source which energizes the circuit to the activating coil of the relay only when the external applied voltage is of proper polarity.
- **9-16. Inspection External Power Relay.** Inspect the external power relay for the following:
  - a. Broken pins

### Table 9-1. Troubleshooting - External Power System

### CONDITION

### **TEST OR INSPECTION**

### **CORRECTIVE ACTION**

- 1. Lack of power when external power plug is inserted into J16.
  - STEP 1. Ensure connectors at attachment points to APU are installed correctly.

### If installed correctly, reverse polarity in plug.

STEP 2. Ensure external power relay (K1) is operative.

### If inoperative, replace relay (K1).

STEP 3. Check voltage output relay (K1)

### If below 28 (±0.5) Vdc, increase output or obtain APU with correct output.

- 2. External power relay (K1) is energized with reverse polarity applied to EXT PWR receptacle.
  - STEP 1. Check for condition of diode (CR7).

### Replace defective diode.

STEP 2. Check wiring for condition, security, and continuity.

### Replace defective wiring.

- **b.** Discoloration
- c. Any obvious damage.

### 9-17. Removal - External Power Relay,

- **a.** Place BAT switch to OFF. Remove external power and ensure battery is disconnected.
- **b.** Remove attaching hardware and remove bus bar.
- **c.** Disconnect wires from relay and tape ends using electrical tape (C137).

**d.** Remove attachment bolts and lift relay free from compartment.

### 9-18. Installation - External Power Relay.

- a. Position relay and install mounting hardware.
- b. Remove tape and connect relay wires.
- c. Install and secure bus bar.

# **9-19. Troubleshooting - External Power Relay.** Refer to table 9-1 for troubleshooting of external power relay (K1).

#### 9-20. **BATTERY AND GENERATOR SYSTEM**

9-21. Description Battery and Generator System. The battery (BT1) furnishes power through relay (K6) when the generator is inoperative. During normal operation, the generator portion of the STARTERGENERATOR (G1) furnishes power at a regulated voltage for all dc electrical components on the helicopter. The battery is capable of supplying electrical power for four consecutive engine starts with 30 second elapsed time between starting cycles. In the event the starter-generator fails, the battery supplies all loads essential to flight. The starter generator, which is self-excited, normally switches onto the main power cables after the engine start procedure when the generator voltage exceeds the voltage on the bus by 0.30 to 0.42 volt. The line control relay (K12) connects generator power to the bus. The voltage regulator (VR1) operates the line control relay, regulates generator voltage, and provides protection against over-voltage (Figure 9-1 and F-8). current flowing through the shunt resistor (R3) allows the ammeter to indicate the amps being used by the operating circuits. The generator fail relay (K11) controls operation of nonessential bus relay (K2) and the generator caution light

#### 9-22. **Testing Battery and Generator System.**

- a. Operational Check Battery Circuits. Ensure that battery quick disconnect is connected to the battery. Place BAT switch to BAT position, Turn on electrical device operating from essential bus to determine if battery power is available at the essential bus.
- b. Operational Check General Circuitry. With engine at operating rpm, turn on generator switch and note indication on ammeter. Add load such as landing light and/or Inverter.
- Operational Check Electrical Circuitry. Disconnect wires with P19C8 and P19D8 from positive terminal B on the starter-generator and connect them to the positive lead of external power source. Take care to isolate connection from helicopter structure. Connect negative lead of external power source to negative terminal E on the starter-generator. Place a jumper wire from terminal D to terminal E on the starter-generator. Disconnect wire P24A16 from starter-generator and take care to isolate wire from aircraft structure. Do not energize power source until specified in the following procedure.

NOTE

The following test shall be performed with the helicopter battery installed or an external 24 to 28 Vdc power source connected at the battery connector.

- (1) Ensure that CAUTION PNL LTS circuit breaker is closed. Place BAT switch to BAT. Check that DC GENERATOR caution light is illuminated.
- (2) Ensure that GEN FIELD circuit breaker is closed. Place the NON-ESS switch to NORM. Energize external power source and adjust to 28 (+1) Vdc. Place GEN/RESET switch to RESET and then go to GEN. Check that the DC GENERATOR caution light is extinguished and that voltage on the essential and nonessential dc buses within one volt of external power source voltage.
- (3) Ensure that LOADMETER circuit breaker is closed. Momentarily turn on a load such as the landing lights. Check that the helicopter ammeter reads upscale.
- (4) Open GEN FIELD circuit breaker. Check that nonessential bus voltage is zero, that essential bus voltage is within one volt of battery voltage, and that the DC GENERATOR caution light is illuminated.
- (5) Ensure that GEN FIELD circuit breaker is closed. Check that the results described in step (2) are obtained.
- (6) Place BAT switch to OFF. Connect the voltmeter to the main dc bus (located on aft electrical shelf over the fuel cell). While monitoring the voltmeter, slowly decrease external power source voltage until voltage indication suddenly drops to zero. Connect the voltmeter to terminal A1 (generator side) on the line control relay K12. Check that the voltage indication is 18 (+1.8) Vdc and that the DC GENERATOR caution light Is illuminated.

### **CAUTION**

DO NOT exceed 33 volts. Damage to equipment may occur.

(7) Reconnect the voltmeter to the main dc bus. While monitoring the voltmeter, slowly increase external power source voltage until voltage indication suddenly deflect upscale. Check that voltage indication is **24** ( $\pm$ **2.4**) Vdc and that the DC GENERATOR caution is extinguished.

### CAUTION

### DO NOT exceed 33 volts. Damage to equipment may occur.

- (8) While monitoring the voltmeter, slowly increase external power source voltage until voltage indication suddenly drops to **zero**. Connect the voltmeter to terminal A1 on line control relay. Check that the voltage indication is 32 (11) Vdc and that the DC GENERATOR caution light is illuminated.
- **(9)** Place BAT switch to BAT. Place the GEN/RESET switch to RESET and the GEN. Check that the DC GENERATOR caution light remains illuminated (no voltage on the main dc bus).
- (10) Decrease external power source voltage to approximately 28 volts. Place the GEN/RESET switch to RESET and the to GEN. Check the DC GENERATOR

caution light is extinguished and the external power source voltage is present on the main dc bus.

(11) Place BAT switch to OFF and de-energize the external power source. Disconnect wires P19C8 and P19D8 from the positive lead of external power source and connect them to positive terminal B on the startergenerator. Disconnect negative lead of external power source from negative terminal E on the starter-generator. Remove jumper wire from terminal D and E on the starter-generator. Check that connections are properly mated, tight, and secure. Secure wire P24A16 to starter-generator.

### **9-23.** Troubleshooting Battery and Generator. Refer to Table 9-2.

### NOTE

Before using Table 9-2, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in Table 9-2, notify the next high level of maintenance.

Table 9-2. Troubleshooting - Battery and Generator

### CONDITION

### TEST OR INSPECTION CORRECTIVE ACTION

BATTERY (BT1) WILL NOT HOLD A CHARGE.

Step 1. Check for excessive battery demand.

Use external power source, when possible, and check battery after operations completed.

Step 2. Check generator output voltage.

Adjust if necessary to maintain battery charge.

Step 3. Check battery for dead or unbalanced cells or broken partitions.

Replace battery.

Step 4. Check for broken wiring, short circuits, or grounded wire.

Repair or replace wiring.

### Table 9-2. Troubleshooting - Battery and Generator (Cont)

### CONDITION

**TEST OR INSPECTION** 

### **CORRECTIVE ACTION**

2. Short battery life in service or excessive loss of electrolyte

STEP 1. Check for electrolyte level below plate

Replace battery.

STEP 2. Terminals corroded

Clean terminals and connectors with fiber brush, rinse with clean water, and wipe dry.

STEP 3. Check for proper maintenance of battery and correct servicing (cells overfilled)

Replace battery. Check generator output and adjust if necessary.

3. Reverse voltage from battery to bus.

STEP 1. Check leads at battery plug.

Connect leads properly.

STEP 2. Battery charged in reverse direction

Replace battery.

4. Battery toggle switch actuation fails to turn on power.

STEP 1. Check battery and connections.

Connect battery or if connected, check battery voltage at terminals. Replace battery if not charged.

STEP 2. Check for burned or corroded contacts or open coil

Replace battery relay.

STEP 3. Check battery switch and circuitry

Repair or replace defective switch or wiring,

5. Starter-generator produces voltage but ammeter does not register.

STEP 1. Check ammeter circuit breakers, wiring, etc.

Repair or replace defective component or wiring of ammeter circuitry.

### Table 9-2. Troubleshooting - Battery and Generator (Cont)

### CONDITION

**TEST OR INSPECTION** 

### **CORRECTIVE ACTION**

- 6. No voltage output from starter-generator.
  - STEP 1. Check generator switch in overhead console for 24 (±2.4 volts) at output terminal.
  - STEP 2. Check voltage regulator for continuity between terminals and residual magnetism.

### Replace faulty regulator.

STEP 3. Check generator Wiring continuity and field winding for open circuit.

### Replete generator or repair wiring.

STEP 4. Check for sheared shaft or burned armature.

### Replace starter-generator.

STEP 5. Check for shorted field winding or armature.

### Replace generator.

STEP 6. Visually check brushes for binding or excessive wear.

### Replace worn brushes, or if binding in holder, remove, dean, and reset brushes.

STEP 7. Check for dirty, pitted, or rough commutator.

### If dirty - clean. If rough or pitted - replete starter-generator.

- 7. Movement of regulator adjustment does not alter voltage within normal range, ammeter fluctuates rapidly, or voltage varies excessively with changes in engine speed or electrical load.
  - STEP 1. Check voltage regulator and circuitry.

### Repair or replace faulty regulator.


#### 9-24. **BATTERY**.



Use an acetic acid solution to neutralize any spillage of the alkaline. Do not use a sodium bicarbonate (baking soda) solution.

### 9-25. Description - Battery.

- **a.** The battery installation consists of a vented 24 volt 13 ampere hour nickel-cadmium battery (BT1) located in the avionics compartment (figure 9-1). This battery uses an alkaline electrolyte.
- **b.** Batteries may be checked during normal helicopter operations as follows: A fully charged battery can be determined only by moving the BAT switch from BAT to OFF and observing the effect on the generator ammeter. If the change in indication is less than **5.00** amperes the battery is fully charged.



Do not open battery compartment and attempt to remove overheated battery. In no case should C02 fire extinguisher be used to cool overheated battery and or to displace battery gases trapped within battery compartment.

The electrolyte used in nickel-cadmium batteries contains potassium hydroxide (KOH), which is a caustic chemical agent. Serious and deep burns of body tissue will result if the electrolyte comes in contact with the eyes or any part of the body. Use rubber gloves, rubber apron, and protective eye covering when handling the battery. If accidental contact with the electrolyte is made, use ONLY clean water and immediately (seconds count) flush contaminated areas. Continue flushing with large quantities of clean water. Seek medical attention immediately. Before removing or installing the battery, ensure that the battery switch is off and the battery has cooled down If overheated. Removal or installation of the battery connector while battery is under load may result in explosion. electrical arcing and possible severe burns to personnel. Take every possible step to keep the nickel/cadmium battery as far away as possible from the lead-acid type of battery. Do not use the same tools and materials (screwdrivers, wrenches, gloves, apron, etc.) for both types of batteries. Anything associated with the lead-acid battery, even the air, must never come in contact with the nickelcadmium battery or its electrolyte. Even a trace of sulfuric acid fumes from a lead-acid battery may result in damage to the nickel-cadmium battery. If sulfuric acid has been Inadvertently mixed with the electrolyte In the battery, the upper areas of the cells will appear greenish in color. In such cases, the battery must be replaced.

### 9-26. Inspection - Battery.

- a. Check for loose connections at battery disconnect.
- **b.** In cases where the battery fluid has spilled or corroded the battery floor, take the following action.
- (1) Inspect the two battery vent tubes to make certain that they are not clogged or contaminated on the inside with battery fluid residue.
- **(2)** To repair or replace damaged floor area refer to paragraph 2-237.
- (3) Inspect the battery vent tubes to see that they project outside the helicopter approximately one inch and the scarf on the forward tube faces directly forward and the scarf on the aft tube faces directly aft.
- **c.** Check for damage to individual cell cases (distortion due to overcharge, cracks, or leaks).
  - d. Check connectors and terminals for corrosion.
- **e.** Inspect condition of pressure relief portion of vent cap.

- **9-27. Inspection Battery Quick-Disconnect**. Disengage battery cable from battery receptacle and inspect cable connector for:
  - a. Evidence of corrosion or pitting of helix.
  - b. Excess free-play in handwheel-worm assembly.
  - c. Evidence of arcing or burn marks on helix.

### **CAUTION**

To avoid damage to cable connector, work-aid Inspection gage used below must be inserted and withdrawn In a straight line.

- d. Insert **0.385** inch diameter end of inspection gage (fabricate locally per figure 9-7) into each helix to a depth of **0.437** inches. Fit shall be snug with a force to remove greater than one pound.
- e. Insert **0.370** inch diameter end of inspection gage into each helix to a depth of 0.437 inches. Fit shall be snug with a force to remove greater than one pound.
- f. Replace cable quick-disconnect connector if discrepancies are noted during above inspection.

### 9-28. Cleaning Battery.

- a. Remove battery and clean in accordance with TM 11-6140-203-14-2.
- b. Clean area around battery in accordance with TM  $\cdot$  1-1500-344-23 with battery removed.
- c. Saturate battery tray felt pad in a 3% solution of boric acid and water (if battery tray and felt pad is installed).

### 9-29. Remove Battery.

- a. Check that BAT switch is OFF, and external power is not applied. Open compartment door.
- b. Remove battery quick-disconnect by turning knob counterclockwise.

- c. Disconnect two vent tubes from battery case.
- d. Remove mounting bolts and washers, lift battery and tray from compartment.
  - e. Close compartment door.
- **9-30. Repair Battery**. (Refer to TM 11-6140-203-14-2). Battery and tray must be removed from helicopter to service or repair.

### 9-31. Installation Battery and Tray (figure 9-2).


a. Check to ensure that BAT switch is OFF and external power is not applied. Open compartment door.

#### CAUTION

Battery floor threaded inserts may be stripped out If torque Is exceeded on battery case to floor attaching bolts. Ensure bolts do not bottom out on floor Inserts. Add washers as required.

- b. Place battery and tray assembly on a shelf aligned for connections. Install bolts and washers. Torque **20 TO 25** inch-pound, then coat bolts with sealing compound (C131).
- c. Connect two vent tubes to battery case and tighten damps. Scarf on forward vent tube must face forward. Scarf on aft vent tube must face aft.
- d. Seal battery case rubber adapter to vent tube with adhesive (C7).
- e. Insert cable connector in battery receptacle and secure by turning knob clockwise.
- f. Adjustment of voltage regulator is required after installation of replacement battery. Refer to TM 11-6140-203-14-2.

Change 24 9-19



206075-276

Figure 9-2. Battery and Tray installation

### 19-31.1. Installation of Increased Capacity Battery. (22 AMP)

- **a.** Remove avionics equipment, as required, to provide a free work area at battery location. Disconnect and remove existing battery, hold down hardware and battery tray and insulator, (if installed).
- **b.** Protect any remaining exposed equipment in the work area. Cover all electrical connectors with plastic film and tape or appropriate caps to prevent retry of metal chips, paint, etc.
- **c.** Thoroughly clean battery deck area and repair any damage or corrosion.
- **d.** Remove ADF antenna located below aft electronics compartment to provide access to the lower face of the battery deck.

### CAUTION (

Use caution when drilling holes through avionics compartment floor skin to avoid damage to amplifier located under compartment deck.

- **e.** Layout and drill holes through upper and lower of avionics compartment floor to the dimensions and locations shown in Figure 9-2.1, sheet 2.
- **f.** Crush back honeycomb core of floor panel to dimensions shown in Figure 9-2.1, sheet 2, for each individual insert and plug and sleeve location.
- **g.** Mix a sufficient quantity of adhesive (C-12). Fill each cavity with adhesive and install inserts, sleeves and plugs, as shown in Figure 9-2.1, sheet 2, in accordance With TM 1-1500-204-23.
- **h.** Thoroughly clean and vacuum all metal chips and debris from avionics compartment. Apply one coat of epoxy primer (C116), followed by two coats of lacquer (C-88), to the battery deck area.
- i. Fabricate the two tube assemblies (7) and (8), Figure 9-2.1, sheet 1, to dimensions shown in Figure D-122. Clean the connecting surfaces of the adapters (5) and tubes (6), Figure 9-2.1, sheet 1, with acetone or methyl ethyl keytone and bond with adhesive (C-7) after installation of battery.


- **j.** Install tiedown rod assemblies (4) into tiedown blocks (3) Figure 9-2.1, sheet 1.
- **k.** If desired, to insulate battery from avionics compartment floor, make insulator 11.75 inches by 9.65 inches, (0.020 thickness), from insulator sheet, MIL-P-15037. Position insulator inside retention blocks (2) and tiedown blocks (3) Figure 9-2.1, sheet 1.

### I. Reinstall ADF antenna

- **m.** Check to ensure that BAT switch is OFF and that external power is not applied. Install battery and utilizing existing cable connector, secure cable connector to the battery by turning knob clockwise.
- **n.** Tighten tiedown rod wing nuts and secure with lockwire (C96).
- **o.** Connect the two vent tube assemblies (7) Figure 9-2.1, sheet 1, to battety ease and tighten clamps. Send adapters (5) and tubes (6) per step i.
- **p.** Functionally test electrical system. Adjustment of voltage regulator is required after installation of replacement battery. Refer to TM 11-6140-203-14-2.
- **q.** Make weight and balance changes for installation of 22 AMP battery on appropriate forms.

### 9-32. BATTERY RELAY.

**9-33. Description - Battery Relay.** The battery relay (K6) located on foward bulkhead of avionics compartment is an electrically operated switch controlling battery power to essential BUS.



- **BATTERY**
- 2 RETENTION BLOCK
- 3 TIEDOWN BLOCK 4 TIEDOWN ROD ASSEMBLY
- **TUBE ADAPTER**
- TUBE
- TUBE ASSEMBLY P/N 206-075-544-1 TUBE ASSEMBLY P/N 206-075-544-5




Figure 9-2.1. Alternate Battery Installation (Sheet 2 of 2)

- **9-34. Inspection Battery Relay.** Inspect the battery relay for the following:
  - a. Contact corrosion
  - b. Faulty insulation
  - c. Broken wires
  - d. Faulty contacts.

### 9-35. Removal — Battery Relay.

- **a.** Set BAT switch in the OFF position and ensure battery is disconnected.
- **b.** Remove attaching hardware and remove bus bar from relay.
- **c.** Disconnect wires from relay and tape ends using electrical tape (C137).
  - d. Remove attachment screws and lift relay free.

### 9-36. Installation — Battery Relay.

- a. Position relay and install attaching screws.
- **b.** Remove protective tape and connect wire to relay.
- **c.** Position bus bar on relay and secure with attaching hardware.
  - d. Connect battery.
- **9-37.** Troubleshooting Battery Relay. Refer to table 9-2 for troubleshooting.

### 9-38. STARTER-GENERATOR. (See figure 9-4).

- **9-39. Description Starter-Generator.** The starter-generator (G1) is located on the underside of the engine to the right of the helicopter center line. This unit is used to start the engine, charge the battery and supply power for the operation of dc equipment. Refer to figure 9-1.
- **9-40. Cleaning Starter-Generator.** Clean exterior of unit with a clean cloth moistened in naphtha (C22) and wipe dry.

### 9-41. Inspection — Starter-Generator.

**a.** Check for warped or cracked terminal board or terminal damage.

- **b.** Remove brush cover. Check brush cover for dents, loose or bent pins, broken spring, or damaged insulation
- **c.** Inspect for oil, dirt, or other foreign material that has entered the unit. Remove material with a vacuum cleaner only.

### **CAUTION**

Do not use compressed air for internal cleaning of starter-generator.

The model 23022-20 series, spline shaft, can get out of line with the centerline if any force is applied to it upon removal from the aircraft. This will cause a false wobble indication when checking for wobble. (This is not to be confused with bending of the spline shaft which necessitates shaft replacement.)

**d.** Rotate the splined shaft to check for fan rub, and/ or bearing condition. The shaft should rotate smoothly and not exhibit any slop or wobble. Return defective starter-generators to the repair/overhaul facility.

### **NOTE**

Do not confuse shaft slop or wobble with an out-of-round dampener plate.

- **e.** Inspect commutator for a smooth bright appearance with a light filming.
- **f.** Inspect drive splines for minimum diameter of **0.729** -inch over two **0.096** -inch diameter pins.
  - g. Inspect upper and lower brushes (4 total).
- (1) Brush leads must be flexible and have a bright appearance.
- (2) Brushes must have more than 1/4 life remaining (figure 9-3).
- (3) Brushes must be properly seated. (A 100% set in direction of rotation and a minimum 75% axially is mandatory.)




Figure 9-3. Starter-Generator Brush Wear

### **CAUTION**

Ensure that brush leads are secure and do not rub or hang on brush holder. If brushes pass inspection they must be returned to their exact original position in the starter-generator.

**h.** Reinstall brush band cover and attaching screws. If any of the brushes will require replacement before next scheduled overhaul or inspection, remove for repair. Refer to paragraphs 9-42,9-43, and 9-44.

### 9-42. Removal - Starter-Generator.

#### CAUTION

It is mandatory that the starter-generator be supported by whatever means necessary whenever the clamp is loosened or until the clamp has been installed and properly torqued (45 TO 55 INCH-POUNDS). Unit must never be allowed to support its own weight through drive spline engagement. If this precaution is not observed, damage to the shaft will result, causing premature failure of the shear section.

- **a.** Disconnect all electrical power from helicopter. Disconnect electrical connectors from starter-generator. Protect ends of wires with electrical tape (C137).
- **b.** Loosen clamp and remove air duct from starter-generator.
- **c.** Loosen nut which secures clamp (6, figure 9-4), and with starter-generator (7) held flush to the adapter (5) pad, unlatch clamp (6).
- **d.** Remove clamp (6) and slide starter-generator (7) straight aft from adapter (5) until splined male driveshaft is free of splined female shaft in engine.

### NOTE


Do not rotate splined shaft unnecessarily.

- e. Lower starter-generator to deck of helicopter.
- f. Remove adapter (5), if necessary, as follows:
- (1) Remove four nuts (8) and four washers (9) attaching adapter (5) to engine.
- (2) Remove adapter (5) and gasket (4) from mounting studs.

### 9-43. Repair - Starter-Generator. (AVIM)

- **a.** Remove fan cover assembly (17, figure 9-5) by removing four screws (18).
  - **b.** Remove screws (10) and remove brushes (9).
  - c. Remove locknut (16) and fan (15).
- **d.** Remove screws (6) and washer (7, 8, and 2). Remove commutator and bell (1) from stator and housing assembly.
- **e.** Clean commutator with a clean, lint-free cloth moistened in denatured alcohol (C59). Inspect to the following limits:
  - (1) 2.030 minimum outside diameter.
- (2) Bars under cut to 0.040 inch maximum wide by 0.032 inch deep.






- 1. Gas Producer Tachometer Generator Pad
- 2. Power Turbine Tachometer Generator Pad
- 3. Starter-Generator Pad
- 4. Gasket
- 5. Adapter

- 6. Clamp
- 7. Starter-Generator
- 8. Nut
- 9. Washer

206061-100

Figure 9-4. Starter-Generator and Tachometer Generator Mounting Pads.



- 1. Commutator and Bell
- 2. Washer
- 3. Sleeving
- 4. Screw
- 5. Washer
- 6. Screw
- 7. Washer, Lock
- 8. Washer, Flat
- 9. Brush

- 10. Screw
- 11. Washer, Nonmetallic
- 12. Spring
- 13. Brush Holder
- 14. Stator and Housing Assembly
- 15. Fan
- 16. Nut, Self-locking
- 17. Cover Assembly
- 18. Screw

206061-101

Figure 9-5. Starter-Generator

### **NOTE**

New brushes must be properly seated on the commutator surface. Failure to do so can result in excessive sparking, which causes burning and pitting of the commutator.

- f. Preliminary brush seating
- (1) Place a strip of sandpaper (C124) or finer, slightly wider than the combined width of the two brush halves, around the commutator with the sand side outward. Cut the sandpaper to 1/8-inch less than the commutator circumference. Secure one end of the sandpaper strip to the commutator surface with masking tape, so that the taped end will lead in the direction of rotation, and the other end will remain loose.

- (2) Position commutator and bell (1) on stator and housing assembly (14). Secure with screws (6) and washers (7, 8, and 2).
  - (3) Install brushes (9) and screws (10).
- (4) With brushes seated against sandpaper, carefully rotate the armature by hand in the normal direction of rotation until a full seat is obtained on each brush.
- **(5)** Remove the sandpaper and blow away carbon dust with dry, compressed air.
  - (6) Install fan (15) and locknut (16).
- (7) Install cover assembly (17) and four screws (18).

- g. Brush Run-In Equipment, The following equipment is required for the brush run-in procedure:
  - (1) The 30-volt dc power source.
- **(2)** A set of V-blocks, padded with sponge rubber, to support the starter-generator.
- (3) A single-pole, single-throw switch capable of handling 300 amperes.
- (4) A rheostat having a minimum rating of 10 ohms, 15 amperes.
- (5) A tachometer of suitable range, or a stroboscopic light for indicating starter-generator speed.
- (6) A resistor in the armature circuit having a rating of 0.100 ohms, 200-500 amperes

### **NOTE**

Instead of running the starter-generator as a motor, brush run-in may be accomplished by using a generator test stand t-o drive the starter-generator, and operate as a generator with 50-100 amperes load at 28-30 volts, and 8000 to 10,000 rpm. The instant-filming type brushes that are used in this starter-generator do not required prolonged run-in to produce a satisfactory film on commutator.

- h. Brush Run-In Procedure. Refer to figure 9-6.
- (1) Place the starter-generator on the V-blocks for support and connect terminal E of the starter-generator to the negative terminal of the dc power source. Refer to figure 4-5 for identification of terminals on the starter-generator.
- **(2)** Connect terminal C to the positive terminal of the dc supply in series through the resistor and single-pole, single-throw switch.
- **(3)** Connect terminal A to the switch through the variable rheostat.
- (4) Rotate the rheostat control to the minimum resistance setting and close the switch. The generator should start and run as a motor rotating in a clockwise direction, as viewed from the commutator end.





Figure 9-6. Brush Run-in Diagram



NOTE: All dimensions are in inches

Figure 9-7. Work and Inspection Gage

- (5) Adjust rheostat until generator revolves at approximately **5000** rpm. Allow generator to operate until brushes are seated a minimum of **100%** in direction of rotation and 90% in axial direction.
- (6) Blow out all carbon dust with clean, dry, compressed air.

### 9-44. Installation Start-Generator.

- a. Install adapter (5, Figure 9-4) if removed, and gasket (4) on engine starter-generator pad (3) studs and secure with four washers (9) and four nuts (8).
- b. Clean driveshaft splines and engine mating splines thoroughly. Apply a film of grease (C77) to the splines.

### NOTE

### Grease (C158) can be used as an alternate to lubricate shaft spline on starter-generator.

c. Slide driveshaft splines into mating splines and firmly support unit against adapters (5) pad.

NOTE

# Prior to Installation of start-generator, rotate splined shaft to check for fan rub and clearance between fan and screen.

- d. With bolt unlatched, place clamp (6) on starter-generator (7) and adapter (5).
  - e. Latch bolt and tighten nut snugly on clamp.
- f. Tap damp in several places with a rubber mallet to align and seat damp. Repeat tapping with mallet and torque nut to 45 TO 55 INCH-POUNDS.
- g. Remove electrical tape, connect electrical wires, and secure installation hardware (Figure 4-5). Restore electrical power to helicopter.
- h. Install air duct on starter-generator and tighten damp.
- i. Voltage regulator check is required after replacement of starter-generator. Reference paragraph 9-52.

9-26 Change 24

### 9-45. GENERATOR SHUNT.

- **9-46. Description Generator Shunt.** The generator shunt (R3) is located on the equipment shelf above the avionics compartment and provides a small voltage drop, proportional to the current, to operate the ammeter.
- **9-47. Inspection Generator Shunt.** Inspect generator shunt for corrosion, scatches, defamation, discoloration, or obvious damage.

### 9-48. Removal - Generator Shunt.

- **a.** Plain BAT switch in OFF position and ensure battery is disconnected.
- **b.** Remove upholstered panel, located aft of rear seat, to gain access to generator shunt.
- **c.** Disconnect eletrical wiring and cover ends with tape (C137).
- **d.** Remove mounting screws and washers and remove shunt.

### 9-49. Installation - Generator Shunt.

a. Position shunt and install mounting hardware.

- b. Remove tape and connect wiring.
- c. Replace upholstered panel.

### 9-50. VOLTAGE REGULATOR.

### 9-51. Description Voltage Regulator

### **CAUTION**

An improperly adjusted voltage regulator may cause high battery temperature and thermal runaway, resulting in battery destruction and possible helicopter damage..

A static type voltage regulator (VR1) is located on the equipment shelf above the avionics compartment and is adjustable for 26.0 to 29.0 volt generator output by an adjustment screw located on end of regulator adjacent to connector. The regulator is a component of the basic DC power system and functions in conjunction with the other components of the system to prevent the generator from being connected to the line until operating voltage is attained. It prevents reverse current flow and holds the generator connected to line unless voltage drops to a point where continued operation would be detrimental to the electrical equipment. It also provides increased resistance in the shunt field circuit to weaken the shunt field of the starter-generator during start operation, and maintains approximately 1.0 volt positive applied to generator terminal A during start operation to maintain generator residual IN An additional static type voltage magnetism. IN An additional static type voltage regulator (VR 2) is located on the equipment shelf above magnetism. the avionics compartment and is adjustable to a 6-volt output by use of an adjusting screw located on the upper surface. The regulator is a component of the night vision goggle system and functions to supply the system with a consent voltage. It protects against undercurrents and overvoltage.

### 9-52. Adjustment Voltage Regulator (Installed).

a. (VR1) Set multimeter to the appropriate scale to measure 28 VDC. Connect positive lead DC bus located adjacent to voltage regulator by turning the adjustment screw on the face clockwise to increase voltage and counterclockwise to decrease voltage. Set regulator as follows:

### NOTE

To measure voltage adjustment (VR1), place positive lead of meter on essential bus terminal of relay (K12). Position negative lead on a TM 55-1520-228-23 ground terminal. To preclude frequent voltage regulator setting changes, the

ambient ground level temperature must be considered as a mean (average) value. For example, if the voltage regulator is checked during the month of December In the northeastern United States and the ambient temperature at that time of day is 28°C (82°F), it is doubtful If that temperature would be a mean value, but rather a daily high; therefore, maintenance personnel must consider the mean or average weekly ambient temperature rather than the ambient temperature on a single day.

- (1) (VR 2) Set multimeter to the appropriate scale to measure 28 VDC. Connect the positive lead to pin W at caution panel P-64 (figure F-34) and negative lead to airframe ground. Adjust voltage regulator by turning the adjustment screw, on upper surface of regulator, clockwise to increase voltage and counterclockwise to decrease voltage.
- (2) Electrical components normally depend upon a constant voltage supply from the generator. Generator voltage output is controlled by the voltage regulator which requires requires precision adjustments as follows: (a) Run aircraft engine at normal RPM/percent.
- (b) Battery switch in the normal on position and generator on.

### NOTE

### Adjust each voltage regulator Independently with other generator(s) turned off.

- (c) Ensure that all communications, navigation and instruments are on and all circuit breakers in. This is to provide a load for aircraft DC bus.
- (d) Connect positive probe of a voltmeter (AN/ USM-451 or an equivalent with a DC voltage scale accuracy of 1 percent) to any convenient point of battery/ essential bus and connect negative probe of voltmeter to a convenient aircraft ground. If a 1 percent voltmeter is not available, an AN/USM-223 or equivalent multimeter may be used; however, aircraft regulator should be readjusted using a 1 percent accurate voltmeter at the earliest possible time.
  - (e) Read and record voltage.

9-27 (f) Using table on next page, adjust voltage regulator according to seasonal average high (ambient ground level) temperature

#### TM 55-1520-228-23

AMBIENT GROUND LEVEL TEMPERATURE	VOLTAGE REGULATOR SETTING VOLTS
Winter: 0°C/32°F	28.5 (:0.2) volts (VR1) 6 ( <u>+</u> 0.2) volts (VR2)
Summer: 27°C 80°F or higher	27.0 ( <u>+</u> 0.2) volts (VR1) 6 ( <u>+</u> 0.2) volts (VR2)
Fall and Spring: 0°C/320F	28.0 ( <u>+</u> 0.2) volts (VR1)
27°C/80°F	6 (±0.2) volts (VR2)

### **NOTE**

## On standby/auxiliary 28 volts DC electrical system, adjust voltage regulators 1 volt lower than normal.

(g) Reduce DC load by turning off equipment that was turned on in step (c) above. DC bus voltage should be the same as in step (f) above. If aircraft DC voltage varies more than 0.5 volts between load and no load condition, shut-in engine according to normal operating procedure and replace regulator.

### 9-53. Inspection Voltage Regulator.

- a. Visually check voltage regulator for cracked case.
- b. Inspect voltage regulator for damaged contact pins.
  - c. Check for secure mounting of voltage regulator.

### 9-54. Removal Voltage Regulator.

- a. Place BAT switch in OFF position and ensure battery is disconnected.
- b. Disconnect electrical connector and protect with cap or tape (C137).
  - c. Remove four mounting screws and washers.
  - d. Lift regulator from shelf.
- **9-55. Repair Voltage Regulator**. Replace with serviceable like item and dispose of locally.

### 9-56. Installation Voltage Regulator.

### 9-28 Change 24

- a. Position regulator and install four mounting screws and washer.
- b. Remove cover and connect electrical connector to regulator.
- c. After a new or different voltage regulator has been installed; adjust voltage regulator. Refer to paragraph 9-52.

### 9-57. UNE CONTROL RELAY (K12).

- **9-58. Description Line Control Relay**. The line control relay (K12), located on equipment shelf above the avionics compartment, is a component of the basic DC power system and functions in conjunction with the other power system components. Operation is controlled by the voltage regulator to close or open the circuit between the generator and the essential bus.
- **9-59. Inspection Line Control Relay**. Visually inspect line control relay for broken pins, discoloration, security of mounting, and obvious damage.

### 9-60. Removal Line Control Relay.

- a. Place BAT switch in OFF position and ensure battery is disconnected.
  - b. Remove bus bar from relays (K2, K3, and K12).
  - c. Disconnect wires and tape ends.
- d. Remove mounting screws and washers and lift relay from shelf.

### 9-61. Installation Line Control Relay.

- a. Position relay on shelf and install mounting hardware.
  - b. Remove tape and connect wires.
  - c. Install bus bar on relays (K2, K3, and K12).
- **9-62.** Troubleshooting Line Control Relay. Refer to table 9-2 and figure F-8.

### 9-63. GENERATOR FAIL RELAY.

- **9-64. Description Generator Fall Relay**. The (K11) generator fail relay is located on the equipment shelf above the avionics compartment. Its coil is connected in parallel with the coil of the line control relay and is supplied with generator power from terminal H of the voltage regulator. Its purpose is to control operation of the DC generator caution light and nonessential bus relay when the nonessential bus switch is in the **NORM** position.
- **9-65. Inspection Generator Fall Relay**. Inspect the generator fail relay for obvious damage such as broken pins, discoloration, security of mounting, etc.

### 9-66. Removal Generator Fall Relay.

a. Place BAT switch in OFF position and ensure battery is disconnected.

- b. Disconnect wires from relay, identify and tape ends.
- c. Remove screws, spacers, and washers and remove relay.

### 9-67. Installation Generator Fall Relay.

- a. Position relay on shelf and install spacers, washers, and screws.
- b. Remove covers from wire ends and connect wires to proper terminals.
- **9-68.** Troubleshooting Generator Fall Relay. Refer to figure F-8.

Change 24 9-28.1/(9-282 blank)

### 9-69. NONESSENTIAL BUS RELAY.

- **9-70. Description Nonessential Bus Relay.** The nonessential bus relay (K2) is an electrically operated switch between the main bus and the nonessential bus and is controlled by either the generator fail relay or the nonessential bus switch (S1).
- **9-71. Inspection Nonessential Bus Relay.** Inspect relay for obvious damage, broken pins, discoloration, security of mounting, etc.

### 9-72. Removal - Nonessential Bus Relay.

- **a.** Place BAT switch in OFF position and ensure battery is disconnected.
  - **b.** Remove bus bar from relays (K2,K3,and K12).
- **c.** Disconnect wires from relay and identify and tape ends with electrical tape (C137).
- **d.** Remove mounting bolts and washers and remove relay from shelf.

### 9-73. Installation - Nonessential Bus Relay.

- **a.** Position relay on shelf and install attaching bolts and washers.
- **b.** Remove tape from wires and connect to proper terminals.
  - c. Install bus bar on relays (K2, K3, and K12).
- 9-74. Troubleshooting Nonessential Bus Relay. Refer to figure F-8.

### 9-75. FUEL BOOST PUMP SYSTEM.

**9-76. Description - Fuel Boost Pump System.** The fuel boost pump system consists of one electrically operated fuel boost pump (B1) submerged in the fuel cell and accessible from the bottom of the fuselage. The pump is energized from a circuit breaker in the overhead console or FUEL BOOST switch on instrument panel. The boost pump can also be activated through the fuel boost relay (K16) by depressing the starter switch or through actuation of the fuel pressure switch (S12). Refer to figures 9-1 and F-18.

### 9-77. Testing - Fuel Pump System.

- **a.** Close FUEL BOOST PUMP circuit breaker or FUEL BOOST switch. Check that fuel boost pump operates.
- **b.** Open FUEL BOOST PUMP circuit breaker or FUEL BOOST switch. Check that fuel boost pump stops operating.
- **9-78.** Troubleshooting Fuel Pump System. Refer to table 9-3 and figure F-17 for troubleshooting of the fuel boost pump system.

### NOTE

Before using teble 9-3, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-3, notify the next higher level of maintenance.

- **9-79. Inspection Fuel Boost Pump System.** Refer to paragraph 10-19 for inspection of the fuel boost pump.
- **9-80.** Removal Fuel Boost Pump System. Refer to paragraph 10-20 for removal of the fuel boost pump.
- **9-81. Installation Fuel Boost Pump.** Refer to paragraph 10-22 for installation of the fuel boost pump.

## 9-82. GOVERNOR CONTROL SYSTEM.

**9-83. Description - Governor Control System.** The governor control system allows pilot control of the governor setting and consists of GOV CONT 5 ampere circuit breaker, a governor control switch (S5), and a governor control actuator (63). Refer to figures 9-1 and F-9.

### 9-84. Testing - Governor Control System.

- **a.** Ensure that GOV CONT circuit breaker is closed. Press GOV RPM switch to INCR. Check that governor control actuator retracts.
- **b.** Press GOV RPM switch to DECR. Check that linear actuator extends.

### Table 9-3. Troubleshooting - Fuel Pump System

### CONDITION

TEST OR INSPECTION

### CORRECTIVE ACTION

- 1. Low pressure flow or no fuel flow to engine.
  - STEP 1. Check circuit breaker in overhead console for engagement

Engage or replace circuit breaker if required.

STEP 2. Check continuity of wiring at boost pump connector.

Repair or replace wiring if continuity does not exist.

STEP 3. Check for low or no fuel boost pump output pressure.

Replace defective boost pump.

STEP 4. Check for clogged filter

Clean or replace filter element.

### **9-85. Troubleshooting - Governor Control System.** Refer to table 9-4 and figure F-9.

#### NOTE

Before using table 9-4, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-4, notify the next higher level of maintenance.

### 9-86. GOVERNOR CONTROL SWITCH.

**9-87. Description - Governor Control Switch.** The governor control switch (S5), located in the pilot collective switch box, is a double-pole, double-throw, spring-loaded, momentary contact switch that enables the pilot to increase or decrease the governor rpm actuator setting, With the switch in INCR position, the circuit to the actuator motor is completed and allows motor to move arm in one given direction. With the switch in DECR position the polarily to the actuator motor is reversed, allowing the actuator arm to move in the opposite direction. When the switch is in rest position, circuit is de-energized. Refer to figure F-9.

- **9-88. Inspection Governor Control Switch.** Refer to paragraph 9-128.
- **9-89.** Removal Governor Control Switch, Refer to paragraph 9-117,
- **9-90.** Installation Governor Control Switch. Refer to paragraph 9-130.
- 9-91. GOVERNOR CONTROL LINEAR ACTUATOR.
- **9-92. Description Governor Control Linear Actuator.** The governor control linear actuator (B3, figure 9-1 and 9-8) is located on the forward side of the engine and is a motor-actuated device operated by the governor switch (S5) on the pilot collective stick to allow engine output speed to be varied over a normal range

### NOTE

Refer to paragraphs 4-113, 4-114, and 4-115 for inspection, removal, and installation procedures for the governor control linear actuator.

### Table 9-4. Troubleshooting - Governor Control System

### CONDITION

### TEST OR INSPECTION

### **CORRECTIVE ACTION**

- 1. Linear actuator fails to respond when governor RPM switch is positioned to INCR or DECR positions.
  - STEP 1. Check for defective or open circuit breaker in overhead console.

### Replace faulty circuit breaker.

STEP 2. Check for faulty wiring or corroded or burned switch contacts.

### Repair or replace wiring or switch.

STEP 3. Check connections at actuator for correct hookup

### Refer to figure F-9 for correct connection and correct faulty hookup.

STEP 4. Check condition of actuator.

### Replace faulty actuator.

- 2. Actuator moves in opposite direction to selected position.
  - STEP 1. Check for leads connected to wrong terminals on actuator.

### Refer to figure F-9 and connect correctly.

## **9-93. Disassembly - Governor Control Linear Actuator. (AVIM)** Refer to figure 9-8.

- a. Remove screw (2, figure 9-8) and cover (1).
- **b.** Remove nut (3), washer (4), and screws (5).
- **c.** Remove nuts (6 and 7) and washers (8). Remove terminal board (9).
- **d.** Remove sealing compound from joints and . grooves with a plastic or wooden scraper to free parts for disassembly.
- **e.** Slide cover and nut assembly (10) partially off actuator until leads of filter (11) prevent further removal. Push filter (11) down until studs on top of filter are clear of cover and nut assembly. Remove cover and nut assembly from actuator.

f. Unsolder filter (11) leads at motor (22).



Use a wrench to hold output shaft assembly (56) during performance of following step to prevent damage to actuator.

- **g.** Loosen nut (13) and remove rod end bearing (12). Remove nut (13) from rod end bearing.
- **h.** Remove screws (15). Remove plate and bearing assembly (14).
- i. Mounting plate assembly (16) and housing group (61) are a matched assembly. Tag these parts for reassembly on the same actuator.

Figure 9-8. Governor Control Linear Actuator Assembly (Sheet 1 of 3)




Figure 9-8. Governor Control Linear Actuator Assembly (Sheet 2)

- 1. Cover
- 2. Screw
- 3. Nut
- 4. Washer
- 5. Screw
- 6. Nut
- 7. Nut
- 8. Washer
- 9. Terminal Board
- 10. Cover and Nut Assembly
- 11. Filter
- 12. Rod End Bearing
- 13. Nut
- 14. Plate and Bearing Assembly
- 15. Screw
- 16. Mounting Plate Assembly
- 17. Screw
- 18. Gear and Shaft Assembly
- 19. Magnet
- 20. Screw
- 21. Washer
- 22. Motor
- 23. Screw
- 24. Resistor
- 25. Nut
- 26. Spacer
- 27. Gear
- 28. Thrust Washer
- 29. Ball Bearing
- 30. Shim
- 31. Shim

- 32. Shim
- 33. Pin
- 34. Plate and Gear Assembly
- 35. Cam Drive Washer
- 36. Screw
- 37. Drive Washer
- 38. Drive Washer
- 39. Packing
- 40. Gear and Bearing Assembly
- 41. Cam Drive Washer
- 42. Plate and Gear Assembly
- 43. Spacer
- 44. Pin
- 45. Gear
- 46. Shaft
- 47. Shim
- 48. Setscrew
- 49. Ball Retainer
- 50. Screw
- 51. Balls
- 52. Thrust Washer
- 53. Ball Bearing
- 54. Spurgear
- 55. Lead Screw Shaft
- 56. Output Shaft Assembly
- 57. Ring
- 58. Gear
- 59. Spacer
- 60. Spacer 61. Housing Grip
- 62. Bearing

206062-125-3

Figure 9-8. Governor Control Linear Actuator Assembly (Sheet 3)

- j. Remove screws (17) and mounting plate assembly (16).
  - k. Remove gear and shaft assembly (18).
- **I.** Remove screws (20) and washers (21). Remove permanent magnet (19).
- **m.** Remove screws (23) and dc motor (22). Do not disassemble motor. Resistor (24) is secured to motor with epoxy resin. Do not remove resistor unless it is found to be faulty during testing procedure after overhaul of actuator.
- n. Turn nut (25) counterclockwise until output shaft assembly (56) stops in fully extended position. Remove nut (25). Remove shims (30, 31, and 32) if installed. Remove spacer (26), gear (27), thrust washers (28), and ball bearing (29). Record number and total thickness of shims for use during reassembly. Discard thrust washers (28) and ball bearing (29).

**o.** Remove shims (30, 31, and 32) from stop and limit shaft assembly (33 through 46). Record number and thickness of shims for use during assembly,

### CAUTION

Shim (47) may be stuck to gear (45). This shim will not clear gear (58) during removal of shaft (46) and gear (45). Slide shim (47) forward during removal of shaft (46) and remove shim (47) after shaft (46) is out. Turn shaft (46) so that ends of pin (44) will not interfere with gear (58) during removal of shaft (46).

**p.** Push on threaded end of shaft (46) and carefully remove shaft and assembled parts (33 through 46) as a unit. Remove plate and gear assembly (34). Do not remove pin (33) unless the pin is damaged and requires replacing.

- **q.** Remove cam drive washers (35) and gear and bearing assembly (40).
- **r.** Remove screw (36) and drive washers (37 and 38). Discard packings (39).
- **s.** Remove cam drive washers (41), plate and gear assembly (42), and spacer (43). Do not remove pin (44) unless gear (54) requires replacement.
  - t. Remove shim (47).
- **u.** Remove setscrews (48), screws (50), and ball retainers (49). Remove and discard balls (51).
- v. Remove lead screw shaft (55) and output shaft (56) as a unit. Remove and discard thrust washers (52). Remove thrust ball bearing (53) and spurgear (54), Remove lead screw shaft (55) from output shaft (56). Discard thrust ball bearing (53).
- w. Remove rings (57), gears (58), and spacers (59 and 60). Discard rings (57).

### 9-94. Inspection - Governor Control Linear Actuator. (AVIM)

- **a.** Inspect cover and nut assembly (10) visually for breaks in chemical film coating and damaged threads.
- **b.** Inspect rod and bearing (12) visually for damaged threads. Visually inspect for cracks. If cracks are suspected inspect using fluorescent penetrant method. inspect for wear on inside diameter. Replace bearing if worn beyond **0.1915** inch diameter.
- **c.** inspect plate and bearing assembly (14) visually and manually for loose bearing. Visually inspect for cracks, if cracks are suspected inspect using fluorescent penetrant method. Inspect inside diameter of bearing for wear. Replace bearing if worn beyond **0.1900** inch diameter or if bearing is loose.
- **d.** inspect mounting plate assembly (16) visually for scored bearing face and for breaks in chemical coating. Visually inspect for cracks in plate, if cracks are suspected inspect using fluorescent penetrant method. inspect inside diameter for wear. Replace assembly if bearing is worn beyond **0.0955** inch diameter.
- **e.** Inspect gears (18, 27, 40, 42, 45, 54, and 56) visually for broken and chipped teeth,

- **f.** Inspect gear and shaft assembly (18) visually for loose shaft and scored gear face. Check shaft for wear. Replace assembly if shaft O.D. is less than 0.0936 inch. Check large gear for square mounting on shaft. Replace assembly if the inboard face of the large gear is not square with shaft within **0.005** inch true indicator reading.
- **g.** Inspect motor (22) visually and manually for loose and defective leads on terminals. Turn rotor by hand and check for free rotation. Check rotor for spring action affecting end play. Check resistor (24) which is mounted on motor. Check drivegear for broken and chipped teeth.
- **h.** Inspect shims (30, 31, 32, and 47) visually for sharp bend, cracks, scoring, and wear.
- i. inspect plate and gear assembly (34) visually for scoring and for burrs on inboard face of plate. Check for loose gear.
- **j.** Inspect cam drive washers (35 and 41) visually for scratches, wear, and scoring.
- **k.** Inspect gear and bearing assembly (40) visually and manually for the following defects:
  - (1) Scratches and scoring on bearing faces
  - (2) Loose bearing
- (3) Bearing for wear on inside diameter. Replace bearing if worn beyond **0.189** inch diameter.
- **I.** Inspect shaft (46) visually for scratches, scoring, evidence of wear, and for damaged threads. Replace shaft if worn beyond **0.1873** inch diameter.
- **m.** inspect ball retainers (49) visually for scratches, scoring, dents, and distortion in groove. Place ball in retainer groove and measure the width of the ball and retainer together. Replace retainer if measurement is less than **0.4230** inches.
- **n.** Inspect spurgear (54) visually for scratches, scoring, and evidence of wear on gear faces.
- **o.** Inspect lead screw shaft (55) visually for damaged threads.
- **p.** Inspect output shaft assembly (56) visually for scratches and scoring on outside diameter. Inspect for damaged threads.

- **q.** Inspect gear (58) visually for scratches and scoring on gear faces.
- r. Inspect housing group (61) visually end manually for the following defects:
  - (1) Loose, bent, and broken pins.
  - (2) Loose shafts.
  - (3) Bearing surfaces for scratches and scoring.
  - (4) Housing for breaks in chemical film coating.
- (5) Large bearing for wear on inside diameter. Replace bearing if worn beyond **0.4875** inch I.D.
- (6) Medium bearing for wear on inside diameter. Replace if worn beyond 0.1891 inch I.D.
- (7) Small bearing for wear on inside diameter. Replace bearing if worn beyond **0.0955** inch I.D.
- **s.** Inspect filter (11) for damaged threads. Test filter for defective circuitry.

### 9-95. Cleaning - Govenor Control Linear Actuator.

- **a.** Clean all parts except electrical components, housing (61), and plate assembly (16) with drycleaning solvent (C62).
- **b.** Clean exterior surfaces of electrical components with a clean, lint-free cloth dampened with drycleaning solvent (C62).
- c. Mounting plate assembly (16) and housing have oil impregnated bearings. Clean these assemblies with a clean, lint-free cloth dampened with drycleaning solvent (C62).
- **d.** After cleaning, dry parts with dry compressed air at 20 psi maximum pressure.
- **e.** If parts are not inspected immediately after cleaning, coat all steel parts with lubricating oil (C87). Store small parts in plastic bags. Cover all parts to prevent collection of dust.

## 9-96. Repair - Governor Control Linear Actuator. (AVIM)

**a.** Replace all parts which do not pass inspections outlined in steps of paragraph 9-94.

- **b.** Replace the following parts at each overhaul:
  - (1) Thrust washers (29 and 52)
  - (2) Thrust ball bearings (29 and 53)
  - (3) Packings (39)
  - (4) Balls (51)
  - (5) Rings (57).
- **c.** For repair of plate and rod end bearings refer to paragraph 9-99 and 9-103.

### 9-97. Assembly - Governor Control Linear Actuator. (AVIM)

- **a.** Apply a light coat of grease (C78) to the following parts (figure 9-8):
  - (1) All gears.
  - (2) Shaft of gear and shaft assembly (18).
  - (3) Pack open side of ball bearings (29 and 53).
- (4) Plate contact side of plate and gear assemblies (34 and 42).
- **(5)** Cam drive washers (35 and 41). Apply grease only on side opposite dogleg cam.
  - (6) Shaft (46).
  - (7) Grooves of ball retainers (49).
  - (8) Balls (51).
  - (9) Threads of lead screw shaft (55).
  - (10) Threads of output shaft assembly (56).
- **b.** Apply staking enamel (C64) to threads and heads of screws (5, 20,23, 48, and 50, figure 9-8) just prior to installing screws. Use following procedure to apply enamel.
- (1) Examine staking enamel prior to use; it should be opaque red in color. If staking enamel contains watery material, solids have separated. Do not use staking enamel if appearance indicates separation of solids. Shake container frequently to prevent material separation.

- (2) Screws and mating surfaces of parts must be free of all oil, grease, dirt, and other foreign matter prior to assembly.
- (3) Apply staking enamel (C64) neatly to threads and heads of screws. The amount of staking enamel used must be sufficient to completely cover the junction of the screw and mating surface and, after curing, the staking enamel must be clearly visible around the screw head.
- (4) Use caution to prevent staking enamel from running into other parts whose operation would be affected. Keep staking enamel off hands and tools to prevent transmitting to other parts.
- (5) After assembly, allow four hours cure time at room temperature and then cure an additional three hours at 79.5°C (175°F).
- **c.** Install spacer (59 and 60) and two gears (58) on shafts of housing group (61). Secure in place with new rings (57).
- **d.** Stand housing group (61) on its gear case end and install parts through slot in bottom of housing as follows:
- (1) Insert one new thrust washer (52) through slot into recess of housing. Place new thrust ball bearing (53) on top of thrust washer and then position other new thrust washer (52) over thrust bearing. Insert spurgear (54) through housing slot and position over thrust parts.
- (2) Insert lead screw shaft (55) down through housing bore and, with flats aligned, slip lead screw shaft into spurgear (54). Slide gear up on shaft slightly, then work shaft down through thrust parts and housing bore.
- (3) Insert detent end of output shaft assembly (56) into housing until it engages lead screw shaft (55). Turn flattened end of lead screw shaft to thread shafts together. Run output shaft in until its two ball detents are approximately centered between setscrew (58) holes in housing group (61).
- (4) Place housing on its side and turn output shaft assembly (56) so that its ball detents are perpendicular to work surface. Place a new ball (51) in detent and carefully install a ball retainer (49) with screws (50) with staking enamel as outlined in step b. Turn housing over and install other ball (51) in same manner.

- (5) Position both ball retainers (49) so that outer edge of retainers are flush with side of housing. Ensure that balls (51) have not fallen out and tighten screws (50) until snug. Final tightening will be accomplished later.
- **(6)** Install setscrews (48) with staking enamel as outlined in step b. Thead setscrews (48) in until they contact ear of ball retainers (49). Final adjustment will be made later.
- **e.** Assemble stop and limit shaft assembly (33 through 46) as follows:
- (1) If shaft (46) and gear (45) were disassembled, install gear on shaft as follows:
- (a) Examine shaft (46) and note that hole for pin (44) is countersunk on one side. Pin (44) entry into shaft must be made on countersink side of shaft.
- **(b)** Position gear (45) on shaft (46) and press new pin (44) in flush to **0.010** inch above gear O.D.
- (2) If plate and gear assembly (34) and pin (33) were disassembled, press a new pin (33) into plate and gear assembly flush to **0.010** inch above gear O.D.
  - (3) Install spacer (43) on shaft (46).
- (4) Install plate and gear assembly (42) on shaft with gear side toward spacer (43).
- (5) Ensure that sixteen cam drive washers (41) have been lubricated as outlined in step a. and install the sixteen cam drive washers on shaft (46) with dogleg of washer cams pointing in direction of plate and gear assembly (42).
- (6) Position new packings (39) on drive washers (37 and 38). Ensure that screw (36) and mating surfaces of drive washers (37 and 38) are clean. Apply a light coating of sealing compound (C120) on threads of screw (36). Position drive washers (37 and 38) on gear and bearing assembly (40) with flattened and concave contours of drive washers aligned. Install screw (36) through drive washer (37) and thread screw into drive washer (38). Position these assembled parts on shaft (46) so that concave contour of drive washer (37) clears adjacent cam drive washer (41).


- (7) Ensure that sixteen cam drive washers (35) have been lubricated as outlined in step a. and install the sixteen cam drive washers on shaft (46) with dogleg of washer cams pointing away from gear and bearing assembly (40),
- (8) Position plate and gear assembly (34) on shaft (46) with gear facing away from shaft (46) and with pin (33) engaged in shaft slot,
  - f. Synchronize mechanical stops as follows:
- (1) Rotate lead screw shaft (55) until gap between spurgear (54) and output shaft is **0.032** inch. Use a feeler gage to take measurement,
- (2) Rotate gear and bearing asembly (40, figure 9-8) counterclockwise to place cam drive washers (35 and 41) and plate and gear assemblies (34 and 42) in position shown in view A-A of figure 9-9, If necessary, turn plate and gear assembly (42, figure 9-8) clockwise to complete positioning cam drive washers (41).


### CAUTION

The ends of pin (44) must not interfere with teeth of gears (58) when installing the stop and limit shaft assembly (33 through 46).

- **g.** Install stop and limit shaft assembly (33 through 46) as follows:
- (1) Lay housing (61) on its side with output shaft assembly (56) to the right.
- (2) Hold shim (47) over bore in housing and position stop and limit shaft assembly (33 through 46) in housing. Maintain the position of mechanical stops set in step f.
- (3) Carefully mesh gears (42 and 45) with gears (58) and gear (40) with gear (54), Install washer (4) and nut (3). Engage hole in washer (4) with pin in housing,
- **(4)** Install same shims (30, 31, and 32) that were removed at disassembly, or new shims of equal thickness, on shaft (46).

- h. Install spurgear (27) as follows:
- (1) Place one new thrust washer (28) in recess in housing (61).
- (2) Install new thrust ball bearing (29) that has been lubricated as outlined in step a., next to thrust washer,
- (3) Install new thrust washer (28) next to thrust ball bearing
- (4) Install spurgear (27) and spacer (26) on lead screw shaft (55) and secure with nut (25). Tighten nut (25) just enough to produce output shaft (56) end play of **0.001 to 0,004** inch, Take end play measurement between spacer (26) and spur gear (27). If end play tolerance cannot be obtained, remove nut (25) and add shims (30, 31, and 32) as required to obtain correct amount of end play.
- i. Position motor (22) on housing (61) and secure with screws (23) which have been coated with staking enamel as outlined in step b.
- j. Position magnet (19) on housing (61) and secure with washers (21) and screws (20) which have been coated with staking enamel as outlined in step b.
- **k.** Install gear and shaft assembly (18) with teeth of gear and shaft assembly meshed with spurgear (27) and motor (22).
  - I. Install mounting plate assembly (16) as follows:
- (1) Install mounting plate assembly (16) on housing (61) with screws (17).
- (2) Check end play between gear and bearing assembly (40) and adjacent cam drive washer (35) with a feeler gage. If end play is not within **0.003** to **0.006** tolerance, remove mounting plate assembly (16) and add or remove shims (30, 31, and 32) as required to obtain correct end play, Install mounting plate (16) and rechecked play dimension to confirm that correct shims were installed.
- **m.** Position plate and bearing assembly (14) on housing (61) and install screws (15).
  - n. Install rod end bearing (12) as follows:
- (1) Turn gear and bearing assembly (40) to position output shaft assembly (56) in fully retracted position.





206062-126

Figure 9-9. Governor Control Linear Actuator Mechanical Stop and Limit Shaft Synchronization

- (2) Thread nut (13) onto rod end bearing (12).
- (3) Screw rod end bearing onto output shaft assembly (56) until dimension from center of rod end bearing (12) to center of bearing in plate and bearing assembly (14) is  $14.225 \ (\pm .030)$  inches.

## CAUTION

Hold output shaft assembly (56) while tightening nut (13).

(4) Tighten nut (13).

**o.** Adjust ball retainers (49, figure 9-8) as follows:



Do not over-tighten screws (50) or ball retainers (49) will be damaged.

- (1) Check that screws (50) are just snug and not over-tightened.
- (2) Turn four setscrews (48) alternately in small increments to move ball retainers inward against and parallel to output shaft assembly (56). Adjust

setscrews so that output shaft assembly rotates from one to six degrees without causing lead screw shaft (55) to bind. Rotate output shaft in one direction and hold while turning gear (40) to run output shaft in and out. Check by feel to be sure there is no binding, Rotate output shaft in opposite direction and hold. Repeat check for binding.

- (3) After setscrews (48) are properly adjusted in preceding step, apply a small amount of staking enamel (C64) to exposed setscrew threads and to internal threads in housing just above setscrews, Do not get staking enamel in setscrew sockets. Refer to step b. for additional information on staking enamel,
  - (4) Tighten screws (50).
- **p.** Run-in and test for linear speed. Refer to paragraph 9-98, steps a. and b.
  - a. Remove nut (3) and washer (4).
  - r. Install cover and nut assembly (10) as follows:
- (1) Position cover and nut assembly (10) on housing and work terminals of filter (11) up through holes in cover. Secure cover and nut assembly with screws (5) which have been coated with staking enamel as outlined in step b.
- (2) Position washer (4) with one hole of washer engaged with pin on housing and install nut (3).
- (3) Install terminal board (9), washer (8), and nuts (6 and 7).
- **s.** Test linear actuator. Refer to paragraph 9-98, step d.
- t. After all testing has been satisfactorily completed, apply sealing compound (C131) as follows:
- (1) Apply a continuous bead approximately 1/16 inch in diameter around joint of plate and bearing assembly (14) and mounting plate assembly (16).
- (2) Fill cover groove in mounting plate assembly (16).
- (3) Apply a continuous bead approximately 1/16 inch in diameter around joint where housing

- (61) protrudes through cover and nut assembly (10). Install terminal board (9), washers (8), and nuts (6 and 7).
- (4) Remove nuts (6 and 7) and terminal board (9). Apply a small continuous bead around the three terminal holes on cover and nut assembly (10). Install terminal board (9), washers (8), and nuts (6 and 7).
  - u. Attach terminal cover (1) with screw (2).
- v. Install lockwire (C96) in screws (15 and 17) as shown in figure 9-10




Figure 9-10. Linear Actuator Lockwire Diagram

# 9-98. Testing - Governor Control Linear Actuator.

# CAUTION

Handle actuator carefully. Do not lift weight of unit by the output shaft or apply any shock or loading that will tend to move housing and shaft with respect to each other in any direction other than the extend and retract motion. If any accidental loading does occur, disassemble the actuator and check for damaged ball retainer grooves.

- **a.** Perform linear actuator run-in after overhaul as follows:
- (1) Mount actuator in test fixture. Refer to figure 9-11.
- (2) Connect motor leads, figure 9-12 and figure 9-13.
- (3) Set up two electrical limit switches in position to be actuated by the output shaft assembly. Position the switches to permit operation of the actuator through nearly full travel, but to prevent impact against the linear actuator mechanical stops in either direction.
- (4) Operate the linear actuator for 1 hour at 20 Vdc and no load.
- **b.** Perform linear actuator linear speed test as follows:
- (1) Connect an axial load of seven pounds (figure 9-11).
- (2) Operate linear actuator with 28 Vdc applied and check linear speed of output shaft in both directions. The speed must be from 0.210 (±20%) inch per second in both directions. If speed is not within limits, change resistor (24, figure 9-8). Increase resistance to decrease speed. Decrease resistance to increase speed.
- (3) Remove faulty resistor (24) from motor. Solder leads of new resistor to motor but do not bond resistor to motor. Repeat linear speed test as outlined in steps (1) and (2).


# WARNING

Avoid skin contact with epoxy resin sealant used to bond resistor to motor. If skin contact does occur, wash immediately with soap and water.

- (4) After resistor has been checked and linear actuator speed is within limits, bond resistor to motor in position shown in figure 9-13. Use epoxy resin sealant (C128). Cure sealant for 24 hours at room temperature or cure in oven for 1 hour at 140°F (60°C).
- **c.** Accomplish linear actuator stroke adjustment as follows:
- (1) Mount actuator in a test fixture (figures 9-11 and 9-12).
- (2) Apply 28 Vdc and no load. Run actuator to full extend and record dimension between centers of bearings (figure 9-15). Run actuator to full decrease and record dimension between centers of bearings. Subtract full retract dimension from full extend dimension to determine stroke. The stroke should be 1.530 (±0.030) inches. If stroke is not correct, accomplish steps (3) through (9).
- (3) Apply 28 Vdc and no load. Run actuator to midpoint of stroke.
- (4) Loosen nut (3, figure 9-8) and lift washer (4) off pin.
- (5) Turn adjustment shaft clockwise to increase stroke. Turn adjustment shaft counterclockwise to decrease stroke. One full turn changes stroke approximately 0.250 inch.
- (6) If adjustments are reversed, remove washer and run unit through full extend and retract strokes. Replace washer and nut. Repeat steps (3) through (5).
- (7) Position washer (4, figure 9-8) over pin in housing and tighten nut (3).
- **(8)** Repeat step (2) to confirm that stroke is correct and that actuator operates smoothly.
- (9) Leave actuator in test fixture for accomplishment of final test.

Figure 9-11.

**Linear Actuator Work Aid** 



206062-128

206062-129




Figure 9-12. Linear Actuator Wiring Schematic

- d. Perform linear actuator final test as follows:
- (1) Mount actuator in a test fixture if not previously accomplished. Refer to figures 9-11 and 9-12.
- (2) Apply 28 Vdc and run actuator to full retract position.
- (3) Attach a seven pound weight in the position shown in figure 9-11 to check actuator extension.
- (4) Set the test fixture timer to zero and apply 28 Vdc. Measure the time of travel to 1.530 inches extension. The time must be from 6.070 to 9.110 seconds. Current must not exceed 2.0 amperes.
  - (5) Run actuator to full extend position.
- **(6)** Change the **seven** pound weight to the pulley marked retract (figure 9-11).
- (7) Set the test fixture timer to **zero** and apply 28 Vdc. Measure the time of travel to **1.530** inches retract. The time must be **6.070** to **9.110** seconds. Current must not exceed **2.0** amperes.
- (8) Remove **seven** pound weight and attach a 0 to 30 pound spring scale to the pivot arm with the scale toward the extend pulley. Apply 28 Vdc to actuator and measure value on scale where actuator motor stalls. The scale value must exceed 15 pounds when the motor stalls and the current must not exceed 5.0 amperes.

- (9) Repeat test described in step (8) but with the spring scale toward the retract pulley. The stall limits for weight and current are the same as those called out in step (8).
- (10) After the requirements of the final test are satisfactorily met, remove the actuator from test fixture and complete assembly of actuator. Refer to paragraph 9-97 step t.
  - e. Test linear actuator resistor as follows:
- **(1)** Unsolder one end of resistor (24, figure 9-8) from its motor terminal.
- (2) Check resistor (24) for an open circuit and for a short circuit with a multimeter. Replace resistor if faulty.
- (3) Solder (C133) resistor to motor at point where removed in step (1).
- f. Test linear actuator filter (figure 9-14) as follows:
- (1) Check resistance between terminals 1 and 6 and between terminals 2 and 5 with a multimeter. Replace filter if resistance exceeds 0.100 ohms.
- (2) Set multimeter on high ohms scale and check resistance between terminals 1 and 3 and between terminals 2 and 3. The needle on the multi meter should deflect slightly. If it does not, reverse leads and test again. If multimeter needle still






Figure 9-13. Linear Actuator External Wiring





2060075-278

Figure 9-14. Linear Actuator Filter Terminal Identification and Schematic

does not deflect, the filter has an open circuit and must be replaced.

- (3) If zero resistance is measured in step (2) the filter has a short circuit and must be replaced.
  - g. Test linear actuator motor as follows:
- (1) Check end play of motor shaft. Apply a force of 12 to 14 pounds axially to gear end of motor shaft and check distance that shaft is displaced from its normal free position. The shaft should move 0.008 to 0.018 inch from its normal position.
- (2) If end play is not within limits, replace the motor.


# 9-99. MOUNTING PLATE BEARING -LINEAR ACTUATOR .

# 9-100. Removal - Mounting Plate Bearing.

- **e.** Remove lockwire and remove four screws (1, figure 9-15).
- **b.** Remove mounting plate and bearing assembly (2).

# 9-101. Repair or Replacement - Mounting Plate Bearing.

**a.** Press bearing (7, figure 9-1 5) from mounting plate (2).



- 1. Screw
- 2. Mounting Plate, Bearing
- 3. Mounting Plate, Housing
- 4. Output Shaft

- 5. Jamnut
- 6. Rod End Bearing Assembly
- 7. Bearing

206062-130

Figure 9-15. Linear Actuator

**b.** Press new bearing (7) into mounting plate (2) and segment stake mounting plate at four equally spaced locations on each side.

### 9-102. Installation - Mounting Plate Bearing.

- **a.** Install bearing mounting plate (2, figure 9-15) with four screws (1).
  - b. Lockwire (C96) screws (1) in pairs.
- **c.** Apply a 1/16 inch diameter bead of sealing compound (C131) around joint between bearing mounting plate (2) and housing mounting plate (3).

# 9-103. ROD END BEARING - LINEAR ACTUATOR.

### 9-104. Removal - Rod End Bearing.



Hold output shaft (4, figure 9-15) with a wrench, to prevent transmitting torque to linear actuator, when removing or installing rod end bearing assembly (6).

- **a.** Loosen jamnut (5) and turn rod end bearing assembly (6) from output shaft (4).
- **b.** Remove jamnut (5) from rod end bearing assembly (6).

### 9-105. Installation - Rod End Bearing.

- **a.** Install jamnut (5) on rod end bearing assembly (6)
- **b.** Install rod end bearing assembly (6) into output shaft (4). Do not tighten jamnut (5).
- c. With linear actuator fully extended, adjust for a maximum 15.755 (±0.030) inches length, measured between centerlines of rod end holes.
- **d.** Hold output shaft (4) with a wrench and tighten jamnut (5).

# 9-106. HYDRAULIC CONTROL SYSTEM.

# **9-107. Description** — **Hydraulic Control System.** The electrical circuitry for control of the hydraulic system consists of a hydraulic bypass solenoid valve (L1), and a HYD BOOST switch (S7), and is protected

by a 5 ampere HYD BOOST circuit breaker. The valve is normally energized to prevent hydraulic fluid flow and may be de-energized to permit fluid flow by setting switch (S7) to ON position. Refer to figures 9-1 and F-11.

### 9-108. Testing — Hydraulic Control System.

- **a.** Place hydraulic boost switch to HYD BOOST. Ensure that HYD BOOST SOL and CAUTION PNLLTS circuit breakers are closed. Apply hydraulic pressure to helicopter from external source. Check that the HYD PRESS caution light is extinguished and that cyclic and collective controls move easily.
- **b.** Place hydraulic boost switch to OFF. Check that HYD PRESS caution light is illuminated and that cyclic and collective controls are harder to move than in step a.

- c. Return hydraulic boost switch to HYD BOOST. Check that HYD PRESS caution light is extinguished and that the cyclic and collective controls move easily.
- **9-109.** Troubleshooting Hydraulic Control **System.** Refer to table 9-5 for troubleshooting of the hydraulic control system.

### NOTE

Before using table 9-6, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-6, notify the next higher level of maintenance.

Table 9-5. Troubleshooting - Hydraulic Control System

# CONDITION

**TEST OR INSPECTION** 

### **CORRECTIVE ACTION**

- Hydraulic pressure continues and solenoid fails to operate after actuation of HYD BOOST toggle switch to OFF.
  - STEP 1. Check for defective or open circuit breaker.

### Replace faulty circuit breaker.

STEP 2. Inspect switch contacts for corrosion, loose connections, burned terminals, etc.

### Replace toggle switch.

STEP 3. Check wiring and solenoid for defects,

#### Repair or replace wiring and replace defective solenoid.

- 2. Circuit breaker opens.
  - STEP 1. Check for shorted wiring and/or solenoid.

Repair or replace defective wiring and/or solenoid.

- 9-110. HYDRAULIC BYPASS SOLENOID.
- **9-111. Description Hydraulic Bypass Solenoid.** The hydraulic bypass solenoid (L1) located on the service deck forward of the transmission is controlled by the HYD BOOST switch (figure 9-1). With the switch in OFF position, the solenoid is energized, allowing the boost system to be bypassed,
- **9-112.** Inspection Hydraulic Bypass Solenoid. Refer to paragraph 7-22.
- **9-113.** Removal Hydraulic Bypass Solenoid. Refer to paragraph 7-23.
- **9-114.** Installation Hydraulic Bypass Solenoid. Refer to paragraph 7-24.

### 9-115. FORCE TRIM SYSTEM.

**9-116. Description - Force Trim System.** The force trim system consists of a fore and aft force trim magnetic brake (L4), and a lateral force trim magnetic brake (L5). The magnetic brakes are wired in parallel and are protected by a 5 ampere FORCE TRIM circuit breaker, FORCE TRIM switches (S60), (S58), and (S59) are all series wired. The entire system serves to return pilot and copilot cyclic to desired initial position when switch (S60) is set to ON position. Switch (S58 or S59) may be triggered to de-energize brakes and eliminate centering force. With switch (S60) set to OFF position, automatic trim force is de-energized. Refer to figures 9-1 and F-11.

### 9-117. Testing - Force Trim System.

- **a.** Ensure that FORCE TRIM circuit breaker is closed. Place force trim switch to FORCE TRIM. Check that the cyclic controls have a holding force in fore and aft and lateral directions.
- **b.** Press force trim switch on pilot cyclic stick. Check that holding forces noted in step a. are not present.
- **c.** Release force trim switch on pilot cyclic stick. Check that holding forces noted in step a. are present.
- **d.** Repeat steps b. and c. except use force trim switch on copilot cyclic switch.
- **e.** Place force trim switch to OFF. Check that holding forces are not present.
- **9-118.** Troubleshooting Force Trim System. Refer to table 9-6 for force trim system troubleshooting procedures.

#### NOTE

Before using table 9-6, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-6, refer to the next higher level of maintenance.

Table 9-6. Troubleshooting - Force Trim System

### CONDITION

**TEST OR INSPECTION** 

### **CORRECTIVE ACTION**

- 1. Magnetic brakes fail to energize with FORCE TRIM switch (S60) ON.
  - STEP 1. Check for defective switch. Shorted wiring, or loose connections

Replace defective switch and/or repair or replace wiring.

STEP 2. Check for defective magnetic brake

Replace defective brake.

2. Magnetic brakes fail to de-energize when switch (S58 or S59) is depressed.

Check for defective switch or shorted wiring. Replace defective switch or repair wiring.

# 9-119. PRIMARY DIRECTIONAL CONTROL VULNERABLITY REDUCTION SYSTEM [ELECTRICAL). C

# 9-120. Description - Primary Directional Control Vulnerability Reduction System (Electrical).

### **NOTE**

The information contained in this paragraph applies to those helicopters with incorporation of MWO 55-1520-228-50-18 (vulnerability raduction flight control system) only.

The vulnerability reduction system is a backup system for the primary directional control system. Electrically it consists of a forward electromechanical control disconnect located on the forward primary directional control tube near the foot pedals, an aft electromechanical control disconnect located on the aft primary control tube in aft end of tailboom, control relay, time delay relay, and PRI DIR CONTR switch located on pilot collective stick. The PRI DIR CONTR panel consists of a JAM indicator light and a DISENG light. System power is provided from the 28 Vdc essential bus through a 5 ampere PRI DIR CONTR circuit breaker.

Mechanically the system consists of a forward control assemby, an idler, an aft control assembly and a number of support and brackets. A shear I ink terminal is incorporated in the forward terminal of the forward control assembly and the aft terminal of the aft control assembly. These shear link terminals are provided to release at a preset force (73 pounds force at the pilots foot) if a jam occurs in the vulnerability reduction flight control system. When the shear link terminal releases, the terminal components will extend or retract freely to allow full travel in' the primary system. Refer to paragraph 11-93 for further description of mechanical functions.

# 9-121. Test - Primary Directional Control Vulnerability Reduction System (Electrical).

- **a.** Close PRI DIR CONTR circuit breaker. Position PRI DIR CONTR DISENG switch (S130) on pilot collective stick to ENGAGE. Check that PRI DIR CONTR JAM and DISENG lights near lower right corner of instrument panel are extinguished.
- **b.** Depress PRESS TO TEST feature on the PRI DIR CONTR JAM and DISENG lights to check that each light will illuminate.

- **c.** Position PRI DIR CONTR DISENG switch (S130) to DISENG. Check that the PRI DIR CONTR DISENG light illuminates, and the JAM light remains extinguished.
- **d.** With switch (S130) positioned to DISENG, clamp the pedals in neutral position (refer to figure 11-17 view A). With the pedals immobile, move the yaw control tube in either direction to cause the control tube to move within the electromechanical control disconnect units.

#### NOTE

# A small amount of force will be required to move the control tube.

- **e.** Position PRI DIR CONTRDISENG switch (S130) to ENGAGE. Check that JAM light illuminates, and DISENG light remains illuminated.
- **f.** Return control tube to neutral position, reset ENGAGE DISENG switch and check that the DISENG and JAM lights extinguish.
  - g. Remove clamp from pedals.

# 9-122. Inspection - Primary Direction Control Vulnerability Reduction System (Electrical).

- a. Inspect switches for weak detents, security, corrosion, and faulty operation.
- **b.** Inspect plugs and connectors for security, contact corrosion, damaged contacts, broken wires, and faulty insulation.
- **c.** Inspect relays for loose connections, damage to case, and evidence of corrosion, pits or discoloration.
- **d.** Inspect panel lights for faulty bulbs, security, and corrosion.

# 9-123. Troubleshooting - Primary Directional Control Vulnerability Reduction System (Electrical), Refer to figure F-30 and table 9-7.

#### NOTE

Before using table 9-7, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-7, refer to the next higher level of maintenance.

# Table 9-7. Troubleshooting - Primary Directional Control Vulnerability Reduction System (Electrical) C.

### CONDITION

**TEST OR INSPECTION** 

#### **CORRECTIVE ACTION**

1. Control relay fails to activate when PRI DIR CONTR DISENG switch (S130) positioned to ENGAGE.

STEP 1. Check circuit breaker.

# Engage breaker if open or replace defective breaker.

STEP 2. Check for 28 Vdc at X1 of control relay.

# If voltage present replace defective control relay.

STEP 3. Check wiring for shorts or loose connections.

### Repair or replace wiring. Tighten loose connections.

Forward or aft or both electromechanical control disconnects fail to actuate when PRI DIR CONTR DISENG switch (S130) positioned to DISENG.

STEP 1. Check circuit breakers.

### Engage breaker if open or replace defective breaker.

STEP 2. Check for 28 Vdc at pin 1 at PRI DIR CONTR DISENG switch (S130).

### If voltage not present replace switch.

STEP 3. Check wiring for shorts or loose connections.

Repair or replace wiring. Tighten loose connections.

STEP 4. Check for 28 Vdc at pin A of forward or aft electromechanical control disconnects.

### If voltage present replace one or both electromechanical control disconnects as necessary.

STEP 5. Check wiring for shorts or loose connections.

### Repair or replace wiring. Tighten loose connections.

3. Time delay relay will not actuate while test (paragraph 9-121) is being performed.

STEP 1. Check for 28 Vdc at pin K at time delay relay.

### if voltage present replace relay.

STEP 2. Check wiring for shorts or loose connections.

### Repair or replace wiring. Tighten loose connections.

# 9-124. MAGNETIC BRAKES (L4, L5).

Refer to paragraph 11-69 for all information relevant to the magnetic brakes.

# 9-125. SWITCH BOX ASSEMBLY - COLLECTIVE CONTROL STICK.

**9-126. Description - Switch Box Assembly - Collective Control Stick.** Switch box on top of pilots collective contains control' switches for engine starter, governor rpm, landing lights, and idle stop release.

# 9-127. Disassembly - Switch Box Assembly - Collective Control Stick.

- a. Disconnect all electrical power from helicopter.
- **b.** Remove locknuts from GOV RPM, LDG LTS, and STARTER switches.
- **c.** Remove three screws (2, figure 9-16) from top of switch box assembly and remove cover (3).

**9-128.** Inspection - Switch Box Assembly - Collective Control Stick. Inspect for frayed or broken wires and stripped or damaged threads on switches in switch box.

# 9-129. Repair - Switch Box Assembly - Collective Control Stick.


- a. Repair all frayed or broken wires.
- **b.** Replace any defective switch.

# 9-130. Assembly - Switch Box Assembly - Collective Control Stick.

- **a.** Align switches with corresponding holes in switch box cover and install locknuts.
- **b.** Position cover onto box and secure with three attaching screws.

# 9-131. CYCLIC STICK GRIP ASSEMBLY.

9-132. Description - Cyclic Stick Grip Assembly. This paragraph contains the maintenance



- 1. Locknuts (3)
- 2. Screws (3)
- 3. Cover

206001-186

Figure 9-16. Switch Box Assembly A

and test instructions for cyclic stick grip assembly (figure 9-17), Maintenance of the grip assembly should be performed under conditions as clean as possible; however, the absence of moving parts, other than the switch assemblies, makes unusual precautions unnecessary. Cover the work bench with a rubber cushion or other cushioning material to prevent damage to the grip and switches in disassembly, Maintenance of the grip assembly consists of removing and replacing switch assemblies that are not functioning properly, with the exception of the RADIO/ICS switch assembly. One or both of the component microswitches can be replaced to render the switch assembly serviceable. Complete assembly and disassembly instructions are given in the following paragraph, but the grip should be disassembled only as necessary to perform the required maintenance. Test procedures of paragraph 9-146 and figure 9-18 will be helpful in locating defective switches that require removal and replacement,

**9-133.** Inspection - Cyclic Stick Grip Assembly. Refer to paragraph 11-43.

**9-134.** Removal - Cyclic Stick Grip Assembly. Refer to paragraph 11-44.

9-135. Disassembly - Cyclic Stick Grip Assembly.

#### **NOTE**

Before disassembling the grip, test all switches and wiring according to step g. below to determine what replacements will be necessary, Do not unsolder leads from any switches that do not require replacement.


- **a.** Remove the six pan head machine screws (2, figure 9-17) and carefully lift off the grip cap (1).
- **b.** If only the toggle switch (6) is to be replaced and not the complete assembly (5, 6, 7), carefully press out the pin (5) to separate the button (7) from the toggle switch (6),
- c. Remove the two pan head screws (18) from the underside of the grip subassembly (13) to release the RADIO-ICS switch (19). Slide the RADIO-ICS out of the grip assembly (13); then carefully unsolder the lead wires to remove the defective microswitch or switches.

**d.** Remove the truss head screw (17) that secures the pushbutton switch (16) to the grip subassembly (13). Lift out the pushbutton switch, or if necessary, push it out from the underside with a blunt instrument

# CAUTION

### Use care not to damage wire insulation.

- e. Unscrew the trigger pin (12) and slowly withdraw it while holding the trigger guard (9) and trigger switch (11) in place. Then pull out the trigger guard and trigger switch, separating the guard from the switch with care so as not to distort or loosen the return spring (10). Carefully unsolder the lead wires to remove the switch.
- **f.** Unscrew the handle retaining screw (15) and remove it from the grip subassembly (13) along with the lockwasher (14).
- g The lead wires passing through the grip subassembly (13) to the various switches are tied securely with a 12-inch length of tying cord and covered with a 2-inch insulating sleeve. There are individual insulating sleeves where the leadwires are soldered to the various switches. Do not remove the twine and 2-inch sleeve unless tests indicate that replacement of leadwires is required.
- **9-136.** Inspection Cyclic Stick Grip Assembly. Inspect those parts that have become accessible through disassembly for damage, wear, or deterioration of any kind. Replace all damaged parts as well as parts that do not function properly. Check security and continuity of soldered connections to all switches and the condition of leadwire insulation. Be sure that all switches are checked for proper actuation and continuity before reinstallation.
- 9-137. Cleaning Cyclic Stick Grip Assembly. Clean all parts exposed in disassembly by using clean, dry, compressed air at approximately 15 psi. New parts should be clean prior to reassembly. Any hard to remove dirt or grease may be cleaned with drycleaning solvent (C62) applied sparingly with a clean cloth.
- 9-138. Repair or Replacement Cyclic Stick Grip Assembly. All defective parts should be replaced. With the exception of the RADIO-ICS



NOTE

Refer to Figure 11-5 for function identification.

206001-98B

Figure 9-17. Disassembly - Cyclic Stick Grip Assembly (Typical)




Figure 9-18. Cyclic Stick Grip Assembly Internal Wiring Schematic A

switch, all switch assemblies must be replaced as assemblies and soldered to the proper lead wires unless complete assemblies with lead wires attached are available. All lead wires replaced must be 63 inches long, except those to the side button switch, which must be 58 inches long and of the size and color specified on the internal wires schematic, figure 9-18.

# 9-139. Reassembly - Cyclic Stick Grip Assembly.

### **CAUTION**

In soldering, use extreme care not to damage wire insulation and ensure that a 3/4-inch piece of insulation sleeving is slipped over the soldered connection,

- **a.** Using solder (C133), carefully resolder lead wires, removed from each defective switch, to the new switch installed. Refer to the internal wiring schematic figure 9-18.
- **b.** In replacing the trigger switch (11, figure 9-17) and guard (9), be sure that the return spring (10) is clipped into the guard (9) and is so placed that the trigger pin (12) may be inserted through it before it enters the holes in the guard and switch.
- **c.** The four-way switch (4) has a small projection or key on the bottom side which must be inserted carefully into matching keyway in the grip subassembly (13).
- **d.** Use care in inserting the toggle switch (5, 6, and 7); see that the button is positioned vertically in line with the grip.

### NOTE

The pin (5), toggle switch (6), and button (7) have been replaced by the MSL ACT switch (21) on the pilot cyclic stick grip assembly on helicopters equipped with ATAS CS.

**e.** Be sure that side pushbutton switch (16) and top left pushbutton switch (3) are the normally open type, and that the top right pushbutton switch (8) is the normally closed type A.

**f.** Be sure that side pushbutton switch (16) is the normally open type, and that the top right pushbutton switch (8) is the normally closed type **C**.

#### NOTE

Pushbutton switch (3) has been replaced by the night vision goggle (NVG) switch (S20) on the OH-58C pilot cyclic stick C.

g. Be sure that the grip cap (1) fits down snugly over all switches and all switches are seated precisely in the grooves provided for them in the grip subassembly before the cap is attached. Coat machine screws (2) with varnish (C153) just before inserting.

# 9-140. CYCLIC BUTTON SWITCH (S58 and S59).

**9-141. Description - Cyclic Button Switch (S58 and S59).** The cyclic button switch is a single-pole, single-throw, press contact switch furnished as part of the cyclic stick grip assembly and enables pilot or copilot to de-energize force trim system.

9-142. Inspection - Cyclic Button Switch (S58 and S59). Inspect switch for condition, faulty contacts, security, and discoloration.

# 9-143. Removal - Cyclic Button Switch (S58 and S59).

- a. Set EMT switch to OFF.
- **b.** Unscrew and remove two attaching screws from grip cap.
- **c.** Remove cap, release and lift switch sufficiently to gain access to switch wires.
- **d.** Disconnect wires from switch, identify and tape wire ends.

#### **NOTE**

Utilize caution in switch removal and installation to prevent chafing or damage to wires.

9-144. Repair or Replacement - Cyclic Button Switch (S58 and S59). Replace switch, failing inspection requirements.

# 9-145. Installation - Cyclic Button Switch (S58 and S59).

- **a.** Remove tape and. attach wires to switch.
- **b.** Carefully position switch in grip assembly, observing that wires are free of obstructions.
- **c.** Place cap on grip assembly and install two attachment screws.
- 9-146. Testing Cyclic Stick Grip Assembly. No special equipment is required for testing the grip assembly, but a multi meter or continuity tester and a 1000 volt, 60 Hz voltage source must be available. Make the following tests on the reassembled grip prior to installation on the helicopter. Refer to internal wiring schematic (figure 9-18) for wiring continuity to the various switches to be tested

  A. Refer to figure 9-19 C.
- **a.** Check the four-way switch (4, figure 9-17) for continuity in all positions with a 20-amp inductive load at 28 Vdc.
- **b.** Check the pushbutton switch (8) for operation and continuity in both normal and depressed positions with a 5-amp inductive load at 28 Vdc. Make certain that the top left switch and the side switch are normally open, and that the top right switch is normally closed.
- **c.** Check the toggle switch for proper operation with a l-amp inductive load at 28 Vdc.
- **d.** Check both circuits of the trigger switch (11) for proper operation with a 5-amp inductive load at 28 Vdc. Actuating travel (at the tip of the trigger) of the trigger switch to make the first contact (an audible click) is 1/8 inch minimum. The force required is 2-1/2 (±3/4) pounds. Travel to engage the detent is 11/32 inch maximum. Force required to go through the detent is 7-1/2 (±3/4) pounds. The point at which the second contact closes lies between the detent and point of maximum travel with a minimum of 1/32-inch overtravel required and a force of 6 pounds (plus 1 pound or minus 2 pounds).

- **e.** Ground test at 1000 vrms, 60 Hz across each normally open contact and between each wire and the metal grip body,
- **f.** Inspect lead wires and vinyl insulation sleeve to see that they are tied securely where they emerge from the grip.

# 9-147. CAUTION AND WARNING LIGHT SYSTEM. A

9-148. Description - Caution and Warning Lights System. The caution and warning lights system includes a caution panel (A1), warning lights (DS12) (DS13) (DS14) and master caution light (DS15), warning light test switch (S86), and engine out tone generator (DS17). The caution panel contains a number of internally lighted capsules that illuminate when associated switches (sensors) located at different places in the helicopter actuate to complete circuits; thus indicating malfunction sin the systems being monitored by the sensors. The panel is energized from the 28 Vdc bus and is protected by a 5 ampere circuit breaker (CB17). Refer to figures 9-1 and F-12.

9-149. Testing - Caution and Warning Lights System. During the following tests, the MASTER CAUTION light shall illuminate each time a caution panel segment illuminates and shall extinguish when reset. A caution panel segment will illuminate each time a fault exists and will remain illuminated until fault is cleared. Each time a caution panel segment becomes illuminated it shall flash at a rate of 3 to 5 times per second until system is reset; then segment shall remain steady on, until fault is cleared. The system shall be reset after each check in readiness for the next fault indication.

### a. Caution Light Panel

- (1) Ensure that CAUTION PNL LTS circuit breaker is closed.
- (2) Position RESET/TEST switch to TEST and check that all caution lights segments and MASTER CAUTION light flash and continue to flash while switch is held in TEST position. Check that lights flash at a rate of 3 to 5 times per second.
- (3) Release the RESET/TEST switch and check that MASTER CAUTION light is extinguished and caution panel segments are in on/off condition listed in (6) below.

- (4) Depress the BRIGHT/DIM switch momentarily to DIM. Check that the caution lights do not dim.
- (5) Rotate the instrument lights dimmer control clockwise from OFF. Depress the caution panel brightness switch momentarily to DIM, Check that the caution lights dim and remain dimly illuminated.




Figure 9-19. Cyclic Stick Grip Assembly internal Wiring Schematic C CS

(6) Momentarily depress the BRIGHT/DIM switch to BRIGHT Check that caution lights become brightly Illuminated

Caution Light	ON/OFF Condition	Para Test Reference
FUEL BOOST	OFF	9-149b
20 MIN FUEL 1	ON OR OFF	9-149c
FUEL FILTER	OFF	9-149f
ENG OIL BYPASS 2	ON OR OFF	9-149g
ENG CHIP DET	OFF	9-1491
XMSN CHIP DET	OFF	9-149k
T/R CHIP DET	OFF	9-1491
INST INVERTER	ON	9-149m
DC GENERATOR	ON	9-149n
HYD PRESS	ON	9-1490



Depends on fuel level

Depends on oil level

#### **NOTE**

# The following checks apply to both OH-58A and OH-58C helicopters.

- b. Fuel Boost Caution Light.
- (1) To check fuel boost caution light, remove plug (P1 72) from fuel pressure switch and connect a jumper between A and B terminals on the cannon plug
- (2) Turn the battery switch and fuel boost pump switch on, the light should illuminate.
- (3) Turn the battery switch off, disconnect the jumper and reinstall the cannon plug on the fuel pressure switch.
- (4) Turn the battery switch on and the fuel boost caution light should be extinguished

#### NOTE

# If, after reinstalling plug (P172), light is still on, check fuel boost system for proper operation.

- c. Twenty-minute fuel caution light The 20 MINUTE FUEL caution light shall be tested In accordance with either paragraph 9-149 d or paragraph 9-149 e., as applicable.
  - d. Procedure for Less Than Twenty Minutes Fuel
- (1) Disconnect wire E40A22 at splice near fuel tank Check that 20 MINUTE FUEL caution light extinguishes.
- (2) Reconnect wire E40A22 at splice Check that 20 MINUTE FUEL caution light Is Illuminated e. Procedure for More Than Twenty Minutes Fuel.
- (1) Disconnect wire E40A22 at splice near fuel tank and connect to ground Check that 20 MINUTE FUEL caution light is illuminated.
- (2) Remove wire E40A22 from ground Check that 20 MINUTE FUEL light Is extinguished.
- (3) Reconnect wire E40A22 at splice Check that the 20 MINUTE FUEL caution light remains extinguished.
- f. Fuel Filter Caution Light After Compliance with MWO 1-1520-228-50-48.
- (1) Disconnect plug (9, figure 10-7), from the externally mounted fuel filter head (8). Temporarily short pins A and B on plug. Check that FUEL FILTER caution light Is illuminated.
- (2) Remove temporary short between pins A and B of plug (9). Check that FUEL FILTER caution light is extinguished.
- (3) Reconnect plug (9) to externally mounted fuel filter head (8). Check that the connection is properly mated (tight and secure) and that FUEL FILTER caution light Is extinguished.
- **g.** Engine Oil Bypass Caution Light. This test may be performed in conjunction with the engine oil bypass valve test.

- h. Procedure for No Engine Oil in Tank.
- (1) Disconnect wire Q30A22 from terminal 2 on terminal board (TB14). Check that ENG OIL BYPASS caution light is extinguished.
- (2) Reconnect wire Q30A22 to terminal 2 on (TB14). Check that ENG OIL BYPASS caution light is illuminated. Check that connection is tight and secure.
  - i. Procedure for Engine Oil in Tank.
- (1) Place a jumper wire from terminal 2 on terminal board (TB14) to helicopter structure. Check that ENG OIL BYPASS caution light is illuminated.
- (2) Remove jumper wire. Check that ENG OIL BYPASS caution light is extinguished.
  - i. Engine Chip Detector Caution Light.
- (1) Remove plug (P113) from one of the engine chip detectors. Create a temporary short between pin A of plug (P113) and helicopter structure. Check that ENGINE CHIP DET caution light is illuminated.
- (2) Remove temporary short created in step (1). Check that ENGINE CHIP DET caution light is extinguished.
- (3) Reconnect plug (P113) to engine chip detector. Check that connection is properly made and that the ENGINE CHIP DET caution light remains extinguished.
- (4) Remove plug (P126) from the other engine chip detector. Create a temporary short between pin A of plug (P126) and helicopter structure. Check that ENGINE CHIP DET caution light is illuminated.
- (5) Remove temporary short. Check that ENGINE CHIP DET caution light is extinguished.
- (6) Reconnect plug (P126) to engine chip detector Check that connection is properly made and that ENG CHIP DET caution light remains extinguished.
  - k. Transmission Chip Detector Caution Light.
- (1) Create a temporary short between the stud on one of the transmission chip detectors and helicopter structure. Check that XMSN CHIP DET caution light is illuminated.

- **(2)** Remove temporary short. Check that XMSN CHIP DET caution light is extinguished.
- (3) Create a temporary short between the stud on the other transmission chip detector and helicopter structure. Check that XMSN CHIP DET caution light is illuminated.
- (4) Remove temporary short. Check that XMSN CHIP DET caution light is extinguished.
  - I. Tail Rotor Chip Detector Caution Light.
- (1) Create a temporary short between the stud on the chip detector in the tail rotor gearbox and helicopter structure. Check that T/R CHIP DET caution light is illuminated.
- (2) Remove temporary short. Check that T/R CHIP DET caution light is extinguished.
- m. Instrument Inverter Caution Light. The INST INVERTER caution light is tested as part of the inverter circuitry.
- n. Dc Generator Caution Light. The DC GENERATOR caution light is tested as a part of the generator circuitry.
  - o. Hydraulic Pressure Caution Light.
- (1) Connect hydraulic power cart to the helicopter hydraulic system. Gradually increase pressure to the point where the HYD PRESS caution light extinguishes. Check that HYD PRESS caution light extinguished by 400 psig increasing pressure.
- (2) Gradually reduce pressure to the point where the HYD PRESS caution light illuminates. Check that HYD PRESS caution light illuminates by 300 psig decreasing pressure.
- (3) Relieve pressure and disconnect the hydraulic power cart. Check that HYD PRESS caution light remains illuminated.
  - p. Warning Lights Panel
- **q.** Master Caution Light. The MASTER CAUTION light is tested in conjunction with the caution lights panel.

r. Engine Out Warning (Visual and Audio). Tests in this paragraph are applicable only to helicopters prior to helicopters S/N 72-21061

#### **NOTE**

Refer to paragraph 9-149u., for testing of helicopter S/N 72-21061 and subsequent. Test engine out warning system by operating the engine and using tachometer test set or equivalent.

- (1) Remove plug (P10) from the gas producer tachometer generator and connect it to the appropriate receptacle on the test set (T3). Close CAUTION PNL LTS circuit breaker and raise the collective stick from its lowest extreme. Check that ENGINE OUT warning light is illuminated and that engine out warning alarm is audible.
- (2) Increase tachometer generator RPM until ENGINE OUT warning light is extinguished. Check that GAS PRODUCER RPM indicator reads 55 (±3) % and that indication is the approximate reading on the test set. Check that engine out warning alarm is not audible,
- (3) Depress the WARNING LTS TEST switch. Check that ENGINE OUT warning light illuminates. Release the test switch and check that ENGINE OUT warning light extinguishes.
- (4) Decrease tach generator RPM to 50%. Check that ENGINE OUT warning light is illuminated and that engine out warning alarm is audible,
- (5) Move the collective stick to its lowest extreme, Check that ENGINE OUT warning light remains illuminated and that engine out warning alarm is not audible.
- **(6)** Remove plug (P10) from test set and reconnect to the gas producer tach generator on the engine. Check that the connector is properly mated, tight, and secure.

### **NOTE**

The engine out warning system may be tested in conjunction with the GAS PRODUCER RPM indicator.

- s. Transmission Oil Pressure Warning Light
- (1) Check that XMSN OIL PRESS warning light is illuminated.
- (2) Disconnect transmission oil pressure line at the engine firewall. Connect a hand pressure gun to the line leading to the pressure transducers. Gradually increase pressure until XMSN OIL PRESS warning light is extinguished. Check that caution light extinguishes at a maximum increasing pressure of 36 psig.
- (3) Depress WARNING LTS TEST switch. Check that XMSN OIL PRESS warning light illuminates when test switch is depressed and extinguishes when test switch is released.
- (4) Continue to decrease pressure on the transducer until XMSN OIL PRESS warning light illuminates. Check that the warning light illuminates at a decreasing pressure of 30 (±2) psig.
- (5) Reduce pressure to zero. Disconnect hand pressure gun and reconnect the transmission lines at the firewall. Check that XMSN OIL PRESS warning light is illuminated and that transmission line connections are tight and secure.
  - t. Transmission Oil Hot Warning Light
- (1) Check that XMSN OIL HOT warning light is extinguished.
- (2) Depress WARNING LTS TEST switch. Check that the XMSN OIL HOT warning light is illuminated when switch is depressed and extinguished when switch is released.
- (3) Create a temporary short from stud on transmission oil temperature switch (S3) to the helicopter structure. Check that XMSN OIL HOT warning light is illuminated.
- **(4)** Remove temporary short. Check that XMSN OIL HOT warning light is extinguished.
- **u.** ENGINE OUT and ROTOR RPM Warning. The following tests are applicable for helicopter S/N 72-21061 and subsequent. For Engine Out Warning tests on helicopter prior to S/N 72-21-61, see paragragh 9-149, step r.
  - (1) Engine Out Warning (Visual and Audio).

- (a) Remove plug (P10) from the gas producer tachometer generator and connect it to the appropriate receptacle on the test set (T3). Remove plug (P174) from the rotor RPM sensor and lay it aside. Close CAUTION PANEL LTS circuit breaker and raise collective stick from its lowest extreme. Check that ENGINE OUT warning light is illuminated and that generator tone is audible.
- **(b)** Increase tach generator RPM until ENGINE OUT warning light is extinguished. Check that GAS PRODUCER RPM indicator reads 55 (±3) % and that indication is the approximate reading on the test set. Check that generator tone is not audible.
- **(c)** Depress the WARNING LTS TEST switch. Check that ENGINE OUT warning light illuminates. Release the test switch and check that ENGINE OUT warning light extinguishes.
- **(d)** Decrease tach generator RPM to 50%. Check that ENGINE OUT warning light is illuminated and that generator tone is audible.
- **(e)** Move the collective stick to its lowest extreme. Check that ENGINE OUT warning light remains illuminated and that generator tone is not audible.
- **(f)** Remove plug (P10) from test set and reconnect to the gas producer tach generator on the engine. Reconnect plug (P174) to rotor rpm sensor. Check that the connections are properly mated, tight, and secure.

### NOTE

The engine out warning system may be tested in conjunction with the gas producer rpm indicator.

- (2) Rotor RPM Warning (Visual and Audio).
- (a) Remove plug (P6) from the rotor tachometer generator and connect it to the appropriate receptacle on the test stand. Remove plug (P38) from the engine out rpm sensor and lay it aside. Close CAUTION PNL LTS circuit breaker and raise the collective stick from its lowest extreme. Check that ROTOR RPM warning light is illuminated and that tone generator is audible.
- **(b)** Increase tach generator rpm until ROTOR RPM warning light is extinguished. Check that

- ROTOR RPM indicator reads 335 (±5) rpm and that indication is the approximate reading on the test stand. Check that tone generator is not audible. The sensor has been adjusted to the proper setting; however, if the actuation point of 335 (±5) rpm is not obtained during operation, this setting may be changed. An adjustment screw is located on the exterior of the sensor housing. Loosen the locknut and turn the screw clockwise to obtain a higher actuation point and counterclockwise to obtain a lower actuation point. Tighten locknut upon completion of adjustment. Sensitivity of the adjustment screw is approximately four rotor rpm per revolution. Observe actuation point on decreasing rpm only.
- **(c)** Depress the WARNING LTS TEST switch. Check that ROTOR RPM warning light illuminates. Release the test switch and check that ROTOR RPM warning light extinguishes.
- **(d)** Decrease tach generator rpm to 325 rpm. Check that ROTOR RPM warning light is illuminated and that tone generator is audible.
- **(e)** Move the collective stick to its lowest extreme. Check that ROTOR RPM warning light remains illuminated and that tone generator is not audible.
- **(f)** Remove plug (P6) from test stand and reconnect to the rotor tach generator. Reconnect plug (P38) to the engine out rpm sensor. Check that the connectors are properly mated, tight, and secure.

### NOTE

The rotor rpm warning system may be tested in conjunction with the dual tachometer indicator.

# 9-150. CAUTION AND WARNING LIGHT SYSTEM.

**9-151. Description** - **Caution** and **Warning Lights System.** The caution and warning lights system includes a caution panel (AI), warning lights (DS12) (DS13) (DS14) and MASTER CAUTION light (DS15), warning light test switch (S86), and engine out tone generator (DS17). The caution panel contains a number of internally lighted capsules that illuminate when associated switches (sensors) located at different places in the helicopter actuate to complete circuits; thus indicating malfunctions in the

systems being monitored by the sensors. The panel is energized from the 28 Vdc bus and is protected by a 5 ampere circuit breaker (CB17). Refer to figures 9-1 and F-34.

- **9-152.** Testing Caution and Warning Lights System. During the following tests, the MASTER CAUTION light shall illuminate each time a caution panel segment illuminates and shall extinguish when reset. A caution panel segment will illuminate each time a fault exists and will illuminate steady until the fault is cleared. The system shall be reset after each check in readiness for the next fault indication.
  - a. Caution Light Panel.
- (1) Ensure that **CAUTION PNL LTS** circuit breaker is closed. Check that **MASTER CAUTION** light and each caution panel segment are illuminated steady.
- (2) Reset **MASTER CAUTION** light and caution panel segments by placing caution panel **RESET/TEST** switch to **RESET** and releasing. Check that the **MASTER CAUTION** lights is extinguished and that caution lights are steadily illuminated.
- (3) Place and hold **RESET/TEST** switch to **TEST**. Check that all caution lights and **MASTER CAUTION** are illuminated steady as long as the switch is held to **TEST**.
- (4) Release the **RESET/TEST** switch. Check that the **MASTER CAUTION** light is extinguished and the caution lights are steadily illuminated.
- (5) Depress the **BRIGHT/DIM** switch momentarily to **DIM**. Check that the caution lights do not **DIM**. Check that the **MASTER CAUTION** and warning lights **DIM**.

### NOTE

TEST-RESET function on annunciator panel does not apply to warning lights. Warning lights test switch is located on the instrument panel.

(6) Rotate the instrument lights dimmer control clockwise from **OFF** Depress the caution panel brightness switch momentarily to **DIM**. Check that the caution lights dim and remain dimly illuminated. Check that the **MASTER CAUTION** and warnings lights also dim. Check that **MASTER CAUTION** illuminates until reset.

- (7) Momentarily depress the **BRIGHT/DIM** switch to **BRIGHT**. Check that the caution lights become brightly illuminated. Check that the **MASTER CAUTION** and warning lights also become brightly illuminated. Check that **MASTER CAUTION** illuminates until reset.
- b. For all other tests to paragraph 9-149 steps b. through  $\boldsymbol{u}.$

### **CAUTION**

To prevent damage to caution panel internal circuitry, disconnect external power and turn battery switch to OFF position prior to removing or replacing CAUTION PANEL warning lights.

- **9-153.** Troubleshooting Caution and Warning Lights System. Refer to circuit diagram (figure F-12) and trace malfunctioning circuit or loop, using standard electronic troubleshooting procedures and standard test equipment. Localize malfunctioning switch components, and repair or replace as required.
- 9-154. TRANSMISSION OIL TEMPERATURE SWITCH.
- 9-155. Description Transmission Oil Temperature Switch. The (S3) transmission oil temperature switch, located adjacent to temperature bulb on left side of transmission, is a hermetically sealed, temperature operated, single-pole switch that closes when temperature of transmission oil rises above safe operating range. This energizes a XMSN OIL HOT warning light in the master caution and warning system.
- **9-156.** Removal Transmission Oil Temperature Switch. Refer to paragraph 6-245.
- **9-157.** Inspection Transmission Oil Temperature **Switch**. Refer to paragraph 6-246.
- **9-158.** Installation Transmission Oil Temperature **Switch**. Refer to paragraph 6-247.

### 9-159. FUEL PRESSURE SWITCH.

- **9-160. Description Fuel Pressure switch.** A pressure operated switch (S12), located in the discharge port of the fuel boost pump provides an indication of pump failure. Should the pressure drop on the pump, the switch closes, energizing FUEL BOOST caution light on the caution panel.
- **9-161. Removal Fuel Pressure Switch.** Refer to paragraph 8-251.

### 9-162. Inspection — Fuel Pressure Switch.

- **a.** Inspect switch for clogged pressure port.
- **b.** Using a source of controlled and monitored pressure, (MP-1, (T6) and 0-30 PSI gauge, (Tx), and a test light or ohmmeter, inspect and test switch as follows:
- (1) Connect leads of light or ohmmeter across pins A and B of the fuel pressure switch.
- (2) The switch contacts should be closed (test light on or continuity between pins A and B.)
- (3) Slowly apply increasing pressure to the pressure port of the switch.
- (4) The switch contacts should open (test light off or no continuity between pin A and B) before increasing pressure exceeds 8 psi.
- **(5)** Slowly decrease pressure from pressure port of the switch.
- (6) The switch contacts should close (test light on or continuity between pin A and B) before decreasing pressure is less than 4 PSI.

### **NOTE**

The system caution light should be on whenever fuel pressure is less than 4 psi and off whenever the fuel pressure is above 8 psi.

Switches which function at any pressure between 4 and 8 psi may be continued in service, for example; switches which function at 6 psi on both increasing and decreasing pressure are acceptable.

(7) Replace switch if it does not operate at the prescribed range.

**9-163. Installation** — **Fuei Pressure Switch.** Refer to paragraph 8-253.

#### 9-164. FUEL FILTER PRESSURE SWITCH.

9-165. Description — Fuei Filter Pressure **Switch.** The fuel filter pressure switch (SIO) attached to a bracket beneath the engine is also called the fuel filter differential pressure switch or the fuel filter bypass warning switch. The fuel filter pressure switch senses the pressure drop across the engine fuel pump filter through before and after filter sense hoses (figure 4-1). As foreign material collects on the filter the pressure drop increases. When the pressure drop reaches approximately **0.750** psi the fuel filter pressure switch closes and energizes the FUEL FILTER caution light on the caution panel alerting the operator of a partially clogged fuel filter and impending filter bypass. Actual filter bypass occurs when the pressure drop across the filter reaches 0.900 to 1.00 psi on the OH-58A or 2.00 to 2.50 psi on the OH-58C.

### **CAUTION**

The switch has been preset at the proper operating point. Do not attempt adjustment below depot level.

- 9-166. Removal Fuei Filter pressure Switch. (Figure 4-1).
- **a.** Disconnect fuel filter sense hoses (5 and 6, figure 4-1) to fuel filter bypass warning switch (7) fittings.
- **b.** Cut lockwire and disconnect plug (P23) from the fuel filter bypass warning switch.
- **c.** Remove nuts (59) and washers (58) from the mounting studs of the fuel filter bypass warning switch, then remove fuel filter bypass warning switch (7) from bracket attached to lower firewall beneath the engine.

### 9-167. Inspection — Fuei Filter Pressure Switch.

- **a.** Disconnect the after filter sense hose (5, figure 4-1) at the switch and cap the hose.
- **b.** Position fuel selector lever to the open position.
- **c.** Activate the fuel boost pump. The FUEL FILTER caution light on the caution light panel should illuminate.
- **d.** If the light illuminates, turnoff fuel boost pump, remove cap, and reconnect the after filter sense hose. Bleed the engine fuel system. Refer to TM

55-2840-231-23 for OH-58A or TM 55-2840-241-23 for OH-58C.

- **e.** If the light fails to illuminate, check the electrical system. Refer to paragraph 9-147 and check switch as follows:
- f. Disconnect plug (P23) from the switch. Check continuity between terminals B and C on the switch. With boost pump off there should be an open circuit between terminals Band C. With after fiLter sense hose disconnected and boost pump on there should be a closed circuit between terminals B and C.
- g. If switch fails electrical test, check for clogged or restricted switch pressure port or before filter sense hose (6, figure 4-1). Adequate fuel and boost pump pressure are also required for a successful test.
- **h.** Test the fuel filter switch for proper actuation point as follows:
- (1) Remove the after filter and before filter hoses from the switch. Refer to paragraph 9-166.
- (2) Install an appropriate fitting with approximately 36 inches of clear plastic tubing at the before filter switch port (outboard side as mounted on the aircraft).
- (3) Insert a small funnel in the free end of the tubing and fill with fuel.
- (4) Check the switch contacts for closing with an ohmmeter. The switch contacts should close when the fuel level is raised 25 to 29 inches above the switch port.
- (5) Replace the switch if the contacts are not closed when the fuel level is raised to 32 inches above the switch port.
- i. Replace switch that fails any of the above inspections.
  - i. Repeat steps a. through d.

# 9-168. Installation - Fuel Filter Pressure Switch. (Figure 4-1.)

- **a.** Install fuel filter bypass warning switch into bracket attached to lower firewall beneath the engine. install and secure the washers (58) and nuts (59) on the mounting studs of fuel filter bypass warning switch.
- **b.** Connect fuel filter sense hoses (5 and 6, figure 4-1) to the fuel filter bypass warning switch (7) fittings.

**c.** Connect plug (P23) to the fuel filter bypass warning switch. Check that the connection is properly mated (tight and secure), and that the FUEL FILTER caution light is extinguished. Install lockwire (C96).

### 9-169. TRANSMISSION OIL PRESSURE SWITCH.

**9-170. Description - Transmission Oil Pressure Switch.** Transmission oil pressure switch (S13), located on the cabin roof to the left of the transmission, is a pressure operated switch and serves to energize XMSN OIL PRESS warning light on the instrument panel, warning the pilot of low oil pressure.

**9-171. Removal - Transmission Oil Pressure Switch.** Refer to paragraph 6-279.

# 9-172. Inspection - Transmission Oil Pressure Switch (S13).

- a. Inspect switch for clogged pressure port.
- **b.** Test switch (S13) using a source of controlled and monitored pressure and test light connected across the 6/32 stud and case; slowly apply increasing pressure to the pressure port of the switch. At 36 psig the switch should actuate to open, extinguishing the test light. On decreasing pressure the switch should close at 30 (±2) psig and illuminate the test lamp.

### NOTE

The switch is preset at the factory and no adjustment is provided. Should the switch fail to operate at this prescribed range, replacement of the switch is necessary.

9-173. Installation - Transmission Oil Pressure Switch. Refer to paragraph 6-280.

### 9-174. CHIP DETECTORS.

**9-175. Description - Chip Detectors.** Chip detectors (E3 and E6) installed on the engine provide an indication of the presence of metal particles in the engine lubrication system on the ENG CHIP DET caution panel segment. The transmission is equipped with chip detectors (E5) and (E7) to provide illumination of XMSN CHIP DET caution panel segment. The tail rotor gearbox is equipped with chip detector (E4) which provides illumination of T/R CHIP DET caution panel segment. The lights are illuminated when metal particles are present in sufficient quantity on the magnetic pole of the detector element to bridge the element.

**9-176. Cleaning - Chip Detectors.** Clean detectors with drycleaning solvent (C62).

# 9-177. Inspection - Chip Detectors.

- **a.** Inspect detector for stripped or damaged threads or bayonet pins.
- **b.** Check for accumulation of metal particles on magnet. Presence of metal may indicate need for further investigation and corrective action.

#### NOTE

Refer to paragraph 8-289 for additional information.

- c. Ins-seal for damage or distortion.
- 9-178. Removal Chip Detectors. Refer to paragraph 6-288.
- **9-179.** Repair or Replacement Chip Detectors. Remove packing and replace detector if threads or bayonet pins are damaged.

**9-180. Installation - Chip Detectors.** Refer to paragraph 6-290.

# 9-181. HYDRAULIC PRESSURE SWITCH.

**9-182. Description - Hydraulic Pressure Switch.** The hydraulic switch (S67) is installed on the right side of the solenoid valve. When hydraulic pressure is below 300 psig the pressure switch causes the HYD PRESS warning light in the pedestal to illuminate.

#### NOTE

For additional description and maintenance, refer to paragraph 7-49.

# 9-183. ENGINE OUT WARNING SWITCH.

**9-184. Description - Engine Out Warning Switch.** An RPM sensor is connected to the gas producer tachometer. Power is supplied from the CAUTION PNL circuit breaker and connects to the ENGINE OUT warning light and to a tone generator which produces a tone in the pilot headset. The engine out warning switch enables the pilot to prevent audio warning in the headset by lowering the collective pitch to the full down position.

### 9-185. Removal - Engine Out Warning Switch.

- **a.** Remove copilot seat and seat pan. Refer to paragraph 2-86.
- **b.** Remove two screws attaching engine out warning switch to mounting bracket beneath collective jackshaft in void beneath copilot seat.
  - c. Disconnect electrical wires and remove switch.

# 9-186. Intallation - Engine Out Warning Switch.

- **a.** Attach electrical wires and install switch with two screws to bottom of mounting bracket beneath collective jackshaft in void beneath copilot seat.
- **b.** Loosen clamp and striker arm on jackshaft and position so that when collective is full down, striker arm depresses engine out warning switch.

- **c.** Check engine out warning switch with battery on. Audio should be heard through pilot/copilot headset when collective is raised approximately one inch.
- **d.** Install copilot seat pan and seat. Refer to paragraph 2-88.

### 9-187. SHUNTS AND BUS BARS.

9-188. Inspection - Shunts and Bus Bars. Inspect the shunts and bus bars for the following:

- a. Corrosion
- **b.** Deep scratches
- c. Deformed
- d. Discoloration
- e. Any obvious damage,
- **9-189.** Ramoval Shunts and Bus Bars. Remove all attaching hardware and remove shunt or bus bar from mounting point.
- **9-190. Repair Shunts and Bus Bars.** If shunts or bus bars show any obvious signs of damage, replace shunt or bus bar.
- **9-191. Installation Shunts and Bus Bars.** Place shunt or bus bar in mounting position and install attaching hardware.

### 9-192. TERMINAL BOARDS.

- **9-193. Inspection Terminal Boards.** Inspect the terminal boards for the following:
  - a. Cracks
  - b. Corrosion
  - c. Security
  - d. Damaged threads.
- **9-194.** Removal Terminal Boards. Remove all attaching hardware and remove terminal board from mounting point.

**9-195.** Repair - Terminal Boards. If terminal board has any obvious damage, replace terminal board.

**9-196. Installation - Terminal Boards.** Place terminal board in mounting position and install attaching hardware to hold terminal board in place.

# SECTION II. ALTERNATING CURRENT SYSTEM

# 9-197. ALTERNATING CURRENT SYSTEM.

**9-198.** General - Alternating Current System. Alternating current is supplied to the 115 Vac bus in the overhead console by a static inverter. The system includes the inverter (PSI), inverter switch (S82), and the inverter fail relay (K10), and supplies operating power for the OH-58A/C gyro compass and attitude gyro and for the OH-58C CONUS NAV and altimeterencoder.

### 9-199. INVERTER.

- **9-200. Description Inverter.** The 65 volt ampere 115 Vac 400 Hz single phase static inverter (PSI) is located on the equipment shelf in the avionics compartment.
- **9-201. Inspection Inverter.** Inspect inverter for cracked or damaged case, proper bonding and security of mounting, broken connector pins, or cracked connector inserts and for proper operation,

### 9-202. Testing - Inverter.

- **a.** Open all circuit breakers and energize external power source.
- **b.** Close INV PWR and CAUTION PNL LTS circuit breakers. Position NON-ESS BUS switch to NORM, Close all ac circuit breakers. Check that INST INVERTER caution light is illuminated.
- c. Position inverter switch (S82) to INV, Check that inverter is energized and that INST INVERTER caution light is extinguished,
- **d.** Check that voltage on the ac bus is 113.5 ( $\pm$ 5) volts when all ac loads are energized and that non-essential bus voltage is 28 ( $\pm$ 0.5) Vdc,
- **e.** If the ac voltage is not within the limits specified above, replace the inverter.

- f. Position inverter switch to OFF. Check that voltage on the ac bus decreases to zero and that inverter becomes de-energized.
- **9-203. Troubleshooting Inverter.** Refer to figure F-4 and table 9-8.

#### NOTE

Before using table 9-8, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-8, notify the next higher level of maintenance.

#### 9-204. Removal - Inverter.

- **a.** Place BAT switch to OFF. Remove external power.
  - b. Gain access to inverter.
  - c. Disengage connector and protect with cap.
  - d. Remove attaching hardware.
  - e. Lift inverter from compartment,
- **9-205.** Repair or Replacement Inverter. Replace with serviceable like item and return removed component to depot if inspection requirements are not met.

#### 9-206. Installation - Inverter.

- a. Position inverter.
- **b.** Remove protective cap from connector and engage with inverter.
  - c. Install attaching hardware

### Table 9-8. Troubleshooting - Inverter

#### CONDITION

**TEST OR INSPECTION** 

#### CORRECTIVE ACTION

- 1. Inverter fails to function.
  - STEP 1. Check for open circuit breaker, faulty wiring, loose connections at switch (S82) or power circuits.

Reset circuit breaker, repair wiring, or tighten loose connections at switch or power circuit.

STEP 2. Check for defective inverter.

### Replace inverter.

- 2. Incorrect output voltage or frequency by inverter.
  - STEP 1. Check input voltage to inverter.

Correct primary low voltage conditions.

# SECTION III. STARTING SYSTEM

# 9-207. STARTER SYSTEM.

**9-208. Description - Starter System.** The starter-generator (G1) is located on the underside of the engine. This unit is used to start the engine, charge the battery and supply power for operation of dc equipment. The starter is energized by the starter-relay (K3) located in the aft electrical compartment. This relay is actuated by the starter switch (S6) located on the pilot collective stick. Refer to figures 9-1 and F-8.

### NOTE

Refer to paragraph 9-38 for coverage of starter-generator.

- **9-209. Cleaning Starter System.** Refer to paragraph 9-40.
- **9-210. Inspection Starter System.** Refer to paragraph 9-41.

# 9-211. Testing - Starter System.

- **a.** Pull fuel pump circuit breaker. Connect battery and position BAT switch to BAT or connect external power. Depress starter switch on pilot collective pitch stick and check starter system for normal operation.
- **b.** Disconnect wires K4B8 and K4D8 from terminal C on the starter-generator and isolate them from ground. Connect an external power source at external power receptacle.
- (1) Energize external power source. Ensure that ENG START circuit breaker is closed. Depress starter switch on pilot collective stick. Check that external power source voltage (approximately 28 Vdc) is present at end of wires K4B8 and K4D8 while starter switch is depressed.
- **(2)** Release pilot starter switch. Check for no voltage at open end of wires K4B8 and K4D8.

(3) Open ENG START circuit breaker. Disconnect external power source. Reconnect wires K4B8 and K4D8 to terminal C on the startergenerator. Check that connections are tight and secure.

**9-212. Troubleshooting - Starter System.** Refer to figure F-8 and table 9-9.

### **NOTE**

Before using table 9-9, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-9, notify the next higher level of maintenance.

# Table 9-9. Troubleshooting - Starter

### CONDITION

**TEST OR INSPECTION** 

### **CORRECTIVE ACTION**

- 1. Starter fails to operate when switch is depressed
  - STEP 1. Check circuit breaker.

Engage breaker if open or replace defective breaker.

STEP 2. Check battery condition.

# Replace defective battery.

STEP 3. Check starter switch contacts for evidence of corrosion, burned contacts, etc.

### Replace defective switch.

STEP 4. Check wiring for shorts and loose connections.

# Repair or replace wiring. Tighten loose connections.

STEP 5. Check starter relay (K3) for operation.

# Replace defective relay.

STEP 6. Check starter brushes for wear or binding.

# Replace worn brushes or if binding in holder, remove, clean and reset brushes.

STEP 7. Check starter armature for pitting, burning, etc.

Replace starter if armature defective.

### Table 9-9. Troubleshooting - Starter (Cont)

### CONDITION

**TEST OR INSPECTION** 

### **CORRECTIVE ACTION**

- Starter fails to produce sufficient rpm during start cycle (15% as indicated on gas producer tachometer indicator).
  - STEP 1. Check battery terminal voltage.

Replace battery if terminal voltege low or use external power source for start.

STEP 2. Check starter bearings for wear or obvious damage.

Replace starter.

- **9-213.** Removal Starter System. Refer to paragraph 9-42.
- **9-214. Installation Starter Systems.** Refer to paragraph 9-44.

# 9-215. STARTER RELAY.

- **9-216. Description Starter Relay.** The starter relay (K3) (figure 9-1) is located on the equipment shelf above the avionics compartment and supplies direct current to the starter when the starter switch is depressed.
- **9-217. Inspection Starter Relay.** Inspect starter relay for the following:
  - a. Broken pins
  - b. Discoloration
  - c. Cracks.

### 9-218. Removal - Starter Relay.

- a. Be sure all electrical power is off
- **b.** Remove bus bar from relays (K2, K3, and K12).
- **c.** Disconnect and tape wire ends using electrical tape (C137).

- **d.** Remove mounting bolts and washers.
- 9-219. Installation Starter Relay.
  - a. Position relay and install mounting hardware.
  - b. Remove tape and connect wires
  - c. Install bus bar on relays (K2, K3, and K12).

# 9-220. STARTER SWITCH.

- **9-221. Description Starter Switch.** The starter switch (S6), located in the collective stick switch box, is a double-pole, single-throw, pushbutton type switch. When switch is pressed to START position, the circuit to starter relay actuating coil and the igniter unit is energized.
- **9-222. Inspection Starter Switch.** Refer to paragraph 9-128.

#### 9-223. Removal - Starter Switch.

- a. Position BAT switch to OFF.
- **b.** Remove switch plate mounting screws and lift plate sufficiently to gain access to switch wires.
- **c.** Disconnect switch wires and tape wire ends using electrical tape (C137).

d. Remove switch from panel.

#### **NOTE**

Utilize caution in switch removal to prevent chafing or damage to wires.

# 9-224. Installation - Starter Switch.

**a.** Install switch to plate observing that indexing key is in proper position.

- **b.** Remove tape and connect wires to switch
- **c.** Position plate on switch box and install mounting screws.

### SECTION IV. IGNITION SYSTEM

### 9-225. IGNITION SYSTEM.

**9-226. Description** - **Ignition System.** The ignition exciter (Z1), furnished with the power turbine, is located below the tachometer generator on the lower left section of the engine and consists of a low tension capacitor discharge ignition exciter. This unit provides a repeating ignition arc during engine start cycle (figures 9-1 and F-8). A key lock ignition switch is installed on the aft left side of the center console.

# 9-227. Inspection - Ignition System.

- a. Inspect cable for cracks, bends, and fraying.
- **b.** Inspect igniter for dents.
- c. Check components for security.

### 9-228. Testing - Ignition System.

- **a.** Pull fuel pump circuit breaker. Connect battery or external power and position BAT switch to BAT and key lock ignition to ON. Depress starter switch on pilot collective pitch stick and check ignition system for normal operation.
- **b.** Operation Check Igniter Only Circuitry. Remove wire J3B18 from ignition unit and isolate from ground, Connect external power source to the helicopter.
- (1) Energize external power source. Ensure that IGN ENG circuit breaker is closed. Depress starter switch on pilot collective stick. Check that external power source voltage is present at open end of wire J3B18.

(2) De-energize external power source. Connect wire J3B18 to ignition unit. Check that connection is tight and secure.

### NOTE

- If MWO 55-1520-228-30-15 was applied, no operational check of engine relight circuit is required. Circuit was deactivated by TB 55-1520-228-20-18.
- **c.** Operational Check Igniter and Engine Relight Circuitry (Helicopters S/N 72-21061 and Subsequent). Remove wires J3B18 and J3C20 from ignition unit and isolate from each other and from ground.
- (1) Energize external power source. Ensure that IGN ENG circuit breaker is closed. Check that ENG RELIGHT indicator light on the instrument panel is not illuminated.
- (2) Depress ENG RELIGHT indicator light and release it. Check that light illuminates when depressed and extinguishes when released.
- (3) Depress starter switch on pilot collective stick. Check that external power source voltage is present at open end of both wires J3B18 and J3C20.
- (4) Release starter switch. Check that there is no voltage at open end of either wire J3B18 or wire J3C20.
- (5) Disconnect pressure line from port on engine relight unit, Apply approximately 20 psig pressure at port. (A short length of plastic tubing may be attached to port to facilitate application of

pressure.) Quickly release the pressure and check that after **5** seconds: the external power source voltage appears at open end of wire J3C20 for approximately **3** seconds and then disappears; ENG RELIGHT indicator light illuminates and remains illuminated. Also, check that during the application of and releasing of pressure, no voltage appears on wire J3B18.



Pressures in excess of 80 psig may cause damage to engine relight unit.

(6) Place ENG RELIGHT switch to RESET OFF and then release it. Check that ENG RELIGHT indicator light extinguishes and remains extinguished.

- (7) Reconnect engine air pressure hose to relight unit. Check that connection is properly made and is tight and secure.
- (8) De-energize external power source. Connect wires J3B18 and J3C20 to igniter unit. Check that connections are tight and secure.
- **9-229. Troubleshooting Ignition System.** Refer to figure F-8 and table 9-10.

#### NOTE

Before using table 9-10, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-10, notify tha next higher level of maintenance,

Table 9-10. Troubleshooting - Ignition system

### CONDITION

**TEST OR INSPECTION** 

### **CORRECTIVE ACTION**

- 1. Ignition system fails to operate when START switch is depressed.
  - STEP 1. Check for open or defective circuit breaker.

Reset open igniter circuit breaker or replace defective breaker.

STEP 2. Check for corroded or burned switch contacts.

Replace defective starter switch.

STEP 3. Loose connections or shorted wiring.

Repair or replace defective wiring or tighten loose connections,

STEP 4. Check for defective engine ignition system or defective igniter.

Refer to TM 55-2840-231-24 and replace defective igniter or other parts of engine ignition system.

### 9-230. IGNITION SWITCH.

- **9-231. Description Ignition Switch.** The ignition switch is a key lock ignition switch installed on the aft left side of the center console. When placed in the ON position it allows the pilot to start the engine.
- **9-232.** Inspection Ignition Switch. Inspect for proper key operation, security, and electrical connections.

# 9-233. Removal - Ignition Switch.

- a. Remove attaching hardware.
- **b.** Lift ignition switch from console and disconnect electrical wires.

# 9-234. Installation - Ignition Switch.

- **a.** Connect electrical wire and position ignition switch in console.
  - b. Install attaching hardware.

### SECTION V. LIGHTING PROVISIONS

### 9-235. LIGHTING PROVISIONS.

**9-236. Description - Lighting Provisions.** Lighting provisions include the equipment necessary for the illumination of instruments and switches; also interior and exterior lighting used for night operation of the helicopter.

### 9-237. INTERIOR LIGHTS SYSTEM.

**9-238. Description - Interior Lights System A**. The interior lights system consists of internal lighting of the instruments, panel edge lights, dimming rheostats (R7 and R25), one transistorized dimming element (Q1), lighting terminal boards (TB6 and TB25), two cockpit lights, signal light, signal light receptacle (J169), and associated wiring as shown in figure F-13.

9-239. Description - Interior Lights System C. The interior lights system consists of internal lighting of the instruments, panel edge lights, console light switch (S122), and instrument light switch (S123) which operates instruments lights rheostat (R7), console light rheostat (R25), one transistorized dimming element (Q1), power supplies (PSI and PS2), lighting terminal boards (TB1, TB6, and TB31), one cockpit light, signal light, signal light receptacle (J169), and associated wiring as shown in figure F-35.

### 9-240. Inspection - Interior Lights System.

- **a.** Check dimming rheostats (and power supplies for mounting security, cracks, and chips.
  - b. Check edge lights for security
  - c. Check wiring for condition and security.

### 9-241. Testing - Interior Lights System.

- **a.** Instrument Lights. Rotate instruments lights control (R7) and console lights control (R25) to their counterclockwise extremes (DIM),
- (1) Ensure that INSTR LTS circuit breaker is closed. Rotate instrument lights control clockwise until dimming switch closes. Check that instrument lights illuminate dimly.
- (2) Continue clockwise rotation of the instrument lights control. Check that the instrument lights increase in brightness as the control is rotated clockwise.
- (3) Rotate the instrument lights control counterclockwise. Check that the instrument lights decrease in brightness as the control is rotated counterclockwise and extinguish when control reaches counterclockwise extreme.

- b. Console lights:
  - (1) Position CSL LT switch to ON C
- (2) Rotate console lights control clockwise. Check that console lights and floodlights (including all avionic equipment lights) and control panel lights illuminate dimly.
- (3) Continue clockwise rotation of the console lights control. Check that the lights which are illuminated in step (2) increase in brightness as the control is rotated clockwise.
- (4) Rotate console lights control counterclockwise. Check that the lights which were illuminated in step (2) decrease in brightness as control is rotated counterclockwise and are extinguished when control reaches counterclockwise extreme.
  - (5) Position console lights switch to OFF C.
  - c. Position CSL LT switch to OFF C.

- (1) Place NON-ESS BUS switch to NORM. Ensure that COCKPIT LTS circuit breaker is closed. Check that the cockpit light is operational in each mode (ON/OFF, DIM/BRIGHT, and SPOT/FLOOD).
- (2) Ascertain that the cockpit light is in the OFF posit ion.
- **d.** Signal Light Receptacle. Ensure that SIGNAL LT circuit breaker is closed. Check that 28 Vdc is present between B and A (ground) of the signal light receptacle.
- 9-242. Troubleshooting Interior Lights System. Refer to figure F-13 and table 9-11 A. Refer to figure F-35 and table 9-12 C.

### **NOTE**

Before using table 9-11 or 9-12, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in tables 9-11 and 9-12, notify the next higher level of maintenance.

# Table 9-11. Troubleshooting - Interior Lights A

# CONDITION

**TEST OR INSPECTION** 

# **CORRECTIVE ACTION**

- 1. Light fails to illuminate when circuit is energized.
  - STEP 1. Check for open lamp filament or light improperly bonded to structure.

# Replete lamp or board lighting fixture to ensure good electrical ground,

- 2. Circuit breaker opens when circuit is energized.
  - STEP 1. Check for shorted wiring

### Repair or replace defective wiring.

- 3. Lights fail to respond to rheostat rotation.
  - STEP 1. Check for defective transistor dimmer element (Q1),

### Replace dimmer element.

#### CONDITION

**TEST OR INSPECTION** 

### CORRECTIVE ACTION

1. Some instrument lights fail to illuminate when circuit is energized.

STEP 1, Check for defective power supply (PS1 or PS2).

### Replace power supply.

2. Circuit breaker opens when instrument lights circuit is energized.

STEP 1. Check for shorted wiring.

### Repair or replace defective wiring.

STEP 2. Check for defective power supply (PS1 or PS2).

### Replace power supply.

STEP 3. Check for defective instrument lights rheostat.

# Replace rheostat.

3. Console lights fail to illuminate when rheostat is rotated.

STEP 1. Check for defective transistors dimming element (Q1).

### Replace dimmer element.

STEP 2. Check for defective circuit breaker.

### Replace circuit breaker.

4. Some console lights fail to illuminate.

STEP 1. Defective console lights switch (S122)

### Replace switch.

### 9-243. COCKPIT LIGHTS.

9-244. Description - Cockpit Lights. These lights have an ON-OFF switch and a rheostat incorporated into the lamp body. One light is located on the center post and the other on the overhead center beam behind the copilot. They may be positioned in their holders or hand-held.

### 9-245. Inspection - Cockpit Lights.

- a. Inspect wiring for chafing and broken insulation.
  - b. Inspect terminals for security.
- c. inspect light base and rheostat for cracks and dents.

### 9-246. Removal - Cockpit Lights.

- a. Check that all electrical power is OFF.
- **b.** Disconnect light wire from terminal board (TB5) and cover terminal for protection.
- **c.** Disconnect ground lead from ground stud and remove cable from grommet.
- **d.** Remove mounting nuts, washers, screws, and spacer, holding light base.
- **9-247. Repair Cockpit Lights.** Replace all items that fail inspection.

### 9-248. Installation - Cockpit Lights.

- **a.** Place light and spacer in position and install screws, washers, and nuts.
- **b.** Connect light by inserting cable through grommet, install and secure ground lead. Check for proper bonding to airframe structure.
- **c.** Remove protective cover and connect light wire to terminal board (TB5).
- **9-249. Troubleshooting Cockpit Lights.** Refer to table 9-11 and figure F-13 for troubleshooting of cockpit lights.

# 9-250. EXTERIOR LIGHTS SYSTEM,

9-251. General - Exterior Lights System. The exterior lights system consists of one infrared/white (IR/white (dual)) landing/searchlight; two switches located in the pilot collective stick switchbox; two position lights (DS2 and DS3) located one each on the right and left tip of the horizontal stabilizer; position lights switch (S68), position lights dimming resistor (R33): two forward NVG position lights (IR) located forward of the FM homing antenna on both sides of aircraft, two lower NVG position lights (IR) forward of the APFI-39 antenna support, one aft NVG position light (IR) located on top the taillight support assembly, one NVG position light switch located on the overhead console; one anticollision light (DS5), and one taillight located on the aft tip of the tailboom fairing. All lighting circuits are energized from essential or nonessential bus and protected by circuit breakers located in the overhead console.

9-252. General - Exterior Lights System. After compliance with MWO 55-1520-228-50-32 A C . The exterior lights system consists of one IR/white (dual) landing/searchlight; two switches located in the pilot collective stick switchbox; two position lights (DS2 and DS3) located one each on the right and left tip of the horizontal stabilizer; position lights switch (S68), position lights dimming resistor (R33): two forward NVG position lights (IR) located forward of the FM homing antenna on both sides of aircraft, two lower NVG position light (IR) forward of the APR-39 antenna support, one aft NVG position light (IR) located on top of the taillight support assembly, one NVG position light switch located on the overhead console; one anticollision light (DS5), and one taillight located on the aft tip of the tail boom fairing. All lighting circuits are energized from essential or nonessential bus and protected by circuit breakers located in the overhead console.

#### 9-253. LANDING LIGHTS.

**9-254. Description - Landing Lights.** Two landing lights (figure 9-1, DS7-DOWN, DS8-FWD) located in the lower center section of the nose are positioned to provide illumination both forward and downward from the helicopter.

# 9-255. Cleaning - Landing Lights.

- **a.** Remove moisture and loose dirt with a clean soft cloth.
- **b.** Remove grease, fungus, and ground-in dirt with a clean, lint-free cloth dampened with drycleaning solvent (C62).

# 9-256. Inspection - Landing Lights.

- **a.** Check light for defective or broken seal beam unit.
  - **b.** Check for loose electrical connections.
  - c. Check for damaged or defective components.

# 9-257. Testing - Landing Lights.

**a.** Place LDG LTS switch on pilot collective stick to OFF. Ensure that LDG LTS circuit breaker is closed. Check that both landing lights are off.

Many OH-58 helicopter operators prefer to illuminate the forward facing light during hovering and taxiing at night to eliminate the glare created if the downward facing light was used. Accordingly, OH-58 users have permission to rewire the lights so that the forward facing light illuminates at the DOWN switch position. Wiring diagram figure F-15, indicates the correct way to accomplish the above. Wires L3A22 and L8A22 have been changed at TB27 from terminals 2 and 3 respectively to 3 and 2 respectively. On helicopters that have been rewired, the switch box on the pilot collective stick should read BOTH. FWD. and OFF. (On helicopters that have not been rewired, the switch box should read BOTH, DOWN and OFF.) Relabel the FWD position by hand on rewired installation. This note does not apply to the OH-58C which has a controllable searchlight.

- **b.** Place LDG LTS switch to FWD position. Check to see that forward facing landing light illuminates.
- **c.** Place LDG LTS switch to BOTH. Check that both landing lights illuminate.

**9-258. Troubleshooting - Landing Lights,** Refer to figure F-15 and table 9-13.

#### NOTE

Before using table 9-13, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-13, notify the next higher level of maintenance.

Refer to table 9-16 for troubleshooting of the controllable landing light.

Table 9-13. Troubleshooting - Exterior Lights

#### CONDITION

**TEST OR INSPECTION** 

#### CORRECTIVE ACTION

- 1. Landing lights fail to illuminate when switch is actuated,
  - STEP 1. Check for open circuit breaker,

#### Reset breaker or replace if required.

STEP 2. Check for loose connections, shorted wiring, or defective switch.

Tighten loose connections and repair or replace defective wiring or switch.

STEP 3. Check lamps for open filament.

#### Replace defective lamp.

- 2. Anti-collision light illuminated constantly.
  - STEP 1. Check for defective flasher unit (210).

#### Replace defective flasher unit (210).

# Table 9-13. Troubleshooting - Exterior Lights (Cont)

# CONDITION

**TEST OR INSPECTION** 

#### **CORRECTIVE ACTION**

- 3. Position lights fail to illuminate when switch (S68) is actuated to BRT.
  - STEP 1. Check for opened circuit breaker, faulty switch, shorted wiring, or loose connection.

Replace circuit breaker or switch as applicable. Repair or replace wiring or tighten loose connections.

STEP 2. Check for broken lamp filament.

#### Replace faulty lamp.

STEP 3. Nonessential bus switch not in manual position.

#### Position switch to MANUAL.

- 4. Position lights fail to dim or fail to burn when switch is actuated to dim position.
  - STEP 1. Check for defective dimming resistor (R33).

Replace dimming resistor.

# Table 9-14. Troubleshooting - Exterior Lights After compliance with MWO 55-1520-228-50-32

#### CONDITION

**TEST OR INSPECTION** 

# **CORRECTIVE ACTION**

- 1. Anticollision light illuminated constantly.
  - STEP 1. Check for defective flasher unit (Z10).

# Replace defective flasher unit (Z10).

- 2. Position lights fail to illuminate when switch (S68) is actuated to BRT.
  - STEP 1. Check for opened circuit breaker, faulty switch, shorted wiring, or loose connection.

Replace circuit breaker or switch as applicable. Repair or replete wiring or tighten loose connections.

# Table 9-14. Troubleshooting - Exterior Lights (Cont) After compliance with MWO 55-1520-228-50-32

#### CONDITION

**TEST OR INSPECTION** 

#### **CORRECTIVE ACTION**

STEP 2. Check for broken lamp filament.

# Replace faulty lamp.

STEP 3. Nonessential bus switch not in manual position.

#### Position switch to MANUAL.

- 3. Position lights fail to dim or fail to burn when switch is actuated to dim position
  - STEP 1. Check for defective dimming resistor (R33).

# Replace dimming resistor.

- 4. NVG position lights fail to illuminate when NVG POS LTS switch is actuated.
  - STEP 1. Check for open circuit breaker, faulty switch, shorted wiring or loose connection

If the lights remain inoperative, replace light assembly.

### 9-259. Removal - Landing Lights.

- a. Check that all electrical power is off
- b. Remove light access window.
- **c.** Remove nuts, spacers, washers, and bolts attaching landing lights.
- **d.** Disconnect electrical wiring from landing lights and cover wire ends using electrical tape (C137). Remove light.

#### NOTE

Replace wires L2A14(L2A12), L6A16N, L5A14(L5A12) and L7A16N, figure F-15 with wire, MIL-W-22759/5. The wire part number conforming to this specification is 140-008-12 for the power lead and 140-008-16 for the ground lead.

**9-260. Repair - Landing Lights.** Replace faulty or damaged component parts.

# 9-261. Installation - Landing Lights.

- **a.** Remove tape from wire ends and connect electrical wiring to landing light.
- **b.** Position light on mounting bracket and install attaching bolts, washers, spacers, and nuts.
- **c.** Adjust "down shining" landing light (DS7) so that rim of light is **1.400** inches below roof of compartment. Adjust "forward shining" landing light (DS8) so that rim of light is **4.750** inches below roof of compartment.
  - d. Install light access window.

#### 9-262. LANDING LIGHT RELAYS.

- **9-263. Description Landing tight Relays.** Two relays (K8 and K9, figure 9-1) located in the nose compartment, control illumination of landing lights and are actuated by landing light switch (S49).
- **9-264. Inspection Landing Light Relays.** Refer to paragraph 9-364.

#### 9-265. Removal - Landing Light Relays.

- a. Check that all electrical power is OFF.
- **b.** Disconnect all electrical wiring from the relay and cover wire ends using electrical tape (C137).
- **c.** Remove screws and washers attaching relay and remove relay.
- **9-266. Repair Landing Light Relays.** Refer to paragraph 9-365.

# 9-267. Installation - Landing Light Relays.

- **a.** Position landing light relay and install attaching washers and screws.
- **b.** Remove tape from wire ends and connect all electrical wiring.
- **9-268.** IR/White (Dual) Landing/Searchlight A

  C . After compliance with MWO 55-1520-228-50-32.
- 9-269. Description IR/White (Dual) Landing/Searchlight. A dual light assembly with a white light on one side and IR light on the other side is mounted in the lower nose section of the helicopter. The circuit consists of two controllable lights; two circuit breakers located in the overhead circuit breaker panel; and two switches, located on the pilot collective stick switch box.

# CAUTION

Do not illuminate light in areas of combustible material, such as tall grass, etc.

Do not illuminate IR light with light assembly fully retracted.

# 9-270. Functional Test - IR/White (Dual) Landing/Searchlight.

- **a.** Close SRCH LT CONTand SRCH LT PWR circuit breakers. Position three-way LDG LT switch to ON and check that white light illuminates. Return switch of OFF.
- **b.** Position four-way LDG LT switch to EXT (forward position). Check that light extends and is stopped by extend li m it switch at 120 degree extension.
- **c.** Position three-way LDG LT switch to NVG position. Check that IR light illuminates. Return switch to OFF.
- **d.** Position four-way switch to RETR (aft position). Check that light retracts.

#### NOTE

White light will automatically extinguish when light rotates 90 degrees right or left of center, if extended less than 60 degrees.

- **e.** With light partially extended, position four-way switch to the left and check that light rotates to the left.
- **f.** Position four-way switch to the right and check that light rotates to the right.

# 9-271. Troubleshooting - IR/White (Dual) Landing/Searchlight. Refer to table 9-15.

# 9-272. Cleaning - IR/White (Dual) Landing/Searchlight.

- a. Remove moisture and loose dirt with a clean, soft cloth.
- **b.** Remove dirt from electrical connectors with a bristle brush.
- **9-273.** Inspection IR/White (Dual) Landing/Searchlight. Visually inspect searchlight assembly and cover(s) for signs of damage or missing parts. Inspect collective head for switch operation, orientation, and missing parts. Ensure C/Bs are correctly labeled and activated.

# MOD, KIT, IR/WH (DUAL) LANDING/SEARCHLIGHT EGD 0967-1 TROUBLESHOOTING CHART

Table 9-15. Troubleshooting - IR/White (Dual) Landing/Searchlight A C

Table 3-13. Houbieshooting - In White (Buai) Landing/ocal chilight				
FAILURE	PROBABLE CAUSE	CHECK/TEST	RESULT - ACTION	
3-position switch WHITE or NVG Lamp fails to turn on	No power to light	Check battery master	Switch off - Turn on.	
	assembly	Check SRCH LT PWR CB	CB disabled - Activate CB	
	Lamp failure (WHITE) or IR)	Remove lamp wiring Ground lamp GND terminal Apply 28 Vdc to other terminal on lamp	Lamp does not light - Replace lamp.	
	Wiring Fault	Check wiring/ continuity per wiring diagram	Wiring incorrect - Correct wiring installation.	
		Connect dc meter GND to terminal No. 1 (TI) and V+ to terminal No. 3 (T3)	No power to light, wiring incorrect at bus - Correct wiring installation.	
	3-position switch failure (WHITE)	Connect dc meter GND to T1 and V+ to T2	No power to relay - Replace 3-position switch	
	3-position switch failure (IR)	Connect dc meter GND to T1 and V+ to T8	No power to relay - Replace 3-position switch	
	Lamp relay failure (WHITE)	Connect dc meter GND to T1 and V+ to T2 then T3 (28 Vdc input)	Power to both terminals (T2 & T3) - Relay failure replace light assembly	
	(IR)	Connect dc meter GND to T1 and V+ to T8 then T3	Power to both terminals (T8 and T3) - Relay failure replace light assembly	
3-position switch OFF lamp(s) fails to turn off	Lamp relay failure/ wiring fault	Connect dc meter GND to T1, V+ to T2 (WHITE) V+ to T8 (IR)	No voltage - Relay failure, replace light assembly, 28 Vdc present-wiring fault - Correct wiring installation	

# MOD, KIT, IR/WH (DUAL) LANDING/SEARCHLIGHT EGD 0967-1

# TROUBLESHOOTING CHART

Table 9-15. Troubleshooting - IR/White (Dual) Landing/Searchlight A A (Cent)

FAILURE	PROBABLE CAUSE	CHECK/TEST	RESULT - ACTION
4-position switch - any position	No power to light assembly	Check SRCH LT CONT CB	CB disabled - Activate CB
		Connect dc meter GND to T1, V+ to T3	No voltage - Wiring incorrect at bus, correct wiring installation.
	Wiring fault	Check continuity from 3-position comm. to 4-position comm. (Pin 6) (Wire L422A20)	No continuity - Correct wiring installation
4-position switch - L	Relay/motor failure	Connect dc meter GND to T1, V+ to T5	Voltage present - Replace light assembly
	4-position switch failure	Connect dc meter GND to T1, V+ to T5	No voltage present - Replace 4-position switch
4-position switch - R	Relay/motor failure	Connect dc meter GND to T1, V+ to T4	Voltage present - Replace light assembly
	4-position switch failure	Connect dc meter GND to T1, V+ to T4	No voltage present - Replace 4-position switch
4-positicm switch - EXT	Relay/motor failure	Connect dc meter GND to T1, V+ to T6	Voltage present - Replace light assembly
	4-position switch failure	Connect dc meter GND to T1, V+ to T6	No voltage present - Replace 4-position switch
4-position switch - RETR	Relay/motor failure	Connect dc meter GND to T1, V+ to T7	Voltage present - Replace light assembly
	4-position switch failure	Connect dc meter GND to T1, V+ to T7	No voltage present - Replace 4-position switch

# 9-274. Removal - IR /White (Dual) Landing/Searchlight.

- a. Be sure all electrical power is off.
- b. Remove light mounting screws.
- c. Lower light assembly.
- **d.** Remove terminal cover, disconnect, and protect wires.
  - e. Remove light assembly.

# 9-275. Repair or Replacement - IR/White (Dual) Landing/Searchlight.

- **a.** Removal/Replacement of sealed beam lamp in non-I R part of searchlight:
- **b.** Ensure that searchlight is in the proper (stowed) position with the white light facing outward. Ensure that the collective-mounted control switch is OFF. Pull LDG LT CONT and LDG LT PWR circuit breakers. Remove four screws securing retaining ring and remove retaining ring. Remove lamp. Label and disconnect wiring.

#### **NOTE**

Observe position of lamp before removal, and install new unit in same position with lamp key inserted in cutaway notch in canopy housing. Reassemble using reverse order of removal procedure.

c. Removal/Replacement of IR filter and sealed beam lamp in IR part of searchlight: Before disconnecting aircraft power, rotate searchlight canopy until IR filter is facing outward. Ensure that the collective-mounted searchlight control switch is OFF. Pull LDG LT CONT and LDG LT PWR circuit breakers. Remove four screws securing IR filter and remove IR filter. Remove lamp.

### NOTE

Observe position of lamp before removal, and install new unit in same position with lamp key inserted in cutaway notch in canopy housing. Reassemble using reverse order of removal procedure.

- **d.** Removal/Replacement of canopy assembly:
- (1) Ensure that white light is facing out in stowed position and extend light completely. Pull LANDING LT CONT and LDG LTPWR circuit breakers, and ensure that the collective-mounted searchlight control switch is OFF.
- (2) Removal: Remove both the IR and white lamps (procedure above). Label the wires to IR lamp and white lamp with tape. Loosen screws holding canopy to shaft. Slide canopy off shaft. Slide wires out of canopy.
- (3) Installation: Slide new canopy over shaft so that the housing for the white light will be facing outward in same position as removed white light. Line up the two setscrews with detents in the shaft. Tighten the setscrews. Check end play in the shaft using a **0.150** inch thickness gage, and reset as required. Slide wires into canopy, Reinstall lamps.
- **e.** Removal/Replacement of IR/white searchlight assembly: Refer to paragraphs 9-274 and 9-275.

# 9-276. CONTROLLABLE LANDING LIGHT C

**9-277. Description - Controllable Landing Light System.** Helicopters having MWO 55-1520-228-50-16 incorporated will have a controllable landing light located in the lower center section of the nose, capable of providing illumination for a full range of 360 degrees, when extended 60 degrees or more. The circuit consists of one controllable light; two circuit breakers, located in the overhead circuit breaker panel and two switches, located on the pilot collective stick switch box.

# CAUTION

Do not illuminate light in areas of combustible material, such as tall grass, etc.

# 9-278. Functional Test - Controllable Landing Light.

**a.** Close landing LTPWR and landing LTCONT circuit breakers. Position landing light switch to ON and check that light illuminates. Return switch to OFF.

- **b.** Position four-way switch to extend (forward position). Check that light extends and is stopped by extend limit switch at approximately 120 degrees extension.
- **c.** Position four-way switch to RETR (aft position). Check that light retracts.

Landing light must be extended at least 60 degrees before full 360 degrees travel can be achieved.

**d.** With light partially extended, position four-way switch to the left and check that light rotates to the left.

- **e.** Position the four-way switch to the right and check that light rotates to the right.
- **f.** With light extended and rotated, position switch to STOW. Check that light retracts and is stopped by the retract limit switch and then rotates to its level stowed position and stops.

**9-279.** Troubleshooting - Controllable Landing Light System. Troubleshoot the controllable landing light system in accordance with table 9-16.

#### **NOTE**

Before using table 9-16, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-16, notify the next higher level of maintenance.

Table 9-16. Troubleshooting - Controllable Landing Light C

#### CONDITION

**TEST OR INSPECTION** 

# **CORRECTIVE ACTION**

- 1. Light fails to illuminate.
  - STEP 1. Check for open or defective landing light control or landing light power circuit breakers. Close or replace circuit breaker as required.
  - STEP 2. Check that light is not rotated more than approximately 90 degrees and extended less than approximately **60** degrees.

# Reposition light to within these limits.

STEP 3. Check for open lamp filament.

# Replace lamp. Refer to paragraph 9-275.

STEP 4. Check for defective switch (ON-OFF-STOW).

#### Replace switch.

STEP 5. Check for open or high resistance in wiring or connection. Refer to figure F-40.

### Replace or repair wiring or clean or tighten connections.

STEP 6. Check for faulty limit switches.

Replace light assembly. Refer to paragraph 9-275.

# Table 9-16. Troubleshooting - Controllable Landing Light C (Cont)

#### CONDITION

**TEST OR INSPECTION** 

# **CORRECTIVE ACTION**

2. Light intermittent or dim

STEP 1. Check for faulty wiring or ground. Refer to figure F-40

#### Repair as required.

3. Light fails to extend or rotate.

STEP 1. Check for open or defective landing light control or landing light power circuit breakers.

# Close or replace circuit breakers as required.

STEP 2. Check for faulty switch (four-way).

#### Replace switch.

STEP 3. Check for faulty wiring. Refer to figure F-40

#### Repair or replace as required.

STEP 4. Check for faulty light assembly.

# Replace light assembly. Refer to paragraph 9-275.

4. Light fails to stow - all other functions are normal.

STEP 1. Check for faulty switch (ON-OFF-STOW),


# Replace switch.

STEP 2. Check for faulty wiring. Refer to figure F-40.

#### Repair or replace as required.

# 9-280. Cleaning - Controllable Landing Light.

a. Remove moisture and loose dirt with a clean, soft cloth.



Drycleaning solvent is flammable and its fumes are toxic. Provide adequate ventilation. Do not use near a flame.

- **b.** Remove grease, fungus, and ground-in dirt with a clean, lint-free cloth dampened with drycleaning solvent (C62).
- **c.** Remove dirt from electrical connectors with a bristle brush (C31).

# 9-281. Inspection - Controllable Landing Light.

a. Check light for defective or broken sealed beam unit.

**b.** Check for loose connections and damaged or defective component parts (terminal strips, limit switches, drive motors, relays, etc).

# 9-282. Removal - Controllable Landing Light.

- a. Ensure all electrical power is OFF.
- **b.** Remove attaching screws from light assembly mounting plate; lower light and plate.
  - c. Remove light mounting screws,
- **d.** Remove terminal cover, disconnect and protect wires.
  - e. Remove light assembly.

# 9-283. Repair or Replacement - Controllable Landing Light.

- a. Ensure all electrical power is off.
- **b.** Accomplish replacement of sealed beam lamp as follows:
- (1) Remove three screws from lamp retainer ring, remove ring and gasket.
  - (2) Lift lamp and disconnect wiring.

# **NOTE**

Observe position of lamp before removal and install new unit in same position using reverse order of removal procedure.

- **c.** Position light on mounting plate and secure with mounting screws.
- **d.** Position plate and light assembly on fuselage and secure with mounting screws.
- **e.** Check light for proper operation. Refer to paragraph 9-270.

#### 9-284. POSITION LIGHTS.

**9-285. Description - Position Lights.** Two lights (DS2-left and DS3-right) located on the tailboom horizonal stabilizer tips are controlled by the position lights switch (S68) and dimming resistor (R33). Refer to figure F-15 and 9-1.

**9-286. Description - NVG Position Lights (IR).** Two forward NVG position lights mounted forward of the FM homing antenna on both sides of the aircraft, two lower NVG position lights mounted forward of the APR-39 antenna support and one aft NVG position light mounted on top of the taillight support assembly are all controlled by the NVG POS LTS switch.

### 9-287. Cleaning - Position Lights.

- **a.** Remove moisture and loose dirt with clean, soft cloth.
- **b.** Remove grease, fungus, and ground-in dirt with a clean, lint-free cloth dampened with drycleaning solvent (C62).
- **9-288.** Cleaning NVG Position Lights. Remove moisture and loose dirt with a clean, soft cloth.

# 9-289. Inspection - Position Lights.

- a. Inspect lights for corroded lamp socket terminals.
  - **b.** Inspect for broken or shorted wires.
- **c.** Check lights for burned out bulbs and cracked lens.
- **d.** Inspect for improper bonding of light case to airframe.

#### 9-290. Inspection - NVG Position Lights.

- a. Inspect for broken or shorted wires.
- b. Check lights for cracked lens.
- **c.** Inspection for improper bonding of light base to airframe.

# 9-291. Testing - Position Lights.

- **a.** Place POS LTS switch to OFF. Place NON-ESS BUS switch to MANUAL. Ensure that POS LTS circuit breaker is closed.
- **b.** Place POS LTS switch (S68) to DIM. Check that both right and left position lights and the taillight are dimly illuminated.

- **c.** Place the POS LTS switch to BRT. Check that both side position lights and the taillight are brightly illuminated.
- **d.** Place POS LTS switch to OFF. Check that the side position lights and the taillight are extinguished.

#### 9-292. Testing - NVG Position Lights.

- a. Ensure that NVG POS LTS circuit breaker is closed.
- **b.** Rotate NVG POS LTS switch through 1, 2, 3,4, and BRT positions. Check that IR light illumination increases with each movement.
- **c.** Rotate NVG POS LTS switch of OFF. Check that all lights extinguish.
- **9-293. Troubleshooting Position Lights.** Refer to tables 9-13 and 9-14.
- **9-294.** Troubleshooting NVG Position Lights. Refer to tables 9-13 and 9-14.
- 9-295. Removal Position Lights.

### **NOTE**

Position light lens or lamps may be replaced by simply removing one light fairing attachment screw; then remove lens or lamp as necessary.

- a. Check that electrical power is OFF.
- b. To remove left or right position lights, remove three attaching screws 'and remove light from mounting. Back off coupling nut and disconnect electrical wiring from light. Cover wire ends using electrical tape (CI 37).

# 9-296. Removal - NVG Position Lights.

- a. Check that electrical power is OFF.
- **b.** Remove two mount screws with washers. Remove light assembly from airframe and cut or disconnect power wire as applicable and disconnect ground wire.
  - c. Protect wires.

**9-297. Repair - Position Lights.** Replace faulty or damaged components.

# 9-298. Installation - Position Lights.

- a. Remove tape from left or right position light wire ends.
- **b.** Thread wires through coupling nut and connect to lights; tighten coupling nut.
- c. Position light and install three attaching screws.

# 9-299. Installation - NVG Position Lights.

- a. Feed light wires through center access hole,
- **b.** Splice or reconnect power and ground wires as applicable.
- c. Install light with two washers and two mount screws.
  - **d.** Apply sealing compound at the light base.

#### 9-300. TAILLIGHT.

- **9-301. Description Taillight.** Taillight (DS4) is located on aft end of tailboom. Refer to figure F-15 and 9-1.
- **9-302. Cleaning Taillight.** Refer to paragraph 9-287.
- **9-303. Inspection Taillight.** Refer to paragraph 9-289.
- **9-304. Testing Taillight.** Refer to paragraph 9-291.
- **9-305. Troubleshooting Taillight,** Refer to table 9-13 and 9-14.

### 9-306. Removal - Taillight.

- a. Check that all electrical power is OFF.
- **b.** Remove two attaching screws and remove light from shock mounting.
- c. Disconnect coupling nut attaching wiring insert to light and cover insert end using electrical tape (C137).

**9-307. Repair** — **Taillight.** Replace faulty or damaged component parts.

### 9-308. Installation — Taillight.

- **a.** Remove tape from wiring insert. Place insert in position and tighten coupling nut.
- **b.** Position light on shock mount, install and tighten attaching screws.

### 9-309. ANTICOLLISION LIGHTS.

- **9-310. Description Anticollision Lights.** The anticollision light circuit consists of a circuit breaker (CB8), a switch (S83), two anticollision lights (DS1, upper and DS5, lower), and a light flasher (Z10). The anticollision lights are energized from the 28 volt bus, located in the overhead console.
- **9-311. Cleaning Anticollision Lights.** Refer to paragraph 9-287.

### 9-312. Inspection — Anticollision Lights.

- **a.** Inspect flasher case for dents or damage that would impair normal operation of unit. Inspect flasher unit for proper operation, refer to paragraph 9-313.
- **b.** Inspect light for broken lens, cover, or open filament.
  - **c.** Inspect for broken or shorted wires or pins.

# 9-313. Testing — Anticollision Lights.

- **a.** Position anticollision lights switch to OFF. Close ANTI COLL LTS circuit breaker.
- **b.** Place anticollision lights switch to ANTICOLLISION LTS. Check that the two anticollision lights illuminate and flash alternately at a rate of **90** (±9) flashes per minute. Replace defective components.
- **c.** Place anticollision lights switch to OFF. Check that anticollision lights are extinguished.
- **9-314. Troubleshooting anticollision Lights.** Refer to figure F-15 and table 9-13 and 9-14.

#### 9-315. Removal — Anticollision Lights.

**a.** Check that all electrical power is OFF.

- **b.** Remove mounting screws and lift lamp assembly to gain access to wiring.
  - c. Disconnect electrical leads and cap ends with tape.
  - **d.** Remove light base from helicopter.

#### NOTE

Due to design features, components manufactured by Aeroflash Signal Corporation will not be used or mixed with another manufacturer's components in this system.

When replacing the bulb in the anticollision light, take care to avoid touching the glass portion of the bulb with bare fingers. Oil from fingers will shorten life of bulb.

# 9-316. Removal — Light Flasher.

- **a.** Cut wires or disconnect wrist splices, as applicable.
  - **b.** Remove mounting hardware and remove flasher.
- **9-317. Repair Anticollision Lights.** Replace faulty or damaged parts.

# 9-318. Installation — Anticollision Lights.

- **a.** Remove tape from wires and connect wiring to lamp terminals.
- **b.** Position lamp assembly on fairing and install mounting hardware.

#### 9-319. Installation — Light Flasher.

- **a.** Install the flasher assembly using six wrist locks (MS27429-1) instead of splices. Stagger the wrist locks per paragraph 14-12, TM 55-1500-325-25.
  - **b.** Install mounting hardware,

#### 9-320. FAULT ANNUNCIATOR PANEL.

**9-321. Description** — Fault Annunciator Panel. The fault annunciator panel contains a number of

internally lighted capsules that illuminate when associated switches (sensors), located at different places in the helicopter, actuate to complete circuits; thus indicating malfunctions in the systems being monitored by the sensors. The panel is energized from the **28** Vdc bus and protected by a **5** ampere circuit breaker.

- **9-322.** Cleaning Fault Annunciator Panel. Remove loose dust or dirt from exposed surfaces, using dry, compressed air at a maximum pressure of **10** psi.
- **9-323. Testing Fault Annunciator Panel.** Testing should be limited to periodically pushing the test/reset switch to TEST. This results in every indicator, including the master caution indicator, lighting either bright or dim, depending on the condition to which the system was last set by the BRIGHT/DIM switch.
- **9-324.** Troubleshooting Fault Annunciator Panel. Refer to schematic diagram (FO-3 or FO-4) and trace malfunctioning circuit or loop, using standard electronic troubleshooting procedures and standard test equipment. Localize malfunctioning components and repair or replace as required.

# 9-325. Removal - Fault Annunciator Panel,

- a. Turn all electrical power OFF.
- **b.** Disengage fasteners holding panel to mounting.
- **c.** Lift panel and remove electrical connector plug from rear of panel.
  - d. Remove panel from console.

# 9-326. Disassembly - Fault Annunciator Panel. (AVIM)

- **a.** Remove 13 screws (1, figure 9-20), cover (2), and plate (3) to gain access to interior of unit.
- **b.** Remove 16 screws (21 and 29, figure 9-21), plate (4) and cover (30) to gain access to interior of unit.

#### NOTE

Disassemble panel in order indexed on figure 9-20 or 9-21. Disassemble only to extent necessary to accomplish replacement of damaged parts, as determined by inspection or troubleshooting procedure.

# 9-327. Cleaning - Fault Annunciator Panel. (AVIM)



Use cleaning solvent in a wall-ventilated area. Avoid inhaling fumes and keep solvent away from open flame.

- **a.** Remove corrosion, dirt or other foreign matter from parts with drycleaning solvent (C62) using a clean, lint-free cloth or a soft bristle brush.
- **b.** Thoroughly dry all parts after cleaning with a clean, lint-free cloth or with compressed air at **10** psi.

# 9-328. Inspection - Fault Annunciator Panel, (AVIM)

- **a.** Inspect all components for security of connections and bent or broken pins, contacts, and terminals.
- **b.** Inspect wiring and connections to all parts looking for loose connections, burned or broken wires, and insulation and proper grounding.
- **c.** Inspect resistors for evidence of loose or broken terminals or wire leads, burned or swollen bodies, or other visual signs of damage.
- **d.** Inspect coils for evidence of damage. If necessary, check continuity of coils with a multi meter.
- **e.** Inspect removed fault function panel for broken leads, shorted or damaged components. Inspect relays and diodes for broken glass envelopes.





Figure 9-20. Fault Annunciator Panel (Sheet 1 of 2)





- 1. Screw
- 2. Cover
- 3. Plate
- 4. Panel, Fault Function
- 5. Panel, Fault Function
- 6. Nut
- 7. Washer
- 8. Spacer
- 9. Screw
- 10. Panel, Fault Function

- 11. Screw
- 12. Panel, Indicating
- 13. Switch
- 14. Connector
- 15. Terminal
- 16. Switch
- 17. Nut
- 18. Washer
- 19. Screw
- 20. Connector

- 21. Nut
- 22. Washer 23. Screw
- 24. Nut
- 25. Washer
- 26. Screw 27. Nut
- 28. Washer
- 29. Screw
- 30. Washer

- 31. Bracket
- 32. Bracket
- 33. Connector
- 34. Lens
- 35. Screw
- 36. Screw
- 37. Indicator Assembly

206075-279-2




Figure 9-21. Fault Annunciator Panel (Sheet 1 of 2)




Figure 9-21. Fault Annunciator Panel (Sheet 2)

# 9-329. Repair - Fault Annunciator Panel. (AVIM)

**a.** Repair of the fault annunciator panel is limited to minor repairs, such as soldering loose connections and straightening bent connector pins. Damaged or malfunctioning electronic parts shall be replaced with no attempt at repair of such items.

#### **NOTE**

In each case, replace components in the exact location from which the replaced pert was removed.

**b.** Replace lamps in indicators of the rototellite assembly by rotating the indicator to reach the lamps in base of the unit. Lamps are held in place by spring clips.

# 9-330. Reassembly - Fault Annunciator Panel. (AVIM)

**a.** Reassemble panel by installing plate (3) and cover (2) using 13 screws (1). Refer to figure 9-20.

**b.** Reassemble panel by installing plate (4) and cover (30) using 16 screws (21 and 29). Refer to figure 9-21.

#### **NOTE**

Refer to schematic diagram, FO-3 or FO-4 when installing new electronic components or wiring. If new parts are installed trim excess wire leads after soldering. Install all attaching hardware in same position and location from which removed.

#### 9-331. Installation - Fault Annunciator Panel.

- a. Connect electrical plug to rear of panel.
- b. Position panel in console.
- c. Engage fasteners securing panel to console.

# SECTION VI. MISCELLANEOUS EQUIPMENT.

# 9-332. MISCELLANEOUS EQUIPMENT.

**9-333. Description - Miscellaneous Equipment.** Miscellaneous equipment covered in this section includes the defogging blower system, bleed air heater system, pitot heater system, auxiliary power receptacle, armament electrical system, common electrical components, and control panels.

# 9-334. DEFOGGING BLOWER SYSTEM.

**9-335. Description - Defogging Blower System.** This system provides air circulation directed on the left and right windshields to dissipate any condensation formation on the windshields, and consists of: right blower motor (B7), left blower motor (B8), wired in parallel and energized by the DEFOG&

VENT circuit breaker (CB5). The system is fed from the **28** Vdc bus in the overhead console.

**9-336. Testing - Defogging Blower System.** Testing the defogging blower system consists of performing operational checks of blower motors (B7 and B8). For testing refer to paragraph 9-341.

**9-337. Troubleshooting - Defogging Blower System.** Troubleshoot the defogging blower system in accordance with table 9-17.

#### NOTE

Before using table 9-17, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-17, notify the next higher level of maintenance.

### Table 9-17. Troubleshooting - Defogging Blower System

#### CONDITION

**TEST OR INSPECTION** 

### **CORRECTION ACTION**

- 1. Blowers fail to operate when DEFOG & VENT switch breaker is positioned to ON.
  - STEP 1. Check for defective switch, loose connections, or shorted wiring.

# Repair or replace wiring, tighten loose connections or replace defective switch.

STEP 2. Check for defective blower motor.

### Replace defective blower.

- 2. Circuit breaker opens when blower is energized,
  - STEP 1. Check for shorted wiring or blower motor

### Repair wiring or replace blower.

STEP 2. Check for overloaded blower motor caused by binding blower fan.

#### Reposition blower to correct binding and ensure that fan operates freely.

# 9-338. DEFOGGING BLOWER MOTORS (B7 and B8).

- **9-339. Description Defogging Blower Motors (B7 and B8).** The blower motors provide circulation of air through vents to the right and left windshields to dissipate any moisture formation,
- **9-340.** Inspection Defogging Blower Motors (B7 and B8). Inspect the blower motor for cracked mounting flange.


# 9-341. Testing - Defogging Blower Motors (B7 and B8).

- **a.** To determine that the blower motors operate, perform the following steps:
- (1) Ensure that GEN and BUS RESET circuit breakers are depressed (closed).
  - (2) Position NON-ESS BUS switch to MAN.

- (3) Position DEFOG & VENT switch breaker to ON.
- (4) Determine that both blower motors are operating.
- **b.** Position DEFOG & VENT switch breaker to OFF. Check that both blower motors stop operating,
- **9-342.** Troubleshooting Defogging Blower Motors (B7 and B8). Troubleshoot blower motors in accordance with table 9-17.

# 9-343. Removal - Defogging Blower Motors (B7 and B8).


- **a.** Unsolder electrical wire from noise filter (4, figure 9-22),
- **b.** Remove screws attaching noise filter (4) to structure,



- 1. Defogging Blower (B7 and B8)
- 2. Air Duct
- 3. Windshield Defog Nozzle
- 4. Noise Filter
- 5. Clamp

206070-312-1

Figure 9-22. Defogging Blower Motors (B7 and B8) (Sheet 1 of 2)



- 1. Vent Control
- 2. Heat Control
- 3. Heat Control Cable
- 4. Bleed Air Tube
- 5. Mixing Valve
- 6. Plenum
- 7. Remote Sensor
- 8. Fresh Air Inlet
- 9. Center Post Duct
- 10. Air Distribution Valves
- 11. Windshield Defog Nozzle

- 12. Plenum Drain
- 13. Plenum Valve Assembly
- 14. Ventilating and Defogging Blower
- 15. Ram Air Intake Grill
- 16. Air Distribution Valves Cargo/Passenger Area
- 17. Coupling
- 18. Clamp
- 19. Noise Filter
- 20. Blower Inlet Duct
- 21. Tee Valve

206070-312-2

Figure 9-22. Defogging Blower Motors (B7 and B8) (Sheet 2)

- **c.** Remove screw, washer, nut, and clamp (5) attaching blower (1) and duct (2).
  - d. Remove blower (1) from duct (2).
- **9-344.** Repair or Replacement Defogging Blower Motors (B7 and 68). Replace the blower motor if it does not meet requirements of test procedure.

# 9-345. Installation - Defogging Blower Motors (B7 and B8).

- **a.** Partially insert blower (1, figure 9-22) in air duct (2).
- **b.** Position clamp (5) on duct (2) and blower (1). Attach clamp (5) to mounting provision on structure with screw, washer, and nut.
- **c.** Install noise filter (4) on nose structure with four screws, washers, and nuts.

#### NOTE

Ensure a good electrical bond is made between case of noise filter (4) and bare structure.

**d.** Using solder (C133) solder wire to noise filter (4).

# 9-346. BLEED AIR HEATER SYSTEM.

- **9-347. Description Bleed Air Heater System.** The electrical portion of the bleed air heater system consists of heater solenoid (L2), heater relay (K15), heater overheat switch (S90) and associated wiring. The system is energized from and protected by a 5 ampere HTR switch breaker located in the overhead console, which energizes heater solenoid (L2) through heater relay (K15). Should an overheat condition occur (S90) closes to actuate (K15) thus breaking circuit to (L2).
- **9-348. inspection Bleed Air Heater System,** Inspect the bleed air heater system in accordance with paragraph 13-3.

#### 9-349. Testing - Bleed Air Heater System.

**a.** Place NON-ESS BUS switch to NORM. Place heater switch breaker to HTR. Check that the cabin bleed-air inlet vent opens.

- **b.** Place a jumper wire from XI of the heater relay to helicopter structure. Check that the cabin bleed-air inlet vent closes.
- **c.** Remove the jumper wire installed in step b. Check that bleed-air inlet vent opens.
- **d.** Place HTR switch breaker to OFF. Check that the cabin bleed-air vent closes.

#### NOTE

For additional information on bleed air heater system refer to Chapter 13.

- **9-350.** Troubleshooting Bleed Air Heater System. Troubleshooting the bleed air heater system in accordance with table 13-1.
- **9-351.** Removal Bleed Air Heater System, Remove bleed air heater system components in accordance with procedures provided in Chapter 13.
- **9-352.** Repair or Replacement Bleed Air Heater System. Repair bleed air heater system components in accordance with procedures provided in Chapter 13.
- **9-353.** Installation Bleed Air Heater System. Install bleed air heater system components in accordance with procedures provided in Chapter 13.

# 9-354. PITOT HEATER SYSTEM.

- **9-355. Description Pitot Heater System.** The pitot heating system consists of a pitot tube heater (HR1), located in the nose section. The pitot heating system is energized from and protected by a 5 ampere PITOT HTR switch breaker, located in the overhead console.
- **9-356. Inspection Pitot Heater System.** Inspect the pitot heater system in accordance with paragraph 8-159.

#### 9-357. Testing - Pitot Heater System.

**a.** Place PITOT HTR switch breaker to PITOT HTR. Check that pitot tube heater begins to heat.



Pitot tube heats rapidly. Use extreme care when checking operation to avoid serious burns.

- **b.** Place PITOT HTR switch breaker to OFF. Check that pitot heater stops heating.
- **9-358.** Troubleshooting Pitot Heater System. To troubleshoot the pitot heater system refer to figure F-10. Use standard procedures to troubleshoot the simple circuit.
- **9-359. Removal Pitot Heater System.** Remove the pitot heater system in accordance with paragraph 8-160.
- **9-360.** Repair or Replacement Pitot Heater System. Repair the pitot heater system in accordance with paragraph 8-161.
- **9-361. Installation Pitot Heater System.** Install the pitot heater system in accordance with paragraph 8-162.

# 9-362. COMMON ELECTRICAL COMPONENTS.

**9-363. Description - Common Electrical Components.** Included in the category of common electrical components are relays, rheostats, switches, circuit breakers, plugs, leads, connectors, wiring, conduits, receptacles, shunts, and shock mounts.

# 9-364. Inspection - Common Electrical Components.

- **a.** Inspect rheostats for security, corrosion, burned element, damaged wiper, cracks, and correct resistance.
- **b.** Inspect switches for weak detents, security, corrosion, continuity in ON and OFF position.
- **c.** Inspect circuit breakers for security, corrosion, actuation for circuit power on and power off and reset retentions.
- **d.** Inspect connectors, plugs, and receptacles for security, contact corrosion, damaged contacts,

broken wires, faulty contacts, insert cracks, and faulty insulation.

- e. Inspect leads and wiring for loose terminals, chafing, corrosion or deteriorated conditions, faulty or damaged insulation, excessive mechanical stress, broken strands, damaged shielding, routing, and mounting condition.
- f. Inspect conduits for security, surface damage, cracks, corrosion, and deterioration.
- **g.** Inspect ammeter shunt for corrosion, security, deep scratches, physical damage, and discoloration.
- **h.** Inspect shock mounts for retention, security, cracks, distortion, corrosion, and bonding.
- i. Inspect relays for loose connections, damaged or broken contact pins or terminals, physical damage to case or insulation between contact pins, and discoloration that would indicate internal shorting or excessive overload.

#### **NOTE**


Clean corrosion from connectors and contacts with cleaner (C151). Use sparingly and keep away from cable assemblies and insulation.

# 9-365. Repair or Replacement - Common Electrical Components.

- **a.** Tighten loose terminal connectors, mounting, and attachment of electrical components.
- **b.** Replace miscellaneous electrical components that fail to meet inspection requirements.

# 9-366. Removal - Common Electrical Components.

**a.** Gain access to applicable components.



Before attempting to remove or adjust any electrical component, disconnect battery.

**b.** Disconnect wiring to component and cover wire ends using electrical tape (C137).

**c.** Remove attaching hardware and remove component.

# 9-367. Installation - Common Electrical Components.

- **a.** Install component and secure with attaching hardware or clamps.
- **b.** Remove cover from wire ends and connect wiring.
- **c.** Install any access panel, sound proofing, or covers removed for access.

# 9-368 AUXILIARY POWER RECEPTACLE (J120).

- **9-369. Description Auxiliary Power Receptacle** (J120). The auxiliary receptacle (J120) is mounted on a bulkhead aft and inboard of the pilot seat and provides power take off of 28 VDC to operate miscellaneous auxiliary equipment. The circuit is powered from 28 Vdc essential bus and protected by a 10 ampere AUX RECP switch breaker (CB11) in the overhead console. Refer to figure 9-1.
- 9-370. Inspection Auxiliary Power Receptacle (J120). Inspect the auxiliary power receptacle for condition and security.

# 9-371. Testing - Auxiliary Power Receptacle (J120).

- a. Connect and energize external power source.
- b. Close circuit breaker switch AUX RECP.
- **c.** Prepare standard voltmeter to measure dc voltage. Place voltmeter lead on receptacle pin A; place the return lead on receptacle pin B.
  - d. The voltmeter shall indicate 28 (±1) Vdc.
- **9-372. Troubleshooting Auxiliary Power Receptacle (J120).** To troubleshoot the auxiliary power receptacle circuit, use a standard voltohmmeter to troubleshoot the simple circuit.
- **9-373.** Removel Auxiliary Power Receptacle (J120). To remove the power receptacle, refer to paragraph 9-366.

- **9-374.** Repair or Replacement Auxiliary Power Receptacle (J120). To repair the power receptacle, refer to paragraph 9-365.
- **9-375.** Installation Auxiliary Power Receptacle (J120). To install the power receptacle, refer to paragraph 9-367.

# 9-376. ARMAMENT ELECTRICAL SYSTEM - AIRFRAME . A

- **9-377. Description Armament Electrical System.** The armament electrical system consists of the following components.
  - a. Control panel located in instrument panel
  - **b.** Firewall disconnect (gun) with dust cover
- **c.** Armament control panel disconnect (P301) located in upper portion of pedestal
- d. Terminal junction (TB4) located in right side of lower console
- **e.** Part of impedance pad network located forward of instrument panel in console
- **f.** Part of junction terminals (TB1 and TB6) located in console adjacent to impedance pad network.
- **9-378.** Inspection Armament Electrical System. Inspect armament electrical system components in accordance with paragraph 9-364.
- 9-379. Testing Armament Electrical System (Armament Control Circuitry).



Test procedures in the following steps require the use of live ammunition. Take adaquate precautionary measures according to Army regulations before performing the following tests.

**a.** Pull out (open) ARMT PWR and ARMT circuit breakers.

- **b.** On armament control panel, position switches as follows:
  - (1) ARMED/SAFE to SAFE
  - (2) MASTER to OFF.
- **c.** Adjust instrument and console panel light controls for dim light conditions (rheostats ccw).
- **d.** Install jumper wires in the armament control circuitry as follows:
- (1) Install a jumper wire between pins C and L, of turret connector (J300).
- (2) Install a jumper wire between pins M and H, of turret connector (J300).
- (3) Install a jumper wire from the helicopter structure (ground) to pins D and E, of turret connector (J300).
  - e. Energize the essential dc bus.

# Use a standard voltmeter to perform voltage measurements in the following steps.

- f. Perform the following armament control circuitry tests.
  - (1) Close ARMT PWR circuit breaker.
- **(2)** Measure 28 Vdc at pin A, turret connector (J300).
  - (3) Open ARMT PWR circuit breaker.
- (4) Close ARMT PWR circuit breaker and measure 28 Vdc at pin M of turret connector.

#### NOTE

# Determine that voltage is not present at pin F or at pin T of turret connector.

(5) On armament panel, observe that only the GUN NOT CLEARED caution lamp is brightly illuminated.

#### NOTE

# All other indicator lamps on the armament panel are out (not lighted).

- **(6)** On armament panel, position MASTER switch to FIRE TO CLEAR.
  - (7) Observe the following lighting conditions.
- (a) GUN NOT CLEARED caution light remains brightly illuminated.
- **(b)** AMMO LOW caution light illuminates brightly.
- (8) Measure 28 Vdc at pins J and F of turret connector.

#### **NOTE**

# Determine that voltage is not present at pin T of the turret connector.

- (9) Position ARMED/SAFE switch to ARMED.
- (10) Observe the following lighting condition.
- (a) ARMED caution lamp illuminates brightly.
- **(b)** GUN NOT CLEARED and AMMO LOW caution lamps remain brightly illuminated.
- (11) Depress and hold trigger switch on pilot cyclic stick to the first position. Check that 28 Vdc is present on pin K of turret connector.
- (12) Depress and hold trigger switch on pilot cyclic stick to the second position. Check that 28 Vdc is present at pin N of turret connector.
- (13) Release trigger switch. Check that there is no voltage present on pin K or pin N of the turret connector.
- (14) Repeat steps (11), (12), and (13) except depress the trigger switch on the copilot cyclic stick.
- (15) Place and hold gun elevation switch on pilot cyclic stick to extreme downward position. Check that 28 Vdc is present on pin R of the turret connector.

- (16) Place and hold pilot gun elevation switch to extreme upward position. Check that 28 Vdc is present on pin P of the turret connector.
- (17) Repeat steps (15) and (16) using the copilot gun elevation switch.
  - (18) Position MASTER switch to FIRE NORM.
- (19) Observe that GUN NOT CLEARED and AMMO LOW indicator lights remain brightly illuminated.
- (20) Measure 28 Vdc at pin J and pin T of the turret connector.

# Determine that voltage is not present at pin F.

- (21) Rotate the instrument lights control slightly clockwise from DIM. Check that armament lights in step (19) are dimly illuminated.
- (22) Depress the WARNING LTS TEST switch. Check that armament lights listed in step (19) return to the bright condition. Release test switch and check that armament lights return to the dim condition.
- (23) Rotate the instrument lights control counterclockwise to DIM. Check that the armament lights listed in step (19) are brightly illuminated.
- **(24)** Rotate the console lights control slightly clockwise. Check that the armament control panel edge lights are dimly illuminated.
- (25) Continue clockwise rotation of the console lights control. Check that armament control panel edge lights increase in brightness with clockwise rotation on the control and are brightest at clockwise extreme (BRT).
- (26) Rotate console lights control in a counterclockwise direction. Check that armament control panel edge lights decrease in brightness as control is rotated counterclockwise and are extinguished as control is rotated to its DIM position.
  - (27) Open ARMT circuit breaker.

- (28) Remove the jumper wires from pins D and E of turret connector.
  - (29) Position ARMED/SAFE switch to SAFE.
  - (30) Close ARMT circuit breaker.
- (31) Observe that GUN NOT CLEARED, ARMED, and AMMO LOW indicator lights are not lighted.
- (32) Depress WARNING LTS TEST switch. GUN NOT CLEARED, ARMED, and AMMO LOW indicator lights will illuminate brightly.
- (33) Release WARNING LTS TEST switch. Armament lights listed in step (32) above will extinguish.
  - g. Open all circuit breakers.
- **h.** Remove all test jumper wires installed on turret connector.
- i. Check that all switches are in off or normal positions.
- 9-380. Troubleshooting Armament Electrical System. A Refer to table 9-18.

#### WARNING

In the following troubleshooting chart items 1 through 25 are to be performed without ammunition present in the gun, delinking feeder, ammunition chutes, or container.

#### NOTE

The following steps are to be observed when troubleshooting the armament electrical system.

**a.** Gun operation (dry firing) shall be held to a minimum to avoid damaging firing pins. The gun safing sector must be installed to prevent gun jamming and damage to bolt assemblies.

- b. AMMO LOW light will remain illuminated without ammunition and with no malfunctions in its circuitry.
- c. Press reset button on control box to extinguish GUN NOT CLEARED light after items 26 and 27.

Before using table 9-18, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in this table, notify the next higher level of maintenance.

9-381. Removal - Armament Electrical System. Remove armament electrical system components in accordance with paragraph 9-366.

9-382. Repair or Replacement - Armament **Electrical System.** Repair armament electrical system components in accordance with paragraph 9-365.

#### Table 9-18. Troubleshooting - Armament Electrical System A

#### CONDITION

TEST OR INSPECTION

#### **CORRECTIVE ACTION**

- ARMED, GUN NOT CLEAR, and AMMO LOW lights do not illuminate when PRESS TO TEST switch is depressed.
  - STEP 1. Check for defective switch, shorted wiring, or loose connections.

Repair or replace defective wiring, replace switch, or tighten loose connections.

- 2. Only the AMMO LOW light does not illuminate when PRESS TO TEST switch is depressed.
  - STEP 1. Check for defective lamp (open filament) or defective diode (CR24 or CR603).

Replace defective lamp or diode.

STEP 2. Check for defective wiring or loose connections.

Repair or replace wiring. Tighten loose connection.

- Only the ARMED light does not illuminate when PRESS TO TEST switch is depressed.
  - STEP 1. Check for defective lamp, shorted wiring, or loose connections.

Replace defective lamp, repair or replace wiring, and tighten loose connections.

# Table 9-18. Troubleshooting – Armament Electrical System A (Cont)

#### CONDITION

TEST OR INSPECTION

# CORRECTIVE ACTION

- 4. Only the GUN NOT CLEARED light does riot illuminate when the PRESS TO TEST switch is depressed.
  - STEP 1. Check for defective lamp, shorted wiring, or loose connections.

### Replace defective lamp, repair or replace wiring, and tighten loose connations.

STEP 2. Check for defective ARM circuit breaker or diode (CR602).

# Replace defective circuit breaker or diode.

- 5. ARMED light illuminates with MASTER switch in FIRE TO CLEAR and ARM/SAFE in SAFE position.
  - STEP 1. Check for defective ARM/SAFE switch or diode (CR24).

#### Replace defective switch or diode.

STEP 2. Check for defective wiring or loose connections.

# Tighten connections and repair or replace wiring.

- ARMED light does not illuminate with MASTER switch in FIRE TO CLEAR and ARM/SAFE in ARM position. 6.
  - STEP 1. Check for defective MASTER switch or ARM/SAFE switch.

# Replace defective switch.

STEP 2. Check for defective diode (CR604) or series resistor (R611).

#### Replace defective diode.

STEP 3. Check for shorted wiring or loose connections.

# Repair or replace wiring or tighten connections.

- 7. With controls positioned as in 6, ARMED light only illuminates when dimming switch is positioned for maximum brightness.
  - STEP 1. Check for defective series resistor (R611) or wiring.

#### Replace resistor or repair or replace wiring.

# Table 9-18. Troubleshooting - Armament Electrical System A (Cent)

#### CONDITION

TEST OR INSPECTION

#### CORRECTIVE ACTION

- 8. ARMED light will not reach maximum brightness with controls positioned as in 6.
  - STEP 1. Check for defective dimming switch (S19) or relay (K602).

#### Replace defective switch or relay.

STEP 2. Check for defective lamp (open filament) or defective wiring.

#### Repair or replace wiring or replace lamp.

- 9. AMMO LOW lamp does not illuminate with ARM/SAFE switch in SAFE and MASTER switch in FIRE TO CLEAR position.
  - STEP 1. Check for defective AMMO LOW or MASTER switch or for shorted wiring or loose connections.

Replace defective switch, repair or replace wiring, or tighten loose connections.

STEP 2. Check for defective diode (CR601 or CR23) or series resistor (R609).

# Replace defective diode or resistor.

- 10. With controls positioned as in 9., AMMO LOW light only illuminated with dimming switch set for maximum brightness.
  - STEP 1. Check for defective series resistor (R609) or shorted wiring.

#### Replace defective resistor or repair or replace wiring.

- 11. With controls positioned as in 9., AMMO LOW light does not attain maximum brightness,
  - STEP 1. Check for defective dimming switch (S19) or relay (K601).

### Replace defective switch or relay.

STEP 2. Check for defective lamp, shorted wiring or loose connection.

Replace defective lamp, tighten loose connection, or repair or replace wiring.

#### 9-104 Change 1

# Table 9-18. Troubleshooting - Armament Electrical System A (Cont)

# CONDITION

TEST OR INSPECTION

#### **CORRECTIVE ACTION**

- 12. GUN NOT CLEARED light illuminates with MASTER switch in FIRE TO CLEAR and ARM/SAFE switch in ARM position.
  - STEP 1. Defective control box logic circuit or wiring.

# Replace control box or repair or replace wiring.

- 13. With controls positioned as in 12, GUN NOT CLEARED light does not illuminate when trigger is depressed.
  - STEP 1. Check for defective series resistor (R610).

#### Replace resistor.

STEP 2. Check for defective control box logic circuit or burst control time delay relay (M2).

# Replace control box.

STEP 3. Check pilot and copilot trigger (S101 or S109).

## Replace defective trigger.

STEP 4. Defective lamp or wiring.

#### Replace lamp or repair or raplace wiring.

- 14. With controls positioned as in 12. and trigger depressed, GUN NOT CLEARED light will not attain maximum brightness.
  - STEP 1. Check for defective dimming switch (S19) or relay (K601).

# Replace defective switch or relay.

STEP 2. Check for defective lamp or wiring.

#### Replace lamp or repair or replace wiring.

- 15. With MASTER switch in FIRE TO CLEAR and ARM/SAFE switch in ARM position, gun will not rotate when trigger is depressed.
  - STEP 1. Check gun to see if it is mechanically jammed.

### Clear jam.

# Table 9-18. Troubleshooting - Armament Electrical System A (Cont)

#### CONDITION

TEST OR INSPECTION

# **CORRECTIVE ACTION**

STEP 2. Check for defective ARM PWR circuit breaker.

Reset or replace breaker.

STEP 3. Check for defective control box (K1 or K2).

Replace control box.

STEP 4. Check for defective speed control unit (CR2, SCR1, SCR2).

Replace defective speed control unit.

STEP 5. Check for defective trigger, shorted wiring, or loose connections.

Replace trigger or repair or replace wiring. Tighten loose connections.

- 16. With controls positioned as in 15., gun rotates at slow rate but rotation will not change to fast rate.
  - STEP 1. Check for defective speed control unit, shorted wiring, or loose connection.

Replace speed control unit, tighten loose connection, or repair or replace wiring.

- 17. With controls positioned as in 15., gun rotates for excessive time after trigger release during fire to clear.
  - STEP 1. Check for defective control box clearing time relay (M1).

Replace control box.

- 18. Gun elevation motor inoperative for any setting of ELEVATE/DEPRESS switches.
  - STEP 1. Check for defective motor, loose connections, or shorted wiring.

Replace motor, tighten loose connection or repair or replace wiring.

- 19. Gun elevation motor responds with ELEVATE/DEPRESS switches in UP only.
  - STEP 1. Check for defective depress relay (K2).

Replace defective relay.

STEP 2. Check for shorted wiring, loose connections, or defective elevation motor.

Repair or replace wiring, tighten connections or replace motor.

# Table 9-18. Troubleshooting – Armament Electrical System A (Cont)

#### CONDITION

TEST OR INSPECTION

#### CORRECTIVE ACTION

- 20. Gun elevation motor responds with ELEVATE/DEPRESS switches in DOWN only.
  - STEP 1. Check for defective elevate relay (K3).

#### Replace relay.

STEP 2. Check for defective wiring, loose connections, or defective motor.

# Repair or replace wiring, tightan connections, or replace motor.

- 21. Gun elevation responds to pilot switch only.
  - STEP 1. Check copilot switch and wiring.

# Replace defective switch and repair or replace wiring.

- 22. Gun elevation responds to copilot switch only.
  - STEP 1. Check pilot switch and wiring.

#### Replace defactive switch and repair or replace wiring.

- 23. Gun sight light does not illuminate with MASTER switch in FIRE TO CLEAR or for any position of filament selector switch.
  - STEP 1. Check for defective INTENSITY CONTROL.

# Replace INTENSITY CONTROL.

STEP 2. Check for defective FILAMENT SELECTOR switch.

### Replace FILAMENT SELECTOR switch.

STEP 3. Check lamp filaments and wiring.

# Replace lamp and repair or replace wiring.

- 24. Sight will not attain maximum intensity.
  - STEP 1. Check for defective INTENSITY CONTROL.

#### Replace INTENSITY CONTROL.

# Table 9-18. Troubleshooting - Armament Electrical System A (Cont)

#### CONDITION

TEST OR INSPECTION

# **CORRECTIVE ACTION**

STEP 2. Check for shorted wiring or loose connections.

Repair or replace wiring. Tighten connections.

25. Gun sight illuminates with FILAMENT SELECTOR in one position only.

STEP 1. Check for open filament in lamp.

Replace defective lamp.

# **WARNING**

Troubleshooting of 26 and 27 requires use of live ammunition. Observe all safety precautions required by Army regulations prior to performing these steps.

26. Gun ejects live ammunition.

STEP 1. Check for defective gun feed solenoid.

Replace solenoid.

STEP 2. Check for defective control box.

Replace control box.

STEP 3. Check for defective trigger.

Replace applicable trigger.

STEP 4. Check all wiring for shorts, condition, or loose connections.

Repair or replace defective wiring.

- 27. GUN NOT CLEARED light remains illuminated after firing to clear.
  - STEP 1. Check that less than seven live rounds ejected.

Refer to TM 55-1520-228-10 for unloading and clearing procedures; then press reset button on control box to extinguish GUN NOT CLEARED light.

# Table 9-18. Troubleshooting – Armament Electrical System (Cont)

#### CONDITION

TEST OR INSPECTION

#### **CORRECTIVE ACTION**

STEP 2. Check for defective gun clear sensor.

Replace defective sensor.

STEP 3. Check for shorted wiring.

Repair or replace wiring.

**9-383. Installation – Armament Electrical System.** Install armament electrical system components in accordance with paragraph 9-367.

# 9-383.1. ARMAMENT ELECTRICAL SYSTEM - AIRFRAME. CS

- **9-383.2. Description Armament Electrical System.** The armament electrical system consists of the following components:
- **a.** ATAS control panel disconnect located in center console.
- **b.** Pilot display unit (PDU) disconnect located aft of pilot windshield frame.
- **c.** Jettison fuselage disconnect and fuselage disconnect located below avionics compartment door.
- **d.** Four circuit breakers located on overhead circuit breaker panel.
- 9-383.3. Inspection Armament Electrical System. Inspect armament electrical system components in accordance with paragraph 9-364.

- **9-383.4.** Operational Check and Testing Armament Electrical System. Testing armament electrical system consists of performing operational checks of ATAS missile system electrical components.
  - a. Perform following operational check:
- (1) Ensure external electrical power off and battery disconnected.
  - (2) Ensure helicopter grounded.
- (3) Ensure ejector rack safety pins installed and impulse cartridges removed.
- **(4)** Install a captive flight trainer (CFT) on the inboard side of the launcher assembly (refer to TM 9-1440-431 -23).
- **(5)** Check status of gas pressure on coolant bottle pressure gage (3500 TO 6000 psi). If less than 3500 psi, coolant bottle must be recharged.
- (6) Set ATAS control panel (figure 9-23) as follows:
  - (a) ATAS MASTER switch OFF




Figure 9-23. ATAS Electrical Controls and Circuit Breakers CS

- (b) UNCAGE switch AUTO
- (c) JTSN switch OFF (cover down)
- (d) MSL AUDIO volume control As desired.
- (7) Verify the following circuit breakers are closed (figure 9-23):
  - (a) ATAS CONT
  - (b) ATAS PWR
  - (c) MSS
  - (d) JETTISON
  - (8) GEN switch OFF.
- (9) Verify battery connected or GPU connected and on.
  - (10) BATT switch ON (OFF if GPU used).
  - (11) Disconnect plug 21P2.
- (12) Check that voltage is not present at 21J2 (2, figure 9-24) between pins A and B and between pins B and C.
- (13) Lift guard on ATAS control panel (figure 9-23) and set JTSN switch (4) to activate position.
- (14) Check for 28Vdc at 21J2 (2, figure 9-24), pins A and B.
- (15) Set JTSN switch (4, figure 9-23) to off and close cover.
  - (16) Connect plug 21P2.
- (17) Adjust PDU (1, figure 9-25) for desired height using height adjustment lock release levers (2) located on each side of PDU.
- (18) Set ATAS MASTER switch (9, figure 9-23) to STBY. Verify that target acquisition reticle and missile symbology is displayed on PDU within 20 seconds.

#### **NOTE**

## Symbology visuability is affected by the brightness level.

(19) Rotate BRT knob (3, figure 9-25) throughout its range and verify corresponding change in brightness.

(20) Adjust brightness to desired level.

#### NOTE

## BIT is not operational with ATAS MASTER switch in ARM position.

- (21) Press TEST button (4) to perform built-in test (BIT).
- **(22)** Verify TEST message (figure 9-26) appears for 5 seconds.
- **(23)** Verify PASS message appears for 5 seconds, if no problems are detected.

#### NOTE


If FAIL appears, failed component(s) will also display (figure 9-26). Refer to troubleshooting procedures. The FAIL message and failed component(s) will appear for 5 seconds, then revert back to acquisition reticle: PDU = Pilot Display Unit; EU = Electronic Unit; IEU = Interface Electronic Assembly; LL = Left Launcher.

- (24) Restart operational check after fault is corrected.
- (25) Verify acquisition reticle reappears after 5 seconds, if BIT passes and PASS message disappears.

#### NOTE

Interface electronic assembly (IEA) is allowed a maximum of 10 seconds to respond during BIT. Therefore, acquisition reticle can require up to 15 seconds to reappear.


- (26) Position ATAS MASTER switch (9, figure 9-23) to ARM.
- (27) Verify ARM message is displayed (figure 9-27).
  - (28) Verify acquisition reticle is displayed.
  - (29) Verify missile symbology is displayed.



Fuselage Disconnect 21J1
 Jettison Fuselage Disconnect 21J2

206704-75

Figure 9-24. Fuselage Disconnect



- Pilot Display Unit
   Height Adjustment Lock Release Lever
   BRT Knob
   BIT TEST Button

206704-74

Figure 9-25. Pilot Display Unit CS





Figure 9-26. PDU TEST, PASS, and FAIL Messages CS



206704-66A

Figure 9-27. Acquisition Reticle and Messages CS

#### **WARNING**

Maintain a minimum distance of 15 feet forward of CFT during maintenance. Malfunction of pressure vent valve may cause excessive pressure in front glass and propel fragments forward. Glass fragments could cause injury to personnel. Refer to FM21 -11 for treatment of cuts.

(30) Press MSL ACT switch (3, figure 9-23).

#### **NOTE**

Once MSL ACT switch is pressed, the coolant is active and only available for 30 minutes with a fully charged coolant bottle. To deactivate, press MSL ACT switch again.

- **(31)** Verify missile gyro spins up within 3 seconds by audio tone presence in ICS.
  - (32) Verify missile is activated (figure 9-28).
- (33) Position IR flashlight 15 feet in front of captive flight trainer.
- (34) Press TRIGGER UNCAGE/FIRE switch (2, figure 9-23) to first detent and hold to uncage captive flight trainer.
- (a) Verify tracking reticle appears on PDU (figure 9-28).
- **(b)** Verify Super Elevation lines appear on PDU.
- (35) Slowly move IR flashlight up and down and back and forth within the capture cone of captive flight trainer line of sight. Verify movement of tracking reticle coincident with movement of flashlight.
- (36) Verify audio tone changes to a clear, high pitch, steady tone indicating IR flashlight is strong enough for guidance and lock-on has occurred.

#### NOTE

If LOW appears on the PDU, the coolant gas bottle must be recharged (TM 9-1440-431-23).


- (37) Move IR flashlight outside captive flight trainer field of view and check for the following:
  - (a) Break lock occurs.

- **(b)** One-half tracking reticle is displayed at edge of PDU and is flashing (figure 9-29).
- (c) The display will remain until reset by releasing TRIGGER UNCAGE/FIRE switch.
- (d) Audio changes from high pitch (lockon) to low variable tone.
- (38) Release TRIGGER UNCAGE/FIRE switch (2, figure 9-23).
- (a) Momentary crossed tracking reticle appears after releasing TRIGGER UNCAGE/FIRE switch (2) which signifies captive flight trainer seeker recaging (figure 9-29).
- **(b)** Acquisition reticle appears centered in PDU.


#### **NOTE**

Once break lock occurs, the target must be reacquired.

- (39) Position IR flashlight in front of captive flight trainer within PDU field of view.
- (40) Press TRIGGER UNCAGE/FIRE switch (2, figure 9-23) to first detent.
- (a) Verity Tracking Reticle appears in PDU.
- **(b)** Verify Super Elevation lines appear in PDU.
- (41) Move IR flashlight outside PDU field of view while remaining in captive flight trainer seeker field of view.
  - (a) Audio tone will signify lock-on.
- **(b)** Verify Super Elevation lines displayed on PDU.
- (c) Check for 1/2 tracking reticle at edge of PDU field of view (not flashing) (figure 9-29).
- (d) Move IR flashlight back into PDU field of view.
- **(e)** Full tracking reticle present and tracking.
- (42) Press TRIGGER UNCAGE/FIRE switch (2, figure 9-23) to second detent and hold. Verify missile activated symbol (figure 9-30) disappears from PDU.



Circumferential dashes represent the PDU field of view.



206704-67A G0848

Figure 9-28. Tracking Reticle and Capture Cone CS





Figure 9-29. Tracking Reticle and Crossed Tracking Reticle CS



206704-69A

Figure 9-30. Missile Selection Symbols CS

- (43) Release TRIGGER UNCAGE/FIRE switch (2, figure 9-23).
- **(44)** Press CFT RST button (7). Verify inboard missile is reselected.
  - (45) Set ATAS MASTER switch (9) to OFF.
- (46) Transfer CFT from inboard to outboard position on launcher assembly (refer to TM 9-1440-431-23).
  - (47) Set ATAS MASTER switch (9) to ARM.
  - (46) Position UNCAGE switch (6) to MAN.
- (49) Press MSL ACT switch (3) and verify presence of audio background noise in ICS.
- **(50)** Verify missile gyro spins up within 3 seconds.
  - (51) Verify missile is activated (figure 9-30).
- (52) Press TRIGGER UNCAGE/FIRE switch (2, figure 9-23) to first detent. Verify tracking reticle appears on PDU (figure 9-28).

#### NOTE

## Tracking reticle should float if there is not an IR source in the vicinity.

- (53) Move IR flashlight across the front of captive flight trainer left to right, approximately 10°, and return to center.
- **(54)** Slowly move IR flashlight into capture cone of captive flight trainer line of sight. Verify movement of tracking reticle coincident with movement of flashlight.
- (55) Verify audio tone changes to a clear, high pitch, steady tone indicating IR flashlight is strong enough for guidance and lock-on has occurred.
  - (56) Verify Super Elevation Lines appear in PDU.

#### NOTE

# If LOW appears on the PDU, the coolant gas bottle must be recharged (TM 9-1440-431-23).

- **(57)** Move IR flashlight outside captive flight trainer field of view and check for the following:
  - (a) Break lock occurs.
- **(b)** One-half tracking reticle is displayed at edge of PDU and is flashing (figure 9-29).
- **(c)** The display will remain until reset by releasing TRIGGER UNCAGE/FIRE switch (2, figure 9-23).
- **(d)** Audio changes from high pitch (lock-on) to low variable tone.
  - (e) Verify Super Elevation lines disappear.
- (58) Release TRIGGER UNCAGE/FIRE switch (2, figure 9-23).
- (a) Momentary crossed tracking reticle appears after releasing TRIGGER UNCAGE/FIRE switch (2) which signifies captive flight trainer seeker recaging (figure 9-29).
- **(b)** Acquisition reticle appears centered in PDU.
- **(59)** Move IR flashlight outside captive flight trainer field of view.
- **(60)** Press TRIGGER UNCAGE/FIRE switch (2, figure 9-23) to first detent.

#### NOTE

## Tracking reticle should float if there is not an IR source in the vicinity.

- **(61)** Press TRIGGER UNCAGE/FIRE switch (2) to second detent and hold. Verify missile activated symbol (figure 9-30) disappears from PDU.
- (62) Release TRIGGER UNCAGE/FIRE switch (2, figure 9-23).

- **(63)** Place ATAS MASTER switch (9) to OFF, then back to STBY/ARM. Verify outboard missile is reselected.
- **b.** Turn off/safe ATAS missile system as follows:
  - (1) Switches
    - (a) ATAS MASTER Switch (9) OFF
    - (b) Uncage Switch AUTO
    - (c) BATT Switch OFF
- **(d)** JTSN Switch Cover down and safetied (4, figure 9-23)
  - (2) ATAS Circuit Breakers Open
    - (a) ATAS PWR
    - (b) ATAS CONT

- (c) MSS
- (d) JETTISON
- (3) Disconnect Battery or GPU.
- **c.** Remove captive flight trainer (refer to TM 9-1440-431-23).

9-383.5. Troubleshooting – Armament Electrical System. S Refer to table 9-18.1.

#### **NOTE**

Perform operational check before using table 9-18.1. If a malfunction not listed in this table occurs, refer to next higher level of maintenance.

Table 9-18.1. Troubleshooting – Armament Electrical System CS

#### CONDITION

TEST OR INSPECTION

#### **CORRECTIVE ACTION**

Target acquisition reticle and missile status symbology does not display within 20 seconds.

STEP 1. Check for defective or open circuit breaker.

Replace faulty circuit breaker.

STEP 2. Check for defective wiring.

Repair defective wiring.

STEP 3. Check for defective relay 21K1.

Replace defective relay.

STEP 4. Check for defective PDU.

Replace defective PDU.

### Table 9-18.1. Troubleshooting – Armament Electrical System CS (Cont)

#### CONDITION

TEST OR INSPECTION

CORRECTIVE ACTION

STEP 5. Check for defective EU.

Replace defective EU.

STEP 6. Check for defective ATAS control panel.

Replace defective ATAS control panel.

2. Display does not change when PDU BIT TEST button is pressed.

STEP 1. Check for defective wiring.

Repair defective wiring.

STEP 2. Check for defective EU.

Replace defective EU.

STEP 3. Check for defective PDU.

Replace defective PDU.

3. Acquisition reticle is displayed, but brightness control will not adjust reticle brightness.

Check for defective PDU.

Replace defective PDU.

4. ARM message not displayed with ATAS MASTER switch set to ARM.

STEP 1. Check for defective wiring.

Repair defective wiring.

STEP 2. Check for defective ATAS control panel.

Replace defective ATAS control panel.

STEP 3. Check for defective EU.

Replace defective EU.

#### Table 9-18.1. Troubleshooting - Armament Electrical Syste CS (Cont)

#### CONDITION

TEST OR INSPECTION

#### **CORRECTIVE ACTION**

STEP 4. Check for defective IEA.

#### Replace defective IEA.

5. Gyro spinup tone not activated and/or missile not shown selected on PDU with UNCAGE switch set to AUTO and MSL ACT switch pressed.

STEP 1. Check for defective wiring.

#### Repair defective wiring.

STEP 2. Check for defective IEA.

#### Replace defective IEA.

STEP 3. Check for defective ATAS control panel.

#### Replace defectiva ATAS control panel.

STEP 4. Check for defective switch/grip.

#### Replace defective switch/grip.

- **6.** Tracking reticle does not replace acquisition reticle with TRIGGER UNCAGE/FIRE switch pressed to first detent.
  - STEP 1. Check for defective wiring.

#### Repair defective wiring.

STEP 2. Check for defective IEA.

#### Replace defective IEA.

STEP 3. Check for defective ATAS control panel.

#### Replace defective ATAS control panel.

### Table 9-18.1. Troubleshooting – Armament Electrical System (Cont)

#### CONDITION

**TEST OR INSPECTION** 

**CORRECTIVE ACTION** 

STEP 4. Check for defective switch/grip.

#### Replace defective switch/grip.

77. Audio tone does not change to high pitched steady tone indicating IR source lock-on.

STEP 1. Check for defective wiring.

#### Repair defective wiring.

STEP 2. Check for defective transformer (21T1).

Replace defective transformer.

STEP 3. Check for defective ATAS control panel.

Replace defective ATAS control panel.

STEP 4. Check for defective IEA.

#### Replace defective IEA.

8. Seeker uncages, but does not track target correctly or at all.

STEP 1. High FAT.

#### Perform check during cooler temperatures.

STEP 2. Check for alternate heat source.

Remove alternate heat source.

STEP 3. Check for defective wiring.

#### Repair defective wiring.

STEP 4. Check weapon system boresight.

Boresight weapon system as required.

### Table 9-18.1. Troubleshooting – Armament Electrical System CS (Cont)

#### CONDITION

**TEST OR INSPECTION** 

### **CORRECTIVE ACTION**

STEP 5. Check for defective missile.

Replace defective missile.

STEP 6. Check for defective IEA.

Replace defective IEA.

STEP 7. Check for defective EU.

#### Replace defective EU.

- 9. Missile symbol does not disappear to verify firing of selected missile when TRIGGER UNCAGE/FIRE switch is pressed to second detent.
  - STEP 1. Check for defective wiring.

#### Repair defective wiring.

STEP 2. Check for defective switch/grip.

#### Replace defective switch/grip.

STEP 3. Check for defective IEA.

#### Replace defective IEA.

- 10. Remaining missile not selected after TRIGGER UNCAGE/FIRE switch is released.
  - STEP 1. Check for defective missile.

#### Replace defective missile.

STEP 2. Check for defective launcher.

#### Replace defective launcher.

STEP 3. Check for defective IEA.

#### Replace defective IEA.

### Table 9-18.1. Troubleshooting – Armament Electrical System (Cont)

#### CONDITION

TEST OR INSPECTION

#### **CORRECTIVE ACTION**

11. Acquisition reticle not displayed after TRIGGER UNCAGE/FIRE switch is released.

Check for defective switch/grip.

Replace defective switch/grip.

12. System does not recycle after CFT RST button is pressed and released.

Check for defective ATAS control panel.

Replace defective ATAS control panel.

13. The next available missile is not selected (activated) when a missile is activated and SEQ STEP switch is pressed and released.

#### **NOTE**

Two missiles must be present for this function to operate. A previously deselected missile will not reselect.

STEP 1. Check for defective wiring.

Repair defective wiring.

STEP 2. Check for a defective ATAS control panel.

Replace defective ATAS control panel.

STEP 3. Check for defective IEA.

Replace defective IEA.

### 9-383.6. ATAS CONTROL PANEL. CS

**9-383.7. Description - ATAS Control panel.** The control panel provides the pilot with a means of applying power to missile system, activating system, and jettisoning ATAS launcher assembly.

9-383.8. Removal - Control Panel.

#### WARNING

To prevent injury, ensure weapon system is unloaded and all armament circuit breakers are out before starting any maintenance procedures.

- a. Disconnect battery.
- **b.** Loosen fasteners (1, figure 9-31)
- **c.** Remove control panel (2) from console and disconnect electrical connectors (3).

#### 9-383.8.1. Disassembly - Control Panel.

#### NOTE

Remove and disassemble ATAS control panel only to the extent required to accomplish or facilitate maintenance.

Secure all attaching hardware for use during assembly.

- a. Remove switch guard (9, figure 9-31.1).
- **b.** Remove screws (7) securing integrally lit panel (8) to plate assembly (6).
- **c.** Remove screws (1), washers (2), and mounting flanges (3) securing electrical connector jacks (4) to connector plate (5).
- **d.** Remove wires (15) from integrated terminal switch (16).

**e.** Remove hex nut (20) securing switch guard (19) and integrated terminal switch (16) to plate assembly (6).

#### **NOTE**

## To prevent switch to plate assembly misalignment do not move hex nut (17).

- **f.** Remove integrated terminal switch (16) and locking ring (18) from plate assembly (6).
- **g.** Remove locknut (21), lockwasher (22), and washer (23) securing terminal lug (24), terminal lug (25), and washer (26) to screw (30).
- **h.** Remove nut (27), lockwasher (28), and washer (29) securing screw (30) to plate assembly (6).
- i. Remove screw (32) and lockwasher (33) securing terminal lug (31) to screw terminal (38).
- **j.** Remove hex nut (37) securing screw terminal switch (34) to plate assembly (6).

#### **NOTE**

## To prevent switch to plate assembly misalignment do not move hex nut (35).

- **k.** Remove screw terminal switch (34) and locking ring (36) from plate assembly (6).
  - I. Remove and discard heat-shrink tubing (40).
  - m. Remove wire (39) from solder terminal (45).
- **n.** Remove hex nut (44) securing solder terminal switch (41) to plate assembly (6).

#### NOTE

### To prevent switch to plate assembly misalignment do not move hex nut (42).

- **o.** Remove solder terminal switch (41) and locking ring (43) from plate assembly (6).
- **p.** Remove screws (10) securing plate assembly (6) to standoffs (11).
- **q.** Remove screws. (14), washers (13), and lockwashers (12) securing standoffs (11) to connector plate (5).

#### 9-383.9. Cleaning - Control Panel.

#### WARNING

Drycleaning solvent is combustible; do not use near open flames, near welding areas, or on hot surfaces. Prolonged contact of skin with liquid can cause skin irritation. Repeated inhalation of vapor can irritate nose and throat and can cause dizziness. If any liquid contacts skin or eyes, immediately flush affected area thoroughly with water. Remove solvent-saturated clothing. If vapors cause dizziness, go to fresh air. In all cases get immediate medical attention. When handling liquid or when applying it in an air-exhausted, partially covered tank, wear approved gloves. When handling liquid or when applying it at unexhausted, uncovered tank or workbench, wear approved respirator and goggles.

- **a.** Remove grease, fungus, and dirt with a clean, low-lint cloth (C45.1) dampened with drycleaning solvent (C62).
- **b.** Remove moisture, dust, and loose dirt with a wiping rag (C119.1).
- **c.** Remove dirt from electrical connectors with electrical contact brush.

#### 9-383.10. Inspection - Control Panel.

- **a.** Inspect control panel for loose and missing hardware.
- **b.** Inspect control panel for dents and cracks. No cracks allowed.
- **c.** Inspect control panel for scratches and bare metal.
- **d.** Inspect electrical connectors for loose, bent, broken, and recessed pins.
  - e. Inspect electrical connectors for cracked insert.
- **f.** Inspect switches for proper operation and security.

#### 9-383.11. Repair - Control Panel.

- a. Tighten loose and replace missing hardware.
- **b.** Replace control panel if cracked or if dents impair serviceability.
  - c. Repair any scratches using sandpaper (C126).
- **d.** Touch up bare metal. (Refer to TM 55-1500-345-23).
  - e. Tighten or replace missing mounting hardware.
  - f. Straighten bent electrical connector pin(s).
- **g.** Replace control panel if any electrical connector pin is broken or insert is cracked.

#### 9-383.11.1. Assembly - Control panel.

#### NOTE

### Use attaching hardware removed during disassembly.


- **a.** Perform class R1 electrical bond between standoff (11, figure 9-31.1) and connector plate (5). (Refer to TM 55-1520-248-23, Appendix M.)
- **b.** Install screws (14), washers (13), and lockwashers (12) securing standoffs (11) to connector plate (5).
- **c.** Perform class RI electrical bond between standoff (11) and plate assembly (6). (Refer to TM 55-1520-248-23, Appendix M.)
- **d.** Install screws (10) securing plate assembly (6) to standoffs (11).

#### NOTE

To prevent switch to plate assembly misalignment do not move hex nut (42).

When installing new switch, align hex nuts (42) of old and new switch.

- **e.** Install solder terminal switch (41) and locking ring (43) on plate assembly (6).
- **f.** Install hex nut (44) securing solder terminal switch (41) to plate assembly (6).



206704-59A

Figure 9-31. ATAS Control Panel CS




Figure 9-31.1. Disassembly – ATAS Control Panel (Sheet 1 of 2) CS




Figure 9-31.1. Disassembly – ATAS Control panel (Sheet 2)

- g. Install new heat-shrink tubing (40) on wire (39).
- h. Solder wire (39) on solder terminal (45).
- i. Shrink heat-shrink tubing (40) to create an environmental seal around solder joint and wire (39).

#### **NOTE**

To prevent switch to plate assembly misalignment do not move hex nut (35).

When installing new switch, align hex nuts (35) of old and new switch.

- **j.** Install screw terminal switch (34) and locking ring (36) on plate assembly (6).
- **k.** Install hex nut (37) securing screw terminal switch (34) on plate assembly (6).
- I. Install screw (32) and lockwasher (33) securing terminal lug (31) to screw terminal (38).
- **m.** Install nut (27), lockwasher (28), and washer (29) securing screw (30) to plate assembly (6).
- **n.** Install locknut (21), lockwasher (22) and washer (23) securing washer (26), terminal lug (25), and terminal lug (24) to screw (30).

#### NOTE

To prevent switch to plate assembly misalignment do not move hex nut (17).

When installing new switch, align hex nuts (17) of old and new switch.

- **o.** Install integrated terminal switch (16) and locking ring (18) on plate assembly (6).
- **p.** Install switch guard (19) on integrated terminal switch (16).
- **q.** Install hex nut (20) securing integrated terminal switch (16) and switch guard (19) on plate assembly (6).
- **r.** Install wire (15) in integrated terminal switch (16).
- **s.** Install screws (1), washers (2), and mounting flanges (3) securing electrical connector jacks (4) to connector plate (5).
- **t.** Install screws (7) securing integrally lit panel (8) to plate assembly (6).
  - u. Install switch guard (9).

9-383.12. Installation - Control Panel.

#### WARNING

To prevent injury, ensure weapon system is unloaded and all armament circuit breakers are out before starting any maintenance procedures.

- a. Disconnect battery.
- **b.** Connect electrical connectors (3, figure 9-31).
- **c.** Position and secure control panel (2) in console with fasteners (1).

9-383.13. ELECTRONICS UNIT. CS



#### 9-383.14. Description - Electronics Unit.

Electronics unit (EU), located in avionics compartment, interfaces with pilot display unit, control panel, and interface electronics assembly. The EU also provides symbol and reticle generation, CRT control circuitry, fault monitoring, and operates and monitors built-in test.

9-383.15. Removal - Electronics Unit.

#### WARNING

To prevent injury, ensure weapon system is unloaded and all armament circuit breakers are out before starting any maintenance procedures.

- a. Disconnect battery.
- h. Remove avionics compartment door {paragraph 2-76.1).

#### **CAUTION**

The EU is sensitive to electrostatic discharge (ESD). Use ESD precautionary procedures when removing EU. Refer to DOD-HDBK-263 and MIL-STD-1686.

- c. Disconnect electrical connectors (1, figure | 9-32).
  - d. Loosen nuts (2) and slide EU (3) off studs (4).

9-383.16. Installation - Electronics Unit.

#### WARNING

To prevent injury, ensure weapon system is unloaded and all armament circuit breakers are out before starting any maintenance procedures.


#### **CAUTION**

The EU is sensitive to electrostatic discharge (ESD). Use ESD precautionary procedures when removing EU. Refer to DOD-HDBK-263 and MIL-STD-1686.

- **a.** Disconnect battery.
- **b.** Position EU (3, figure 9-32) over studs (4) and secure EU by tightening nuts (2).
  - c. Connect electrical connectors (1).
- d. Install avionics compartment door (paragraph 2-78.1).
  - e. Connect battery.

### 9-383.17. INTERFACE ELECTRONICS ASSEMBLY. CS

9-383.18. Description - Interface Electronics Assembly. Interface electronics assembly (IEA). located in the avionics compartment, contains the circuitry to interface between electronics unit (EU) and missile launcher.



206704-58A

Figure 9-32. Electronics Unit (EU) CS

## 9-383.19. Removal - Interface Electronics Assembly.

#### WARNING

To prevent injury, ensure weapon system is unloaded and all armament circuit breakers are out before starting any maintenance procedures.

- **a.** Remove avionics compartment door (paragraph 2-76.1).
- **b.** Remove interface electronics assembly (TM 9-1440-431 -23).

## 9-383.20. Installation – Interface Electronics Assembly.

#### **WARNING**

To prevent injury, ensure weapon system is unloaded and all armament circuit breakers are out before starting any maintenance procedures.

- **a.** Install interface electronics assembly (TM 9-1440-431-23).
- **b.** Install avionics compartment door (paragraph 2-78.1).

## 9-383.21. INTERFACE ELECTRONICS ASSEMBLY MOUNT TRAY. CS

**19-383.22. Description - Interface Electronics Assembly Mount Tray.** The interface electronics assembly (IEA) mount tray provides a shock and vibration free means for attaching the IEA to the airframe.

## 19-383.23. Removal - interface Electronics Assembly Mount Tray.

**a.** Remove interface electronics assembly (IEA) (paragraph 9-383. 19).

#### NOTE

## Ensure bonding straps are not damaged while handling IEA mount tray.


**b.** Remove IEA mount tray (1, figure 9-33) by removing screws (2) and washers (3).

## 9-383.24. Inspection - Interface Electronics Assembly Mount-Tray.

- **a.** Inspect interface electronics assembly (IEA) mount tray for loose and missing mounting hardware.
- **b.** Inspect IEA mount tray for dents, cracks, scratches, and bare metal. No cracks allowed.
  - c. Inspect shock absorbers for deterioration.
  - d. Inspect bonding straps for damage.

## 9-383.25. Repair - Interface Electronics Assembly Mount Tray.

- **a.** Tighten loose and replace missing mounting hardware.
- **b.** Replace interface electronics assembly (IEA) mount tray if cracked.
  - c. Repair scratches using sandpaper (C126).
  - d. Touch up bare metal (TM 55-1500-345-23).
  - e. Replace deteriorated shock absorbers.
- **f.** Replace IEA mount tray if any bonding straps are damaged.



- IEA Mount Tray
   Screw
- Washer
- 4. Bonding Strap 206704-61A

Figure 9-33. IEA Mount Tray CS

## 9-383.26. Installation - Interface Electronics Assembly Mount Tray.

#### **NOTE**

It may be necesary to enlarge hole in boding strap before attaching bonding strap between IEA mount tray and avionics compartment shelf.

- **a.** Properly position bonding strap (4, figure 9-33) between interface electronics assembly (IEA) mount tray and avionics compartment shelf.
- **b.** Position and secure IEA mount tray (1) using screws (2) and washers (3).
  - c. Install IEA (paragraph 9-383.20).

## 9-383.27. FUSELAGE DISCONNECTS.

#### 9-383.28. Description - Fuselage Disconnects.

The fuselage disconnects (1 and 2, figure 9-24) provide electrical connection for the ejector rack and ATAS missile launcher. The disconnects are located below the avionics compartment door. Refer to paragraph 9-362 for fuselage disconnect maintenance procedures.

#### 9-384. PITOT TUBE HEATER.

Refer to paragraph 9-354.

## 9-385. NIGHT VISION GOGGLES SYSTEM.

Prior to compliance with MWO 55-1520-228-50-32.

9-386. Description - Night Vii Goggles (NVG) System. The night vision goggles (NVG)

system consists of the night vision goggles and associated electrical lighting control and dimming circuitry. The night vision goggles system allows the pilot, when wearing the night vision goggles, to see and read all instruments and control panels without impairing his night vision capability. When night vision goggles switch (S90) is in the NVG position and NVG ENBL/OFF switch (S123) is in the NVG ENBL position, the intensity of the instrument and panel lighting is extremely low and the instruments cannot be seen with the naked eye.

## 9-387. Testing - Night Vision Goggles (NVG) System.

- **a.** Close INSTR LTS, CSL LTS, CAUTION PANEL LTS, and NVG/VR circuit breakers. Rotate INST LTS and CSL LTS controls clockwise. Note that these lights become brightly illuminated.
- **b.** Return INSTR LTS and CSL LTS controls counterclockwise to the normal dim position.
- **c.** Momentarily depress the BRIGHT/DIM switch on caution panel to BRIGHT and note that the caution lights become brightly illuminated.
- **d.** Position NVG ENBL/OFF switch, located on the pedestal, to NVG ENBL and the NVG/NORM switch, located on the pilot cyclic stick to NVG. Check that all instrument lights, console lights, and caution, and warning lights become extremely dim (appear to extinguish) to the naked eye.



Do not position NVG switch to NORM while wearing night vision goggles.

**e.** Test for proper function of the cockpit night vision goggle lighting system as follows:



Assure that systems are functional under normal lighting conditions before the NVG test. If caution and warning system lights provide a flashing indication the NVG lighting system cannot be adequately tested for proper function as the flashing indication may fail to

illuminate at other conditions of temperature or system voltage. Install the proper fault annunciator panal P/N 206-075-456-101 or subsequent to provide a steady caution/warning light indication,

- (1) Place the helicopter in a dark environment or block all light to the cockpit by suitable covers.
- (2) Place the NVG ENBL/OFF switch located on the center console to the NVG ENBL position and place the NVG/NORM switch on the cyclic stick to the NVG position.



Do not place cyclic stick NVG switch to NORM position while using night vision goggles.

- (3) Using night vision goggles, check all instrument and console lighting and all caution and warning lights for proper function. Operate all press to test switches and dimming controls. All lighted items must be clearly visible and legible.
- (4) Return all switches to normal position after the check.
- **f.** Remove night vision goggles. Place NVG/NORM to NORM and NVG ENBL/OFF switch to OFF. Note that all instrument lights, console lighting and caution, and warning panel lights return to normal brilliance.

9-388. Troubleshooting - Night Vision (NVG) Goggles System. Refer to figure F-31 and table 9-19.

#### NOTE

Before using table 9-19, ensure all normal operational checks have been performed. If a malfunction exists which is not listed in table 9-19, notify the next higher level of maintenance.

#### Table 9-19. Troubleshooting - Night Vision Goggles (NVG) System

#### CONDITION

**TEST OR INSPECTION** 

#### CORRECTIVE ACTION

- 1. Night vision goggles relay (K18) will not energize when night vision goggles switch is positioned to NVG positon.
  - STEP 1. Check circuit breaker.

Engage breaker if open or replace defective breaker.

STEP 2. Check for 28 Vdc at pin X1 of NVG relay (K18).

If voltage present replace defective NVG relay.

STEP 3. Loose connections or shorted wiring.

Repair or replace defective wiring. Tighten loose connections.

- 2. Caution light relay (K19) will not energize when night vision goggles switch is positioned to NVG position.
  - STEP 1. Check circuit breaker.

Engage breaker if open or replace defective breaker.

STEP 2. Check for 28 Vdc at Pin X1 of caution light relay (K19).

If voltage present replace caution light relay.

STEP 3. Shorted wiring or loose connections.

Repair or replace defective wiring. Tighten loose connections,

- 3. When NVG switch (S90) is positioned to NVG position, instrument and control panel lights do not illuminate (while using night vision goggles).
  - STEP 1. Check circuit breaker.

Engage breaker if open or replace defective breaker.

STEP 2. Check for 28 Vdc at pin A of voltage regulator (VR2)

If voltage is present replace voltage regulator (VR2).

STEP 3. Shorted wiring or loose connections.

Repair or replace defective wiring. Tighten loose connections.

Paragraph, Figure, Table

### **ALPHABETICAL INDEX**

Paragraph,

Figure, Table

Number	Number
Α	A (Cont)
Abbreviation F-3 Accelerometer and Reflective Target	Adjustment (Cent) Swashplate and Support Assembly5-113
Installation F 5-93	Swashplate and Support Assembly
Accelerometer, Attach5-270	(AVIM)
Acceptance/Rejection Criteria	Swashplate Friction
Crosstubes - High Landing Gear 3-65 Crosstubes - Standard Landing Gear 3-26	Tail Rotor Control System
Cyclic Control Stick Assembly	Voltage Regulator,
High Landing Gear	Vulnerability Reduction Flight Control
Main Rotor Blade	System -Tail Rotor Control C
Pitch Link Assembly	Adjustment and Alignment - Tail Rotor
Power Controls 4-101	Driveshaft 6-127,6-180
Shielded Ignition Lead Assembly13-79	Adjustment/Replacement - Thermocouple
Skid Tubes - High Landing Gear3-48	Resistor 8-130
Skid Tubes - Standard Landing Gear 3-14	Adjustment (Rigging)
Tail Rotor Blades (After Compliance with	Collective Pitch Control System
MWO 55-1520-228-50-25)	Vulnerability Reduction Flight Control
Access Areas - Forward Fuselage C F 11-20	System -Tail Rotor Control C
Access Doors and panels F 2-2, 2-71	Aft Crosstube Support Assembly F 3-12
Access Panels and Doors CS F 2-2.1 Access Panels, Doors, and Ballast	Aft Disc Assembly
installation A F 2-1	Inspect ion
Accident Engines Preservation -	Installation A
Intermediate Storage E-44	Installation C
Acrylic, Cleaning	Removal A
Actuator, Linear, Governor Control	Removal C
Actuator Travel Limit Microswitch	Repair
Adjustment F 4-10	Aft Fuselage Assembly2-204
Adjustment	Inspection
Actuator Travel Limit Microswitch F 4-10	Repair
Combustion Heater Fuel Pressure Relief	Aft Short Shaft 6-144
Valve	Inspection
Cyclic Control Friction	Installation
Cyclic Control System	Lubrication
Cyclic Stick Balance Spring	Removal
Door Assemblies	Aft Vertical Fin Support - Repair Limits F 2-53
Droop Compensation N2	Air Duct Hose Assembly
Gas Producer N1	Inspection
Jackshaft	Installation
pilot Display Unit Mount	Removal
Assembly CS F16-5, 16-26	Repair
Power Turbine Governor	Airframe
Pressure Regulator Valve	Flyable Storage E-10

Figure, Table Figure, Table Number Number A (Cont) A (Cont) Anti-Collision Lights (Cont) Airframe (Cont) Intermediate Storage . . . . . . . . . . . . . . E-42 Air Mixing Valve ...... 13-5 Application of Coating for Corrosion Application of External Power . . . . . . . . . . . . . . . . 1-46 Inspection . . . . . . . . . . . . . . . . . . 8-169 Armament Electrical System, Airframe A ...9-376 Removal . . . . . . . . . . . . . . . . . . 8-172 Repair ..... 8-173 Troubleshooting ......T 8-8, 8-171 Alignment Main Rotor Assembly . . . . . . . . . . . . . . . . F 5-10 Armament Electrical System -Alignment Assembly installation, Launcher . . . . . . . F 16-20, 16-62 PDU Installation . . . . . . . . . . F 16-21, 16-63 Alignment and Balance Main Rotor Assembly (installed). . . . . . . . . . 5-6 Troubleshooting . . . . . . . . . T 9-18.1,9-383.5 Armament Subsystem M27E1 A . . . . . . . . . 16-2 Alignment and Balance (Static) installation A . . . . . . . . . . . . . . . . . F 16-1.16-5 Alteration of Engine Anti-ice Clevis . . . . . . . . F4-11 Armament System - Wiring Diagram . . . . . F F-16 Alternate Procedure for Tracking Main Cleaning . . . . . . . . . . . . . . . . . 8-177 Inspection ..... 8-178 Assembly Altimeter Scale Error ...... T8-11 Aft Sway Brace and Step Aluminum and Magnesium Alloy Corrosion, Assembly CS . . . . . . . . . . . . . . F16-13. 16-50 ATAS Control Panel CS . . . . F9-31.1,9-383.11.1 Inspection ..... 9-312 

Paragraph

Paragraph

Paragraph,		Paragraph,
Figure, Table		Figure, Table
Number	A (Cont)	Number
A (Cont)	A (Cont)	
A (Cont)	ATAS Boresight and Alignment Procedures (Cont)	
Assembly (Cont)	` ,	
	Missile Launcher Yaw	F 40 04 40 74
Driveshaft Segment (After Compliance with	Adjustment	F 16-24, 16-71
MWO 55-1 520-228-50-25)	PDU Alignment Assembly	E 40.04 40.00
Ejector Rack CS	Installation	
Float Landing Gear	PDU Boresighting Procedures	
Foward Sway Brace CS F 16-13, 16-50	PDU Pitch Adjustment	
Freewheeling Assembly (AVIM) 6-32	PDU Roll Adjustment	
Governor Control Linear Actuator (AVIM) 9-97	PDU Yaw Adjustment	
Grips, Main Rotor (AVIM) 5-22	Preliminary Boresight Procedures .	
Housing Assembly	Target Placement	
Hub Strap/Pin/Fitting and Ring/Static	ATAS Control Panel CS	
Stop (AVIM)	Assembly F 9-3	
Hydraulic Pump	Cleaning,	
Main Driveshaft	Description	
Mast Assembly (AVIM) 6-98	Disassembly F 9-	
(Oil Selector (Bypass) Valve4-91	Inspection	
Pillow Block - Main Rotor (AVIM)5-84	Installation	9-383.12
Pilot Display Unit Mount	Removal	
Assernbly CS F16-4, 16-25	Repair	9-383.11
Pylon Installation CS	ATAS Electrical Controls and	
Skid Shoe - High Landing Gear3-56	Circuit Breakers	
Skid Shoe - Standard Landing Gear3-22	ATAS Missile System CS	
Skid Tubes - Standard Landing Gear 3-16	ATAS Missile System Fitting Assemblies	
Solenoid Valve	and Clevis CS	
Swashplate and Support Assembly	ATAS Fitting Assemblies	F 16-18
(AVIM)	Description	16-54
Switch Box Assembly - Collective Control	Inspection, Cleaning, Repair,	
<b>6</b> 14 1	or Replace	16-56
Switch Tail Rotor Hub (After Compliance with	Installation	16-57
MWO 55-1520-228-50-25)	Removal	16-55
Tail Rotor Hub (Before Incorporation of	Attach Tip Targets	5-72
MWO 55-1520-228-50-25)	Attitude indicator A	8-202
Tail Rotor Hub and Blades (After Compliance	Cleaning	8-204
with MWO 55-1520-228-50-25)5-236	Inspection	8-205
Tail Rotor Pitch Change Mechanism5-213	Installation	8-210
Trunnion - Main Rotor (AVIM)	Removal	
ATAS Boresight and Alignment	Repair or Replacement	8-209
Procedures CS	Testing	
Boresight Completion	Troubleshooting	. T 8-15, 8-207
	Attitude/Turn and Slip Indicator C .	8-211
Gunner Quadrant Settings F 16-23, 16-68	Cleaning	8-213
Launcher Alignment Assembly Installation F 16-20, 16-62	Inspection	8-214
Launcher Boresight Procedures 16-73	Installation	8-219
· · · · · · · · · · · · · · · · · · ·	Removal	
Maximum Strut Dimensions F 16-26 Missile Launcher Pitch	Repair or Replacement	8-218
	Testing	
Adjustment , F 16-24, 16-69 Missile Launcher Roll	Troubleshooting	
	Audio Threshold System - Wiring	
Adjustment F 16-25, 16-70	Diagram	F F-22

Paragraph Figure, Table Number	Paragraph, Figure, Table Number
A (Cont)	B (Cont)
Auxiliary Equipment       F 2-27, 2-142         Auxiliary Fuel Cell       F 10-3, 10-8         Installation       F10-4,10-12         Removal       10-10         Repair      10-11	Ballast Installation (Cont) Installation (Forward Ballast) C2-214 Removal (Aft Ballast)
Auxiliary Power Receptacle (J120)       9-368         Inspection       9-370         Installation       9-375         Removal      9-373         Repair or Replacement      9-374         Testing      9-371         Troubleshooting      9-372	Battery       9-24         Cleaning       9-28         Inspection       9-26         Installation       9-31         Removal       9-29         Repair       9-30         Servicing       1-13
Avionics Compartment Door       2-73         Inspection       2-75         Installation       2-78         Removal       2-76         Repair       2-77         Avionics Compartment Floor       2-237	Short Term Storage
Inspection       2-239         Installation       2-242         Removal       2-240         Repair       2-241         Avionics       Equipment	Battery Relay       9-32         Inspection       9-34         Installation       9-36         Removal       9-35         Troubleshooting       9-37
intermediate Storage	Beam Upper Cabin Roof
В	Bearing Locations and Numbering (Typical)
Balance Chart Incorrect Clock Angle - Main Rotor	Bearings, Freewheeling Assembly6-57 Inspection6-59 Installation6-62 Removal6-60 Repair6-61
Balance Forces - Tail Rotor Control11-103 Balance Rotors	Bearings - Maximum Allowable Play T 11-5 Bellcranks, Levers, and Walking Beams11-112 Inspection
Tail Rotor Hub and Blade Assembly (After Compliance with MWO 55-1520-228-50-25)	Blade Bolt - Main Rotor-Inspection and Repair Limits
55-1520-228-50-25)	Removal      13-22         Repair      13-23         Bleed Air Heater System      9-346         Inspection      9-348         Installation      9-353

Paragraph, Figure, Table Number

Paragraph Figure, Table Number

#### B (Cont)

Bleed Air Installation . . . . . . . . . . . . F 4-3, 4-34 Inspection ...... 4-36

Bleed Air Heater System (Cont)

### C (Cont) Caution and Warning Light System A . . . . . 9-147 Test ing ......9-149 Caution and Warning Light System C . . . . . 9-150 Testing ...... 9-152 Caution and Warning Lights System A -Wiring Diagram . . . . . . . . . . . . . . . . F F-12 Caution and Warning Lights System C -4 0 2 4 6 7 0 8 9

Inspection 4-36	Caution and Warning Lights System C -
Installation 4-39	Wiring Diagram F F-34
Removal	Check Tail Rotor Track
Repair or Replacement	Check Track of Main Rotor
Bleed Air Valve Assembly - Bleed Air	(From Cabin Door)
Heater	Chip Detectors 9-174
Bolt and Blade Latch Retainer 5-55	Cleaning
Inspection	Inspection 9-177
Installation	Installation
Removal	Removal 9-178
Repair	Repair or Replacement
Bolt and Blade Latch Retainer - Main	Chip Detectors - Tail Rotor Gearbox
Rotor - Inspecton and Repair Limits F 5-24	(After Compliance with MWO
Bonded Rod Ends and Bearings	55-1520-228-50-25)6-217
Inspection11-125	Inspection 6-220
Bonding Strap - Crashworthy	Installation
Inspection10-49	Removal
Installation	Chip Detectors - Tail Rotor Gearbox (Prior to
Removal 10-50	MWO 55-1520-228-50-25)
Boost Pump, Crashworthy	Inspection 6-195
Inspection 10-19	Installation 6-196
Installation	Removal 6-194
Removal	Chip Detectors - Transmission6-286
Boresight Completion CS	Inspection 6-289
Brush Run-In Diagram F 9-6	Installation 6-290
Brushes	Removal 6-288
Installation13-107	Cleaning
Removal	Acrylic
Run-In	Airspeed Indicator
Build-up Engine Assembly 4-9	Altimeter 8-177
Build-up Main Rotor Mast F 6-17	Anticollision Lights
Build-Up Power Plant	ATAS Control Panel CS
Bushing Wear Limits CS	ATAS Missile System Fitting Assemblies
	and Clevis CS
	Attitude Indicator
С	Attitude/Turn and Slip Indicator 8-213
	Battery 9-28
Cabin, Door Assemblies	Chip Detectors
Cap Assembly - Tail Rotor Gearbox6-223	Clock
Cargo Platform 2-138	Controllable Landing Light
Installation	Cyclic Stick Grip Assembly
Removal	DC Ammeter 8-270

Paragraph Figure, Table Number Paragraph Figure, Table Number

### C (Cont)

### C (Cont)

	Olegaries (Ogent)
Cleaning (Cont)	Cleaning (Cont)
Description	Pillow Block - Main Rotor Yoke 5-76
Disc Assembly	Pillow Blocks - Main Rotor Yoke (AVIM) 5-81
Drag Pin <u></u>	Pitch Horn, Main Rotor5-27
Ejector Rack CS	Pitot Static Piping and Fittings 8-150
Engine Oil Pressure Indicator 8-14	Pitot Tube
Engine Oil Temperature Indicator 8-100	Plexiglas
Engine Oil Temperature Transmitter	Position Lights
Bulb	Power Plant
Exterior	Power Turbine Tachometer Generator 8-55
Fault Annunciator Panel	Rotor Blades
Fault Annunciator Panel (AVIM)	Rotor Tachometer Generator
Float Landing Gear	Sensors, RPM
Forward and Aft Short Shafts	Servoactuators (Cyclic and Collective) 7-33
Free Air Temperature Indicator	Skid Tubes - Standard Landing Gear 3-11
(Thermometer)	Solenoid Valve
Freewheeling Assembly	Soundproofing Blankets
Fuel Quantity Indicator	
	Standard Landing Gear
Gas Producer Tachometer Generator. 8-64, 8-73 Governor Control Linear Actuator 4-112, 9-95	Starter-Generator
•	Starter System
Grips, Main Rotor (AVIM)	Swashplate and Support Assembly
Helicopter	(AVIM)
High Landing Gear	Sway Braces and Struts~
Housing Assembly	Tachometer Indicator
Hydraulic Filters	Taillight
Hydraulic Pump	Tail Rotor
Hydraulic Pump (After Disassembly)7-16	Tail Rotor Blades (After Compliance with
Idler Link Assembly and Collar Set5-163	MW0 55-1520-228-50-25)
Instantaneous Vertical Speed Indicator 8-186	Tail Rotor Blades (Prior to Compliance with
Instrument Panel and Covers 8-3	MW0 55-1520-228-50 -25)
Interior	Tail Rotor Gearbox (After Compliance with
IR/White (Dual) Landing/Searchlight9-272	MW0 55-1520-228-50-25)
Landing Lights	Tail Rotor Gearbox (Prior to Compliance
Magnetic Compass (Standby)8-222	with MWO 55-1520-228-50-25)6-184
Main Rotor Blades	Tail Rotor Hub (After Compliance with
Main Rotor Blades (Prior to Refinishing)5-101	MW0 55-1520-228-50 -25)
Main Rotor Driveshaft 6-12	Tail Rotor Pitch Change
Main Rotor Hub5-13	Mechanism 5-206, 5-211
Mast Assembly (AVIM)	Torquemeter indicator:
NVG Position Lights	Transmission Oil Pressure Indicator8-284
Oil Cooler	Transmission Oil Pressure Transmission 8-293
Oil Cooling Blower and Shaft Assembly6-137	Turbine Outlet Temperature (TOT)
Oil Nozzle (Jets) 6-284	Indicator
Oil Selector (Bypass Valve) 8-43	Turbine Outlet Temperature (TOT)
Oil Transfer Tube	indicator C8-138
Particle Separator	Turn and Slip Indicator 8-195
Pilot Display Unit Mount	Vulnerability Reduction Flight Control
Assembly	System -Tail Rotor Gearbox
7.000(11b)y	Control C
	Control 2

### Paragraph, Figure, Table Number

Paragraph, Figure, Table Number

### C (Cont)

### C (Cont)

Cleaning and Inspection - Pylon Supports (AVIM)	Combat Damaged Fuel Tanks - Intermediate Storage
Cleaning of Honeycomb Core Cavity	Combustion Chamber Drain Hose
(AVIM)2-176	Installation
Clock	Collective Sleeve - Inspection and Repair
Cleaning	Limits F 5-44
Inspection 8-265	Collective Sticks
Installation	Inspection
Removal 8-266	Installation
Closed Circuit Refueling Receiver F 1-2, 10-30	Removal
Installation	Repair or Replacement
Removal	Collective Support and Friction Clamp F 11-2
Clutch Assembly, Freewheeling Assembly 6-51	Combustion Heater Assembly
Inspection	Installation
Installation	Removal
Removal	Combustion Heater Combustion Air
Repair 6-55	Pressure Switch
Cockpit Lights	Installation
Inspection 9-245	Removal
Installation	Combustion Heater Combustion Blower 13-86
Removal	Installation
Repair 9-247	Removal
Troubleshooting	Repair
Coil and Body Assembly13-74	Combustion Heater Fuel Filter
Inspection	Installation
Test	Removal 13-92
Collar Set - Pylon (Swashplate) -	Combustion Heater Fuel Pump
Inspection and Repair Limits F 5-49	Installation
Collective Controls F 11-1	Removal
Collective Lever and Link Assembly 5-167	Combustion Heater Fuel Pressure
Inspection 5-171	Relief Valve
inspection (installed)	Adjustment
Installation	Installation
Removal	Removal
Repair	Combustion Heater Fuel Shut-off Valve13-101
Collective Lever, Idler Link, and Collar Set	Installation
Installation F 5-36	Removal
Collective Lever - Inspection and Repair	Combustion Heater Ignition Assembly 13-59
Limits F 5-46	Disassembly
Collective Lever Link (Idler) - Inspection	Inspect ion
and Repair Limits F 5-45	Installation
Collective Pitch Control System	Operational Test
Adjustment (Rigging)	Reassembly
Troubleshooting	Removal
Collective Pitch Linkage	Combustion Heater Plenum
Inspect ion11-27	Installation
Installation	Removal
Removal 11-28	

Number Number C (Cont) C (Cont) Combustion Heater Support Bracket . . . . . ....13-51 Wiring Diagram (Prior to Compliance with MW0 55-1520-228-50 -32) . . . . . . . . . . F F-40 Combustion Heater System . . . . . . F 13-4, 13-38 Troubleshooting . . . . . . . . . . . . . . T 13-2, 13-42 Corrosion Removal and Repair-Tail Rotor Combustion Heater - Wiring Diagram . . . . . F F-19 Corrosion Treatment for Inside Surfaces of Input Pinion Gear (AVIM) Inspection ...... 9-304 (Prior to Compliance with MWO Cover Assembly - Bellcrank Stop., F11-4, 11-30 Compensation (Swinging) Magnetic Compass Components Involved in An Accident . . . . . . . E-1 Connect Magnetic Pickup and Accelerometer Cowling and Fairings - Engine and Connect Magnetic Pickup Cable and Crashworthy Fuel System A - Wiring Connecting Link Assembly . . . . . . . . . . . . . . . . . . 12-5 Crashworthy Fuel System C — Wiring Crew and Passenger Seat Belt Installation . F 2-14 Crew Door Latch Assembly . . . . . . . . . . . . F 2-4 Connection for Pitot Leak Check (Typical). . . . . F 8-2 Cross-Section of Particle Separator . . . . . . . . F 4-8 Connector Replacement Chart.....T F-2 Cross Tubes, High Landing Gear . . . . . . . . . . . . . . . 3-62 Consumable Maintenance Supplies and Acceptance/Rejection Criteria . . . . . . . . . . . . . 3-56 Consumable Materials, List of . . . . . . . . . . . 1-27 Control Assemblies (VR-FCSystems) Tail Rotor Control - Removal and Installation C... F 11-19 Cross Tubes, Standard Landing Gear . . . . ...3-23 Control Tube Assemblies (Electrical Mechanical Acceptance/Rejection Criteria . . . . . . . . . . . . . . . . . 3-26 Disconnect) - Removal and Installation ..... F 11-22 Cutter Blades (Upper and Lower) -Cyclic and Collective Servoactuator 

Paragraph

Figure, Table

Paragraph

Figure, Table

Paragraph,

Figure, Table Figure, Table Number Number C (Cont) C (Cont) Cyclic Stick Grip Assembly Internal Wiring Cylinder Cap CS Disassembly . . . . . . . . . . . . . F 16-12, 16-42 D Damage Limits Main Driveshaft ...... F 6-4 Needle Bearing Housing . . . . . . . . . . . . F 5-77 Outer Cap ..... F 5-50 Pitch Link Assembly . . . . . . . . . . . . . F 5-53 Power Control - Torque Tube Assembly . . F 4-17 Tail Rotor Knurled Nut . . . . . . . . . . . . . F 5-57 Tail Rotor Pitch Control Pedal . . . . . . . . F 11-14 Cyclic Controls Mixing Lever . . . . . . . . . F 11-10 Cyclic Stick and Friction Control . . . . . . . . F 11-8 Tail Rotor - Static Stop . . . . . . . . . . F 5-56 Cyclic Stick Assembly ..... F 11-6 Transmission Mount Support Stop. . . . . . . F 2-56 Cyclic Stick Assembly C (After Compliance Trunnion . . . . . . . . . . . . . . . . . F 5-78 with MWO 55-1 520-228-50-32) . . . . . . . . F 11-7 Yoke ..... F 5-88 Cyclic Stick Assembly (Prior to Compliance Damaged, Cannibalized or Failed Engine with MWO 55-1520-228-50-32) . . . . . . . . F 11-7 Preservation Procedure - Intermediate Cyclic Stick Assembly CS . . . . . . . . F 11-7.1 DC Ammeter . . . . . . . . . . . . . . . . . 8-268 Inspect ion ...... 8-271 Troubleshooting . . . . . . . . . . . . . . . . . . T 8-18, 8-272 DC Power and Starter Systems A -Wiring Diagram . . . . . . . . . . . . . . . . . F F-8 DC Power and Starter Systems C -Wiring Diagram . . . . . . . . . . . . . . . F F-28 **Defogging Blower Motors** Disassembly . . . . . . . . . . . . . . . . . F 9-17, 9-135 (B7 and B8) . . . . . . . . . . . . . . . . . F 9-22, 9-338 Reassembly .....9-139 Test ing ...... 9-146 Testing ...... 9-341 Cyclic Stick Grip Assembly Internal Wiring Schematic A ..... F 9-18

Paragraph,

Figure, Table Figure, Table Number Number D (Cont) D (Cont) Jackshaft Support and Friction Mast Assembly (AVIM) . . . . . . . . . . . . . . . . F6-14, 6-94 Depreservation Oil Cooling Blower and Shaft Assembly . . . . 6-140 Oil Selector (Bypass) Valve (AVIM) . . . . . . . . . . . . . . . . . 4-87 After Intermediate Storage . . . . . . . . . . . E-48 Description pillow Block - Main Rotor Yoke (AVIM) . . ...5-80 Pilot Display Unit Mount Assembly CS . . . . . . . . . . . . . . . . . F16-4, 16-22 Short Term Storage ..... E-13 Swashplate and Support Assembly Switch Box Assembly - Collective Control Determining Crosstube Center (Typical) . . . . . F3-1 Direct Current Power Distribution and Tail Rotor Driveshaft Segment (After Incorporation of MWO Disc Assembly ...... 6-119,6-173 55-1520-228-50-25) . . . . . . . . . . . F 6-26, 6-163 Adjustment and Alignment . . . . . . . . . 6-127,6-180 Tail Rotor Hub (After Incorporation of Tail Rotor Hub (Before Incorporation of 6-175 Tail Rotor Hub and Blade Assembly. . . . . . F 5-60 Tail Rotor Hub and Blade Assembly (Before Incorporation of MWO Disassembly 55-1520-228-50-25) . . . . . . . . . . . . . . F 5-186 Aft Sway Brace and Step Tail Rotor Hub and Blades (After Assembly . . . . . . . . . . . . . . . F 16-13, 16-46 Incorporation of MWO ATAS Control Panel CS . . . . . F 9-31.1, 9-383.8.1 Tail Rotor Pitch Change Mechanism . . . ...5-209 Combustion Heater ignition Assembly . . . . . 13-62 Cylinder Cap CS . . . . . . . . . F 16-12, 16-42 Ejector Rack CS . . . . . . . . . . . F 16-11, 16-41 Forward Sway Brace and Struts CS . . . . . . . . . . F16-34, F-14, 16-46 Door Seals Governor Control Linear Actuator 

Paragraph

Paragraph

Paragraph,

Figure, Table Figure, Table Number Number D (Cont) E (Cont) Drag Pin . . . . . . . . . . . . . . . . 6-75 Emergency Equipment . . . . . . . . . . F 17-1. 17-1 Intermediate Storage . . . . . . . . . . . . . . . E-40 **Engine** Intermediate Storage . . . . . . . . . . . . . . . . . E-30 Removal ..... 6-79 Engine and Transmission Cowling A ..... F 2-10 Repair . . . . . . . . . . . . 6-81 Engine and Transmission Cowling C ..... F 2-11 Drain Installation . . . . . . . . . . . . . . . . . 2-223 Drain Valves and Refueling . . . . . . . . . . . . . . . . 1-7 Installation and Rigging . . . . . . . . . . . . . . . . . 4-53 Troubleshooting . . . . . . . . . . . . . . . . . . T 12-1, 12-4 Driveshafts - Tail Rotor (Forward Short Droop Compensator (N2) Adjustment ...... 4-106 Dual Tachometer Indicator Inspection ..... 8-38 Servicing ...... 4-25 Testing ..... 8-39 Inspection ......2-159 Ε Ejector Rack CS Removal/installation ., . . . . . . . . . . . F 16-10 Electrical Cable Assembly - Engine, Installation of ...... F 4-5 Electrical Symbol Chart . . . . . . . . . . . . . . . F F-2 Electrical System ..... 9-1 Intermediate Storage . . . . . . . . . . . . . . E-34 Electronics Unit CS . . . . . . . . . F 9-32, 9-383.13 

Paragraph,

Paragraph, Figure, Table Number

#### E (Cont)

#### E (Cont)

E (Cont)	E (Cont)
Engine Auto Relight System A -	Engine Oil Temperature Indicator
Wiring Diagram F F-20	Cleaning
Engine Auto Relight System C -	Inspection
Wiring Diagram F F-38	Installation
Engine Cleaning Provision F 4-4	Removal 8-103
Engine Cowling 2-44	Repair or Replacement 8-104
Inspection 2-46	Testing 8-102
Installation	Engine Oil Temperature System
Removal	Troubleshooting
Repair	Engine Oil Temperature Transmitter
Engine Cowling (AVIM) - Rework	Bulb
Engine Exhaust Stack F 4-12	Cleaning 8-108
Engine Installation	Functional Test8-112
Engine Installation - T63-A-720 C F 4-2	Inspection 8-109
Engine Mount Fittings	Installation 8-113
Inspection 4-19	Removal
Installation	Repair 8-111
Removal	Troubleshooting
Repair	Engine Out Warning Switch
Engine Mount Leg Attaching Bolts T 2-3	Installation
Engine Mount Leg Wear and Damage	Removal 9-185
Limits F 2-62	Engine Out Warning Switch (S70) 8-88
Engine Mounts	Inspect ion 8-90
Inspection 2-304, 2-306	Installation 8-93
Installation 2-308	Removal 8-91
Removal	Repair or Replacement
Repair	Engine Pan 2-201
Engine Oil and Turbine Outlet Temperature	Damage Classification
Indicating Systems A - Wiring Diagram F F-7	Equip Tail Rotor 5-273
Engine Oil and Turbine Outlet Temperature	Equip the Ship 5-286
Indicating Systems C - Wiring Diagram . F F-30	Equipment List T F-1
Engine Oil Cooler	Equipment Location AF 9-1
Engine Oil Inlet Hose and Elbow F 1-4	Exhaust System 4-54
Engine Oil Pressure and Torquemeter	Inspection 1 4-56
Indicator - System Bleeding	Inspect ion C 4-57
Engine Oil Pressure Indicator	Installation
Cleaning	Removal
Inspection 8-15	Repair 1 - 4-59
Installation	Repair C4-60
Removal	Exterior, Cleaning 1-18
Repair or Replacement	Exterior Lights System 9-250, 9-251,
Testing 8-16	9-252
Troubleshooting	Exterior Lights System A (Use for Rewired
Engine Oil System	Lights) - Wiring Diagram
Engine Oil System Bypass Valve,	Exterior NVG Position Light C - Wiring
Selector Valve Assembly	Diagram F F-36
Engine Oil System, Servicing 1-8	External Power, Application of 1-46

Figure, Table Figure, Table Number Number F (Cont) E (Cont) External Power Receptacle . . . . . . . . . . . . . . . . . . 9-9 Inspection ..... 9-11 External Power Receptacle Access Door . . . . . 2-79 Fitting Assembly - Armament Inspection ..... 9-16 Inspection ...... 2-219 Testing ...... 9-7 Troubleshooting . . . . . . . . . . . . . . . . . . T 9-1, F-8, 9-8 Troubleshooting . . . . . . . . . . . . . . . . . 7-6 Fault Annunciator Panel . . . . . . . . F 9-20, F 9-21, 9-320 Flyable Storage Testing ...... 9-323 Fault Annunciator Panel Schematic C .....FO-3 Filler Cap and Adapter, Crashworthy . . . . ....10-63 Main Rotor Blades . . . . . . . . . E-11 Maintenance of Preservation. . . . . . . . . . E-12 Force Gradient Assembly . . . . . . . . F 11-9, 11-60 Filter ..... 6-248 Force Trim and Hydraulic Control Systems -Forward and Aft Shirttail Rotor 

Paragraph

Paragraph

Paragraph, Figure, Table Number

F (Cont) F (Cont)

Forward Fairing Repai r C F 2-12	Fuel Density/Dielectric Chart F 8-4
Forward and Aft Short Shafts	Fuel Drain Cock Assembly F 10-6
Cleaning	Fuel Filter Pressure Switch 8-276, 9-164
Inspection/Repair	Inspection
Installation	Installation
Removal	Removal
Forward Short Shaft	Fuel Pressure Switch
Inspection	Inspection
Installation	Installation
Lubrication	
Removal	Removal
Repair	Fuel Pump System
Forward Vertical Fin Support—	Inspection
Repair Limits	Installation
Frame Assembly(Seat)	Removal
Inspection	Testing
Installation	Troubleshooting T 9-3, 9-78
Removal	Fuel QuantityGaging System
	Fuel Quantity indicating System A —
Repair	Wiring Diagram
(Thermometer)	Fuel Quantity Indicating System C —
Cleaning	Wiring Diagram
Inspection	Fuel Quantity Indicator
Installation	Cleaning
Removal	Inspection
	Installation
Repairer Replacement	Removal
Testing	Repair
Assembly (AVIM)	Troubleshooting T 8-17, 8-237
	Fuel Quantity Transmitter
Cleaning	Installation
Disassembly(AVIM)	Removal
Inspection 6-24, 6-27	Repair or Replacement
Inspection(Disassembled)	Testing
Installation	Troubleshooting
Limit Chart	Fuel Shutoff Lever
Removal	Fuel Shutoff Valve-Crashworthy
Repair	Inspection
VentAssembly(AVIM)	Installation
Freewheeling Housing	Removal
Fuel Calibration Card	
Fuel Cell, Crashworthy Fuel System F 10-1,10-3	Fuel System
Inspection	Flyable Storage
Installation	Intermediate Storage
Removal	Servicing
Fuel CellSupport(AVIM) F 2-44, 2-196	Short Term Storage
Repair	Fuel System —Crashworthy
Fuel Control Lever	General Maintenance
Inspection	Troubleshooting T 10-1, 10-16

Paragraph, Figure, Table Number

Fuel System, Precaution in Fuel Servicing and Refueling	10-15 9-63 9-65 9-67 9-66 9-68 9-45 9-47
Functional Check (Crashworthy)	9-63 9-65 9-67 9-66 9-68 9-45 9-47
Altimeter	9-67 9-66 9-68 9-45 9-47
Indicators — Pitot-Static System Removal	9-66 9-68 9-45 9-47
Vertical Speed Indicator	9-45 9-47
Tail Rotor Control	
Controllable Landing Light	
(AVIM)	
Fuselage	), 9-91
and Shell Assembly)	2, 9-95
Inspection	4-113
Fuselage Disconnects CS F 9-24, 9-383.27 Inspection(AVIM)	4-115
G Removal	9-96
Gas Producer Control Bellcrank	
Gas ProducerControl Bracket	9-86
Gas ProducerControl Tube	9-90
Gas Producer Control Installation	9-82
Gas Producer (N1), Adjustment	4, 9-85
Gas Producer TachometerGenerator	
Inspection           8-74         Rotor Hub           5-69,           Installation            5-69,	9, 5-71
Removal	5-70
Testing	5-14
Gas ProducerTachometer Indicator	5-19
Inspection	5-18
Removal	5-23 5-16
Testing (NI)	
Gear, Float Landing	3-70
General, Hydraulic System	3-72 , 16-68

Paragraph, Figure, Table Number

Н

## H (Cont)

Harding, Ground F 1-6, 1-35	Honeycomb Panels - Repair (Cent)
Heating and Ventilating System A F 13-1	Passenger Seatback Bulkhead F 2-33
Heating and Ventilating System C F 13-2	Seatback Electrical Shelf F 2-34
Heating and Ventilating System	Upper Cabin Roof F 2-28
Inspection 13-3	Vertical Fin F 2-39
Troubleshooting T 13-1, 13-4	Hoisting 1-42
Heating, Defogging Blower, and Engine	Horizontal Stabilizer
De-Icing Systems - Wiring Diagram F F-10	Inspection
Helicopter, Cleaning	Installation
Covers	Removal
Helicopter Leveling Plates	Repair
High Gear Interchange with Standard	Horizontal Stabilizer and Vertical Fin
Gear F 3-15	Installation F 2-50
High Landing Gear	Hoses and Lines - Freewheeling Unit 6-291
Cleaning	Housing Assembly 6-41
Cross Tubes	Assembly 6-49
Inspection	Cleaning
Installation	Disassembly
Removal	inspection
Repair	Installation
Skid Shoe Assembly	Removal
Skid Tubes 3-44	Repair (AVIM)
	Hub Assembly - Disassembly/Assembly
High Landing Gear Crosstubes - Inspection Limits	
	(After Compliance with MWO
High Landing Gear Skid Tubes -	55-1520-228-50-25 )
Repair Limits F 3-13	Hub Strap/Pin/Fitting and Ring -
High Landing Gear Step, Skid Shoe,	Main Rotor
and Ballast Installation F 3-11	Assembly 5-36
Honeycomb Panel Major Edge Damage	Inspection 5-34
Limitations	Removal
Limits and Repair2-191	Repair 5-35
Repair 2-193	Hydraulic Bypass Solenoid
Honeycomb Panel Minor Edge Damage	Inspection 9-112
Limitations	Installation
Limits and Repair	Removal
Repair 2-190	Hydraulic Check Valve
Honeycomb Panels - Installation of	Inspection 7-75
Inserts F 2-43	Installation 7-78
Honeycomb Panels - Repair	Removal 7-76
Aft Fuel Cell Bulkhead F 2-36	Repair or Replacement
Aft Lower Cabin Shell F 2-30	Hydraulic Control System
Crew Seat and Bulkhead F 2-31	Testing 9-108
Edge Damage F 2-42	Troubleshooting T 9-5, 9-109
Electrical Compartment Floor F 2-37	Hydraulic Filters 7-60
Forward Lower Cabin Shell F 2-29	Cleaning
Lower Aft Fuselage F 2-36	Inspection
Major Damage	Installation
Oil Cooler Support F 2-38	Removal
Passenger Seat Structure F 2-32	Repair or Replacement

Paragraph, Figure Table Number

H (Cont)

,	, ,
Hydraulic Hoses, Lines, and Quick-Disconnects .7-67	Installation
Inspection	Removal
Installation	Repair or Replacement
Removal	Ignition Plug Cap Fixture
Repair or Replacement	Ignition Switch
Hydraulic Pressure Switch	Inspection
Hydraulic Pump	Installation
Assembly	Removal
Cleaning	Ignition System
Cleaning (After Disassembly) (AVIM)7-16	Inspection
Disassembly	Testing
Inspection (installed)	Troubleshooting
Inspection (Removed)	ignition Unit Assemibly F 13-5
Installation	Impulse Cartridges CS
Removal	Description
Repairer Replacement	Inspection
Hydraulic Relief Valve	Installation
Inspection	Removal
Installation	Index
Removal	Inertia Reel
Repair or Replacement	Inspection
Test	Installation
Hydraulic Reservoir	Removal
Inspection	Repair
Installation	Inertia Reel Strap
Removal	Inspection
Repair or Replacement	Installation
Hydraulic Servoactuator	Removal
Hydraulic System	inertia Reel Strap Assembly installation F 2-17 Inflight Track Main Rotor
Functions	Inlet Pump Screen
General	Removal
Intermediate Storage	Clean and inspect
Schematic	Install
Servicing	Inner Ring
Short Term Storage	Inspection
Testing (with HydraulicTest Stand)7-7	Installation
Testing (with Transmission-Driven Pump)7-8	Removal
3 ( )	Repair
	Inner Ring -Inspection and Repair Limits F 5-42
I	Input Pinion Cork Seal (AVIM)-Repair6-89.1
	Input Pinion Gear, Corrosion Treatment for
Ice and Snow-Removal	Inside Surfaces of (Prior to Compliance with
identification of Metal Particles	MW0 55-1520-228-50-25)
Idle Detent Replacement	Input Pinion Housing Adapter and Seals . F 6-12, 6-83
idler Link and Collar Set	Inspection (AVIM) 6-85, 6-87
Cleaning	Installation (AVIM)
Inspection	Removal (AVIM)
Inspection (Disassembled)	Repair

Paragraph Figure, Table Number

#### I (Cont)

I (Cont)	I (Cont)
Input Seal, Tail Rotor Gearbox -	Inspection (Cont)
Replacement	·
Inspection	Clutch Assembly - Freewheeling
Aft Fairing	Assembly
Aft Fuselage Assembly2-206	Cockpit Lights
Aft Short Shaft	Coil and Body Assembly
Air Duet Hose Assembly 6-260	Collective Lever and Link Assembly  Collective Lever and Link Assembly
Air Mixing Valve	(Installed)5-169
Airspeed Indicator	Collective Pitch Linkage
Anticollision Lights	Collective Sticks
Anti-Icing Lever	Combustion Heater Ignition Assembly 13-63
Armament Electrical System	Combustion Heater System
Armament Electrical System - CS9-383.3	Common Electrical Components
-	Connecting Link Assembly 12-7
Armor Panels	Control Tubes
ATAS Control Panel CS9-383.10	Controllable Landing Light
ATAS Missile System Fitting Assemblies	Cover Assembly - Bellcrank Stop11-32
and Clevis CS	Crosstubes - High Landing Gear3-64
Attitude Indicator	Crosstubes - Standard Landing Gear3-25
Attitude/Turn and Slip Indicator 8-214	Cutter Blades (Upper and Lower)
Auxiliary Power Receptacle (J120) 9-370	Cyclic Button Switch (S58 and S59)9-142
Avionics Compartment Door	Cyclic Control Friction Adjuster
Avionics Compartment Floor	Cyclic Control Linkage
Ballast Installation	Cyclic Control Stick Assembly
Battery 9-26	Cyclic Stick Balance Spring
Battery Quick-Disconnect	Cyclic Stick Grip Assembly9-133, 9-136
Beam, Upper Cabin Roof	DC Ammeter
Bearings - Freewheeling Assembly6-59	Defogging Blower Motors (B7 and B8)9-340
Bellcranks, Levers and Walking Beams 11-114	Detent Button
Bleed Air Heater Plenum	Disc Assembly 6-121, 6-124,
Bleed Air Heater System	6-175
Bleed Air Installation	Door Assemblies 2-5
Bolt and Blade Latch Retainer 5-57	Doublers
Bonded Rod Ends and Bearings11-125	Drag Pin 6-77, 6-80
Bonding Strap (Crashworthy) 10-49	Drip Pan and Frame Assembly
Boost Pump(Crashworthy)	Dust and Moisture Boot
Breakaway Tip	Ejector Rack CS
Buildup - Power Plant	Engine Anti-Icing Control
Chip Detector Assembly - Tail Rotor Gearbox	Engine Assembly
(After Compliance with MWO	Engine Cowling
55-1520-228-50-25)	Engine Mounts
Chip Detectors, Tail Rotor Gearbox	Engine Mounts
(Prior to Compliance with MWO	Engine Oil Pressure Indicator 8-15  Engine Oil Temperature Indicator 8-101
55-1 520-228-50-25)	Engine Oil Temperature Transmitter Bulb .8-109
Chip Detectors - Transmission6-289	Engine Out Warning Switch 8-90
Clock	Exhaust System A4-56
0 200	

Paragraph, Figure, Table Number

Inspection (Cont)	Inspection (Cont)
Exhaust System C4-57	Hydraulic Pump (Installed) 7-12
External Power Receptacle 9-11	Hydraulic Pump (Removed)
External Power Relay	Hydraulic Relief Valve
Fault Annunciator Panel (AVIM)	Hydraulic Reservoir,
Filter	Idler Link Assembly and Collar Set5-161
Filter Bypass Valve	Idler Link Assembly and Collar Set
Fire Extinguisher	(Disassembled)
Fitting Assembly -Armament	Ignition Switch
(Hard Points) A	Ignition System
Float Landing Gear	Impulse Cartridges CS
Force Gradient Assembly	Inertia Reel
Forward Short Shaft	Inner Ring
Frame Assembly	Input Pinion Housing Adapter and
Free Air Temperature Indicator	Seals (AVIM) 6-85, 6-87
(Thermometer)	Instrument Panel, Shroud and Console 2-19
Freewheeling Assembly 6-24, 6-27,	Prior to Intermediate Storage E-28
6-29	Prior to Short Term Storage E-14
Fuel Boost Pump System	Stored Helicopters E-5
Fuel Cell (Crashworthy Fuel System) 10-5	Instantaneous Vertical Speed Indicator8-187
Fuel Filter Pressure Switch	Instruments
Fuel Pressure Switch	Interface Electronics Assembly
Fuel Pump System	Mount Tray CS 9-383.24
Fuel Quantity Indicator	Interior Lights System
Fuel Shutoff Valve (Crashworthy)	Intersystem Oil Leakage
Gas Producer Tachometer Indicator 8-65	Inverter
Gas Producer Tachometer Generator 8-74	IR/White (Dual) Landing/Searchlight9-273
Generator Fail Relay	Jackshaft
Governor Control Linear Actuator	Landing Gear Support Fittings 3-34, 2-318
Governor Control Linear Actuator	Landing Light Relay s
(AVIM)	Landing Lights
Governor Control Switch	Lever
Grip Reservoirs and Sight Glass - Oil	Line Control Relay
Lubricated Main Rotor Hub 5-69, 5-71	Long Shaft
Grips, Main Rotor (AVIM)	Lower Cutter Assembly
Heating and Ventilating System 13-3	Magnetic Brake
High Landing Gear	Magnetic Compass (Standby) 8-223
Honeycomb Panels and Shell Assembly2-172	Main Driveshaft 6-9, 6-13
Horizontal Stabilizer	Main Rotor Assembly
Housing Assembly 6-43, 6-47	Main Rotor Blade F 5-32, 5-99
Hub Strap/Pin/Fittings and Ring	Main Rotor Blade Bolt
Hydraulic Check Valve	Main Transmission
Hydraulic Filters	Mast Assembly
Hydraulic Hoses, Lines, and	Mixing Lever/Trunnion and Lever-
Quick-Disconnects	Cyclic Control Linkage
	-,

Paragraph, Figure, Table Number

## I (Cont)

. (••)	. (••,
Inspection (Cont)	Inspection (Cont)
Nonessential Bus Relay 9-71	Sawtooth Blades, Cutter Deflector
NVG Position Lights 9-290	(Upper and Lower)
Oil Cooler	Seal Foam Assembly2-312
6-256	Seals, Freewheeling Housing 6-64
Oil Cooler (Disassembled)	Seals, Main Driveshaft 6-18
	Seat Belts
Oil Cooling Blower and Shaft Assembly	Second Accumulator
Oil Filter Head Assembly 6-235	Segmented Tail Rotor Driveshaft
•	(After Incorporation of MWO
Oil Selector (Bypass) Valve (AVIM)	
(Disassembled)	55-1520-228-50-25)
Oil Selector (Bypass Valve) (Installed)4-84	Sensors, RPM
Oil Supply System Hoses, Fittings, and	Servoactuator Support (Installed)
Tubing	Servoactuator Support (Removed) 7-45
Oil Tank	Servoactuators (Cyclic and Collective) 7-36
Oil Transfer Tube 6-268	Shaft Assembly, Freewheeling
Outer Ring	Shear Link Terminals a
Particle Separator	Shielded Ignition Lead Assembly13-79
Passenger Seats2-92	Shoulder Harness
Passive Defemse A	Shunts and Bus Bars
Pillow Block - Main Rotor Yoke	Sight Gage Oil Level Assembly 6-102
Pillow Block - Main Rotor Yoke	Skid Shoe Assembly - High Landing
(AVIM)	Gear 3-53
Pilot and Copilot Seats	Skid Shoe Assembly - Standard Landing
Pilot Display Unit Mount	Gear 3-19
Assembly	Skid Tubes - High Landing Gear 3-46, 3-48
Pitch Horn, Main Rotor	Skid Tubes - Standard Landing Gesir 3-12
Pitch Link Assembly	Solenoid Valve
Pitot Heater System	Soundproofing Blankets 2-165
Pitot-Static Piping and Fittings 8-151	Spherical Outer Coupling Spline Teeth F 6-5
Pitot Tube 8-159	Spindle (Transmission)
Pivot Sleeve 5-124	Standard Lending Gear
Pocket Assambly	Starter-Generator
Position Lights 9-289	Starter Relay
Power Controls 4-101	Starter Switch 9-222
Power Turbine Tachometer Generator8-56	Starter System 9-210
Pressure Regulator Valve	Static Stop - Main Rotor Hub
Pressure Switch	Stiffeners 2-384
Pressure Switch8-250	Strut Assemblies (Upper and Lower)2-341
Primary Direction Control Vulnerability	Sump Valve (Crashworthy) 10-36, 10-39
Reduction System (Electrical) 9-122	Support Assembly (Swashplate)
Pylon isolation Mounts and Transmission	Support, Taillight
Mount Support 2-291, 2-292,	Swashplate and Support Assembly5-112
2-294	Swashplate and Support Assembly
PYLON sUI)DOrtS2-284, 2-286	(AVIM)
Ram Air Duct A	Sway Braces and Struts
Remote Sensor	Switch Box Assembly - Collective
Roll Staked Bearings	Control Stick
Rotor Tachometer Generator	Tachometer Indicator
Rotor radiomotor denotator	

Paragraph, Figure, Table Number

Inspection (Cont) Tailboom	Inspection (Cont) Trunnion — Main Rotor (AVIM) 5-40, 5-46 Tube Assembly (Flexible)
Tail Rotor Blades (After Compliance with MWO 55-1520-228-50-25)	Indicator A8-122 Turbine Outlet Temperature (TOT)
Tail Rotor Blades (Prior to Compliance with MWO 55-1520-228-50-25)5-242, 5-244	Indicator
Tail Rotor Control Linkage	Upper Cutter Assembly
Tail Rotor Control Pedals and Adjuster11-106	Ventilating and Defogging Ducts
Tail RotorDriveshaft (After Compliance	Vertical Fin and Supports
with MWO 55-1520-228-50-25) 6-160	Vibrator
Tail Rotor Driveshaft (Prior to Compliance	Voltage Regulator
with MWO 55-1520-228-50-25) 6-115	Vulnerability Reduction Flight Control
Tail Rotor Driveshaft Cover	System — Tail Rotor Control C11-136
Tail Rotor Gearbox (After Compliance	Windshields Deflector Assembly
with MWO 55-1520-228-50-25) 6-201	Windshields and Windows
Tail Rotor Gearbox (prior to Compliance	Yoke/Shield — Main Rotor Hub (AVIM)5-52
with MWO 55-1520-228-50-25)	Inspection and Repair Limits Blade Bolt —Main Rotor
Tail Rotor Gearbox Output Seal	Bolt and Blade Latch Retainer —
Tail Rotor Hub (After Compliance with	Main Rotor,
MWO 55-1 520-228-50-25)	Collar Set – Pylon (Swashplate) F 5-49
Tail Rotor Hub	Collective Lever
Tail Rotor and Blade Assembly (After	Collective Lever Links (idler) F 5-45
Compliance with MWO 55-1520-228-50-25) 5-233	Collective Sleeve
Tail Rotor Hub and Blade Assembly	Inner Ring
(Prior to Compliance with MWO	Lever
55-1520-228-50-25)	Main Rotor Hub Fitting
Tail Rotor Hub Trunnion	Main Rotor Hub Pin
Tail Rotor Installation Components5-184  Tail Rotor Pitch Change	Main Rotor Hub Ring
Mechanism 5-207, 5-210	Main Rotor Hub Static Stop F 5-25 Outer Ring
Tail Rotor Pitch Horn	Pillow Block — Main Reservoir
Tail Skid	Pitch Horn —Main Rotor
Terminal Boards	Pylon (idler) Link
Torquemeter Indicator	Support Pylon (Swashplate) F 5-48
Transmission Fairing Assembly	Tail Rotor Hub Bearing Liner F 5-61
Transmission Isolation Mount	Tail Rotor Hub Trunnion F 5-63
(P/N 206-030-539-5 and -101) T 2-2	Tail Rotor Hub Yoke F 5-58
Transmission Oil Pressure Indicator 8-285	Tail Rotor Pitch Horn F 5-71
Transmission Oil Pressure	Trunnion — Main Rotor F 5-3
Switch (S13)	Yoke — Main Rotor
Transmission Oil Pressure Transmitter8-294	Inspection and Repair of
Transmission Oil Pump	Exhaust Stack
Transmission Support Straps	Inspection Area Diagram F1-8 Inspection Limits Chart — Pitch Link and
Trunnion —Main Rotor	Crosshead
Transfer Main Rotol	0100011000

Paragraph, Figure, Table Number

## I (Cont)

Inapartian Limita Standard Landing	1 (11 (1 (2 )
Inspection Limits, Standard Landing Gear F 3-2	Installation (Cont)
Inspection Panels	Boost Pump (Crashworthy)
Installation	Breakaway Tip
Removal	Brushes
	Cargo Platform
Inspection Requirements	Channel A
Install Interrupters	Channel C
Install Rubber Pad Below Fuel	Chip Detector Assembly - Tail Rotor
Receiver	Gearbox (After Compliance with
Installation	MWO 55-1520-228-50-25)
Access Panels, Doors, and Ballast A F 2-1	Chip Detectors9-180
Accelerometer and Reflective Target F 5-93	Chip Detectors, Tail Rotor Gearbox
Aft Ballast	(Prior to Compliance with MWO
Aft Fairing A	55-1520-228-50-25)6-195
Aft Fairing C	Chip Detectors - Transmission6-280
Aft Short Shaft	Clock
Air Duct Hose Assembly 6-263	Closed Circuit Refueling Receiver 10-33
Air Mixing Valve	Clutch Assembly - Freewheeling
Airspeed Indicator	Assembly 6-56
Altimeters	Cockpit Lights 9-248
Anticollision Lights	Collective Lever and Link Assembly,5-173
Anti-Icing Control	Collective Lever, Idler Link, and
Anti-icing Lever	Collar Set F 5-36
Armament Electrical System	Collective Pitch Linkage
Armament Subsystem M27E1 A F 16-1, 16-5	Collective Sticks
Armor Panels	Combustion Chamber Drain Hose F 4-6
Ash Tray	Combustion Heater Assembly
ATAS Control Panel. CS	Combustion Heater Combustion
ATAS Missile System Fitting Assemblies	Air Pressure Switch
and Clevis CS	Combustion Heater Combustion Blower13-90
Attitude Indicator	Combustion Heater Fuel Filter
Attitude/Turn and Slip Indicator 8-219	Combustion Heater Fuel Pressure
Auxiliary Fuel Cell F 10-4, 10-12	Relief Valve
Auxiliary Power Receptacle (J120)9-375	Combustion Heater Fuel Pump
Avionics Compartment Door	Combustion Heater Fuel Shutoff Valve 13-103
Avionics Compartment Door CS2-78.1	Combustion Heater Ignition Assembly 13-66
Avionics Compartment Floor	Combustion Heater Plenum
Battery 9-31	Combustion Heater Support Bracket13-54
Battery Relay 9-36	Common Electrical Components
Battery and TrayF 9-2	Connecting Link Assembly
Bearings - Freewheeling Assembly6-62	Control Tube Assemblies - Tail Rotor
Bellcranks, Levers and Walking Beams 11-116	Control C F 11-22
Bleed Air Heater Plenum	Control Tubes
Bleed Air Heater System	Cover Assembly - Bellcrank Stop11-35
Bleed Air Installation	Crew and Passenger Seat Belt F 2-14
Bolt and Blade Latch Retainer	Crosstubes - High Landing Gear
Bonding Strap (Crashworthy)	Crosstubes - Standard Landing Gear3-25
Boost Pump Cartridge (Crashworthy) 10-23	Cutter Blades (Lower)

Paragraph Figure, Table Number

Installation (Cont)	Installation (Cont)
Cutter Blades (Upper)	Frame Assembly
Cyclic and Collective Servoactuator F 7-8	Free Air Temperature Indicator
Cyclic Button Switch	(Thermometer) 8-261
Cyclic Control Friction Adjuster	Freewheeling Assembly
Cyclic Control Linkage	Freewheeling Housing
Cyclic Control Stick Assembly	Fuel Boost Pump
Cyclic Stick Balance Spring	Fuel Cell (Crashworthy Fuel System) 10-7
Cyclic Stick Grip	Fuel Filter Pressure Switch
DC Ammeters	Fuel Pressure Switch
Defogging Blower Motors (B7 and B8)9-345	Fuel Quantity Indicator
Detent Button	Fuel Quantity Transmitters
Disc Assembly	Fuel Shutoff Valve (Crashworthy)10-45
Door	Gas Producer Control
Door Assemblies	Gas Producer Tachometer Indicator 8-70
Door Seals	Gas Producer Tachometer Generator8-79
Doubler to Passenger Seat Panel F 2-16	Generator Fail Relay
Doublers	Generator Shunt
Drag Pin	Governor Control Linear Actuator4-115
Dust and Moisture Boot	Governor Control Switch
Ejector Rack CS F 16-10	Grip Reservoirs and Sight Glass - Oil
Electrical Cable Assembly - Engine F 4-5	Lubricated Main Rotor Hub
Electronics Unit CS9-383.16	Grips, Main Rotor (AVIM)
Engine	Ground Handling Trucks
Engine Assembly	High Landing Gear
Engine Cowling	High Landing Gear Step, Skid Shoe,
Engine Mount Fittings	and Ballast
Engine Mounts	Horizontal Stabilizer F 2-50, 2-263
Engine Oil Pressure Indicator	Hydraulic Bypass Solenoid
Engine Oil Temperature Indicator 8-105	Hydraulic Check Valve
Engine Oil Temperature Bulb	Hydraulic Filters
Engine Out Warning Switch 8-93, 9-186	Hydraulic Hoses, Lines, and
Exhaust System	Quick-Disconnects
External Power Receptacle	Hydraulic Pump
External Power Relay	Hydraulic Relief Valve
Filter	Hydraulic Reservoir
Filter Bypass Valve	Idler Link Assembly and Collar Set5-166
Fire Extinguisher	Ignition Switch
First Aid Kit	Impulse Carttidges CS
Fitting Assembly - Armament	Inertia Reel
(Hard Points) A2-222	Inertia Reel Strap
Float Landing Gear	Inner Ring (AVIM)
Force Gradient Assembly	Input Pinion Housing Adapter and
Forward and Aft Short Shafts	Seals (AVIM)
Forward Short Shaft	Inserts - Honeycomb Panels F 2-43
Forward Ballast A2-213	Inspection Panels
Forward Ballast C2-214	Instantaneous Vertical Speed indicator8-192
1 01 Wala Dallast 3	instrument Panel, Shroud and Console 2-22

Paragraph

Figure, Table

Number Number I (Cont) I (Cont) installation (Cont) Installation (Cont) Oil Selector (Bypass) Valve . . . . . . . . . . . . 4-91 Interface Electronics Oil Tank ...... 4-69 Interface Electronics Assembly Mount Tray CS . . . . . . . . . F 9-33, 9-383.26 Landing Gear Support Fittings . . . ...6-36, 2-315 Pilot and Copilot Armor . . . . . . . . . . . F 2-18 Pilot Display Unit Mount Assembly CS . ..16-27 Launcher Assembly . . . . . . . . . F 16-7, 16-36 Light Flasher ..... 9-319 Pitot Heater System .....9-361 Long Driveshaft - Tail Rotor Pitot-Static Piping A (After Incorporation of Long Driveshaft - Tail Rotor Pitot-Static Piping and Fittings . . . . . . . . . . . . . . . . . 8-154 (Spring Type) . . . . . . . . . . . . . . . . . . F 6-21 Long Shaft ..... 6-157 Pitot Tube ...... 8-162 Pivot Sleeve (AVIM) .....5-127 Low Level Switch (Crashworthy) . . . . . . . . . 10-29 Pocket Assembly .....2-156 Low Pressure Sensing Switch . . . . . . . . . 6-280 Position Lights . . . . . . . . . . . . . . . . . . 9-298 Power Controls . . . . . . . . . . . . . . . . . . 4-109 Power Controls - Control Cable Magnetic Compass (Standby) . . . . . . . . . 8-226 Power Turbine Tachometer Generator . . ...8-61 Magnetic Pickup and Doubler Main Driveshaft . . . . . . . . . . . . . . . 6-15 Pressure Sensing Switch . . . . . . . . . . . . F 6-41 Main Input Quill, Seal . . . . . . . . . . . F 6-13 Main Rotor Assembly. . . . . . . . . . . . . . . 5-10 Main Rotor Blade Bolt . . . . . . . . . . . . . . 5-90 Main Rotor Blade Tracking Target . . . . . . F 5-94 Pylon Isolation Mount . . . . . . . . . . . F 2-57 Pylon Isolation Mounts and Transmission Mount Support . . . . . . . . . . . . . . . F 2-57, 2-298 Main Rotor Pitch Horn Trunnion . . . . . . . . . 5-95 Map and Data Case .....2-147 Reel Strap Assembly . . . . . . . . . . . . F 2-17 Mixing Lever/Trunnion and Lever -Sawtooth Blades, Cutter Deflector Oil Cooling Blower and Shaft Sawtooth Blades, Cutter Deflector (Upper) ......2-329 Assembly . . . . . . . . . . . . . . . . . 6-143 Seal Foam Assembly .....2-324

Paragraph

Figure, Table

Paragraph, Figure, Table Number

# I (Cont)

Seals, Freewheeling Housing.   6-67	Installation (Cont)	1 ( 11 ( 12 ( 12 ) )
Seals Main Driveshaft	Installation (Cent)	Installation (Cont)
Seat Belts		
Seats and Restraint		· · · · · · · · · · · · · · · · · · ·
Second Accumulator		· · · · · · · · · · · · · · · · · · ·
Sensors, RPM		
Servoactuators (Cyclic and Collective)		· · · · · · · · · · · · · · · · · · ·
Servoactuators (Cyclic and Collective)		
Collective) F 7-8, 7-39 Shart Assembly, Freewheeling 6-40 Shear Link Terminals		· · · · · · · · · · · · · · · · · · ·
Shaft Assembly, Freewheeling   .6-40   Shear Link Terminals		,
Shear Link Terminals		
Tail Rotor Hub (Prior to Compliance with MWO 55-1520-228-50-25)		
Shoulder Harness		
Shunts and Bus Bars,   9-191		
Sight Gage Oil Level Assembly   .6-105		,
Single Interrupter		
Skid Tubes - High Landing Gear   3-50   Solenoid Valve   7-24, 7-32   (With Dynamic Balance Wheel)  5-188   Soundproofing Blankets   2-169   (With Dynamic Balance Wheel)  5-189   Spindle (Transmission)  6-111   Tail Rotor Hub Trunnion  5-220   Tail Rotor Pedal Assembly  5-189   Tail Rotor Pitch Change Mechanism  5-220   Tail Rotor Pitch Control Pedal  5-111   Tail Rotor Pitch Horn  5-226   Tail Rotor System  5-126   Tail Rotor System  5-121   Tail Rotor System  5-121   Tail Rotor System  5-121   Tail Rotor Rosembly  5-151   Torquemeter indicator  5-290   Tail Rotor Rosembly  5-151   Torquemeter indicator  5-290   Tail Rotor Blades (After Compliance   with MWO 55-1520-228-50-25)  5-246   Tail Rotor Blades (Prior to Compliance   with MWO 55-1520-228-50-25)  5-246   Tail Rotor Control Pedals and   Adjuster  5-126   Turbine Outlet Temperature (TOT)   Indicator  5-189   Tail Rotor Pitch Hub Trunnion  5-220   Tail Rotor Pitch Control Pedal Assembly  5-181   Tail Rotor Pitch Hub Trunnion  5-220   Tail Rotor Pitch Control Pedal  5-113   Tail Rotor System  5-118   Tail Rotor System  5-118   Tail Rotor System  5-118   Tail Rotor Pitch Hub Trunnion  5-220   Tail Rotor System  5-118   Tail Rotor System  5-118   Tail Rotor Pitch Control Pedal  5-118   Tail Rotor Pitch Hub Trunnion  5-220   Tail Rotor System  5-118   Tail Rotor Pitch Horn  5-226   Tail Rotor System  5-118   Tail Rotor Pitch Horn  5-226   Tail Rotor System  5-151   Tarl Rotor Pitch Hub Trunnion  5-226   Tail Rotor Pitch Hub Trunnion  5-226   Tail Rotor Pitch Hub Trunnion  5-226   Tail Rotor Pi		
Solenoid Valve		,
Soundproofing Blankets   2-169   Spindle (Transmission)   6-111   Tail Rotor Hub Trunnion   5-220   Tail Rotor Pedal Assembly   11-110   Starter-Generator   9-44   Starter Generator   9-944   Starter Relay   9-219   Starter Switch   9-224   Starter System   9-214   Statter System   9-224   Starter System   9-224   St		· · · · · · · · · · · · · · · · · · ·
Spindle (Transmission)         6-111         Tail Rotor Hub Trunnion         .5-220           Standard Landing Gear         .3-8         Tail Rotor Pedal Assembly         .11-110           Starter Generator         .9-44         Tail Rotor Pedal Assembly         .11-110           Starter Relay         .9-219         Tail Rotor Pitch Control Pedal         F 11-13           Starter Switch         .9-224         Tail Rotor Pitch Control Pedal         F 11-13           Starter System         .9-214         Tail Rotor Pitch Horn         .5-226           Static Stop - Main Rotor Hub         .5-66         Control C.         .9-196           Stiffeners         .2-387         Tail Rotor System - Tail Rotor         .9-196           Strut Assemblies (Lower)         .2-346         Tail Rotor System - Tail Rotor         .9-196           Strut Assembly (Upper)         .2-345         Tail Rotor System - Tail Rotor         .9-196           Support Assembly (Swashplate)         .5-151         Transmission Cill Resistor         .8-131           Swashplate and Support Assembly         .5-121         Transmission Oil Pressure Indicator         .8-29           Tail Rotor Blades (After Compliance with MWO 55-1520-228-50-25)         .5-24         Transmission Oil Pressure Transmiter         .9-19           Tail Rotor Control Pedals an		
Standard Landing Gear	Soundproofing Blankets	
Starter-Generator         .9-44         Tail Rotor Pitch Change Mechanism         .5-214           Starter Relay         .9-219         Tail Rotor Pitch Control Pedal         F 11-13           Starter Switch         .9-224         Tail Rotor Pitch Control Pedal         F 11-13           Starter System         .9-214         Tail Rotor Pitch Control Pedal         F 11-13           Starter System         .9-214         Tail Rotor Pitch Control Pedal         F 11-13           Starter System         .9-214         Tail Rotor Pitch Control Pedal         F 11-13           Starter Switch         .9-224         Tail Rotor Pitch Control Pedal         F 11-13           Tail Rotor Pitch Control Pedal         F 11-13         Tail Rotor Pitch Control Pedal         F 11-13           Tail Rotor Pitch Control Pedal         F 11-13         Tail Rotor Pitch Hom         .5-226           Tail Rotor System         - Tail Rotor System         - Tail Rotor Control Pedals         .9-214           Tail Rotor System         - Tail Rotor System         - Tail Rotor System         - Tail Rotor System         - Tail Rotor Control Pedals         .9-196           Strut Assembly (Upper)         .2-345         Thermical Boards         .9-196         Terminal Boards         .9-196           Support, Taillight         .5-254         .2-281	Spindle (Transmission) 6-111	
Starter Relay         9-219         Tail Rotor Pitch Control Pedal         F 11-13           Starter Switch         9-224         Tail Rotor Pitch Horn         5-226           Starter System         9-214         Tail Rotor Pitch Horn         5-226           Static Stop - Main Rotor Hub         5-66         Control Image         11-138           Stiffeners         2-387         Tail Rotor System - Tail Rotor         11-138           Stiffeners         2-346         Tail Rotor System - Tail Rotor         11-138           Stiffeners         2-346         Tail Rotor System - Tail Rotor         11-138           Strut Assemblis (Lower)         2-346         Tail Rotor System - Tail Rotor         11-138           Strut Assembly (Upper)         2-346         Tail Rotor Skid         2-275           Strut Assembly (Upper)         2-345         Tail Rotor Resistor         8-131           Sump Valve (Crashworthy)         10-40         Thermocouple Resistor         8-131           Tip Targets         F 5-92         Torquemeter indicator         8-292           Support Assembly (Swashplate)         5-121         Transmission Fairing Assembly         2-43           Tail Rotor Ender Indicator         8-43         Transmission Oil Pressure Indicator         8-290           Ta	Standard Landing Gear	
Starter Switch         .9-224         Tail Rotor Pitch Horn         .5-226           Starter System         .9-214         Static Stop - Main Rotor Hub         .5-66         Control		
Starter System         .9-214         Tail Rotor System - Tail Rotor           Static Stop - Main Rotor Hub         .5-66         Control □         .11-138           Stiffeners         .2-387         Tail Skid         .2-275           Strut Assemblies (Lower)         .2-346         Tail Skid         .2-275           Strut Assembly (Upper)         .2-345         Terminal Boards         .9-196           Strut Assembly (Upper)         .2-345         Thermocouple Resistor         .8-131           Support Assembly (Swashplate)         .5-151         Torquemeter indicator         .8-29           Support, Taillight         F 2-54, 2-281         Transmission Fairing Assembly         .2-43           Transmission Oil Pressure Indicator         .8-290         Transmission Oil Pressure Switch         .9-173           Taillight         .9-308         Transmission Oil Pressure Transmitter         .9-299           Taill Rotor Blades (After Compliance with MWO 55-1520-228-50-25)         .5-254         Tube Assembly (Flexible)         .2-236 <td></td> <td></td>		
Static Stop - Main Rotor Hub        5-66         Control <td></td> <td></td>		
Stiffeners         2-387         Tail Skid         2-275           Strut Assemblies (Lower)         2-346         Terminal Boards         9-196           Strut Assembly (Upper)         2-345         Terminal Boards         9-196           Thermocouple Resistor         8-131         Tip Targets         5-59           Support Assembly (Swashplate)         5-151         Torquemeter indicator         8-29           Swashplate and Support Assembly         5-121         Transmission Fairing Assembly         2-43           Transmission Oil Pressure Indicator         8-290         Transmission Oil Pressure Switch         9-173           Tail Rotor         F 5-54         Transmission Oil Pressure Transmitter         9-299           Tail Rotor Blades (After Compliance with MWO 55-1520-228-50-25)         5-254         Tube Assembly (Metal)         2-236           Tail Rotor Control Linkage         11-97         Indicator		
Strut Assemblies (Lower)		
Strut Assembly (Upper)		
Sump Valve (Crashworthy)	· ,	
Support Assembly (Swashplate)		
Support, Taillight		
Swashplate and Support Assembly5-121 Tachometer Indicator8-43 Tailboom		·
Tachometer Indicator	• • • •	
Tailboom F 2-46,2-250 Taillight 9-308 Tail Rotor F 5-54 Tail Rotor Blades (After Compliance with MWO 55-1520-228-50-25) 5-254 Tail Rotor Control Linkage 11-97 Tail Rotor Control Pedals and Adjuster 11-108 Tail Rotor Driveshaft (Prior to Compliance with MWO 50-1520-228-50-25) 11-108 Tail Rotor Driveshaft (Prior to Compliance with MWO 50-1520-228-50-25) 11-108 Tail Rotor Control Pedals and Adjuster 11-108 Tail Rotor Driveshaft (Prior to Compliance with MWO 50-1520-228-50-25) 11-108 Tail Rotor Control Pedals and Adjuster 11-108 Tail Rotor Driveshaft (Prior to Compliance with MWO 50-1520-228-50-25) 11-108 Tail Rotor Control Pedals and Adjuster 11-108 Tail Rotor Driveshaft (Prior to Compliance with MWO 50-1520-228-50-25) 11-108 Transmission Oil Pump 6-231 Transmission Oil Pump 6-247, 9-158 Tube Assembly (Metal) 2-230 Turbine Outlet Temperature (TOT) Indicator A 11-108 Indicator A 11-108 Turbine Outlet Temperature (TOT) Indicator A 11-108 Indicator A 11-108 Turbine Outlet Temperature (TOT) Indicator A 11-108 Indicator A 11-108 Turbine Outlet Temperature (TOT) Indicator A 11-108 Indicator A 11-108 Indicator A 11-108 Turbine Outlet Temperature (TOT) Indicator A 11-108		
Taillight		
Tail Rotor Blades (After Compliance with MWO 55-1520-228-50-25)5-254 Tail Rotor Blades (Prior to Compliance with MWO 55-1520-228-50-25)5-246 Tail Rotor Control Linkage11-97 Tail Rotor Control Pedals and Adjuster		
Tail Rotor Blades (After Compliance with MWO 55-1520-228-50-25)5-254 Tail Rotor Blades (Prior to Compliance with MWO 55-1520-228-50-25)5-246 Tail Rotor Control Linkage5-246 Tail Rotor Control Pedals and Adjuster		
with MWO 55-1520-228-50-25)5-254 Tail Rotor Blades (Prior to Compliance with MWO 55-1520-228-50-25)5-246 Tail Rotor Control Linkage	Tail Rotor	
Tail Rotor Blades (Prior to Compliance with MWO 55-1520-228-50-25)	Tail Rotor Blades (After Compliance	Switch 6-247, 9-158
with MWO 55-1520-228-50-25)5-246 Tail Rotor Control Linkage	with MWO 55-1520-228-50-25)5-254	
Tail Rotor Control Linkage		
Tail Rotor Control Pedals and Adjuster		
Adjuster	Tail Rotor Control Linkage	
Tail Rotor Driveshaft (Prior to Turn and Slip Indicator	Tail Rotor Control Pedals and	
Compliance with MWO Upper Cutter Assembly	Adjuster	
	Tail Rotor Driveshaft (Prior to	
55-1520-228-50-25)		
	55-1520-228-50-25)	Ventilating and Defogging Blower A13-30

I (Cont)

Paragraph Figure, Table Number

Paragraph, Figure, Table Number

` ,	i (Going
Installation (Cont)	Interface Electronics Assembly (Cont)
Ventilating and Defogging Blower C13-31	Description
	Installation
Ventilating and Defogging Ducts	Removal
Ventilation Blower	Interface Electronics Assembly Mount
Vertical Fin	Tray CS
2-269	
Vibrator	Description
Voltage Regulator	Inspection
Vulnerability Reduction Flight Control	Installation
System -Tail Rotor Control C	Removal
Windshield Deflector Assembly	Repair
Windshields and Windows	Interior Lights System A -
Yoke/Shield - Main Rotor Hub (AVIM)5-54	Wiring Diagram
Installation of Doubler to Passenger	Interior Lights System A -
Seat Panel F 2-16	Wiring Diagram (After Compliance with
Installation of Electrical Cable	MWO 55-1 520-228-50/22 NVG) F F-14
Assembly - Engine	Interior Lights System C -
	Wiring Diagram F F-35
[nstallation/Reassembly - Crosstubes -	Intermediate Storage
Standard Landing Gear	Accident Engines Preservation E-44
Instantaneous Vertical Speed Indicator 8-184	Airframe E-42
Cleaning	Avionics Equipment E-39
Functional Check	Combat Damaged Fuel Tanks E-32
Inspection 8-187	Damaged, Cannibalized or Failed
Installation	Engine Preservation Procedure E-45
Removal 8-190	Depreservation After E-48
Repair	Description E-46
Troubleshooting	
Instrument Maintenance	Electrical System
Cleaning	Emergency Equipment
General 8-2	Engine E-30
Inspect ion	Fuel System E-31
Installation 8-7	Hydraulic System
Removal	inspection Prior to
Repair or Replacement	Instruments
Testing 8-8	Landing Gear E-41
Instrument Panel, Shroud and Console 2-16	Main Rotor Blades
Cleaning	Main Rotor Hub and Mast Assembly E-36
Inspection	Maintenance of Preservation E-43
Installation	Power Train System E-29
Removal 2-20	Tail Rotor Group E-37
Repair	Intersystem Oil Leakage
	Inspect ion
Instrument Panel (Typical) AF 8-3	Repair/Replacement
Instrument Panel (Typical) C F 8-3	Inventoriable Items
Instruments	Inventory, Master Guide
Intermediates borage	Inventory Sections
Short Term Storage E-21	Inverter, Attitude, and Turn and
interface Electronics	Slip Indicator Systems A -
Assembly CS	Wiring Diagram F F-4
	3 0

Paragraph Figure, Table Number	Paragraph, Figure, Table Number
I (Cont)	L (Cont)
Inverter, Attitude, and Turn and Slip Indicator Systems ————————————————————————————————————	Landing Lights (Cont)  inspection
Diagram	Leveling Plates, Helicopter
J Jacking	Inspection
L  Landing Gear Intermediate StorageE-41 Short Term StorageE-23 Landing Gear Support Fittings	Honeycomb Panel Major Edge Damage2-192 Honeycomb Panel Minor Edge Damage2-189 Major Panel Damage2-186 Minor Panel Damage2-182 Negligible Honeycomb Panel Damage2-179 Limits Chart Freewheeling Assembly

#### Paragraph, Figure, Table Number

#### L (Cont)

Linear Actuator, Governor Control (Cont)	
Inspection (AVIM)	9-96 9-98
Linear Actuator Wiring Schematic	
Linear Actuator Work Aid	
Line Control Relay (K12)	
Inspect ion	
Installation	
Removal	
Troubleshooting	
g	9-62
List of Consumable Materials	1-27
Load Analysis Chart A	F F-3
Load Analysis Chart C	
Long Driveshaft Installation -	
Tail Rotor (Hard Type)	F 6-20
Long Driveshaft Installation -	
Tail Rotor (Spring Type)	
Long Shaft	
Inspection	
Installation.	
Lubrication	
Removal	
Repair	
Low Level Switch - Crashworthy installation	10-24
Removal	
Repair or Replacement	_
Testing	
Low Pressure Sensing Switch	6-277
Installation	
Removal	
Lower Cutter Assembly	
Lubrication	
Aft Short Shaft	6-146
Forward Short Shaft	6-130

Paragraph, Figure, Table Number

## L (Cont)

## M (Cont)

L (OOIII)	W (COIII)
Lubrication (Cont)  Long Shaft	Main Rotor Blade - Bond Area Inspection . F 5-31  Main Rotor Blade Bolt
Magnesium Alloy and Aluminum Corrosion,           Treatment of         1-23           Magnetic Brake         9-124, 11-69           Inspection         11-71           Installation         11-74           Removal         11-72           Repair or Removal         11-73           Magnetic Compass (Standby)         8-220           Cleaning         8-222           Compensation (Swinging)         8-224           Inspection         8-223           Installation         8-225           Troubleshooting         8-225           Adjust         5-269           Attach         5-267           Magnetic Pickup and Double Interrupter         Installation         F 5-90           Main Driveshaft         F 6-2, 6-7           Cleaning         6-12           Disassembly         F 6-3, 6-11           Inspection         6-9, 6-13           Installation         6-15           Removal         6-10           Main Input Quill Seal Installation         F 6-1, 5-265           Necessary Equipment         5-266           Operational Check         5-266           Toubleshooting         T 5-1, 5-5           Main Rotor Assembly <td>Main Rotor Blade Corrosion - Repair Dimensions F 5-33 Main Rotor Blade Drain Holes F 5-33.1 Main Rotor Blade Tracking Target F 5-94 Main Rotor Blades F 5-96 Cleaning Frior to Refinishing 5-98 Cleaning Prior to Refinishing 5-101 Flyable Storage F-11 Inspection F 5-32, 5-99 Installation 5-106 Intermediate Storage F-35 Painting 5-107 Removal F 5-11, 5-100 Refinishing (AVIM) 5-105 Repair Areas F 5-34 Repair (Corrosion) 5-102 Repair (Patching) (AVIM) 5-103 Repair - Wear and Grip Pads 5-104 Short Term Storage F-20 Main Rotor Chart Examples and Corrections 5-259 Main Rotor Grips 5-14 Assembly (AVIM) 5-19 Damage Limits F 5-13 Disassembly (AVIM) 5-19 Damage Limits F 5-13 Disassembly (AVIM) 5-17 Inspection (AVIM) 5-18 Installation (AVIM) 5-18 Installation (AVIM) 5-10 Repair (AVIM) 5-10 Repair (AVIM) 5-10 Repair (AVIM) 5-10 Repair (AVIM) 5-17 Inspection (AVIM) 5-18 Installation (AVIM) 5-17 Inspection (AVIM) 5-18 Installation (AVIM) 5-10 Repair (AVIM) 5-20 Main Rotor Hub 5-11 Cleaning and Corroson Protection 5-13 Servicing 1-9 Main Rotor Hub And Mast Assembly Intermediate Storage 5-12 Main Rotor Hub Grip Seals and Bearings, Replacement of 5-12 Main Rotor Hub Pin - Inspection and</td>	Main Rotor Blade Corrosion - Repair Dimensions F 5-33 Main Rotor Blade Drain Holes F 5-33.1 Main Rotor Blade Tracking Target F 5-94 Main Rotor Blades F 5-96 Cleaning Frior to Refinishing 5-98 Cleaning Prior to Refinishing 5-101 Flyable Storage F-11 Inspection F 5-32, 5-99 Installation 5-106 Intermediate Storage F-35 Painting 5-107 Removal F 5-11, 5-100 Refinishing (AVIM) 5-105 Repair Areas F 5-34 Repair (Corrosion) 5-102 Repair (Patching) (AVIM) 5-103 Repair - Wear and Grip Pads 5-104 Short Term Storage F-20 Main Rotor Chart Examples and Corrections 5-259 Main Rotor Grips 5-14 Assembly (AVIM) 5-19 Damage Limits F 5-13 Disassembly (AVIM) 5-19 Damage Limits F 5-13 Disassembly (AVIM) 5-17 Inspection (AVIM) 5-18 Installation (AVIM) 5-18 Installation (AVIM) 5-10 Repair (AVIM) 5-10 Repair (AVIM) 5-10 Repair (AVIM) 5-10 Repair (AVIM) 5-17 Inspection (AVIM) 5-18 Installation (AVIM) 5-17 Inspection (AVIM) 5-18 Installation (AVIM) 5-10 Repair (AVIM) 5-20 Main Rotor Hub 5-11 Cleaning and Corroson Protection 5-13 Servicing 1-9 Main Rotor Hub And Mast Assembly Intermediate Storage 5-12 Main Rotor Hub Grip Seals and Bearings, Replacement of 5-12 Main Rotor Hub Pin - Inspection and
Troubleshooting	Repair Limits

Figure, Table Figure, Table Number Number M (Cont) M (Cont) Main Rotor Hub Static Stop -Maximum Internal Corrosion Removal Limits Inspection and Repair Limits . . . . . . . . . F 5-25 for Tail Rotor Gearbox Input Main Rotor Hub Surface Repair Limits . . . . . . . F 5-2 Main Rotor Hub Trunnion and Pillow Maximum Strut Dimensions CS . . . . . . . . F 16-26 Metal Particles Contamination, Main Rotor Mast Build-Up . . . . . . . . . . . F 6-17 Main Rotor Mast Nut Torqueing . . . . . . . . . . F 5-7 Main Rotor Mast Protective Cap - Plug..... F 5-9 Minor Panel Damage Main Rotor Mast Subassemblies . . . . . . . F 6-15 Main Rotor Pitch Horn Trunnion . . . . . . . . . 5-91 Main Rotor Seal (Outboard) Retainer Missile Launcher Pitch Main Rotor Trunnion Centering. ... . . . . . . F 5-21 Adjustment . CS . . . . . . . . . . F 16-24, 16-69 Missile Launcher Roll Adjustment CS . . . . . . . . . . . F 16-25, 16-70 Missile Launcher Yaw Preparation for Shipment and Storage . . . . . 6-74 Adjustment . CS . . . . . . . . . . . F 16-25, 16-71 Mission Equipment - General . . . . . . . . . . . . 16-1 Mixing Lever/Trunnion and Lever -Maintenance Allocation Chart . . . . . . . . . . . . . . . . B-1 Maintenance of preservation -Maintenance Precautions - Engine Major Panel Damage Mounting Plate Bearing - Linear Actuator . ..9-99 Make Required Changes and Check Results .5-284 Manufacturer Items (AVUM, AVIM) . . . . . . . . . D-1 Ν Needle Bearing Housing Damage Limits . . . . F 5-77 Negligible Honeycomb Panel Damage -Disassembly (AVIM) . . . . . . . . . . . . F 6-14, 6-94 Inspection (AVIM) . . . . . . . . . . . . . . . 6-92, 6-96 Night Vision Goggles System C (After Mast Repair Areas and Limits . . . . . . . . . F 6-16 Compliance with MWO 55-1520-228-50-32) -Maximum Allowable Leakage for 

Paragraph

Paragraph

Paragraph, Figure, Table Number

# N (Cont) O (Cont)

Night Vision Goggles System C (Prior to Compliance with MWO 55-1520-228-50-32) — Wiring Diagram	Oil System       .4-62         Oil Tank       .4-64         Inspection       .4-66         Installation       .4-69         Removal       .4-67         Repair       .4-68         Oil TankSupportAssembly —Removal       4-71.1         Installation       .4-71.2         Oil TransferTube       .6-264         Cleaning       .6-267         Inspection       .6-268
U	
Oil Cooler	Installation
Inspection	Removal

Paragraph	Paragraph,
Figure, Table Number	Figure, Table
	Number
P (Cont)	P (Cont)
Passenger Door - Latch Assembly F 2-5	Pilot Display Unit Mount Assembly (Cont)
Passenger Entrance SCUFF PLATES -	Description
Repair F 2-7, 2-11	Disassembly
Passenger Seats	Inspection
Inspection         2-92           Installation         2-95	Removal
Removal	Repair
Repair	Pitch Change Mechanism Control Tube -
Passive Defense A	Tail Rotor - Repair Limits F 5-68
Disassembly	Pitch Change Mechanism Housing and
Inspection	Trunnion - Tail Rotor - Repair Limits F 5-66
Installation	Pitch Change Mechanism Idler Clevis -
Reassembly	Tail Rotor - Repair Limits F 5-67
Removal	Pitch Change Mechanism Lever and Cap -
Repair or Replacement	Tail Rotor - Repair Limits F 5-65
PDU Alignment Assembly	Pitch Change Mechanism Straight Pin -
installation CS F 16-21,16-63	Tail Rotor - Wear Limits
PDU Boresighting Procedures 16-64	Pitch Change Mechanism - Tail Rotor F 5-64
PDU Pitch Adjustment CS 16-65	Pitch Horn, Main Rotor
PDU Roll Adjustment CS	Cleaning
PDU Yaw Adjustment CS F 16-22, 16-67	Inspection
Periods of Inventory	Inspection and Repair Limits F 5-15
Pillow Block - Main Reservoir -	Installation
Inspection and Repair Limits F 5-28	Removal
Pillow Block - Main Rotor Yoke	Repair
Assembly (AVIM)	Pitch Link and Crosshead - Inspection
Cleaning 5-76	Limits Chart
Cleaning (AVIM)	Pitch Link Assembly
Disassembly (AVIM) 5-80	Damage Limits F 5-53
Inspect ion	Inspection
Inspection (AVIM)	Installation
Removal (AVIM)	Preliminary Dimensions Prior to
Repair 5-78	Tracking
Repair (AVIM)	Removal
Pillow Block Seal - Removal F 5-26	Repair
Pilot and Copilot Armor Installation F 2-18	Pitot Heater System
Pilot and Copilot Seats	Inspection
Inspection	Installation
Installation 2-89	Removal
Removal2-87	Repair or Replacement
Repair	Testing 9-357
Pilot Display Unit CS F 16-2, 16-14	Troubleshooting
Description	Pitot-Static System
Installation,	Troubleshooting
Removal	Pitot-Static Piping and Fittings
Pilot Display Unit Mount	Cleaning
Assembly . CS	Inspection 8-151
Assembly	Installation
Adjustment F 16-5, 16-26	Installation (After Incorporation of
Cleaning	MWO 55-1520-228-30/22) F 8-1, 8-154

Paragraph Figure, Table Number

# P (Cont)

## P (Cont)

Pitot Static Piping and Fittings (Cont)		` ,
Repair or Replacement	Pitot-Static Piping and Fittings (Cont)	Power Turbine Tachometer Generator (Cont)
Pivot Sleeve   5-122   Removal   Repair or Replacement   Replacement   Repair or Replacement   Replacement   Repair or Replacement   Repair or Replacement   R	Removal 8-152	Inspection 8-56
Inspection   5-124   Repair or Replacement   3-60   Restrict   3-125   Removal (AVIM)   5-125   Repair (AVIM)   5-125   Repair (AVIM)   5-126   Rep	Repair or Replacement	Installation 8-61
Installation (AVIM)   .5-127   Testing	Pivot Sleeve 5-122	Removal 8-59
Removal (AVIM)	Inspection 5-124	Repair or Replacement
Removal (AVIM)	Installation (AVIM)	Testing A 8-57
Refuelling	Removal (AVIM)	Testing C
Cleaning   8-158   Inspection   8-159   Inspection   8-162   Removal   8-160   Repair   8-161   Repair	Repair (AVIM) 5-126	Precautions in Fuel Servicing and
Inspection   Section	Pitot Tube 8-156	Refueling
Inspection   Section	Cleaning 8-158	Preliminary Boresight Procedures CS16-59
Removal         8-160         Main Transmission         .6-74           Repair         8-161         Preparation of Bonding Surfaces         2-177           Pitot Tube Heater         9-384         Preparation of Honeycomb Core Plug (AVIM)         2-178           Plexiglas - Cleaning         1-20         Preparation of Honeycomb Core Plug (AVIM)         2-178           Plexiglas - Cleaning         1-20         Preparation of Honeycomb Core Plug (AVIM)         2-178           Inspection         2-151         Inspection         6-273           Installation         2-156         Inspection         6-276           Removal         2-154         Removal         6-276           Repair         2-155         Pressure Sensing Switch Installation         6-276           Removal         9-284         Inspection         7-50, 8-250           Inspection         9-284         Inspection         7-53, 8-253           Removal         9-295         Removal         7-51, 8-261         Repair or Replacement         7-52, 8-252           Primary Directional Control Vulnerability         Reduction System (Electrical)         9-119         Inspection         9-119           Toobleshooting         9-291         Troubleshooting         7-7-7, 9-123         Primary Directional	Inspection 8-159	Preparation for Removal - Engine Assembly. 4-29
Repair	installation 8-162	Preparation for Shipment of Storage -
Pitot Tube Heater	Removal 8-160	Main Transmission
Pressure Regulator Valve	Repair 8-161	Preparation of Bonding Surfaces
Plexiglas - Cleaning	Pitot Tube Heater	Preparation of Honeycomb Core Plug (AVIM) 2-175
Pocket Assembly	Plexiglas - Cleaning	
Installation	Pocket Assembly 2-151	Adjustment
Removal	Inspection 2-153	Inspection 6-275
Repair	Installation 2-156	Installation 6-276
Position Lights	Removal	Removal 6-274
Inspection	Repair	Pressure Sensing Switch Installation F 6-41
Inspection	Position Lights 9-284	Pressure Switch
Removal	Cleaning 9-287	Inspection
Removal         9-295         Repair or Replacement         .7-52, 8-252           Repair         9-297         Primary Directional Control Vulnerability           Testing         9-291         Reduction System (Electrical)         .9-119           Troubleshooting         .9-293         Reduction System (Electrical)         .9-119           Power Control - Torque Tube Assembly         F 4-17         Inspection         .9-121           Power Controls         .4-99         Toubleshooting         .7-97, 9-123           Droop Compensator N2         F 4-20         Primary Directional Control Vulnerability           Gas Poducer N1         F 4-19         Reduction System © - Wiring Diagram         F F-30           Inspection (Acceptance/Rejection Criteria)         4-101         Reduction System © - Wiring Diagram         F F-30           Procedure Common to All Modes         of Storage         .5-4           Removal         4-108         Procedure Common to All Modes         of Storage         .5-11-21           Power Plant         4-2         Proximity Warning System         .5-15-21           Proximity Warning System         .5-15-21           Proximity Warning System         .5-16-2           Proximity Warning System         .5-16-2           Wiring Diagram         .5-15-2 </td <td></td> <td>Installation</td>		Installation
Repair 9-297 Testing 9-291 Troubleshooting 9-293 Power Control - Torque Tube Assembly F 4-17 Power Controls 4-99 Droop Compensator N2 F 4-20 Gas Poducer N1 F 4-101 Installation 4-101 Installation 4-101 Installation 4-103 Removal 4-108 Troubleshooting 4-107 Power Plant 4-2 Build-up 4-7 Cleaning 4-5 Inspection 4-8 Operational Control Vulnerability Reduction System (Electrical) 6 9-119 Inspection (Place Installation 9-122 Test 9-121 Troubleshooting T 9-7, 9-123 Troubleshooting T 9-7, 9-123 Primary Directional Control Vulnerability Reduction System 0 9-122 Test 9-121 Troubleshooting T 9-7, 9-123 Primary Directional Control Vulnerability Reduction System 0 9-122 Test 9-121 Troubleshooting T 9-7, 9-123 Primary Directional Control Vulnerability Reduction System 0 9-122 Test 9-121 Troubleshooting T 9-7, 9-123 Primary Directional Control Vulnerability Reduction System (Electrical) 0 9-122 Test 9-121 Troubleshooting T 9-7, 9-123 Primary Directional Control Vulnerability Reduction System (Electrical) 0 9-122 Test 9-12 Test 9-121 Troubleshooting T 9-7, 9-123 Primary Directional Control Vulnerability Reduction System (Electrical) 0 9-122 Test 9-121 Troubleshooting T 9-7, 9-123 Primary Directional Control Vulnerability Reduction System (Electrical) 0 9-122 Test 9-121 Troubleshooting T 9-7, 9-123 Primary Directional Control Vulnerability Reduction System (Electrical) 0 9-122 Test 9-12 Tes	installation	Removal 7-51, 8-261
Testing 9-291 Troubleshooting 9-293 Power Control - Torque Tube Assembly F 4-17 Power Controls 4-99 Droop Compensator N2 F 4-20 Gas Poducer N1 F 4-19 Inspection (Acceptance/Rejection Criteria) 4-101 Installation 4-103 Removal 4-108 Troubleshooting 4-107 Power Plant 4-2 Build-up 4-7 Cleaning 4-5 Inspection 4-8 Operational Checks 4-6 Power Train Flyable Storage F-7 Intermediate Storage E-19 Short Term Storage E-15 Power Turbine Tachometer Generator 8-9-293 Reduction System (Electrical) C 9-119 Inspection System (Electrical) C 9-119 Inspection 9-122 Test 9-121 Troubleshooting Test 9-121 Test 9-12	Removal 9-295	Repair or Replacement
Troubleshooting 9-293 Power Control - Torque Tube Assembly F 4-17 Power Controls 4-99 Droop Compensator N2 F 4-20 Gas Poducer N1 F 4-19 Inspection (Acceptance/Rejection Criteria) 4-101 Installation 4-103 Removal 4-108 Troubleshooting 4-107 Power Plant 4-2 Build-up 4-7 Cleaning 4-5 Inspection Assembly for 1-21 Proximity Warning System 6-2 Wiring Diagram F 7-21 Proximity Warning System 6-2 Wiring Diagram F 7-30 Wiring Diagram F 7-30 Wiring Diagram F 7-30 Proximity Warning System 6-3 Wiring Diagram F 7-30 Wiring Diagram F 7-30 Proximity Warning System 6-3 Wiring Diagram F 7-30 Wiring D	Repair	Primary Directional Control Vulnerability
Power Control - Torque Tube Assembly F 4-17 Power Controls 4-99 Droop Compensator N2 F 4-20 Gas Poducer N1 F 4-19 Inspection (Acceptance/Rejection Criteria) 4-101 Installation 4-103 Removal 4-108 Troubleshooting 4-107 Power Plant 4-2 Build-up 4-7 Cleaning 4-5 Inspection Checks 4-8 Operational Checks 4-8 Operational Checks 4-7 Flyable Storage E-7 Intermediate Storage E-29 Short Term Storage E-15 Power Turbine Tachometer Generator 8-53  Prosetion Control Vulnerability Reduction System - Ty-7, 9-123 Primary Directional Control Vulnerability Reduction System - Ty-7 - Wiring Diagram - F F-30 Procedure Common to All Modes of Storage - Wiring Diagram - F -4 Proximity Warning System - F -11-21 Proximity Warning System - Wiring Diagram - F F-21 Proximity Warning System - Wiring Diagram - F F-39 Wiring Diagram - F F-39 Wiring Diagram - F F-39 Viring Diagram - F F-30 V	Testing 9-291	Reduction System (Electrical) C9-119
Power Controls4-99TroubleshootingT 9-7, 9-123Droop Compensator N2F 4-20Primary Directional Control VulnerabilityGas Poducer N1F 4-19Reduction System C - Wiring DiagramF F-30Inspection (Acceptance/Rejection Criteria)4-101Procedure Common to All ModesInstallation4-103Proper Handling of Control Assembly forRemoval4-108Proper Handling of Control Assembly forTroubleshooting4-107Proximity Warning SystemF F-21Power Plant4-2Wiring DiagramF F-21Euild-up4-7Wiring DiagramF F-21Cleaning4-5Proximity Warning SystemC -Inspection4-8Wiring DiagramF F-39Operational Checks4-6Pylon (Idler) LinkPower TrainInspection and Repair LimitsF 5-47Flyable StorageE-7Pylon Idler Link and Collar Set5-159Intermediate StorageE-29Cleaning5-163Short Term StorageE-15Inspect ion5-161Power Turbine Tachometer Generator8-53Inspection (Disassembly)5-164		Inspection 9-122
Droop Compensator N2 F 4-20 Gas Poducer N1 F 4-19 Inspection (Acceptance/Rejection Criteria) 4-101 Installation 4-103 Removal 4-108 Troubleshooting 4-107 Power Plant 4-2 Build-up 4-7 Cleaning 4-5 Inspection Checks 4-8 Operational Checks 4-8 Operational Checks 4-6 Power Train Flyable Storage E-7 Intermediate Storage E-7 Short Term Storage E-14 Primary Directional Control Vulnerability Reduction System - Wiring Diagram F F-30 Procedure Common to All Modes of Storage E-4 Proper Handling of Control Assembly for Installation/Storage/Shipping - F 11-21 Proximity Warning System - Wiring Diagram F F-21 Proximity Warning System - Wiring Diagram F F-39 Wiring Diagram F F-39 Pylon (Idler) Link Inspection and Repair Limits F 5-47 Pylon Idler Link and Collar Set 5-159 Inspect ion 5-163 Inspect ion 5-161 Inspection (Disassembly)5-164		
Gas Poducer N1F 4-19Reduction System C - Wiring DiagramF F-30Inspection (Acceptance/Rejection Criteria)4-101Procedure Common to All ModesInstallation4-103of StorageE-4Removal4-108Proper Handling of Control Assembly forTroubleshooting4-107Installation/Storage/ShippingF 11-21Power Plant4-2Proximity Warning SystemF F-21Build-up4-7Wiring DiagramF F-21Cleaning4-5Proximity Warning SystemF F-39Inspection4-8Wiring DiagramF F-39Operational Checks4-6Pylon (Idler) LinkPower TrainInspection and Repair LimitsF 5-47Flyable StorageE-7Pylon Idler Link and Collar Set.5-159Intermediate StorageE-29Cleaning.5-163Short Term StorageE-15Inspection.5-161Power Turbine Tachometer Generator.8-53Inspection (Disassembly)5-164		Troubleshooting
Inspection (Acceptance/Rejection Criteria) 4-101 Installation	· · · · · · · · · · · · · · · · · · ·	Primary Directional Control Vulnerability
Installation 4-103 Removal 4-108 Troubleshooting 4-107 Power Plant 4-2 Build-up 4-7 Cleaning 4-5 Inspection 4-8 Operational Checks 4-8 Proper Handling of Control Assembly for Installation/Storage/Shipping C F 11-21 Proximity Warning System A - Wiring Diagram F F-21 Proximity Warning System C - Wiring Diagram F F-39 Wiring Diagram F F-39 Operational Checks 4-6 Pylon (Idler) Link Inspection and Repair Limits F 5-47 Pylon Idler Link and Collar Set 5-159 Intermediate Storage E-29 Short Term Storage E-15 Power Turbine Tachometer Generator 8-53		Reduction System C - Wiring Diagram F F-30
Removal 4-108 Troubleshooting		
Troubleshooting		
Power Plant 4-2 Build-up 4-7 Cleaning 4-5 Inspection 4-8 Operational Checks 4-6 Power Train Flyable Storage E-7 Intermediate Storage E-29 Short Term Storage E-15 Proximity Warning System C- Wiring Diagram F-21 Wiring Diagram F-3 Viring Diagram F-3 Cleaning Inspection and Repair Limits F-3 Pylon Idler Link and Collar Set 5-159 Cleaning 5-163 Inspection Inspection (Disassembly) 5-164		
Build-up 4-7 Cleaning 4-5 Inspection 4-8 Operational Checks 4-6 Power Train Intermediate Storage E-29 Short Term Storage E-15 Power Turbine Tachometer Generator 8-53  Wiring Diagram F-21 Proximity Warning System C- Wiring Diagram F-21 Note C- Wiring Diagram F-21 Proximity Warning System C- Wiring Diagram F-21 Note C- Wiring Diagram F-21	· · · · · · · · · · · · · · · · · · ·	
Cleaning 4-5 Inspection 4-8 Operational Checks 4-6 Power Train 4-7 Flyable Storage E-7 Intermediate Storage E-7 Short Term Storage E-15 Power Turbine Tachometer Generator 8-53  Proximity Warning System Wiring Diagram. F F-39 Pylon (Idler) Link Inspection and Repair Limits F 5-47 Pylon Idler Link and Collar Set 5-159 Cleaning 5-163 Inspect ion 5-161 Inspection (Disassembly) 5-164		
Inspection4-8Wiring Diagram.F F-39Operational Checks4-6Pylon (Idler) LinkPower TrainInspection and Repair LimitsF 5-47Flyable Storage E-7Pylon Idler Link and Collar Set.5-159Intermediate Storage E-29Cleaning 5-163Short Term Storage E-15Inspect ion 5-161Power Turbine Tachometer Generator 8-53Inspection (Disassembly) 5-164	·	
Operational Checks		
Power TrainInspection and Repair LimitsF 5-47Flyable StorageE-7Pylon Idler Link and Collar Set.5-159Intermediate StorageE-29Cleaning.5-163Short Term StorageE-15Inspect ion.5-161Power Turbine Tachometer Generator.8-53Inspection (Disassembly)5-164		
Flyable Storage E-7 Intermediate Storage E-29 Short Term Storage E-15 Power Turbine Tachometer Generator8-53  Flyable Storage E-7 Pylon Idler Link and Collar Set 5-159 Cleaning 5-163 Inspect ion 5-161 Inspection (Disassembly) 5-164		
Intermediate StorageE-29Cleaning5-163Short Term StorageE-15Inspect ion5-161Power Turbine Tachometer Generator8-53Inspection (Disassembly)5-164		·
Short Term Storage		
Power Turbine Tachometer Generator8-53 Inspection (Disassembly)5-164		<u> </u>
Cleaning 8-55 Installation		
	Gleaning 8-55	Installation 5-166

Paragraph, Paragraph Figure, Table Figure, Table Number Number P (Cont) R (Cont) Pylon Idler Link and Collar Set (Cont) Recommended Standard Nut Torques . . . . . . . T 1-1 Refinishing-Main Rotor Blade (AVIM) . . . ..5-105 CS . . . . . . . . . . . . . . . . . . Refueling Receptacle . . . . . . . . . . . . . . . . F-3 Pylon Installation Bushing Wear Limits . . . . . . . . . . . . F 16-15 Pylon Isolation Mount Repair . . . . . . . . . . F 2-58 Removal Pylon Isolation Mount (PN 206-030-539-5 and -101) . . . . . . . . . F 2-59 Pylon Isolation Mount and Transmission Inspection (P/N 206-030-539-3) . F 2-57, 2-291, 2-294 Inspection (P/N 206-030-539-3 Armament Electrical System . . . . . . . . . . 9-381 Armament Subsystem M27E1 A . . . . . ...16-4 Pylon Support Link and Fitting . . . . . . . . . F 2-55 Q ATAS Missile System Fitting Assemblies R Attitude/Turn and Slip Indicator. . . . . . . . . . . . . . . 8-217 Auxiliary Power Receptacle (J120). . . . ...9-373 Avionics Compartment Door A C . . . . . . . . 2-76 Avionics Compartment Door CS . . . . ...2-76.1 Reading a Main Rotor Balance Chart with an Incorrect Clock Angle . . . . . . . . . F 5-88, 5-261 Reading the Tail Rotor Charts . . . . . F 5-89, 5-262 Reassembly Bearings - Freewheeling Assembly . . . . . . 6-60 Bellcranks, Levers and Walking Beams . ..11-115 Combustion Heater Ignition System . . . . ...13-64 Mixing Lever/Trunnion and Lever -Bolt and Blade Latch Retainer . . . . . . . . . . 5-58 Boost Pump Cartridge (Crashworthy). . . ...10-21 Breakaway Tip . . . . . . . . . . . . . . . . F 2-74, 2-379 Receptacle - Refueling . . . . . . . . . . . . . . . . F 1-3

Paragraph, Figure, Table Number

# R (Cont)

Removal (Cont)	Removal (Cont)
Brushes	
	Cyclic Button Switch
Cargo Platform	Cyclic Control Friction Adjuster
Channel	Cyclic Control Linkage
•	Cyclic Control Stick Assembly
Upper Cutter Assembly F 2-79	Cyclic Stick Balance Spring
Chip Detector Assembly - Tail Rotor	Cyclic Stick Grip
Gearbox (After Compliance with	Cyclic Stick Grip Assembly9-134
MWO 55-1520-228-50-25)	DC Ammeters
Chip Detectors	Defogging Blower Motors (B7 and B8)9-343
Chip Detectors, Tail Rotor Gearbox	Detent Button
(Prior to Compliance with MWO	Disc Assembly6-122,6-177
55-1 520-228-50-25)6-194	Door Assemblies 2-7
Chip Detectors - Transmission6-288	Door Seals
Clock	Doublers 2-356
Closed Circuit Refueling Receiver 10-32	Doublers A
Clutch Assembly - Freewheeling	Doublers and Saw Blade C F 2-77
Assembly 6-54	Drag Pin 6-79
Cockpit Lights	Dustand Moisture Boot
Collective Lever and Link Assembly 5-170	Ejector Rack F 16-10
Collective Pitch Linkage	Electronics Unit CS
Collective Sticks	Engine Anti-Icing Control
Combustion Heater Assembly	Engine Assembly 4-30
Combustion Heater Combustion	Engine Cowling 2-47
Air Pressure Switch	Engine Mount Fittings
Combustion Heater Combustion Blower13-88	Engine Mounts 2-305
Combustion Heater Fuel Filter 13-92	Engine Oil Pressure Indicator
Combustion Heater Fuel Pressure	Engine Oil Temperature Indicator
Relief Valve	Engine Oil Temperature Bulb,
Combustion Heater Fuel Pump	Engine Out Warning Switch 8-91
Combustion Heater Fuel Shutoff Valve13-102	External Power Receptacle 9-12
Combustion Heater Ignition Assembly 13-61	External Power Relay
Combustion Heater Plenum	Fault Annunciator Panel
Combustion Heater Support Bracket13-53	Filter 6-250
Combustion Heater Ventilation Air	Filter Bypass Valve
Blower13-104	Fire Extinguisher and Bracket 17-5
Common Electrical Components	First Aid Kit
Connecting Link Assembly 12-8	Fitting Assembly - Armament
Control Tube Assemblies - Tail Rotor	(Hard Points)2-220
Control C	Float Landing Gear
Control Tubes	Force Gradient Assembly
Controllable Landing Light	Forward and Aft Short Shafts
Cover Assembly - Bellcrank Stop	Forward Ballast A2-211
Crosstubes - High Landing Gear 3-66	Forward Ballast C2-212
Crosstubes - Standard Landing Gear3-27	Frame Assembly2-121
Cutter Blades (Lower) 2-335	Free Air Temperature Indicator
Cutter Blades (Upper)	(Thermometer)8-259
Cutter Blades (Upper and Lower) F 2-68	Freewheeling Assembly6-25

Paragraph, Figure, Table Number

R (Cont)

Removal (Cont)

D (00.0)	Removal (Cont)
Removal (Cont)	,
Fuel Boost Pump	IR/White (Dual) Landing/
Fuel Cell (Crashworthy Fuel System) 10-6	Searchlight
Fuel Filter Pressure Switch	Jackshaft
	Jettison Mechanism
Fuel Pressure Switch	Landing Gear Support Fittings 3-31, 2-317
Fuel Quantity Indicator	Landing Light Relays
Fuel Quantity Transmitters	Landing Lights
Fuel Shutoff Valve	Launcher Assembly F 16-7, 16-35
Gas Producer Tachometer Indicator 8-68	Lever
Gas Producer Tachometer Generator8-77	Light Flasher
Generator Fail Relay	Line Control Relay
Generator Shunt	Long Shaft
Governor Control Linear Actuator	Low Level Switch
Governor Control Switch 9-89	Low Level Switch (Crashworthy)
Grip Reservoirs and Sight Glass - Oil	Low Pressure Sensing Switch
Lubricated Main Rotor Hub 5-70	Lower Cutter Assembly F 2-73, 2-373
Grips, Main Rotor (AVIM) 5-16	Magnetic Brake
Ground Handling Trucks	Main Driveshaft
High Landing Gear	Main Rotor Assembly F 5-6, 5-8
Horizontal Stabilizer	Main Rotor Blade F 5-11, 5-100
Housing Assembly	Main Rotor Blade Bolt
Hub Strap/Pin/Fittings and Ring5-33	Main Rotor Pitch Horn Trunnion 5-94
Hydraulic Bypass Solenoid	Main Transmission
Hydraulic Check Valve	Map and Data Case
Hydraulic Filters	Mast Assembly
Hydraulic Hoses, Lines, and	Mounting Plate Bearing - Linear
Quick-Disconnects	Actuator
Hydraulic Pump	Nonessential Bus Relay
Hydraulic Relief Valve	NVG Position Lights
Hydraulic Reservoir	oil Cooler
Idler Link Assembly and Collar Set5-162	Oil Cooling Blower and Shaft
Ignition Switch	Assembly
impulse Cartridges CS F 16-6, 16-30	Oil Filter Head Assembly 6-234
Inertia Reel	Oil Nozzle (Jets)
Inertia Reel Strap	Oil Selector (Bypass) Valve
Inner Ring (AVIM)	Oil Tank
Input Pinion Housing Adapter and	Oil Transfer Tube 6-266
Seals (AVIM)	Outer Ring
Inspection Panels	particle separator
Instantaneous Vertical Speed indicator 8-190	passenger Seats
Instrument Panel, Shroud and Console 2-20	Passive Defense A
Instruments	Pillow Block - Main Rotor Yoke (AVIM) 5-79
Interface Electronics	Pillow Block Seal
Assembly CS 9-383.19	Pilot and Copilot Seats
Interface Electronics Assembly	Pilot and Copilot Seats
Mount Tray CS	Pilot Display Unit Mount
Inverter	Assembly CS

#### Paragraph, Figure, Table Number

,	
Removal (Cont)	
Pitch Horn, Main Rotor	5-26
Pitch Link Assembly	-155
Pitot Heater System9	-359
Pitot-Static Piping and Fittings	-152
Pitot Tube8	
Pivot Sleeve (AVIM) 5	-125
Pocket Assembly	2-154
Position Lights9	-295
Power Controls	-108
Power Controls - Control Cable	
Assembly 4	-102
Power Turbine Tachometer Generator	.8-59
Pressure Regulator Valve	-274
Pressure Switch	7-51
Pressure Switch	-251
Pylon Installation CS	6-39
Pylon Isolation Mount and Transmission	
Mount Supports	2-293
Pylon Supports	2-285
Ram Air Duct A	.16-9
Remote Sensor	3-15
Rod End Bearing	-104
Roll Staked Bearings (AVIM)	-129
Rotor Tachometer Generator	8-50
Sawblade, Cutter Deflector (Upper	
and Lower) F	2-67
Sawtooth Blades, Cutter Deflector	
(Upper) 2-	-326
Sawtooth Insert	-365
Sawtooth Insert/Channel Assembly	
Deflector Assembly A	2-72
Seal Foam Assembly2	
Seals, Freewheeling Housing	6-65
Seals, Main Driveshaft	6-19
Seat Belts2	-101
Second Accumulator	.4-14
Sensors, RPM	
Servoactuator Support	7-44
Servoactuators (Cyclic and	
Collective)	
Shaft Assembly, Freewheeling	6-38

Paragraph Figure, Table Number

# R (Cont)

D 1/0 )	Demond (Oct.)
Removal (Cont)	Removal (Cont)
Shear Link Terminal C	Tail Rotor Gearbox (After Compliance with
Shielded Ignition Lead Assembly 13-81	MWO 55-1520-228-50-25) F 6-36, 6-203
Shoulder Harness	Tail Rotor Gearbox (Prior to Compliance
Shunts and Bus Bars	with MWO 55-1520-228-50-25)
Sight Gage Oil Level Assembly 6-103	Tail Rotor Gearbox Input Seal (AVIM)6-212
Skid Shoe Assembly - High Landing	Tail Rotor Gearbox Output Seal 6-208
Gear 3-54	Tail Rotor Hub
Skid Shoe Assembly - Standard Landing	Tail Rotor Hub and Blade Assembly
Gear F 3-9, 3-20	(After Compliance with MWO
Skid Tubes - High Landing Gear	55-1 520-228-50-25) .,
Skid Tubes - Standard Landing Gear 3-13	Tail Rotor Hub and Blade Assembly
Solenoid	(Prior to Compliance with MWO
Solenoid Valve	55-1520-228-50-25)
Soundproofing Blankets	Tail Rotor Hub Trunnion
Spindle (Transmission) 6-109	Tail Rotor Pedal Assembly
Standard Landing Gear	Tail Rotor Pitch Change Mechanism5-208
Starter-Generator	Tail Rotor Pitch Horn
Starter Relay 9-218	Tail Skid
Starter Switch 9-223	Terminal Boards
Starter System	Torquemeter indicator
Static Stop - Main Rotor Hub	Transmission Fairing Assembly A
Stiffeners	Transmission Fairing Assembly C 2-40
Strut Assemblies (Lower)	Transmission Oil Pressure Indicator8-288
Strut Assembly (Upper and Lower) F 2-69	Transmission Oil Pressure Switch
Strut Assembly, Cutter Blades C F 2-78	Transmission Oil Pressure Transmitter 8-297
Strut Assembly, (Upper)	Transmission Oil Pump
Sump Valve (Crashworthy)	Transmission Oil Temperature
Support Assembly (Swashplate)5-149	Switch
Support, Taillight	Trunnion Bearing Inner Race
Swashplate and Support Assembly F 5-38, 5-114 Tachometer indicator	Trunnion - Main Rotor (AVIM) 5-43 Tube Assembly (Flexible) 2-234
Tailboom	Tube Assembly (Metal)
Tailboom <b>C</b>	Turbine Outlet Temperature (TOT)
Taillight <b>C.</b>	Indicator A8-125
Tail Rotor Blades (After Compliance with	Turbine Outlet Temperature (TOT)
MWO 55-1520-228-50-25)	Indicator C8-142
Tail Rotor Blades (Prior to Compliance with	Turn and Slip Indicator
MWO 55-1520-228-50-25)	Upper Cutter Assembly
Tail Rotor Control Linkage	Ventilating and Defogging Blower A 13-28
Tail Rotor Control Pedals and Adjuster11-107	Ventilating and Defogging Blower C 13-29
Tail Rotor Driveshaft (Prior to Compliance	Ventilating and Defogging Ducts 13-35
with MWO 55-1520-228-50-25) 6-116	Vertical Fin and Supports
Tail Rotor Driveshaft Cover	Vibrator
Tail Rotor Driveshaft Segment	Voltage Regulator
(After Compliance with MWO	Vulnerability Reduction Flight Control
55-1520-228-50-25)	System - Tail Rotor Control C11-134
, , , , , , , , , , , , , , , , , , , ,	

Paragraph, Figure, Table Number	Paragraph Figure, Table Number
R (Cont)	R (Cont)
Removal (Cont)	Panair (Cont)
Windshield Deflector Assembly	Repair (Cont)
Windshields and Windows	Control Tubes
Yoke/Shield - Main Rotor Hub 5-51	Controllable Landing Light
Removal and Disassembly - Mixing	Cover Assembly - Bellcrank Stop11-34
Lever/Trunnion and Lever -	Crosstube Supports
Cyclic Control Linkage	Crosstubes - High Landing Gear 3-67
Removal/Disassembly - Crosstubes -	Crosstubes - Standard Landing Gear 3-28
Standard Landing Gear 3-27	Cutter Blades (Upper and Lower)
Removal/Installation - Tail Rotor Hub	Cyclic Button Switch
and Blade Assembly F 5-72	Cyclic Control Friction Adjuster
Removal of Paint and Primer from	Cyclic Control Stick Assembly 11-46
Honeycomb Panels (AVIM)	Cyclic Stick Grip
Repair	Cyclic Stick Grip Assembly
Aft Fairing	DC Ammeters
Aft Fuselage Assembly (AVIM)	Defogging Blower Motors (B7 and B8)9-344
Aft Short Shaft	Detent Button
Aft Sway Brace and Step Assembly CS16-49	Disc Assembly
Air Duct Hose Assembly	Door Assemblies
Air Mixing Valve (AVIM)	Door Frame/Windshield Frame Assembly F 2-23.1
Airspeed Indicator	Door Frame/Windshield Frame Assembly 2-136.1
Altimeters	Doublers
Anticollision Lights	Drag Pin (AVIM)
Anti-Icing Lever	Drip Pan and Frame Assembly
Armament Electrical System	Dust and Moisture Boot
ATAS Control Panel CS	Engine
ATAS Control Parier CS	Engine Cowling
and Clevis CS	Engine Mount Fittings
ATAS Missile System CS16-51	Engine Oil Pressure Indicator 8-19
Attitude Indicator	Engine Oil Temperature Indicator
Attitude/Turn and Slip Indicator	Engine Oil Temperature Transmitter
Auxiliary Fuel Cell (AVIM)	Bulb
Auxiliary Power Receptacle (J120)9-374	Engine Out Warning Switch
Avionics Compartment Door	Fault Annunciator Panel (AVIM)
Avionics Compartment Floor	Firewall
Battery	Fitting Assembly - Armament
Beam, Upper Cabin Roof	(Hard Points)
Bearings - Freewheeling Assembly6-61	Fitting Assembly - Crosstubes -
Bleed Air Heater Plenum	Standard Landing Gear
Bleed Air Heater System	Float Landing Gear
Bleed Air Installation	Force Gradient Assembly
Bolt and Blade Latch Retainer 5-59	Forward and Aft Short Shafts 6-168
Breakaway Tip	Forward Fairing C F 2-12
Chip Detectors	Forward Short Shaft
Clutch Assembly - Freewheeling Assembly 6-55	Forward Sway Brace and Struts CS16-49
Cockpit Lights	Frame Assembly
Collective Lever and Link Assembly5-172	Free Air Temperature Indicator
Collective Sticks	(Thermometer)
Common Electrical Components	Freewheeling Assembly
Connecting Link Assembly 12-9	Fuel Cell Support
	Fuel Quantity Indicator
ndex 36 Change 1	Fuel Quantity Transmitters 8-246

Paragraph Figure, Table Number

R (Cont)	R (Cont)
Repair (Cont)	Repair (Cont)
Gas Producer Tachometer Indicator 8-69	Instantaneous Vertical Speed
Gas Producer Tachometer Generator8-78	Indicator
Governor Control Linear Actuator	Instruments
(AVIM)9-96	Interface Electronics Assembly
Grip Buffer Plate (AVIM)	Mount Tray CS
Grip Reservoirs and Sight Glass - Oil	Intersystem Oil Leakage
Lubricated Main Rotor Hub 5-72	Inverter
Grips, Main Rotor (AVIM) 5-20	IR/White (Dual) Landing/Searchlight9-275
High Landing Gear	Jettison Mechanism
Honeycomb Panel	Landing Gear Skid Tube Shoes F 3-14
Aft Lower Cabin Shell F 2-30	Landing Gear Support Fittings 3-35, 2-319
Forward Lower Cabin Shell F 2-29	Landing Light Relays9-266
Major Edge Damage	Landing Lights 9-260
Minor Edge Damage	Lever
	Long Shaft 6-156
Honeycomb Panels  Aft Fuel Cell Bulkhead F 2-35	Low Level Switch (Crashworthy) 10-28
Crew Seat and Bulkhead	Lower Cutter Assembly
Edge Damage	Magnetic Brake
Electrical Compartment Floor F 2-37	Magnetic Compass (Standby) 8-225
General	Main Rotor Assembly
Lower Aft Fuselage F 2-36	Main Rotor Blades (Corrosion) 5-102
Major Damage	Main Rotor Blades (Patching) (AVIM) 5-103
Minor Damage F 2-40	Main Rotor Blades Wear and
Oil Cooler Support	Grip Pads
Passenger Seat Structure	
Passenger Seatback Bulkhead F 2-32 Seatback Electrical Shelf F 2-34	Main Transmission
	Major Panel Damage
Upper Cabin Roof F 2-28  Vertical Fin	Mast Assembly (AVIM)
	Minor Panel Damage F 2-40, 2-183
Horizontal Stabilizer	Mixing Lever/Trunnion and Lever -
Housing Assembly (AVIM) 6-48	Cyclic Control Linkage
Hub Strap/Pin/Fittings and Ring5-35	Mounting Plate Bearing
Hydraulic Check Valve	Negligible Honeycomb Panel
Hydraulic Filters	Damage 2-180
Hydraulic Hoses, Lines, and	Oil Cooling Blower and Shaft
Quick-Disconnects	Assembly
Hydraulic Pump	Oil Selector (Bypass) Valve 4-89
Hydraulic Relief Valve	Oil Supply System Hoses, Fittings,
Hydraulic Reservoir	and Tubing
Idler Link Assembly and Collar	Oil Tank
Set	Oil Transfer Tube
Inertia Reel	Outer Ring
Infrared Exhaust System	Particle Separator
inner Ring (AVIM)	Passenger Entrance SCUFF
Input Pinion Housing Adapter	PLATES F 2-7, 2-11
and Seals (AVIM)	Passenger Seats
Instrument Panel, Shroud and	Passive Defense A
Console 2-21	

Pillow Block - Main Rotor

Pilot Display Unit Mount

Repair (Cont)

Paragraph Figure, Table Number Paragraph, Figure, Table Number

#### R (Cont)

#### Repair (Cont) Standard Exhaust System ...... . . . . ...4-59 Standard Landing Gear System . . . . . . . . . . . . . . . . 3-7 Support Assembly (Swashplate) . . . . . . . . . . . . . . . . 5-150 Swashplate and Support Assembly Switch Box Assembly - Collective Tailboom Attachment Fitting . . . . . . . . . F 2-45 Tail Rotor Blades (After Compliance with Tail Rotor Blades (Prior to Compliance with MWO 55-1520-228-50-25) F 5-80, 5-245 Tail Rotor Driveshaft (After Compliance with MWO 55-1520-228-50-25) . . . . . . ...6-160 Tail Rotor Driveshaft (Prior to Compliance with MWO 55-1520-228-50-25) . . . . . . ...6-117 Tail Rotor Gearbox (After Compliance with Tail Rotor Gearbox (Prior to Compliance with MWO 55-1520-228-50-25) F 6-31, 6-186 Tail Rotor Gearbox input Seal (AVIM) . . ...6-211 Tail Rotor Hub (After Compliance with Tail Rotor Hub (Prior to Compliance with MWO 55-1520-228-50-25) . . . . . . ...5-200 Tail Rotor installation Components . . . . . . . . . . . 5-185 Tail Rotor Pitch Change Mechanism . . ...5-212 Torquemeter Indicator . . . . . . . . . . . . 8-28, 8-42 Transmission Fairing Assembly A . . . . . . . 2-41

R (Cont)

Assembly CS	10-24
Pitch Horn, Main Rotor	5-29
Pitch Link Assembly	5-157
Pitot Heater System	9-360
Pitot-Static Piping and	
Fittings	8-153
Pitot Tube	
Pivot Sleeve (AVIM)	
Pocket Assembly	
Position Lights	
Power Turbine Tachometer Generator	
Pressure Switch	
Pressure Switch	
Pylon Isolation Mount	
Pylon Isolation Mount	2 00
(P/N 206-030-539-5 and-101)	F 2-59
Pylon Isolation Mount and	1 2 00
Transmission Mount Support	2-296
Ram Air Duct A	
Remote Sensor	
Rotor Tachometer Generator	
Sawtooth Blade, Cutter Deflector	
(Upper and Lower)	2-328
Seal Foam Assemblies	
Seals, Freewheeling Housing	
Seals, Main Driveshaft	
Second Accumulator	
Sensors, RPM	
Servoactuator Support	
Servoactuators (Cyclic and	,
Collective)	7-38
Shaft Assembly, Freewheeling	
Shielded ignition Lead Assembly	
Shunts and Bus Bars	
Sight Gage Oil Level Assembly	
Skid Shoe Assembly -High Landing	
Gear (AVIM)	3-55
Skid Shoe Assembly - Standard Landing	
Gear	3-21
Skid Tube Insertion	
Skid Tubes - High Landing Gear	
Skid Tubes - Standard Landing Gear	
Colorada Valva	7 00

Paragraph,

Figure, Table

Number

Number R (Cont) R (Cont) Repair of Landing Gear Skid Tube Repair (Cont) Shoes ..... F 3-14 Transmission Fairing Assembly C ...... 2-42 Repair or Replacement - Door Assemblies .. 2-10 Transmission Oil Pressure Indicator . . . ...8-289 Replacement Transmission Oil Pressure Transmitter ..... 8-298 Aluminum Wool - Tail Rotor Gearbox Trunnion - Main Rotor . . . . . . . . . . . . 5-41, 5-47 Cap Assembly . . . . . . . . . . . . . . . . . 6-224 Tube Assembly (Metal) . . . . . . . . . . . . . . . . . 2-229 Turbine Outlet Temperature (TOT) Indicator A . . . . . . . . . . . . 8-126 ATAS Missile System Fitting Assemblies Turbine Outlet Temperature (TOT) Turn and Slip Indicator ......8-200 Attitude/Turn and Slip Indicator . . . . . . . . 8-218 Auxiliary Power Receptacle (J120) . . . . . . . 9-374 Ventilating and Defogging Ducts . . . . . . . . . . 13-36 Vulnerability Reduction Flight Control System - Tail Rotor Control (AVIM) C......11-137 Window A ...... F 2-25 Windshield A..... F 2-23 Cyclic Button Switch .....9-144 Windshield Deflector Assembly . . . . . . . . . 2-363 Windshields and Cabin Roof Windows C ..... F 2-22 Defogging Blower Motors Yoke/Shield - Main Rotor Hub (AVIM) . ...5-53 Engine ..... 4-32 Repair Areas - Main Rotor Blades . . . . . . . F 5-34 Repair Dimensions - Main Rotor Blade Corrosion . . . . . . . . . . . . . . . . . F 5-33 Engine Oil Temperature Indicator . . . . . . . 8-104 Repair Limits Engine Out Warning Switch . . . . . . . . . . . . 8-92 Aft Vertical Fin Support . . . . . . . . . . . . . F 2-53 Forward Vertical Fin Support . . . . . . . . . . F 2-52 High Landing Gear Skid Tube . . . . . . . . . F 3-13 Fitting Assembly - Armament (Hard Points) . . . . . . . . . . . . . . . . . . 2-221 Standard Landing Gear -Cross Tube ...... F 3-4 Free Air Temperature Indicator Tail Rotor - Pitch Change Mechanism (Thermometer) .....8-260 Control Tube . . . . . . . . . . . . . . . . . . F 5-68 Tail Rotor - Pitch Change Mechanism Gas Producer Tachometer Indicator . . . . . . . 8-69 Housing and Trunnion . . . . . . . . . . . . F 5-66 Gas Producer Tachometer Generator . . . . . 8-78 Tail Rotor - Pitch Change Mechanism Tail Rotor - Pitch Change Mechanism Hydraulic Hoses, Lines, and Repair Material ...... T 2-1 Hydraulic Pump . . . . . . . . . . . . . . . . . 7-17

Paragraph

Figure, Table

Paragraph, Figure, Table Number

## R (Cont)

	D 1 (0 )
Replacement (Cont)	Replacement (Cont)
Hydraulic Relief Valve	Tail Rotor Gearbox Input Seal
Hydraulic Reservoir	(AVIM)
Idle Detent	Tail Rotor Gearbox Output
Idler Link Assembly and Collar	Seal
Set 5-165	Tail Rotor Gearbox Seal F 6-34
Input Seal, Tail Rotor Gearbox 6-189	Tail Rotor Gearbox Stud F 6-37
Instruments	Thermocouple Resistor
Intersystem Oil Leakage	Torquemeter indicator 8-38, 8-42
Inserter	Transmission Oil Pressure Indicator8-289
IR/White (Dual) Landing/Searchlight9-275	Transmission Oil Pressure Transmitter8-298
Jettison Mechanism	Turbine Outlet Temperature (TOT)
Low Level Switch (Crashworthy)	indicator A
Magnetic Brake	Turbine Outlet Temperature (TOT)
Main Rotor Hub Grip Seals	Indicator <b>C</b>
and Bearings F 5-12	Turn and Slip indicator
Mixing Lever/Trunnion and Lever -	Vulnerability Reduction Flight Control
Cyclic Control Linkage	SystemTail Rotor Control (AVIM) C .11-137
Mounting Plate Bearing	Window A
Oil Supply System Hoses, Fittings,	Windshield A F 2-23
and Tubing	Windshields and Cabin Roof
Output Seal, Tail Rotor Gearbox 6-188	Windows <b>C</b> F 2-22
Passive Defense A	Requirements - Storage
Pitot Heater System	Resistance Bulbs
Pitot-Static Piping and Fittings	Restraint Equipment
Power Turbine Tachometer Generator8-60	Re-Use of Self -Locking Nuts 1-26
Pressure Switch	Rework-Channel
Pressure Switch	Rework-Channel/Insert
Ram Air Duct A	Rework - Freewheeling Assembly -
Remote Sensor	Vent Assembly (AVIM)
Rotor Tachometer Generator	Rework Necessary if AN/ARC-51 is Mounted
Seals, Freewheeling Housing 6-66	to Bulkhead, Seal, Foam Assembly F 2-64
Seals, Main Driveshaft	Rework of Pivot Sleeve Assembly F 5-51
Second Accumulator	Rework-Sawtooth Insert
Sensors, RPM	
Shaft Assembly, Freewheeling	Rigging -Tail Rotor Control System
Shielded Ignition Lead Assembly13-83	(After MWO 55-1520-228-50-25)11-101
Sight Glass - Tail Rotor Gearbox6-222	Rigging Vulnerability Reduction Flight
Soundproofing Blankets	Control System - Tail Rotor
Spindle (Transmission)	Control
Stud - Tail Rotor Gearbox (AVIM)6-215	Right Front Door
Sump Valve (Crashworthy)	Rod End Bearing - Linear Actuator9-103
Tachometer Indicator	Installation
Tail Rotor Blade Bearing, F 5-81	Removal
Tail Rotor Control Linkage	Roll Staked Bearings
Tail Notor Control Ellinage	Inspection
	Installation
	Removal (AVIM)
	Rotor Blades - Cleaning
	Rotor System - Short Term Storage E-19

Paragraph Figure, Table Number

### R (Cont)

### S (Cont)

K (Colli)	3 (Colli)
Rotor Tachometer Generator       .8-44         Cleaning       8-46         Inspection       8-47         Installation       8-52         Removal       8-50         Repair or Replacement       .8-51         Testing       8-48         Testing       8-49    Sablade, Cutter Deflector	Sensor RPM       8-80, 9-172         Cleaning       8-82         Inspection       8-83         Installation       8-87         Removal       8-85         Repair or Replacement       8-86         Testing       8-84         Separator, Particle       F 4-7, 4-42         Serviceability Check       6-6         Servicing       F 1-1, 1-1         ATAS Launcher Coolant Bottle-       .1-14.1         Battery       1-13
(Upper and Lower)	Description
Seal Filler Assembly (Fire Suppressant	Engine Assembly
Foam Assemblies)	Engine Oil System
Seal Foam Assembly	Fuel System 1-5
Inspection 2-312	Fuel System (Rapid) Hot Refueling 1-6
Installation	Hydraulic System
Removal	Main Rotor Hub 1-9
Repair 2-313	Oil Lubricated Main Rotor Hub 1-9
Seals, Main Driveshaft 6-16	Tail Rotor Gearbox 1-11
Inspection 6-18	Tires 1-14
Installation 6-21	Servoactuators (Cyclic and Collective) 7-33
Removal 6-19	Cleaning
Repair or Replacement	Inspection
Seals, Freewheeling Housing 6-63	Installation F 7-8, 7-39
Inspection	Removal
Installation 6-67	Repair
Removal	Servoactuator Support
Repair or Replacement	Inspection (installed)
Seat Belts	Inspaction (Removal)
Inspection	Installation F 7-9, 7-47
Removal	Removal       7-44         Repair       7-43, 7-46
Seats and Restraint Installation F 2-13	Shaft Assembly, Freewheeling
Second Accumulator A	Inspection
Inspection A	Installation 6-40
Installation A	Removal
Removal A	Repair or Replace6-39
Repair or Replacement A 4-15	Shear Link Terminal C
Security	Inspection
Segmented Tail Rotor Driveshaft (After	Installation C11-144
Incorporation of MWO	Removal C
55-1520-228-50-25) F 6-25	Shielded Ignition Lead Assembly F 13-9, 13-77
Selector Valve Assembly (Engine Oil	Disassembly
System Bypass Valve) F 4-16	Inspection
Self-Locking Nuts. Re-Use of	Installation
	Operational Test

Paragraph, Figure, Table Number

## S (Cont) S (Cont)

Shielded Ignition Lead Assembly (Cont)	Inspection
Reassembly	Removal
Removal	Repair
Repair or Replacement	SkidShoeAssembly, Standard Landing Gear3-17
Shielded Lead Assembly F 13-9	Assembly
Shim Thickness	Inspection
Short Term Storage	Removal
Airframe	Repair
Avionics Equipment	SkidTube Insertion Repair(Typical)
Battery	Skid Tube Patch Repair (Typical)
Depreservation After	SkidTubes, High Landing Gear
Description	Acceptance/Rejection Criteria
Engine	Inspection
Fuel System	Installation/Reassembly
HydraulicSystem	Removal/Disassembly
inspection Prior to	Repair
Instruments	Skid Tubes, Standard Landing Gear
Landing Gear	Assembly
Main Rotor Blades	Cleaning
Maintenance of Preservation	Inspection
Power Train System	Removal
Shoulder Harness	Repair
Inspection	Sling Loading
Installation	Snow and Ice Removal
Removal	Solenoid Valve
Shroud and Console, InstrumentPanel2-16	Assembly
Shunts and Buss Bars	Cleaning
Inspection	•
Installation	Disassembly
Removal	installation
Repair	Removal
Sight Gage, Oil Level Assembly	Repair
Inspection	Test
Installation	
Removal	SoundproofingBlankets
Repair	Cleaning
SightGlass Replacement (After Compliance	Inspection
	Installation
with MWO 55-1520-228-50-25)	Removal
Sight Glass Replacement (Prior to Compliance	Repairer Replacement
with MWO 55-1520-228-50-25)	Special Drill Point for Drilling Plexiglas F 2-24
Single Interrupter Installation	Special Inspection (Inspection Requirements)1-50
Skid ShoeAlternate, Full Length F 3-9.1	Special Tools and Test Equipment T 1-3, 1-29
Skid ShoeAlternate, Full Length	Spherical OuterCoupling Spline Teeth
Cleaning	Inspection
Inspection	Spindle, Transmission
Removal	Inspection
Installation	Installation
Skid Shoe Assembly, High Landing Gear3-51	Removal
Assembly	Repair or Replacement

	Paragraph,		Paragraph,
	Figure, Table		Figure, Table
	Number		Number
S (Cont)		S (Cont)	
Standard Groups		Stud Replacement Limits (After Com	
Standard Landing Gear		with MWO 55-1520-228-50-25)	T 6-5
Cleaning	3-4	Stud Replacement Limits (Prior to	
Crosstube inspection Limits		Compliance with MWO	
Crosstubes		55-1520-228-50-26)	T 6-4
Fitting Assembly	F 3-3	Stud Tearout and Door Hinge -	
Inspection	3-5	Repair	F 2-6
Installation	3-8	Sump Valve - Crashworthy	10-34
Removal	3-6	Inspection	10-36, 10-39
Repair	3-7	Installation	
Skid Shoe Assembly	3-17	Removal	10-37
Skid Tubes	3-9	Repair or Replacement	10-38
Skid Tubes Repair Limits	F 3-4	Support Assembly (Swashplate)	5-146
Standards of Serviceability		Inspection	5-148
(Inspection Requirements)	1-48	Installation	5-151
Stater-Generator	F 9-5, 9-38	Removal	5-149
Cleaning	9-40	Repair	
Inspection	9-41	Support Equipment	T 1-4, 1-31
Installation	9-44	Support Pylon (Swashplate) - Inspec	tion
Removal	9-42	and Repair Limits	F 5-48
Repair (AVIM)	9-43	Support, Taillight	2-276
Starter-Generator and Tachometer		Inspection	2-278
Generator Mounting Pads	F 9-4	Installation	. F 2-54, 2-281
Starter-Generator Brush Wear	F 9-3	Removal	
Starter Relay	9-216	Repair	2-280
Inspection	9-217	Swashplate and Support Assembly	F 5-35,
Installation	9-219		F 5-39, 5-110
Removal	9-218	Adjustment	5-113
Starter Switch	9-220	Adjustment (AVIM)	5-120
Inspection	9-222	Assembly (AVIM)	5-119
Installation	· ·	Cleaning (AVIM)	
Removal		Disassembly (AVIM)	
Starter System		Inspection	
Cleaning		Inspection (AVIM)	
Inspection		Installation	
Installation		Limits Chart	
Removal		Repair (AVIM)	
Testing		Swashplate Friction Adjustment	F 5-37
Troubleshooting		Sway Braces and Struts (S)	
Static Stop, Main Rotor Hub		Assembly F 16-13,	
Inspection		Cleaning	
Installation		Damage Limits, Sway Braces	
Removal		Disassembly	
Repair		Inspection	
Static Vent		Maximum Strut Dimensions	
Cleaning, Inspection, and Repair		Nominal Strut Dimensions	
Station Diagram		Repair	16-49
Storage of helicopter		Switch Box Assembly U	F 9-16
Stowage - Copilot Cyclic Stick		Switch Box Assembly — Collective	
Strut Assemblies (Upper and Lower)		Control Stick	9-125
Removal	F 2-69	Assembly	9-130

Paragraph, Figure, Table Number

S (Cont) T (Cont)

Switch Box Assembly - Collective (Cont)	Tail Rotor Blade installation - Work Aid F 5-82
Disassembly	Tail Rotor Blades (After Compliance with
Inspection	MWO 55-1520-228-50-25)
Repair	Cleaning
Symbols	Inspection
System Bleeding - Engine Oil Pressure Indicator and	Installation
Torquemeter indicator	Removal
Torquomotor maioator	Repair
Т	Tail Rotor Blades (Prior to Compliance with MWO 55-
•	
Tachemeter Indicating Custom 0.20	1520-228-50-25)
Tachometer Indicating System	Cleaning
Testing	Inspection
Troubleshooting T 8-2, 8-34	Installation
Tachometer Indicator Systems A - Wiring	Painting
Diagram	Removal
Tachometer Indicator Systems C —	Repair (AVIM)
Wiring Diagram	Replacement
Tailboom	Tail Rotor Blade Rivet installation F 5-83.1
Damage Limits F 2-47, 2-247	Tail Rotor Control
Inspection	Balance Forces
Installation	Functional Check
Removal <b>C</b>	Tail Rotor Control Linkage
Repair	Inspection
Torque Requirement	Installation
Tailboom Assembly (MWO 55-1520-228-30-24	Removal
Accomplished)	Tail Rotor Control System F 11-12, 11-93
(MWO 55-1520-228-50-25 Accomplished) F 2-49	Adjustment (Rigging)
Tailboom Attachment Fitting Repair F 2-45	Troubleshooting T 11-3, 11-98
Taillight	Tail Rotor Controls Friction Adjustment
Cleaning	(After Compliance with MWO
Inspection	55-1520-228-50-25) F 11-16
Installation	Tail Rotor Control Rigging (After Compliance
Removal	with MWO 55-1520-228-50-25) F 11-15
Repair	Tail Rotor Control System Rigging (After
Testing	Compliance with MWO 55-1520-228-50-25) .11-101
Troubleshooting	Tail Rotor Driveshaft - Adjustment and
Taillight installation Support	Alignment
Tail Rotor	Tail Rotor Driveshaft (After Compliance with
Cleaning	· · · · · · · · · · · · · · · · · · ·
<del>-</del>	MWO 55-1520-228-50-25)
Inspection	Assemble
Removal/Installation	Cleaning
Troubleshooting	Disassemble
Tail, Rotor, Alignment and Balance (With Balance	Inspection/Repair
Wheels)	Installation
Tail Rotor Blade Bearing-Replacement F 5-81	Removal

Paragraph Figure, Table Number	Paragraph, Figure, Table Number
T (Cont)	T (Cont)
Tail Rotor Driveshaft (Prior to	Tail Rotor Gearbox - Output Seal
Compliance with MWO	Replacement (Cent)
55-1520-228-50-25)6-112	Removal (AVIM)
Inspection 6-115	Replacement
Installation 6-118	Tail Rotor Gearbox Stud Replacement
Lubrication 6-114	(Prior to Incorporation of MWO
Removal 6-116	55-1520-228-50-25)6-190
Repair	Tail Rotor Group - Intermediate
Tail Rotor Driveshaft Cover	Storage E-37
inspection	Tail Rotor Hub (After Compliance
Installation	with MWO 55-1520-228-50-25)
Removal	Assembly
Repair	Cleaning
Tail Rotor Gearbox (After Compliance	Disassembly
with MWO 55-1520-228-50-25) F 6-36, 6-199	Inspection
Cleaning	Repair
Inspection	with MWO 55-1520-228-50-25)
Installation	Assembly
Operational Check	Cleaning
Repair	Disassembly
Tail Rotor Gearbox (Prior to Compliance	Inspection
with MWO 55-1520-228-50-25)	Installation 5-203
Cleaning	Removal
Inspection	Rapair
Installation	Tail Rotor Hub and Blade Assembly
Removal 6-185	(After Compliance with
Repair	MWO 55-1520-228-50-25
Tail Rotor Gearbox	Assembly
Cap Assembly 6-223	Disassembly/Assembly F 5-3
Corrosion Removal and Repair	Disassembly
External Components F 6-33	Installation
Installation F 6-28	Removal
Mounting (After Incorporation of	Removal/installation F 5-72
MWO 55-1520-228-50-25) F 6-35	Tail Rotor Hub and Blade Assembly
Servicing 1-11	(Prior to Compliance with
Tail Rotor Gearbox Cap Assembly -	MWO 55-1520-228-50-25
	Assembly
Tail Rotor Gearbox Stud Replacement	Disassembly
(After Incorporation of MWO	Inspect ion
55-1520-228-50-25) F 6-37, 6-215	Installation (With Dynamic
Tail Rotor Gearbox - Input Seal Replacement	Balance Wheel)
Inspection/Repair	Installation (Without Balance
Installation	Wheel)
Removal (AVIM)	Removal
Replacement	Tail Rotor Hub and Blades -
Tail Rotor Gearbox - Output Seal Replacement	Disassembly
inspection/Repair	Tail Rotor Hub and Controls
Installation	

Paragraph, Paragraph, Figure, Table Figure, Table Number Number T (Cont) T (Cont) Tail Rotor Hub Bearing Liner -Inspection and Repair Limits . . . . . . . . . F 5-61 inspection and Repair Limits . . . . . . . . . F 5-63 Take Main Rotor Balance Readings . . . . . . . ... 5-283 Take Tail Rotor Balance Readings. . . . . . . . . . . . . . . . . . 5-281 Tail Rotor Hub Yoke -inspection and Repair Limits . . . . . . . . . . F 5-58 Tail Rotor Hub Wear Limits. . . . . . . . . . . . . . F 5-75 Tail Rotor Knurled Nut -Damage Limits . . . . . . . . . . . . . . . . . F 5-57 Test Tail Rotor Pitch Change Mechanism . . . . . . . . . . . . . . . . . . F 5-64, 5-204, 11-111 Test and Adjustment - Fuel Test Equipment and Special Tools . . . .. T 1-3, 1-29 Armament Electrical System Tail Rotor Pitch Control Pedal installation . . . . . . . . . . . . . . . F 11-13 Tail Rotor - Pitch Change Mechanism Control Tube - Repair Limits . . . . . . . . . F 5-68 Tail Rotor - Pitch Change Mechanism Battery and Generator System . . . . . . . . . 9-22 Housing and Trunnion -Caution and Warning Lights Tail Rotor - Pitch Change Mechanism idler Clevis - Repair Limits. . . . . . . . . . F 5-67 Caution and Warning Lights Tail Rotor-Pitch Change Mechanism Lever and Cap -Repair Limits. . . . . . . . . . F 5-65 Tail Rotor - Pitch Charge Mechanism Straight Pin - Wear Limits..... F 5-70 **Defogging Blower Motors** Dual Tachometer Indicating System . . . . . . . 8-33 Inspection and Repair Limits . . . . . . . . . F 5-71 Engine Oil Pressure Indicator . . . . . . . . . 8-16 Engine Oil Temperature Indicator . . . . . . . . . . . 8-102 Tail Rotor Spacer - Damage Limits . . . . . . F 5-55 Tail Rotor - Static Stop -Fault Annunciator ......9-323 Force Trim System ..... 9-117

Paragraph, Figure, Table Number

## T (Cont)

## T (Cont)

Testing (Cont)	Testing (Cont)
Free Air Temperature Indicator	Turbine Outlet Temperature
(Thermometer)8-258	(TOT) indicator A
Fuel Pump System	Turbine Outlet Temperature
Fuel Quantity Transmister	·
Gas Producer Tachometer	(TOT) Indicator q8-140
	Turbine Outlet Temperature System 8-117
Generator A8-75	Turn and Slip Indicator8-198
Gas Producer Tachometer	Vulnerability Reduction Flight Control
Generator C	System — Tail Rotor Control C11-139
Gas Producer Tachometer	Thermocouple Resistor A8-128
Indicator (N1)	Adjustment/Replacement
Governor Control Linear Actuator 9-98	Installation
Governor Control System	Tip Targets installation
Hydraulic Control System	Tires, Servicing 1-14
Hydraulic System With Hydraulic	Tools and Test Equipment
Test Stand	Tools and Test Equipment
Hydraulic System With Transmission-	Requirements
Driven Pump 7-8	Torquemeter indicator
Ignition System	Cleaning
Instruments 8-9	Inspect ion 8-24
Interior Lights System	Installation 8-29
Inverter	Removal 8-27
Landing Lights 9-257	Repair or Replacement
Low Level Switch (Crashworthy) 10-26	Test 8-25
Night Vision Goggles (NVG) System9-387	Troubleshooting 8-26
NVG Position Lights	Torque Procedures and Requirements 1-25
Pitot Heater System9-357	Torque Requirement - Tailboom
Position_Lights 9-291	Torsion-Tension Strap F 5-16
Power Turbine Tachometer	Touch-Up, Painting
Generator q 8-57	Tow Ring Doubler Plate
Power Turbine Tachometer	Tow Ring Repair F 3-7
Generator q8-58	Towing
Primary Directional Control Vulnerability	Tracking and Balancing Rotor Blades
Reduction System (Electrical)	and Troubleshooting Other Rotating
Rotor Tachometer Generator A	Elements Using the VIBREX 4591
Rotor Tachometer Generator C	System
Sensors, RPM 8-84	Transmission External Components F 6-40
Starter System 9-211	Transmission Fairing Assembly 2-36
Tachometer Indicator	Inspection 2-38
Taillight 9-304	Installation 2-43
Torquemeter indicator	Removal A 2-39
Transmission Oil Pressure	Removal C 2-40
Inclicating System	Repair A 2-41
Transmission Oil Pressure Indicator8-286	Repair C 2-42
Transmission Oil Pressure	Transmission Mount Support and
Transmitter 8-295	Access F 2-60
Turbine Outlet Temperature	Transmission Oil Level Indicator
indicating System C8-134	Inspection

Number T (Cont) T (Cont) Troubleshooting (Cont) Transmission Oil Pressure Indicating Testing ...... 8-280 Armament Electrical System CS . . . . . . . T 9-18.1, Troubleshooting . . . . . . . . . . . . . . . . . . T 8-19, 8-281 9-383.5 Transmission Oil Pressure Indicating Attitude Indicator . . . . . . . . . . . . . T 8-15, 8-207 System C - Wiring Diagram . . . . . . . . . F F-33 Attitude/Turn and Slip Transmission Oil Pressure Battery and Generator System . . . . . T 9-2, 9-23 Inspection ...... 8-285 Combustion Heater System . . . . . T 13-3, 13-42 Troubeshooting ...... 8-287 Controllable Landing Light C .... T 9-16,9-279 Transmission Oil Pressure Switch ...... 8-277, 9-169 DC Ammeter . . . . . . . . . . . . . . . . . T 8-18, 8-272 Inspection ...... 9-172 Defogging Blower Motors (B7 and B8) . ...9-342 Transmission Oil Pressure Engine Anti-Icing System . . . . . . . . . . . . . . . . . 12-4 Engine Oil Pressure Indicator . . . . . . T 8-1, 8-17 Inspection ...... 8-294 Engine Oil Temperature Transmitter Exterior Lights (After Compliance with MWO 55-1520-228-50-25) . . . . . . . T 9-14 Inspection ...... 6-229 External Power System . . . . . . . . . . . . T 9-1, 9-8 Force Trim System . . . . . . . . . . . . . . . . . T 9-6, 9-118 Servicing ...... 1-10 Fuel Quantity Indicator . . . . . . . T 8-17, 8-237 Transmission Oil System Schematic . . . . . . F 6-38 Transmission Oil Temperature Gas Producer Tachometer Indicator . . . . . . . 8-67 Removal . . . . . . . . . . . . . . . . . . 6-245, 9-156 Governor Control System . . . . . . . . . T 9-4, 9-85 Heating and Ventilating System . . .. T 13-1, 13-4 Hydraulic Control System . . . . . . . . T 9-5, 9-109 Treatment of Aluminum and Magnesium Alloy Corrosion . . . . . . . . . . . . . . . . . . 1-23 Troubleshooting 9-229 Instantaneous Vertical Speed Altimeters ...... T8-10, 8-180 

Paragraph,

Figure, Table

Paragraph,

Figure, Table

Number

Paragraph, Figure, Table Number

## T (Cont)

# T (Cont)

·	• •
Troubleshooting (Cont)	Trunnion Damage Limits F 5-78
Interior Lights 🛕 T 9-11, 9-242	Trunnion - Main Rotor
Interior Lights A T 9-11, 9-242 Interior Lights C T 9-12, 9-242	Adjustment (AVIM) 5-42
Inverter T 9-8, 9-203	Assembly (AVIM)
IR/White (Dual Landing/	Cleaning
Searchlight	Cleaning (AVIM) 5-45
Landing Lights T 9-13, T 9-16,	Disassembly (AVIM)5-44
9-258	Inspection 5-40
Line Control Relay	Inspection (AVIM)5-46
Main Rotor Assembly T 5-1, 5-5	Removal (AVIM) 5-43
Night Vision Goggles (NVG) System 9-388	Repair (AVIM) 5-47
NVG Position Lights9-294	Tube Assembly (Flexible) 2-231
Nonessential Bus Relay	Inspection 2-233
Pitot Heater System	Installation
Pitot-Static System8-147	Removal2-234
Position Lights	Repair
Primary Directional Control	Tube Assembly (Metal) 2-225, 4-10
Vulnerability Reduction System	Inspection 2-227
(Electrical)	Installation
Power Controls	Removal
Starter System	Repair
Tachometer Indicator	Turbine Outlet Temperature Indicating
Taillight9-305	System C8-132
Tail Rotor	Testing8-134
Tail Rotor Assembly	Troubleshooting8-135
Torquerneter indicator T 8-1, 8-26	Turbine Outlet Temperature
Transmission Oil Pressure Indicating	System A 8-115
System	Testing 8-117
Transmission Oil Pressure Indicator8-287	Troubleshooting
Transmission Oil Pressure Transmitter 8-296	Turbine Outlet Temperature (TOT) Indicator A 8-119
Turbine Outlet Temperature Indicating	Cleaning
system C 8-135	inspection 8-122
Turbine Outlet Temperature (TOT)	Installation 8-127
Indicator A	Removal
Turbine Outlet Temperature (TOT)	Repair or Replacement
Indicator C	Testing 8-123
Turbine Outlet Temperature System8-118	Troubleshooting8-124
Turn and Slip Indicator8-197	Turbine Outlet Temperature
VIBREX 4591 System with VIBREX	Indicator
Tester, Model 11	Cleaning
Vulnerability Reduction Flight Control	Inspect ion
System -Tail Rotor Control	Installation
Trucks, Ground Handling	Removal
Trunnion and Lever Assembly F 11-11	Repair or Replacement
Trunnion Bearing Inner Race -	Testing
Removal F 5-5	Troubleshooting
Trunnion Centering Shaft -	
Work Aid F 5-79	

Paragraph, Figure, Table Number	Paragraph, Figure, Table Number
T (Cont)	V (Cont)
Turn and Slip indicator A	Voltage Regulator      9-50         Adjustment      9-52         Inspection      9-53         Installation      9-56         Removal      9-54         Repair      9-55         Vulnerability Reduction Flight         Control System-Tail Rotor         Control C
Use of Maintenance Allocation Chart B-2 Using the VIBREX 4591	inspection <b>C</b>
v	Repair or Replacement C
Valve, Oil Selector (Bypass)4-81  Ventilating and Defogging Blower13-25 installation A	Troubleshooting <b>G</b>
Ventilating and Defogging Ducts	w
Removal	Wear and Damage Limits  Engine Mount
Brush Replacement       F 13-10         Installation      13-109         Removal      13-104         Repair      13-105	Wear Limits, Bushing CS F 16-15  Wear Limits - Tail Rotor -  Pitch Change Mechanism  Straight Pin
Vertical Fin and Supports       .2-264         Inspection       .2-266         Installation       .2-269         Removal       .2-267         Repair       .2-268	Tail Rotor Hub
Vertical Fin installation         F 2-51           Vertical Speed Indicator Tolerance         T 8-13           Vibrator         13-67           Inspection         13-69           Installation         13-72           Removal         13-70           Repair         13-71           Test         13-73           Vibrator Performance Chart         F 13-6	Inspection
VIBREX 4591 System Components and Carrying Case	Windshields and Cabin Roof Windows Replacement C

Paragraph Figure, Table Number

## W (Cont)

## W (Cont)

,	(5)
Wire Identification F-2	WSPS, Breakaway Tip (Lower Cutter
Wire Strike Protection System (WSPS)	Assembly) 2-376
Configuration A F 2-66	Inspection 2-378
Configuration C F 2-66	Removal
Wire Strike protection System	Repair
(WSPS) A 2-321	Installation
WSPS, Sawtooth Blades, Cutter	WSPS, Stiffeners (Lower Cutter)
Deflectors (Upper and Lower) 2-323	Inspection 2-384
Inspection (Upper and Lower)	Removal
Removal (Upper)	Repair
Removal (Lower)	Installation
Repair (Upper and Lower)	Wiring Data F-1
Installation (Upper)	Wiring Diagrams
Installation (Lower)	Armament System F F-16
WSPS, Cutter Blades (Upper and Lower)2-331	Audio Threshold System F F-22
Inspection (Upper end Lower)	Avionics Power A F F-17
Removal (Upper)	Caution and Warning Lights
Removal (Lower)	System A F F-12
	Caution and Warning Lights
Repair (Upper and Lower)	System C F F-34
installation (Upper)	Combustion Heater
WSPS, Strut Assemblies (Upper and	Controllable Landing Light
	(Prior to Compliance with
Lower)	MWO 55-1520-228-50-25) F F-40
Inspection (Upper and Lower)	· · · · · · · · · · · · · · · · · · ·
Removal (Upper)	Crashworthy Fuel System A F F-18 Crashworthy Fuel System C F F-37
Removal (Lower)	
Repair	DC Power and Starter Systems A F F-8  DC Power and Starter Systems C F F-28
Installation (Upper)	
Installation (Lower)	Engine Auto Relight System A F F-20
WSPS, Upper Cutter Assembly	Engine Auto Relight System C F F-38
Inspection	Engine Oil and Turbine Outlet
Removal	Temperature Indicating Systems A F F-7
Repair	Engine Oil and Turbine Outlet
Installation	Temperature Indicating Systems C F F-30
WSPS, Doublers, Upper Cutter 2-353	Exterior Lights System A (Use
Inspection	for Rewired Lights)
Removal	Exterior NVG Position Light C F F-36
Repair	Force Trim and Hydraulic Control
Installation	Systems F F-11
WSPS, Windshield Deflector Assembly 2-359	Fuel Quantity Indicating System A F F-6
Inspaction 2-361	Fuel Quantity Indicating System C F F-26
Removal	Governor and Control Systems F F-9
Repair 2-363	Heating, Defogging Blower, and
Installation	Engine De-Icing Systems F F-10
WSPS, Lower Cutter Assembly 2-370	Interior Lights System A
Inspection 2-372	(After Compliance with
Removal 2-373	MWO 55-1520-228-50/22 NVG) F F-14
Repair	interior Lights System A F F-13
Installation	

Paragraph, Figure, Table Number

W (Cont)

### W (Cont)

Wiring Diagrams (Cont) Interior Lights System C	Work Aid for Fuel Pump Cartridge Removal
Reduction System C	Υ
Proximity Warning System C F-39  Tachometer Indicator Systems A F-5	Yoke Brinell Depth Inspection With Work Aid
Tachometer Indicator Systems C F-25  Transmission Oil Pressure Indicating  System C	Yoke Damage Limits F 5-77 Yoke - Main Rotor - Inspection and Repair Limits F 5-23 Yoke/Shield, Main Rotor Hub
Distribution	Z

By Order of the Secretary of the Army:

CARL E. VUONO General, United States Army Chief of Staff

Official:

WILLIAM J. MEEHAN II Brigadier General, United States Army The Adjutant General

**DISTRIBUTION:** 

To be distributed in accordance with DA Form 12-31 AVUM and AVIM Maintenance requirements for OH-58A and OH-58C Helicopters, Observation.

**♣** U.S. GOVERNMENT PRINTING OFFICE: 1989 654-127/87010

### RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



# SOMETHING WRONG WITH THIS PUBLICATION?

THEN. . JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL! FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

**PUBLICATION NUMBER** 

TM 55-1520-228-23-1

PUBLICATION DATE

PUBLICATION TITLE

28 Feb 1989

ARMY MODEL OH-58A AND OH-58C

85 500		OINT '4" :-	DE IT IS		
BE EXAC	PARA-	OINT WHE		IN THIS SPACE TELL AND WHAT SHOULD	WHAT IS WRONG
PAGE NO	PARA- GRAPH	NO	TABLE NO	AND WHAI SHOULD	DE DUNE ABOUT II:
			İ		
			į		•
		·			
			Ì		
		1	,		
	į	l	Į l		
	ł		l i		
	ł				
	]		]		
	1	]			
	1				
			}		
	1	ļ	1		
	•	ţ	1		
l	l	l	l		
	1		l	l	
	1.			1	
PRINTED	NAME GRAD	PE OR TITLE	AND TELEF	PHONE NUMBER	SIGN HERE
1					

1 Nov 80

\_ TEAR ALONG PERFORATED LINE \_

FILL IN YOUR UNITS ADDRESS
DEPARTMENT OF THE ARMY
OFFICIAL BUSINESS

COMMANDER
U.S. ARMY AVIATION AND TROOP COMMAND
ATTN: AMSAT-I-MP
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120-1798

FOLD BACK

## The Metric System and Equivalents

### Linear Measure

1 centimeter = 10 millimeters = .39 inch 1 decimeter = 10 centimeters = 3.94 inches 1 meter = 10 decimeters = 39.37 inches 1 dekameter = 10 meters = 32.8 feet 1 hectometer = 10 dekameters = 328.08 feet 1 kilometer = 10 hectometers = 3,280.8 feet

#### Weights

1 centigram = 10 milligrams = .15 grain 1 decigram = 10 centigrams = 1.54 grains 1 gram = 10 decigram = .035 ounce 1 dekagram = 10 grams = .35 ounce 1 hectogram = 10 dekagrams = 3.52 ounces 1 kilogram = 10 hectograms = 2.2 pounds 1 quintal = 100 kilograms = 220.46 pounds 1 metric ton = 10 quintals = 1.1 short tons

### Liquid Measure

1 centiliter = 10 milliters = .34 fl. ounce 1 deciliter = 10 centiliters = 3.38 fl. ounces 1 liter = 10 deciliters = 33.81 fl. ounces 1 dekaliter = 10 liters = 2.64 gallons 1 hectoliter = 10 dekaliters = 26.42 gallons 1 kiloliter = 10 hectoliters = 264.18 gallons

### Square Measure

1 sq. centimeter = 100 sq. millimeters = .155 sq. inch 1 sq. decimeter = 100 sq. centimeters = 15.5 sq. inches 1 sq. meter (centare) = 100 sq. decimeters = 10.76 sq. feet 1 sq. dekameter (are) = 100 sq. meters = 1,076.4 sq. feet 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47 acres 1 sq. kilometer = 100 sq. hectometers = .386 sq. mile

### Cubic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

# **Approximate Conversion Factors**

To change	To	Multiply by	To change	To	Multiply by
inches	centimeters	2.540	ounce-inches	newton-meters	.007062
feet	meters	.305	centimeters	inches	.394
yards	meters	.914	meters	feet	3.280
miles	kilometers	1.609	meters	yards	1.094
square inches	square centimeters	6.451	kilometers	miles	.621
square feet	square meters	.093	square centimeters	square inches	.155
square yards	square meters	.836	square meters	square feet	10.764
square miles	square kilometers	2.590	square meters	square yards	1.196
acres	square hectometers	.405	square kilometers	square miles	.386
cubic feet	cubic meters	.028	square hectometers	acres	2,471
cubic yards	cubic meters	.765	cubic meters	cubic feet	35.315
fluid ounces	milliliters	29,573	cubic meters	cubic yards	1.308
pints	liters	.473	milliliters	fluid ounces	.034
quarts	liters	.946	liters	pints	2.113
gallons	liters	3.785	liters	quarts	1.057
ounces	grams	28.349	liters	gallons	.264
pounds	kilograms	.454	grams	ounces	.035
short tons	metric tons	.907	kilograms	pounds	2.205
pound-feet	newton-meters	1.356	metric tons	short tons	1.102
pound-inches	newton-meters	.11296		4	

# Temperature (Exact)

۰F	Fahrenheit
	temperature

PIN: 035016-000