

OH-58D...

Add & Change Skids & Shoes


Dear Windy,

Help me pass the word on a TM change the field needs to know about. Here's how it goes.

ADD: There's a new 1-piece, heavy-duty skid shoe, NSN 1630-01-301-0945, available as an alternative to the old 3-piece shoe. Use the heavy-duty shoe if you're wearing through the old shoes and damaging the tubes.

To attach the new shoe, follow Task 3-1-10.1 in TM 55-1520-248-23. The shoe NSN will be added to your -23P manual soon.

Mike Sisco
AVSCOM



AND HERE'S ANOTHER CHANGE: THE NSNs FOR YOUR SKID TUBES IN FIG 61 OF TM 55-1520-248-23P ARE NO GOOD.

USE NSN 1620-01-297-1038 TO GET THE LEFT SKID TUBE AND NSN 1620-01-299-1731 TO GET THE RIGHT.