

CONSOLE CAPER

Disconnecting some cockpit console components in the OH-58A?

Fine, bird-mech—but while you're working in the terminal-strip area behind the console, be careful not to hit the terminal-strip plug-in connectors.

If a plug is jarred loose in its receptacle, the transmission and receiving audio could be knocked out.

If you do happen to nudge a connector, give it a friendly push to make things right.

