



It doesn't take much to break a door hinge angle bracket on your OH-58A/C. A gust of wind or rotorwash will do it if the doors are open. To head off sidelining your baby for repairs, always close those doors when you exit the aircraft.