




OH-58 ...


Controlling Grease

HERE'S ONE WAY TO CUT CLEAN-UP TIME WHEN YOU LUBE THE OH-58'S HEAD.


Instead of letting excess grease ooze out the grease relief fitting and get all over the top of the head, do this:



- Punch a hole in the bottom of a small Styrofoam cup. The hole should be the size of the relief fitting.



- Set the cup over the fitting.



- Pump grease into the head fitting on the grip. Excess grease coming out the relief fitting goes into the cup.

THEN — WIPE OFF THE FITTING.
NO MORE MESSY CLEAN UP!

