

NO MURPHY, PLEASE!

Watch your step, bird mechs, when you change the hydraulic pump in the flight control system.

The check valve in the pump will fit in bassackwards, in which case you'll get excessive pressure build up and pump failure in a matter of hours.

Look for an arrow on the valve

which must point *up* for correct installation.

