

## For a Good Seal...



SARGE... I THINK YOU'D BETTER HAVE THOSE DOOR SEALS CHECKED!!

I FELT A SLIGHT PRAFT DURING THE FLIGHT!

?

If you've had problems with your OH-58 door seals coming unglued, here're some tips to keep 'em in place:

Remove the retainers and rivets. Discard the old seal and remove the old glue. Clean the area with a cloth dampened with toluene, and dry with a clean cloth.



Defective, drooping seals?

Remove old seal and clean area with toluene

Wear plastic gloves when handling toluene

Clean a new seal with a toluene-dampened cloth. Use 80-grit sandpaper to roughen the seal so the glue will stick better, and clean the seal again with toluene. Dry it with a clean cloth.

Brush cement, NSN 8040-01-084-3861, on the seal and doorframe. Let it dry for the time specified on the label.

Firmly press the seal into place. You can maintain pressure for an hour or so by closing the door on the seal.



When glue is dry, add the clips

After the glue dries, install the retainer clips with blind-type rivets.



FOR MORE INFO, CHECK OUT Para 2-8 THRU 2-10 IN TM 55-1520-228-23!